3 ARM Cortex-M4 Flow Control, Procedures, and Stack

Learning Objectives

- Implement conditional and unconditional branching using ARM branch instructions.
- Design and implement loops (for, while) using compare and branch instructions.
- Create and call procedures with proper parameter passing and return mechanisms.
- Manage the stack for local variables, parameter passing, and nested procedure calls.
- Apply the ARM Procedure Call Standard (AAPCS) for register usage and calling conventions.

Experiment Overview

This experiment explores program control flow, procedure implementation, and stack management in ARM Cortex-M4 assembly. You will learn to control program execution using branches and loops, create reusable code modules through procedures, and manage memory efficiently using the stack. You will:

- Implement various loop constructs and conditional statements in assembly.
- Write procedures that follow standard calling conventions.
- Handle nested procedure calls and parameter passing.
- Manage stack operations for local variables and return addresses.

After completing this experiment, you will understand how to use branches and loops in ARM assembly, write simple procedures that follow standard conventions, and manage the stack for function calls.

Contents

3	ARI	RM Cortex-M4 Flow Control, Procedures, and Stack			
	1	Theoretical Background			
		1.1	Flow Control Instructions		
			1.1.1	Branch Instructions	
			1.1.2	How Branch Instructions Work	
			1.1.3	Condition Codes	
		1.2	Loop In	$oxed{ injle} ext{plementation} \ldots \ldots \ldots \ldots \ \ \ \ \ \ \ \ \ \$	
			1.2.1	For Loop Structure	
			1.2.2	While Loop Structure	
		1.3	Procedu	ures (Subroutines)	
			1.3.1	Basic Structure	
			1.3.2	ARM Architecture Procedure Call Standard (AAPCS)	
		1.4	Stack M	Ianagement	
			1.4.1	Stack Operations	
			1.4.2	Nested Procedure Calls	
	2	Proce	edure		
		2.1	Exampl	es	
			2.1.1	Example 1: Array Example — Find Maximum Element	
			2.1.2	Example 2: String Example — Count Uppercase Letters	
			2.1.3	Example 3: Stack Example — Nested Uppercase Counter 10	
		2.2	Tasks		
			2.2.1	Task 1: Count Vowels in a String	
			2.2.2	Task 2: Factorial Calculation (Iterative)	
			2.2.3	Task 3: Factorial Calculation (Recursive)	

1 Theoretical Background

1.1 Flow Control Instructions

Flow control instructions alter the sequential execution of instructions by changing the program counter (PC). These instructions enable the implementation of conditional statements, loops, and procedure calls that are fundamental to structured programming.

1.1.1 Branch Instructions

Branch instructions are the primary mechanism for implementing flow control in ARM assembly. They modify the program counter to jump to different parts of the code based on conditions or unconditionally.

Instr. Description / Usage **Syntax** В B label Unconditional branch to label (always jumps) B<cond> B<cond> label Conditional branch based on flags BLBranch with link: calls a subroutine, storing return address in LR. BL label BXBX Rm Branch to address in register, often BX LR to return from a subroutine. CBZCBZ Rn, label Branch if Rn == 0. Example: CBZ RO, Done. CBNZ CBNZ Rn, label Branch if Rn != 0. Example: loop until counter reaches zero.

Table 3.1: ARM Cortex-M4 Branch Instructions

CBZ/CBNZ instructions have specific constraints:

- Register: operand must be a low register RO-R7.
- Range: branch is *forward-only*; the destination must be within 0–126 bytes after the instruction.
- Flags: does not update condition flags (N, Z, C, V).

For backward or longer jumps, use CMP/TST with conditional branches (BEQ, BNE, BGT, ...).

1.1.2 How Branch Instructions Work

Branch instructions change the flow of execution by modifying the Program Counter (PC). When a branch is executed, the instruction encodes an *offset* which is added to the current value of the PC.

Offset calculation: The branch instruction contains a signed immediate value (positive or negative). The processor adds this offset (aligned to halfword boundaries) to the current PC.

- A positive offset causes a **forward branch** (jump to a higher memory address, later in the program).
- A negative offset causes a backward branch (jump to a lower memory address, earlier in the program).

Example: Suppose a branch instruction is located at address 0x100, and the assembler encodes an immediate offset of -0x08. The effective target address will be:

$$0x100 + 4 + (-0x08) = 0xFC$$

This means the processor jumps **backward** to an earlier instruction. Such negative offsets are typically used to implement loops (e.g., repeat until zero).

1.1.3 Condition Codes

Conditional branches use condition codes that test the processor status flags (N, Z, C, V) set by previous instructions. These conditions enable implementation of high-level constructs like if-statements and loops.

Cond. Meaning Description Execute if Z = 1. EQEqual Execute if Z = 0. NENot equal CS/HS Execute if C = 1. Carry set / Unsigned higher or same CC/LO Carry clear / Unsigned lower Execute if C = 0. MIMinus (negative) Execute if N = 1. PLExecute if N = 0. Plus (non-negative) VSOverflow set Execute if V = 1. VCExecute if V = 0. Overflow clear $_{\rm HI}$ Unsigned higher Execute if C = 1 and Z = 0. LS Unsigned lower or same Execute if C = 0 or Z = 1. Execute if N = V. GEGreater or equal (signed)

Execute if $N \neq V$.

no condition).

V.

Execute if Z = 0 and N =

Execute if Z = 1 or $N \neq V$.

Always execute (default if

Reserved / do not use.

Table 3.2: Common ARM Condition Codes

1.2 Loop Implementation

LT

GT

LE

AL

NV

Less than (signed)

Greater than (signed)

Less or equal (signed)

Always

Never

Loops are fundamental control structures that repeat a block of code based on conditions. ARM assembly implements loops using combinations of compare instructions, conditional branches, and counters.

1.2.1 For Loop Structure

A typical for loop has the structure: initialization, condition check, body execution, and increment/decrement. This type of loop executes a known number of times.

```
AREA M_DATA, DATA, READONLY
array DCD 10, 20, 30, 40, 50 ; array of 5 integers
length EQU 5 ; number of elements (; just a constant, no memory)
```

Listing 3.1: Declaring Array and Length

```
; Initialization
        MOV
                RO, #0
                                         ; i = 0
                R1, #0
        MOV
                                         ; sum = 0
                R3, =array
                                         ; load base address of array into R3
        LDR
for_start
        ; Condition check
        CMP
                RO, #length
                                         ; compare i with length
        BGE
                for_end
                                         ; if i \ge length, exit loop
        ; Loop body
                R2, [R3, R0, LSL #2]
                                         ; load array[i]; EA: R3 + (R0 * 4)
        LDR
                                         ; sum += array[i]
        ADD
                R1, R1, R2
        ; Increment
        ADD
                RO, RO, #1
                                         ; i++
                for_start
                                         ; repeat
for end
```

Listing 3.2: For loop implementation pattern

1.2.2 While Loop Structure

While loops check the condition before executing the loop body, potentially executing zero times if the initial condition is false. This type of loop is useful when the number of iterations is not known in advance and depends on dynamic conditions.

```
AREA M_DATA, DATA, READONLY
mystring DCB "Hello World!", 0 ; null-terminated string
```

Listing 3.3: Declaring Null-Terminated String

Note: 0 and '0' are two different values, as the former is actually zero, while the latter is the ASCII code for the character '0' (which is 48 in decimal).

```
; Intialization
   LDR
            RO, =mystring
                           ; pointer to string
   MOV
            R1, #0
                            ; character\ count = 0
while_start
                            ; Condition check
    LDRB
            R2, [R0], #1
                            ; load current character and post-increment pointer
    CMP
            R2, #0
                            ; check for null terminator
    BEQ
            while_end
                            ; if zero, exit loop
                            ; Loop body - do something with R2
    В
            while_start
                            ; repeat
while_end
```

Listing 3.4: While loop with string processing example

1.3 Procedures (Subroutines)

Procedures are reusable blocks of code that encapsulate a specific task. They promote modular design, code reuse, and clearer program structure. In ARM assembly, procedures are implemented using branch-and-link instructions (BL, BLX) along with register usage conventions defined by the ARM Architecture Procedure Call Standard (AAPCS).

1.3.1 Basic Structure

A procedure is entered with a BL (branch-with-link) instruction, which stores the return address in the link register LR. The callee returns by branching to LR (e.g., BX LR). By the AAPCS, the first four arguments are passed in RO-R3 and the primary return value is placed in RO.

Example: simple procedure that expects two integers in R0 and R1 and returns their sum in R0.

```
AddTwo PROC
ADD RO, RO, R1 ; return RO+R1 in RO
BX LR
ENDP
```

Listing 3.5: Basic procedure structure

Note: The PROC and ENDP directives are assembler-specific and may vary between assemblers. They help define the start and end of a procedure for readability and organization and could be omitted if not supported.

1.3.2 ARM Architecture Procedure Call Standard (AAPCS)

The AAPCS is the set of rules that define how functions exchange data and how registers must be preserved during a procedure call:

- R0-R3: Hold the first four parameters. R0 also holds the return value. Caller-saved.
- Stack: Any additional parameters beyond the first four are passed on the stack.
- R4–R11: Must be preserved by the callee. If a procedure uses them, it must save and restore them.
- SP (R13): Stack pointer, always points to the current top of the stack.
- LR (R14): Link register holds the return address. Caller-saved.

Note: Callees are the procedures being called, while callers are the ones calling the procedure.

1.4 Stack Management

The stack is a memory region used to hold return addresses, local variables, and saved registers. On the Cortex-M4, the stack is implemented as a *full descending stack*: it grows from high memory addresses to low addresses, and the stack pointer (SP) always points to the last stored value.

Stack Terminology

- Full stack: The stack pointer (SP) points to the last used location. The memory at the address of SP contains valid data.
- Empty stack: The stack pointer (SP) points to the next free location. The memory at the address of SP is unused.
- Ascending stack: The stack grows toward higher memory addresses (not used in ARM Cortex-M).

• **Descending stack**: The stack grows toward lower memory addresses (the model used by ARM Cortex-M).

1.4.1 Stack Operations

The Cortex-M4 provides PUSH and POP instructions that automatically update the stack pointer (SP) and allow saving or restoring multiple registers in one instruction.

PUSH

- Format: PUSH {<reglist>}
- **Operation:** SP is decremented to create space, then the registers in <reglist> are stored on the stack.
- Storage order: Registers are always stored in ascending register number order, regardless of how they appear in the reglist. After the operation, the lowest numbered register is at the lowest memory address of the block, and the highest numbered register at the highest address. Example:

```
PUSH {R4, R0, R2, LR}
```

In memory (from lowest to highest address): R0, R2, R4, LR. The order in the curly braces does not matter.

- **Restriction:** The program counter (PC) cannot be pushed.
- Effect on SP: SP decreases by 4 bytes per register pushed.

POP

- Format: POP {<reglist>}
- Operation: Registers in <reglist> are restored from the stack, then SP is incremented.
- Load order: Registers are always loaded in ascending register number order, not in the order written.
- Example:

```
POP {R4, R0, R2}
```

Restores R0, then R2, then R4 (in register number order).

- **Special case:** If PC is included, the loaded value becomes the new program counter, effectively returning from the procedure.
- Effect on SP: SP increases by 4 bytes per register popped.

1.4.2 Nested Procedure Calls

When one procedure calls another, the link register (LR) must be preserved, otherwise the return address would be lost. This is done by pushing LR onto the stack before making another call.

```
OuterProc
        PUSH
                {LR}
                                 ; Save return address
        BI.
                InnerProc
                                 ; Call inner procedure
        MOV
                R1, RO
                                 ; Use return value
                {PC}
                                 ; Return to caller
        POP
InnerProc
                RO, #42
        MOV
                                  ; Return value
        BX
                LR
                                  ; Return
```

Listing 3.6: Nested procedure example

2 Procedure

2.1 Examples

2.1.1 Example 1: Array Example — Find Maximum Element

This example demonstrates how to find the maximum element in an array using a standard for loop structure.

```
RESET, CODE, READONLY
        AREA
        EXPORT
                __Vectors
__Vectors
        DCD
                0x20001000
                                    ; Initial SP
        DCD
                Reset_Handler
                                     ; Reset vector
        ALIGN
        AREA
                MYCODE, CODE, READONLY
        ENTRY
        EXPORT
               Reset_Handler
; Find maximum element in ARR[O..LEN-1]
; Result (max) is written to MAXRES.
Reset_Handler
        LDR
                RO, =ARR
                                    ; RO = \&ARR[O]
        MOV
                R1, #0
                                    ; R1 = i (index)
        LDR
                R2, [R0]
                                    ; R2 = max = ARR[0]
for_start
        CMP
                R1, #LEN
                                    ; i >= LEN ?
        BGE
                                     ; yes -> done
                for_end
                R3, [R0, R1, LSL #2]; R3 = ARR[i]
        LDR
                R3, R2
        CMP
                                    ; if ARR[i] > max
                R2, R3
                                    ; max = ARR[i]
        {\tt MOVGT}
                R1, R1, #1
                                    ; i++
        ADD
                for_start
for_end
        LDR
                R4, =MAXRES
                                    ; store result for easy checking
                R2, [R4]
        STR
                STOP
STOP
        В
        AREA
                CONSTANTS, DATA, READONLY
ARR
        DCD
                10, 20, 30, -5, 11, 0
LEN
        EQU
                MYDATA, DATA, READWRITE
        AREA
MAXRES
        DCD
                                    ; expect 30
        END
```

Listing 3.7: Find maximum element in an array

Check: Verify that the maximum element is correctly identified and stored in MAXRES.

2.1.2 Example 2: String Example — Count Uppercase Letters

This example demonstrates how to process a null-terminated string and count the number of uppercase letters (A-Z) using a while-loop structure.

```
RESET, CODE, READONLY
        EXPORT
                __Vectors
__Vectors
        DCD
                0x20001000
                                     ; Initial SP
        DCD
                Reset_Handler
                                     ; Reset vector
        ALIGN
                MYCODE, CODE, READONLY
        AREA
        ENTRY
        EXPORT Reset_Handler
; Count uppercase ASCII letters in the null-terminated string MYSTR.
; Result (count) is written to UPPERCOUNT.
Reset_Handler
        LDR
                RO, =MYSTR
                                    ; RO = ptr to string
        MOV
                R1, #0
                                     ; R1 = count
while_next
                R2, [R0], #1
                                     ; R2 = *p++; post-increment pointer
        LDRB
        CBZ
                R2, while_end
                                     ; if '\0' -> exit
                R2, #'A'
                                     ; below 'A'?
        CMP
                while_next
        BLT
        CMP
                R2, #'Z'
                                     ; above 'Z'?
        BGT
                while_next
                R1, R1, #1
        ADD
                                     ; count++
                while_next
        В
while_end
                R3, =UPPERCOUNT
        LDR
        STR
                R1, [R3]
STOP
                STOP
        AREA
                CONSTANTS, DATA, READONLY
MYSTR
                "Hello ARM World!", 0
        DCB
        AREA
                MYDATA, DATA, READWRITE
                                     ; expect 5 ('H', 'A', 'R', 'M', 'W')
UPPERCOUNT DCD 0
        END
```

Listing 3.8: Count uppercase letters in a string

Check: Verify that the program correctly counts the uppercase letters and stores the result in UPPERCOUNT.

2.1.3 Example 3: Stack Example — Nested Uppercase Counter

This example demonstrates a nested call: CountUpperNested(ptr) scans a null-terminated string and calls IsUpper(ch) for each character. It shows saving/restoring LR and using a callee-saved register (R4) for the running count.

```
AREA
                RESET, CODE, READONLY
        EXPORT
                __Vectors
__Vectors
                0x20001000
                                     ; Initial SP
        DCD
        DCD
                Reset Handler
                                     ; Reset vector
        ALIGN
        AREA
                MYCODE, CODE, READONLY
        ENTRY
        EXPORT Reset_Handler
; IsUpper(RO = ch) \rightarrow RO = 1 \ if \ 'A'...'Z', else O
IsUpper
                RO, #'A'
        CMP
                not_upper
        BLT
                RO, #'Z'
        CMP
        BGT
                not_upper
        MOV
                RO, #1
        BX
                LR
not_upper
                RO, #0
        MOV
        BX
                LR
; CountUpperNested(RO = ptr) -> RO = count of uppercase letters
CountUpperNested
                                     ; save callee-saved + return address
        PUSH
                {R4, LR}
        VOM
                R1, R0
                                     ; R1 = ptr (keep pointer here)
        MOV
                R4, #0
                                     ; R4 = count
cu_next
        LDRB
                RO, [R1], #1
                                    ; RO = *ptr++; post-increment pointer in R1
        CBZ
                RO, cu done
                                     ; if null terminator, finish
                                     ; RO = O/1 based on 'A'..'Z'
        BL
                IsUpper
                R4, R4, R0
        ADD
                                     ; count += result
                cu_next
cu_done
        MOV
                RO, R4
                                     ; return count in RO
        POP
                {R4, PC}
Reset_Handler
        LDR
                RO, =mystring
        BL
                CountUpperNested
                R2, =UPPERCOUNT
        LDR
                RO, [R2]
        STR
STOP
                STOP
        В
        AREA
                CONSTANTS, DATA, READONLY
mystring DCB
                "Hello ARM World!", O ; Uppercase: H, A, R, M, W -> 5
        AREA
                MYDATA, DATA, READWRITE
UPPERCOUNT DCD O
                                         ; should be 5
        END
```

Listing 3.9: Nested procedure call to count uppercase letters

Check: Verify that UPPERCOUNT contains 5 for the test string.

2.2 Tasks

2.2.1 Task 1: Count Vowels in a String

Implement procedures to process strings with the following requirements:

- Create a procedure CountVowels that takes a string pointer in R0 and returns the number of vowels (a, e, i, o, u) in R0.
- Use nested procedure calls where CountVowels calls a helper procedure IsVowel.
- Follow AAPCS conventions for parameter passing and register usage.

2.2.2 Task 2: Factorial Calculation (Iterative)

Implement a procedure to calculate the factorial of a non-negative integer:

- Create a procedure Factorial that takes a non-negative integer in R0 and returns its factorial in R0.
- Use an iterative approach with a loop to compute the factorial.
- Ensure proper handling of edge cases, such as 0! = 1.
- Follow AAPCS conventions for parameter passing and register usage.

2.2.3 Task 3: Factorial Calculation (Recursive)

Implement a recursive version of the factorial calculation:

- Create a procedure FactorialRec that takes a non-negative integer in R0 and returns its factorial in R0.
- Use recursion to compute the factorial, ensuring proper base case handling.
- Manage the stack appropriately to save and restore registers as needed.
- Follow AAPCS conventions for parameter passing and register usage.
- Test the procedure with various inputs to verify correctness.