# 2 ARM Cortex-M4 Instructions and Addressing Modes

# **Learning Objectives**

- Recognize the three main categories of ARM Cortex-M4 instructions: data processing, load/store, and branch.
- Perform arithmetic, logical, shift/rotate, and compare/test operations on registers.
- Access memory using load and store instructions with different addressing modes (immediate, register offset, pre-/post-indexed).
- Apply conditional execution using condition codes in the xPSR.
- Observe and interpret the effects of instructions on registers, memory, and status flags using the **Keil uVision5** debugger.

# **Experiment Overview**

This experiment introduces the core instruction set of the ARM Cortex-M4 processor. You will learn how to manipulate data in registers using arithmetic and logical instructions, how to transfer data between memory and registers using load/store instructions, and how to control program execution using condition codes and branches.

In the process, you will:

- Step through assembly instructions in the debugger and watch how registers and memory change.
- Observe how flags (Z, N, C, V) are updated and used for conditional execution.
- Practice pointer-style memory access through different addressing modes.

By the end of this lab, you will have gained practical experience in writing, executing, and debugging ARM Cortex-M4 assembly programs. These foundational skills in instruction-level programming, register manipulation, and memory access will serve as essential building blocks for subsequent experiments on flow control, interrupt handling, and peripheral interfacing.

# **Contents**

2 ARM Cortex-M4 Instructions and Addressing Modes				
	1	Theor	retical Background	3
		1.1	Data Processing Instructions	3
			1.1.1 Arithmetic Instructions	3
			1.1.2 Logical and Move Instructions	4
			1.1.3 Shift and Rotate Instructions	4
			1.1.4 Compare and Test Instructions	5
		1.2		5
		1.3	Branch Instructions and Condition Codes	6
		1.4		7
	2	Proce		9
		2.1		9
			2.1.1 Example 1 — Arithmetic and Bitwise Operations	9
			2.1.2 Example 2 — Status Flags and Logical Tests	
			2.1.3 Example 3 — Load/Store with Different Addressing Modes 1	
		2.2	Tasks	
			2.2.1 Task 1 — Bitwise Register Manipulation	2
			2.2.2 Task 2 — Arithmetic and Status Flags	
			2.2.3 Task 3 — Addressing Modes with an Array	

# 1 Theoretical Background

As mentioned in Experiment 1, assembly instruction are split into three main categories: data processing, load/store, and branch instructions. This experiment focuses on data processing instructions, load/store instructions and their addressing modes. While branch instructions would be covered in more detail in Experiment 3 (Flow Control), a brief overview is provided here for completeness.

## 1.1 Data Processing Instructions

Data processing instructions perform arithmetic and logical operations on data stored in registers. They can also manipulate the condition flags in the xPSR based on the results of the operations. Common data processing instructions take the following form:

#### OPCODE{<cond>}{S} Rd, Rn, Operand2

#### where:

- OPCODE: the operation to be performed (e.g., ADD, SUB, AND, ORR).
- <cond>: optional condition code that predicates execution.
- S: optional suffix indicating whether to update the condition flags.
- Rd: destination register where the result is stored.
- Rn: first operand register.
- Operand2: second operand, which can be an immediate value limited to 8 bits, a register, or a barrel shifter operation.

#### 1.1.1 Arithmetic Instructions

Arithmetic instructions perform basic mathematical operations. Some common arithmetic instructions include addition, subtraction, multiplication, and their variants. The following table summarizes some of the most commonly used arithmetic instructions in the ARM Cortex-M4 architecture.

Table 2.1: Common ARM Cortex-M4 Arithmetic Instructions

Instr.	Syntax	Operation	Description
ADD	ADD{S} Rd, Rn, Operand2	$Rd \leftarrow Rn + Operand2$	Operand2 may be a register, an immediate, or a shifted register.
ADC	ADC{S} Rd, Rn, Operand2	$Rd \leftarrow Rn + Operand2 + C$	Adds carry-in $C$ .
SUB	SUB{S} Rd, Rn, Operand2	$Rd \leftarrow Rn - Operand2$	Standard subtraction.
SBC	SBC{S} Rd, Rn, Operand2	$Rd \leftarrow Rn - Operand2 - (1 - C)$	Subtract with borrow (borrow encoded via carry flag $C$ ).
RSB	RSB{S} Rd, Rn, Operand2	$Rd \leftarrow Operand2 - Rn$	Reverse subtract.
MUL	MUL{S} Rd, Rn, Rm	$Rd \leftarrow (Rn \times Rm)_{[31:0]}$	$32 \times 32 \rightarrow \text{low } 32 \text{ bits.}$
MLA	MLA Rd, Rn, Rm, Ra	$Rd \leftarrow (Rn \times Rm) + Ra$	Multiply-accumulate.
MLS	MLS Rd, Rn, Rm, Ra	$Rd \leftarrow Ra - (Rn \times Rm)$	Multiply-subtract.
UMULL	UMULL RdLo, RdHi, Rn, Rm	$\{RdHi, RdLo\} \leftarrow Rn \times Rm$	Unsigned $32 \times 32 \rightarrow 64$ -bit product.
SMULL	SMULL RdLo, RdHi, Rn, Rm	$\{RdHi, RdLo\} \leftarrow Rn \times Rm$	Signed $32 \times 32 \rightarrow 64$ -bit product.

Note: C denotes the carry flag in xPSR. Operand2 may be an immediate or a shifted register depending on the encoding.

#### 1.1.2 Logical and Move Instructions

Logical instructions perform bitwise operations on data, while move instructions transfer data between registers or load immediate values. The following table summarizes some of the most commonly used logical and move instructions in the ARM Cortex-M4 architecture.

Table 2.2: Logical and Move Instructions

Instr.	Syntax	Operation	Description
AND	AND Rd, Rn, Operand2	$Rd \leftarrow Rn \& Operand2$	Bitwise AND.
ORR	ORR Rd, Rn, Operand2	$Rd \leftarrow Rn   Operand 2$	Bitwise OR.
EOR	EOR Rd, Rn, Operand2	$Rd \leftarrow Rn \oplus Operand2$	Bitwise XOR.
BIC	BIC Rd, Rn, Operand2	$Rd \leftarrow Rn \& \neg Operand 2$	Bit clear.
MVN	MVN Rd, Operand2	$Rd \leftarrow \neg Operand2$	Bitwise NOT of operand.
MOV	MOV Rd, Operand2	$Rd \leftarrow Operand2$	Register or immediate move.
MOVW	MOVW Rd, #imm16	$Rd[15:0] \leftarrow imm16$	Write low halfword.
MOVT	MOVT Rd, #imm16	$Rd[31:16] \leftarrow imm16$	Write high halfword (low preserved).

Note: C denotes the carry flag in xPSR. Operand2 may be an immediate or a shifted register depending on the encoding.

We will be using bitwise logical instructions extensively in this experiment to manipulate specific bits in registers from setting, clearing, and flipping certain bits, or checking if certain bits are set or cleared.

#### Setting and Clearing Bits

To set, clear, or toggle specific bits in a register, you can use the following logical instructions:

- ORR Rd, Rn, #mask: Sets bits in Rd where the corresponding bits in mask are 1.
- BIC Rd, Rn, #mask: Clears bits in Rd where the corresponding bits in mask are 1.
- EOR Rd, Rn, #mask: Toggles bits in Rd where the corresponding bits in mask are 1.

to check if certain bits are set or cleared, you can use the TST instruction:

• TST Rn, #mask: Performs a bitwise AND between Rn and mask, updating the condition flags based on the result. If the result is zero, the zero flag (Z) is set, indicating that none of the bits in mask are set in Rn.

#### 1.1.3 Shift and Rotate Instructions

Table 2.3: Shift and Rotate Instructions

Instr.	Syntax	Operation	Description
LSL	LSL Rd, Rm, #sh Rs	$Rd \leftarrow Rm \ll sh$	Logical left shift by immediate or by register.
LSR	LSR Rd, Rm, #sh Rs	$Rd \leftarrow Rm \gg sh$	Logical right shift (zero fill).
ASR	ASR Rd, Rm, #sh Rs	$Rd \leftarrow Rm \gg sh$	Arithmetic right shift (sign fill).
ROR	ROR Rd, Rm, #sh Rs	$Rd \leftarrow \text{ROR}(Rm, sh)$	Rotate right by immediate or by register.
RRX	RRX Rd, Rm	$Rd \leftarrow \text{ROR}_C(Rm, 1)$	Rotate right 1 bit through carry (uses $C$ as incoming
			bit 31, outgoing bit $0 \to C$ ).

Note: Shift amount can be an immediate #sh (0-31) or a register Rs (low 8 bits used). For immediates: LSL #0 = no shift; LSR #0 is treated as shift by 32; ASR #0 is treated as shift by 32; ROR #0 means RRX.

Not all shift/rotate instructions are explicitly present in the ARMv7-M ISA. For example, there is no ROL (rotate left) or ASL (arithmetic shift left) instruction, as these operations can be achieved using existing shift instructions: ROL can be implemented using ROR with a complementary shift amount, and ASL is equivalent to LSL.

#### 1.1.4 Compare and Test Instructions

Compare and test instructions are used to compare values and set condition flags without producing a direct result in a register. These instructions are useful for conditional execution and branching based on the results of comparisons. The following table summarizes the compare and test instructions in the ARM Cortex-M4 architecture.

Table 2.4: Compare and Test Instructions

Instr.	Syntax	Operation	Description
CMP	CMP Rn, Operand2	Flags from $(Rn - Operand2)$	Comparison; no register result.
CMN	CMN Rn, Operand2	Flags from $(Rn + Operand2)$	"Compare negative" (add then set flags).
TST	TST Rn, Operand2	Flags from $(Rn \& Operand 2)$	Bitwise test; no register result.
TEQ	TEQ Rn, Operand2	Flags from $(Rn \oplus Operand2)$	XOR test; no register result.

#### 1.2 Load and Store Instructions

Since the ARM Cortex-M4 architecture follows the RISC design philosophy, it uses a load/store architecture. This means that data processing instructions can only operate on data in registers, and any data in memory must first be loaded into a register before it can be processed. Similarly, results from data processing operations must be stored back to memory if they need to be preserved. The following table summarizes the load and store instructions in the ARM Cortex-M4 architecture.

Table 2.5: Load and Store Instructions (Summary)

Instr.	Syntax Example	Description
LDR / STR	LDR/STR Rt, [Rn, #off]	Load/store a 32-bit word.
LDRB / STRB	LDRB/STRB Rt, [Rn, #off]	Load/store an 8-bit byte.
LDRH / STRH	LDRH/STRH Rt, [Rn, #off]	Load/store a 16-bit halfword.
LDRSB / LDRSH	LDRSB/LDRSH Rt, [Rn, #off]	Load signed byte/halfword and sign-extend to 32 bits.
LDRD / STRD	LDRD/STRD Rt, Rt2, [Rn, #off]	Load/store a 64-bit doubleword (two registers).

- LDR Rt, =label is a *pseudo-instruction*. The assembler replaces it with code to load the address of label into Rt.
- LDR Rt, label (without =) loads the contents stored at label.

```
AREA
                MYDATA, DATA, READONLY
XVAL
        DCD
                0x12345678
                                   ; word in memory
YPTR
        DCD
                YVAL
                                   ; contains the address of YVAL
        AREA
                MYDATA2, DATA, READWRITE
YVAL
        DCD
        AREA
                MYCODE, CODE, READONLY
        ENTRY
        EXPORT
                Reset_Handler
Reset_Handler
                                   ; RO = &XVAL (address of XVAL)
                RO, =XVAL
        LDR
        LDR
                R1, [R0]
                                   ; R1 = 0x12345678 (load word from memory)
        LDRB
                R2, [R0]
                                   ; R2 = 0x78 (lowest byte of XVAL)
        LDRH
                R3, [R0]
                                   ; R3 = 0x5678 (lowest halfword of XVAL)
        MOV
                R4, #0xFF
        LDR
                RO, YPTR
                                   ; RO = contents of YPTR = &YVAL
                R4, [R0]
                                   ; store OxFF into YVAL (low byte only)
        STRB
STOP
        В
                STOP
        END
```

Listing 2.1: Examples of Load and Store Instructions

#### Note:

- The line YPTR DCD YVAL allocates a 32-bit word at the label YPTR and initializes it with the address of YVAL.
- Executing LDR RO, YPTR loads the contents of YPTR (the address of YVAL) into RO, making RO a pointer to YVAL.
- By contrast, LDR RO, =YVAL directly loads the address of YVAL into RO without going through memory.

Address	Label	Contents
0x2000	XVAL	0x12345678
0x2004	YPTR	0x2008 (address of YVAL)
0x2008	YVAL	0x00000000

#### 1.3 Branch Instructions and Condition Codes

Branch instructions change the flow of execution by jumping to a different part of the program. They can be unconditional or conditional based on the status flags in the xPSR. The following table summarizes the branch instructions in the ARM Cortex-M4 architecture.

Table 2.6: Branch Instructions

Instr.	Syntax Example	Description
В	B label	Unconditional branch to label.
B < cond >	B <cond> label</cond>	Conditional branch based on condition flags.
$\operatorname{BL}$	BL label	Branch with link (calls subroutine, saves return address in LR).
BX	BX Rm	Branch to address in register Rm (LR is usually used here).

Table 2.7: Condition Codes

Cond.	Meaning	Description
EQ	Equal	Z set (zero result)
NE	Not equal	Z clear (non-zero result)
CS/HS	Carry set / Unsigned higher or same	C set
CC/LO	Carry clear / Unsigned lower	C clear
MI	Minus / Negative	N set (negative result)
PL	Plus / Positive or zero	N clear
VS	Overflow set	V set
VC	Overflow clear	V clear
HI	Unsigned higher	C set and Z clear
LS	Unsigned lower or same	C clear or Z set
GE	Signed greater than or equal	N == V
$\operatorname{LT}$	Signed less than	N != V
GT	Signed greater than	Z clear and $N == V$
LE	Signed less than or equal	Z set or $N != V$
AL	Always	(unconditional)
NV	Never	(not used)

# 1.4 Addressing Modes

Addressing modes define how the effective address or operand value is obtained by an instruction. The ARM Cortex-M4 supports several common addressing modes, summarized below:

Table 2.8: General Addressing Modes in ARM Cortex-M4

Mode	Syntax Example	Description
Immediate	MOV RO, #10	Operand is a constant value encoded in the instruction.
Register Direct	MOV RO, R1	Operand is taken directly from a register.
Register Indirect	LDR RO, [R1]	Register holds the address of the operand in memory.
Register Offset	LDR RO, [R1, R2]	Effective address $=$ base register $+$ offset register.
Immediate Offset	LDR RO, [R1, #4]	Effective address $=$ base register $+$ constant offset.
Pre-indexed	LDR RO, [R1, #4]!	Base updated first, then memory access.
Post-indexed	LDR RO, [R1], #4	Memory access first, then base register updated.

Listing 2.2: Examples of Offset, Pre-indexed, and Post-indexed Addressing Modes

### 2 Procedure

#### 2.1 Examples

#### 2.1.1 Example 1 — Arithmetic and Bitwise Operations

This example demonstrates basic arithmetic and bitwise operations in ARM assembly, showing how to set, clear, and flip bits.

```
AREA RESET, CODE, READONLY
    EXPORT __Vectors
__Vectors
    DCD 0x20001000
    DCD Reset_Handler
    ALIGN
; Data section
NUM1 DCD 50
                          ; First integer
NUM2
                            ; Second integer
       DCD 12
       DCD RESULT
RP
                          ; Pointer to RESULT variable
    AREA MYDATA, DATA, READWRITE
RESULT DCD 0
                ; Will hold the final computed value
    AREA MYCODE, CODE, READONLY
    ENTRY
    EXPORT Reset_Handler
Reset_Handler
    ; Load values from memory into registers
    LDR R1, NUM1 ; R1 = 50
    LDR R2, NUM2
                           ; R2 = 12
    ; Perform arithmetic
    ADD R3, R1, R2
                            ; R3 = 50 + 12 = 62
                          ; R3 = 62 - 4 = 58
    SUB R3, R3, #4
    MUL R4, R3, R2
                          ; R4 = 58 * 12 = 696
    ; Logical operations
                       ; R5 = 696 & OxFF = OxB8 (184)
    AND R5, R4, #0xFF
   ORR R5, R5, #0x01 ; R5 = 0xB8 | 0x01 = 0xB9 (185)
BIC R5, R5, #0x08 ; R5 = 0xB9 & ~0x08 = 0xB1 (177)
EOR R5, R5, #0x02 : R5 = 0xB1 ^ 0x02 = 0xB3 (179)
                            ; R5 = 0xB1 ^0 0x02 = 0xB3 (179)
    EOR R5, R5, #0x02
    ; Store result in memory using a pointer
    LDR R6, RP ; R6 = address \ of \ RESULT
    STR R5, [R6]
                            ; RESULT = R5
    ; Read back for verification
                   ; R7 = RESULT
    LDR R7, [R6]
STOP B STOP
    END
```

Listing 2.3: Arithmetic and bitwise operations example

#### 2.1.2 Example 2 — Status Flags and Logical Tests

This example demonstrates the use of status flags and logical tests in ARM assembly, including conditional execution based on comparison results.

```
AREA RESET, CODE, READONLY
   EXPORT __Vectors
__Vectors
   DCD 0x20001000
   DCD Reset_Handler
   ALIGN
   AREA MYCODE, CODE, READONLY
   EXPORT Reset_Handler
Reset_Handler
   ; Set up registers
   MOVS RO, #10 ; RO = 10, updates flags (N=0, Z=0)
   MOVS R1, #10
                      ; R1 = 10, updates flags
   ; Compare RO and R1 using SUBS (RO - R1)
   SUBS R2, R0, R1 ; R2 = 10 - 10 = 0
    ; Flags after SUBS:
    ; Z=1 (result zero), N=0, C=1 (no borrow), V=0
    ; Compare with immediate using TST (bitwise AND, updates flags)
   MOV R3, #0x0F ; R3 = 0x0F (binary 00001111)
   TST R3, #0x08
                       ; Test bit 3
    ; Flags:
    ; Z=0 (bit 3 is set), N=0
   TST R3, #0x10
                 ; Test bit 4
    ; Flags:
    ; Z=1 (bit 4 not set), N=0
    ; Test equivalence using TEQ (bitwise XOR, updates flags)
   MOV R4, #0x55 ; 0x55 = 01010101b
                     ; same value
   MOV R5, #0x55
   TEQ R4, R5
                       ; R4 XOR R5 = 0
    ; Flags:
    ; Z=1 (equal), N=0
   MOV R6, \#0x33 ; 0x33 = 00110011b
   TEQ R4, R6
                      ; 0x55 \ XOR \ 0x33 \ != 0
    ; Flags:
    ; Z=0, N=0
    ; Negative result example with ADDS
                 ; R7 = 5
   MOVS R7, #5
                      ; R7 = 5 - 10 = -5 (two's complement)
   SUBS R7, R7, #10
   ; Flags:
    ; N=1 (negative), Z=0, C=0, V=0
STOP
     B STOP
   END
```

Listing 2.4: Status flags and logical tests example

#### 2.1.3 Example 3 — Load/Store with Different Addressing Modes

This example demonstrates load and store instructions using various addressing modes.

```
RESET, CODE, READONLY
       AREA
      EXPORT __Vectors
__Vectors
                           ; Initial SP (example)
             0x20001000
      DCD
      DCD
             Reset_Handler
                               ; Reset vector
             MYCODE, CODE, READONLY
       AREA
      ENTRY
      EXPORT Reset_Handler
Reset_Handler
       ; Base address of the array
           RO, =ARRAY ; RO = \&ARRAY
      LDR
       ; 1) Immediate Offset: EA = RO + #8 (third element)
             R1, [R0, #8] ; R1 = ARRAY[2] = ? (expect 30)
      LDR
      LDR
             R7, =OUT
                          ; OUT[O] = R1
            R1, [R7, #0]
      STR.
       ; -----
       ; 2) Pre-indexed: R2 = [R2 + #4], then R2 = R2 + #4
       ; Use a scratch pointer so RO remains the base.
       : -----
             R2, R0
                                ; R2 = &ARRAY
      MOV
             R3, [R2, #4]!
                                ; R2 -> &ARRAY[1], R3 = ARRAY[1] = ? (expect
      LDR
   20)
            R3, [R7, #4]
      STR.
                                ; OUT[1] = R3
       ; After this, R2 now points at ARRAY[1].
       ; 3) Post-indexed: R4 = [R4], then R4 = R4 + #12
          Load first element, then advance pointer to the 4th.
       ; -----
            R4, R0
                                 ; R4 = &ARRAY
      MOV
                                ; R5 = ARRAY[0] = ? (expect 10), R4 ->
      LDR
             R5, [R4], #12
   &ARRAY[3]
      STR
            R5, [R7, #8]
                                ; OUT[2] = R5
       ; 4) Register Offset: EA = RO + R6
       ; Offset register holds byte offset (multiple of 4 for words).
                            ; byte offset to ARRAY[3]
      VOM
             R6, #12
      LDR.
             R8, [R0, R6]
                                ; R8 = ARRAY[3] = ? (expect 40)
             R8, [R0, R6] ; KS = AKKAYL
R8, [R7, #12] ; OUT[3] = R8
      STR
       ; read second element via register offset
            R6, #4
                               ; byte offset to ARRAY[1]
      VOM
            R9, [R0, R6]
                                 ; R9 = ARRAY[1] = ? (expect 20)
      LDR
STOP
             STOP
             CONSTS, DATA, READONLY
      AREA
      DCD 10, 20, 30, 40 ; four words at consecutive addresses
ARRAY
      AREA MYDATA, DATA, READWRITE
OUT
      DCD 0, 0, 0, 0
                         ; capture buffer for observed loads. Could by
   replaced by space 16
      END
```

Listing 2.5: Load/store with different addressing modes example

#### 2.2 Tasks

#### 2.2.1 Task 1 — Bitwise Register Manipulation

Start with R0 = 0x12345678. Perform the following operations and observe the results in the debugger:

- Clear bits 4–7 (second hex nibble).
- Set bits 8–11 (force nibble to F).
- Toggle bits 28–31 (highest nibble).

Hint: Use BIC, ORR, and EOR with appropriate masks.

#### 2.2.2 Task 2 — Arithmetic and Status Flags

Assume initial values R0 = 25 and R1 = 10.

- Add R0 + R1, store the result in R2.
- Subtract R1 from R0, store the result in R3.
- Multiply RO and R1, store the result in R4.
- Compare R0 and R1 using CMP. If greater, set R5 = 1; otherwise, set R5 = 0.

Observe how the Z (zero) and N (negative) flags in the xPSR are affected.

#### 2.2.3 Task 3 — Addressing Modes with an Array

Given the following array:

```
ARRAY DCD 0x11, 0x22, 0x33, 0x44
```

Perform the following loads using different addressing modes:

- Load the first element (0x11) using immediate offset.
- Load the second element (0x22) using pre-indexed addressing.
- Load the third element (0x33) using post-indexed addressing.
- Load the fourth element (0x44) using a register offset (offset in another register).

Store each result into an output buffer OUT and verify the results in memory.