


2

1

B

B



A

A

### XY Frame Assembly



Created by:  
Joshua Vasquez


last edited:  
1/24/2020

SCALE: 1:3 SHEET 1 OF 29

2

1

This next process aligns the Inside-Corner Brackets to ensure a square frame.  
Using the temporary short extrusions, slide the top frame onto the completed Lower frame assembly.



B

B

**A** Tighten all Inside-Corner Brackets on the lower frame first to set their location. Then tighten the screws for all Inside-Corner Brackets attached to the upper frame.

With all set screws tightened, the Inside-Corner Bracket positions should be fixed on the upper and lower frames.

Now, loosen all set-screws connecting the red extrusions only and separate the frames, removing the red extrusions.

Set aside the lower frame.

#### Upper Bracket Alignment 1



Created by:  
Joshua Vasquez


last edited:  
1/24/2020

SCALE: 1:4

SHEET 2 OF 29



2

1



Exploded View

ITEM NO.	DESCRIPTION	QTY.
1	M3 18mm standoff, 6mm wide	2
2	Corner Pulley Reinforcement Plate	1
3	M4 shoulder screw, 20mm-l, 5mm-d	1
4	M3 Buttonhead Screw, 6mm long	2
5	M5 Shim, 0.2mm thick	2
6	20T Idler pulley, 2GT, 5mm bore	2



Assembled View

1


2

## Left Corner Pulley Assembly




Created by:  
Joshua Vasquez  
last edited:  
1/24/2020

SCALE: 1:1 SHEET 3 OF 29



Install this assembly upside-down such that the shim seats properly on the shoulder screw as the entire assembly is screwed in.



Keep these T-Nuts loose, only two full turns; they will be tightened into the frame later.

ITEM NO.	DESCRIPTION	QTY.
1	Left Corner Plate with Insert Installed	1
3	Left Corner Pulley Assembly	1
6	M3 Buttonhead Screw, 10mm long	2
7	M5 x 0.8 Screw, Low Profile. 20mm	3
10	M5 Drop-In T-Nut for 20x20 Extrusion	3

#### Left Corner Pulley Plate Assembly




Created by:  
Joshua Vasquez

last edited:  
1/24/2020


SCALE: 1:1 SHEET 4 OF 29

2


1



Top View



Note the plate orientation! Also note that this orientation is different from the prior pulley assembly.



ITEM NO.	DESCRIPTION	QTY.
1	M3 18mm standoff, 6mm wide	2
2	Corner Pulley Reinforcement Plate	1
3	M4 shoulder screw, 20mm-l, 5mm-d	1
4	M3 Buttonhead Screw, 6mm long	2
5	20T Idler pulley, 2GT, 5mm bore	2
6	M5 Shim, 0.2mm thick	2

2

1

Right Corner Pulley Assembly





Created by:  
Joshua Vasquez  
last edited:  
1/24/2020

SCALE: 1:1 SHEET 5 OF 29

2

1



B

B

ITEM NO.	DESCRIPTION	QTY.
1	Right Corner Plate with Insert Installed	1
3	Right Corner Pulley Assembly	1
5	M3 Buttonhead Screw, 10mm long	2
7	M5 x 0.8 Screw, Low Profile. 20mm	3
9	M5 Drop-In T-Nut for 20x20 Extrusion	3

2

1

#### Right Corner Pulley Plate Assembly



Created by:  
Joshua Vasquez


last edited:  
1/24/2020

SCALE: 1:1

SHEET 6 OF 29

2



1



2

1

1



### Left Crossbar Pulley Assembly



Created by:  
Joshua Vasquez  
last edited:  
1/24/2020

SCALE: 1:5      SHEET 8 OF 29

2


1

2


1

B

Note that this assembly is NOT merely a mirrored version of the previous one.  
Ensure that the pulleys are installed in the order shown.



Fully-tighten this assembly upside-down such that this shim seats properly on the shoulder screw and doesn't catch in the threads.



ITEM NO.	DESCRIPTION	
1	M3 18mm standoff, 6mm wide	1
2	Printed Pulley Spacer	2
3	M5 Shim, 0.2mm thick	2
4	M4 shoulder screw, 20mm-l, 5mm-d	2
5	Crossbar Pulley Reinforcement Plate	1
6	M3 Buttonhead Screw, 6mm long	1
7	M3 Buttonhead Screw, 10mm long	1
8	20T Idler pulley, 2GT, 5mm bore	1
9	20T toothless idler, 5mm bore	1
10		1

#### Right Crossbar Pulley Assembly



Created by:  
Joshua Vasquez

last edited:  
1/24/2020

SCALE: 1:5 SHEET 9 OF 29

2


1

B

A

2

1



Loosely install the rail with the screws and lock nuts such that the rail is snug but can slide around inside the holes from the screw clearances by hand. It will be tightened later.

B

B

ITEM NO.	DESCRIPTION	QTY.
8	M3 Buttonhead Screw, 12mm long	16
9	M3 Locknut	16
10	395mm long MGN12 rail	1
11	MGN12C Carriage Block	1
14		1

A

A

#### Crossbar Rail Installation



Created by:  
Joshua Vasquez  
last edited:  
1/24/2020


SCALE: 1:2 SHEET 10 OF 29

2

1


2

1




B


B



Top View



This limit switch should have wires attached to it (not shown in the rendering above).



Ensure that when the carriage is installed, it clears the crossbar on both sides. Otherwise, the carriage will bind when it slides back-and-forth.

**DETAIL C**  
SCALE 1 : 1

A

A

ITEM NO.	DESCRIPTION	QTY.
1	Crossbar Assembly	1
2	Carriage Center Assembly	1
3	M3 Buttonhead Screw, 8mm long	4

#### Carriage Center Installation



Created by:  
Joshua Vasquez  
last edited:  
1/24/2020

SCALE: 1:2 SHEET 11 OF 29



2

1

2

1

Make 2 Assemblies.



ITEM NO.	DESCRIPTION	QTY.
1	450mm long MGN12 rail	1
2	MGN12H Carriage Block	1
3	M3 Buttonhead Screw, 8mm long	6
4	M3 Drop-In T-Nut for 20x20 Extrusion	6

### Y Rail Assembly



Created by:  
Joshua Vasquez

last edited:  
1/24/2020

SCALE: 1:2



SHEET 12 OF 29

2

1

2

1



ITEM NO.	DESCRIPTION	QTY.
1	CoreXY Frame Assembly	1
2	Left Corner Pulley Plate Assembly	1
3	Right Corner Pulley Plate Assembly	1
4	Left Motor Plate Assembly	1
5	Right Motor Plate Assembly	1

Assembled View

## Plate Installation



Created by:  
Joshua Vasquez  
last edited:  
1/24/2020

SCALE: 1:4 SHEET 13 OF 29

2


1

2

1


B

B



The exact location of these four assemblies doesn't matter as we will dial them in upon first power-up.

Exploded View



Assembled View

A

A

ITEM NO.	DESCRIPTION	
1	CoreXY Frame Assembly	1
6	Adjustable Parking Post	2
7	Tool Cable Management Assembly	2

#### Tool Post Installation



Created by:  
Joshua Vasquez



last edited:  
1/24/2020

SCALE: 1:4


SHEET 14 OF 29

2

1



Install the Y rails snugly, but do not yet fully-tighten them.



DETAIL K  
SCALE 2 : 5

#### Y Rail Installation



Created by:  
Joshua Vasquez

last edited:  
1/24/2020

SCALE: 1:5


SHEET 15 OF 29

2

1

B

B



Install the Crossbar in the orientation shown above. Secure it with fasteners snugly, but do not fully tighten it.

A

A

ITEM NO.	DESCRIPTION	QTY.
1	CoreXY Frame Assembly with Y Rails	1
7	M3 Buttonhead Screw, 10mm long	8
8	Crossbar Assembly with Carriage Center	1

Crossbar Installation			
	Created by: Joshua Vasquez	last edited: 1/24/2020	
SCALE: 1:3		SHEET 16 OF 29	

2


1

2

1

B

B



Install the carriage back plate assembly with 4 screws.

A

A

ITEM NO.	DESCRIPTION	QTY.
1	CoreXY Frame with Carriage Center Assembly	1
7	M3 Buttonhead Screw, 10mm long	4
9	Carriage Back Plate Assembly	1

#### Carriage Back Installation



Created by:  
Joshua Vasquez  
last edited:  
1/24/2020


SCALE: 1:3 SHEET 17 OF 29

2

1

2



1



Install the remaining carriage items as shown.

Tip: start by inserting the twist-lock assembly.

Ensure that the twist-lock assembly is pushed all the way into the Carriage back plate.



A

A

ITEM NO.	DESCRIPTION	QTY.
9	Toolchanger Twist-Lock Assembly	1
10	Toolchanger Coupling Plate Assembly	1
12	M3 Flathead Screw, 16mm long	4
13	M5 Belleville Disc Spring	1
14	M5 Shim, 0.2mm thick	1
15	Toolchanger Pulley Assembly	1

#### Full Carriage Assembly




Created by:  
Joshua Vasquez  
last edited:  
1/24/2020

SCALE: 1:10 SHEET 18 OF 29


2

1

2





1



Center the 3mm dowel pin and tighten it with the setscrew.

B



Fasten down the pulley setscrew ensuring that it engages the flat part of the twist-lock shaft.

B

A

DETAIL H  
SCALE 1 : 1

#### Twist Lock Orientation Check



Created by:  
Joshua Vasquez

last edited:  
1/24/2020

SCALE: 1:10 SHEET 19 OF 29

2

1


2

1

Install the Lock Actuator in the temporary position shown below. This orientation makes subsequent wire-rope threading easier.

B

B



A

A

#### Lock Actuator Temporary Fixturing



Created by:  
Joshua Vasquez  
last edited:  
1/24/2020


SCALE: 1:3 SHEET 20 OF 29

2

1


2

Take 1600mm of wire rope and form a loop around the halfway point with your fingers.



1

Fasten the loop under the pulley's buttonhead screw. Note: you may need to unscrew it to fit it under the screw head.



Spool the corresponding loose ends through the two adjacent holes in the Carriage Back Plate.

Note: there should not be any twists. Each loose end should fit through the closest hole.

B

B

A

A

2

1

#### Carriage-Side Control Cable Installation



Created by:  
Joshua Vasquez

last edited:  
1/24/2020

SCALE: 1:10

SHEET 21 OF 29


2

1

Either zip-tie the two spring guides together at several points to create one bundle  
 OR  
 thread the spring guides into a length of nylon sleeving and heat-shrink the tips.

B

B



A

A

Thread the two loose ends through the entire length of both spring-guides until each spring guide seats into the back carriage coupler plate.

ITEM NO.	DESCRIPTION	QTY.
1	600mm Spring Guide	2

#### Carriage-Side Spring Guide Installation



Created by:  
 Joshua Vasquez  
 last edited:  
 1/24/2020

SCALE: 1:10 SHEET 22 OF 29

2

1



2

1


Continue threading each wire rope end into the Lock Actuator in the locations shown below. Firmly install the spring guide all the way into the hole until it reaches its hard stop.

B

B



Spring Guide A      Spring Guide B



DETAIL I  
SCALE 2 : 3

2

1

#### Lock Actuator Spring Guide Installation



Created by:  
Joshua Vasquez      last edited:  
1/24/2020

SCALE: 1:10      SHEET 23 OF 29

A

A

2

1


Center the lock actuator such that the cinch plates are approximately centered.

Loosen both cinch plates on the Lock Actuator. Loop each wire rope end into each corresponding cinch plate as shown below.

Take out all the slack and tighten both cinch plates gently. Keep the cinch plates loose enough such that tugging on the wire would cause them to slip. In the next step we will fasten them down in the proper alignment.

B

B



A

A

#### Lock Actuator Pulley Cinching



Created by:  
Joshua Vasquez


last edited:  
1/24/2020

SCALE: 1:10 SHEET 24 OF 29


2

1

2



Hold the carriage-side pulley in this configuration.



1

By hand, manually twist the pulley on the carriage until it is in the fully unlocked position as shown on the left.

Put one hand on the pulley to hold it in this position and prevent it from rotating.

B

B

With one hand on the carriage-side pulley, rotate the lock actuator pulley such that it is clicking the external switch. In this process, one wire rope should slip while the other one should stay under tension.

Now let go of the carriage side pulley. With a hex key, fully-tighten down both cinch plates such that the wire rope can no longer slip.

Note: you may need to rotate the Lock Actuator pulley to a neutral position to tighten down the cinch plates. This is fine, but ensure that the wire ropes do not slip any further in the process. If they do, restart this procedure from the last page.

A

A

#### Lock Actuator Tension Check



Created by:  
Joshua Vasquez

last edited:  
1/24/2020

SCALE: 1:10

SHEET 25 OF 29

2

1


2

1

Reinstall the lock actuator in the original position.

B

B



Ensure that the crossbar can slide up-and-down the Y-rail by hand, and then fully tighten all Y-rail screws.

A

A

#### Lock Actuator Final Installation



Created by:  
Joshua Vasquez

last edited:  
1/24/2020

SCALE: 1:3 SHEET 26 OF 29

2


1

Do this part on a table or other flat surface.

With two 1-2-3 blocks, align the loose x-rail with the carriages on the y-rails by pushing both blocks into the corners ensuring that both contacting faces of all parts are fully flush to the 1-2-3 blocks. Gently apply clamps to hold the blocks in this position. Fully-tighten all remaining loose screws in this configuration. When done, remove the blocks.

B

B



A

A

#### Crossbar Squaring




Created by:  
Joshua Vasquez      last edited:  
1/24/2020


SCALE: 1:3      SHEET 27 OF 29

2

1



Install the lower belt by following the pattern shown above and tightening both ends into the carriage. Only 4-5 timing belt teeth need to seat into the carriage, and the belt will feel extremely loose in this configuration. Then do the same for the upper belt pattern shown below.



ITEM NO.	DESCRIPTION	QTY.
1	CoreXY Frame	1
2	2GT Timing Belt, 6mm wide, 2300mm long	2

#### Belt Installation



Created by:  
Joshua Vasquez  
last edited:  
1/24/2020

SCALE: 1:4 SHEET 28 OF 29


2

1


2

1

First ensure both drive motors are loose and can slide back-and-forth in their slots when pushed by-hand. Then locate the tensioning setscrews on each sides of the motor corner plates.



These motor screws should be loose.



DETAIL J  
SCALE 2 : 3

Install the Gates Carbon Drive App to a smartphone. With your smartphone microphone near the belt and the app running, *pluck* the belt like a guitar string and measure the frequency. Gradually increase belt tension by tightening the setscrew until the measurements average 50Hz. Do this process in a quiet environment on both belts. When done, tighten down the motor screws.

A

B

Your XY Frame is complete!

Belt Tensioning		
	Created by: Joshua Vasquez	last edited: 1/24/2020
	SCALE: 1:10	SHEET 29 OF 29

2

1