AArch32 Instructions AArch64
Instructions

Index by Encoding External Registers

# PMINTENCLR\_EL1, Performance Monitors Interrupt Enable Clear Register

The PMINTENCLR EL1 characteristics are:

### **Purpose**

Disables the generation of interrupt requests or, when FEAT\_EBEP is implemented, PMU exceptions on overflows from the instruction counter, <a href="MICNTR\_EL0">PMICNTR\_EL0</a>, the cycle counter, <a href="MICNTR\_EL0">PMCCNTR\_EL0</a>, and the event counters <a href="MICNTR<">PMEVCNTR<<<a href="MICNTR\_EL0">PMEVCNTR<<<a href="MICNTR\_EL0">PMEVCNTR\_EL0</a>. Reading the register shows which overflow interrupt requests or PMU exceptions are enabled.

### **Configuration**

AArch64 System register PMINTENCLR\_EL1 bits [31:0] are architecturally mapped to AArch32 System register PMINTENCLR[31:0].

AArch64 System register PMINTENCLR\_EL1 bits [31:0] are architecturally mapped to External register PMU.PMINTENCLR\_EL1[31:0].

AArch64 System register PMINTENCLR\_EL1 bits [63:32] are architecturally mapped to External register <a href="MU.PMINTENCLR\_EL1[63:32">PMU.PMINTENCLR\_EL1[63:32]</a> when FEAT\_PMUv3p9 is implemented or FEAT PMUv3 EXT64 is implemented.

This register is present only when FEAT\_PMUv3 is implemented. Otherwise, direct accesses to PMINTENCLR\_EL1 are undefined.

## **Attributes**

PMINTENCLR\_EL1 is a 64-bit register.

## Field descriptions

63 62 61 60 59 58 57 56 55 54 53 52 51 50 49 48 47 46 45 44 43 42 41 40 39 38 37 36 RESO

C|P30|P29|P28|P27|P26|P25|P24|P23|P22|P21|P20|P19|P18|P17|P16|P15|P14|P13|P12|P11|P10|P9|P8|P7|P6|P5|P4|

31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4

Bits [63:33]

Reserved, res0.

### F<m>, bit [m+32], for m = 0 When FEAT\_PMUv3\_ICNTR is implemented:

Interrupt request or PMU exception on unsigned overflow of fixed-function counter <m> disable. On writes, allows software to disable the interrupt request or PMU exception on unsigned overflow of fixed-function counter <m>. On reads, returns the interrupt request or PMU exception on unsigned overflow of fixed-function counter <m> enable status.

F <m></m>	Meaning
0b0	Interrupt request or PMU exception on unsigned overflow of fixed-function counter <m> disabled.</m>
0b1	Interrupt request or PMU exception on unsigned overflow of fixed-function counter <m> enabled.</m>

PMINTENCLR EL1.F0 holds the enable status for **PMICNTR EL0**.

Accessing this field has the following behavior:

- This field reads-as-zero if all of the following are true:
  - Any of the following are true:
    - EL3 is implemented and  $\underline{SCR}$  EL3.FGTEn2 == 0.
    - HDFGRTR2 EL2.nPMICFILTR EL0 == 0.
  - FEAT FGT2 is implemented.
  - EL2 is implemented and enabled in the current Security state.
  - Accessed at EL1.
- This field reads-as-zero and ignores writes if any of the following are true:
  - All of the following are true:
    - EL3 is implemented.
    - MDCR EL3.EnPM2 == 0.
    - Accessed at EL2 or EL1.
- This field ignores writes if any of the following are true:
  - All of the following are true:
    - EL3 is implemented and <u>SCR\_EL3</u>.FGTEn2 == 0, or <u>HDFGWTR2\_EL2</u>.nPMICFILTR\_EL0 == 0.
    - FEAT FGT2 is implemented.
    - EL2 is implemented and enabled in the current Security state.
    - Accessed at EL1.
- Otherwise access to this field is W1C.

The reset behavior of this field is:

• On a Warm reset, this field resets to 0.

#### Otherwise:

Reserved, res0.

### C, bit [31]

Interrupt request or PMU exception on unsigned overflow of <a href="PMCCNTR\_EL0">PMCCNTR\_EL0</a> disable. On writes, allows software to disable the interrupt request or PMU exception on unsigned overflow of <a href="PMCCNTR\_EL0">PMCCNTR\_EL0</a>. On reads, returns the interrupt request or PMU exception on unsigned overflow of <a href="PMCCNTR\_EL0">PMCCNTR\_EL0</a> enable status.

С	Meaning
0b0	Interrupt request or PMU
	exception on unsigned overflow of
	PMCCNTR_ELO disabled.
0b1	Interrupt request or PMU
	exception on unsigned overflow of
	PMCCNTR_EL0 enabled.

Access to this field is W1C.

The reset behavior of this field is:

• On a Warm reset, this field resets to an architecturally unknown value.

### P < m >, bit [m], for m = 30 to 0

Interrupt request or PMU exception on unsigned overflow of <a href="PMEVCNTR<m>\_EL0">PMEVCNTR<m>\_EL0</a> disable. On writes, allows software to disable the interrupt request or PMU exception on unsigned overflow of <a href="PMEVCNTR<m>\_EL0">PMEVCNTR<m>\_EL0</a>. On reads, returns the interrupt request or PMU exception on unsigned overflow of <a href="PMEVCNTR<m>\_EL0">PMEVCNTR<m>\_EL0</a> enable status.

P <m></m>	Meaning
0b0	Interrupt request or PMU
	exception on unsigned overflow
	of PMEVCNTR <m>_EL0</m>
	disabled.
0b1	Interrupt request or PMU
	exception on unsigned overflow
	of PMEVCNTR <m> EL0</m>
	enabled.
-	

Accessing this field has the following behavior:

- This field reads-as-zero and ignores writes if any of the following are true:
  - All of the following are true:
    - EL2 is implemented and enabled in the current Security state.
    - $\blacksquare$  m >= UInt(MDCR EL2.HPMN).
    - Accessed at EL1.
  - $\circ$  m >= UInt(<u>PMCR EL0.N</u>).
- Otherwise access to this field is W1C.

The reset behavior of this field is:

• On a Warm reset, this field resets to an architecturally unknown value.

## **Accessing PMINTENCLR EL1**

Accesses to this register use the following encodings in the System register encoding space:

# MRS <Xt>, PMINTENCLR\_EL1

op0	op1	CRn	CRm	op2
0b11	0b000	0b1001	0b1110	0b010

```
if PSTATE.EL == ELO then
   UNDEFINED:
elsif PSTATE.EL == EL1 then
   if Halted() && HaveEL(EL3) && EDSCR.SDD == '1'
&& boolean IMPLEMENTATION_DEFINED "EL3 trap priority
when SDD == '1'" && MDCR EL3.TPM == '1' then
        UNDEFINED;
    elsif EL2Enabled() &&
IsFeatureImplemented(FEAT_FGT) && (!HaveEL(EL3)
SCR_EL3.FGTEn == '1') && HDFGRTR_EL2.PMINTEN == '1'
then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() && MDCR_EL2.TPM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif HaveEL(EL3) && MDCR_EL3.TPM == '1' then
        if Halted() && EDSCR.SDD == '1' then
            UNDEFINED;
        else
            AArch64.SystemAccessTrap(EL3, 0x18);
        X[t, 64] = PMINTENCLR\_EL1;
elsif PSTATE.EL == EL2 then
    if Halted() && HaveEL(EL3) && EDSCR.SDD == '1'
&& boolean IMPLEMENTATION_DEFINED "EL3 trap priority
```

# MSR PMINTENCLR EL1, <Xt>

op0	op1	CRn	CRm	op2
0b11	0b000	0b1001	0b1110	0b010

```
if PSTATE.EL == ELO then
    UNDEFINED;
elsif PSTATE.EL == EL1 then
    if Halted() && HaveEL(EL3) && EDSCR.SDD == '1'
&& boolean IMPLEMENTATION_DEFINED "EL3 trap priority
when SDD == '1'" && MDCR EL3.TPM == '1' then
        UNDEFINED;
    elsif EL2Enabled() &&
IsFeatureImplemented(FEAT_FGT) && (!HaveEL(EL3) | |
SCR_EL3.FGTEn == '1') && HDFGWTR_EL2.PMINTEN == '1'
then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif EL2Enabled() && MDCR_EL2.TPM == '1' then
        AArch64.SystemAccessTrap(EL2, 0x18);
    elsif HaveEL(EL3) && MDCR_EL3.TPM == '1' then
        if Halted() && EDSCR.SDD == '1' then
            UNDEFINED;
        else
            AArch64.SystemAccessTrap(EL3, 0x18);
        PMINTENCLR_EL1 = X[t, 64];
elsif PSTATE.EL == EL2 then
    if Halted() && HaveEL(EL3) && EDSCR.SDD == '1'
&& boolean IMPLEMENTATION_DEFINED "EL3 trap priority
when SDD == '1'" && MDCR_EL3.TPM == '1' then
        UNDEFINED;
    elsif HaveEL(EL3) && MDCR_EL3.TPM == '1' then
        if Halted() && EDSCR.SDD == '1' then
            UNDEFINED;
        else
            AArch64.SystemAccessTrap(EL3, 0x18);
    else
        PMINTENCLR_EL1 = X[t, 64];
elsif PSTATE.EL == EL3 then
    PMINTENCLR_EL1 = X[t, 64];
```

AArch32AArch64AArch32AArch64Index byExternalRegistersRegistersInstructionsInstructionsEncodingRegisters

28/03/2023 16:02; 72747e43966d6b97dcbd230a1b3f0421d1ea3d94

Copyright  $\hat{A}$  © 2010-2023 Arm Limited or its affiliates. All rights reserved. This document is Non-Confidential.