### SRI

Shift Right and Insert (immediate). This instruction reads each vector element in the source SIMD&FP register, right shifts each vector element by an immediate value, and inserts the result into the corresponding vector element in the destination SIMD&FP register such that the new zero bits created by the shift are not inserted but retain their existing value. Bits shifted out of the right of each vector element of the source register are lost. The following figure shows an example of the operation of shift right by 3 for an 8-bit vector element.

shift right by 3 for an 8-bit vector element

Depending on the settings in the *CPACR\_EL1*, *CPTR\_EL2*, and *CPTR\_EL3* registers, and the current Security state and Exception level, an attempt to execute the instruction might be trapped.

It has encodings from 2 classes: Scalar and Vector

#### **Scalar**

```
31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0

0 1 1 1 1 1 1 1 0 != 0000 | immb | 0 1 0 0 0 1 | Rn | Rd

immh
```

# SRI <V><d>, <V><n>, #<shift>

```
integer d = UInt(Rd);
integer n = UInt(Rn);

if immh<3> != '1' then UNDEFINED;
constant integer esize = 8 << 3;
constant integer datasize = esize;
integer elements = 1;

integer shift = (esize * 2) - UInt(immh:immb);</pre>
```

### Vector

	 0 0 1	3 2 1 0
0 Q 1 0 1 1 1 1 0 != 0000   immb   0 1 0 0 0 1   Rn		Rd

immh

# SRI <Vd>.<T>, <Vn>.<T>, #<shift>

```
integer d = UInt(Rd);
integer n = UInt(Rn);

if immh == '0000' then SEE(asimdimm);
if immh<3>:Q == '10' then UNDEFINED;
constant integer esize = 8 << HighestSetBit(immh);
constant integer datasize = 64 << UInt(Q);
integer elements = datasize DIV esize;

integer shift = (esize * 2) - UInt(immh:immb);</pre>
```

# **Assembler Symbols**

<V>

Is a width specifier, encoded in "immh":

immh	<v></v>
0xxx	RESERVED
1xxx	D

<d>Is the number of the SIMD&FP destination register, in the "Rd" field.

<n> Is the number of the first SIMD&FP source register, encoded in the "Rn" field.

<Vd> Is the name of the SIMD&FP destination register, encoded in the "Rd" field.

<T> Is an arrangement specifier, encoded in "immh:Q":

immh	Q	<t></t>
0000	Х	SEE Advanced SIMD modified
		<u>immediate</u>
0001	0	8B
0001	1	16B
001x	0	4H
001x	1	8H
01xx	0	2S
01xx	1	4S
1xxx	0	RESERVED
1xxx	1	2D

<Vn> Is the name of the SIMD&FP source register, encoded in the "Rn" field.

For the scalar variant: is the right shift amount, in the range 1 to 64, encoded in "immh:immb":

immh	<shift></shift>
0xxx	RESERVED
1xxx	(128-UInt(immh:immb))

For the vector variant: is the right shift amount, in the range 1 to the element width in bits, encoded in "immh:immb":

immh	<shift></shift>		
0000	SEE Advanced SIMD modified immediate		
0001	(16-UInt(immh:immb))		
001x	(32-UInt(immh:immb))		
01xx	(64-UInt(immh:immb))		
1xxx	(128-UInt(immh:immb))		

# Operation

```
CheckFPAdvSIMDEnabled64();
bits(datasize) operand = V[n, datasize];
bits(datasize) operand2 = V[d, datasize];
bits(datasize) result;
bits(esize) mask = LSR(Ones(esize), shift);
bits(esize) shifted;

for e = 0 to elements-1
    shifted = LSR(Elem[operand, e, esize], shift);
    Elem[result, e, esize] = (Elem[operand2, e, esize] AND NOT(mask)) CV[d, datasize] = result;
```

#### **Operational information**

If PSTATE.DIT is 1:

- The execution time of this instruction is independent of:
  - The values of the data supplied in any of its registers.
  - The values of the NZCV flags.
- The response of this instruction to asynchronous exceptions does not vary based on:
  - The values of the data supplied in any of its registers.
  - The values of the NZCV flags.

<u>Base</u>	SIMD&FP	<u>SVE</u>	<u>SME</u>	Index by
<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<u>Instructions</u>	<b>Encoding</b>

Internal version only: isa v33.64, AdvSIMD v29.12, pseudocode no\_diffs\_2023\_09\_RC2, sve v2023-06\_rel; Build timestamp: 2023-09-18T17:56

Sh Pseu

Copyright © 2010-2023 Arm Limited or it	s affiliates. All rights reserved. This document is Non-Confidential.