

Synchronization in cache-coherent architectures

Performance enhancement by reducing bus traffic


Lagani • Micera • Miliani

Outline


- Introduction
- Snooping-based protocols
- Synchronization
 - Lock acquisition problem
 - Atomic instructions
 - Test-and-set: lock contention problem
 - QL and QOLB

Introduction


Introduction




Write-through cache




Bottleneck




Write-back cache




Write-back cache



Write-back cache



Incoherence






Snooping based protocols


Snooping based protocols

- Cache controllers (snoopers) snoop bus transactions to maintain coherency.
- Two possible behaviours when a cache block is modified:
 - Write-update
 - Write-invalidate




Write-update protocol

- Writing processor's snooper propagates the updated cache block
- Other snoopers snoop the new cache block and update their own cache block copy




Write-update protocol

- Writing processor's snooper propagates the updated cache block
- Other snoopers snoop the new cache block and update their own cache block copy




Write-update protocol

- Writing processor's snooper propagates the updated cache block
- Other snoopers snoop the new cache block and update their own cache block copy




Write-update protocol

- Writing processor's snooper propagates the updated cache block
- Other snoopers snoop the new cache block and update their own cache block copy




Write-update protocol

- Writing processor's snooper propagates the updated cache block
- Other snoopers snoop the new cache block and update their own cache block copy




Write-invalidate protocol

- Writing processor issues an invalidation signal just for the first write
- All other snoopers invalidate their own cache block copy




Write-invalidate protocol

- Writing processor issues an invalidation signal just for the first write
- All other snoopers invalidate their own cache block copy




Write-invalidate protocol

- Writing processor issues an invalidation signal just for the first write
- All other snoopers invalidate their own cache block copy




Write-invalidate protocol

- Writing processor issues an invalidation signal just for the first write
- All other snoopers invalidate their own cache block copy




Write-invalidate protocol

- Writing processor issues an invalidation signal just for the first write
- All other snoopers invalidate their own cache block copy



Update vs invalidate: bus transactions

- How many transactions do these protocols require?



- **Write-run:**
 - Set of consecutive writes from the **same** processor which ends with a read or write from **another** processor
 - Let W_r be the average number of writes in it
- Let also n be the average number of operations made by other processors on the same cache block after each write-run

Update vs invalidate: cost evaluation

Write-update	Write-invalidate
<ul style="list-style-type: none">• W_r write transactions	<ul style="list-style-type: none">• 1 invalidation message• n misses<ul style="list-style-type: none">○ Each operation after the write-run will cause a miss

- C_u : updating message cost
- Average write-invalidate cost per time window
 - $C_{\text{Invalidate}} = C_i + n * C_u$
- Average write-update cost per time window
 - $C_{\text{Update}} = W_r * C_u$

Update vs invalidate: cost evaluation

- Write-invalidate outperforms write-update when:

$$C_{\text{Invalidate}} < C_{\text{Update}}$$

$$C_i + n * C_u < W_r * C_u$$

$$W_r > n + C_i / C_u$$

- The best protocol to use depends on W_r and n

Update vs invalidate: which is better

Write-invalidate



- Better to use when the write-run is long
- Misses will have to be served synchronously, hence they cannot be delayed

Write-update

- Better to use when there's high contention between processors
- Block updates are asynchronous and can be delayed

Invalidate vs. update evaluation: traffic

- Simulated 1 MB cache, 64 B lines



Fatahalian, K. (2017). Snooping Cache Coherence: Part II - CMU 15-418: Parallel Computer Architecture and Programming.
Available at http://15418.courses.cs.cmu.edu/spring2017/lecture/cache-coherence1/slide_041

Typical commercial solutions

- Most of the commercial multiprocessors use:
 - **Write-Back** caches
 - to reduce bus traffic
 - they allow more processors on a single bus
 - **Write-Invalidate** protocol
 - to preserve bus bandwidth
- Typical write-back/write-invalidate protocols:
 - MOESI
 - MESIF

MOESI in AMD and ARM

- Current AMD and ARM cache coherence implementations use MOESI protocol

7.3 Memory Coherency and Protocol

Implementations that support caching support a cache-coherency protocol for maintaining coherency between main memory and the caches. The cache-coherency protocol is also used to maintain coherency between all processors in a multiprocessor system. The cache-coherency protocol supported by the AMD64 architecture is the **MOESI** (modified, owned, exclusive, shared, invalid) protocol. The states of the MOESI protocol are:

<http://support.amd.com/TechDocs/24593.pdf>

6.5.1 Data cache coherency

The Cortex-A73 processor uses the **MOESI** protocol to maintain data coherency between multiple cores.

MOESI describes the state that a shareable line in a L1 data cache can be in:

http://infocenter.arm.com/help/topic/com.arm.doc.100048_0002_05_en/cortex_a73_trm_100048_0002_05_en.pdf

MESIF in Intel

- Another cache coherency protocol developed by Intel
- Uses state F instead of state O

With the introduction of the Intel® QuickPath Interconnect protocol the 4 MESI states are supplemented with a fifth, Forward (F) state, for lines forwarded from one socket to another.


https://software.intel.com/sites/products/collateral/hpc/vtune/performance_analysis_guide.pdf

Synchronization



Multiprocessor synchronization

- Concurrent processes may want to
 - access shared data (or acquire a physical resource) concurrently
 - coordinate their progress relative to each other
- This implies that concurrent processes must be synchronized
 - Cooperation among processors (e.g. Producer–Consumer relationship)



Final result is $A + 1$ instead of $A + 3$.

Lock acquisition problem

- Synchronization quite often implies the acquisition and release of **locks**
- These primitives are used by sync libraries which allow developers to write something like:

```
while(!acquire(lock)) { waiting algorithm }
```

Computation on shared data

```
release(lock)
```

- Waiting algorithms:
 1. Busy waiting
 2. Blocking
- Acquisition process must be **atomic**

Test-and-set

- Test-and-set is an atomic operation that atomically reads the value of a memory location and writes 1 in it
- In early implementations, the operation was performed by blocking the bus for all the duration of the instruction, but there is a more efficient solution based on cache coherence:
 - Reads the lock value
 - Sets it to 1 anyway
 - If, in the meantime, the copy was invalidated → another processor got the lock → returns 1
 - Returns the lock initial value otherwise

```
loop: test-and-set R2, lock // test and set the value in location lock
      bnz      R2, loop // if the result is not zero, spin
      ld       R1, A   // the lock has been acquired
      addi    R1, R1, 1 // increment A
      st       R1, A   // store A
      st       R0, lock // release the lock; R0 contains 0
```

Other implementations

- Other test-and-set generalizations
 - *Exchange-and-swap*
 - *Compare-and-swap*
- **Fetch-and- Θ** operation is a generic name for:
 - Fetch-and-increment
 - Fetch-and-add
 - ...
- Its use it's way more simpler than the test-and-set
 - fetch-and-increment A
 - fetch-and-add A, R1
 - ...

Test-and-set: lock contention problem


- **Lock contention in spinning locks implementation**
- The first processor that wants to acquire a lock succeeds and caches the lock in a line in the modify (M) state
- The first processor that requests the lock subsequently will get a copy of the lock and test it (unsuccessfully)
 - A write operation is always performed due to the test-and-set implementation: it will then invalidate the holder cache block copy
 - The processor keeps its cached copy in the M state
- The last processor that requests the block will have the unique copy of it in the M state.
- All requesters are repeatedly trying to read and modify the lock, which is in the M state in another cache.

Test-and-set: lock contention problem

- **Lock contention in spinning locks implementation**
- The first processor that wants to acquire a lock succeeds and caches the lock in a line in the modify (M) state
- The first processor that requests the lock subsequently will get a copy of the lock and test it (unsuccessfully)
 - A write operation is always performed due to the test-and-set implementation: it will then invalidate the holder cache block copy
 - The processor keeps its cached copy in the M state
- The last processor that requests the block will have the unique copy of it in the M state.
- All requesters are repeatedly trying to read and modify the lock, which is in the M state in another cache.

Problem: heavy bus utilization


Test-and-set lock performance



Fatahalian, K. (2017). Snooping Cache Coherence: Part II - CMU 15-418: Parallel Computer Architecture and Programming.
Available at http://15418.courses.cs.cmu.edu/spring2017/lecture/synchronization/slide_023


First solution: queueing locks

- Let n be the number of processors
- Contention can be reduced by having requesting processors enter a n bits long FIFO queue
 - Each bit represents the lock state for each processor
each lock bit must be in a different cache line, otherwise the lock contention problem appears again
 - Initially the first element contains a “free lock” flag, so the first processor can acquire the lock




First solution: queueing locks

- A processor requesting the lock will perform:
`my_index = fetch-and-increment(tail)`
- After this function call:
 - `my_index` is 0
 - `tail` is 1




First solution: queueing locks

- The processor reads `flag[my_index]` and caches it
 - its value is 0, so the processor can enter the critical section
 - otherwise it would have continued spinning




First solution: queueing locks

- The processor, once it entered the critical section, sets his lock state to 1 to make it busy for the next round




First solution: queueing locks

- At the end of its critical section, the processor releases the lock to the next processor, by setting
`flag[(my_index + 1) % n]` to 0



First solution: queueing locks

- The write operation will invalidate the line containing the lock in the cache of the processor corresponding to $\text{myindex} + 1$.
 - This will generate a read miss for the latter, and upon reading of its flag, its test will be successful.



Software implementation of QL

```
init:    flag[0] := 0; // Initially, 1st processor can have the lock
        for(i:= 0; i < n; i++) // All other processors will see a busy lock
            flag[i] := 1;
        tail := 0;

acq:     myindex := fetch-and-increment(tail); // Increment is modulo n
        while(flag[myindex] == 1); // Spins while the lock is held elsewhere

        // The processors gets the lock and makes it busy for the next round
        flag[myindex] := 1;

rel:     // Releases the lock and passes it on the next processor
        flag[(myindex + 1) % n] := 0;
```

Queuing Locks: pros & cons

- Advantages:
 - Reduced bus traffic
- Drawbacks:
 - Relying on fetch-and-increment
 - Each lock must be in a different cache line (distributed lock), or contention will occur while performing fetch-and-increment.
 - No shared data coallocation

Second solution: QOLB

- Completely in hardware (Queue On Locked Bit)
- Hardware queue of waiting processors' IDs
- Only **one lock variable**
 - Enqueue operation allocates a shadow copy of the line containing the lock in the processor's cache
 - Spinning is performed in cache if the lock bit is set to busy
 - When the processor holding the lock releases it, it performs a *dequeue operation* that directly **sends the freed lock and the data in the same line to the next waiting processor**
- Pro: QOLB outperforms other schemes
- Cons: Significant complexity cost
 - Further complications in coherence protocols
 - **Direct transfer from one cache to another is required**

References

- Jean-Loup Baer, Microprocessor Architecture: from Simple Pipelines to Chip Multiprocessor
- Hennessy & Patterson, Computer Architecture, 5th edition
- http://infocenter.arm.com/help/index.jsp?topic=/com.arm.doc_subset.cortexa.cortexa73/index.html
- <http://www.anandtech.com/show/10347/arm-cortex-a73-artemis-unveiled/2>
- <http://ark.intel.com/products/series/53672/Intel-Xeon-Processor-E7-8800-Product-Family>
- https://en.wikipedia.org/wiki/MOESI_protocol
- https://en.wikipedia.org/wiki/MESIF_protocol
- <http://www.realworldtech.com/common-system-interface/5/>
- http://15418.courses.cs.cmu.edu/spring2017content/lectures/16_synchronization/16_synchronization_slides.pdf
- https://it.wikipedia.org/wiki/Memoria_cache#Protocolli_di_Coerenza
- <http://ieeexplore.ieee.org/stamp/stamp.jsp?tp=&arnumber=1676921>



Any questions?



**Thank you for your
attention**