

Project 1 Executuion Platforms

Hamden Brini, Wilches Juan, Barau Elena, Marculescu Tudor

January 2025

1 Introduction to RISC-V Instruction Set Architecture

In this section we are focusing on a decomposition of RISC-V hex instruction into the ASM instruction. The instruction format is determined based on the opcode, funct3 and funct7 fields. Table 1 depicts a detailed translation of each instruction from it's hex code to it's format fields. Some of them not used in certain instruction types, and are marked with a dash (-) in the table. The ultimate factor that determines the instruction type is the "Type" column, which indicates instruction format label R, I, S or SB.

1.1 Program Instructions Decomposition

| Address | Hex Code | Opcode (6:0) | rd (11:7) | funct3 (14:12) | rs1 (19:15) | rs2 (24:20) | funct7 (31:25) | imm[11:0] (31:20) | imm[11:5] (31:25) | imm[4:0] (11:7) | Type |
|---------|--------------|--------------|-----------|----------------|-------------|-------------|----------------|-------------------|-------------------|-----------------|------|
| 0x0 | 0x00050893 | 0010011 | 10001 | 000 | 01010 | - | - | 000000000000 | - | - | I |
| 0x4 | 0x00068513 | 0010011 | 01010 | 000 | 01101 | - | - | 000000000000 | - | - | I |
| 0x8 | 0x04088063 | 1100011 | - | 000 | 10001 | 00000 | - | - | 0000010 | 00000 | SB |
| 0xc | 0x04058263 | 1100011 | - | 000 | 01011 | 00000 | - | - | 0000010 | 00100 | SB |
| 0x10 | 0x04060063 | 1100011 | - | 000 | 01100 | 00000 | - | - | 0000010 | 00000 | SB |
| 0x14 | 0x04d05063 | 1100011 | - | 101 | 00000 | 01101 | - | - | 0000010 | 00000 | SB |
| 0x18 | 0x00088793 | 0010011 | 01111 | 000 | 10001 | - | - | 000000000000 | - | - | I |
| 0x1c | 0x00269713 | 0010011 | 01110 | 001 | 01101 | - | - | 000000000010 | - | - | I |
| 0x20 | 0x00e888b3 | 0110011 | 10001 | 000 | 10001 | 01110 | 0000000 | - | 0000000 | 10001 | R |
| 0x24 | 0x0007a703 | 0000011 | 01110 | 010 | 01111 | - | - | 000000000000 | - | - | I |
| 0x28 | 0x0005a803 | 0000011 | 10000 | 010 | 01011 | - | - | 000000000000 | - | - | I |
| 0x2c | 0x01070733 | 0110011 | 01110 | 000 | 01110 | 10000 | 0000000 | - | 0000000 | 01110 | R |
| 0x30 | 0x00e62023 | 0100011 | - | 010 | 01100 | 01110 | - | - | 000000000000 | 00000 | S |
| 0x34 | 0x00478793 | 0010011 | 01111 | 000 | 01111 | - | - | 00000000100 | - | - | I |
| 0x38 | 0x00458593 | 0010011 | 01011 | 000 | 01011 | - | - | 00000000100 | - | - | I |
| 0x3c | 0x00460613 | 0010011 | 01100 | 000 | 01100 | - | - | 00000000100 | - | - | I |
| 0x40 | 0xffff1792e3 | 1100011 | - | 001 | 01111 | 10001 | - | - | 1111111 | 00101 | SB |
| 0x44 | 0x000008067 | 1100111 | 00000 | 000 | 00001 | - | - | 000000000000 | - | - | I |
| 0x48 | 0xffff00513 | 0010011 | 01010 | 000 | 00000 | - | - | 111111111111 | - | - | I |
| 0x4c | 0x000008067 | 1100111 | 00000 | 000 | 00001 | - | - | 000000000000 | - | - | I |
| 0x50 | 0xffff00513 | 0010011 | 01010 | 000 | 00000 | - | - | 111111111111 | - | - | I |
| 0x54 | 0x000008067 | 1100111 | 00000 | 000 | 00001 | - | - | 000000000000 | - | - | I |

Table 1: Decomposition of Hex Codes to RISC-V Instruction Format

A point to note is that the immediate fields for UJ and U type instructions are missing from Table 1. This is because the provided program is missing them. There is also an overlap between the immediates of S and SB type instructions, as they share the same positions in the instruction format. The table head includes just the immediate fields for S out of simplicity, but in the case of SB, they were calculated as depicted in the RISC-V specification from the Project 1 description [1].

| Address | Hex Code | ASM Instruction (ABI) | ASM Instruction (x-registers) |
|---------|-------------|-----------------------|-------------------------------|
| 0x0 | 0x00050893 | addi a7, a0, 0 | addi x17, x10, 0 |
| 0x4 | 0x00068513 | addi a0, a3, 0 | addi x10, x13, 0 |
| 0x8 | 0x04088063 | beq a7, zero, 64 | beq x17, x0, 64 |
| 0xc | 0x04058263 | beq a1, zero, 68 | beq x11, x0, 68 |
| 0x10 | 0x04060063 | beq a2, zero, 64 | beq x12, x0, 64 |
| 0x14 | 0x04d05063 | bge zero, a3, 64 | bge x0, x13, 64 |
| 0x18 | 0x00088793 | addi a5, a7, 0 | addi x15, x17, 0 |
| 0x1c | 0x00269713 | slli a4, a3, 2 | slli x14, x13, 2 |
| 0x20 | 0x00e888b3 | add a7, a7, a4 | add x17, x17, x14 |
| 0x24 | 0x0007a703 | lw a4, 0(a5) | lw x14, 0(x15) |
| 0x28 | 0x0005a803 | lw a6, 0(a1) | lw x16, 0(x11) |
| 0x2c | 0x01070733 | add a4, a4, a6 | add x14, x14, x16 |
| 0x30 | 0x00e62023 | sw a4, 0(a2) | sw x14, 0(x12) |
| 0x34 | 0x00478793 | addi a5, a5, 4 | addi x15, x15, 4 |
| 0x38 | 0x00458593 | addi a1, a1, 4 | addi x11, x11, 4 |
| 0x3c | 0x00460613 | addi a2, a2, 4 | addi x12, x12, 4 |
| 0x40 | 0xff1792e3 | bne a5, a7, -28 | bne x15, x17, -28 |
| 0x44 | 0x00008067 | jalr zero, ra, 0 | jalr x0, x1, 0 |
| 0x48 | 0xffff00513 | addi a0, zero, -1 | addi x10, x0, -1 |
| 0x4c | 0x00008067 | jalr zero, ra, 0 | jalr x0, x1, 0 |
| 0x50 | 0xffff00513 | addi a0, zero, -1 | addi x10, x0, -1 |
| 0x54 | 0x00008067 | jalr zero, ra, 0 | jalr x0, x1, 0 |

Table 2: RISC-V Instructions with register numbers, symbolic names and addresses

In order to better understand the provided program, Table 2 is introduced to map the hex codes with their corresponding assembly instructions. As an overall view, the program is making use of

RV32I instruction set only. The registers are represented in both their symbolic names (ABI) and x-register numbers. in order to facilitate the understanding of the program.

1.2 Branch Delay Slot Concept

The branch delay slot concept is interesting when discussing pipelined processors. Essentially, when a branch instruction is taken, the instructions that were fetched after the branch instructions become invalid if there is no branch prediction. To avoid this, the branch delay slot declares that the instruction immediately following a branch instruction is always executed, regardless of whether the branch is taken or not. This helps to mitigate the performance penalty associated with branch instructions that invalidate subsequent instructions in the pipeline. As explained in [2]: "The idea of the branch shadow or delay slot is to recover a part of the clocks. If you declare that the instruction after a branch is always executed then when a branch is taken, then the instruction in the decode slot also gets executed, while the instruction in the fetch slot is discarded. Therefore one has a hole of time not two." The branch delay slot will be filled with an instruction that is independent of the branch outcome by the compiler in the compilation phase of the program. It will look in a window of instructions before and after the branch instruction to find a suitable candidate that will come right after it.

In terms of advantages and disadvantages, there are several points to consider.

For disadvantages:

- Branch delay slots may create complications in code debugging, since the instruction in the delay slot might have side effects, it may lead to an unexpected state of the registers and memory.
- It adds to the waiting time when trying to execute interruptions, since they will be deferred until the delay slot instruction is executed. This is a problem in the case of real time systems.
- Software compatibility requirements dictate that an architecture may not change the number of delay slots from one generation to the next. This inevitably requires that newer hardware implementations contain extra hardware to ensure that the architectural behaviour is followed despite no longer being relevant.

Advantages of using branch delay slots include:

- Improved performance in pipelined architectures, since it helps to reduce the number of pipeline stalls caused by branch instructions if no branch prediction is used.
- The use of branch delay slots helps simplify processor design by removing the need for sophisticated branch prediction mechanisms in early architectures. As a result, the hardware becomes easier and less expensive to implement.

Nowadays, the branch delay slot concept became obsolete, as modern processors use branch prediction techniques to mitigate the branching performance penalty. This also mitigates the complications of having the compiler finding suitable instructions to fill the delay slots.

1.3 Branch Instructions Analysis

In order to understand better the provided program, it is useful to check the branch instructions and where they lead to.

| Address | Conditional branch | Branch to |
|---------|--------------------|-------------------------|
| 0x08 | beq a7, zero, 64 | 0x48: addi a0, zero, -1 |
| 0x0c | beq a1, zero, 68 | 0x50: addi a0, zero, -1 |
| 0x10 | beq a2, zero, 64 | 0x50: addi a0, zero, -1 |
| 0x14 | bge zero, a3, 148 | 0x54: jalr zero, ra, 0 |
| 0x40 | bne a5, a7, -28 | 0x24: lw a4, 0(a5) |

Table 3: RISC-V Instructions with Addresses

From the table above we can see that there are 4 first conditional branches, that being the addresses 0x08, 0x0c, 0x10 and 0x14, which resemble input value checks. Considering the calling convention for RISC-V, the registers a0-a7 are used for passing function arguments from the caller to the callee. In this case, the supposition of input value checks is valid. The first three jump to a return -1 in case the input values are 0, while the fourth one jumps to a return with the number of elements to be processed, which would be less than or equal to 0.

The last conditional branch at address 0x40 is part of a loop. It checks whether the address stored in register a5, used as a counter, is equal to the last address to be processed, which is stored in register a7. If they are not equal, the program branches back to address 0x24 to continue processing the next elements. If they are equal, the program continues to the return instruction.

1.4 Program Functionality

The program can be divided into three main parts: input validation, processing loop, and return value. The input validation part checks if any of the first three caller arguments are 0. The arguments are passed are actually pointers to the input and output arrays, so they are checked if they are null, which would indicate an invalid memory access, therefore leading to a jump to the section of the program corresponding to return -1. The fourth argument is the number of elements to be processed, which is checked in the register a3 to see if it is less than or equal to 0. In case it is, the program jumps to the section corresponding to return, with the number of elements to be processed.

The processing loop starts at address 0x18 and continues until the branch instruction at address 0x40. It consists of an initial setup for the loop counter in register a5 and for the final value of the counter, which is stored in register a7. Register a7 will store the address of the last element to be processed from one of the input arrays, calculated as the base address plus the number of elements multiplied by 4, the size of each element. Because the elements are 4 bytes long, it can be extrapolated that the arrays are made of 32-bit integers. The loop itself consists of loading the elements from both input arrays, by using registers a5 and a1, which store the current addresses of the elements. Afterwards, the elements are summed and stored in register a4, which is then stored in the output array location pointed by register a2. Finally, the addresses in registers a5, a1 and a2 are incremented by 4 to point to the next elements to be processed. The loop continues until the address in register a5 is equal to the address in register a7. This is ensured by the branch if not equal instruction at address 0x40.

Finally, the return part is reached at address 0x44, where the program jumps back to the calle, using the address stored in register ra. The return value is stored in register a0, which is equal to the number of elements to be processed.

| Situation | Return value |
|---------------------------------------------|------------------------------------|
| input pointers are null | -1 |
| number of elements to be processed $i=0$ | number of elements to be processed |
| processing finished and the result is ready | number of processed elements |

Table 4: Return values of the program

2 RISC-V Tool Chain

2.1 Reimagined C Code

The above explanation of the program's functionality allows us to reimagine the C code that could have generated the assembly instructions that were previously described. To do so, one can have an intuition on what certain assembly instructions would mean in C. For example, for the part of input validation, the conditional branches checks can be equivalent to if statements in C.

```
beq a7, zero, 64
...
addi a0, zero, -1
jalr zero, ra, 0 —> if (in1 == NULL) return -1;
```

There is no direct connection between the register names and C variables, therefore arbitrary names can be assigned to them based on their usage. For example, register a0 can be assigned to the variable "in1", register a1 to "in2", register a2 to "out" and register a3 to "n", representing the two input arrays, the output array and the number of elements to be processed from the arrays.

For the processing loop, one can reimagine it as a for loop in C, iterating from 0 to n-1. This is reflected in the assembly instructions which first setup the counter and the final conditional branch to check if it has reached its final value.

```
bne a5, a7, -28
addi a5, a7, 0
slli a4, a3, 2
add a7, a7, a4 —> for (int i = 0; i < n; i++) { ... }
```

As for the operations inside the loop, the lw can be mapped to array accesses in C, the add instruction to the assignment operator and the sw to the assignment operator as well.

```
lw a4, 0(a5)
lw a6, 0(a1)
add a4, a4, a6
sw a4, 0(a2) —> out[i] = in1[i] + in2[i];
```

Therefore, taking into account all of the above observations, a complete C functions that could have generated the provided assembly instructions is represented below:

```
1 int addv(int *in1, int *in2, int *out, int n)
2 {
3     if (in1 == NULL)
4         return -1;
5     if (in2 == NULL)
6         return -1;
7     if (out == NULL)
8         return -1;
9     if (n <= 0)
10        return n;
11
12    for (int i = 0; i < n; i++) {
13        out[i] = in1[i] + in2[i];
14    }
15
16    return n;
17 }
```

2.2 Compiling the C Code to RISC-V Assembly

By using the RISC-V GCC toolchain, one can compile the above C code into RISC-V object code and then disassemble it to obtain the assembly instructions. The following command was used in order to produce the object file "se201-prog.o" from the C source file "se201-prog.c":

```
riscv64-linux-gnu-gcc -g -O0 -mcmode=medlow -mabi=ilp32 -march=rv32im -Wall -c -o se201-prog.o se201-prog.c
```

A fair mention is that in order to have a compilable C program, one needs to provide a main function as an entry point. In it, the input arrays and the output array are defined, along with the number of elements to be processed. The call to the addv function, which was seen previously, is also made in main.

```
1 int main() {
2     volatile int n = 50;
3     volatile int a[50] = {0};
4     volatile int b[50] = {0};
5     volatile int result[50] = {0};
6
7     addv(a, b, result, n);
8
9     return 0;
10 }
```

The volatile keyword is used to prevent the compiler from optimizing away the arrays and the variable n, as they are used in the function call to addv. Also, it is important to force the compiler to use load store instruction when operating on the elements of the arrays, such that the generated assembly can be compared with the one provided in the first section.

2.3 Comparison between the generated and the previous instructions

After successfully compiling the C code, one can disassemble it to obtain the assembly instructions. The following command is used to do so:

```
riscv64-linux-gnu-objdump -d ./se201-prog.o
```

Then, because the addv function is the one of interest, we can navigate to the corresponding part of the output, containing the label "addv". Below is a snippet of the generated assembly instructions for it:

Generated Assembly Instructions:

00000000 <addv>:

| | | | |
|-----|-----------|------|----------------|
| 0: | fd010113 | addi | sp , sp , -48 |
| 4: | 02812623 | sw | s0 , 44(sp) |
| 8: | 03010413 | addi | s0 , sp , 48 |
| c: | fca42e23 | sw | a0 , -36(s0) |
| 10: | fcb42c23 | sw | a1 , -40(s0) |
| 14: | fcc42a23 | sw | a2 , -44(s0) |
| 18: | fcd42823 | sw | a3 , -48(s0) |
| 1c: | fdc42783 | lw | a5 , -36(s0) |
| 20: | 00079663 | bnez | a5 , 2 c <.L2> |
| 24: | fff00793 | li | a5 , -1 |
| 28: | 0980006 f | j | c0 <.L3> |

0000002 c <.L2>:

| | | | |
|-----|-----------|------|----------------|
| 2c: | fd842783 | lw | a5 , -40(s0) |
| 30: | 00079663 | bnez | a5 , 3 c <.L4> |
| 34: | fff00793 | li | a5 , -1 |
| 38: | 0880006 f | j | c0 <.L3> |

0000003 c <.L4>:

| | | | |
|-----|-----------|------|----------------|
| 3c: | fd442783 | lw | a5 , -44(s0) |
| 40: | 00079663 | bnez | a5 , 4 c <.L5> |
| 44: | fff00793 | li | a5 , -1 |
| 48: | 0780006 f | j | c0 <.L3> |

0000004 c <.L5>:

| | | | |
|-----|-----------|------|----------------|
| 4c: | fd042783 | lw | a5 , -48(s0) |
| 50: | 00f04663 | bgtz | a5 , 5 c <.L6> |
| 54: | fd042783 | lw | a5 , -48(s0) |
| 58: | 0680006 f | j | c0 <.L3> |

0000005 c <.L6>:

| | | | |
|-----|-----------|----|------------------|
| 5c: | fe042623 | sw | zero , -20(s0) |
| 60: | 0500006 f | j | b0 <.L7> |

00000064 <.L8>:

| | | | |
|-----|----------|------|----------------|
| 64: | fec42783 | lw | a5 , -20(s0) |
| 68: | 00279793 | slli | a5 , a5 , 0x2 |
| 6c: | fdc42703 | lw | a4 , -36(s0) |
| 70: | 00f707b3 | add | a5 , a4 , a5 |
| 74: | 0007a683 | lw | a3 , 0(a5) |
| 78: | fec42783 | lw | a5 , -20(s0) |
| 7c: | 00279793 | slli | a5 , a5 , 0x2 |
| 80: | fd842703 | lw | a4 , -40(s0) |
| 84: | 00f707b3 | add | a5 , a4 , a5 |
| 88: | 0007a703 | lw | a4 , 0(a5) |
| 8c: | fec42783 | lw | a5 , -20(s0) |

```

90: 00279793      slli    a5 , a5 , 0x2
94: fd442603      lw       a2 , -44(s0)
98: 00f607b3      add     a5 , a2 , a5
9c: 00e68733      add     a4 , a3 , a4
a0: 00e7a023      sw      a4 , 0( a5 )
a4: fec42783      lw       a5 , -20(s0)
a8: 00178793      addi    a5 , a5 , 1
ac: fef42623      sw      a5 , -20(s0)

000000b0 <.L7>:
b0: fec42703      lw       a4 , -20(s0)
b4: fd042783      lw       a5 , -48(s0)
b8:faf746e3       blt    a4 , a5 , 64 <.L8>

000000bc <.LBE2>:
bc: fd042783      lw       a5 , -48(s0)

000000c0 <.L3>:
c0: 00078513      mv      a0 , a5
c4: 02c12403      lw       s0 , 44( sp )
c8: 03010113      addi    sp , sp , 48
cc: 00008067      ret


```

By comparing the generated assembly with the one provided in the first section, one can observe that several differences exist. Firstly, the compiler puts the code in different sections, with different labels, such as .L2, .L3, .L4 etc, which correspond to parts of the addv function.

Secondly, the check for null pointers, which can be observed in the section .L2, .L4 and .L5 is done using the "bnez" instruction instead of a "beq", which instead of jumping to a common return -1, each "bnez" contains its own jump to the return -1 section. This leads to a larger code size and is also less efficient. The efficiency problem arises from the fact that if bnez is taken, when the pointer is valid, then the processor will have to flush the pipeline, if no branch prediction is used.

Thirdly, the loop structure is different, as it can be seen in .L8 and .L7 sections. The loop counter is stored on stack, instead of in a register, which leads to additional load and store instructions. It is increment only by 1, instead of 4, and then multiplied by 4 when calculating the address of the element to be processed.

2.4 Changing the Optimization Level

By switching the optimization level from -O0 to -O1, the generated assembly code changes significantly. It is observed that the code size is reduced, and the loop starts to resemble more the code provided in the first section. Below is a snippet of the generated assembly instructions:

```

00000000 <addv>:
0: 00050813      mv      a6 , a0
4: 00068513      mv      a0 , a3

00000008 <.LVL1>:
8: 04080063      beqz   a6 , 48 <.L4>
c: 04058263      beqz   a1 , 50 <.L5>


```

```

10: 04060463      beqz   a2 ,58 <.L6>
14: 04d05463      blez   a3 ,5 c <.L2>
18: 00080793      mv     a5 ,a6
1c: 00269713      slli   a4 ,a3 ,0x2
20: 00e80833      add    a6 ,a6 ,a4

00000024 <.L3>:
24: 0007a703      lw     a4 ,0( a5 )
28: 0005a883      lw     a7 ,0( a1 )
2c: 01170733      add   a4 ,a4 ,a7
30: 00e62023      sw     a4 ,0( a2 )
34: 00478793      addi  a5 ,a5 ,4
38: 00458593      addi  a1 ,a1 ,4
3c: 00460613      addi  a2 ,a2 ,4
40: ff0792e3      bne   a5 ,a6 ,24 <.L3>
44: 00008067      ret

00000048 <.L4>:
48: fff00513      li     a0 ,-1
4c: 00008067      ret

00000050 <.L5>:
50: fff00513      li     a0 ,-1

00000054 <.LVL5>:
54: 00008067      ret

00000058 <.L6>:
58: fff00513      li     a0 ,-1

0000005c <.L2>:
5c: 00008067      ret

Changes in code size occur as well when switching to higher optimization levels, such as -O3.

00000000 <addv>:
0: 00050793      mv     a5 ,a0
4: 04050063      beqz   a0 ,44 <.L8>
8: 02058e63      beqz   a1 ,44 <.L8>
c: 02060c63      beqz   a2 ,44 <.L8>
10: 00269893     slli   a7 ,a3 ,0x2
14: 011508b3     add    a7 ,a0 ,a7
18: 02d05263     blez   a3 ,3 c <.L5>

0000001c <.L4>:
1c: 0007a703      lw     a4 ,0( a5 )
20: 0005a803      lw     a6 ,0( a1 )
24: 00478793      addi  a5 ,a5 ,4
28: 00458593      addi  a1 ,a1 ,4

```

| | | | |
|-------------------|----------|------|---------------------|
| 2c: | 01070733 | add | a4 , a4 , a6 |
| 30: | 00e62023 | sw | a4 , 0 (a2) |
| 34: | 00460613 | addi | a2 , a2 , 4 |
| 38: | ff1792e3 | bne | a5 , a7 , 1 c <.L4> |
| 0000003c <.L5>: | | | |
| 3c: | 00068513 | mv | a0 , a3 |
| 00000040 <.LVL2>: | | | |
| 40: | 00008067 | ret | |
| 00000044 <.L8>: | | | |
| 44: | fff00513 | li | a0 , -1 |
| 00000048 <.LVL4>: | | | |
| 48: | 00008067 | ret | |

3 RISC-V Architecture

4 Processor Design

4.1 Instruction Set Architecture

For the processor that we are designing, we will have an instruction set based on 16 bit wide instructions. There are 16 registers, all of them being 32 bit wide. The processor is of harvard architecture type.

- R0-R1: Return Registers
- R0-R4: Argument Registers (used to pass up to 4 function arguments)
- R5-R8: Temporary Registers (not preserved across function calls)
- R9-R12: Saved Registers (preserved across function calls)
- R13: Stack Pointer (SP)
- R14: Return Address Register (RA)
- R15: Program Counter (PC) (implicit, cannot be directly modified)

The operands are sign extended.

Arithmetic and logic instructions:
- SUM rd, rs1, rs2 ; rd = rs1 + rs2
- DIF rd, rs1, rs2 ; rd = rs1 - rs2
- SHL rd, rs1, rs2 ; rd = rs1 \ll rs2

Load from memory a 32bit value:
- MEL rd, rs1, imm ; rd = MEM[rs1 + imm]
- MES rd, rs1, imm ; MEM[rs1 + imm] = rd

Instruction to copy an immediate value to a register:
- SET rd, imm ; rd = imm

Define a conditional branch instruction having 1 register operand and 10 bit immediate
- BNZ rs1, imm ; if (rs1 != 0) PC = PC + imm * 2

Define an unconditional jump instruction having 1 register operand (read)
- GTO rs1 ; PC = rs1

Define a call instruction having 1 imm 9 bits
- CALL imm ; RA = PC + 2; PC = PC + imm * 2

Conditional branches, unconditional jumps, and calls in the instruction set have a branch delay slot for a single instruction.

References

- [1] *PR1-SE201-21*, 2021. Unpublished internal document.
- [2] James. What is a branch delay slot and why is it used?, 2020. Accessed: June 10, 2024.