edurov Documentation

Release 0.0.4

Trolllabs

Contents

1	Main features	
2	Prerequisites	
3	Installation	
4	Usage	
	4.1 Engage eduROV submersible	
	4.1 Engage eduROV submersible	٠
5	Performance	1
	5.1 Installation	. 1
	5.2 Engage eduROV	. 1
	5.3 Getting started	
	5.4 Examples	. 1
	5.5 API	
D۲	hon Module Index	3

Stream camera feed from a Raspberry Pi camera to any web browser on the network. Control the robot with your keyboard directly in the browser.

The eduROV project is all about spreading the joy of technology and learning. The eduROV is being developed as a DIY ROV kit meant to be affordable and usable by schools, hobbyists, researchers and others as they see fit. We are committed to be fully open-source, both software and hardware-wise, everything we develop will be available to you. Using other open-source and or open-access tools and platforms.

GitHub https://github.com/trolllabs/eduROV

PyPI https://pypi.org/project/edurov/

Documentation http://edurov.readthedocs.io

Engage eduROV https://www.edurov.no/



Contents 1

2 Contents

CHAPTER 1

Main features

1. Low video latency

You can stream HD video from the Raspberry Pi camera to any unit on the same network with a video delay below 200ms.

2. No setup required

The package works by displaying the video feed and other content in a web browser. This means that you can use any device to display your interface.

3. Very easy to use

With the exception of Pyro4 (which is installed automatically), edurov doesn't require any other packages or software. Everything is written in python and html. 4 lines of code is everything needed to get started!

4. Highly customizable

Since you define the html page yourself, you can make it look and work exactly the way you want. Use css and javascript as much as you want.

5. True parallelism

Need to control motors, read sensor values and display video feed at the same time? edurov can spawn your functions on multiple CPU cores while still maintaining the possibility to share variables.

CHAPTER 2

Prerequisites

- eduROV requires python 3, if you don't have python installed, you can download it here: https://www.python.org/downloads/
- the camera on the raspberry pi has to be enabled, see https://www.raspberrypi.org/documentation/configuration/camera.md

			•	7
\frown	VD.		_	≺
CH	42	ı⊏ı	づ 、	J

Installation

Run the following commands in a terminal on the Raspberry Pi.:

sudo pip3 install edurov

For a more in depth description visit the official documentation.

CHAPTER 4

Usage

4.1 Engage eduROV submersible

On the Raspberry Pi, run the following command:

edurov-web

This will start the web server and print the ip where the web page can be viewed, e.g. Visit the webpage at 192.168.0.197:8000.

4.2 Create your own


The eduROV package includes multiple classes and functions to facilitate easy robot communication with video feed. It will get you up and running in a matter of minutes. Visit the official documentation for a *getting started*, examples and API.

10 Chapter 4. Usage

CHAPTER 5

Performance

The eduROV package were created with a strong focus on keeping the latency at a minimum. When deploying on a wireless network the actual performance will vary depending on factors such as distance, interference and hardware.



5.1 Installation

5.1.1 Raspbian

First, you will need a raspberry pi with an operating system running on it. Visit the official software guide for a step by step guide on how to do that.

5.1.2 Remote control

In most cases it is more practical to control the Raspberry Pi using another computer. The two most popular methods are with either SSH or VNC.

5.1.3 Update system

Make sure that your Raspberry Pi is up to date:

```
sudo apt-get update
sudo apt-get dist-upgrade
```

5.1.4 Python version

The edurov package requires python 3. If python 3 si not your default python version (check by running python --version), you can either (1) change the default python version, or (2) use pip3 and python3 instead.

1. Change default python version

Take a look at this page.

2. Use pip3 and python3

If you don't want to make any changes, you can call pip3 instead of pip and python3 instead of python. This will use version 3 when installing and running python scripts instead.

5.1.5 Install using pip

Install edurov, sudo rights are needed to enable console scripts:

```
sudo pip install edurov
```

5.1.6 Static IP

If you are remotely connected to the Pi it can be very useful with a static ip so that you can find the Pi on the network. How you should configure this depends how your network is setup. A guide can be found here.

5.1.7 Start at system startup

If you want the edurov-web command to run automatically when the raspberry pi has started. Run the following command:

```
sudo nano /etc/rc.local
```

Then add the following line to the bottom of the screen, but before the line that says exit 0:

```
edurov-web &
```

Exit and save by pressing CTRL+C, y, ENTER. The system then needs to be rebooted:

```
sudo shutdown -r now
```

5.2 Engage eduROV

5.2.1 Terminal command

By calling edurov-web in the terminal the edurov-web example will be launched. This command also supports multiple flags that can be displayed by running edurov-web -h

-r resolution, use format WIDTHxHEIGHT (default 1024x768)

-fps framerate for the camera (default 30)

-port which port the server should serve it's content (default 8000)

-d set to print debug information

Example

```
edurov-web -r 640x480 -fps 10
```

Will then set the the video to 640x480 @ 10 fps

5.3 Getting started

Tip: If you came here to find out how to use the Engage ROV submersible, the Engage eduROV page is probably for you. If you instead plan to create your own ROV or make some kind of modifications, you are in the right place.

Note: Not all details at explained on this page. You should check the API page for more information on the classes, methods and parameters when you need.

On this page we will walk through the features example, one feature at a time. This example was created with the intention of describing all the features of the edurov package. Let's get started!

5.3.1 Displaying the video feed

There are two main parts needed in any edurov project. First, it's the python file that creates the WebMethod class and starts serving the server. Secondly, a index.html file that describes how the different objects will be displayed in the browser.

In the two code blocks underneath you can see how simple they can be created. The index.html file needs to be called exactly this. We use the os.path() library to ensure correct file path description.

Listing 1: features.py

```
import os
from edurov import WebMethod

# Create the WebMethod class
web_method = WebMethod(
    index_file=os.path.join(os.path.dirname(__file__), 'index.html'),

# Start serving the web page, blocks the program after this point
web_method.serve()
```

The index.html file must have an img element with src="stream.mjpg". The server will then populate this image with the one coming from the camera.

Listing 2: index.html

Our file structure now looks like this:

```
project

— features.py
— index.html
```

If you wanted to have a security camera system this is all you had to do. If you instead want to control you robot through the browser or display other information, keep reading.

5.3.2 Moving a robot

This section will let us control the ROV from within the web browser. In computer technology there is something called *parallelism*. It basically means that the CPU does multiple things at the same time in different processes. This is an important feature of the edurov package as it let's us do many things without interrupting the video feed. (It wouldn't be very practical if the video stopped each time we moved the robot).

Reading keystrokes

First, we have to ask the browser to send us information when keys are pressed. We do this by including keys.js inside the index.html file. We have put it inside a folder called *static* as this is the convention for these kind of files.

Listing 3: index.html

```
1  <!DOCTYPE html>
2  <html>
3  <head>
```

(continues on next page)

```
<pr
```

Listing 4: /static/keys.js

```
var last_key;
2
   document.onkeydown = function(evt) {
       evt = evt || window.event;
       if (evt.keyCode != last_key) {
           last_key = evt.keyCode;
6
            send_keydown(evt.keyCode);
       }
10
   document.onkeyup = function(evt) {
       last_key = 0;
12
       send_keyup(evt.keyCode);
13
14
15
   function send_keydown(keycode) {
16
       var xhttp = new XMLHttpRequest();
17
       xhttp.open("GET", "/keydown="+keycode, true);
       xhttp.setRequestHeader("Content-Type", "text/html");
19
       xhttp.send(null);
20
21
22
   function send_keyup(keycode) {
23
       var xhttp = new XMLHttpRequest();
24
       xhttp.open("GET", "/keyup="+keycode, true);
25
       xhttp.setRequestHeader("Content-Type", "text/html");
26
       xhttp.send(null);
27
28
```

Controlling motors (or anything)

In this example we will not show how to move the motors, instead the program will print out which arrow key you are pressing. You can then change the code to do whatever you want!

Listing 5: features.py

```
import os
import Pyro4
from edurov import WebMethod

def control_motors():
    """Will be started in parallel by the WebMethod class"""
    with Pyro4.Proxy("PYRONAME:KeyManager") as keys:
        with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
        while rov.run:
        (continues on next page)
```

5.3. Getting started 15

```
if keys.state('K_UP'):
10
                        print('Forward')
11
                    elif keys.state('K_DOWN'):
12
                        print('Backward')
                    elif keys.state('K_RIGHT'):
                        print('Right')
15
                    elif keys.state('K_LEFT'):
16
                        print('left')
17
18
   # Create the WebMethod class
19
   web_method = WebMethod(
20
       index_file=os.path.join(os.path.dirname(__file__), 'index.html'),
       runtime_functions=control_motors,
23
   # Start serving the web page, blocks the program after this point
24
   web_method.serve()
```

On line 22 we are telling the <code>WebMethod</code> that <code>control_motors</code> should be a <code>runtime_function</code>. This starts the function in another process and shuts it down when we stop the ROV. For more information visit the API page. Since this function is running in another process it needs to communicate with the server. It does this by the help of <code>Pyro4</code> (line 2). We then connect to the <code>KeyManager</code> and <code>ROVSyncer</code> on line 7-8. This let's us access the variables we need.

The resulting file structure:

```
project
— features.py
— index.html
— static
— keys.js
```

5.3.3 Making it pretty

At this point our web page is very boring. It is white with one image. Since it's a html file we can add whatever we want to it! This time we are adding a header, a button to stop the server and some information. In addition we are adding some styling that will center the content and make it look nicer.

Listing 6: index.html

```
<!DOCTYPE html>
   <html>
   <head>
       <title>Features</title>
       rel="stylesheet" type="text/css" href="./static/style.css">
       <script src="./static/keys.js"></script>
6
   </head>
   <body>
       <main>
           <h2>Welcome to the features example</h2>
10
           <img src="stream.mjpq">
11
           <q>
12
                <a href="stop">Stop server</a>
13
           </p>
14
           <p>
                Use arrow keys to print statements in the terminal window.
```

(continues on next page)

Listing 7: /static/style.css

```
body {
       margin: 0;
2
       padding: 0;
3
        font-family: Verdana;
4
   a {
        text-decoration: none;
   img {
       width: 100%;
10
       height: auto;
11
12
   main{
13
       width: 700px;
14
       margin-top: 20px;
15
       margin-left: auto;
16
       margin-right: auto;
17
18
```

```
project

features.py

index.html

static

keys.js

style.css
```

5.3.4 Displaying sensor values

Coming soon

5.3.5 Custom responses

In some cases you want to display information in the browser that you want to create yourself in a python function. The WebMethod has a parameter exactly for this purpose.

Listing 8: features.py

```
import os
import subprocess

import Pyro4

from edurov import WebMethod

def my_response(not_used, path):

(continues on next page)
```

5.3. Getting started 17

```
"""Will be called by the web server if it not able to process by itself"""
10
       if path.startswith('/cpu_temp'):
11
           cmds = ['/opt/vc/bin/vcgencmd', 'measure_temp']
12
           return subprocess.check_output(cmds).decode()
13
       else:
           return None
15
16
17
   def control_motors():
18
       """Will be started in parallel by the WebMethod class"""
19
       with Pyro4.Proxy("PYRONAME: KeyManager") as keys:
20
           with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
21
22
                while rov.run:
                    if keys.state('K_UP'):
23
                        print('Forward')
24
                    elif keys.state('K_DOWN'):
25
                        print('Backward')
26
                    elif keys.state('K_RIGHT'):
27
                        print('Right')
28
                    elif keys.state('K_LEFT'):
29
                        print('left')
30
31
32
   # Create the WebMethod class
33
   web_method = WebMethod(
       index_file=os.path.join(os.path.dirname(__file__), 'index.html'),
       runtime_functions=control_motors,
36
       custom_response=my_response
37
38
   # Start serving the web page, blocks the program after this point
39
   web_method.serve()
```

Listing 9: index.html

```
<!DOCTYPE html>
   <html>
2
   <head>
       <title>Features</title>
       <link rel="stylesheet" type="text/css" href="./static/style.css">
5
       <script src="./static/keys.js"></script>
       <script src="./static/extra.js"></script>
   </head>
   <body>
10
           <h2>Welcome to the features example</h2>
11
           <img src="stream.mjpg">
12
                <a href="stop">Stop server</a>
                <button onclick="cpuTemp()">Display CPU temp</button>
15
           16
           >
17
               Use arrow keys to print statements in the terminal window.
18
           </main>
21
   </body>
   </html>
```

Listing 10: /static/extra.js

```
function cpuTemp() {
    var xhttp = new XMLHttpRequest();
    xhttp.onreadystatechange = function() {
        if (this.readyState == 4 && this.stat == 200) {
            alert('The CPU temperature is '+this.responseText);
    };
    xhttp.open("GET", "cpu_temp", true);
    xhttp.send();
}
```

As an example we have created a button in index.html (line 15) which calls a function in extra.js that asks the server what the CPU temperature is. The new .js file is included as usual (index.html (line 7)). On line 7 in extra.js we send a GET request with a value of *cpu_temp*. The server does not know how it should answer this request, but since we have defined a custom_response (line 37) in features.py the request is forwarded to this function and we can create the response our self!

Note that this function needs to accept *two* parameters whereas the last one is path that is requested. If the path starts with /cpu_temp we can return the value, else return None.

```
project

— features.py
— index.html
— static
— keys.js
— style.css
— extra.js
```

5.3.6 Adding more pages

Coming soon

5.4 Examples

Tip: The following examples can be downloaded from the eduROV examples folder.

5.4.1 Minimal working code

This is a bare minimum example so that the image stream and nothing more can be seen in the browser. A great starting point if you want to expand the functionality yourself.

Listing 11: minimal.py

```
from os import path
from edurov import WebMethod
web_method = WebMethod(
```

5.4. Examples

(continues on next page)

```
index_file=path.join(path.dirname(__file__), 'index.html')
)
web_method.serve()
```

Listing 12: index.html

5.4.2 Features

An example created to explain most of the features in the edurov package. See the *Getting started* page in the official documentation for a full walkthrough.

Listing 13: features.py

```
import os
import subprocess
import Pyro4
from edurov import WebMethod
def my_response(not_used, path):
    """Will be called by the web server if it not able to process by itself"""
    if path.startswith('/cpu_temp'):
        cmds = ['/opt/vc/bin/vcgencmd', 'measure_temp']
        return subprocess.check_output(cmds).decode()
    else:
        return None
def control_motors():
    """Will be started in parallel by the WebMethod class"""
   with Pyro4.Proxy("PYRONAME:KeyManager") as keys:
        with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
            while rov.run:
                if keys.state('K_UP'):
                    print('Forward')
                elif keys.state('K_DOWN'):
                    print('Backward')
                elif keys.state('K_RIGHT'):
                    print('Right')
                elif keys.state('K_LEFT'):
                    print('left')
```

(continues on next page)


```
# Create the WebMethod class
web_method = WebMethod(
   index_file=os.path.join(os.path.dirname(__file__), 'index.html'),
   runtime_functions=control_motors,
   custom_response=my_response
)
# Start serving the web page, blocks the program after this point
web_method.serve()
```

Listing 14: index.html

```
<!DOCTYPE html>
<html>
<head>
   <title>Features</title>
   <link rel="stylesheet" type="text/css" href="./static/style.css">
   <script src="./static/keys.js"></script>
    <script src="./static/extra.js"></script>
</head>
<body>
        <h2>Welcome to the features example</h2>
        <img src="stream.mjpg">
        <q>
            <a href="stop">Stop server</a>
            <button onclick="cpuTemp()">Display CPU temp</button>
        </p>
        <p>
           Use arrow keys to print statements in the terminal window.
        </main>
</body>
</html>
```

5.4. Examples 21

5.4.3 Wireless RC car with camera feed



Create your very own wireless RC car with camera! The streaming video can be viewed in a browser on any device on the same network, it is controlled by using the arrow keys on the keyboard.

Bill of materials

Name	Price USD	Comment
Raspberry Pi Zero WH	18	A full size board can also be used
Raspberry Pi Camera Module V2	33	
DC 6V 210RPM Geard Motor Wheel Kit	23	found on eBay
L298N Dual H Bridge Motor Controller Board	1.8	found on eBay
DC-DC 5V 12V Step Down Module Converter 3A	1.6	found on eBay
Total	76	

In addition you will need a swivel wheel, M3/M2.5 bolts and nuts, cables and connectors, 12V battery and a car frame. The car frame used in the picture above was cut from 3mm MDF with a laser cutter and can be found here.

CAD files

Visit https://grabcad.com/library/772279

5.4.4 Engage eduROV

This example is used to control the ROV used in the eduROV project, see www.edurov.no.

Listing 15: start.py

```
import os
import time
import Pyro4
from edurov import WebMethod
from edurov.utils import detect_pi, serial_connection, send_arduino, \
    receive_arduino, free_drive_space, cpu_temperature
if detect_pi():
    from sense_hat import SenseHat
def valid_arduino_string(arduino_string):
    if arduino_string:
        if arduino_string.count(':') == 2:
                [float(v) for v in arduino_string.split(':')]
                return True
            except:
                return False
    return False
def arduino():
   lastState = '0000'
    ser = serial_connection()
    # 'letter': [position, value]
    config = \{'w': [0, 1],
              's': [0, 2],
              'a': [1, 1],
              'q': [1, 2],
              'd': [2, 1],
              'e': [2, 2]}
   with Pyro4.Proxy("PYRONAME:KeyManager") as keys:
        with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
            keys.set_mode(key='l', mode='toggle')
            while rov.run:
                dic = keys.qweasd_dict
                states = [0, 0, 0, 0]
                for key in config:
                    if dic[key]:
                        states[config[key][0]] = config[key][1]
                states[3] = int(keys.state('1'))
                state = ''.join([str(n) for n in states])
                if state != lastState:
                    lastState = state
                    if ser:
                        send_arduino(msg=state, serial_connection=ser)
                    else:
                        print (state)
                if ser:
```

(continues on next page)

5.4. Examples 23

```
arduino_string = receive_arduino(serial_connection=ser)
                    if valid_arduino_string(arduino_string):
                        v1, v2, v3 = arduino_string.split(':')
                        rov.sensor = {
                            'tempWater': float(v1),
                             'pressureWater': float (v2),
                             'batteryVoltage': float(v3)
                        }
def senser():
    sense = SenseHat()
    with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
        while rov.run:
            orientation = sense.get_orientation()
            rov.sensor = {'temp': sense.get_temperature(),
                          'pressure': sense.get_pressure() / 10,
                          'humidity': sense.get_humidity(),
                          'pitch': orientation['pitch'],
                          'roll': orientation['roll'] + 180,
                          'yaw': orientation['yaw']}
def system_monitor():
    with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
        while rov.run:
            rov.sensor = {'free_space': free_drive_space(),
                          'cpu_temp': cpu_temperature() }
            time.sleep(10)
def main(video_resolution='1024x768', fps=30, server_port=8000, debug=False):
    web_method = WebMethod(
        index_file=os.path.join(os.path.dirname(__file__), 'index.html'),
        video_resolution=video_resolution,
        fps=fps,
        server_port=server_port,
        debug=debug,
        runtime_functions=[arduino, senser, system_monitor]
    web method.serve()
if __name__ == '__main__':
    main()
```

Listing 16: index.html

(continues on next page)

```
<link rel="stylesheet" type="text/css" href="./static/style.css">
 <link rel="stylesheet" type="text/css" href="./static/bootstrap.css">
</head>
<body onload="set_size()">
<div class="grid-container">
 <div class="d-none d-md-block side-panel " style="display:none;">
   <div class="card bg-light cinema">
     <h5 class="card-header">Sensors</h5>
     <div class="card-body">
       <h5>ROV</h5>
       Temperature
           &#8451
         Pressure
           kPa
         Humidity
           %
         Pitch
           & #176
         Roll
           &#176
         Yaw
           &#176
         </t.r>
         <h5>Water</h5>
       Temperature
           &#8451
         Pressure
           kPa
```

(continues on next page)

5.4. Examples 25

```
</div>
     </div>
     <div class="card bg-light cinema">
         <h5 class="card-header">System</h5>
         <div class="card-body">
            Battery
                  V
               Disk space
                  MB
               CPU temp
                  &#8451
               </div>
     </div>
  </div>
  <div class="center-panel">
     <img id="image" src="stream.mjpg">
     <img class="rollOverlay" id="rollOverlay" src="./static/roll.png">
  <div class="d-none d-md-block side-panel">
     <div class="card bg-light cinema">
         <h5 class="card-header">Options</h5>
         <div class="card-body">
            <button type="button" onclick="toggle_armed()" id="armBtn"</pre>
                  class="btn btn-outline-success btn-sm btn-block"
                  title="Use this to arm the robot">
               Arm
            </but.t.on>
            <button type="button" onclick="rotate_image()"</pre>
                  class="btn btn-outline-primary btn-sm btn-block"
                  title="Will rotate the video 180 degrees">
               Flip video
            </button>
            <button type="button" onclick="toggle_roll()" id="rollBtn"</pre>
                  class="btn btn-outline-primary btn-sm btn-block active"
                  title="Toggle the roll indicator on/off">
               Roll
            </button>
            <button type="button" onclick="toggle_cinema()"</pre>
                  class="btn btn-outline-primary btn-sm btn-block"
                  title="Toggle cinema mode which hides everything except video
→">
```

(continues on next page)

```
Cinema
             </button>
             <button type="button" onclick="set_update_frequency()"</pre>
                   class="btn btn-outline-primary btn-sm btn-block"
                   title="Changes the sensor update frequency to desired value">
                Sensor frequency
             </button>
             <button type="button" onclick="toggle_light()" id="lightBtn"</pre>
                   class="btn btn-outline-warning btn-sm btn-block"
                   title="Toggle the light on the ROV on/off">Light
             </button>
             <button type="button" onclick="stop_rov()"</pre>
                   class="btn btn-outline-danger btn-sm btn-block"
                   title="Stops the ROV, this page will stop working">
                Shutdown
             </button>
         </div>
      </div>
      <div class="card bg-light cinema">
         <h5 class="card-header">Hotkeys</h5>
         <div class="card-body">
             Fullscreen
                Lights
                Cinema
                <t.r>
                   Arm
                </div>
      </div>
   </div>
</div>
</body>
</html>
```

5.5 API

5.5. API 27

Tip: If you are having a hard time, you can always have a look at the examples page where the classes, methods and parameters are used in practice.

5.5.1 WebMethod

class edurov.core. WebMethod (index_file, video_resolution='1024x768', fps=30, server_port=8000, debug=False, runtime_functions=None, custom_response=None)

Starts a video streaming from the rasparry pi and a webserver that can handle user input and other requests.

Parameters

- index_file (str) absolute path to the frontpage of the webpage, must be called index.html
- video_resolution (str, optional) a string representation of the wanted video resolution in the format WIDTHxHEIGHT
- fps (int, optional) wanted framerate, may not be achieved depending on available resources and network
- server_port (int, optional) the web page will be served at this port
- **debug** (bool, optional) if set True, additional information will be printed for debug purposes
- runtime_functions (callable or list, optional) should be a callable function or a list of callable functions, will be started as independent processes automatically
- **custom_response** (*callable*, *optional*) if set, this function will be called if default web server is not able to handle a GET request, should return a str or None. If returned value starts with redirect= followed by a path, the browser wil redirect the user to this path. The callable must accept two parameters whereas the second one is the requested path

Examples

```
>>> import os
>>> from edurov import WebMethod
>>>
>>> file = os.path.join(os.path.dirname(__file__), 'index.html', )
>>> web_method = WebMethod(index_file=file)
>>> web_method.serve()
```

serve (timeout=None)

Will start serving the web page defined by the index_file parameter

Parameters timeout (*int*, *optional*) – if set, the web page will only be served for that many seconds before it automatically shuts down

Notes

This method will block the rest of the script.

5.5.2 ROVSyncer

```
class edurov.sync.ROVSyncer
```

Holds all variables for ROV related to control and sensors

Examples

```
>>> import Pyro4
>>>
>>> with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
>>> while rov.run:
>>> print('The ROV is still running')
```

actuator

Dictionary holding actuator values

Getter Returns actuator values as dict

Setter Update actuator values with dict

Type dict

run

Bool describing if the ROV is still running

Getter Returns bool describing if the ROV is running

Setter Set to False if the ROV should stop

Type bool

sensor

Dictionary holding sensor values

Getter Returns sensor values as dict

Setter Update sensor values with dict

Type dict

5.5.3 KeyManager

```
class edurov.sync.KeyManager
```

Keeps control of all user input from keyboard.

Examples

```
>>> import Pyro4
>>>
>>> with Pyro4.Proxy("PYRONAME:KeyManager") as keys:
>>> with Pyro4.Proxy("PYRONAME:ROVSyncer") as rov:
>>> keys.set_mode(key='l', mode='toggle')
>>> while rov.run:
>>> if keys.state('up arrow'):
>>> print('You are pressing the up arrow')
>>> if keys.state('l'):
```

(continues on next page)

5.5. API 29

```
>>> print('light on')
>>> else:
>>> print('light off')
```

Note: When using the methods below a **key identifier** must be used. Either the keycode (int) or the KeyASCII or Common Name (str) from the table further down on this page can be used. Using keycode is faster.

arrow_dict

Dictionary with the state of the keys up arrow, down arrow, left arrow and right arrow

keydown (key, make_exception=False)

Call to simulate a keydown event

Parameters

- **key** (int or str) key identifier as described above
- make_exception (bool, optional) As default an exception is raised if the key is not found, this behavior can be changed be setting it to False

keyup (key, make_exception=False)

Call to simulate a keyup event

Parameters

- **key** (*int* or str) key identifier as described above
- make_exception (bool, optional) As default an exception is raised if the key is not found, this behavior can be changed be setting it to *False*

qweasd_dict

Dictionary with the state of the letters q, w, e, a, s and d

set (key, state)

Set the state of the key to True or False

Parameters

- **key** (*int* or *str*) key identifier as described above
- state (bool) True or False

 $\mathtt{set}_\mathtt{mode}\,(\mathit{key},\mathit{mode}\,)$

Set the press mode for the key to hold or toggle

Parameters

- **key** (*int* or *str*) key identifier as described above
- mode (str) hold or toggle

state (key)

Returns the state of key

Parameters key (int or str) – key identifier as described above

Returns state – *True* or *False*

Return type bool

Keys table

KeyASCII	ASCII	Common Name	Keycode
K_BACKSPACE	\b	backspace	8
K_TAB	\t	tab	9
K_CLEAR		clear	
K_RETURN	\r	return	13
K_PAUSE		pause	
K_ESCAPE	^ [escape	27
K_SPACE		space	32
K_EXCLAIM	!	exclaim	
K_QUOTEDBL	"	quotedbl	
K_HASH	#	hash	
K_DOLLAR	\$	dollar	
K_AMPERSAND	&	ampersand	
K_QUOTE		quote	
K_LEFTPAREN	(left parenthesis	
K_RIGHTPAREN)	right parenthesis	
K_ASTERISK	*	asterisk	
K_PLUS	+	plus sign	
K_COMMA	,	comma	
K_MINUS	_	minus sign	
K_PERIOD		period	
K_SLASH	/	forward slash	
K_0	0	0	48
K_1	1	1	49
K_2	2	2	50
K_3	3	3	51
 K_4	4	4	52
 K_5	5	5	53
K_6	6	6	54
K_7	7	7	55
K_8	8	8	56
K_9	9	9	57
K_COLON	:	colon	
K_SEMICOLON	;	semicolon	
K_LESS	<	less-than sign	
K_EQUALS	=	equals sign	
K_GREATER	>	greater-than sign	
K_QUESTION	?	question mark	
K_AT	@	at	
K_LEFTBRACKET	-	left bracket	
K_BACKSLASH	\	backslash	
K_RIGHTBRACKE	т 1	right bracket	
K_CARET	^	caret	
K_UNDERSCORE		underscore	
K_BACKQUOTE	_	grave	
K_a	2	-	65
	a b	a b	66
K_b			67
K_c	c d	C	68
K_d		d	
K_e	e	e	69
K_f	f	f	70
K_g	g	g	71
K_h	h	h ·	72
K_i	i	i	73
K_j	j	j	74

(continues on next page)

5.5. API 31

K_h k k k 75 K_l 1 1 76 K_m m m m 77 K_n n n n 78 K_0 0 0 0 0 79 K_p p p p 80 K_q q q 91 K_r r r r 82 K_s s s 8 83 K_t t t 0 84 K_u u u 95 K_u v v v 86 K_v v v v v 86 K_v v v v 86 K_v v v v v v v 86 K_v v v v v v 86 K_v v v v v v v 86 K_v v v v v v 86 K_v v v v v v v 86 K_v v v v v v v 86 K_v v v v v v v v 86 K_v v v v v v v v v v v 86 K_v v v v v v v v v v v v v 86 K_v v v v v v v v v v v v v v v v v v v					(continued from previous page)
K.m n n 77 K.n n n n 78 K.n n n n 18 K.n n n n n 78 80 K.n n n n n 18 K.n n n n n 78 80 K.n n n n n 18 K.n n n n n 18 80 K.n n n n n n n 18 80 K.n n n n n n n 18 80 K.n n n n n n n 18 80 K.n n n n n n n n n n n n n n n n n n n	K_k	k	k	75	
K_m m m m 777 K_n n n n 78 K_n o o o 79 K_p p p p 80 K_r q q q 81 K_r = r r 82 K_s s s s 83 K_t t t t 84 K_u u u 85 K_v v v v v 86 K_w w w 87 K_x x x x 88 K_y y y 98 K_z 2 2 2 2 90 K_DELETE delete K_RE0 Keypad 0 K_RE1 keypad 1 K_RE2 keypad 2 K_RE3 keypad 2 K_RE3 keypad 3 K_RE4 keypad 6 K_RE5 keypad 6 K_RE7 keypad 7 K_RE8 keypad 6 K_RE9 keypad 8 K_KP p keypad 8 K_KP p keypad 9 K_KP_DIVIDE / keypad divide K_RP_DIVIDE / keypad divide K_RP_MITTIPLY * keypad multiply K_MITTIPLY * keypad multiply K_MITTIPLY * keypad multiply K_MITTIPLY * keypad	K_1	1	1	76	
K_no		m	m	77	
K_O					
K_DP P P 80 80 K_C1					
K.G.					
K_T Y Y S S S S S S S S S S S S S S S S S					
K_S S S S S S S S S S S S S S S S S S S					
K_L					
K_U U U U W 85 K_V V V V RA 86 K_W W W W RA 87 K_X X X RA 88 K_Y Y Y SA 88 K_Y Y Y SA 88 K_Y Y Y SA 88 K_DELETE delete K_KPO					
K_W W W W W W W W K 86 K K W W W W W W W W W W W W W W W W W					
K_W W W W 87 K_X X X X 88 K_Y Y Y Y 99 89 K_Z Z Z Z 90 K_DELETE delete K_KPO					
K_X					
K_Y Y Y S 89 K_2 Z Z 90 K_2 Z Z 90 K_2 DELETE		W	W		
K_DELETE delete K_KP0 keypad 0 K_KP1 keypad 1 K_KP1 keypad 2 K_KP3 keypad 3 K_RP4 keypad 5 K_KP6 keypad 5 K_KP6 keypad 6 K_KP7 keypad 7 K_KP8 keypad 8 K_KP9 keypad 9 K_KP9 keypad 9 K_KP_DIVIDE / keypad period K_KP_DIVIDE / keypad multiply K_KP_MULTIPLY * keypad multiply K_KP_MULTIPLY * keypad multiply K_KP_BUS + keypad minus K_KP_EUS + keypad enter K_KP_EUS + keypad enter K_KP_EUS + keypad enter K_KP_EUS = keypad enter K_KP_EUS + keypad enter K_KP_EUS + keypad enter K_KP_EUS + keypad enter K_KP_EUS + keypad senter K		X	X		
K_DELETE K_KPO		У	У		
K_KP0	K_z	Z	Z	90	
K_KP1	K_DELETE		delete		
K_KP2 K_KP3 K_KP4 K_KP5 K_KP6 K_KP6 K_KP6 K_KP7 K_KP8 K_KP7 K_KP8 K_KP9 K_KP9 K_KP9 K_KP9 K_KP9 K_KP9 K_KP9 K_KP9 K_KP9 K_KP, PERIOD K_KP_DIVIDE K_KP_MULTIPLY K_KP, MULTIPLY K_K, M	K_KP0		keypad 0		
K_KP3	K_KP1		keypad 1		
K_KP3	K_KP2		keypad 2		
K_KP4 K_KP5 K_KP6 K_KP6 K_KP7 K_KP7 K_KP8 K_KP9 K_KP94 K_KP8 K_KP9 K_KP94 K_KP9 K_KP94 K_KP9 K_KP94 K_KP95 K_KP94 K_KP98 K_KP94 K_KP98 K_KP98 K_KP98 K_KP98 K_KP994 K_KP_ERIOD K_KP_DIVIDE K_KP,MINUS	K_KP3				
<pre>K_RP5</pre>					
K_KP6 K_KP7					
<pre>K_KP7 K_KP8</pre>					
K_KP8					
<pre>K_KP9</pre>					
<pre>K_KP_PERIOD . keypad period K_KP_DIVIDE / keypad divide K_KP_MULTIPLY * keypad multiply K_KP_MINUS - keypad minus K_KP_PLUS + keypad plus K_KP_ENTER \r keypad enter K_KP_EQUALS = keypad enter K_RP_EQUALS = keypad enter K_DOWN</pre>					
<pre>K_KP_DIVIDE / keypad divide K_KP_MULTIPLY * keypad multiply K_KP_MINUS</pre>					
K_RP_MULTIPLY * keypad minus K_RP_MINUS - keypad minus K_RP_PLUS + keypad plus K_RP_ENTER \r keypad enter K_RP_EQUALS = keypad equals K_UP up arrow 38 38 K_DOWN down arrow 40 40 K_RIGHT right arrow 37 37 K_INSERT insert 45 45 K_HOME home 36 36 K_END end 35 33 K_PAGEUP page up 33 34 K_F1 F1 F1 K_F2 F2 F2 K_F3 F3 F3 K_F4 F4 F4 K_F5 F5 F5 K_F6 F6 F6 K_F7 F7 F7 K_F8 F8 F8 K_F9 F9 F9 K_F10 F10 F10 K_F11 F11 F12 K_F12 F12 F12 K_F13 F14 F14					
K_KP_MINUS - keypad plus K_KP_PLUS + keypad plus K_KP_ENTER \r keypad enter K_KP_EQUALS = keypad equals K_UP up arrow 38 K_DOWN down arrow 40 K_RIGHT right arrow 39 K_LEFT left arrow 37 K_INSERT insert 45 K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 F1 K_F2 F2 F2 K_F3 F3 F3 K_F4 F4 F4 K_F5 F5 F5 K_F6 F6 F6 K_F7 F7 F8 K_F9 F9 F9 K_F10 F10 F12 K_F13 F13 F14					
<pre>K_KP_PLUS</pre>					
<pre>K_KP_ENTER \r keypad equals K_UP</pre>					
K_KP_EQUALS = keypad equals K_UP up arrow 38 K_DOWN down arrow 40 K_RIGHT right arrow 39 K_LEFT left arrow 37 K_INSERT insert 45 K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 F1 K_F2 F2 K_F3 K_F3 F3 F4 K_F5 F5 F5 K_F6 F6 F6 K_F7 F7 F7 K_F8 F8 F8 K_F9 F9 F1 K_F10 F10 F11 K_F12 F12 K K_F13 F13 F14					
K_UP up arrow 38 K_DOWN down arrow 40 K_RIGHT right arrow 39 K_LEFT left arrow 37 K_INSERT insert 45 K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 K_F2 K_F2 F2 K_F3 K_F3 F3 K_F4 K_F5 F5 K_F6 K_F6 F6 K_F7 K_F8 F8 K K_F9 F9 K K_F10 F10 K K_F11 F11 K K_F12 F12 K K_F13 F13 K K_F14 F14 F14					
K_DOWN down arrow 40 K_RIGHT right arrow 39 K_LEFT left arrow 37 K_INSERT insert 45 K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 K_F2 K_F3 F3 K K_F4 F4 K K_F5 F5 K K_F6 F6 K K_F7 F7 K K_F8 F8 K K_F9 F9 K K_F11 F11 K K_F12 F12 K K_F13 F13 K K_F14 F14 K		=			
K_RIGHT right arrow 39 K_LEFT left arrow 37 K_INSERT insert 45 K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 K K_F2 F2 K K_F3 F3 K K_F4 F4 K K_F5 F5 K K_F6 F6 K K_F7 F7 K K_F8 F8 K K_F9 F9 K K_F11 F11 K K_F12 F12 K K_F13 F13 K K_F14 F14 K			_		
K_LEFT left arrow 37 K_INSERT insert 45 K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 K K_F2 F2 K K_F3 F3 K K_F4 F4 K K_F5 F5 K K_F6 F6 K K_F7 F7 K K_F8 F8 K K_F9 F9 K K_F11 F11 K K_F12 F12 K K_F13 F13 K K_F14 F14 K	K_DOWN		down arrow		
K_INSERT insert 45 K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 K K_F2 F2 K K_F3 F3 K K_F4 F4 K K_F5 F5 K K_F6 F6 K K_F7 F7 K K_F8 F8 K K_F9 F9 K K_F11 F11 K K_F12 F12 K K_F13 F13 K K_F14 F14 K	K_RIGHT		right arrow		
K_HOME home 36 K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 K_F2 F2 K_F3 F3 K_F4 F4 K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14	K_LEFT		left arrow	37	
K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 F1 K_F2 F2 K_F3 K_F3 F3 K_F4 K_F4 F4 K_F5 K_F5 F5 K_F6 K_F6 F6 K_F7 K_F8 F8 K_F9 K_F9 F9 K_F10 K_F11 F11 K_F12 K_F13 F13 K_F14			insert		
K_END end 35 K_PAGEUP page up 33 K_PAGEDOWN page down 34 K_F1 F1 F1 K_F2 F2 K_F3 K_F3 F3 K_F4 K_F4 F4 K_F5 K_F5 F5 K_F6 K_F6 F6 K_F7 K_F8 F8 K_F9 K_F9 F9 K_F10 K_F11 F11 K_F12 K_F13 F13 K_F14	K_HOME		home	36	
K_PAGEDOWN page down 34 K_F1 F1 K_F2 F2 K_F3 F3 K_F4 F4 K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14			end	35	
K_PAGEDOWN page down 34 K_F1 F1 K_F2 F2 K_F3 F3 K_F4 F4 K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14	K_PAGEUP		page up	33	
K_F1 F1 K_F2 F2 K_F3 F3 K_F4 F4 K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F2 F2 K_F3 F3 K_F4 F4 K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F3 F3 K_F4 F4 K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F4 F4 K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F5 F5 K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F6 F6 K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F7 F7 K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F8 F8 K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F9 F9 K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F10 F10 K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F11 F11 K_F12 F12 K_F13 F13 K_F14 F14					
K_F12 F12 K_F13 F13 K_F14 F14					
K_F13 F13 K_F14 F14					
K_F14 F14					
	K_F14		F' 1 4		(continues on next page)

(continues on next page)

K_F15	F15
K_NUMLOCK	numlock
K_CAPSLOCK	capslock
K_SCROLLOCK	scrollock
K_RSHIFT	right shift
K_LSHIFT	left shift
K_RCTRL	right control
K_LCTRL	left control
K_RALT	right alt
K_LALT	left alt
K_RMETA	right meta
K_LMETA	left meta
K_LSUPER	left Windows key
K_RSUPER	right Windows key
K_MODE	mode shift
K_HELP	help
K_PRINT	print screen
K_SYSREQ	sysrq
K_BREAK	break
K_MENU	menu
K_POWER	power
K_EURO	Euro

5.5.4 Utilities

Different utility functions practical for ROV control

```
edurov.utils.cpu_temperature()
```

Checks and returns the on board CPU temperature

Returns temperature – the temperature

Return type float

```
edurov.utils.free_drive_space(as_string=False)
```

Checks and returns the remaining free drive space

Parameters as_string (bool, optional) – set to True if you want the function to return a formatted string. 4278 -> 4.28 GB

Returns space – the remaining MB in float or as string if *as_string=True*

Return type float or str

```
edurov.utils.receive_arduino(serial_connection)
```

Returns a message received over serial_connection

Expects that the message received starts with a 6 bytes long number describing the size of the remaining data. "0x000bhello there" -> "hello there".

Parameters serial_connection (object) – the serial. Serial object you want to use for receiving

Returns msg – the message received or None

Return type str or None

edurov.utils.receive_arduino_simple(serial_connection, min_length=1)

Returns a message received over serial_connection

5.5. API 33

Same as receive_arduino but doesn't expect that the message starts with a hex number.

Parameters

- **serial_connection** (*object*) the serial. Serial object you want to use for receiving
- min_length (int, optional) if you only want that the function to only return the string if it is at least this long.

Returns msg – the message received or None

Return type str or None

```
edurov.utils.send_arduino (msg, serial_connection)
```

Send the *msg* over the *serial_connection*

Adds a hexadecimal number of 6 bytes to the start of the message before sending it. "hello there" -> "0x000bhello there"

Parameters

- msg (str or bytes) the message you want to send
- **serial_connection** (*object*) the serial. Serial object you want to use for sending

```
edurov.utils.send_arduino_simple (msg, serial_connection)
```

Send the *msg* over the *serial_connection*

Same as send_arduino, but doesn't add anything to the message before sending it.

Parameters

- msg (str or bytes) the message you want to send
- **serial_connection** (*object*) the serial. Serial object you want to use for sending

edurov.utils.serial_connection(port='/dev/ttyACM0', baudrate=115200, timeout=0.05) Establishes a serial connection

Parameters

- port (str, optional) the serial port you want to use
- baudrate (int, optional) the baudrate of the serial connection
- timeout (float, optional) read timeout value

Returns connection – a serial. Serial object if successful or None if not

Return type class or None

Python Module Index

е

edurov.utils,33

36 Python Module Index

Index

Α actuator (edurov.sync.ROVSyncer attribute), 29 arrow_dict (edurov.sync.KeyManager attribute), 30 C cpu_temperature() (in module edurov.utils), 33 edurov.utils (module), 33 F free_drive_space() (in module edurov.utils), 33 K keydown() (edurov.sync.KeyManager method), 30 KeyManager (class in edurov.sync), 29 keyup() (edurov.sync.KeyManager method), 30 Q qweasd_dict (edurov.sync.KeyManager attribute), 30 R receive_arduino() (in module edurov.utils), 33 receive_arduino_simple() (in module edurov.utils), 33 ROVSyncer (class in edurov.sync), 29 run (edurov.sync.ROVSyncer attribute), 29 S send_arduino() (in module edurov.utils), 34 send arduino simple() (in module edurov.utils), 34 sensor (edurov.sync.ROVSyncer attribute), 29 serial connection() (in module edurov.utils), 34 serve() (edurov.core.WebMethod method), 28 set() (edurov.sync.KeyManager method), 30 set_mode() (edurov.sync.KeyManager method), 30 state() (edurov.sync.KeyManager method), 30 W WebMethod (class in edurov.core), 28