#### MrRoboto

### 1 How to setup system

#### 1.1 Initial computer settings

- 1. Install ubuntu 12.04 on your computer.
- 2. Install ROS GROOVY according to: http://wiki.ros.org/groovy/Installation/Ubuntu
- 3. Install git, type:
  - \$ sudo apt-get install git (in a terminal window)
    Password is ubuntu for the computer in the robot lab.
- 4. Clone the repository of the project. cd\* into a folder where you want the folder containing the code. Type:

  \$\int \text{oit clone ait} \( \text{Octable to prove matrix} \) 796 (robot security to \( \text{bh} \) 1.

\$ git clone git@github.com:matni796/robot-security-tsbb11 (\*cd is a terminal command. If your not familiar with navigation in terminal, see http://linuxcommand.org/lc3\_lts0020.php)

- 5. Source your own created packages in .bashrc: type: gedit /.bashrc add the line: source wherever\_path\_you\_put\_repository/robotsecuritytsbb11/catkin\_ws/src/devel/setup.bash
- 6. Install freenect, type:
  - $\$\ sudo\ apt\text{-}get\ install\ ros\text{-}groovy\text{-}freenect\text{-}stack$
  - \$ sudo apt-get install ros-groovy-freenect-launch
- Disable gspca kernel according to: http://openkinect.org/wiki/Getting\_ Started
- 8. cd into the installed folder and into catkin\_ws and type catkin\_make to build.

#### 1.2 Setup of DX100 controller

- 1. Make sure the controller's version supports MotoPlus applications, should be a version ending with -14. Current version (20131206) is DS3.53.01A-14.
- 2. Load parameters. The file ALL.PRM can be found in git repo, under the folder robot/. Transfer it to a cf card or usb. Start the controller regularly. Go into management mode (see below). Then go to:

EX MEMORY  $\rightarrow$  FOLDER, set folder where you put ALL.PRM.

## EX MEMORY $\rightarrow$ LOAD $\rightarrow$ PARAMETERS $\rightarrow$ BATCH PARAMETERS ALL.PRM

You might need to do a safety reset of the flash device. This is done by starting up the controller in Maintenance mode. In Maintenance Mode, enter Management mode. INITIALIZE  $\rightarrow$  system flash safety reset, might take a while, wait for beep (CHECK NAME). Shut off controller and restart it regularly.

NOTE: Might change the setup of the controller. Should be done with caution. Contact Yaskawa if uncertain.

- 3. To install MotoPlus application, follow the tutorial on http://wiki.ros.org/motoman\_driver/Tutorials/InstallServer.
  - For step 3 in tutorial, see PDF file *MotoPlus Application Installation* in folder *robot*/. Follow the instructions on step 2.1. The application file: *MpRosSia20.out* to be loaded is also in the in the *robot*/ folder.

NOTE: We have used an .out file hardcoded for a SIA20D robot. This version does not come with the motoman files from ROS.

• For step 4 in tutorial, transfer INIT\_ROS.JBI to CF card or USB device. File can be found under ../catkin\_ws/src/motoman/motoman\_driver/Inform/DX100/. Start the controller regularly. In menu, go to:

Ex MEMORY  $\rightarrow$  FOLDER move to the folder where you put  $INIT\_ROS.JBI$  file. Then:

Ex Memory  $\rightarrow$  LOAD  $\rightarrow$  job.

#### 1.3 Setup of computer network settings

- 1. Connect the computer to the controller via ethernet cable. Use the output CN104 on the YCP01 board.
- 2. Edit settings for wired/local network on computer. Set computer wired network address to 192.168.255.9 and netmask 255.255.255.0.

NOTE: On the computer, running Ubuntu 12.04, in the robot lab, there is a profile for the connection named "DX100". When connecting the controller to the computer via ethernet, choose this.

# 1.4 Run program/Use of interface between controller and computer.

Källskript bör ordnas.

Follow the instructions on http://wiki.ros.org/motoman\_driver/Tutorials/Usage.

- On step 3, enter the controller IP **192.168.255.1**.
- On step 3.1.2.1, use the path ..catkin\_ws/src/motoman/motoman\_config/cfg/sia20D\_mesh.xml
- To obtain visualization, type: \$ roslaunch sia20d\_mesh\_arm\_navigation planning\_scene\_warehouse\_viewer\_sia20d\_mesh.launch
- Choose the correct frame, baselink something...
- vad mer behöver man köra. kan vi skriva ett källskript som sköter ovanstående.