

created: 15.07.15/Praher. checked: 15.07.15/Kürnst. released: 16.07.15/SchwarzR.

E2 Interface for EE892-Series:

Additional to the specification E2 interface "specification E2-interface_ex.doc": For additional information please see www.epluse.com

Readable parameters

These parameters/values [hex] can be read via E2 interface:

| rnese parameters/var | ues [nex] can be rea | au via Ez iliterrace. | | | |
|------------------------------|----------------------------|--|---|---|--------|
| command: | return-value | kind | format | measuring-range | output |
| Group (two bytes) | 0x037C (892 _d) | | unsigned int. | | |
| Sub-Group | 0x09 | | byte | | |
| Available measured variables | 0x08 | | byte | | |
| Statusbyte: ¹⁾ | 0x0_ | | byte | | |
| Measuring value 1: | | Not defined | | | |
| Measuring value 2: | | Not defined | | | |
| Measuring value 3: | eg. for handhelds | | 0 – 2000 or 0 – 5000 or 0 – 10000 | ppm | |
| Measuring value 4: | | CO2 Averaged Value eg. for climate control | unsigned int. | 0 – 2000 or 0 – 5000 or 0 – 10000 | ppm |

 $^{^{\}rm 1)}$ Gives information on whether last measurement was successful

Available parameters in custom area

- Firmware-Mainversion
- Firmware-Subversion
- Offset CO₂
- Gain CO₂
- Upper calibration point CO₂
- Lower calibration point CO₂

- Last customer adjustment
- Last customer adjustment of CO₂
- Serial number
- Part name
- Error code
- global measurement time interval

Electrical requirements

| 2100ti 10ti 1 0quii 0monto | | | | | | |
|----------------------------|------------------|---------|---------|------|---|--|
| Symbol | Parameter | Minimum | Maximum | Unit | Remark | |
| V_{DD} | Bus-High-Voltage | 3,6 | 5,2 | V | For minimizing the supply current use 4.5V to 5.0V | |
| f _{CLK} | Clock frequency | 500 | 5000 | Hz | The highest achievable data rate depends on the | |
| Rup | Pull-up resistor | 4,7 | 100 | kΩ | combination of line capacity and the pull-up resistors. | |

Error Code List

| Error Code | Description | | |
|------------|--|--|--|
| 1 | Supply Voltage Low detected | | |
| 200 | Sensor Counts Low | | |
| | possible damage of electronic or sensor-cell | | |
| 201 | Sensor Counts High | | |
| | possible damage of electronic or sensor-cell | | |
| 202 | Supply Voltage Breakdown at current peak for measurement | | |
| | maybe the internal resistance of supply unit is to high | | |

File: E2_Interface_EE892_v1.3.docx




created: 15.07.15/Praher. checked: 15.07.15/Kürnst. released: 16.07.15/SchwarzR.


Measurement Timing

| | minimum | typical | maximum |
|-------------------|---------|---------|---------|
| t pwrup | | 5s | 10s |
| t _{stab} | | 4,3s | 9,3s |
| t meas | | 0,7s | |
| t _{mti} | 15s | | 3600s |

Examples:



For measuring time interval > 15s a measurement can be triggered by reading the status byte, nevertheless only if the last measurement dates back longer than 10s





created: 15.07.15/Praher. checked: 15.07.15/Kürnst. released: 16.07.15/SchwarzR.

Timing for write commands

Writing a byte to the device (with control byte 0x10) takes <=150ms and can be done by writing the flash memory. During the writing time E2 communication interrupts are deactivated. The attempt to communicate with the device while the flash is being written forces the clock low extension which holds the clock line low until the write routine has finished.

Note: When writing the measurement interval (address 0xC6 and 0xC7) both values will be written together into the flash. Writing will start after sending both bytes and will cause a communication delay of <=300ms.

File: E2_Interface_EE892_v1.3.docx