Ages 8 to adult 2-8 PLAYERS

B-8920

NOTE

This equipment has been tested and found to comply with the limits for a Class Bidigital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no quarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reprient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- + Consult the dealer or an experienced radio/TV technician for help.





in this FAST-ACTION GRAD of categories & letters!

THE CH-CH-CHILLY
PASS-AROUND
GATEFORY (FAME)





FREEZE UP'S COOL FEATURES



OBJECT OF THE GAME

To be the last player with time remaining in the game.

At the beginning of the game, each player starts with 60 seconds. As the timer ticks down during his or her turn, a player must name something in a specified category (such as fruits) that begins with a specific letter (such as P). The faster a player responds, the less time is deducted from his or her all otted time. As the categories and letters keep coming and players' time runs out, they are eliminated. The last player in the game with time remaining is the **WINNER**.

GETTING STARTED

Decide on the number of players. Because you pass Freeze Up around, sit close to one another in the order that you will play (Player 1, Player 2, Player 3, etc.).

PLAYING FREEZE UP

- 1. Turn Freeze Up on by pressing the On/Off button.
- Choose the game mode (Auto or Manual). See page 6 for a description of game modes.
- Press the Players Button to choose the number of players (from 2 to 8) for your game, Wait several seconds until the unit acknowledges the number of chosen players.
- Press the GO Button. Freeze Up announces Player 1's turn, gives a category and letter at random (for example, "Name a sport, letter P"), and starts the timer ticking.
- Player 1 quickly thinks of an answer (for example, "tennis").
 Player 1 shouts it out, presses the FREEZE Button to halt the timer, and passes the unit to the next player.
- The game continues with players passing Freeze Up around and taking turns answering questions.

BRAIN FREEZE!

"NAME A SPORT, LETTER T!"

It's easy to freeze up when the timer is ticking! If you get stuck, don't lose your cool. You have OPTIONS!



Press the **New Category** button for a new category with the same letter (for example, "Name a flower, letter T").



Press the New Letter button for a new letter with the same category (for example, "Name a sport, letter B").

WINNING THE GAME

The last player in the game with time remaining on the clock is the Freeze Up champion!

CHALLENGING A WORD

"HEY, I THINK THAT ANSWER IS WRONG!"

If you disagree with a player's answer, challenge it. However, you can only challenge the player immediately before you. For example, Player 1 says a word and presses FREEZE.

Player 2 disagrees with Player 1's word choice and, on his turn, presses the CHALLENGE button. The timer is stopped while the rest of the players discuss the challenged word and vote to accept or reject it. The majority rules. In case of a tievote, the challenged player presses the Challenge Button again to start his turn over with a new category and letter.





If the group votes to ACCEPT the word, the challenger presses the Word Accepted button. The challenger loses five seconds from his or her remaining time.





If the group votes to **REJECT** the word, the challenger presses the Word Rejected button. The challenged player loses five seconds from his or her remaining time.



NAME A TV SHOW, LETTER A!



NOTE: PRESSING EITHER BUTTON RESULTS IN A 3-SECOND PENALTY, BUT IF YOU'RE FREEZING UP, IT CAN BE WORTH IT!

NOTE: In the case of a two-player game, players may consult a dictionary or encyclopedia to check the challenged word.

CHANGING GAME MODE

Freeze Up has two fun game modes - Auto and Manual.



AUTO MODE

In an Auto mode game, the next player's turn begins automatically after the previous player has finished his or her turn by pressing the FREEZE button.

MANUAL MODE

To play a slower-paced, player-controlled game, switch to Manual mode. In a Manual mode game, each player must press the GO button to start his or her turn after the previous player has pressed the FREEZE button.

NAME SOMETHING CRUNCHY, LETTER P!

NAME A FRUIT, LETTER B!

NAME A SPORT, LETTER T!

CARING FOR FREEZE UP

Clean Freeze Up with a damp or dry cloth.

Do not immerse in water or spray liquid on Freeze Up.

BATTERY INSTALLATION INSTRUCTIONS

- Open the battery compartment door on the back of Freeze Up and insert 3 AA batteries (not included).
 - · Do not use rechargeable batteries.
 - . Do not mix old and new batteries.
 - Do not mix different types of batteries: alkaline, standard (carbon zinc) or rechargeable (nickel-cadmium) batteries.
 - Non-rechargeable batteries are not to be recharged.
 - Rechargeable batteries are to be removed from the toy before being charged.
 - Rechargeable batteries are only to be charged under adult supervision.
 - Only batteries of the same or equivalent type as recommended are to be used.
 - · Batteries are to be inserted with the correct polarity.
 - Exhausted batteries are to be removed from the toy.
 - The supply terminals are not to be short-circuited.
- 2. Close the battery compartment door and secure.

