# NITROCOMPUTE ASSEMBLER DOCUMENTATION

# **TABLE OF CONTENT**

TABLE OF CONTENT	 01
DESCRIPTION	 02
INSTALLATION	 02
INSTRUCTION SET	 02
ALU OPERATION SYNTAX	 03
ADD	 03
SUB	 03
MUL	 04
DIV	 04
SHL	 04
SHR	 05
AND	 05
OR	 05
CISC OPERATION SYNTAX	 06
MOVR	 06
MOVI	 06
LOAD	 06
STORE	 06
JMP	 07
JMPZ	 07
JMPN	 07
HALT / NOP	 07
DEVELOPERS	 08
APPENDIX	 08
LIST OF FIGURES	
FIGURE 1.0	 04
FIGURE 2.0	 05

# **DESCRIPTION**

The NitroCompute Assembler was built using Python programming language and converts Assembly Language into hexadecimal code fed into The NitroCompute microprocessor. When executed, an application console which has a menu bar, text area and title bar appears.

The menu bar contains the following drop down menus.;

- File
  - Open: Allow user to provide input from a text file
  - Exit: Close application
- Save
  - Save: Store the content in the text area into a specified file.
- Assemble
  - Assemble: Allow user to convert the assembly code into a hexadecimal code and store the output into a specified file.

The text area is a rectangular are with a white background where the user can type the assembly code.

# **INSTALLATION**

This application is an executable file that requires no prior installation.

# **INSTRUCTION SET**

There are two main categories of instructions, namely;

- ALU operations
- Miscellaneous operations

# **ALU OPERATION SYNTAX**

Under the ALU, there are 8 operations;

• **ADD** - ADDITION

• SUB - SUBTRACTION

• MULT - MULTIPLICATION

• **DIV** - DIVISION

• SHL - LOGICAL SHIFT LEFT

• SHR - LOGICAL SHIFT RIGHT

• AND - LOGICAL MULTIPLICATION

• OR - LOGICAL ADDITION

The general syntax for an ALU operation is,

[ALU] [RA],[RB],[RC]

Where:

ALU is the ALU operation

**RA** is the first register

**RB** is the second register

**RC** is the destination register

#### **ADD**

The desired operation to be performed is:

2 + 3 = 5

In assembly representation,

[ADD] [R1],[R2],[R3]

Where:

**ADD** is the operation being performed on the numbers

R1 contains the number 2

R2 contains the number 3

R3 is the register that will contains the result of the operation

## **SUB**

The desired operation to be performed is:

6 - 2 = 5

In assembly representation,

[SUB] [R1],[R2],[R3]

Where:

**SUB** is the operation being performed on the numbers

R1 contains the number 6

R2 contains the number 2

R3 is the register that will contains the result of the operation

#### **MUL**

The desired operation to be performed is:

$$2 \times 3 = 6$$

In assembly representation,

Where:

MULT is the operation being performed on the numbers

R1 contains the number 2

R2 contains the number 3

R3 is the register that will contains the result of the operation

## DIV

The desired operation to be performed is:

$$4 \div 2 = 2$$

In assembly representation,

Where:

**DIV** is the operation being performed on the numbers

R1 contains the number 4

**R2** contains the number 2

R3 is the register that will contains the result of the operation

## SHL

The desired operation to be performed is:




Figure 1.0

In assembly representation,

Where:

**SHL** is the operation being performed on the numbers

R1 contains the number 4 which is the value we want to do the operation on

**R2** contains a number that tell the processor how many times to shift left. In this case the value will contain 1 in order to perform our required operation

R3 is the register that will contains the result of the operation

#### **SHR**

The desired operation to be performed is:




Figure 2.0

In assembly representation,

[SHR] [R1],[R2],[R3]

Where:

**SHR** is the operation being performed on the numbers

R1 contains the number 4 which is the value we want to do the operation on

**R2** contains a number that tell the processor how many times to shift right. In this case the value will contain 1 in order to perform our required operation

R3 is the register that will contains the result of the operation

## **AND**

The desired operation to be performed is:

2 & 3 = 2

In assembly representation,

[AND] [R1],[R2],[R3]

Where:

**AND** is the operation being performed on the numbers

R1 contains the number 2

**R2** contains the number 3

R3 is the register that will contains the result of the operation

## OR

The desired operation to be performed is:

2 OR 3 = 3

In assembly representation,

[ADD] [R1],[R2],[R3]

Where:

**OR** is the operation being performed on the numbers

R1 contains the number 2

**R2** contains the number 3

R3 is the register that will contains the result of the operation

## CISC OPERATION SYNTAX

Under the MISC, there are 8 different operations;

**MOVR** - REGISTER TO REGISTER MOVE

**MOVI** - IMMEDIATE VALUE TO REGISTER MOVE

**LOAD** - PUSH CONTENT IN MEMORY TO REGISTER

**STORE** - SAVE DATA FROM REGISTER TO MEMORY

JMP - EXECUTE FROM SPECIFIED LOCATION IN MEMORY

JMPZ - EXECUTE FROM SPECIFIED LOCATION IF ZERO FLAG IS TRIGGERED

JMPN - EXECUTE FROM LOCATION IF NEGATIVE FLAG IS TRIGGERED

HALT/NOOP - STOP MICROPROCESSOR

## **MOVR**

This operation allows us to move the contents from one register to another register.

The syntax for a MOVR operation is,

[MOVR] [RA],[RB]

Where:

MOVR is the operation being performed

RA is the SOURCE register

**RB** is the **DESTINATION** register

#### MOVI

This operation allows us to move an immediate value into a register

The syntax for a MOVI operation is,

[MOVI] [RA],[IMME]

Where:

MOVI is the operation being performed

RA is the DESTINATION register

**IMME** is the immediate value

## **LOAD**

This operation allows us to load contents in memory into a register

The syntax for a MOVI operation is,

[LOAD] [RA],[ADDR]

Where:

LOAD is the operation being performed

**RA** is the **DESTINATION** register

**ADDR** is the address location of the data in memory.

#### **STORE**

This operation allows us to store the data from a register into memory.

The syntax for a STORE operation is,

[STORE] [RA],[ADDR]

Where:

STORE is the operation being performed

RA field is the SOURCE register

**ADDR** is the address location to store the value

## **JMP**

This operation allows us to jump to a specified instruction location in memory.

The syntax for a JMP operation is,

[JMP] [ADDR]

Where:

JMP is the operation being performed

ADDR is the address location of the instruction to jump to

#### **JMPZ**

This operation allows us to jump to a specified instruction location in memory if the zero flag is enabled, The syntax for a JMPZ operation is,

[JMPZ] [ADDR]

Where:

JMPZ is the operation being performed

ADDR is the address location of the instruction to jump to

## **JMPN**

This operation allows us to jump to a specified instruction location in memory if the negative flag is enabled. The syntax for a JMPN operation is,

[JMPN] [ADDR]

Where:

JMPN is the operation being performed

ADDR is the address location of the instruction to jump to

## NOP

This opcode means no operation. That is no operation is to be done.

The syntax for a NOP operation is,

[NOP]

Where:

NOP is the operation being performed

## **HALT**

This opcode halts the microprocessor

The syntax for a HALT operation is,

[HALT]

Where:

**HALT** is the operation being performed

## **DEVELOPERS**

maxotuteye (Max Otuteye) (github.com) hanskod (Hansen Koduah) (github.com) dzeble (github.com) Adaks (github.com) Dillys3567 (github.com)

# **APPENDIX**

https://github.com/maxotuteye/nitro-compute.git

ALU - ARITHMETIC AND LOGIC UNIT

ADD - ADDITION SUB - SUBTRACTION MULT - MULTIPLICATION

DIV - DIVISION SHL - SHIFT LEFT SHR - SHIFT RIGHT

AND - LOGICAL MULTIPLICATION

OR - LOGICAL ADDITION

RA - REGISTER A

RB - REGISTER B

RC - REGISTER C

R1 - REGISTER 1

R2 - REGISTER 2

R3 - REGISTER 3

MOVR - REGISTER TO REGISTER MOVE

MOVI - IMMEDIATE VALUE TO REGISTER MOVE LOAD - PUSH CONTENT IN MEMORY TO REGISTER STORE - SAVE DATA FROM REGISTER TO MEMORY

JMP - EXECUTE FROM SPECIFIED LOCATION IN MEMORY

JMPZ - EXECUTE FROM SPECIFIED LOCATION IF ZERO FLAG IS TRIGGERED
JMPN - EXECUTE FROM LOCATION IF NEGATIVE FLAG IS TRIGGERED

HALT - STOP MICROPROCESSOR

NOP - STOP MICROPROCESSOR (NO OPERATION)

IMME - IMMEDIATE VALUE

ADDR - ADDRESS LOCATION OF THE DATA IN MEMORY.