Ceaseless Flow

Water Beads Preparation Guide

1. Add ~1 teaspoon of dry water beads to a separate clean bowl. Cover them with 1 inch of fresh clean water.



4. To create the best shadow pattern, leave only 1 loose layer of water beads so they move around when the bowl moves, and keep the water level at half of the water bead height.

2. Let them soak for ~6 hours. The water beads will absorb water and grow larger.





3. Pour the wet water beads to the lamp bowl. Add more water to the bowl.



Notes: Refer to the Bill of Materials for bowl and water beads specification.