RW354 Principles of Computer Networking


- Larry L. Peterson and Bruce S. Davie. Computer Networks: A Systems Approach (Fifth Edition). Morgan Kaufmann Publishers. ISBN 1-55860-577-0.
- Behrouz A. Forouzan. Data Communications and Networking. McGraw Hill. ISBN 007-123241-9.
- Alberto Leon-Garcia and Indra Widjaja. Communication Networks: Fundamental Concepts and Key Architectures. McGraw Hill. ISBN 0-07-119848-2.

This document may not be reproduced for commercial purposes without the express written consent of the authors.



Links - electromagnetic spectrum

The radio, microwave, infrared, visible & UV portions of the spectrum are used to transmit information by modulating the amplitude, frequency or phase of the waves.



ITU names: Low, Medium, High, Very, Ultra, Super, Extremely, Tremendously High Frequency Bands.



Chapter 2.1




Links - leased line

Sometimes the links are leased from the phone company

| T1 1.544 Mbps T3 44.736 Mbps STS-1 51.840 Mbps STS-3 155.250 Mbps STS-12 622.080 Mbps STS-24 1.244160 Gbps | | |
|---|--------------------|-------------------|
| T1 1.544 Mbps T3 44.736 Mbps STS-1 51.840 Mbps STS-3 155.250 Mbps STS-12 622.080 Mbps STS-24 1.244160 Gbps | Service to ask for | Bandwidth you get |
| T3 44.736 Mbps STS-1 51.840 Mbps STS-3 155.250 Mbps STS-12 622.080 Mbps STS-24 1.244160 Gbps | ISDN | 64 Kbps |
| STS-1 51.840 Mbps STS-3 155.250 Mbps STS-12 622.080 Mbps STS-24 1.244160 Gbps | T1 | 1.544 Mbps |
| STS-3 155.250 Mbps STS-12 622.080 Mbps STS-24 1.244160 Gbps | T3 | 44.736 Mbps |
| STS-12 622.080 Mbps STS-24 1.244160 Gbps | STS-1 | 51.840 Mbps |
| STS-24 1.244160 Gbps | STS-3 | 155.250 Mbps |
| | STS-12 | 622.080 Mbps |
| STS-48 2.488320 Gbps | STS-24 | 1.244160 Gbps |
| | STS-48 | 2.488320 Gbps |

STS: Synchronous Transfer Signal.

STSN is sometimes called OCN: Optical Carrier.



Channan'a thaorem

The maximum channel capacity C in bits/second is

$$C = B \log_2(1 + S/N)$$

where B is the bandwidth of the channel in hertz and S/N is the signal to noise ratio. S/N is expressed in decibels

$$dB = 10 \log_{10}(S/N).$$

For a telephone line $B=3300-300=3000\,\mathrm{Hz}$ and dB=30 so that $S/N=10^3$. Then

$$C = 3000 \log_2 1001 \sim 30 \textit{Kbps}$$
.

Modern modems provide 56 Kbps thanks to better S/N ratios & the use of clever coding & compression methods.

lodes

Consider two nodes connected by a physical link. The following issues must be addressed for the nodes to successfully exchange data

- data encoding
- frame delimitation
- error detection
- error correction
- media access control.

Chapter 2.1

Links - cables

Sometimes you install your own links

| Category 5 twisted pair | 10-100Mbps | 100m |
|-------------------------|--------------|------|
| 50-ohm coax (ThinNet) | 10-100Mbps | 200m |
| 75-ohm coax (ThickNet) | 10-100Mbps | 500m |
| Multimode fiber | 100Mbps | 2km |
| Single-mode fiber | 100-2400Mbps | 40km |

Chapter 2.1 (W0034 – 3-44)

Asynchronous digital subscriber line (ADSL) connects the subscriber to the central office via the local loop.



Very-high-rate DSL (VDSL) connects the subscriber to the optical network that reaches the neighbourhood.



S Chapter 2.1 Encoding: overview


Signals propagate over a physical medium

- digital signals
- analog signals.

Data can be either digital or analog: we are interested in digital data.

Problem: encode the binary data that the source node wants to send to the destination node into the signal that propagates over the medium.





Encoding: Non-Return to Zero (NRZ

The most common way to transmit digital signals is to use two different voltage levels for the two binary digits.

The voltage level is constant (non-return to zero) during a bit interval.



Problem: consecutive 0's and 1's

- long sequences of 1's give rise to a dc-component which necessitates physical coupling of the transmission components (no dc-component allows ac-coupling via a transformer)
- unable to recover a clock signal.


Chapter 2.2 NW354-p. svi

Encoding: NRZI

Problems: a dc-component can be present, and we are unable to recover a clock signal.

Modulation rate (signals per bit)

- all 0's: 0
- 101010...: 0.5
- all 1's: 1.0




Chapter 2.2

S Encoding: Manchester

Modulation rate (signals per bit)

- 101010...: 1.0
- all 0's: 2.0
- all 1's: 2.0



Chapter 2.2

Encoding: 4B/5B

| 4-bit Data | 5-bit Code | 4-bit Data | 5-bit Code |
|------------|------------|------------|------------|
| 0000 | 11110 | 0001 | 01001 |
| 0010 | 10100 | 0011 | 10101 |
| 0100 | 01010 | 0101 | 01011 |
| 0110 | 01110 | 0111 | 01111 |
| 1000 | 10010 | 1001 | 10011 |
| 1010 | 10110 | 1011 | 10111 |
| 1100 | 11010 | 1101 | 11011 |
| 1110 | 11100 | 1111 | 11101 |

Encoding: NR


Non-return to Zero Invert on ones (NRZI). The data are encoded by the presence/absence of a signal transition at the beginning on the bit interval.

0: no transition.

1: transition.

This solves the problem of consecutive 1's.

NRZI is an example of a differential encoding scheme.




S Chapter 2.2

0: transition from low to high in the middle of a bit interval.
1: transition from high to low in the middle of a bit interval.

Advantages

- no dc-component
- a transition is present in the middle of each bit interval: the clock can be recovered.



Chapter 2.2 (NW254 - p. 1287)

Encoding: 4B/5B

- 4 bits of data are encoded into a 5-bit code. The 5-bit codes are selected to have no more than one leading 0 and no more than two trailing 0's.
- Two concatenated 5-bit codes never have more than three consecutive 0's.
- The resulting 5-bit codes are transmitted using the NRZI encoding.
- There are no problems with consecutive 0's.
- This achieves 8/10 = 80% modulation efficiency.

Chapter 2.2


Framing: Overview

A sequence of bits is assembled into a frame

- determine the first and last bit of the frame
- this is typically implemented by the network adapter
- the adapter fetches (deposits) frames out of (into) the host memory.



Bits flow between adapters, frames flow between hosts.



p. 15/87

Chapter 2.3

00000 - 10

Framing: byte-oriented protocols

The sentinel approach as used in BISYNC. The control characters STX & ETX delimit the data portion of a frame.



- Problem: the ETX character might appear in the data portion of the frame.
- Solution: escape the ETX character with a DLE character.

Framing: byte-oriented protoco

The byte counting approach as used in DDCMP



- Problem: the count field is corrupted a framing error.
- · Solution: detect when CRC fails.

The Cyclic Redundancy Check (CRC) is used to detect errors

Chapter 2.3

• the basic SONET building block is the STS-1 frame of 810 octets sent once every 125µs: 51.84 Mbps

Chapter 2.3

HDLC: High-Level Data Link Control (also SDLC and PPP)

Delineate the frame with a special bit-sequence: 01111110



Bit stuffing

- Sender: if five consecutive 1's are transmitted in the body of the message, append a 0.
- · Receiver: if five consecutive 1's arrive
- if the next bit is 0: remove it
- else
- if the next bits are 10: end-of-frame marker


Chapter 2.3

• else if the next bits are 11: error.

The frame can be viewed logically as a matrix of 9 rows & 90 columns.

SONET: Synchronous Optical NetworkITU standard for transmission over fiber

Framing: SONET



Chapter 2.3

The first 2 bytes of a frame are a synchronization pattern.

The first 3 columns of each frame are reserved for system management information

- the first 3 rows contain section overhead
- the next 6 rows contain line overhead.

Framing: SONET


| SONET | | SDH | Data rate (Mbps) | | | |
|------------|---------|---------|------------------|----------|----------|--|
| Electrical | Optical | Optical | Gross | SPE | User | |
| STS-1 | OC-1 | | 51.84 | 50.112 | 49.536 | |
| STS-3 | OC-3 | STM-1 | 155.52 | 150.336 | 148.608 | |
| STS-9 | OC-9 | STM-3 | 466.56 | 451.008 | 445.824 | |
| STS-12 | OC-12 | STM-4 | 622.08 | 601.344 | 594.432 | |
| STS-18 | OC-18 | STM-6 | 933.12 | 902.016 | 891.648 | |
| STS-24 | OC-24 | STM-8 | 1244.16 | 1202.688 | 1188.864 | |
| STS-36 | OC-36 | STM-12 | 1866.24 | 1804.032 | 1783.296 | |
| STS-48 | OC-48 | STM-16 | 2488.32 | 2405.376 | 2377.728 | |
| STS-192 | OC-192 | STM-64 | 9953.28 | 9621.504 | 9510.912 | |

Framing: SONET

 the remaining 87 columns contain 50.112Mb of user data: the Synchronous Payload Envelope SPE


Chapter 2.3

 a pointer in the line overhead points to the SPE which can begin anywhere within a frame & can span frames



Chapter 2.3

Errors: two-dimensional parity



Chapter 2.4

2-D parity finds all 1-, 2- and 3-bit errors & most 4-bit errors.

Errors: Internet checksum algorith

The checksum algorithm is based on addition.

The message is viewed as a sequence of 16-bit integers. Add these integers together using 16-bit 1's complement arithmetic, and then take the 1's complement of the result. That 16-bit number is the checksum.

```
u_short
cksum(u_short *buf, int count) {
    register u_long sum = 0;
    while (count--) {
        sum + *buf*+;
        if (sum & OxFFFF00000) { /* a carry occurred in the top 16 bits */
            sum +- 0xFFFF; /* bottom 16 bits */
            sum +- 0xFFFF; /* add the carry to the result */
    }
}
return `(sum & OxFFFFF);
}
```

Chapter 2.4


Errors: CRC sender

S

- Form $T(x) = M(x) \times x^k$. In our example we get $T(x) = x^{10} + x^7 + x^6 + x^4$ (10011010000).
- Divide T(x) by C(x) (1101). The CRC is the remainder



• Send T(x) – CRC (10011010000 - 101 = 10011010101) which is exactly divisible by C(x).



Frrors: CBC

Common polynomials C(x) are:

| CRC | C(x) |
|-----------|--|
| CRC-8 | $x^8 + x^2 + x^1 + 1$ |
| CRC-10 | $x^{10} + x^9 + x^5 + x^4 + x^1 + 1$ |
| CRC-12 | $x^{12} + x^{11} + x^3 + x^2 + 1$ |
| CRC-16 | $x^{16} + x^{15} + x^2 + 1$ |
| CRC-CCITT | $x^{16} + x^{12} + x^5 + 1$ |
| CRC-32 | $x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} +$ |
| | 10 +8 +7 +5 +4 +2 + + 1 |

Errors: Cvclic Redundancy C

- Add k bits of redundant data to an n-bit message where k << n.
- Represent an n+1-bit message as an n degree polynomial. Thus MSG=10011010 corresponds to $M(x)=x^7+x^4+x^3+x^1$.
- Let k be the degree of some divisor polynomial C(x). For example k=3 and $C(x)=x^3+x^2+1$.
- Transmit the polynomial P(x) that is evenly divisible by C(x). The polynomial P(x)+E(x) is received: E(x)=0 implies no errors.
- The recipient divides P(x)+E(x) by C(x). The remainder will be zero if E(x) was zero (there was no error), or E(x) is exactly divisible by C(x). Choose C(x) to make second case extremely rare.

S Chapter 2.4 (800354-p.2

Errors: CRC

We want to ensure that C(x) does not divide evenly into the polynomial E(x). The following errors can be detected

- All single-bit errors, as long as the x^k and x^0 terms have non-zero coefficients.
- All double-bit errors, as long as C(x) has a factor with at least three terms.
- Any odd number of errors, as long as C(x) contains the factor (x + 1).
- Any burst error (a sequence of consecutive errored bits) for which the length of the burst is less than k bits.
- Most burst errors of larger than k bits can also be detected.

Chapter 2.4 RW254-p, 2019


Reliability: overview

Recover from corrupt frames

- Forward error correction: the frames contain error correction codes (ECC) which are used to recover from transmission errors.
- Automatic Repeat reQuest: acknowledgements & timeouts are used to detect & re-transmit lost frames & frames with errors.



Reliability: ARQ



Reliability: Stop-and-Wait

Stop-and-wait uses a 1-bit sequence number.




Problem: only 1 frame is sent per RTT – the pipe is not full.

Example: 1.5Mbps link × 45ms RTT = 67.5Kb (8KB). Assuming a frame size of 1KB, stop-and-wait uses about one-eight of the link's capacity. We want the sender to transmit up to 8 frames before having to wait for an ACK.



Reliability: sliding window

Allow the sender to transmit several frames before receiving an ACK, thus keeping the pipe full. There is an upper limit on the number of outstanding (un-ACKed) frames allowed.



Chapter 2.5

Reliability: sliding window receiver

- · Maintain three state variables
 - the receive window size: RWS
- the last frame acceptable: LFA
- the next frame expected: NFE
- Maintain the invariant: LFA NFE + 1 \leq RWS



Chapter 2.5 Reliability: sliding window

The sliding window protocol serves three different roles

- reliable delivery: the reliable delivery of frames over an unreliable link
- · ordered delivery: frames are delivered in the correct order
- flow control: the receiver can throttle the sender.

Chapter 2.5

- SeqNum field is finite; sequence numbers wrap around
- The sequence number space must be larger than the number of outstanding frames
- $SWS \le MaxSeqNum 1$ is not sufficient
- assume a 3-bit SeqNum field 0 . . . 7
- SWS = RWS = 7
- sender transmits frames 0 . . . 6
- · they arrive successfully, but the ACKs are lost
- the sender retransmits 0 . . . 6
- the receiver expects 7,0...5 but receives the second incarnation of 0...6
- SWS < (MaxSeqNum + 1)/2 is the correct rule
- Intuitively SeqNum "slides" between the two halves of sequence number space.

Chapter 2.5

- · Maintain three state variables
 - the send window size: SWS
 - the last acknowledgment received: LAR


• Assign a sequence number to each frame: SeqNum

- the last frame sent: LFS
- Maintain the invariant: LFS LAR + 1 \leq SWS




- When the ACK arrives, advance LAR thereby opening the window
- Buffer up to SWS frames.

Reliability: sliding window receiver



- Frame SeqNum arrives
- if NFE \leq SeqNum \leq LFA then accept
- \bullet if SeqNum < NFE or SeqNum > LFA then discard
- Send a cumulative ACK for the highest numbered frame received in order
- Variations
 - · selective acknowledgements
 - negative acknowledgements (NAK)



- Multiplex several logical channels over a single point-to-point link. Run the stop-and-wait protocol on each logical channel.
- Maintain three bits of state for each logical channel
 - boolean: the channel is/not currently busy
- sequence number: frames sent on the channel
- next sequence number to expect on the channel
- ARPANET supported eight logical channels over each ground link (16 over each satellite link).
- Header for each frame included a 3-bit channel number and a 1-bit sequence number, for a total of 4 bits; same number of bits as the sliding window protocol requires to support up to eight outstanding frames on the link.
- · Separates reliability from flow control and frame order. Chapter 2.5

Ethernet: overv

- History
- developed by Xerox PARC in mid-1970s
- roots in the Aloha packet-radio network
- standardized by Xerox, DEC, and Intel in 1978
- similar to IEEE 802.3 standard
- CSMA/CD
- carrier sense
- multiple access
- collision detection
- Bandwidth: 10Mbps, 100Mbps and 1Gbps
- Problem: distributed algorithm that provides fair access to a shared medium

Chapter 2.6

Ethernet: frame format



Ethernet addresses

- unique 48-bit unicast address assigned to each adaptor
- example: 8 : 0 : 2b : e4 : b1 : 2
- broadcast: all 1's
- multicast: first bit is 1
- type field: identifies the network layer protocol of the packet in the frame body
- frame body: 46 ≤ body ≤ 1500 bytes
- preamble: 7 bytes 10101010, 1 byte 10101011.

Chapter 2.6 NW054-p.

20101110011001111

- If the medium is idle
- send immediatelyupper bound message size of 1500 bytes
- must wait $51\mu s$ between back-to-back frames.
- If the medium is busy
- wait until idle and transmit immediately
- called 1-persistent which is a special case of p-persistent: when the line becomes idle transmit with probability p.

If a collision occurs . . .

RW354 - p. 45/87

Ethernet: experiences

Observed in practice

- 10-200 hosts, not 1024
- length shorter than 2500m, RTT closer to $5\mu s$ than $51\mu s$
- packet length is bimodal
- high-level flow control and host performance limit the carried load.

Chapter 2.6

Recommendations

- do not overload. 30% utilization is about max
- implement controllers correctly
- use large packets
- get the rest of the system right (broadcast, retransmission).

Ethernet: physical prop

- Classical Ethernet (thick-net): also called 10Base5
- maximum segment of 500m
- transceiver taps are at least 2.5m apart
- · connect multiple segments with repeaters
- no more than 4 repeaters between any pair of nodes (2500m total)
- maximum of 1024 hosts; Manchester encoding

| | Ъ | Ь | Ь | 占 |
|----|---|---|---|-------|
| | Ъ | Ь | Ь | Ь |
| F- | Ъ | Ь | Р | Т |
| L | Ъ | Ъ | Ъ | Ъ |

- 10Base2 (thin-net): 200m, daisy-chain configuration
- 10BaseT (twisted-pair): 100m, star configuration.

Chapter 2.6

Etnernet: trame format

The adaptor receives all frames. It accepts & passes to the host

- frames addressed to its own unicast address
- frames addressed to the broadcast address
- frames addressed to any multicast address it has been programmed to accept
- all frames when in promiscuous mode.

S Chapter 2.6

20101110111111111111

If a collision occurs

- jam for 512 bits, then stop transmitting the frame
- the minimum frame is 64 bytes: header + 46 bytes of data = 512 bits so that the frame is long enough for a collision to be detected
- · delay and try again: exponential backoff
- 1st time: $U(0,51.2)\mu s$
- 2nd time: $U(0, 102.4)\mu s$
- 3rd time: $U(0, 204.8)\mu s$
- give up after several tries, usually 16.

where U(0,x) is a random number uniformly distributed in the range (0,x].

Chapter 2.6

Ethernet: Quality of Service

Different applications require different levels of service. A network can deliver predictable service to different application traffics by

- flow identification assign the network traffic to distinct service profiles
- appropriate queueing and scheduling for different traffic types
- intelligent route selection to avoid congested areas of the network

Chapter 2.6

• reserve bandwidth for different traffic types.

The IEEE 802.1p standard tags Ethernet frames with priority information.

The Ethernet frames are tagged with up to 8 levels of

The network switches and routers use the priority information to ensure that traffic requiring low latency and sustained throughput (voice, video, multimedia) receives better service levels over best effort traffic (email, FTP, ...).

The switches use 2 to 8 queues. The highest priority frames are placed in the highest priority queue. High priority queues are served more often than low priority queues – so higher priority frames get more bandwidth.

The 8 frame priority tags are used to define 8 different traffic classes.

The priority tags are ordered (1,2,0,3,4,5,6,7). For example

- tags (1,2) identify low-priority or background traffic
- tags (0,3) identify normal-priority or best effort traffic
- tags (4,5) identify controlled-load traffic (video frames)
- tags (6,7) identify high-priority traffic (voice frames or network management frames)

Chanter 2.6

IEEE 802.1p is deployed at Layer 2: this requires a change to the 802.3 Ethernet frame format. Four bytes are added to the frame.

The additional bytes increase the maximum frame size from 1518 to 1522 bytes. Most pre-1998 network equipment will flag a frame greater than 1518 bytes as oversize, assume them corrupted and drop them!

802.1p capable switches can be programmed to remove the additional 4 bytes before forwarding the frame to legacy networks.

Token ring networks: overview

Token ring networks

- PRONET: 10Mbps and 80 Mbps rings
- IBM: 4Mbps token ring
- 16Mbps IEEE 802.5 token ring
- 100Mbps Fiber Distributed Data Interface (FDDI)



Chapter 2.6

Chapter 2.7

Token ring networks: overview



The basic idea

- frames flow in one direction: upstream to downstream
- · a special bit pattern (token) rotates around the ring
- a station must capture the token before transmitting
- · a station releases the token after transmitting
 - early or delayed release
- · station removes its frame when it comes back around
- stations get round-robin service.

Dual ring configuration

Single and dual attachment stations

- the Token Holding Time (THT): the upper limit on how long a station can hold the token.
- the Token Rotation Time (TRT): how long it takes the token to traverse the ring.

TRT < ActiveNodes × THT + RingLatency

- the Target Token Rotation Time (TTRT): an agreed-upon upper bound on the TRT.
- Algorithm . . .

• each station imposes a delay (e.g., 50ns)

- a maximum of 500 stations
- an upper limit of 100km (200km of fiber)
- uses 4B/5B encoding
- can be implemented over copper (CDDI).

FDDI: timed token algorithi

- each node measures the TRT between successive arrivals of the token: the MTRT
- if MTRT > TTRT then the token is late; don't send data
- if MTRT < TTRT then the token is early: hold the token for TTRT-MTRT and send data
- · define two classes of traffic
- · synchronous data: can always send
- asynchronous data: can send only if token is early
- worse case: 2×TTRT between seeing token
- not possible to have back-to-back rotations that take 2×TTRT time

FDDI: token maintena

- Lost token
 - · no token when initializing ring
- bit error corrupts the token pattern
- node holding the token crashes.
- Monitoring for a valid token
 - should see valid transmission (frame or token) periodically
 - maximum gap = ring latency + max frame ≤ 2.5ms
 - set timer at 2.5ms and send claim frame if it expires
- Generating a Token (and agreeing on TTRT) . . .

Chapter 2.7 Necosi-p. stret S


FDDI: token maintenance

- generating a token (and agreeing on TTRT)
- · execute when join ring or suspect a failure
- each node sends a special claim frame that includes the node's bid for the TTRT
- when a node receives a claim frame, update the bid and forward it
- if your claim frame makes it all the way around the ring
- your bid was the lowest
- everyone knows the TTRT
- you insert a new token.

FDDI: trame format




- Control Field
- 1st bit: asynchronous (0) or synchronous (1) data
- 2nd bit: 16-bit (0) or 48-bit (1) addresses
- last 6 bits: demux key (includes reserved patterns for token & claim frame)
- Status Field
- from receiver back to sender
- · error in frame
- recognized address
- · accepted frame (flow control)



Wireless: 802 11


Wireless ethernet, Wi-Fi.



- frequency hopping transmits the signal over a pseudo-random sequence of frequencies.
- Spread spectrum spreads the signal over a wide frequency band to minimize interference from other devices

802.11 Direct Sequence Spread Spectrun

DSSS represents each bit in the original signal by multiple bits in the transmitted signal: the chipping code.





Chapter 2.8 (M224 – p. 0287

Chapter 2.8

802.11b defines the physical layer in the unlicensed ISM S-band 2.4 – 2.5 GHz (ISM: Industrial, Scientific and Medical)

- frequency hopping: 75 channels each 1 MHz wide
- infrared: 10m range, no implementations
- DSSS: 11-bit chipping code
 - 1, 2, 5.5 or 11 Mbps.
- 11 operating channels, each 5 MHz wide
- cells using different channels can operate simultaneously without interference if the distance between the centre frequencies is at least 25 MHz: channels 1, 6 and 11.

Chapter 2.8

200 11h and the ICO OCI madel



- FHSS: Frequence Hopping Spread Spectrum.
- OFDM: Orthogonal frequency division multiplexing.

Chapter 2.8

 HR/DSSS: High Rate Direct Sequence Spread Spectrum.

The data rate is increased from 2 Mbps to 5.5 or 11 Mbps using advanced coding techniques rather than 11-bit chipping codes.

- 5.5 Mbps: 4 bits encoded into 64 8-bit codewords
- 11 Mbps: 8 bits encoded into 64 8-bit codewords.

Dynamic rate shifting: users connect at 11 Mbps. If the signal strength weakens, the device transmits at lower speeds falling back to 5.5, 2 and 1 Mbps.

802.11 does not specify any particular technology for the distribution system used to relay frames between access points. Ethernet is generally used as the backbone network technology.

802.11 frames must be converted to another type of frame for delivery to the rest of the world. Access points perform the wireless-to-wired bridging.



Chanter 2.8

802.11b architecture

The cell (Base Service Set) is the building block of the 802.11b architecture

- infrastructure mode: a BSS contains 1 or more wireless stations & a base station (Access Point)
 - the AP forms a bridge between the wireless and the wired network: STAs communicate via the AP
- ad-hoc mode: stations can group to form an ad-hoc network - no AP, no connections to the outside world; STA's communicate directly



Wired Ethernets generally deliver frames successfully.

Radio links use unlicensed ISM bands

- radio transmissions subject to noise & interference
- interference will exist and must be dealt with
- multipath fading where frames cannot be transmitted because a node moves into a dead spot.

Radio links are unreliable: all frames must be acknowledged.






A and C wish to communicate with B. Their frames will collide at B. A and C are hidden nodes with respect to each other - they are not aware of the collision.

B sends to A. C is an exposed node: it is aware that B is sending to A, yet C can send to D.

Chapter 2.8

802.11 creates wireless networks of arbitrarily large size by linking BSSs into an extended service set (ESS).




Chapter 2.8

Frames are prepared by the PLCP before transmitted.

The long frame format must be supported. The short PLCP format is optional.

The preamble is transmitted at 1.0 Mbps.


The Signal field indicates the speed and transmission method of the enclosed MAC frame.



In infrastructure mode

- the sender sends a RTS frame to the AP
 - the RTS frame specifies the length of the data frame to be transmitted: the sender will hold the medium for an amount of time T_{length}
- the AP replies with a CTS frame which contains
- the sender starts transmitting when it receives the CTS frame from the AP
- all other stations in the BSS receive the CTS: they delay their transmissions for an amount of time T_{length}
- DCF is much more complicated in an ad-hoc network.

802 11b: the hidden node proble



- RTS/CTS consumes bandwidth and introduces additional latency before transmission can begin
- RTS/CTS is used in high capacity environments and environments with significant contention on transmission. For lower capacity environments, it is not necessary.
- RTS/CTS is performed for frames larger than the RTS threshold. Frames shorter than the threshold are sent without RTS/CTS.

Chapter 2.8 FW254-p.7

802.11b: carrier-sensing

Carrier-sensing determines if the medium is available.

- Physical carrier-sensing
 - RF transceivers which transmit and receive simultaneously are expensive
 - physical carrier-sensing cannot provide all the necessary information because
 of hidden nodes.
- Virtual carrier-sensing is provided by the Network Allocation Vector
- 802.11 frames carry a duration field, which is used to reserve the medium for a fixed time period
- the NAV indicates the amount of time the medium will be reserved
- · stations set the NAV to the time for which they expect to use the medium
- other stations count down from the NAV to 0
- NAV > 0: the medium is busy
- NAV = 0: the medium is idle.

Chapter 2.8

802 11b: inter frame spacing



Varying IFSs are used to create different priority levels for different types of traffic.

- The short IFS is used for the highest-priority transmissions, such as RTS/CTS frames and ACKS. High-priority transmissions can begin once the SIFS has elapsed. Once these high-priority transmissions begin, the medium becomes busy, so frames transmitted after the SIFS has elapsed have priority over frames that can be transmitted only after longer IFS intervals.
- The DCF IFS is the minimum medium idle time for contention-based services.
 Stations may have immediate access to the medium if it has been free for a period longer than the DIFS.

Chapter 2.8

802.11b: the contention window



- After frame transmission has completed and the DIFS has elapsed, nodes may attempt to transmit congestion-based data.
- The contention window follows the DIFS.
- The contention window is divided into slots.

In fact it is more complicated . . . Chapter 2.8

- Slot length is medium- dependent; higher-speed physical layers use shorter slots.
- Nodes pick a random slot and wait for that slot before trying to access the medium.
- When several nodes are attempting to transmit, the node that picks the first slot (the node with the lowest random number) wins.

802 11h: MAC access mo



Coordination functions control access to the wireless medium

- DCF The distributed control function implements CSMA/CA. DCF first checks that the radio link is clear before transmitting. To avoid collisions, stations use a random backoff after each frame, with the first transmitter seizing the channel. DCF may use CTS/RTS to reduce the possibility of collisions.
- PCF The point coordination provides contention-free services. APs are used to ensure that the medium is provided without contention, so PCF is restricted to infrastructure networks. PCF is not widely implemented.

Chapter 2.8 (NW354-p. 748)

802.11b: the NAV and virtual carrier-sensing



The NAV ensures that frame transmission is atomic.

- Node 1 sends an RTS. Nodes that hear the RTS set their NAVs and defer access to the medium until the NAV elapses.
- Node 2 responds with a CTS. Nodes that hear the CTS set their NAVs and defer access to the medium until the NAV expires.
- The NAV prevents other nodes from accessing the medium until the RTS-CTS-FRAME-ACK transmission completes.
- After the transmission completes, the medium can be used by any station after distributed interframe space (DIFS).


Chapter 2.8 (N9354 – p. 76

802 11h: inter frame spacino


```
MAC802_11_b.SIFS = 10 * 1E-6; // seconds
MAC802_11_b.SLOT = 20 * 1E-6; // seconds
MAC802_11_b.PIFS = MAC802_11_b.SIFS + MAC802_11_b.SLOT;
MAC802_11_b.DIFS = MAC802_11_b.SIFS + MAC802_11_b.SLOT * 2;
/* short preamble */
MAC802_11_b.Preamble = 96 * 1E-6; // seconds
MAC802_11_b.PLCPHeader = 24 * 1E-6; // seconds
/* long preamble */
//MAC802_11_b.Preamble = 192 * 1E-6; // seconds
//MAC802_11_b.PLCPHeader = 48 * 1E-6; // seconds
/\star the following i3 packets transmitted at the basic rate of 1Mbps \star/
MAC802_11_b.RTS = 20 * 8 / 1 * 1E-6; // seconds
MAC802_11_b.CTS = 14 * 8 / 1 * 1E-6; // seconds
MAC802_11_b.ACK = 14 \star 8 / 1 \star 1E-6; // seconds
MAC802_11_b.RTS_timeoutDelay
 = MAC802_11_b.SIFS
```

+ MAC802_11_b.Preamble + MAC802_11_b.CTS + MAC802_11_b.PropagationDelay;

802 11h: the backoff procedure



Node C has the shortest random backoff, followed by nodes D, E and B in that order.



The Point Coordination Function can be used to transmit

• time slicing: the BSS alternates between PCF and

• In PCF mode: the AP polls each station in turn. A station can send/receive only when polled. This sets

802.11b: CSMA/CA

Unlike the 802.3 Ethernet MAC protocol, the Wi-Fi 802.11 MAC protocol does not implement collision detection

- Carrier sense: the sender listens to the medium if the medium is idle the sender transmits else the sender waits until the medium is idle.
- If two or more senders find the medium to be idle their RTS frames may collide in which case the senders will not receive their CTS frames within a timeout period: they each wait a random amount of time (binary exponential backoff) before trying again.
- Stop-and-wait: each successfully received frame is

voice/video data


DCF mode

Chapter 2.8

Chapter 2.8

Some nodes can roam. The access points (AP's) are connected to a wired infrastructure.

AP's are connected by a distribution system.



Each node is associated with one AP. When node A communicates with node E: A \rightarrow AP-1 \rightarrow AP-3 \rightarrow E.

Chapter 2.8

an upper bound on the latency. PCF does not scale.


Chapter 2.8

802.11: Active Scanning

When a node joins the network, or when a node decides to change its AP

- the node sends a Probe frame
- all AP's in reach reply with a Probe Response frame
- the node selects one of the AP's & sends that AP an AssociationRequest frame
- the selected AP replies with an Association Response frame.

802.11: Active & Passive Scanning



AP's periodically send Beacon frames that advertise the capabilities of an AP.

In between beacon frames the stations are in power saving mode (radio off).

Chapter 2.8



- Control
- 6-bit Type: data, CTS, RTS, scanning
- 1-bit ToDS, FromDS
- four addresses (same structure as 802.3)
- ToDS = FromDS = 0: the source & destination are in the same cell
- Addr1 = source, Addr2 = dest
- ToDS = FromDS = 1: the source & destination are in different cells Addr1 = dest, Addr2 = Dest AP
- Addr3 = source AP, Addr4 = source.