






Brief overview — Q1002, R1003, D1002 preform an active transient protection. It will suppress voltages up to 200V down to 19V. — Q1001, R1001, D1001 preform a reverse polarity protection. If the input signal is the wrong polarity, the gate will not conduct which will prevent current from flowing. — D1003 is a second transient suppressor, it would catch faster transients allowing a brief amount of time for Q1002 to preform it's duty. L1003 is a choke, it simple prevents switching noise from going up the power wire where it can get into other circuits. C1001 is a bulk cap, it simply stores energy locally such that the regulator can draw large currents in short periods of time. -- U1001 and the components to the right, are a buck style switching regulator, that will pull the 5V line up to 5V. It will not pull it down from 5V if there is an external voltage. The U1001 circuit has been designed for 3A output and up to 20V input, but typically 14.4V or 12.4V input. L1001 wants to be about 68uH to 100uH with less than 0.3 ohms resistance. 200V surge, 18V to 7V typical. Suggested mininium 16awg Upstream 1A fuse littel fuse 0287001 5V 5mVp-p 1A Suggested external wires U1001 18awg min Vin⊳ FB901 FB902 GNDD 3A possible with ALTERNATIVE DIODE FOR D1004 more expensive LIMITS OUTPUT TO 2.3A components. rusEFI.com Sheet: /PWR_buck_12V_switcher/ File: PWR_buck_12V_switcher.sch Alternate options Title: frankenso Q1002 Microchip,DN2625K4-G with FAIRCHILD,1N5247B D1002 IXYS,IXTA6N50D2 with FAIRCHILD,1N5244B Size: A Date: 2018-02-24 Rev: 0.5.3 D1004 VISHAY, VS-50WQ04FN-M3 with VISHAY, VS-50WQ04FNPBF KiCad E.D.A. kicad 4.0.7 ld: 9/15

















That's alternative signal OUTPUT — these traces should be routable to PC6 and PA5 via jumpers. Aleternative to W212 and W212 routung of op—amps ch 11 and ch 12

CRANKD—ODO CAM

See below links about barriers in GND planes. The current loops in the layout do not appear to need barriers.

http://rusefi.com/wiki/index.php?title=Manual:Hardware:PCB_design_rules http://www.maximintegrated.com/en/app-notes/index.mvp/id/5450

rusEFI.com		
Sheet: /Misc_Via	s/	
File: Misc_Vias.sch		
Title: franke	nso	
Size: B	Date: 2018-02-24	Rev: 0.5.3
KiCad F D A kicad 4 0 7		ld: 15/15