Polyphase Filter Banks: A Physicist's Attempt

Matthew Cooper

Sometime in May, 2019

# Contents

1	Intr	roduction	2
2	Fun	damentals of Digital Signals	4
	2.1	Analog Vs. Digital	4
	2.2	Analog Signal Sampling	5
	2.3	Downconversion	6
	2.4	Digital Signal Filters	8
	2.5	Summary	9
3	Pol	yphase Implementation	11
	3.1	Theory	11
	3.2	2-tap Example	11
	3.3	Coded Example	13

## Chapter 1

## Introduction

In the modern era, the speed of digital processing components has made it such that the gap between digital and analog is becoming ever smaller, allowing us the advantages that come with conversion of analog signals to digital signals. These advantages are numerous, but, as with anything, there is an equivalent exchange, and there are tradeoffs in using digital signals which, if not taken into account, can turn a scientific data product into something completely unusable.

In my researching of this subject, it became clear early on that my understanding of the fundamentals that go into digital signal processing (DSP hereafter) were not up to par, which resulted in several hours of researching different aspects of DSP in order to complete the mental picture I needed. It is my goal in the pages of this report to recreate, as best I can, this journey, making pitstops at different ideas that helped shape my current, albeit incomplete understanding.

The first reference I was able to find for polyphase filter bank implementation was a paper from 1973 (Schafer and Rabiner, 1973). In this paper, however, the term polyphase had not been coined yet. Its original implementation was

to increase resolution of frequency channels for speech analysis and synthesis. Not suprising, this came out of Bell Labs. We'll discuss this paper in greater detail when we come to the theory side of things.

Although it started as a method of reconstructing speech output, the applications of polyphase filter banks has found use in almost all areas where channelization is required, such as cell phone signal downconversion and up conversion (Harris, 2003), as well as being considered for implementation in the Extended Owens Valley Solar Array(CITE).

In this report, we will review some basics of analog-to-digital conversion, methods which have been created to navigate the restrictions that such conversions place on the type of data which can be sampled, and then proceed with how polyphase filter banks are utilized in the optimization of such a process.

## Chapter 2

# Fundamentals of Digital Signals

#### 2.1 Analog Vs. Digital

The filtering and manipulation of analog signals has been widely used for decades. Why, then, is there the push for analog-to-digital conversion? For systems where the average power of a signal is the only necessity, staying in the analog domain is perfectly acceptable. The issue arises when a system also needs to accurately measure and record phase information. In analog systems, the gain to phase balance of a signal cannot be maintained to better than 1% over a range of temperatures (Harris, 2003).

Figure 1.1 gives an example of the error which can be introduced by such errors. This is particularly crippling for a multi-antennae radio array, which relies on phase-locking between antennae in order to steer the beam. Since no two antennae's analog components can match identically, leaving the signal in the analog domain can produce spurious phase shifts, which are functions of




Figure 2.1: Plotted above is an ideal signal which has had uncertainty introduced in its phase and amplitude profile.

many variables which cannot be accounted for simply, if at all. This is where analog-to-digital conversion is helpful, since the phase information stored in a digital signal is not subject to environmental effects.

#### 2.2 Analog Signal Sampling

In analog-to-digital conversion, there are two relations which must be considered: the Nyquist Sampling Theorem, and the Frequency Resolution Relation. These combined determine the sampling rate which must be attained in order to recover a maximum frequency, as well as how much resolution there will be between frequencies. The Nyquist Theorem (Landau, 1967) states that

$$f_{crit} = \frac{f_{sample}}{2} \tag{2.1}$$

where  $f_{crit}$  is the maximum frequency which can have power 'definitively' attributed to it (i.e. has no alias), and  $f_{sample}$  is the sampling frequency. This relation is troubling for radio transmissions. Consider a 10 GHz signal. In order to recover this signal, it must be sampled at 20 billion samples per second. At 64 bit resolution, this equates to around 160 Gigabytes of data. Currently, FPGA's on the market sit in the MHz processing speed range, although ADC converters currently exist which can handle giga-samples per second.

The second relation, the Frequency Resolution Relation, gives a size requirement for the hardware register which must be fed to the FFT in order to maintain a specific resolution between frequencies.

$$f_{res} = \frac{f_{sample}}{N} \tag{2.2}$$

where  $f_{res}$  is the resolvability. So, for higher sample rates, the register size must also increase to maintain frequency resolvability. Clearly, a register which is of the order of 160 Gigabytes is something science fiction would hesitate to create, so how is this issue circumvented? The obvious answer is to sample less, but therein lies the problem, since in the process we lose information either by loss of resolution or by ambiguity in frequency aliasing. The method which was created to circumvent this problem was the concept of downconversion.

#### 2.3 Downconversion

Downconversion (heterodyning) was originally worked on by Nikola Telsa and Reginald Fessenden (Espenschied 1959). Fessenden patented the heterodyne principle in 1902, and that same year founded the National Electrical Signaling Company (NESCO). John Vincent Lawless Hogan, who went to work for Fessenden in 1910, showed how the concept had greatly improved the sensitivity


of radio receivers (Godara, 1999). The introduction of this concept revolutionized electromagnetic signaling, and it is no stretch to say that without it, the subject of this paper, as well as many other DSP related ideas, would never have existed.

What is heterodying? Heterodyning is the process by which a signal is mixed with a higher frequency signal in order to mirror the signal to a lower frequency band. This can be easily shown mathematically. Consider a monochromatic input signal,  $x_{in}$ , and a local signal,  $x_{lo}$ . Then,

$$x_{in} * x_{lo} = sin(f_{in}t)sin(f_{lo} * t)$$
(2.3)

$$= \frac{1}{2} [\cos((f_{lo} - f_{in}) * t) - \cos((f_{lo} + f_{in}) * t]$$
 (2.4)

Here, we see that there are two mirrors of the input signal; one which is at higher frequencies, and one which is at lower frequencies, with an example shown in Figure 1.




**Figure 2.2:** (top) Signal  $x_{in}$  in the time and frequency domain (middle) Signal  $x_{lo}$  in time and frequency domain (bottom) Signal  $x_{in}x_{lo}$  in the time and frequency domain

The part we are interested in is, of course, the lower frequencies, since we don't have to sample these as often. Therefore, the higher frequency components must be removed. We remove these signal contributions by the process of filtering.

#### 2.4 Digital Signal Filters

Digital signal filters are arguably one of the biggest fields within the realm of electrical engineering, and for good reason. This process allows one to attenuate certain frequency bands, while leaving others (relatively) unaffected.



**Figure 2.3:** Plotted above is the frequency responses for a Butterworth filter of low-pass type. The y-axis indicated the attenuation (in dB) of the different frequency components. The first dashed line indicated the end of the pass-band, and the second is the beginning of the stop band.

Figure 2.3 shows a typical frequency response profile for a filter transfer function. As can be seen, all frequencies are affected, but the stopband frequences are attenuated much more heavily than in the passband. Other filter types, such as Chebyshev, Bessel, and Elliptic, have other features which would

appear in such a plot. The Butterworth filter has no rippling in the attenuation of its passband, whereas an Elliptic or Bessel filter would. Thus, different filters are chosen for different applications. Specific bandstop filters have been created for radio astronomy in particular, such as the cryogenic S-band filter, which is a hardware bandstop filter which mimics a Chebyshev/Elliptic bandpass filter (Srikanta, 2012). This filter differs from digital filters in that it cannot have its bandwidth adjusted. A digital filter can be altered simply by changing the coefficient register in the FPGA.


Signal filters are commonly derived in the Laplace domain, due to the simplicity of the mathematics. The task is then to convert it to the Z-domain, via transforms such as a bilinear transform. One then takes the impulse response of a given filter, which for an FIR filter gives the coefficients with which to convolve the input signal, via.

$$y[n] = \sum_{k=0}^{N-1} x[k]h[n-k]$$
 (2.5)


Example time-domain coefficients for the Butterworth filter above are given in Figure 2.2. The results of such a convolution can be observed in Figure 2.5, where we have taken the down-converted signal from above and implemented a bandpass Butterworth filter. This signal can now be decimated (down-sampled) without any loss of information.

#### 2.5 Summary

In this section, we have gone through the steps a signal takes after being measured by a front end system and converted to a digital signal. This process involves sampling as a given rate, downconverting to a lower/higher frequency band, filtering to remove the high frequency component, then decimating the



**Figure 2.4:** Plotted above is the impulse response, h[n], for a Butterworth filter of low-pass type. The y-axis indicated the coefficient value.



**Figure 2.5:** (top) Downconverted signal and its Fourier Transform. (bottom) Downconverted and filtered signal and its Fourier Transform.

low frequency result. As one can imagine, this process can be very hardware expensive. Are there ways to make this process more efficient? It happens to be the topic of this paper.

## Chapter 3

## Polyphase Implementation

Up to this point, we have discussed the individual components that make up digital signal processing. What, then, is a polyphase filter bank? A polyphase filter bank (PFB) is a method of deconstructing the input signal and filter in order to more efficiently carry out the convolution-decimation process which was outlined above. In a direct implementation, as will be shown below, several of the multiplications and additions are unnecessary, as this data will be discarded during the decimation process. The PFB allows one to avoid these extra calculations, thus limiting the amount of hardware needed, which is especially important when utilizing finite-space FPGA boards.

#### 3.1 Theory

#### 3.2 2-tap Example

This section provides a mathematical walkthrough of a simple 2-tap polyphase implementation. It suffices to exhibit the time delay which the second filter must have in order to recover the same output as the direction convolution-

decimation. In a direct computation of the convolution of a signal/filter pair, as shown in Figure 3.1, where the signal is  $x[n] = \{x_0, x_1, x_2, x_3, x_4, x_5\}$ , and the filter is  $h[n] = \{h_0, h_1, h_2, h_3\}$ , where the lengths are L=6 and M=4, respectively,

$h_0x_0$	$h_0x_1$	$h_0x_2$	$h_0x_3$	$h_0x_4$	$h_0x_5$	0	0	0
0	$h_1x_0$	$h_1x_1$	$h_1x_2$	$h_1x_3$	$h_1x_4$	$h_1x_5$	0	0
0	0	$h_2x_0$	$h_2x_1$	$h_2x_2$	$h_2x_3$	$h_2x_4$	$h_2x_5$	0
0	0	0	$h_3x_0$	$h_3x_1$	$h_3x_2$	$h_3x_3$	$h_3x_4$	$h_3x_5$
$y_0$	$y_1$	$y_2$	$y_3$	$y_4$	$y_5$	$y_6$	$y_7$	$y_8$

**Figure 3.1:** The above table represents the computations necessary to implement a direction convolution. Each column in the table is summed to create the  $y_i$  coefficients at the bottom.

We can easily see that there are 24 multiplications (L\*M), and 27 additions (M-1)\*(L+M-1). Now, if we change our sample rate, as shown in Figure 3.2,

Before Decimation	After Decimation
$y_0 = h_0 x_0$	$y_0 = h_0 x_0$
$y_1 = h_0 x_1 + h_0 x_1$	0
$y_2 = h_0 x_2 + h_1 x_1 + h_2 x_0$	$y_2 = h_0 x_2 + h_1 x_1 + h_2 x_0$
$y_3 = h_0 x_3 + h_1 x_2 + h_2 x_2 + h_3 x_1$	0
$y_4 = h_0 x_4 + h_1 x_3 + h_2 x_2 + h_3 x_1$	$y_4 = h_0 x_4 + h_1 x_3 + h_2 x_2 + h_3 x_1$
$y_5 = h_0 x_5 + h_1 x_4 + h_2 x_3 + h_3 x_2$	0
$y_6 = h_1 x_5 + h_2 x_4 + h_3 x_3$	$y_6 = h_1 x_5 + h_2 x_4 + h_3 x_3$
$y_7 = h_2 x_5 + h_2 x_4$	0
$y_8 = h_3 x_5$	$y_8 = h_3 x_5$

**Figure 3.2:** In the above left column are the coefficients produced by the direct convolution, and in the above right the coefficients remaining after a 2-tap decimation (every other sample).

we see that large fraction of the multiplications and additions that were carried out have now been through away. Now we show how a polyphase implementation avoids these unnecessary computations. First, we split the filter into N-tap subfilters, in this case N=2, which gives  $h[n]^+ = \{h_0, h_2\}$  and

 $h[n]^- = \{h_1, h_3\}$ . We then convolve each of these with a sub-band of the input signal, x[n], which are  $x[n]^+ = \{x_0, x_2, x_4\}$  and  $x[n]^- = \{x_1, x_3, x_5\}$ , respectively. These convolutions are shown in Figure 3.3 and 3.4.

٠	$h_0x_0$	$h_0x_2$	$h_0x_4$	0	
	0	$h_2x_0$	$h_2x_2$	$h_2x_4$	
	$y_0^+$	$y_1^+$	$y_2^+$	$y_3^+$	

**Figure 3.3:** This table represents the convolution of  $h[n]^+$  and  $x[n]^+$ .

If we count up the number of multiplications from this, we see that now there are only 12 which must be carried out. We have thus reduced the number of multiplications by half, which for a 2-tap decimation seems reasonable. However, we have also lowered the number of summations, from 27 to 13.

$h_1x_1$	$h_1x_3$	$h_1x_5$	0
0	$h_3x_1$	$h_3x_3$	$h_3x_5$
$y_0^-$	$y_1^-$	$y_2^-$	$y_3^-$

**Figure 3.4:** This table represents the convolution of  $h[n]^-$  and  $x[n]^-$ .

Now, we combine the results of these two separate convolutions, but as we saw in the theory, we take the second output to be delayed by a timestep, which effects a spectral folding of sorts, but with the added benefit of the stopband phase offsets destructively cancelling one another.

First Filter	Second Filter	Convolution and Decimation
$y_0^+ = h_0 x_0$	$y_{-1}^- = 0$	$y_0^+ + y_{-1}^- = h_0 x_0 = \mathbf{y_0}$
$y_1^+ = h_0 x_2 + h_2 x_0$	$y_0^- = h_1 x_1$	$y_1^+ + y_0^- = h_0 x_2 + h_1 x_1 + h_2 x_0 = \mathbf{y_2}$
$y_2^+ = h_0 x_4 + h_2 x_2$	$y_1^- = h_1 x_3 + h_3 x_1$	$y_2^+ + y_1^- = h_0 x_4 + h_1 x_3 + h_2 x_2 + h_3 x_1 = \mathbf{y_4}$
$y_3^+ = h_2 x_4$	$y_2^- = h_1 x_5 + h_3 x_3$	$y_3^+ + y_2^- = h_1 x_5 + h_2 x_4 + h_3 x_3 = \mathbf{y_6}$
$y_4^+ = 0$	$y_3^- = h_3 x_5$	$y_4^+ + y_3^- = h_3 x_5 = \mathbf{y_8}$

**Figure 3.5:** The table above shows how the coefficients of the separate convolutions are summed.

### 3.3 Coded Example

Herein we present an example Python code which implements a polyphase decomposition on a Butterworth Filter which has been chosen so that the coefficients divide nicely.