
Wireless Networks

Wireless Network Introduction

- A wireless host is a network host that communicates wirelessly. Such devices may be stationary or mobile.
- A base station is a transmission and reception station that is located in a fixed location and serves as a central connection point for wiresless devices to communicate.
 - They are usually connected to a wired network, and relay packets between wireless devices and devices on the wired network.
 - An example is cellular towers.
- A wireless link is a link that is used to connect wireless hosts to base stations.
 - They have different access protocols to coordinate link access, and can have various transmission rates, distances, and frequency bands.
- Types of wireless links, and their ranges:



- A handoff occurs when a mobile device changes from one base station to another.
- Wireless network modes:
 - 1. Infastructure mode is when a base station connects mobile devices, to wired networks.
 - 2. Ad hoc mode is when there are no base stations, nodes can only transmit wirelessly to each other.

Wireless Network Characteristics

- As the distance increases between wireless nodes, the signal strength of the link decreases.
- There can be interference from other sources if a lot of wireless links are in the same
- Multipath propagation occurs; radio signals reflect off of objects and arrive at the destination at slightly different times.
- Overall, wireless communication is much more difficult than wired communication.
- Signal-To-Noise Ratio (SNR) is one way measure interference.

Code Division Multiple Access (CDMA)

- Code Division Multiple Access (CDMA) consits of assigning a unique code to each user. All users communicate over the same frequency, but each user has a "chipping" sequence to encode data.
- If codes are "orthogonal" it allows multiple users to coexist and transmit simultaneously with minimal interference.

802.11 Wireless Local Area Networks (Wi-Fi)

- The **802.11 LAN** architecture consists of wireless hosts communicating with a base station.
- Base stations are referred to as Access Points (AP).
- The **802.11** frequency spectrum is divided into channels at different frequencies.

 The access point admin chooses the frequency for each access point (interference is possible).
- New arriving hosts must associate with an access point. They do this by scanning channels and listening for beacon frames containing the access point's service set identifier (SSID) and MAC address. After they receive the beacon frames, they can choose an access point to associate with.
- Some access points require authentication inorder for wireless hosts to connect.
- Access points have an internal DHCP server, allowing them to assign ip addresses to wireless hosts.
- There are two ways that arriving hosts can scan for access points:
 - 1. **Passive Scanning** The wireless host listens for beacon frames, sends an association request frame, and waits for an association response frame.
 - 2. **Active Scanning** The wireless host broadcasts a probe request, probe responses are sent back from access points, the wireless host then sends a request frame to the access point it wants to associate with, and waits for a response frame.
- CSMA/CA is used to detect collision. If the sender detects that the channel is idle, they will send the entire frame. If the sender detects that the channel is busy, it will start a random backoff time and wait to transmit. After transmission the sender will wait from an ACK response, if it does not receive the response, the frame is retransmitted.
- 802.11 frames consist of 9 parts:
 - 1. Frame Control Bit flags.
 - 2. **Duration** The duration of reserved transmission time.
 - 3. Address 1 The MAC address of the wireless host or access point receiving the frame.
 - 4. **Address 2** The MAC address of the wireless host or access point transmitting the frame.
 - 5. Address 3 The MAC address of the router interface to which the access point is attached to.
 - 6. **Sequence Control** The frame sequence number for reliable data transmission.
 - 7. Address 4 An address that is reserved for use in ad hoc mode.
 - 8. **Payload** The encapsulated datagram.
 - 9. **CRC**

2	2	6	6	6	2	6	0 - 2312	4
frame control	duration	address 1	address 2	address 3	seq control	address 4	payload	CRC

Bluetooth

- Bluetooth is a short-range, wireless technology that is used for transmitting data between fixed and mobile devices over short distances.
- Bluetooth is ad hoc; it has no Infastructure.
- Bluetooth uses a 2.4-2.5 GHz ISM radio band and can transmit up to 3Mbps.
- Bluetooth clients can "go to sleep" (park) and wakeup later to preserve battery. This is known as parked mode.
- Bluetooth uses bootstrapping. Nodes self-assemble into piconet.

4G/5G Cellular Networks

- Cellular networks are the solution for wide-area mobile networks. Such networks have a transmission rate of up to 100s of Mbps.
- Cellular networks are interconnected to the wired internet.
- Cellular devices are identified via Subscriber Identity Module Cards (SIM Cards).
- Unlike the wired-internet, in cellular networks, mobility is treated as a first class service.
- LTE introduced a seperation between the control plane and the data plane. LTE introduced new protocols for mobility managment, security, and authentication on the control plane. LTE introduced new protocols at the link and physical layer aswell.