
Wireless Pi

DSP, Wireless Communications, SDR and More

https://wirelesspi.com

Phase Locked Loop (PLL) in a Software Defined Radio (SDR)

By Qasim Chaudhari



IBM Watson and Google DeepMind are the most complex computers that, some believe, will try to run the world in a distant future. A PLL on the other hand is the simplest computer that actually runs so much of the world as a fundamental component of intelligent electronic circuits. The PLL was invented by the French engineer Henri de Bellescize in 1932 when he published his first implementation in the French journal *L'Onde Electrique*.

A Phase Locked Loop (PLL) is a device used to synchronize a periodic waveform with a reference periodic waveform. In essence, it is an automatic control system, an example of which is a cruise control in a car that maintains a constant speed around a given threshold. Although a PLL can be used for a variety of applications, it is enough for our purpose to treat it as a device that tracks the phase and frequency of an incoming sinusoid.


In a PLL, a control mechanism adjusts input signal to an oscillator according to a derived phase error such that the eventual phase error converges towards zero. We say that the phase of the output signal is locked to the phase of the input reference signal and hence it is called a Phase Locked Loop. In this text, we will focus on discrete-time PLLs.

PLL design and analysis

From a functional perspective, a PLL is the most important block in a digital communication system and hence it requires careful mathematical understanding and design. Usually this is done through application of Laplace Transform in continuous-time case and z-Transform in discrete-time domain. However, for the sake of simplicity, we treat just one transform, namely the Discrete Fourier Transform (DFT) in our articles.

Therefore, in regard to PLL design and analysis, we will take some key results from the literature without deriving them. This is due to our limitation of not covering the Laplace and z-Transforms. It should also be remembered that the design and analysis of a PLL does become mathematically untractable beyond an initial assumption of linearity and extensive computer simulations are needed in any case for its implementation in a particular application.

Let us start with a block diagram of a basic PLL shown in Figure below.



....

Assume that the discrete-time sinusoidal input to the PLL is given as

$$ext{input} = A \cos igg(2 \pi rac{k}{N} n + heta[n] igg)$$


The PLL is designed in a way that the output is

$$ext{output} = \cos\!\left(2\pirac{k}{N}n + \hat{ heta}[n]
ight)$$

where $\hat{\theta}[n]$ should be as close to $\theta[n]$ as possible after acquisition. This phase difference $\theta[n] - \hat{\theta}[n]$ is called **phase error** and is denoted by $\theta_e[n]$.

$$heta_e[n] = heta[n] - \hat{ heta}[n]$$

The phase error $heta_e[n]$ computed at time n is drawn in Figure below for a continuous-time signal.



The roles played by each block in the PLL are as follows.

[Phase error detector] A phase error detector determines the phase difference between a reference input waveform and a locally generated waveform and generates a corresponding signal denoted as $e_D[n]$. [Loop filter] A loop filter sets the dynamic performance limits of a PLL. Moreover, it helps filter out noise and irrelevant frequency components generated in the phase error detector. Its output signal is denoted as $e_F[n]$. [Numerically controlled oscillator (NCO)] An NCO generates a local discrete-time discrete-valued waveform with a phase as close to the phase of the reference signal as possible. The amount of the phase adjustment during each step is determined by the loop filter output.

As a first step towards our understanding, assume that heta[n] is zero and so the frequency of the input signal is $2\pi k/N$. Consequently,

- the NCO operates at the same frequency as well and the phase error $heta_e$ is zero,
- then the phase error detector output $e_D[n]$ must ideally be zero,
- that leads to loop filter output $e_F[n]$ to be zero.

However, if θ_e was not zero at the start,

- the phase error detector would develop a non-zero output signal $e_D[n]$ which would rise or fall depending on θ_e ,
- ullet the loop filter subsequently would generate a finite signal $e_F[n]$, and
- ullet this would cause the NCO to change its phase in such a way as to turn $heta_e$ towards zero again.

Let us find out how this control mechanism adapts favorably in opposite direction to the input phase changes.


Phase error detector

The phase error detector is a device which outputs some function $f\{\cdot\}$ of the difference between the phase $\theta[n]$ of the PLL input and the phase $\hat{\theta}[n]$ of the PLL output. So the phase error detector output is written as

$$e_D[n] = f\left\{ heta[n] - \hat{ heta}[n]
ight\} = f\left\{ heta_e[n]
ight\}$$
 (1)

The function $f\{\cdot\}$ is in general non-linear due to the fact that the phase $\theta[n]$ is embedded within the incoming sinusoid and is not directly accessible.

A phase equivalent representation of such a PLL can be drawn by taking into account the phases of all sinusoids and tracking the operations on those phases through the loop. This is illustrated in Figure below.



As mentioned before, a PLL is a non-linear device due to the phase error detector not having direct access to the sinusoidal phases. Although in reality the output is in general a non-linear function $f(\cdot)$ of the phase difference between the input and output sinusoids, a vast majority of the PLLs in locked condition can be approximated as linear due to the following reason.

In equilibrium, the loop has to keep adjusting the control signal $e_F[n]$ such that the output $\hat{\theta}[n]$ of the NCO is almost equal to the input phase $\theta[n]$. So during a proper operation, the phase error $\theta_e[n]$ should go to zero.


$$heta_e[n] = heta[n] - \hat{ heta}[n] o 0$$

To make this happen, what should be the shape of the curve at the phase error detector output $e_D[n]=f(\theta_e[n])$?

For finding the answer, first assume that $\theta_e[n]$ is positive and see what can make it go to zero.

$$egin{aligned} heta_e[n] > 0 &\Longrightarrow heta[n] - \hat{ heta}[n] > 0 \ &\Longrightarrow heta[n] > \hat{ heta}[n] \ dots & \hat{ heta}[n] ext{ should increase} \ &\Longrightarrow e_F[n] > 0 \ &\Longrightarrow e_D[n] > 0 \ &\Longrightarrow f(e[n]) > 0 \end{aligned}$$

Similarly, when $\theta_e[n] < 0$, it can be concluded that $e_D[n] = f(e[n])$ should be negative as well. This leads to the symbolic phase error detector input/output relationship drawn in Figure below for the **phase error** θ_e and **average phase error detector output** $\operatorname{Mean}\{e_D[n]\} \equiv \overline{e_D}$. This kind of relationship is called an **S-curve** due to its shape resembling the English letter "S". In articles on synchronization, we learn more about this shape and name.



Under steady state conditions, $\theta_e[n]$ hovers around the origin and hence $e_D[n]=f(e[n])$ also stays within the region indicated with the red ellipse in Figure above. An extended typical S-curve is also drawn where one can observe that the PLL has the ability to pull back even a larger error $\theta_e[n]$. There is an increase in $e_D[n]$ with larger $\theta_e[n]$, thus $\hat{\theta}[n]$ increases and subsequently pulls $\theta_e[n]=\theta[n]-\hat{\theta}[n]$ back towards zero. However, the steering force depends on the magnitude of $e_D[n]$ which is different outside the linear region. It can be deduced that in the linear region of operation (a straight line relationship),


- a positive slope around zero produces a stable lock point, and
- a negative slope around zero does not generate a stable lock point.

Within the small linear operating range, the PLL can be analyzed using linear system techniques. Around this region for small θ_e , the non-linear operation $f(\cdot)$ can be approximated as

$$f\left\{ heta_{e}
ight\} pprox K_{D}\cdot heta_{e}$$

where K_D is the slope of the line known as the gain of the phase error detector.

The phase equivalent loop for this linear model is shown in Figure below, where the phase error detector now consists of just an adder and a multiplier: the difference between the input phase and the output phase is simply scaled by the gain K_D .



As we will find in later chapters, the phase error detector is the most versatile block in a PLL that leads to an extremely wide range of PLL designs. On the other hand, depending on a certain application, there are set rules for choosing a loop filter and an NCO which simplify the process to some extent. In this text, our main purpose to employ PLLs is to build phase and timing synchronization modules instead of investigating the

PLL theory in depth. Therefore, we will devise several different kinds of phase error detectors while using the same loop filter and NCO for each PLL.

Proportional + Integrator (PI) Loop Filter

The loop filter in a PLL performs two main tasks.

- 1. The primary task of a loop filter is to deliver a suitable control signal to the NCO and establish the dynamic performance of the loop. Most PLL applications require a loop filter that is capable of driving not only a phase offset between the input and output sinusoids to zero, but also tracking frequency offsets within a reasonable range. For larger carrier frequency offsets, a <u>Frequency Locked Loop (FLL)</u> is needed.
- 2. A secondary task is to suppress the noise and high frequency signal components.

For this purpose, a **Proportional + Integrator (PI)** loop filter is most commonly used in PLL design. As the name suggests, a PI filter has a proportional and an integrator component:

[Proportional] The proportional term is a simple gain of K_P . To the filter output, it contributes a signal that is proportional to the filter input as

$$e_{F,1}[n] = K_P \cdot e_D[n]$$

[Integrator] The integrator term is an ideal integrator with a gain of K_i . To the filter output, it contributes a signal that is proportional to the integral of the input signal. Or in discrete-time,


$$e_{F,2}[n] = e_{F,2}[n-1] + K_i \cdot e_D[n]$$

It can be deduced that it executes forward difference integration to accumulate its input. The accumulation component is necessary to drive the steady-state error at the PLL output to zero in the presence of a frequency offset.

Combining the proportional and integrator components leads to the loop filter output $e_F[n]$.

$$e_F[n] = e_{F,1}[n] + e_{F,2}[n]$$

When a PI filter is incorporated in the linear PLL model, we get the discrete-time PLL block diagram drawn in Figure below. The notation D_1 represents a delay of one sample time.



For the sake of completion, it is important to know that

- a PLL without a loop filter (understandably known as a first order PLL) is also used in some applications
 where noise is not a primary concern [1], and
- a higher order loop filter can suppress spurs but increasing the order also increases the phase shift of such filters, thus making them prone to become unstable.

Numerically Controlled oscillator (NCO)

The signal $e_F[n]$ forms the input as a control signal to set the phase of an oscillator. The name controlled oscillator arises from the fact that its phase depends on the amplitude of the input control signal. Some examples of controlled oscillators are Voltage Controlled Oscillator (VCO) and a Numerically Controlled Oscillator (NCO).

The oscillation frequency of a **Voltage Controlled Oscillator (VCO)** is controlled by its voltage input and hence it is an integral part of analog PLLs. As more and more functionality of the transceiver shifts towards the digital domain, the analog PLLs are seldom employed for waveform synchronization.

A Numerically Controlled Oscillator (NCO) creates a discrete-time as well as discrete-valued (i.e., digital) representation of a waveform whose phase is steered by digital representation of a number at its input. In wireless communication devices, an NCO plays a central role in creating a digital version of a PLL for synchronization purpose. It has two main components:

[Phase Accumulator] The NCO adjusts its output phase $\hat{ heta}[n]$ based on its input signal $e_F[n]$ as

$$\hat{ heta}[n] = K_0 \sum_{i=-\infty}^{n-1} e_F[i]$$

where K_0 is a constant of proportionality known as the oscillator gain. From this expression, we can see that an NCO acts as a phase accumulator. Note that the output can also be modified as

$$\hat{\theta}[n] = K_0 \sum_{i=-\infty}^{n-1} e_F[i] = K_0 \sum_{i=-\infty}^{n-2} e_F[i] + K_0 \cdot e_F[n-1]
= \hat{\theta}[n-1] + K_0 \cdot e_F[n-1] \mod 2\pi$$
(2)


It can be deduced that an NCO executes backward difference integration to accumulate its input. Unlike the analog VCO, the gain K_0 of the phase accumulator can be easily set to a fixed value, say 1.

[Look-Up Table (LUT)] In embedded wireless devices, the phase update $\hat{\theta}[n]$ from the integrator serves as an index into a Look-Up Table (LUT) which stores the numeric values of a desired sampled waveform (such as a sine and a cosine). So the output can be computed as

$$egin{aligned} s_I[n] &= \cos\Bigl(\hat{ heta}[n]\Bigr) \ s_Q[n] &= \sin\Bigl(\hat{ heta}[n]\Bigr) \end{aligned}$$

Naturally, the size of the lookup table determines the memory requirements as well as the amount of quantization on $\hat{\theta}[n]$, hence leading to a tradeoff between memory consumption and waveform approximation error. In most applications, a finer estimate is required to reduce this phase error noise which can be generated through interpolation between the stored samples, thus a change in the LUT size is not needed.

With the inner workings of NCO available, a complete block diagram of a phase equivalent model of a PLL is now drawn in Figure below. The notation D_1 represents a delay of one sample time.



As stated earlier, it is easier to establish the kind of loop filter and NCO according to the desired PLL performance and then search for a suitable phase error detector. For the purpose of carrier phase

synchronization, we will continue to use a PI loop filter and an NCO for all different phase error detectors. For symbol timing synchronization, the loop filter will remain the same while a discrete-time interpolator will be employed instead of an NCO due to the nature of the underlying problem.

Designing a PLL


For the synchronization setup in this text, the PLL response is determined by two parameters: damping factor ζ and natural frequency ω_n , which are taken from the standard control system terminology for a second order system. A description of ζ and ω_n is as follows.

[Damping factor ζ :] Imagine dropping a ball on the ground. After hitting the ground, the ball bounces up to a distance, and repeats damped oscillations before finally settling in equilibrium. Similarly, a PLL phase acquisition process exhibits an oscillatory behavior in the beginning which can be controlled by the damping factor.

For a given input signal, a PLL behaves differently for different values of ζ . This is illustrated in Figure below for a unit step phase input (when the input is a unit impulse, the output is an impulse response and when the input is a unit step, the output is known as a step response).

- When $\zeta < 1$, the loop response exhibits damped oscillations in the form of overshoots and undershoots and the system is termed as **underdamped**.
- When $\zeta > 1$, the loop response is the sum of decaying exponentials, oscillatory behaviour disappears with large ζ and the system is **overdamped**.
- Finally, when $\zeta=1$, the response is somewhere between damped oscillations and decaying exponentials and the PLL is termed as **critically damped**.

PLL output as a response to a step input



[Natural frequency ω_n :] We will shortly see that the PLL in tracking mode acts as a lowpass filter. In this role, the natural frequency ω_n can be considered a coarse measure of the loop bandwidth.


PLL as a Lowpass Filter

The purpose of employing a PLL in a communications receiver is to track an incoming waveform in phase and frequency. This input signal is inherently corrupted by additive noise. In such a setup, a receiver locked in phase should reproduce this original signal adequately while removing as much noise as possible. The Rx uses a VCO or an NCO with a frequency close to that expected in the signal for this purpose. Through the loop filter, the PLL averages the phase error detector output over a length of time and keeps tuning its oscillator based on this average.

If the input signal has a stable frequency, this long term average produces very accurate phase tracking, thus eliminating a significant amount of noise. In such a scenario, the input to the PLL is a noisy signal while the output is a clean version of the input. We can say that when operating as a linear tracking system, a PLL is a filter that passes signal and rejects noise.

Passband of a PLL

Having established the filtering operation of a PLL, we need to find out what kind of a filter a PLL is. For this purpose, consider the fact that within the linear region of operation, the PLL output phase closely follows the input phase for small and slow phase deviations. On the other hand, it loses lock for large and quick input variations, thus necessitating a lowpass frequency response.



The above Figure shows the frequency response of a PLL with PI loop filter: it is indeed a lowpass filter. Before we think of it having a sharp transition bandwidth, remember that the frequency axis is also drawn on a logarithmic scale. Moreover, the frequency scale is normalized to natural frequency ω_n which makes the curve valid for all such PLLs.

The figure also reveals that the spectrum of this PLL as a lowpass filter is approximately flat between zero and ω_n . This implies that the PLL should be able to track phase and frequency variations in the reference signal as long as these variations remain roughly below ω_n .

By the same token, the bandwidth of this lowpass system varies with ω_n . However, a better definition of the bandwidth is needed because the loop frequency response strongly depends on ζ for the same ω_n .

Therefore, a bandwidth measure known as the **equivalent noise bandwidth** B_n (see Ref. [1]) is used that is related to natural frequency ω_n and damping factor ζ as

$$B_n = \frac{\omega_n}{2} \left(\zeta + \frac{1}{4\zeta} \right) \tag{3}$$

for a PI loop filter.

Computing the Loop Constants

Designing a PLL in a software defined radio starts with defining the noise bandwidth B_n and damping coefficient ζ .

[Loop noise bandwidth B_n :] As we will see in Example below, there is a tradeoff involved between choosing

- a small noise bandwidth that filters out most of the noise (and by extension the frequencies falling in the stopband), and
- a large noise bandwidth that can track fast phase variations, i.e., higher frequencies (and by extension allowing more noise to enter through the loop).

Both of the above objectives cannot be achieved simultaneously. However, a software radio based approach allows some relaxation as explained later in this article. For most cases of communication receivers, a B_n value between 1% and 5% of the sample rate suffices for rejecting the noise and tracking the input phase.

[Damping factor ζ :] On the other hand, a large ζ results in no overshoots but long convergence time while a small ζ exhibits relatively fast convergence but damped oscillations. A good balance between the two is achieved with $1/\sqrt{2}=0.707$ as a frequently used value. Typical values of ζ range from 0.5 to 2 in practical applications.

Next, having already chosen a PI loop filter, there are four constants that need to be determined: K_0 , K_D , and K_i .

[K_0 :] In a discrete-time system, the NCO gain K_0 can be easily fixed to a suitable value, say 1.

[K_D :] The phase error detector gain K_D is computed according to the structure and resulting expression of the phase error detector, some examples of which we will see in later examples below. Due to this dependence on the nature of phase error detector, K_D can be treated as a fixed given parameter around which the rest of the loop is designed.

[K_P , K_i :] With K_0 and K_D established, the PI filter coefficients K_P and K_i remain the two unknowns in the above two equations and hence can easily be computed. Under the assumption that the loop noise bandwidth is small compared to the sample rate

$$B_n << F_S$$

control systems theory sets the following relationships between the loop constants and loop parameters, see Ref. [2].

$$K_P pprox rac{1}{K_D K_0} \cdot rac{4\zeta}{\zeta + rac{1}{4\zeta}} \cdot rac{B_n}{F_S}$$
 $K_i pprox rac{1}{K_D K_0} \cdot rac{4}{\left(\zeta + rac{1}{4\zeta}
ight)^2} \cdot \left(rac{B_n}{F_S}
ight)^2$ (4)

Notice that the PLL noise bandwidth is specified according to the sample rate F_S . However, symbol rate $R_M=1/T_M$ is a more appropriate parameter in digital communication systems and hence noise bandwidth can be specified according to R_M . From the relation $F_S=L\cdot R_M$, where L is the number of samples/symbol, the above equations can be modified as


$$K_{P} \approx \frac{1}{K_{D}K_{0}L} \cdot \frac{4\zeta}{\zeta + \frac{1}{4\zeta}} \cdot \left(\frac{B_{n}}{R_{M}}\right)$$

$$K_{i} \approx \frac{1}{K_{D}K_{0}L^{2}} \cdot \frac{4}{\left(\zeta + \frac{1}{4\zeta}\right)^{2}} \cdot \left(\frac{B_{n}}{R_{M}}\right)^{2}$$
(5)

These are the equations we will use for computing the values for loop constants in specific PLL applications.

In summary, a software PLL whose code runs in a wireless device can be designed through the procedure outlined in Figure below.

Software PLL Design Procedure for a PI filter



Next, we cover a few examples to demonstrate the phase tracking capability of a PLL and how different parameters influence its performance.

Example 1


Assume that the a PLL has to be designed such that it locks to a real sinusoid with discrete frequency k/N=1/15 cycles/sample. Thus, the incoming sinusoid can be written as

$$r[n] = A \cos igg(2\pi rac{1}{15} n + heta[n] igg)$$

where $\theta[n]$ can be a slowly changing phase. Here, we set a constant phase angle $\theta[n]=\pi$ that needs to be tracked. Such a large phase difference will enable us to clearly observe the PLL convergence process.

The block diagram for such a system is drawn in Figure below. The NCO has one complex output, or two real outputs with an inphase and a quadrature component.

$$egin{align} s_I[n] &= \cosigg(2\pirac{k}{N}n + \hat{ heta}[n]igg) \ s_Q[n] &= -\sinigg(2\pirac{k}{N}n + \hat{ heta}[n]igg) \ \end{aligned}$$



Phase Error Detector

The phase error detector is a simple multiplier that forms the product between the input sinusoid and the quadrature component of the NCO output.

$$egin{align} e_D[n] &= -\sinigg(2\pirac{k}{N}n + \hat{ heta}[n]igg)\cdot A\cosigg(2\pirac{k}{N}n + heta[n]igg) \ &= rac{A}{2}\sinigg(heta[n] - \hat{ heta}[n]igg) - rac{A}{2}\sinigg(2\pirac{2\cdot k}{N}n + heta[n] + \hat{ heta}[n]igg) \ &= rac{A}{2}\sinigg(heta_e[n]igg) + ext{double frequency term} \ \end{split}$$


where the identity $\cos(A)\sin(B)=\frac{1}{2}\left\{\sin(A+B)\right\}-\sin(A-B)$ has been used. The second term involving $2\pi(2\cdot k/N)$ is the double frequency term that is filtered out by the loop filter. Therefore, the loop tracks the first term only, given by

$$e_D[n] pprox rac{A}{2} \mathrm{sin} \left(heta_e[n]
ight)$$

The S-curve is the sine of θ_e which can be approximated using the identity $\sin A \approx A$ for small A. For this reason, the phase error detector output is approximately linear for steady state operation around the origin.

$$egin{aligned} \overline{e_D} &= rac{A}{2} {\sin heta_e} \ &pprox rac{A}{2} heta_e \quad ext{for small } heta_e \end{aligned}$$

This S-curve is plotted in Figure below.



Loop Constants

From the above equation, the phase error detector gain K_D is clearly seen to be

$$K_D=rac{A}{2}$$

and hence is a function of sinusoid amplitude at the PLL input. Remember from Eq (4) that loop filter gains K_P and K_i involve K_D in their expressions. If the input signal level is not controlled, loop filter will have incorrect coefficients and the design will not perform as expected. In a wireless receiver, this amplitude is maintained at a predetermined value by using an Automatic Gain Control (AGC).

For the purpose of this example, we assume that A is fixed to 1 and hence

$$K_{D} = 0.5$$

Next, we design a PLL with damping factor

$$\zeta = 1/\sqrt{2} = 0.707$$

and loop noise bandwidth $B_n=5\%$ of the sample rate F_S , or

$$B_n/F_S=0.05$$

Thus, plugging these parameters in Eq (4), we get

$$K_P = 0.2667$$


 $K_i = 0.0178$

After setting the rest of the parameters at the start of this example, the PLL can be simulated through any programming loop in a software routine that computes the sample-by-sample product of the loop input and quadrature loop output.

Phase Error Detector Output $e_D[n]$


We start with the plot shown in Figure below displaying $e_D[n]$ that contains the following two components.

- A slowly varying average component hidden in $e_D[n]$ is shown in red. This can be thought of the true phase error to which the loop responds by converging to the incoming phase. Observe that this error stays positive for the first 27 samples, then goes negative before settling to zero at around 70 samples mark. Therefore, as we will see later, the NCO output should overcome the initial phase difference of π and track the input sinusoid after around 70 samples.
- A constant amplitude sinusoid with double frequency $2\cdot 2\pi(k/N)=2\pi(2/15)$. Observe in Figure that every 15 samples, there are 2 complete oscillations of this sinusoid riding on average error curve. This is more clearly visible towards the end of the curve where steady state is seen to be reached. Since A/2=0.5, the amplitude of this double frequency term approximately varies from around -0.5 to +0.5, resulting in a peak-to-peak amplitude of 1.



Loop Filter Output $e_F[n]$

Figure below displays the error signal $e_F[n]$ at the output of the loop filter. Similar kinds of trajectories are visible as in $e_D[n]$. However, the amplitude of double frequency term has been reduced from a peak-to-peak value of 1 in $e_D[n]$ to a peak-to-peak value of 0.3. This behaviour reinforces the lowpass characteristic of a PLL. Recall that the input sinusoid has a discrete frequency k/N=1/15 which was chosen for the purpose of better visualization of error convergence. If we had chosen a higher frequency, the attenuation of double frequency term would have been different.




Phase Estimate $\hat{\theta}\left[n\right]$

The phase estimate $\hat{\theta}[n]$ is plotted in Figure below. Just like $e_D[n]$ approaching zero after 70 samples, $\hat{\theta}[n]$ is seen to approach the initial phase difference π between the input and PLL output sinusoids. The oscillations due to double frequency term still remain.

Observe that the phase estimate does not directly converge to the actual value of π . Instead, its average value exhibits oscillatory behaviour by going beyond π , then returning and oscillating around this value, which could have been clearer if the figure was extended to display more samples. This is due to the value chosen for the damping factor $\zeta=0.707$.


Just like dropping a ball on the ground, the phase estimate $\hat{\theta}[n]$ repeats damped oscillations before finally settling at the equilibrium.



PLL Output Sinusoid

Finally, the output inphase sinusoid $\cos\left(2\pi(k/N)n+\hat{\theta}[n]\right)$ is shown along with the input sinusoid in Figure below. Initially, there is a phase difference of π between them but gradually the PLL compensates for this difference and approaches the input sinusoid tracking successfully afterwards. This happens after 70 samples where $e_D[n]$ was seen to draw towards zero.

Interestingly, the little oscillatory behaviour shown by $\hat{\theta}[n]$ can be spotted here as well after convergence has reached, where the red dashed curve slightly leads and then slightly lags behind the input blue curve.




The Python code and the corresponding output is shown next.

Python code

```
# PLL in an SDR
# Import the necessary packages and modules
import matplotlib.pyplot as plt
import numpy as np
k = 1
N = 15
K_p = 0.2667
K_i = 0.0178
K 0 = 1
input_signal = np.zeros(100)
integrator_out = 0
phase_estimate = np.zeros(100)
e D = [] #phase-error output
e_F = [] #loop filter output
sin_out = np.zeros(100)
cos_out = np.ones(100)
for n in range(99):
    input_signal[n] = np.cos(2*np.pi*(k/N)*n + np.pi)
    # phase detector
        e_D.append(input_signal[n] * sin_out[n])
```

```
except IndexError:
        e_D.append(0)
    #loop filter
    integrator_out += K_i * e_D[n]
    e_F.append(K_p * e_D[n] + integrator_out)
    #NCO
    try:
        phase_estimate[n+1] = phase_estimate[n] + K_0 * e_F[n]
    except IndexError:
        phase estimate[n+1] = K \ 0 * e F[n]
    sin_out[n+1] = -np.sin(2*np.pi*(k/N)*(n+1) + phase_estimate[n])
    cos_out[n+1] = np.cos(2*np.pi*(k/N)*(n+1) + phase_estimate[n])
# Create a Figure
fig = plt.figure()
# Set up Axes
ax1 = fig.add_subplot(211)
ax1.plot(cos_out, label='PLL Output')
plt.grid()
ax1.plot(input_signal, label='Input Signal')
plt.legend()
ax1.set_title('Waveforms')
# Show the plot
#plt.show()
ax2 = fig.add_subplot(212)
ax2.plot(e_F)
plt.grid()
ax2.set_title('Filtered Error')
plt.show()
```



Similar to the above example, different PLLs can be designed for different phase detectors, different values of damping factor ζ and loop noise bandwidth B_n and the results can be plotted to see how each parameter value affects the PLL behaviour. In the next example, we implement a PLL based on complex signal processing.


Example 2

The PLL now has to be designed such that it locks to a complex sinusoid with discrete frequency k/N=1/15 cycles/sample. Thus, the input sinusoid can be written as

$$egin{aligned} r_I[n] &= A\cosigg(2\pirac{k}{N}n + heta[n]igg) \ r_Q[n] &= A\sinigg(2\pirac{k}{N}n + heta[n]igg) \end{aligned}$$

The block diagram for such a system is drawn in Figure below. The NCO also has a complex output, or two real outputs with an inphase and a quadrature component, written as

$$egin{align} s_I[n] &= \cosigg(2\pirac{k}{N}n+\hat{ heta}[n]igg) \ s_Q[n] &= -\sinigg(2\pirac{k}{N}n+\hat{ heta}[n]igg) \ \end{aligned}$$



Here, the phase detector first computes the product of the input and output complex sinusoids. Although the block diagram shows a simple product operator, remember that a complex product actually implements 4 real multiplications and 2 real additions. Using the trigonometric identities as before, the double frequency terms simply cancel out and the result of the product is

$$egin{aligned} \{r[n] \cdot s[n]\}_I &= \cos \left(\hat{ heta}[n] - \hat{ heta}[n]
ight) = \cos heta_e[n] \ \{r[n] \cdot s[n]\}_Q &= \sin \left(\hat{ heta}[n] - \hat{ heta}[n]
ight) = \sin heta_e[n] \end{aligned}$$

Note the difference in complex signal processing: the double frequency terms actually cancel out instead of being filtered out by the loop filter. Furthermore, the phase of the above complex signal is precisely the error signal which needs to be extracted to form $e_D[n]$.


Accordingly, a four-quadrant inverse tangent defined in the article on <u>complex numbers</u> is used to compute the phase of this complex signal at multiplier output. Therefore, the output of the phase detector is simply

$$e_D[n] = \measuredangleig(r[n]\cdot s[n]ig) = heta_e[n]$$

for which the corresponding S-curve is drawn in Figure below.

$$\overline{e_D} = heta_e$$

Notice that the S-curve is linear over the whole range $-\pi \le \theta_e \le \pi$ and its expression implies that the phase detector gain $K_D=1$.




Now we design three PLLs with different damping factors ζ and loop noise bandwidth normalized with sample rate B_n/F_S as follows.


[Case 1]
$$\zeta=1/2$$
 and $B_n/F_S=0.05$

[Case 2]
$$\zeta=3$$
 and $B_n/F_S=0.05$

[Case 3]
$$\zeta=3$$
 and $B_n/F_S=0.01$

Loop filter coefficients K_P and K_i can be found by plugging these values in Eq (4). Next, the PLL can be simulated as in the previous example and the phase detector output $e_D[n]$ as well as the phase estimate $\hat{\theta}[n]$ are plotted for these three PLLs in Figures below.





Here, some comments about acquisition and locking behaviour of a PLL are in order.

Comments on Locking and Acquisition

A complete study of a PLL design and performance involves an in-depth mathematical formulation including solutions to non-linear equations. Just like we took some key results for PLL design without deriving them, we next comment on some key parameters that govern its performance. We start with the parameters that specify the frequency range within which a PLL can be operated. The details of most of what follows are nicely explained in Ref. [1].

[Hold range] There is a critical value of the frequency offset between the input and output waveforms after which the slightest disturbance causes the PLL to lose phase tracking forever. This range, in which a PLL can statically maintain phase tracking, is known as **hold range** F_H .

[Pull-in range] When the frequency offset of the reference signal in an unlocked state reduces below another critical value, the buildup of the average phase error starts decelerating thus leading to an eventual system lock. This value is known as pull-in range F_P . The pull-in range is significantly smaller than the hold range. Even though the pull-in process itself is relatively slow, the PLL will always become locked for an offset within this range.

[Lock range] Obtaining a locked state within a short time duration is desirable in most applications. If the frequency offset reduces below another value -- called the **lock range** F_L -- the PLL becomes locked within one single-beat note between the reference and the output frequencies. The lock range is much smaller than the pull-in range; however on the up side, the lock-in process itself is much faster than the pull-in process.

Remember that the lock actually implies that for each cycle of the input, there is one and only one cycle of NCO output. Even with a phase lock, both steady phase errors and fluctuating phase errors can be present. In practical applications, the operating frequency range of a PLL is normally restricted to the lock range.

In summary, the hold range and the lock range are the largest and the smallest, respectively, while the pull-in range lies somewhere within the boundaries set by them. Thus, the following inequality holds.

$$F_H > F_P > F_L$$

Next, we describe two other important quantities which determine the suitability of a PLL for an application.

[Acquisition time] A PLL requires a finite amount of time to successfully adjust to the incoming signal and reduce the phase error to zero, which is called acquisition time. The acquisition time is given by the sum of the time to achieve frequency lock as well as that of the phase lock. It is inversely proportional to B_n because a PLL with a large noise bandwidth lets more frequencies through its passband, consequently becoming able to track rapid variations and locking quicker than a PLL with narrower noise bandwidth. In above Figures, this can be noticed in a comparison between cases 2 and 3 with same $\zeta=3$ but different loop noise bandwidths. As a general rule, for a frequency offset F_{Δ} ,

$$T_{\rm acq} \propto \frac{F_{\Delta}^2}{B_n^3}$$
 (6)

[Tracking error] The performance of a PLL is determined by tracking error which is the power of the phase error signal. For a PLL in tracking mode (i.e., during linear operation), the noise power at the PLL input is given by AWGN with power spectral density N_0 defined in article on <u>AWGN</u> and the loop noise bandwidth B_n as

$$P_w = N_0 \cdot B_n$$

For a sinusoidal input with power P_s at the PLL input, the ratio P_s/P_w is the Signal-to-Noise Ratio (SNR). The expression for the tracking error ρ_{θ_s} is

$$\rho_{\theta_e} = \frac{N_0 B_n}{P_s} = \frac{P_w}{P_s} = \frac{1}{P_s/P_w} \tag{7}$$

Therefore, the tracking error in the presence of AWGN is inversely proportional to SNR and consequently directly proportional to B_n . It makes sense that a wider bandwidth allows a larger amount of noise at the PLL output, thus increasing the tracking error.

A Fast Lock Technique

From Eq (6) above, it is evident that selecting a large B_n in PLL design results in faster acquisition since the acquisition time is inversely proportional to a power of B_n . On the other hand, Eq (7) shows that a narrow B_n generates less tracking error since it is directly proportional to B_n . In conclusion, a good PLL design balances the opposite criteria of fast acquisition time and reduced tracking error.

In the world of hardware radio, PLL designers had to balance these two performance criteria by finding an acceptable compromise. The realm of software radio offers a better solution due to our ability to change the code on the fly which is explained below.

In an unlocked state, the PLL noise bandwidth B_n is made large so that it can achieve fast lock. In parallel, a certain algorithm known as a **lock detector** is run which generates a binary output depending on whether the PLL has acquired lock or not. Since the loop constants are reconfigurable in this scenario, their values are changed such that the PLL bandwidth B_n is reduced to a smaller value.

In other articles, we discuss carrier and timing synchronization procedures in a communications receiver. These blocks incorporate a PLL as an integral component.

References

[1] R. Best, Phase Locked Loops - Design, Simulation and Applications (6th Edition), McGraw Hill, 2007.


[2] M. Rice, Digital Communications - A Discrete-Time Approach, Prentice Hall, 2009.

About the Author




Qasim Chaudhari is an independent consultant and trainer with expertise in wireless communications, Software Defined Radio (SDR) and Digital Signal Processing (DSP). After obtaining a PhD in Electrical Engineering from Texas A&M University, he worked in different research labs on DSP algorithms development for real world demonstrations of wireless systems such as a MIMO-OFDM testbed, low-SNR receivers and phase of arrival based localization.


As the founder of https://wirelesspi.com, his focus is on explaining concepts through beautiful figures, simple mathematics and intuitive reasoning. He is an author of two books, Wireless Communications from the Ground Up - An SDR Perspective (along with a video course with practical exercises to implement the concepts) and 5G Physical Layer - An Easy Guide to Key Technologies. You can reach him at info@wirelesspi.com.



Send and receive wireless signals over the air without expensive SDR hardware through a speaker (Tx) and a microphone (Rx)



Learn about 5G physical layer through great visualizations, simple maths and intuitive explanations



Learn about Wireless Communications and SDR through great visualizations, simple maths and intuitive explanations