

8086 Addressing Modes

Dept. of Computer Science and Engineering BRAC University

CSE 341 Team





Lecture References:

? Book:

- ? Microprocessors and Interfacing: Programming and Hardware, Chapter # 2, Author: Douglas V. Hall
- ? The 8086/8088 Family: Design, Programming, And Interfacing, Chapter # 2, Author: John Uffenbeck.





Addressing Mode and Categories

- ? The different ways in which a microprocessor can access data are referred to as its addressing modes.
- ? Addressing modes of 8086 Microprocessor are categorized as:
 - ? Addressing Data
 - ? Addressing Program codes in memory
 - ? Addressing Stack in memory
 - ? Addressing I/O
 - ? Implied addressing






Things to know...

Instruction format

- Instructions can have 1, 2 or no operands
 - INCAX ; I operand
 - **ADD CX, DX**; 2 operands

Destination source

HLT; no operand



- Instruction cannot have:
 - SUB [DI], [1234h]; memory locations as both operands
 - MOV 2345, 5425; immediate data as both operands
 - MOV 1234, AX; immediate data as destination operand





- I. Immediate addressing
- II. Direct addressing
- III. Register [direct] addressing
- IV. Register indirect addressing
- v. Base-plus-index addressing
- VI. Register relative addressing
- VII. Base-relative-plus-index addressing





I. Immediate addressing

? Data is immediately given in the instruction

MOV BL, III

By default if no number system is given, we will consider it as decimal,d.

II. Direct addressing

? Data address is directly given in the instruction

MOV BX, [437AH]





III. Register [direct] addressing

? Data is in a register (here BX register contains the data)

MOVAX, BX

IV. Register [indirect] addressing

? Register supplies the address of the required data

MOV CX, [BX]





v. Base-plus-index addressing

- ? Base register is either BX or BP
- ? Index register is either DI or SI

MOV DX, [BX+DI]

v. Register relative addressing

- Register can be a base (BX, BP) or an index register (DI, SI)
- ? Mainly suitable to address array data

MOV AX, [BX+1000]





VII. Base-relative-plus-index addressing

? Suitable for array addressing

MOV AX, [BX+DI+10] MOV [BX+DI+10],AX



2. Addressing Program Codes in Memory

- ? Used with JMP and CALL instructions
- ? 3 distinct forms:
 - I. Direct
 - II. Indirect
- III. Relative

2. Addressing Program Codes in Memory

? Address is directly given in the instruction

JMP 1000: 0000

JMP doagain; doagain is a label in code

CALL 1000:0000

CALL doagain; doagain is a procedure in code

? Often known as far jump or far call



2. Addressing Program Codes in Memory, spiring Ex

- ? Address can be obtained from
 - a) any GP registers (AX,BX,CX,DX,SP,BP,DI,SI)

```
    \int MP AX

    IP = AX; then CS:
    IP
```

b) any relative registers ([BP],[BX],[DI],[SI])

```
JMP [BX]

IP = what is inside the physical address of DS: BX; then CS: IP
```

? c) any relative register with displacement

```
JMP [BX + 100h]

IP = what is inside the physical address of DS: BX +100h; then CS: IP
```





Address	31234h	31235h	12000h	12001h	30600h	30601h
Data	Data 12h		10h	20h	11h	21h

A. Assume for an 8086, DS = 1000h, CS = 3000h, SS = 8A40h, BX = 2000h, BP = 1234h, SI = 0020h, DI = 030Fh. We also execute the JMP [BX] instruction. Now, deduce the physical address of the memory location 8086 will jump to. [4]



Address	31234h	31235h	30600h	30601h	40600h	40601h
Data	12h	34h	11h	21h	30h	40h

8

A. Assume for an 8086, DS = 4000h, CS = 3000h, SS = 8A40h, BX = 2000h, BP = 1234h, SI = 600h, DI = 030Fh. We also execute the JMP [SI] instruction. Now, deduce the physical address of the memory location 8086 will jump to. [4]



Answer the questions based on the given table and data

Physical Address	8 bit hex data
14001h	78h
14000h	56h
13001h	34h
13000h	12h
03000h	ABh

Given DS = 1000h, CS = 3000h, SS = 8A40h, SI = 2000h, CX = 43AEh, DI = 030Fh. We also execute the JMP [SI + 1000h] instruction. Now, answer the questions based on the given table and data:



3. Addressing Stack in Memory

 PUSH and POP instructions are used to move data to and from stack (in particular from stack segment).

PUSH AX

POP CX

 CALL also uses the stack to hold the return address for procedure.

CALL SUM; SUM is a procedure name



4. Addressing Input and Output Porting Excellence

- ? IN and OUT instructions are used to address I/O ports
- ? Could be direct addressing

IN AL, 05h; Here 05h is a input port number

? or indirect addressing

OUT DX, AL; DX contains the address of I/O port

? Only DX register can be used to point a I/O port





5. Implied Addressing

- ? No explicit address is given with the instruction
- ? implied within the instruction itself
- ? Examples:

```
CLC; clear carry flag
```

HLT; halts the program

RET; return to DOS





8086 Machine Codes

Dept. of Computer Science and Engineering BRAC University

CSE 341 Team





- ? For 8085: Just look up the hex code for each instruction.
- ? For 8086 it is not simple.
- ? E.g 32 ways to specify the source in MOV CX, source.
- ? MOV CX, source

a 16-bit register (8 in number)
a memory location (24 possible memory addressing modes)


- ? Each of these 32 instructions require different binary code.
- ? Impractical to list them all in a table.
- ? Instruction templates help code the instruction properly.







Instruction template (6 bytes)



An instruction after conversion can have I to 6 bytes long of machine code

Constructing Machine Codes for 8086

- ? Each instruction in 8086 is associated with the binary code.
- ? You need to locate the codes appropriately.
- ? Most of the time this work will be done by assembler
- ? The things needed to keep in mind is:
 - ? Instruction templates and coding formats
 - ? MOD and R/M Bit patterns for particular instruction






MOV Instruction Coding

? MOV data from a register to a register/to a memory location or from a memory location to a register.

(Operation Code of MOV: 100010)







MOD and R/M Field

- ? 2-bit Mode (MOD) and 3-bit Register/Memory (R/M) fields specify the other operand.
- ? Also specify the addressing mode.

RM MOD	00	01	10	11		
				W = 0	W = 1	
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX	
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a.	cx	
010	[BP]+[SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX	
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX	
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP	
101	[D]	[DI] + d8	[DI]+d16	СH	BP	
110	d16 (direct address)	(BP)+d8	[BP] +d16	DH	SI	
111	[BX]	[BX] + d8	[BX] + d16	BH	DI	





MOD and R/M Field

- ? If the other operand in the instruction is also one of the eight register then put in II for MOD bits in the instruction code.
- ? If the other operand is memory location, there are 24 ways of specifying how the execution unit should compute the effective address of the operand in the main memory.
- ? If the effective address specified in the instruction contains displacement less than 256 along with the reference to the contents of the register then put in 01 as the MOD bits.
- ? If the expression for the effective address contains a displacement which is too large to fit in 8 bits then out in 10 in MOD bits.








? REG field is used to identify the register of the one operand

REG	W = 0	W = 1
000	AL	AX
001	CL	CX
010	DL	DX
011	BL	BX
100	AH	SP
101	СН	BP
110	DH	SI
111	ВН	DI



Instruction template



D - direction

If **D=0**, then direction is from a register (source)

If **D=1**, then direction is to a register (destination)

W - word

If **W=0**, then only a byte is being transferred (8 bits)

If **W=1**, them a whole word is being transferred (16 bits)

- 34h here is an 8-bit displacement
- [BX+34h] is a memory/offset address

MODE	OPERAND NATURE	
00	Memory with no displacement	→ MOV AX, [BX]
01	Memory with 8-bit displacement	→ MOV AX, [BX + 12h]
10	Memory with 16-bit displacement	→ MOV AX, [BX + 1234h]
11	Both are registers	→ MOVAX, BX

• 1234h here is a 16-bit immediate data




Instruction	D	W	MOD	
MOV BL, [1234H]	1	0	00	
MOV [DX], BX	0	1	00	
MOV [BX + SI + 1000H], AX	0	1	10	
MOV AL, [DI + 34H]	1	0	01	
MOV CX, DX	0/1	1	11	
MOV [2344H], [1234H]	Not Valid			
MOV 2344H, CX	Not Valid			





Instruction template



- Value for R/M with corresponding MOD value
- Value for REG with corresponding W value and the register considered in D


Check column that matches with MOD value

M					<u> </u>
RM	00	01	10	11	
				W = 0	W = 1
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a	cx
010	[BP]+[SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[D]	[DI] + d8	[DI]+d16	CH	BP
110	d16 (direct address)	(BP) + d8	[BP] +d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with 16 bit displacement given the opcode for MOV=100010



CSE – 341: Microprocessors BRAC University


HIGH BYTE DISPLACEMENT / DATA

LOW BYTE DISPLACEMENT / DATA





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with 16 bit displacement given the opcode for MOV=100010




MOV [SI + 8B43H] ,

RM MOD	00	01	10	11		
				W = 0	W = 1	
000	[BX] + [SI]	[BX]+[SI]+d8	[BX] + [SI] + d16	AL	AX	
001	[BXI+[DI]	[BX] + [Di] + d8	[BX] + [DI] + d16	a	cx	
010	[BP] + [SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX	
011	(BP)+[DI)	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX	
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP	
101	[D]	[DI] + d8	[DI]+d16	ан	BP	
110	d16 (direct address)	(BP) + d8	[BP] +d16	DH	SI	
111	[BX]	[BX] + d8	[BX] + d16	BH	DI	





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with \16 bit displacement given the opcode for MOV=100010




MOV [SI + 8B43H] , DH

RM M	00	01	10	11		
				W = 0	W = 1	
000	[BX] + [SI]	[BX]+[SI]+d8	[BX] + [SI] + d16	AL	AX	
001	[BXI+[OI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a	cx	
010	(BP)+(SI)	[BP] + [SI] + d8	[BP] + [SI] + d16	DL	DX	
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX	
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP	
101	[DI]	[DI] + d8	[DI] +d16	ан	BP	
110 d16 (direct address)		(BP) + d8	[BP]+d16	DH	SI	
111 [BX]		[BX] + d8 [BX] + d16		BH	DI	





? MOV 8B43H [SI], DH: Copy a byte from DH to memory with 16 bit displacement given the opcode for MOV=100010





BYTE 3


Machine Code: 1000 1000 1011 0100 0100 0011 1000 10112 or 88 B4 43 8B16







? MOV AX, BX: given the opcode for MOV=100010







? MOV AX, BX: given the opcode for MOV=100010

Considering AX to be our main register

BYTE I						-	→ BYTE 2 —						-	
1	0	0	0	1	0	1	1	1	1	0	0	0		
	OPCODE		D	W	M	OD	(REG)	R/M				


RM MOD	-80	01	10	14	
				W = 0	W = 1
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a	cx
010	[BP] + [SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[DI]	[DI] + d8	[DI]+d16	CH	BP
110	d16 (direct address)	(BP) + d8	[BP] +d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI

Example 2

Machine Code: 1000 1011 1100 00112 or 88 C316

UNIVERSITY

? MOV AX, BX: given the opcode for MOV=100010



RM MOO	00	01	10	11	
				W = 0	W = 1
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX
001	[BXI+(OI)	[BX] + [DI] + d8	(BX) + (DI) + d16	a	cx
010	[BP]+[SI]	(BP)+(SI)+d8	[BP] + [SI] + d16	DŁ.	DX
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP
101	[D]	[DI] + d8	[DI]+d16	ан	BP
110	d16 (direct address)	(BP)+d8	[BP]+d16	DH	SI
111	[BX]	[BX] + d8	[BX] + d16	BH	DI



BRAC UNIVERSITY Inspiring Excellence

Example 2 (Alternative)

MOV AX, BX

Now Considering BX to be our main register

OPCODE						D	w
1	0	0	0	1	0	0	1
					Here, since MAIN registe source so D	er and it at	

MOD		REG			R/M			
1	1	0	1	1	0	0	0	
Here for REG, we are considering BX						lere for R/M, onsidering A		





MOV [1234H], DL

RM MOD	00	01	10	11		
				W = 0	W = 1	
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX	
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a.	cx	
010	[BP] + [SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX	
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX	
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP	
101	[DI]	[DI] + d8	[DI]+d16	CH	BP	
110	d16 (direct address)	(BP)+d8	[BP] +d16	DH	SI	
111	[BX]	[BX] + d8	[BX] + d16	BH	DI	





OPCODE						D	W
1	0	0	0	1	0	0	0

MOD	REG		R/M				
0	0	0	1	0	1	1	0

Low 8 Bit / Low 1 Byte / Low 2 Hex Digit									
0	0	1	1	0	1	0	0		

High 8	High 8 Bit / High 1 Byte / High 2 Hex Digit									
0	0	0	1	0	0	1	0			



MOV 1234H, DL

RM MOD	00	01	10	11		
				W = 0	W = 1	
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX	
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a	cx	
010	[BP]+[SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX	
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX	
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP	
101	[D]	[DI] + d8	[DI]+d16	ан	BP	
110	d16 (direct address)	(BP)+d8	[BP] +d16	DH	SI	
111	[BX]	[BX] + d8	[BX] + d16	BH	DI	

Not valid. No machine code.





MOV DH, [BP+SI+7Dh]

RM MOD	00	01	10	11		
				W = 0	W = 1	
000	[BX] + [SI]	[BX] + [SI] + d8	[BX] + [SI] + d16	AL	AX	
001	[BXI+[DI]	[BX] + [DI] + d8	[BX] + [DI] + d16	a	cx	
010	[BP]+[SI]	[BP]+[SI]+d8	[BP] + [SI] + d16	DL	DX	
011	[BP]+[DI]	[BP]+[DI]+d8	[BP] + [DI] + d16	BL	BX	
100	[SI]	[SI] + d8	[SI]+d16	, AH	SP	
101	[DI]	[DI] + d8	[DI]+d16	ан	BP	
110	d16 (direct address)	(BP)+d8	[BP] +d16	DH	SI	
111	[BX]	[BX] + d8	[BX] + d16	BH	DI	





OPCODE						D	W
1	0	0	0	1	0	1	0

MOD		REG		R/M			
0	1	1	1	0	0	1	0

Low 8 Bit / Low 1 Byte / Low 2 Hex Digit									
0	1	1	1	1	1	0	1		

There is no 4th Byte

Machine Code Size



MOD = 00

- **1**. MOV [1234H], DL → 4 bytes
- 2. MOV AX, [BX] \rightarrow 2 bytes

MOD = 01

MOV DH, [BP + 7Dh] \rightarrow 3 bytes

MOD = 10

MOV DH, [BP + 712Dh] \rightarrow 4 bytes





MOD = 11

MOV DH,AL \rightarrow 2 bytes



• 89807812h to instruction





Thus, the instruction will be MOV [BX+SI+1278h], AX



Find the address mode, mod value and byte length



Instruction	Addressing Mode	Mod	Byte Length
MOV AH, BL	Register Direct Addressing	11	2
MOV [AX], BL	Register Indirect Addressing	00	2
MOV CX, [BP + SI + 3452h]	Base relative plus index Addressing	10	4
MOV [AH], [BL]	Not Valid	-	-
MOV [BX + DI], AX	Base plus index Addressing	00	2
MOV [BX + 22h], AX	Base plus relative	01	3
MOV AX, [1422h]	Direct Addressing	00	4
MOV 1234h[SI], AX	Base plus relative	10	4








? The Intel literature shows two different formats for coding 8086 instructions.

? Instruction templates helps you to code the instruction

properly.

? Example:

IN AL, 05H








- MOV BL,AL
- Opcode for MOV = 100010
- We'll encode AL so
 - D = 0 (AL source operand)
- W bit = 0 (8-bits)
- MOD = 11 (register mode)
- REG = 000 (code for AL)
- R/M = 011

OPCODE		W	MOD	REG	R/M
100010	0	0	11	000	011




? MOV 43H [SI], DH: Copy a byte from DH register to memory location.





? MOV CX, [437AH]: Copy the contents of the two memory locations to the register CX.







Thank You!!!