# Gas density-based BMP measurement\*

Sasha D. Hafner, Jacob R. Mortensen, Sergi Astals

October 12, 2020

Document number 304. File version 1.3. This document is from the Standard BMP Methods collection. †

# 1 Introduction

By measuring BMP bottle mass loss and biogas volume, gas density can be calculated, and from this, biogas composition. Development and validation of the method is described in Justesen et al. [2019]. This document describes the laboratory measurements needed for applying this "GD-BMP" (for gas density) method. For information on GD-BMP calculations, see document 204 from the Standard BMP Methods website [Hafner et al., 2020].

### 2 Protocol

## 2.1 Required equipment and supplies

- Digital scale
- Syringes and needles
- Manometer
- Typical BMP bottles and septa

The required accuracy of the scale will depend on the quantity of biogas produced. Generally, stated accuracy<sup>1</sup> of the scale should be around 30 mg for

<sup>\*</sup>Recommended citation: Hafner, S.D.; Mortensen, J.R.; Astals, Gas density-based BMP measurement. Standard BMP Methods document 304, version 1.3. Available online: https://www.dbfz.de/en/BMP (accessed on October 12, 2020).

Or see  ${\tt https://www.dbfz.de/en/BMP}$  for a BibTeX file that can be imported into citation management software.

<sup>&</sup>lt;sup>†</sup>For more information and other documents, visit https://www.dbfz.de/en/BMP. For document version history or to propose changes, visit https://github.com/sashahafner/BMP-methods.

<sup>&</sup>lt;sup>1</sup>Manufacturers often report accuracy as "linearity". Note that accuracy is not the same as "readability", which is the smallest value that can be read.

every g of substrate volatile solids (VS) used. As described below, the precision and stability of the scale is checked as part of the protocol.

A simple closed U-tube manometer is sufficient for determining that postventing headspace pressure is close to atmospheric. One can be made with some plastic tubing filled with water and a simple valve (made, e.g., by folding flexible tubing).

It is best to have several sizes of syringes, in order to have high relative precision in volume measurements when biogas production is both high or low. Ideally the largest syringe will be large enough to measure the largest volume of biogas produced in a single interval (e.g., 1 L if the largest volume is 800 mL of biogas). But large syringes are expensive, and not necessary. Instead, a single small syringe can be used multiple times to remove the biogas from a single bottle in a single interval. But this approach requires that the manometer is directly connected to the syringe and there is a valve between the syringe and the bottle.

#### 2.2 Setup

During setup, inoculum and substrate are added to bottles, and the headspace of each bottle is flushed to remove  $O_2$  and ensure anaerobic conditions. Pure  $N_2$  is preferred for flushing over mixtures containing  $CO_2^2$ . Bottles are then weighed and placed in an incubator.

#### 2.2.1 Step-by-step instructions

- 1. Check the accuracy of the scale with a weight set. It is particularly important that the actual accuracy is close to reported accuracy when weighing an object with a mass close to the total mass of a BMP bottle and its contents. For a scale with a reported accuracy of 50 mg, for example, this could be checked by taring the scale with a full bottle or equivalent mass, and adding a 50 mg weight.
- 2. Add the required mass of inoculum, substrate, and other additions (e.g., a trace element solution) to each labeled bottle and seal with a septum and cover. Determination of the quantity of material added by mass difference is the recommended approach: Tare scale with bottle, add approximately the desired quantity, wipe any material from near the mouth of the bottle, and finally determine the actual quantity from the scale reading. Note that the scale used here does not need to be the same scale used for determining mass loss (see "Incubation and sampling", below).
- 3. Flush the bottle headspace to remove  $O_2$ . A simple approach is to use a needle attached to a flow meter (e.g., a rotameter), a pressure regulator (to ensure low pressure), and a gas cylinder (generally with  $N_2$ ) with

 $<sup>^2</sup> Flushing gas results in a (generally small) error because its density may differ from produced biogas density (the density of <math display="inline">\rm N_2$  is identical to a  $\rm CH_4 : CO_2$  mixture with 58%  $\rm CH_4,$  and higher for a mixture with more  $\rm CH_4)$  but this can be corrected in calculations.

plastic tubing, along with a separate needle for venting. Minimize  $\mathrm{CO}_2$  removal by flushing for only 3 to 4 headspace volume exchanges. Ensure that the flushing gas does not bubble through the liquid in the bottle (needle should not be submerged). Allow the pressure in each bottle's headspace to equilibrate with atmospheric pressure before removing the venting needle.

- 4. Make 2 "water control" bottles that contains only water. They should be the same size and weigh about as much as the other BMP bottles. These bottles should never be vented; they are used to check the stability of the scale and it is essential that they do not lose any mass.
- 5. Weigh each bottle and record as "initial mass". Repeat this initial weighing in order to minimize the chance of a recording error, because calculations of cumulative CH<sub>4</sub> production at all timepoints require an accurate initial mass measurement. If there is a discrepancy between these two initial measurements, weigh again to determine the correct mass. It is important that the only change in bottle mass after this time is due to biogas removal. Bottles should be kept clean, and labels should not be added after this time, for example.
- 6. Place bottles in incubator set at the test temperature.

# 2.3 Incubation and sampling

Bottles are removed from the incubator occasionally to vent and weigh in what is here referred to as a "sampling event". Biogas temperature affects water vapor content. To minimize uncertainty in the headspace temperature used in calculations, the time that bottles spend outside the incubator should be short, and the same procedure and timing should be followed for each sampling event. (Ideally, venting and weighing should be done inside a temperature-controlled room, so bottles are always at the incubation temperature. However, the effects of headspace temperature on accuracy are small, so this is not required.)

The accuracy of the GD-BMP method is affected only slightly by variation in headspace pressure, and it is possible to correct for leakage of biogas. However, for safety (to avoid exploding bottles), for maximum precision, and to minimize possible effects of high  ${\rm CO_2}$  dissolution, total headspace pressure (absolute) should be kept below 3 bar (2 bar gauge pressure). Bottle pressures can be estimated from headspace and vented biogas volume.

#### 2.3.1 Step-by-step instructions

1. Remove both water control bottles from the incubator and weigh them to confirm scale consistency. If the results are the same as the initial masses (within the expected accuracy) proceed, otherwise, identify and address the problem with the scale or replace the scale if necessary. If the problem cannot be resolved, proceed and later correct mass results for scale drift.

- 2. Remove a single set of replicates from the incubator (e.g., the three replicates for cellulose).
- 3. Always starting with the same replicate (e.g., "1" or "a") gently swirl the bottle for at least  $10\,\mathrm{s}$  to mix the contents and encourage  $\mathrm{CO}_2$  equilibration between solution and headspace. During swirling, avoid contact between the liquid and the septum.
- 4. Weigh the bottle and record the result as pre-venting mass.
- 5. Vent the bottle using a syringe and measure biogas volume. Use the manometer to ensure that the headspace pressure is close to atmospheric after venting (gauge pressure ±3 kPa). Note any loss of reacting material through the needle or other unusual event.
- 6. Weigh the bottle after venting, and record the result as post-venting mass.
- 7. Proceed to the next replicate (e.g., "2" or "b") and repeat steps 3 6.
- 8. After all replicates have been mixed, weighed, vented, and weighed again, place the bottles back in the incubator.
- 9. Proceed to the next set of replicates (e.g., the three replicates for substrate "food waste A") and repeat steps 2 9.

### References

- S. D. Hafner, C. Justesen, R. Thorsen, S. Astals, C. Holliger, K. Koch, and S. Weinrich. Calculation of Methane Production from Gas Density-Based Measurements. Standard BMP Methods document 204, version 1.6., 2020. URL https://www.dbfz.de/en/BMP.
- C. G. Justesen, S. Astals, J. R. Mortensen, R. Thorsen, K. Koch, S. Weinrich, J. M. Triolo, and S. D. Hafner. Development and validation of a low-cost gas density method for measuring biochemical methane potential (bmp). Water, 11(12):2431, Dec. 2019. doi: 10.3390/w11122431. URL https://www.mdpi.com/2073-4441/11/12/2431.

<sup>&</sup>lt;sup>3</sup>If the septum becomes contaminated with reacting material, a small amount may be pushed out during venting, which will result in error in the determination of mass loss.