Yagi Antenna Workshop Building a Tape Measure Antenna

Northeastern University Wireless Club - W1KBN

September 9, 2024 Sign in here!

https://l.w1kbn.org/signin

Welcome to Our First Workshop!

- Welcome to the Wireless Club's first workshop of the semester!
- ► Who we are:
 - We are Northeastern University's Wireless Club, a student group passionate about electronics, antennas, and wireless technologies.
 - Our workshops are designed to be accessible for all skill levels—whether you have experience or not, you're in the right place.
- ▶ Today's Plan:
 - Introduction to HAM Radio and Antennas
 - Step-by-step Yagi Antenna build using a tape measure and basic materials
 - QA and hands-on assembly
- ► Visit our website for more: https://nuwireless.org/

Welcome!

- Wireless Club Meetings: 7 PM Thursdays @ 503 Hayden (Free Pizza!)
- Workshop Meetings: 7 PM Mondays @ East Village, Room 010
- ► Join our Slack: https://neuwireless.slack.com/join/signup
- ▶ Join our mailing list: http://eepurl.com/gduCIr
- Scope of today's workshop:
 - Rapid-Fire Ham Radio Overview
 - Antennas 101
 - ► The Build: https: //www.instructables.com/The-Tape-Measure-Antenna/
- ► Sign-in: https://l.w1kbn.org/signin

Common Terms and Abbreviations

- ► **HAM Radio** Amateur Radio, used for personal, non-commercial communication.
- ▶ VHF Very High Frequency (radio waves in the 30 MHz to 300 MHz range).
- SWR Standing Wave Ratio, a measure of the efficiency of the antenna's power transfer.
- ▶ RG-58 Cable A type of coaxial cable used for radio frequency signals.
- ▶ BNC Connector A common radio-frequency connector used for coaxial cable.
- Impedance Matching Adjusting the antenna so the electrical load matches the transmission line for better power transfer.

What is HAM Radio?

- A hobby and service that allows individuals to communicate using designated radio frequencies for personal, non-commercial purposes.
- HAM radio operators can use equipment like handheld transceivers (walkie-talkies) to communicate.
- Different modes include voice (talking), Morse code (using beeps), and data (sending text over the airwaves).

Yagi Antenna Overview

- ▶ A **Yagi antenna** is a type of directional antenna, which means it focuses the radio signal in a specific direction.
- ▶ It consists of:
 - Driven Element The part that connects to the transmitter/receiver (this part sends or receives the signal).
 - ► **Reflector** A passive element that bounces signals back towards the driven element to strengthen them.
 - Director(s) Elements that help further focus the signal in one direction.
- Yagi antennas are commonly used in amateur radio, TV reception, and Wi-Fi because they are great for long-distance communication.

Bill of Materials

Materials Needed:

- PVC Pipe (3/4" Schedule 40) Minimum 25 inches
- ► Hose Clamps 6 clamps, large enough to fit around the PVC pipe
- ► **PVC Tee** 1 piece (3/4")
- ▶ PVC Crosses 2 pieces (3/4")
- RG-58 Cable 8 feet long, with a connector on one end (e.g., female BNC)
- Wire − 5 inches of wire (e.g., 18 gauge solid copper wire or similar)
- Rosin Core Solder For soldering connections
- ► Tape Measure 1 inch wide
- PVC Glue For securing PVC joints

Tools Needed:

- Soldering Iron For soldering wire connections
- ► **Tape Measure** For measuring lengths accurately
- Pipe Cutters To cut the PVC pipe
- Wire Stripper For stripping insulation off wires
- Shears or Scissors To cut the tape measure
- ► Sandpaper To smooth cut edges of metal parts
- SWR Meter For testing antenna performance
- Screwdriver/Wrench To tighten hose clamps

Step 1: Cutting the Elements

- ► Cut two PVC pieces (17.5" and 7") for the frame.
- Disassemble the tape measure and cut three elements:

► Director: 35 1/8"

▶ Driven Elements: Two 17 3/4"

► Reflector: 41 3/8"

Sand the ends of the elements for safety and soldering.



Step 2: Installing the Elements

- Attach the Director element at the front with hose clamps.
- Install the driven elements and ensure they are spaced 1" apart.
- Secure the Reflector element at the rear of the antenna.

Step 3: Soldering the Wires

- ▶ Tin the ends of the driven elements with solder.
- ➤ Solder the RG-58 cable: Inner wire to one driven element, outer to the other.
- ▶ Use a 5" wire to connect the two driven elements.





Antenna Adjustment

- Use an SWR meter to tune the antenna.
- ▶ Adjust driven elements if SWR reading exceeds 1.2:1.
- Ensure radio is off when adjusting.

Contact Us

- ▶ If you have any questions or want to learn more, feel free to reach out!
- Workshop Team Emails: {elarbi.m, aviedov.v, meaney.ma}[at]northeastern[d0t]edu
- General Workshop Email: workshops[at]nuwireless[d0t]org
- ► Website: https://nuwireless.org/
- Visit us at: Hayden Hall, Room 503

© 2024 Northeastern Wireless Club Design: Muhammad Elarbi, based on LaTeX Beamer

References

- Original design by Joe Leggio, WB2HOL (http: //theleggios.net/wb2hol/projects/rdf/tape_bm.htm)
- Additional designs: KC0TKS (http://www.kc0tks.org) and NT1K (http://nt1k.com)
- ➤ This workshop presentation is based on the project tutorial by jcoman (https://www.instructables.com/ The-Tape-Measure-Antenna/).
- ► All images used in this presentation are sourced from jcoman's tutorial on Instructables.