# **ImageViewer**

Release 1.0.dev0

**Melissa Lajtos** 

# **CONTENTS:**

1	Subn	odules	1			
	1.1	main module	1			
	1.2	fileHandling module	6			
2	Subp	nckages	9			
	2.1	imageviewer.ui package	9			
		2.1.1 mplwidget module	9			
		2.1.2 mainWindow module	13			
		2.1.3 metadataWindow module	13			
		2.1.4 selectBox module	13			
	2.2	imageviewer.tests package	13			
		2.2.1 test module	13			
3	Indices and tables					
Рy	Python Module Index					

### **SUBMODULES**

### 1.1 main module

class imageviewer.main.DataHandler
 Bases: object

Class for storing image data.

active\_data is the attribute the program will usually work with, and is always equal to either magn\_data or phase\_data. The data arrays stored in these variables are always 4-dimensional. The 4 dimensions are:

- 1. Slices
- 2. Dynamics
- 3. x
- 4. y

The original\_data array is either 4- or 5-dimensional, see also add\_data() for more information.

### **Variables**

- original\_data (numpy.ndarray) Contains the original image data from the file (squeezed if there was an unnecessary dimension).
- magn\_data (numpy.ndarray) The magnitude values of the image data.
- phase\_data (numpy.ndarray) The phase values of the image data.
- active\_data (numpy.ndarray) Contains either magnitude or phase data, depending on magnitude.
- active min (float) Minimum value of active data.
- active\_max (float) Maximum value of active data.
- **magnitude** (bool) Indicates whether magnitude or phase of data is currently selected by the user. Defaults to True.
- empty (bool) Indicates whether data is currently loaded. Defaults to True.

add\_data (data, slices=1, dynamics=1)

This function takes the image data from a loaded file, processes it, and stores it in the right attributes.

The number of dimensions gets checked:

• If 2, the data contains only one slice and one dynamic and will be expanded by two dimensions before being stored in order to handle it the same as 4-dimensional data.

- If 3, it is checked if the data contains multiple slices or multiple dynamics by looking at the parameters and will be expanded by one dimension before it is further processed.
- If 4, which is the desired number of dimensions, its magnitude and phase get stored in magn\_data and phase\_data directly.
- If there are 5 dimensions (even after squeezing), the first index of the third dimension is selected by default, so that active\_data holds only 4 dimensions, while original\_data holds all 5 dimensions.

It is important that the dimensions of data follow the order *slices*, *dynamics*, *x*, *y*.

Depending on the value of magnitude, either the magnitude or phase data gets stored in active\_data.

#### **Parameters**

- data (numpy.ndarray) Image data loaded from file.
- **slices** (*int*) Number of slices data contains. Defaults to 1.
- dynamics (int) Number of dynamics data contains. Defaults to 1.

### change\_active\_data(dim3=None)

Responsible for setting active\_data, which is used for plotting.

Changes the value of active\_data to either magn\_data or phase\_data depending on the value of attribute magnitude. Also changes active\_min and active\_max accordingly.

If dim3 is given, magn\_data and phase\_data are changed to absolute and phase values of original\_data [:, :, dim3, :, :] respectively first.

### clear\_data()

Sets all data attributes back to None as they were after initialization.

### rotate data(k)

Rotates data (magn\_data, phase\_data, and active\_data) at axes (-2, -1).

**Parameters k** (*int*) – Specifies how often the data is rotated by 90 degrees in anti-clockwise direction.

### class imageviewer.main.ImageViewer

Bases: PyQt5.QtWidgets.QMainWindow, imageviewer.ui.mainWindow.Ui\_MainWindow

Main class for showing the UI. Runs in the main thread.

Lets user open h5 and dicom files of which image data will be displayed and metadata can be shown.

#### **Variables**

- **filename** (h5py.\_hl.files.File, or list[str]) Either the h5 file the user selected, or a list of the names of the first files of all dicom dataset within a dicom directory.
- **filetype** (str) Indicates which filetype was loaded; either 'h5' or 'dicom'.
- **directory** (str) Whole path of the dicom directory the user selected (including trailing slash '/').
- **dicom\_sets** (list[dict]) One dictionary (with keys *name*, *slices*, *dynamics*) for each dataset within the dicom directory identified by IdentifyDatasetsDicom.
- **dicom\_ref** (str) Filename (incl. path) of reference file of selected dicom set.
- **slice** (*int*) The index of the slice of the image data being displayed.
- **dynamic** (*int*) The index of the dynamic of the image data being displayed.

- dim3 (int) The index of the 3rd dimension of the image data being displayed.
- mean (float) The mean value of the data inside the current selector (roi) of NavigationToolbar.
- **std** (*float*) The standard deviation of the data inside the current selector (roi) of *NavigationToolbar*.
- data\_handler (DataHandler) Image data is being processed and stored here.
- metadata window (MetadataWindow) Window to show metadata of loaded file.
- mplWidget (MplWidget) Widget used to visualize image data.
- **select\_box** (SelectBox) Window which lets user select a dataset within a selected file/directory.

### add\_data (data, slices=1, dynamics=1)

Hands the data over to <code>DataHandler</code> to store it appropriately by calling it's method <code>add\_data()</code>.

Before that, clear() is called.

#### **Parameters**

- data (numpy.ndarray) Image data from file.
- **slices** (*int*) Number of slices data contains. Defaults to 1.
- **dynamics** (*int*) Number of dynamics data contains. Defaults to 1.

#### after\_data\_added()

Takes care of enabling input fields and setting labels, before calling MplWidget.create\_plot().

Gets called after data was loaded from a file and added using add\_data().

### browse\_folder\_dcm()

Opens a file dialog for selecting a dicom folder.

Once a folder is selected, it is stored in directory and filetype is set. If there is more than one file present within this directory (which is usually the case), a new thread, started by IdentifyDatasetsDicom, will identify the datasets. Once it is done, it will call open\_file\_dcm().

If there is only one dicom file present in the directory (very untypically), this file is loaded directly using <code>GetFileContentDicom</code> which will run in a new thread to get the data within the file and call <code>add\_data()</code> and <code>after\_data\_added()</code> when finished. Some attributes are also set directly, so other functions can be used either way.

### browse\_folder\_h5()

Opens a file dialog for selecting an .h5 file.

Once a file is selected, it is stored in filename, filetype is set and open\_file\_h5() gets called.

### change\_cmap()

```
Calls MplWidget.change_cmap().
```

### ${\tt change\_cmax} \ ( \ )$

```
Calls MplWidget.change_cmax().
```

### change\_cmin()

```
Calls MplWidget.change_cmin().
```

### $change\_dim3(d)$

Changes the current index of 5th dimension of data (if not out of range for the current dataset).

Calls DataHandler.change active data() and update plot().

1.1. main module 3

**Parameters** d(int) – The difference between new and old dim3 number.

#### change dynamic(d)

Changes the current dynamic of data (if not out of range for the current dataset).

```
Calls set_dynamic_spinbox() and update_plot().
```

**Parameters** d(int) – The difference between new and old dynamic number.

### change\_magn\_phase()

Handles changing from magnitude to phase display and vice versa.

Is called when user changes the value of the comboBox in the GUI regarding magnitude and phase. Sets attribute magnitude to True when user selected *Magnitude*, sets it to False when user selected *Phase*. Calls <code>DataHandler.change\_active\_data()</code> and <code>update\_plot()</code> afterwards. The colorscale limits and spin boxes get adjusted too.

### $change_slice(d)$

Changes the current slice of data (if not out of range for the current dataset).

```
Calls set_slice_spinbox() and update_plot().
```

**Parameters** d(int) – The difference between new and old slice number.

### close()

Exits the application.

### closeEvent (event)

Calls close ().

**Parameters event** (QCloseEvent:) – PyQt close event.

### dim3\_value\_changed()

Gets called when value inside the dim3 spin box was changed. Calls change\_dim3().

### dynamic\_value\_changed()

Gets called when value inside the dynamic spin box was changed. Calls change\_dynamic().

### keyPressEvent (event)

Handles key press inputs.

**Parameters** event (QKeyEvent) – PyQt key input event.

### mousePressEvent (event)

Sets focus on self.

Parameters event (QMouseEvent) - PyQt mouse input event.

```
open_file_dcm (file_sets)
```

Handles opening of dicom datasets after folder was selected.

Checks if there is more than one dataset within file\_sets. If yes, opens instance of SelectBox which lets user select a dataset; if no, directly loads the data of the only dataset using GetFileContentDicom, which will call add\_data() and after\_data\_added() when finished.

It sets attribute dicom\_sets to file\_sets and attribute filename to a list of dictionaries with the names of the first files, the #slices, and the #dynamics for each fileset.

**Parameters file\_sets** (list[dict]) – A list that contains a dictionary which holds filename, #slices, #dynamics for each fileset.

### open\_file\_h5()

Handles opening/selecting of h5 dataset after file was selected.

Checks if there is more than one dataset within the file (attribute filename) to open. If yes, opens instance of <code>SelectBox</code> which lets user select a dataset and will call <code>read\_data()</code>; if no, creates instance of <code>GetFileContentH5</code> which will run in a new thread to get the data within the file and call <code>add\_data()</code> and <code>after\_data\_added()</code> when finished.

### read\_data()

Handles the reading of a dicom or h5 dataset which was selected.

Depending on attribute filetype, the suiting thread (GetFileContentH5 or GetFileContentDicom) is created to load the data. Methods add\_data() and after\_data\_added() are called.

### reset\_colorscale\_limits()

Sets colorscale limits to actual minimum and maximum of currently selected dataset, DataHandler.active\_min and DataHandler.active\_max.

### reset\_statistics()

Sets statistics (mean and std) values and GUI labels back to default.

### set\_dynamic\_spinbox()

Sets the spin box for current dynamic (spinBox dynamic) to according value.

### set\_patientdata\_labels()

Sets the text values of the labels regarding patient data to metadata of read file, if metadata given.

### set\_slice\_spinbox()

Sets the spin box for current slice (spinBox\_slice) to according value.

### show\_metadata()

Calls MetadataWindow.open().

### slice\_value\_changed()

Gets called when value inside the slice spin box was changed. Calls <code>change\_slice()</code>.

### statistics (startposition, endposition, selector)

Calculates mean and std of data within a ROI.

Calculates mean and std of DataHandler.active\_data within the patch defined by selector and startposition (upper left corner) and endposition (lower right corner). Changes the GUI labels' text values accordingly.

### **Parameters**

- startposition (tuple[numpy.float64]) Coordinates of top left corner.
- endposition (tuple [numpy.float 64]) Coordinates of bottom right corner.
- **selector** (*str*) Type of selector (*rectangle* or *ellipse*).

### update\_plot()

Calls MplWidget.update\_plot().

### wheelEvent (event)

Enables going through the data slices and dynamics using the mouse wheel.

A 120° turn in the y direction is turned into a slice difference of 1 and <code>change\_slice()</code> is called. A 120° turn in the x direction is turned into a dynamic difference of -1 and <code>change\_dynamic()</code> is called.

**Parameters event** (QWheelEvent) – The wheel event which contains parameters that describe a wheel event.

### class imageviewer.main.MetadataWindow

```
Bases: PyQt5.QtWidgets.QMainWindow, imageviewer.ui.metadataWindow.Ui\_MainWindow
```

1.1. main module 5

Window for showing metadata of loaded files.

#### **Variables**

- **treeWidget** (QTreeWidget) Widget which is used to list all metadata instances. Its 4 columns are Tag, Name, VR, Value.
- lineEdit (QLineEdit) Input field used for searching metadata by name.

#### cancel()

Clears attribute treeWidget and closes the window.

#### filter()

Hides all items in attribute treeWidget whose names do not include the current text in attribute lineEdit.

### open (file, filetype)

Populates attribute treeWidget with the metadata of the given file and opens the window.

### **Parameters**

- **file** (str, or h5py.\_hl.dataset.DataSet) Full filename including path of the dicom file, or h5 dataset.
- **filetype** (str) Indicates type of file; either 'h5' or 'dicom'.

### class imageviewer.main.SelectBox

Bases: PyQt5.QtWidgets.QMainWindow, imageviewer.ui.selectBox.Ui\_MainWindow

Window for selecting the desired dataset within an h5 file or dicom folder.

#### **Variables**

- **treeWidget** (QTreeWidget) Widget used to list all datasets to choose from. Has 4 columns: Dataset name, slices, dynamics, size.
- **selected** (*str*) Name of the dataset selected in the UI window.

#### cancel()

Closes the window.

Clears attribute treeWidget and sets attribute selected to None.

### confirm()

Stores the scan name and scan ID of the selected dataset in attribute selected and closes the window.

# 1.2 fileHandling module

```
class imageviewer.fileHandling.GetFileContent(selected)
    Bases: PyQt5.QtCore.QRunnable
```

This class serves as a parent class for other classes which will handle loading data from different file types. It inherits from QRunnable, thus it will be called in a separate thread.

**Parameters** selected (str) – The name of the selected dataset data shall be loaded from.

```
class imageviewer.fileHandling.GetFileContentDicom (file_sets, selected, directory)
          Bases: imageviewer.fileHandling.GetFileContent
```

Class for loading dicom image data. Inherits from GetFileContent.

#### **Parameters**

• file\_sets (list[dict]) - Filesets identified by IdentifyDatasetsDicom.

- **selected** (str) The scan name and ID of the selected dataset within the directory.
- **directory** (*str*) The directory containing dicom files to read.

### run()

Responsible for loading image data of a dicom dataset.

Loads the image data of a selected dataset into an array. The data array and the numbers of slices and dynamics are emitted with the signals.add\_data signal. The signal signal. finished is emitted afterwards.

To load the slices and dynamics correctly, it is important that the filenames are named in a way that the slices number comes before the dynamics number.

Gets called when the thread is started.

### class imageviewer.fileHandling.GetFileContentH5(filename, selected)

Bases: imageviewer.fileHandling.GetFileContent

Class for loading h5 image data. Inherits from GetFileContent.

### **Parameters**

- **filename** (h5py.\_hl.files.File) The selected .h5 file.
- **selected** (*str*) The name of the selected dataset within the file. If the file only contains one dataset, this needs to be the same as parameter filename.

#### run()

Responsible for loading image data of .h5 file.

Loads the image data of a selected dataset into an array. Determines the number of slices and the number of dynamics by simply looking at the number of dimensions and the shape of the data under the following assumptions:

- 1. If the data has 3 dimensions, there are multiple slices, represented by the first dimension, and only one dynamic.
- 2. If the data has more than 3 dimensions, the first dimension represents slices, the second dimension represents dynamics.

The data array and the numbers of slices and dynamics are emitted with the signals.add\_data signal. The signal signals.finished is emitted afterwards.

Gets called when the thread is started.

### ${\bf class} \ {\tt imageviewer.fileHandling.GetFileContentSignals}$

```
Bases: PyQt5.QtCore.QObject
```

Class for generating thread signals for GetFileContent.

### add\_data

Signal to emit with loaded data (array), number of slices (int), number of dynamics (int).

#### finished

Signal to emit when all is finished.

### class imageviewer.fileHandling.IdentifyDatasetsDicom(filenames)

Bases: PyQt5.QtCore.QRunnable

Class for identifying files belonging together (forming a dataset) within a bunch of dicom files.

Inherits from QRunnable, thus it will be called in a separate thread.

Signals are from the IdentifyDatasetsDicomSignals class.

**Parameters filenames** (list[str]) – The names of all dicom files.

**Variables filesets** (list[dict]) – Dictionaries for all identified filesets, which hold filename, #slices, #dynamics.

run()

This function identifies the filesets formed by the files in parameter filenames.

The filename of the first file, the number of slices, and the number of dynamics are stored inside a dictionary for each fileset. All these dicts are stored in the list attribute file\_sets, which is then passed on when the signals.setsIdentified signal is emitted.

The following naming conventions for files are important for this function to work (assuming the file ending '.dcm' is included):

- 1. The first to -25th characters, which usually contain the scan name and the scan ID, are identical for each file belonging to the same set, and are unique among different sets.
- 2. Characters -20 to -17 contain the slice number.
- 3. Characters -8 to -5 contain the dynamic number.

Gets called when the thread is started.

class imageviewer.fileHandling.IdentifyDatasetsDicomSignals
 Bases: PyQt5.QtCore.QObject

Class for generating thread signals for the IdentifyDatasetsDicom class.

#### setsIdentified

Signal to emit with filesets (list[dict]).

**CHAPTER** 

**TWO** 

### **SUBPACKAGES**

# 2.1 imageviewer.ui package

The modules *mainWindow module*, *metadataWindow module*, and *selectBox module* have been created automatically from their .ui equivalents, which were created using the QTDesigner, and are therefore not documented properly. To convert a .ui to a .py file, simply run:

```
pyuic5 <filename>.ui -o <filename>.py
```

in the command line.

### 2.1.1 mplwidget module

class imageviewer.ui.mplwidget.MplWidget(parent=None)
 Bases: PyQt5.QtWidgets.QWidget

Widget used to visualize image data.

A widget which holds a matplotlib canvas and a toolbar (NavigationToolbar) as attributes. Colormap and color limits can be changed, the plot can be zoomed and panned. Most of the actions however can be found in the toolbar.

### Variables

- canvas (matplotlib.backends.backend\_qt5agg.FigureCanvasQTAgg) The actual matplotlib figure canvas where data and colormap are plotted.
- toolbar (NavigationToolbar) Toolbar with actions.
- **empty** (bool) Indicates if canvas is empty.
- **cmap** (str) Name of the colormap (matplotlib) used to plot the data. Defaults to 'plasma'.
- im (matplotlib.image.AxesImage) The image which gets displayed.
- **color\_min** (float) Minimum limit for color scale for the currently loaded data.
- color\_max (float) Maximum limit for color scale for the currently loaded data.
- imageViewer (ImageViewer) Instance of the main window the widget is part of. Allows access to data and variables. It is set in ImageViewer's \_\_init\_\_().

### canvasMouseMoveEvent (event)

Used to overwrite the default FigureCanvasQT.mouseMoveEvent () method of attribute canvas.

Does what original method does and then calls own mouseMoveEvent () method.

Parameters event (QMouseEvent) - Instance of a PyQt input event.

#### canvasMousePressEvent (event)

Used to overwrite the default FigureCanvasQT.mousePressEvent() method of attribute canvas.

Does what original method does and then calls own mousePressEvent () method.

**Parameters** event (QMouseEvent) – Instance of a PyQt input event.

### change\_cmap (cmap)

Handles changing the colormap.

Sets attribute cmap to parameter cmap, changes colormap of the actual image and calls  $update\_plot()$ .

Is called when user changes the colormap in the main window (ImageViewer).

**Parameters** cmap (str) – Name of new colormap.

#### change\_cmax (cmax)

Handles changing the maximum color limit of the plot.

Changes attribute color\_max to parameter cmax and updates the image shown, given that minimum would not be higher than maximum. In the other case attributes cmin and cmax would be set to the same value.

**Parameters** cmax (float) – New colormap maximum value.

### change cmin(cmin)

Handles changing the minimum color limit of the plot.

Changes attribute <code>color\_min</code> to parameter <code>cmin</code> and updates the image shown, given that minimum would not be higher than maximum. In the other case attributes <code>cmin</code> and <code>cmax</code> would be set to the same value.

**Parameters** cmin (float) – New colormap minimum value.

#### clear()

Resets attributes to initial values and clears the canvas.

#### create\_plot()

Used to create a plot on attribute canvas and set attributes for a dataset.

Clears canvas.axes and draws a new image on it. A matching colorbar is created on canvas.axesc. It is intended to use this method when a new dataset or file is loaded.

canvas.axes.format\_coord() gets overwritten, so that data coordinates are shown in integer numbers. The selection mode (*rectselect* or *ellipseselect*) is also taken care of here (in case the button is pressed or there was a selector present used on the old image).

See also: update\_plot().

### mouseMoveEvent (event)

Handles mouse moving while middle button (wheel) is being pressed.

Adjusts color range limits if movement direction is mainly vertical (upwards narrows the range, downwards widens it). Mainly horizontal movement moves the whole window of the color range (right movement sets it higher, left movement lower). <code>change\_cmin()</code> and <code>change\_cmax()</code> are triggered.

Parameters event (QMouseEvent) - Instance of a PyQt input event.

### mousePressEvent (event)

Handles events caused by pressing mouse buttons.

Sets focus on main window (*ImageViewer*) if left mouse button was pressed.

Saves current cursor position when middle button (wheel) was pressed.

Parameters event (QMouseEvent) - Instance of a PyQt input event.

```
pan_plot (direction)
```

Allows panning plot in 4 main directions.

The distance (in pixels) by which the plot is panned depends on the current x and y limits of the plot, so that the plot is panned less after zooming in, and more after zooming out. Calls update\_plot().

**Parameters direction** (str) – Indicates direction to move plot to. Valid values are 'left', 'right', 'up', and 'down'.

### update\_plot()

Changes image data to currently active data and updates the plot and the colorbar.

The toolbar functions and settings remain as they are. It is intended to use this method when another image of the same dataset needs to be visualized (e.g. after colormap was changed or another slice was selected).

```
See also: create_plot().
```

### zoom\_plot (direction)

Zooms in or out of the plot.

```
Calls update plot().
```

**Parameters direction** (str) – Indicates whether to zoom in or out. Valid values are 'in' and 'out'.

Custom matplotlib navigation toolbar used by MplWidget.

Enables matplotlib's default functionalities *home*, *pan*, *zoom*, *savefigure*, and adds new functionalities, which are selecting a region of interest (ROI), and rotating the plot by 90 degrees.

The class variable <code>toolitems</code> is overwritten so that some of matplotlibs default buttons and functionalities are removed. The method <code>\_update\_buttons\_checked()</code> overwrites the parent method to include the self made <code>rectselect</code> and <code>ellipseselect</code> actions.

**Variables** *toolitems* (tuple[tuple[str]]) - List of toolitems to add to the toolbar, format of one toolitem is:

```
text, # the text of the button (often not visible to users)
tooltip_text, # the tooltip shown on hover (where possible)
image_file, # name of the image for the button (without the extension)
name_of_method, # name of the method in NavigationToolbar2 to call
)
```

### \_update\_buttons\_checked()

Syncs button checkstates to match active mode. Overwrites parent function to include *rectselect* and *ellipseselect* modes.

### activate\_ellipse\_select()

Activates or deactivates *ellipseselect* mode. If needed, deactivates *pan* or *zoom*. Gets called when *ellipseselect* action is toggled.

### activate\_rect\_select()

Activates or deactivates *rectselect* mode. If needed, deactivates *pan* or *zoom*. Gets called when *rectselect* action is toggled.

### create ellipse selector()

Enables ellipse selection by creating an instance of matplotlib.widgets.EllipseSelector.

### create\_icon(name)

Creates a responsive icon with the style of default icons to be placed in the toolbar.

**Parameters name** (str) – Name (including relative path) of image file to be used.

**Returns** Icon for the toolbar.

Return type PyQt5.QtGui.QIcon

### create\_rectangle\_selector()

Enables rectangular selection by creating an instance of matplotlib.widgets. RectangleSelector.

### deactivate\_ellipse\_selector()

Deactivates *ellipseselect* mode and button/action. Gets called when *pan* or *zoom* action is toggled.

### deactivate\_hide\_ellipse\_selector()

Calls deactivate\_ellipse\_selector() and hides the selector (in the GUI). Gets called when rectselect action is toggled.

### deactivate hide rect selector()

Calls deactivate\_rect\_selector() and hides the selector (in the GUI). Gets called when ellipseselect action is toggled.

#### deactivate\_rect\_selector()

Deactivates rectselect mode and button/action. Gets called when pan or zoom action is toggled.

#### home()

Sets plot back to original view by calling MplWidget.create\_plot().

All pan, zoom, selection, and colorscale limits settings are discarded, rotation not. Also calls reset\_statistics() and reset\_colorscale\_limits().

Overwrites parent function.

### on\_ellipse\_select (eclick, erelease)

Gets called when the user completes an ellipse selection and emits a signal with the start and endpoints of the ellipse.

### **Parameters**

- eclick (matplotlib.backend\_bases.MouseEvent) Matplotlib mouse click event, holds x and y coordinates.
- erelease (matplotlib.backend\_bases.MouseEvent) Matplotlib mouse release event, holds x and y coordinates.

### on\_rect\_select (eclick, erelease)

Gets called when the user completes a rectangular selection and emits a signal with the start and endpoints of the rectangle.

### **Parameters**

- **eclick** (matplotlib.backend\_bases.MouseEvent) Matplotlib mouse click event, holds x and y coordinates.
- **erelease** (matplotlib.backend\_bases.MouseEvent) **Matplotlib** mouse release event, holds x and y coordinates.

```
rotate_anticlockwise()
    Rotates plot anti-clockwise once by calling DataHandler.rotate_data() and MplWidget.
    update_plot().

rotate_clockwise()
    Rotates plot clockwise once by calling DataHandler.rotate_data() and MplWidget.
    update_plot().

toolitems = (('Home', 'Reset original view', 'home', 'home'), (None, None, None, None)
    Overwritten parent attribute.

class imageviewer.ui.mplwidget.NavigationToolbarSignals
    Bases: PyQt5.QtCore.QObject
    Class for generating thread signals for the NavigationToolbar class.

roiSelection
    Signal to emit with startposition (tuple), endposition (tuple), selector (str) after ROI was drawn.
```

### 2.1.2 mainWindow module

```
class imageviewer.ui.mainWindow.Ui_MainWindow
    Bases: object
    retranslateUi(MainWindow)
    setupUi(MainWindow)
```

### 2.1.3 metadataWindow module

```
class imageviewer.ui.metadataWindow.Ui_MainWindow
    Bases: object
    retranslateUi (MainWindow)
    setupUi (MainWindow)
```

### 2.1.4 selectBox module

```
class imageviewer.ui.selectBox.Ui_MainWindow
    Bases: object
    retranslateUi (MainWindow)
    setupUi (MainWindow)
```

# 2.2 imageviewer.tests package

### 2.2.1 test module

```
class imageviewer.tests.test.TestDataHandling(methodName='runTest')
    Bases: unittest.case.TestCase
    Tests DataHandler.
```

Create an instance of the class that will use the named test method when executed. Raises a ValueError if the instance does not have a method with the specified name.

### setUp()

Sets up the testing environment.

### test\_add\_data\_2dim()

Tests imageviewer.main.DataHandler.add\_data() with 2-dimensional (one slice, one dynamic) data. Magnitude is wanted.

### test\_add\_data\_3dim()

Tests add\_data() with 3-dimensional (multiple slices, one dynamic) data. Phase is wanted.

```
class imageviewer.tests.test.TestFileLoad(methodName='runTest')
```

Bases: unittest.case.TestCase

Tests file and data loading functionality of class ImageViewer and module fileHandling.

Create an instance of the class that will use the named test method when executed. Raises a ValueError if the instance does not have a method with the specified name.

#### setUp()

Sets up the testing environment.

### test\_identify\_datasets\_dicom()

Tests run().

### test\_open\_dicom()

Tests open\_file\_dcm() in the case of a single dicom fileset containing multiple files.

Since the method being tested also calls <code>add\_data()</code> and <code>after\_data\_added()</code>, these methods are also being tested along the way. Normally, the function would start the thread of <code>GetFileContentDicom</code>, so the <code>run()</code> method of it is called manually and tested.

### test\_open\_h5()

Tests open\_file\_h5() in the case of an .h5 file containing 3 sets, where the one selected has one slice.

Since the method being tested also calls read\_data(), add\_data(), and after\_data\_added(), these methods are also being tested along the way.

```
class imageviewer.tests.test.TestImageViewer (methodName='runTest')
```

Bases: unittest.case.TestCase

Class for testing basic settings and behaviour of the *ImageViewer* class.

Create an instance of the class that will use the named test method when executed. Raises a ValueError if the instance does not have a method with the specified name.

#### setUp()

Sets up the testing environment.

### test\_colormap\_change()

Test setting different colormap by triggering action in menuColormap. Only one action should be checked at a time.

#### test defaults()

Test default values that should be set when creating an instance of ImageViewer.

### test\_statistics\_ellipse()

Tests statistics () in the case of an ellipse selector.

### test\_statistics\_rectangle()

Tests statistics () in the case of a rectangle selector.

```
\textbf{class} \text{ imageviewer.tests.test.} \textbf{TestMetadataWindow} \ (\textit{methodName='runTest'}) \\ \textbf{Bases: unittest.case.TestCase}
```

Tests MetadataWindow.

Create an instance of the class that will use the named test method when executed. Raises a ValueError if the instance does not have a method with the specified name.

### setUp()

Sets up the testing environment.

### test\_open()

Tests open ().

## **CHAPTER**

# **THREE**

# **INDICES AND TABLES**

- genindex
- modindex
- search

# **PYTHON MODULE INDEX**

```
imageviewer.fileHandling,6
imageviewer.main,1
imageviewer.tests.test,13
imageviewer.ui.mainWindow,13
imageviewer.ui.metadataWindow,13
imageviewer.ui.mplwidget,9
imageviewer.ui.selectBox,13
```