## Queensland University of Technology

## **EGB242**

Signal Analysis

Profressor Wageeh Boles

Dinal Atapattu

November 3, 2023

# Contents

1	Sign	nal Sampling and Quantisation	2
	1.1	Continuous and Discrete Time Representations	2
	1.2	The Impulse Function	2
	1.3	Sifting Property of the Impulse	2
	1.4	Analogue to Digital Conversion	2
	1.5	Sampling Theory	3
	1.6	From Pulse Train to Impulse Train	3
	1.7	Sampling Process	3
	1.8	Anti-Aliasing	4
	1.9	Anti-Aliasing Spectrum	4
	1.10	Discrete to Digital	4
		1.10.1 Uniform Quantiser	5
		1.10.2 Quantisation Error	6
		1.10.3 Signal to Quantisation Noise Ratio	6
		1.10.4 Quantisation Noise Power	6
		1.10.5 Noise Power as a Function of n	6
		1.10.6 Limitations	6
		1.10.7 Non-Uniform Quantisers	6
	1.11	Encoding	7
		1.11.1 Waveform Encoding	7
<b>2</b>	Line	ear Time Invariant Systems	8
	2.1	Transfer Functions	8
	2.2	Transfer Functions from Block Diagrams	8
	2.3	Filters	9
		2.3.1 Ideal Filters	9
		2.3.2 Practical Filters	9
	_		
3	_	lace Transform	10
	3.1	Relationship with the Fourier Transform	10
	3.2	Region of Convergence (ROC)	10
	3.3	Circuit Analysis	10
	3.4	Partial Fraction Expansion	10
4	Creat	tem Characterisation	12
4	·	Second Order Systems	12
	4.1	· ·	
	4.2	Natural Response By Inspection	12
	4.3	Poles of general 2nd order systems	13
	4.4	Step Response of Underdamped 2nd Order Systems	13
5	Don	ninant Poles	14
6	Tut	orial Questions	15
•	6.1		15

# Signal Sampling and Quantisation

### 1.1 Continuous and Discrete Time Representations

- An analogue signal is continuous in time and amplitude
- A discrete-time signal is discrete in time but continuous in amplitude/value
- A digital signal is discrete in time and amplitude

### 1.2 The Impulse Function

The Dirac Delta function  $\delta(t)$ , is intuitively

- The limit of a pulse of fixed area as its width tends to zero
- Area is equal to one
- Also called the impulse function




Figure 1.1: Impulse Function

## 1.3 Sifting Property of the Impulse

$$\int_{-\infty}^{\infty} f(t)\delta(t-t_0)dt = f(t_0)$$
 (f(t) is continuous)

 $t \neq 0$ 

This follows as the impulse function is zero everywhere except at  $t = t_0$ . So if  $t_0 = T_s$  where  $T_s$  is the sampling interval, then:

$$\int_{-\infty}^{+\infty} f(t)\delta(t - nT_s)dt = f(nT_s)$$

Produces the signals at the following intervals/samples  $f(0), f(T_s), f(2T_s), f(3T_s), \dots f(nT_s)$ 

## 1.4 Analogue to Digital Conversion

Consists of 2 steps

• Sampling

Page 3 of 15


• Quantisation



Figure 1.2: Analogue to Digital Conversion

### 1.5 Sampling Theory

A continuous signal with a maximum frequency of  $f_m$  can be recovered back grom its samples if the sampling frequency  $f_s$  is greater than twice the maximum frequency of the continuous signal.






Figure 1.3: Continuous Signal

Figure 1.4: Sampling

### 1.6 From Pulse Train to Impulse Train

When evaluating the Fourier series of a pulse train with height A, width  $\tau$  (area  $A\tau$ ), and period  $T_s$ 

$$c_n = \frac{A\tau}{T_s} \frac{\sin(\pi n f_s \tau)}{\pi n f_s \tau}$$

Taking the limit of  $\tau \to 0$ :

$$\lim_{\tau \to 0} \frac{\sin(\pi n f_s \tau)}{\pi n f_s \tau} = \frac{1}{T_s} \lim_{\tau \to 0} \frac{\sin(\pi n f_s \tau)}{\pi n f_s \tau} = \frac{1}{T_s}$$


$$\delta(t)_{train} = \sum_{n=-\infty}^{\infty} \frac{1}{T_s} e^{j2\pi n f_s t}$$

$$= \frac{1}{T_s} + \sum_{\substack{n=-\infty\\n\neq 0}}^{\infty} \frac{2}{T_s} \cos(2\pi n f_s t)$$

## 1.7 Sampling Process

Sampling of a discrete signal can be obtained by multiplying the signal by an impulse train  $\delta(t)$  of period  $T_s$ . The output of the multiplier is a discrete signal called the sample signal

The spectra of the input and sampled signals are represented as



Dinal Atapattu

### 1.8 Anti-Aliasing

Hardware constraints may not allow sampling at the Nyquist frequency.

By using an anti-aliasing (low-pass) filter before the sampling stage, we can eliminate spectral overlap.

This lowpass filter must have a bandwidth at or below  $\frac{f_s}{2}$ 

Example: If an analog signal has a bandwidth of 2 kHz and must be sampled at 3 kHz, then the anti-aliasing filter must have a bandwidth of 1 kHz or less.





Figure 1.6: Anti-Aliasing Spectra

## 1.9 Anti-Aliasing Spectrum



Reconstruction is still accomplished by low pass filtering.




Figure 1.7: Anti-Aliasing Spectrum

## 1.10 Discrete to Digital

Digital signals are discrete in time AND amplitude. The quantizer transforms each sampled value to take one of L distinct levels.




Figure 1.8: Quantiser

These leves are allocated over the entire dynamic range of the analog signal.

$$x_{\min} \le x(t) \le x_{\max}$$

This is lossy and non-invertible.

Dinal Atapattu Page 4 of 15

### 1.10.1 Uniform Quantiser

Levels are **uniformly** allocated across the dynamic range The step size  $\Delta$  between quantization levels is given by

$$\Delta = \frac{x_{\text{max}} - x_{\text{min}}}{L}$$

Many applications have  $x_{\text{max}} = -x_{\text{min}}$ . Which gives

$$\Delta = \frac{2x_{\text{max}}}{L}$$

The number of levels is often chosen to be a power of two to better use binary words

$$L=2^n$$

Where n is the number of bits used to encode L levels.

#### Example

A signal with a dynamic range between  $\pm 4V$  is to be uniformly quantizzed with each level encoded by 4 bits. What is the step size between bits.


- n=4 bits
- $L = 2^n = 2^4 = 16$  levels

$$\Delta = \frac{2x_{\text{max}}}{L} = \frac{2(4)}{16} = 0.5V$$

- 4 bits allow for encoding 16 unique code words
- Each code word represents a single quantization level


#### Uniform Quantizer Types

- Mid-tread quantizer



- Enforces a quantisation step at zero
- -L is odd if  $x_{\min} = -x_{\max}$
- May waste one level

Mid-rise quantizer



- -L levels are evenly distributed about 0
- Can't guarantee 0
- Uses all levels when  $x_{\min} = -x_{\max}$

Dinal Atapattu

#### 1.10.2 Quantisation Error

Quantisation error is the difference between the quantised signal and the sampled signal

$$e_q(n) = x(n) - \hat{x}(n)$$

This is a function of n, where n is the sample number.

### 1.10.3 Signal to Quantisation Noise Ratio

SQNR represents the amount of distortion due to quantisation defined as the ratio of signal power to the quantisation noise power

 $\label{eq:sqnr} {\rm SQNR} = \frac{{\rm Signal~Power}}{{\rm Quantisation~Noise~Power}}$ 

The difference between the sampled signal and quantised signal is the quantisation error.

### 1.10.4 Quantisation Noise Power

Quantisation noise power is the variance of the quantisation error Can be treated as a uniformly distruibuted random variable between  $\frac{\Delta}{2}$  and  $\frac{\Delta}{2}$ 

$$P_{\text{noise}} = \int_{-\infty}^{\infty} e^2 f(e) de = \frac{\Delta}{12}$$
 (1.1)

#### 1.10.5 Noise Power as a Function of n

Expressing the noise power as a function of n gives

$$P_{\text{noise}} = \frac{\Delta^2}{12} = \frac{1}{12} \times \left(\frac{x_{\text{max}} - x_{\text{min}}}{L}\right)^2$$
$$= \frac{x_{\text{max}}^2 - x_{\text{min}}^2}{12n^2}$$
(1.2)

Increasing the number of quantisation levels improves SQNR. The number of representation levels is determined by the number of bits used to encode the sample  $L = 2^n$ . PCM for example encodes each sample with equal length binary words.

#### 1.10.6 Limitations

While qunatisation noise power is equal across the input signal range, the input signal's power changes across decision levels. Resulting in differing SQNR across the input signal range.

For example with human speech, louder sounds carry higher signal power than softer sounds.

Uniform quantisation would result in different SQNR for different sounds.

### 1.10.7 Non-Uniform Quantisers

A constant SQNR can be achieved using a non uniform quantiser. These have different step sizes over their dynamic range, allocating more levels to the range of signals with smaller power.




Figure 1.9:  $\mu$  Law Non-Uniform Quantiser Transfer Function

Dinal Atapattu Page 6 of 15

### 1.11 Encoding

### 1.11.1 Waveform Encoding

Encodes each quantized sample as a string of bits

- Pulse Code Modulation (PCM)
- Differential Pulse Code Modulation (DPCM)
- Shannon-Fano Encoding
- Huffman Encoding

#### Pulse Code Modulation

Each sample is an equal length code binary word with length n bits, allowing for  $2^n$  encoding levels and is the standard for analogue to digital (A/D) conversion.

Dinal Atapattu Page 7 of 15

# Linear Time Invariant Systems

### 2.1 Transfer Functions

- Time domain output  $\longrightarrow$  convolution of time domain input with impulse response of the system y(t) = x(t) \* h(t)
- ullet Spectrum of the output  $\longrightarrow$  product of the Fourier transform of the input with the Fourier transform of the impulse response


$$Y(f) = X(f)H(f)$$

ullet Fourier Transform of the impulse response  $\longrightarrow$  Transfer Function

$$H(f) = \frac{Y(f)}{X(f)}$$

Provides the system's gain and phase change information

### 2.2 Transfer Functions from Block Diagrams



From the block diagram we can see that:

$$Z_1(f) = X(f) - Z_2(f) \tag{1}$$

$$Z_2(f) = kY(f) \tag{2}$$

Substituting (2) into (1) gives:

$$Z_1(f) = X(f) - kY(f)$$

Note that:

$$Y(f) = G(f)X(f) \tag{3}$$

Substituting this into the above equation gives:

$$Y(f) = G(f)(X(f) - kY(f))$$
  
=  $G(f)X(f) - kG(f)Y(f)$  (4)

Therefore:

$$Y(f) + kG(f)Y(f) = G(f)X(f)$$

$$Y(f) (1 + kG(f)) = G(f)X(f)$$

$$\frac{Y(f)}{X(f)} = \frac{G(f)}{1 + kG(f)}$$
(5)

### 2.3 Filters

Attenuate certain ranges of frequencies in a signal In the following forms

• Lowpass

Only allows low frequencies to pass

• Highpass

Only allows high frequencies to pass

Bandpass

Only allows a band of frequencies to pass

• Bandstop

Only blocks a band of frequencies

Note that:

- Pass band is the range of frequencies that are allowed to pass
- Stop band is the range of frequencies that are blocked

### 2.3.1 Ideal Filters

They are unrealisable (cannot exist in the real world) and have the following characteristics

- Completely attenuate signals in their stop bands
- Completely pass signals in their pass bands
- Immediately transition between pass and stop bands
- Have no effect on phase

#### 2.3.2 Practical Filters




Figure 2.1: Ideal Filter

Dinal Atapattu Page 9 of 15

# Laplace Transform

### 3.1 Relationship with the Fourier Transform

$$G(s) = \int_{-\infty}^{\infty} g(t)e^{-(\sigma+j\omega t)}dt$$
$$= \int_{-\infty}^{\infty} g(t)e^{-\sigma t}e^{-j\omega t}dt$$

Where  $\sigma$  is the real part of s and  $\omega$  is the imaginary part of s

for  $\sigma = 0$ 

$$G(j\omega) = \int_{-\infty}^{\infty} g(t)e^{-j\omega t}dt$$

$$G(j\omega) = \int_{-\infty}^{\infty} g(t)e^{-j2\pi nft}dt = G(f)$$

## 3.2 Region of Convergence (ROC)

The Laplace Transform exists for all complex numbers if  $a < Re\{s\} < b$  where a and b are real numbers. The set of values of s for which the Laplace Transform converges is called the Region of Convergence (ROC).

## 3.3 Circuit Analysis

Element	Time Domain	Laplace Domain
Resistor	R	R
Capacitor	$\frac{1}{C}\int i(t)dt$	$\frac{1}{Cs}$
Inductor	$L\frac{di(t)}{dt}$	Ls

Figure 3.1: Circuit Analysis

Done in the following steps

- 1. Convert circuit components, voltages, and currents to Laplace domain
- 2. Obtain the transfer function in the Laplace domain using mesh, nodal or any other circuit analysis technique (may need to be simplified using Partial Fraction Expansion)
- 3. Convert the transfer function back to the time domain using the inverse Laplace Transform

## 3.4 Partial Fraction Expansion

1. Factorise the denominator of the transfer function

- 2. Write the transfer function as a sum of fractions with the factors of the denominator as the denominators of the fractions
- 3. Write the numerator of the transfer function as the numerator of the fractions
- 4. Solve for the unknown coefficients
- 5. Convert the fractions back to the time domain using the inverse Laplace Transform

Example:

$$H(s) = \frac{1}{s^2 + 2s + 1}$$

$$= \frac{1}{(s+1)^2}$$

$$= \frac{A}{s+1} + \frac{B}{(s+1)^2}$$

$$= \frac{A(s+1) + B}{(s+1)^2}$$

$$= \frac{As + A + B}{(s+1)^2}$$

Comparing coefficients gives:

$$A = 1$$

$$A + B = 0$$

$$B = -1$$

Therefore:

$$\begin{split} H(s) &= \frac{1}{s+1} - \frac{1}{(s+1)^2} \\ &= \frac{1}{s+1} - \frac{1}{s+1} + \frac{1}{(s+1)^2} \\ &= \frac{1}{s+1} - \frac{1}{(s+1)^2} \\ &= e^{-t} - te^{-t} \end{split}$$

Dinal Atapattu

# System Characterisation

## 4.1 Second Order Systems

Systems in the form of

$$\frac{Y(s)}{X(s)} = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

System Type	Nature of Roots	Condition	Roots	System Figure
Overdamped	Two Real Roots	$0 < \zeta < 1$	$s_1 = -\zeta \omega_n + \omega_n \sqrt{\zeta^2 - 1}$	$x(t) \longrightarrow t$
Critically Damped	One Real Root	$\zeta = 1$	$s_1 = -\zeta \omega_n$	$x(t) \longrightarrow t$
Underdamped	Two Complex Roots	$\zeta = 1$ $\zeta > 1$	$s_1 = -\zeta \omega_n \pm j \omega_n \sqrt{\zeta^2 - 1}$	$x(t) \longrightarrow t$
Undamped	Tura Imaginawy Pasta			$x(t) \longrightarrow t$
Undamped	Two Imaginary Roots	$\zeta = 0$	$s_1 = \pm j\omega_n$	

Figure 4.1: Second Order Systems

- $\omega_n$  is the natural frequency
- $\zeta$  is the damping ratio

## 4.2 Natural Response By Inspection

• Overdamped, poles at  $-\sigma_1, -\sigma_2$ 

$$y(t) = A_1 e^{-\sigma_1 t} + A_2 e^{-\sigma_2 t}$$

• Underdamped, poles at  $-\sigma \pm j\omega_d$ 

$$y(t) = Ae^{-\sigma t}\cos(\omega_d t + \phi)$$

• Undamped, poles at  $\pm j\omega_n$ 

$$y(t) = A\cos(\omega_n t + \phi)$$

• Critically damped, poles at  $-\sigma$ 

$$y(t) = (A_1 + A_2 t)e^{-\sigma t}$$

### 4.3 Poles of general 2nd order systems

$$G(s) = \frac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2} \tag{4.1}$$

The roots of the denominator polynomial are the poles of the system

$$s^2 + 2\zeta\omega_n s + \omega_n^2 = 0 \tag{4.2}$$

$$s_{1,2} = -\zeta \omega_n \pm \omega_n \sqrt{\zeta^2 - 1} \tag{4.3}$$

## 4.4 Step Response of Underdamped 2nd Order Systems

Specifications are

• Settling Time

$$t_s = \frac{4}{\zeta \omega_n}$$

• % Overshoot

$$\%OS = e^{\frac{-\zeta\pi}{\sqrt{1-\zeta^2}}} \times 100$$

• Peak Time

$$T_p = \frac{\pi}{\omega_n \sqrt{1 - \zeta^2}}$$


Dinal Atapattu Page 13 of 15


# **Dominant Poles**

# **Tutorial Questions**

### **6.1** Tutorial 13

### Question 1





Express  $s_1(t)$  and  $s_2(t)$  as complex Fourier series.

$$s_1(t) = \begin{cases} 1 & -\frac{1}{2} \le t < 0 \\ -1 & 0 \le t < \frac{1}{2} \end{cases}$$

Note that T = 1 and  $f_0 = \frac{1}{T} = 1$ 

$$c_0 = \int_0^\infty -\infty s_1(t)dt$$

$$= \int_0^0 -0.51dt + \int_0^{0.5} 0 - 1dt$$

$$= [t]^0 -0.5 + [-t]^{0.5} 0$$

$$= 0.5 - 0.5 = 0$$

$$c_{n} = \frac{1}{T} \int_{-\infty}^{\infty} -\infty s_{1}(t) e^{-j2n\pi f_{0}t} dt$$

$$= \frac{1}{1} \int_{-0.5}^{0} -0.5 e^{-j2n\pi t} dt + \frac{1}{1} \int_{-0.5}^{0.5} 0 - e^{-j2n\pi t} dt$$

$$= \int_{-0.5}^{0} -0.5 e^{-j2n\pi t} dt + \int_{-0.5}^{0} 0.5 e^{-j2n\pi t} dt$$

$$= \left[ \frac{e^{-j2n\pi t}}{-j2n\pi} \right]_{-0.5}^{0} -0.5 + \left[ \frac{e^{-j2n\pi t}}{-j2n\pi} \right]_{-0.5}^{0.5} 0$$

$$= \frac{e^{-j2n\pi \times 0.5}}{-j2n\pi} - \frac{e^{-j2n\pi \times 0}}{-j2n\pi} + \frac{e^{-j2n\pi \times 0.5}}{-j2n\pi} - \frac{e^{-j2n\pi \times 0}}{-j2n\pi}$$

$$= \frac{e^{-jn\pi}}{-j2n\pi} - \frac{1}{-j2n\pi} + \frac{e^{-jn\pi}}{-j2n\pi} - \frac{1}{-j2n\pi}$$

$$= \frac{e^{-jn\pi}}{-jn\pi} - \frac{1}{-jn\pi}$$

$$= \frac{j}{\pi n} ((-1)^{n} - 1)$$

Therefore:

$$s_1(t) = \sum_{n=-\infty}^{\infty} \frac{j}{\pi n} ((-1)^n - 1) e^{j2n\pi t}$$