## **Damping Ratio**

#Damping-Ratio

## 1.1 Definition:

$$\xi = a/\omega_n$$

- $\xi$  is the damping ratio
- a is the rate of exponential decay
  - For second order systems:  $e^{-at}$
- $\omega_n$  is the natural frequency of oscillation
- Measures the relative rate at which oscillation magnitudes are **reduced**, normalized by the natural frequency of the system
- $\zeta < 1$  -> underdamped
  - Oscillatory response decays exponentially
  - Lots of periods to eliminate the motion following a disturbance
- $\zeta = 0$ 
  - Indefinitely oscillating response
- $\lim_{\zeta \to 1} \zeta$ 
  - Oscillations dissipate in relatively few periods of oscillatory motion
- $\zeta = 1$ 
  - Critically damped system, with no motion

## 1.1.1 Percent Overshoot Method

$$\zeta = \frac{-\ln(\%OS/100)}{\sqrt{\pi^2 + \ln^2(\%OS/100)}}$$

- Response with too few peaks or too small to accurately extract from the time response
- %OS: Percent overshoot to a step input
  - Applying it to a system with additional poles and/or zeros is a goodway of determining "effective" damping ratio
  - Large amount of overshoot but small residual oscillations
    - Could be caused by presence of uncanceled zeros in the mid-frequency range (e.g. 1-10 rad/sec)
    - Perceived as lightly damped mode by pilot, especially in turbulence

Doesn't exist for impulse resulting in a steady state value of zero

## 1.1.2 Logarithmic Decrement

$$\zeta = \frac{\delta}{\sqrt{4\pi^2 + \delta^2}}$$

- Where  $\delta$  (the natural logarithm of the ratio of successive peaks with period T overreacted in measurement y(t):
  - $\delta = \ln \left[ \frac{y(t)}{y(t+T)} \right]$
- Significant residual oscillations exists
- Used peak times and magnitude to determine natural frequency and decay frequency of the response, from which  $\zeta$  is calculated
- Usually calculated from an impulse inputs and rate output (e.g., pitch rate)
  - But step input should work
- At least 3 oscillations required

From Wikipedia: The method of logarithmic decrement **becomes less** and less precise as the damping ratio increases past about **0.5**; it does not apply at all for a damping ratio greater than 1.0 because the system is overdamped