Mark3 Realtime Kernel

Generated by Doxygen 1.8.13

Contents

•	ine	warks Realtime Kernei	1
2	Lice	nse	3
	2.1	License	3
3	Con	figuring The Mark3 Kernel	5
	3.1	Overview	5
	3.2	Timer Options	5
	3.3	Blocking Objects	7
	3.4	Inter-process/thread Communication	7
	3.5	Debug Features	8
	3.6	Enhancements, Security, Miscellaneous	8
4	Buile	ding Mark3	11
	4.1	Source Layout	11
	4.2	Toolchain Integration	11
	4.3	Installing Dependencies	12
	4.4	Building Mark3 Kernel and Libraries	12
	4.5	Exporting the kernel source	13

ii CONTENTS

5	Getti	ing Started With The Mark3 API		15
	5.1	Kernel Setup		15
	5.2	Threads		16
		5.2.1 Thread Setup		16
		5.2.2 Entry Functions		17
	5.3	Timers		18
	5.4	Semaphores		18
	5.5	Mutexes		19
	5.6	Event Flags		20
	5.7	Messages		20
		5.7.1 Message Objects		21
		5.7.2 Global Message Pool		21
		5.7.3 Message Queues		22
		5.7.4 Messaging Example		22
	5.8	Mailboxes		22
		5.8.1 Mailbox Example		23
	5.9	Notification Objects		23
		5.9.1 Notification Example		23
	5.10	Condition Variables		24
		5.10.1 Condition Variable Example	•	24
	5.11	Reader-Write Locks	•	25
		5.11.1 Reader-Write Lock Example		25
	5.12	Sleep		25
	5.13	Round-Robin Quantum		26
6	Why	Mark3?		27

CONTENTS

7	Whe	n shou	ld you use an RTOS?	29
	7.1	The re	ality of system code	29
	7.2	Superl	oops, and their limitations	30
		7.2.1	Intro to Superloops	30
		7.2.2	The simplest loop	31
		7.2.3	Interrupt-Driven Super-loop	31
		7.2.4	Cooperative multi-tasking	33
		7.2.5	Hybrid cooperative/preemptive multi-tasking	34
	7.3	Proble	ms with superloops	35
		7.3.1	Hidden Costs	35
		7.3.2	Tightly-coupled code	35
		7.3.3	No blocking Calls	35
		7.3.4	Difficult to guarantee responsiveness	35
		7.3.5	Limited preemption capability	36
8	Can	you aff	ord an RTOS?	37
	8.1	Intro .		37
	8.2	Applica	ation description	38
	8.3	Runtim	ne Overhead	39
	8.4	Analys	is	40
9	Marl	k3 Desig	gn Goals	41
	9.1	Overvi	ew	41
		9.1.1	Services Provided by an RTOS Kernel	41
		9.1.2	Guiding Principles of Mark3	41
		9.1.3	Be feature competitive	41
		9.1.4	Be highly configuration	41
		9.1.5	No external dependencies, no new language features	42
		9.1.6	Target the most popular hobbyist platforms available	42
		9.1.7	Maximize determinism – but be pragmatic	42
		9.1.8	Apply engineering principles – and that means discipline, measurement and verification	42
		9.1.9	Use Virtualization For Verification	43

iv CONTENTS

10	Mark	3 Kernel Architecture	45
	10.1	Overview	45
	10.2	Threads and Scheduling	47
		10.2.1 A Bit About Threads	48
		10.2.2 Thread States and ThreadLists	49
		10.2.3 Blocking and Unblocking	49
		10.2.4 Blocking Objects	49
	10.3	Inside the Mark3 Scheduler	50
		10.3.1 Considerations for Round-Robin Scheduling	52
		10.3.2 Context Switching	53
		10.3.3 Putting It All Together	53
	10.4	Timers	53
		10.4.1 Tick-based Timers	55
		10.4.2 Tickless Timers	55
		10.4.3 Timer Processing Algorithm	55
	10.5	Synchronization and IPC	56
	10.6	Blocking Objects	56
		10.6.1 Semaphores	57
		10.6.2 Mutex	57
		10.6.3 Event Flags	57
		10.6.4 Notification Objects	58
	10.7	Messages and Global Message Queue	58
		10.7.1 Messages	58
		10.7.2 Message Objects	58
		10.7.3 Global Message Pool	59
		10.7.4 Message Queues	59
		10.7.5 Mailboxes	59
		10.7.6 Atomic Operations	60
		10.7.7 Atomic Operations	60
		10.7.8 Drivers	61
	10.8	Kernel Proper and Porting	63

CONTENTS

11	Mark3C - C-language API bindings for the Mark3 Kernel.	71
	11.1 API Conventions	71
	11.2 Allocating Objects	72
12	Release Notes	73
	12.1 R7 Release	73
	12.2 R6 Release	73
	12.3 R5 Release	74
	12.4 R4 Release	74
	12.5 R3 Release	75
	12.6 R2	75
	12.7 R1 - 2nd Release Candidate	75
	12.8 R1 - 1st Release Candidate	75
13	Code Size Profiling	77
	13.1 Information	77
	13.2 Compiler Version	
	13.3 Profiling Results	
	10.0 Froming Floodito	,,
14	Namespace Index	79
	14.1 Namespace List	79
15	Hierarchical Index	81
	15.1 Class Hierarchy	81
16	Class Index	83
10		03
	16.1 Class List	83
17	File Index	85
	17.1 File List	85

<u>vi</u> <u>CONTENTS</u>

18	Nam	espace	Documentation	89
	18.1	Mark3	Namespace Reference	89
		18.1.1	Detailed Description	91
		18.1.2	Typedef Documentation	91
			18.1.2.1 TimerCallback	91
		18.1.3	Enumeration Type Documentation	91
			18.1.3.1 EventFlagOperation	91
	18.2	Mark3:	:Atomic Namespace Reference	92
		18.2.1	Detailed Description	92
		18.2.2	Function Documentation	92
			18.2.2.1 Add()	92
			18.2.2.2 Set()	93
			18.2.2.3 Sub()	93
			18.2.2.4 TestAndSet()	94
	18.3	Mark3:	:KernelAware Namespace Reference	94
		18.3.1	Detailed Description	95
		18.3.2	Function Documentation	95
			18.3.2.1 ExitSimulator()	95
			18.3.2.2 IsSimulatorAware()	95
			18.3.2.3 Print()	95
			18.3.2.4 ProfileInit()	96
			18.3.2.5 ProfileReport()	96
			18.3.2.6 ProfileStart()	96
			18.3.2.7 ProfileStop()	97
			18.3.2.8 Trace() [1/3]	97
			18.3.2.9 Trace() [2/3]	97
			18.3.2.10 Trace() [3/3]	98

CONTENTS vii

19	Class	s Docui	mentation		99
	19.1	Mark3:	:BlockingC	Object Class Reference	99
		19.1.1	Detailed	Description	100
		19.1.2	Member	Function Documentation	100
			19.1.2.1	Block()	100
			19.1.2.2	BlockPriority()	100
			19.1.2.3	IsInitialized()	101
			19.1.2.4	UnBlock()	101
	19.2	Mark3:	:CircularLi	nkList Class Reference	102
		19.2.1	Detailed	Description	102
		19.2.2	Member	Function Documentation	102
			19.2.2.1	Add()	102
			19.2.2.2	InsertNodeBefore()	103
			19.2.2.3	PivotBackward()	103
			19.2.2.4	PivotForward()	103
			19.2.2.5	Remove()	104
	19.3	Mark3:	:Condition	Variable Class Reference	104
		19.3.1	Detailed	Description	104
		19.3.2	Member	Function Documentation	105
			19.3.2.1	Init()	105
			19.3.2.2	Wait() [1/2]	105
			19.3.2.3	Wait() [2/2]	105
	19.4	Mark3:	:DoubleLir	nkList Class Reference	106
		19.4.1	Detailed	Description	106
		19.4.2	Construc	tor & Destructor Documentation	106
			19.4.2.1	DoubleLinkList()	107
		19.4.3	Member	Function Documentation	107
			19.4.3.1	Add()	107
			19.4.3.2	Remove()	107
	19.5	Mark3:	:EventFlag	g Class Reference	108

viii CONTENTS

19.5	1 Detailed Description)9
19.5	2 Member Function Documentation)9
	19.5.2.1 Clear())9
	19.5.2.2 GetMask())9
	19.5.2.3 Set()	10
	19.5.2.4 Wait() [1/2]	10
	19.5.2.5 Wait() [2/2]	10
	19.5.2.6 Wait_i()	12
	19.5.2.7 WakeMe()	12
19.6 Mar	3::FakeThread_t Struct Reference	13
19.6	1 Detailed Description	13
19.7 Mar	3::Kernel Class Reference	14
19.7	1 Detailed Description	15
19.7	2 Member Function Documentation	15
	19.7.2.1 GetIdleThread()	15
	19.7.2.2 GetThreadContextSwitchCallout()	15
	19.7.2.3 GetThreadCreateCallout()	16
	19.7.2.4 GetThreadExitCallout()	16
	19.7.2.5 Init()	16
	19.7.2.6 IsPanic()	17
	19.7.2.7 IsStarted()	17
	19.7.2.8 Panic()	17
	19.7.2.9 SetIdleFunc()	17
	19.7.2.10 SetPanic()	18
	19.7.2.11 SetThreadContextSwitchCallout()	18
	19.7.2.12 SetThreadCreateCallout()	19
	19.7.2.13 SetThreadExitCallout()	19
	19.7.2.14 Start()	20
19.8 Mar	3::KernelTimer Class Reference	20
19.8	1 Detailed Description	21

CONTENTS

19.8.2	Member Function Documentation
	19.8.2.1 ClearExpiry()
	19.8.2.2 Config()
	19.8.2.3 DI()
	19.8.2.4 EI()
	19.8.2.5 GetOvertime()
	19.8.2.6 Read()
	19.8.2.7 RI()
	19.8.2.8 SetExpiry()
	19.8.2.9 Start()
	19.8.2.10 Stop()
	19.8.2.11 SubtractExpiry()
	19.8.2.12 TimeToExpiry()
19.9 Mark3:	:LinkList Class Reference
19.9.1	Detailed Description
19.9.2	Member Function Documentation
	19.9.2.1 GetHead()
	19.9.2.2 GetTail()
	19.9.2.3 Init()
19.10Mark3:	:LinkListNode Class Reference
19.10.1	Detailed Description
19.10.2	2 Member Function Documentation
	19.10.2.1 ClearNode()
	19.10.2.2 GetNext()
	19.10.2.3 GetPrev()
19.11Mark3:	:LockGuard Class Reference
19.11.1	Detailed Description
19.11.2	2 Constructor & Destructor Documentation
	19.11.2.1 LockGuard() [1/2]
	19.11.2.2 LockGuard() [2/2]

CONTENTS

19.11.3 Member Function Documentation	130
19.11.3.1 isAcquired()	130
19.12Mark3::Mailbox Class Reference	130
19.12.1 Detailed Description	132
19.12.2 Member Function Documentation	132
19.12.2.1 CopyData()	132
19.12.2.2 GetHeadPointer()	133
19.12.2.3 GetTailPointer()	133
19.12.2.4 Init() [1/2]	133
19.12.2.5 Init() [2/2]	134
19.12.2.6 MoveHeadBackward()	134
19.12.2.7 MoveHeadForward()	134
19.12.2.8 MoveTailBackward()	135
19.12.2.9 MoveTailForward()	135
19.12.2.10Receive() [1/2]	135
19.12.2.11Receive() [2/2]	135
19.12.2.12Receive_i()	136
19.12.2.13ReceiveTail() [1/2]	136
19.12.2.14ReceiveTail() [2/2]	137
19.12.2.15Send() [1/2]	137
19.12.2.16Send() [2/2]	138
19.12.2.17Send_i()	138
19.12.2.18SendTail() [1/2]	139
19.12.2.19SendTail() [2/2]	139
19.12.3 Member Data Documentation	140
19.12.3.1 m_clSendSem	140
19.13Mark3::Message Class Reference	140
19.13.1 Detailed Description	141
19.13.2 Member Function Documentation	141
19.13.2.1 GetCode()	141

CONTENTS xi

19.13.2.2 GetData()	. 141
19.13.2.3 Init()	. 142
19.13.2.4 SetCode()	. 142
19.13.2.5 SetData()	. 142
19.14Mark3::MessagePool Class Reference	. 143
19.14.1 Detailed Description	. 143
19.14.2 Member Function Documentation	. 143
19.14.2.1 GetHead()	. 144
19.14.2.2 Init()	. 144
19.14.2.3 Pop()	. 144
19.14.2.4 Push()	. 144
19.15Mark3::MessageQueue Class Reference	. 145
19.15.1 Detailed Description	. 146
19.15.2 Member Function Documentation	. 146
19.15.2.1 GetCount()	. 146
19.15.2.2 Init()	. 146
19.15.2.3 Receive() [1/2]	. 146
19.15.2.4 Receive() [2/2]	. 146
19.15.2.5 Receive_i()	. 147
19.15.2.6 Send()	. 147
19.16Mark3::Mutex Class Reference	. 148
19.16.1 Detailed Description	. 149
19.16.2 Member Function Documentation	. 149
19.16.2.1 Claim() [1/2]	. 149
19.16.2.2 Claim() [2/2]	. 149
19.16.2.3 Claim_i()	. 150
19.16.2.4 Init()	. 150
19.16.2.5 Release()	. 151
19.16.2.6 WakeMe()	. 151
19.16.2.7 WakeNext()	. 151

xii CONTENTS

19.17Mark3::Notify Class Reference
19.17.1 Detailed Description
19.17.2 Member Function Documentation
19.17.2.1 Init()
19.17.2.2 Signal()
19.17.2.3 Wait() [1/2]
19.17.2.4 Wait() [2/2]15
19.17.2.5 WakeMe()
19.18Mark3::PriorityMap Class Reference
19.18.1 Detailed Description
19.18.2 Constructor & Destructor Documentation
19.18.2.1 PriorityMap()
19.18.3 Member Function Documentation
19.18.3.1 Clear()
19.18.3.2 HighestPriority()
19.18.3.3 Set()
19.19Mark3::ProfileTimer Class Reference
19.19.1 Detailed Description
19.19.2 Member Function Documentation
19.19.2.1 ComputeCurrentTicks()
19.19.2.2 GetAverage()
19.19.2.3 GetCurrent()
19.19.2.4 Init()
19.19.2.5 Start()
19.19.2.6 Stop()
19.20Mark3::Quantum Class Reference
19.20.1 Detailed Description
19.20.2 Member Function Documentation
19.20.2.1 AddThread()
19.20.2.2 ClearInTimer()

CONTENTS xiii

19.20.2.3 RemoveThread()	 160
19.20.2.4 SetInTimer()	 160
19.20.2.5 SetTimer()	 160
19.20.2.6 UpdateTimer()	 161
19.21 Mark3::ReaderWriterLock Class Reference	 161
19.21.1 Detailed Description	 162
19.21.2 Member Function Documentation	 162
19.21.2.1 AcquireReader() [1/2]	 162
19.21.2.2 AcquireReader() [2/2]	 162
19.21.2.3 AcquireReader_i()	 163
19.21.2.4 AcquireWriter() [1/2]	 163
19.21.2.5 AcquireWriter() [2/2]	 163
19.21.2.6 AcquireWriter_i()	 164
19.21.2.7 Init()	 164
19.22Mark3::Scheduler Class Reference	 164
19.22.1 Detailed Description	 165
19.22.2 Member Function Documentation	 165
19.22.2.1 Add()	 166
19.22.2.2 GetCurrentThread()	 167
19.22.2.3 GetNextThread()	 167
19.22.2.4 GetStopList()	 168
19.22.2.5 GetThreadList()	 168
19.22.2.6 Init()	 168
19.22.2.7 IsEnabled()	 169
19.22.2.8 QueueScheduler()	 169
19.22.2.9 Remove()	 169
19.22.2.10Schedule()	 169
19.22.2.11SetScheduler()	 170
19.23Mark3::Semaphore Class Reference	 170
19.23.1 Detailed Description	 171

xiv CONTENTS

19.23.2 Member Function Documentation	71
19.23.2.1 GetCount()	72
19.23.2.2 Init()	72
19.23.2.3 Pend() [1/2]	72
19.23.2.4 Pend() [2/2]	73
19.23.2.5 Pend_i()	73
19.23.2.6 Post()	73
19.23.2.7 WakeMe()	74
19.23.2.8 WakeNext()	74
19.24Mark3::Thread Class Reference	74
19.24.1 Detailed Description	77
19.24.2 Member Function Documentation	77
19.24.2.1 ContextSwitchSWI()	78
19.24.2.2 Exit()	78
19.24.2.3 GetCurPriority()	78
19.24.2.4 GetCurrent()	79
19.24.2.5 GetEventFlagMask()	79
19.24.2.6 GetEventFlagMode()	79
19.24.2.7 GetExpired()	80
19.24.2.8 GetExtendedContext()	80
19.24.2.9 GetID()	80
19.24.2.10GetOwner()	81
19.24.2.11GetPriority()	81
19.24.2.12GetQuantum()	81
19.24.2.13GetStack()	82
19.24.2.14GetStackSize()	82
19.24.2.15GetStackSlack()	82
19.24.2.16GetState()	83
19.24.2.17InheritPriority()	83
19.24.2.18nit() [1/2]	83

CONTENTS xv

19.24.2.19nit() [2/2]	84
19.24.2.20nitldle()	84
19.24.2.21SetCurrent()	85
19.24.2.2SetEventFlagMask()	85
19.24.2.23SetEventFlagMode()	85
19.24.2.24SetExpired()	86
19.24.2.25SetExtendedContext()	86
19.24.2.26SetID()	86
19.24.2.27SetOwner()	87
19.24.2.2&etPriority()	87
19.24.2.29SetPriorityBase()	88
19.24.2.30SetQuantum()	88
19.24.2.31SetState()	88
19.24.2.3&leep()	89
19.24.2.3 % tart()	89
19.24.2.34Stop()	89
19.24.2.35USleep()	90
19.24.2.36Yield()	90
19.25Mark3::ThreadList Class Reference	90
19.25.1 Detailed Description	91
19.25.2 Constructor & Destructor Documentation	91
19.25.2.1 ThreadList()	91
19.25.3 Member Function Documentation	92
19.25.3.1 Add() [1/2]	92
19.25.3.2 Add() [2/2]	92
19.25.3.3 AddPriority()	92
19.25.3.4 HighestWaiter()	93
19.25.3.5 Remove()	93
19.25.3.6 SetMapPointer()	93
19.25.3.7 SetPriority()	94

xvi CONTENTS

19.26Mark3::ThreadPort Class Reference
19.26.1 Detailed Description
19.26.2 Member Function Documentation
19.26.2.1 InitStack()
19.26.2.2 StartThreads()
19.27Mark3::Timer Class Reference
19.27.1 Detailed Description
19.27.2 Constructor & Destructor Documentation
19.27.2.1 Timer()
19.27.3 Member Function Documentation
19.27.3.1 GetInterval()
19.27.3.2 Init()
19.27.3.3 IsInitialized()
19.27.3.4 SetCallback()
19.27.3.5 SetData()
19.27.3.6 SetFlags()
19.27.3.7 SetIntervalMSeconds()
19.27.3.8 SetIntervalSeconds()
19.27.3.9 SetIntervalTicks()
19.27.3.10SetIntervalUSeconds()
19.27.3.11SetOwner()
19.27.3.12SetTolerance()
19.27.3.13Start() [1/3]
19.27.3.14Start() [2/3]
19.27.3.15Start() [3/3]
19.27.3.16Stop()
19.28Mark3::TimerList Class Reference
19.28.1 Detailed Description
19.28.2 Member Function Documentation
19.28.2.1 Add()
19.28.2.2 Init()
19.28.2.3 Process()
19.28.2.4 Remove()
19.29Mark3::TimerScheduler Class Reference
19.29.1 Detailed Description
19.29.2 Member Function Documentation
19.29.2.1 Add()
19.29.2.2 Init()
19.29.2.3 Process()
19.29.2.4 Remove()

CONTENTS xvii

20	File I	Docume	entation	209
	20.1	/home/	moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/public/fake_types.h File Reference	. 209
		20.1.1	Detailed Description	. 209
	20.2	fake_ty	pes.h	. 209
	20.3	/home/	moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/public/mark3c.h File Reference .	. 212
		20.3.1	Detailed Description	. 213
		20.3.2	Enumeration Type Documentation	. 214
			20.3.2.1 event_flag_operation_t	. 214
		20.3.3	Function Documentation	. 214
			20.3.3.1 Kernel_Init()	. 214
			20.3.3.2 Kernel_IsPanic()	. 214
			20.3.3.3 Kernel_IsStarted()	. 215
			20.3.3.4 Kernel_Panic()	. 215
			20.3.3.5 Kernel_SetPanic()	. 215
			20.3.3.6 Kernel_Start()	. 216
			20.3.3.7 Scheduler_Enable()	. 216
			20.3.3.8 Scheduler_GetCurrentThread()	. 216
			20.3.3.9 Scheduler_IsEnabled()	. 217
			20.3.3.10 Thread_GetCurPriority()	. 217
			20.3.3.11 Thread_GetID()	. 218
			20.3.3.12 Thread_GetPriority()	. 218
			20.3.3.13 Thread_GetStackSlack()	. 219
			20.3.3.14 Thread_GetState()	. 219
			20.3.3.15 Thread_Init()	. 220
			20.3.3.16 Thread_SetID()	. 220
			20.3.3.17 Thread_SetPriority()	. 221
			20.3.3.18 Thread_Start()	. 221
			20.3.3.19 Thread_Stop()	. 221
			20.3.3.20 Thread_Yield()	. 222
	20.4	mark3c	s.h	. 222

xviii CONTENTS

File Reference	228
20.5.1 Detailed Description	228
20.6 kernelprofile.cpp	229
20.7 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kernelswi.cpp File Reference	230
20.7.1 Detailed Description	230
20.8 kernelswi.cpp	230
20.9 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kerneltimer.cpp File Reference	231
20.9.1 Detailed Description	231
20.10kerneltimer.cpp	232
20.11/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kernelprofile.h File Reference	234
20.11.1 Detailed Description	234
20.12kernelprofile.h	235
20.13/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kernelswi.h File Reference	235
20.13.1 Detailed Description	235
20.14kernelswi.h	236
20.15/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kerneltimer.h File Reference	236
20.15.1 Detailed Description	236
20.16kerneltimer.h	237
20.17/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/portcfg.h File Reference	237
20.17.1 Detailed Description	238
20.17.2 Macro Definition Documentation	238
20.17.2.1 AVR	238
20.17.2.2 K_WORD	239
20.17.2.3 PORT_PRIO_TYPE	239
20.17.2.4 PORT_SYSTEM_FREQ	239
20.17.2.5 PORT_TIMER_COUNT_TYPE	239

CONTENTS xix

20.17.2.6 PORT_TIMER_FREQ	240
20.18portcfg.h	240
20.19/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/threadport.h File Reference	240
20.19.1 Detailed Description	241
20.19.2 Macro Definition Documentation	241
20.19.2.1 CS_ENTER	242
20.20threadport.h	242
20.21/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/threadport.cpp File Reference	244
20.21.1 Detailed Description	245
20.22threadport.cpp	245
20.23/home/moslevin/projects/github/m3-repo/kernel/src/atomic.cpp File Reference	247
20.23.1 Detailed Description	247
20.24atomic.cpp	247
20.25/home/moslevin/projects/github/m3-repo/kernel/src/autoalloc.cpp File Reference	249
20.25.1 Detailed Description	249
20.26autoalloc.cpp	249
20.27/home/moslevin/projects/github/m3-repo/kernel/src/blocking.cpp File Reference	253
20.27.1 Detailed Description	253
20.28blocking.cpp	254
20.29/home/moslevin/projects/github/m3-repo/kernel/src/condvar.cpp File Reference	255
20.29.1 Detailed Description	255
20.30condvar.cpp	255
20.31/home/moslevin/projects/github/m3-repo/kernel/src/eventflag.cpp File Reference	256
20.31.1 Detailed Description	257
20.32eventflag.cpp	257
20.33/home/moslevin/projects/github/m3-repo/kernel/src/kernel.cpp File Reference	261
20.33.1 Detailed Description	261
20.34kernel.cpp	261
20.35/home/moslevin/projects/github/m3-repo/kernel/src/kernelaware.cpp File Reference	263

CONTENTS

20.35.1 Detailed Description
20.36kernelaware.cpp
20.37/home/moslevin/projects/github/m3-repo/kernel/src/ksemaphore.cpp File Reference
20.37.1 Detailed Description
20.38ksemaphore.cpp
20.39/home/moslevin/projects/github/m3-repo/kernel/src/ll.cpp File Reference
20.39.1 Detailed Description
20.40II.cpp
20.41/home/moslevin/projects/github/m3-repo/kernel/src/lockguard.cpp File Reference
20.41.1 Detailed Description
20.42lockguard.cpp
20.43/home/moslevin/projects/github/m3-repo/kernel/src/mailbox.cpp File Reference
20.43.1 Detailed Description
20.44mailbox.cpp
20.45/home/moslevin/projects/github/m3-repo/kernel/src/message.cpp File Reference
20.45.1 Detailed Description
20.46message.cpp
20.47/home/moslevin/projects/github/m3-repo/kernel/src/mutex.cpp File Reference
20.47.1 Detailed Description
20.48 mutex.cpp
20.49/home/moslevin/projects/github/m3-repo/kernel/src/notify.cpp File Reference
20.49.1 Detailed Description
20.50 notify.cpp
20.51/home/moslevin/projects/github/m3-repo/kernel/src/priomap.cpp File Reference
20.51.1 Detailed Description
20.52 priomap.cpp
20.53/home/moslevin/projects/github/m3-repo/kernel/src/profile.cpp File Reference
20.53.1 Detailed Description
20.54profile.cpp
20.55/home/moslevin/projects/github/m3-repo/kernel/src/public/atomic.h File Reference

CONTENTS xxi

20.55.1 Detailed Description	89
20.56atomic.h	89
20.57/home/moslevin/projects/github/m3-repo/kernel/src/public/autoalloc.h File Reference	90
20.57.1 Detailed Description	90
20.58autoalloc.h	90
20.59/home/moslevin/projects/github/m3-repo/kernel/src/public/blocking.h File Reference	93
20.59.1 Detailed Description	93
20.60 blocking.h	94
20.61/home/moslevin/projects/github/m3-repo/kernel/src/public/buffalogger.h File Reference	94
20.61.1 Detailed Description	94
20.62buffalogger.h	95
20.63/home/moslevin/projects/github/m3-repo/kernel/src/public/condvar.h File Reference	95
20.63.1 Detailed Description	95
20.64condvar.h	96
20.65/home/moslevin/projects/github/m3-repo/kernel/src/public/eventflag.h File Reference	96
20.65.1 Detailed Description	97
20.66eventflag.h	97
20.67/home/moslevin/projects/github/m3-repo/kernel/src/public/kernel.h File Reference	98
20.67.1 Detailed Description	98
20.68kernel.h	98
20.69/home/moslevin/projects/github/m3-repo/kernel/src/public/kernelaware.h File Reference	99
20.69.1 Detailed Description	00
20.70kernelaware.h	01
20.71/home/moslevin/projects/github/m3-repo/kernel/src/public/kerneldebug.h File Reference 36	01
20.71.1 Detailed Description	02
20.72kerneldebug.h	02
20.73/home/moslevin/projects/github/m3-repo/kernel/src/public/kerneltypes.h File Reference	07
20.73.1 Detailed Description	80
20.74kerneltypes.h	80
20.75/home/moslevin/projects/github/m3-repo/kernel/src/public/ksemaphore.h File Reference 30	09

xxii CONTENTS

20.75.1 Detailed Description
20.76ksemaphore.h
20.77/home/moslevin/projects/github/m3-repo/kernel/src/public/II.h File Reference
20.77.1 Detailed Description
20.78II.h
20.79/home/moslevin/projects/github/m3-repo/kernel/src/public/lockguard.h File Reference
20.79.1 Detailed Description
20.80 lockguard.h
20.81/home/moslevin/projects/github/m3-repo/kernel/src/public/mailbox.h File Reference
20.81.1 Detailed Description
20.82mailbox.h
20.83/home/moslevin/projects/github/m3-repo/kernel/src/public/manual.h File Reference
20.83.1 Detailed Description
20.84manual.h
20.85/home/moslevin/projects/github/m3-repo/kernel/src/public/mark3.h File Reference
20.85.1 Detailed Description
20.86mark3.h
20.87/home/moslevin/projects/github/m3-repo/kernel/src/public/mark3cfg.h File Reference
20.87.1 Detailed Description
20.87.2 Macro Definition Documentation
20.87.2.1 GLOBAL_MESSAGE_POOL_SIZE
20.87.2.2 KERNEL_AWARE_SIMULATION
20.87.2.3 KERNEL_EXTRA_CHECKS
20.87.2.4 KERNEL_NUM_PRIORITIES
20.87.2.5 KERNEL_TIMERS_MINIMUM_DELAY_US
20.87.2.6 KERNEL_TIMERS_THREADED
20.87.2.7 KERNEL_TIMERS_TICKLESS
20.87.2.8 KERNEL_USE_ATOMIC
20.87.2.9 KERNEL_USE_AUTO_ALLOC
20.87.2.10KERNEL_USE_CONDVAR

CONTENTS xxiii

20.87.2.11KERNEL_USE_DYNAMIC_THREADS	322
20.87.2.12KERNEL_USE_EVENTFLAG	322
20.87.2.13KERNEL_USE_IDLE_FUNC	323
20.87.2.14KERNEL_USE_MAILBOX	323
20.87.2.15KERNEL_USE_MESSAGE	323
20.87.2.16KERNEL_USE_PROFILER	323
20.87.2.17KERNEL_USE_QUANTUM	324
20.87.2.18KERNEL_USE_READERWRITER	324
20.87.2.19KERNEL_USE_SEMAPHORE	324
20.87.2.20KERNEL_USE_STACK_GUARD	324
20.87.2.21KERNEL_USE_THREAD_CALLOUTS	325
20.87.2.22KERNEL_USE_THREADNAME	325
20.87.2.23KERNEL_USE_TIMEOUTS	325
20.87.2.24KERNEL_USE_TIMERS	325
20.87.2.25SAFE_UNLINK	326
20.87.2.26THREAD_QUANTUM_DEFAULT	326
20.88mark3cfg.h	326
20.89/home/moslevin/projects/github/m3-repo/kernel/src/public/message.h File Reference	328
20.89.1 Detailed Description	328
20.89.2 using Messages, Queues, and the Global Message Pool	329
20.90 message.h	329
20.91/home/moslevin/projects/github/m3-repo/kernel/src/public/mutex.h File Reference	330
20.91.1 Detailed Description	331
20.91.2 Initializing	331
20.91.3 Resource protection example	331
20.92 mutex.h	332
20.93/home/moslevin/projects/github/m3-repo/kernel/src/public/notify.h File Reference	332
20.93.1 Detailed Description	333
20.94notify.h	333
20.95/home/moslevin/projects/github/m3-repo/kernel/src/public/paniccodes.h File Reference	334

xxiv CONTENTS

20.95.1 Detailed Description
20.96paniccodes.h
20.97/home/moslevin/projects/github/m3-repo/kernel/src/public/priomap.h File Reference
20.97.1 Detailed Description
20.98priomap.h
20.99/home/moslevin/projects/github/m3-repo/kernel/src/public/profile.h File Reference
20.99.1 Detailed Description
20.10 p rofile.h
20.10/home/moslevin/projects/github/m3-repo/kernel/src/public/quantum.h File Reference
20.101. Detailed Description
20.10 a juantum.h
20.102home/moslevin/projects/github/m3-repo/kernel/src/public/readerwriter.h File Reference 339
20.103. Detailed Description
20.104eaderwriter.h
20.10 25 home/moslevin/projects/github/m3-repo/kernel/src/public/scheduler.h File Reference
20.105. Detailed Description
20.10 6 cheduler.h
20.107/home/moslevin/projects/github/m3-repo/kernel/src/public/thread.h File Reference
20.107. Detailed Description
20.10 8 hread.h
20.10@home/moslevin/projects/github/m3-repo/kernel/src/public/threadlist.h File Reference
20.109. Detailed Description
20.11 6 hreadlist.h
20.11/home/moslevin/projects/github/m3-repo/kernel/src/public/timer.h File Reference
20.111. Detailed Description
20.111.2Macro Definition Documentation
20.111.2.1TIMERLIST_FLAG_EXPIRED
20.11 g mer.h
20.112home/moslevin/projects/github/m3-repo/kernel/src/public/timerlist.h File Reference
20.113. Detailed Description

CONTENTS xxv

20.11 4 merlist.h
20.115home/moslevin/projects/github/m3-repo/kernel/src/public/timerscheduler.h File Reference 351
20.115. Detailed Description
20.11 6 merscheduler.h
20.117/home/moslevin/projects/github/m3-repo/kernel/src/public/tracebuffer.h File Reference
20.117. Detailed Description
20.11 8 acebuffer.h
20.11 home/moslevin/projects/github/m3-repo/kernel/src/quantum.cpp File Reference
20.119. Detailed Description
20.12 q uantum.cpp
20.12/home/moslevin/projects/github/m3-repo/kernel/src/readerwriter.cpp File Reference
20.121. Detailed Description
20.122eaderwriter.cpp
20.122home/moslevin/projects/github/m3-repo/kernel/src/scheduler.cpp File Reference
20.123. Detailed Description
20.12 4 cheduler.cpp
20.125home/moslevin/projects/github/m3-repo/kernel/src/thread.cpp File Reference
20.125. Detailed Description
20.12 6 hread.cpp
20.127/home/moslevin/projects/github/m3-repo/kernel/src/threadlist.cpp File Reference
20.127. Detailed Description
20.128hreadlist.cpp
20.12@home/moslevin/projects/github/m3-repo/kernel/src/timer.cpp File Reference
20.129. Detailed Description
20.13 6 mer.cpp
20.13/home/moslevin/projects/github/m3-repo/kernel/src/timerlist.cpp File Reference
20.131. Detailed Description
20.13 2 merlist.cpp
20.132home/moslevin/projects/github/m3-repo/kernel/src/tracebuffer.cpp File Reference
20.133. Detailed Description
20.13#acebuffer.cpp

xxvi CONTENTS

21	Example Documentation	377
	21.1 buffalogger/main.cpp	377
	21.2 lab10_notifications/main.cpp	377
	21.3 lab11_mailboxes/main.cpp	378
	21.4 lab1_kernel_setup/main.cpp	380
	21.5 lab2_idle_function/main.cpp	382
	21.6 lab3_round_robin/main.cpp	383
	21.7 lab4_semaphores/main.cpp	385
	21.8 lab5_mutexes/main.cpp	386
	21.9 lab6_timers/main.cpp	388
	21.10lab7_events/main.cpp	390
	21.11lab8_messages/main.cpp	392
	21.12lab9_dynamic_threads/main.cpp	394
Ind	lex	399

Chapter 1

The Mark3 Realtime Kernel



The Mark3 Realtime Kernel is a completely free, open-source, real-time operating system aimed at bringing powerful, easy-to-use multitasking to microcontroller systems without MMUs.

It uses modern programming languages and concepts to minimize code duplication, and its object-oriented design enhances readibility. The API is simple – in six function calls, you can set up the kernel, initialize two threads, and start the scheduler.

The source is fully-documented with example code provided to illustrate concepts. The result is a performant RTOS, which is easy to read, easy to understand, and easy to extend to fit your needs.

But Mark3 is bigger than just a real-time kernel, it also contains a number of class-leading features:

- Native implementation in C++, with C-language bindings.
- Device driver HAL which provides a meaningful abstraction around device-specific peripherals.
- CMake-based build system which can be used to build all libraries, examples, tests, documentation, and user-projects for any number of targets from the command-line.
- Graphics and UI code designed to simplify the implementation of systems using displays, keypads, joysticks, and touchscreens
- Robust and deterministic dynamic memory management libraries
- A Variety of general-purpose libraries to speed up embedded app development
- · Emulator-aware debugging via the flAVR AVR emulator
- A bulletproof, well-documented bootloader for AVR microcontrollers Support for kernel-aware simulators, incluing Funkenstein's own flAVR.

Chapter 2

License

2.1 License

Copyright (c) 2012 - 2018, m0slevin All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of mOslevin, nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL FUNKENSTEIN SOFTWARE AND/OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

4 License

Chapter 3

Configuring The Mark3 Kernel

3.1 Overview

The Mark3 Kernel features a large number of compile-time options that can be set by the user. In this way, the user can build a custom OS kernel that provides only the necessary feature set required by the application, and reduce the code and data requirements of the kernel.

Care has been taken to ensure that all valid combinations of features can be enabled or disabled, barring direct dependencies.

When Mark3 is built, the various compile-time definitions are used to alter how the kernel is compiled, and include or exclude various bits and pieces in order to satisfy the requirements of the selected features. As a result, the kernel must be rebuilt whenever changes are made to the configuration header.

Note that not all demos, libraries, and tests will build successfully if the prerequisite features are not included.

Kernel options are set by modifying mark3cfg.h, located within the /kernel/public folder.

In the following sections, we will discuss the various configuration options, grouped by functionality.

3.2 Timer Options

KERNEL USE TIMERS

This option is related to all kernel time-tracking:

- Timers provide a way for events to be periodically triggered in a lightweight manner. These can be periodic, or one-shot.
- Thread Quantum (usedd for round-robin scheduling) is dependent on this module, as is Thread Sleep functionality.

Setting this option to 0 disables all timer-based functionality within the kernel.

KERNEL TIMERS TICKLESS

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

Tick-based timers provide a "traditional" RTOS timer implementation based on a fixed-frequency timer interrupt. While this provides very accurate, reliable timing, it also means that the CPU is being interrupted far more often than may be necessary (as not all timer ticks result in "real work" being done).

Tick-less timerLs still rely on a hardware timer interrupt, but uses a dynamic expiry interval to ensure that the interrupt is only called when the next timer expires. This increases the complexity of the timer interrupt handler, but reduces the number and frequency.

Note that the CPU port (kerneltimer.cpp) must be implemented for the particular timer variant desired.

Set this option to 1 to use the tickless timer implementation, 0 to use the traditional tick-based approach. Tickless timers are a bit more heavy weight (larger code footprint), but can yield significant power savings as the CPU does not need to wake up at a fixed, high frequency.

KERNEL USE TIMEOUTS

By default, if you opt to enable kernel timers, you also get timeout- enabled versions of the blocking object APIs along with it. This support comes at a small cost to code size, but a slightly larger cost to realtime performance - as checking for the use of timers in the underlying internal code costs some cycles.

As a result, the option is given to the user here to manually disable these timeout-based APIs if desired by the user for performance and code-size reasons.

Set this option to 1 to enable timeout-based APIs for blocking calls.

KERNEL_USE_QUANTUM

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way. This allows equal tasks to use unequal amounts of the CPU, which is a great way to set up CPU budgets per thread in a round-robin scheduling system. If enabled, you can specify a number of ticks that serves as the default time period (quantum). Unless otherwise specified, every thread in a priority will get the default quantum.

Set this option to 1 to enable round-robin scheduling.

THREAD_QUANTUM_DEFAULT

This value defines the default thread quantum when KERNEL_USE_QUANTUM is enabled. The value defined is a time in milliseconds.

KERNEL USE SLEEP

This define enables the Thread::Sleep() API, which allows a thread to suspend its operation for a defined length of time, specified in ms.

3.3 Blocking Objects 7

3.3 Blocking Objects

KERNEL USE NOTIFY

This is a simple blocking object, where a thread (or threads) are guaranteed to block until an asynchronous event signals the object.

KERNEL USE SEMAPHORE

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h. If you have to pick one blocking mechanism, this is the one to choose.

Note that all IPC mechanisms (mailboxes, messages) rely on semaphores, so keep in mind that this is a prerequisite for many other features in the kernel.

KERNEL_USE_MUTEX

Do you want the ability to use mutual exclusion semaphores (mutex) for resource/block protection? Enabling this feature provides mutexes, with priority inheritence, as declared in mutex.h.

KERNEL_USE_EVENTFLAG

Provides additional event-flag based blocking. This relies on an additional per-thread flag-mask to be allocated, which adds 2 bytes to the size of each thread object.

KERNEL USE READERWRITER

Provides reader-writer locks. Allows current read access, or single write-access to a resource. Readers wait for the writer to release the lock, and writers wait for all readers to release the lock before acquiring the resource.

KERNEL_USE_CONDVAR

Provides condition variables. Allows a thread to wait for a specific condition to be true before proceeding, with a mutual-exclusion lock held.

3.4 Inter-process/thread Communication

KERNEL USE MESSAGE

Enable inter-thread messaging using message queues. This is the preferred mechanism for IPC for serious multi-threaded communications; generally anywhere a semaphore or event-flag is insufficient.

GLOBAL MESSAGE POOL SIZE

If Messages are enabled, define the size of the default kernel message pool. Messages can be manually added to the message pool, but this mechansims is more convenient and automatic. All message queues can share their message objects from this global pool to maximize efficiency and simplify data management.

KERNEL_USE_MAILBOX

Enable inter-thread messaging using mailboxes. A mailbox manages a blob of data provided by the user, that is partitioned into fixed-size blocks called envelopes. The size of an envelope is set by the user when the mailbox is initialized. Any number of threads can read-from and write-to the mailbox. Envelopes can be sent-to or received-from the mailbox at the head or tail. In this way, mailboxes essentially act as a circular buffer that can be used as a blocking FIFO or LIFO queue.

3.5 Debug Features

KERNEL USE THREADNAME

Provide Thread method to allow the user to set a name for each thread in the system. Adds a const char* pointer to the size of the thread object.

KERNEL USE DEBUG

Provides extra logic for kernel debugging, and instruments the kernel with extra asserts, and kernel trace functionality.

KERNEL_ENABLE_LOGGING

Set this to 1 to enable very chatty kernel logging. Since most important things in the kernel emit logs, a large log-buffer and fast output are required in order to keep up. This is a pretty advanced power-user type feature, so it's disabled by default.

KERNEL ENABLE USER LOGGING

This enables a set of logging macros similar to the kernel-logging macros; however, these can be enabled or disabled independently. This allows for user-code to benefit from the built-in kernel logging macros without having to account for the super-high-volume of logs generated by kernel code.

KERNEL EXTRA CHECKS

This option provides extra safety checks within the kernel APIs in order to minimize the potential for unsafe operations. This is especially helpful during development, and can help catch problems at development time, instead of in the field.

KERNEL_USE_STACK_GUARD

This feature, when enabled, tells the kernel to check whether any Thread's stack has been exhausted (or slack falls below a certain safety threshold) before executing each context switch. Enabling this is the most effective means to guard against stack corruption and stack overflow in the kernel, at the cost of increased context

3.6 Enhancements, Security, Miscellaneous

KERNEL_USE_DRIVER

Enabling device drivers provides a posix-like filesystem interface for peripheral device drivers.

KERNEL_USE_DYNAMIC_THREADS

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime. useful for designs implementing worker threads, or threads that can be restarted after encountering error conditions.

KERNEL_USE_PROFILER

Provides extra classes for profiling the performance of code. useful for debugging and development, but uses an additional hardware timer.

KERNEL_USE_ATOMIC

Provides support for atomic operations, including addition, subtraction, set, and test-and-set. Add/Sub/Set contain 8, 16, and 32-bit variants.

SAFE_UNLINK

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists. This goes beyond pointer checks, adding a layer of structural and metadata validation to help detect system corruption early.

KERNEL AWARE SIMULATION

Include support for kernel-aware simulation. Enabling this feature adds advanced profiling, trace, and environment-aware debugging and diagnostic functionality when Mark3-based applications are run on the flAVR AVR simulator.

KERNEL_USE_IDLE_FUNC

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality. This saves a full thread stack, but also requires a bit extra static data. This also adds a slight overhead to the context switch and scheduler, as a special case has to be taken into account.

KERNEL_USE_AUTO_ALLOC

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory).

AUTO ALLOC SIZE

Size (in bytes) of the static pool of memory reserved from RAM for use by the auto allocator (if enabled).

KERNEL_USE_THREAD_CALLOUTS

This feature provides additional kernel APIs to register callout functions that are activated when threads are created or exited. This is useful for implementing low-level instrumentation based on information held in the threads.

KERNEL_USE_EXTENDED_CONTEXT

Allocate an extra pointer's worth of storage within a Thread object (and corresponding accessor methods) to provide the user with a means to implement arbitrary Thread-local storage.

Chapter 4

Building Mark3

4.1 Source Layout

One key aspect of Mark3 is that system features are organized into their own separate modules. These modules are further grouped together into folders based on the type of features represented:

```
Root Base folder, contains license info and build system configuration arduino Arduino-specific headers and API documentation files bootloader build Device-specific toolchain configuraton files for various platforms docs Documentation (pdf + html) Device driver code for various supported devices example Example applications Platform specific output folder, used when running export.sh fonts Bitmap fonts converted from TTF, used by Mark3 graphics library kbuild Build output directory kernel Basic Mark3 Components (the focus of this manual) cpu CPU-specific porting code scripts Scripts used to simplify build, documentation, and profiling libs Utility code and services, extended system features tests Unit tests, written as C/C++ applications util Host utilities - including a ttf font converter and device programmer
```

4.2 Toolchain Integration

Mark3 supports a variety of GCC ports out of the box - however, depending on your host OS and target processor, there may be some effort required to tie the toolchain into the build system.

After installing your toolchain of choice, you must make sure that the main toolchain binary paths are set in your systems PATH environment variable, ensuring that they are accessible directly from the command-line. Without this step, the build configuration step (cmake) will inevitably fail.

Depending on your toolchain, you may also be required to add toolchain-specific include directories to the build flags. These flags can be added to the cmake variables defined in /build/<cpu>/<variant>/<toolchain>/platform.cmake for your target architecture.

12 Building Mark3

4.3 Installing Dependencies

The Mark3 build system uses CMake (3.4.2 or above) for configuration management, and Ninja to execute the build steps. The combination of these two tools results in exceptionally fast builds - so fast that the previous makefile build system was scrapped in its favor.

These tools are readily available for most common host operating systems.

CMake can be found here: https://cmake.org Ninja can be found here: https://ninja-build.org

4.4 Building Mark3 Kernel and Libraries

Once a sane environment has been created, the kernel, libraries, examples and tests can be built by running ./scripts/build.sh from the root directory. By default, Mark3 builds for the atmega328p target, but the target can be selected by manually configuring the above environment variables, or by running the included ./scripts/set_target.sh script as follows:

```
./scripts/set_target.sh <architecture> <variant> <toolchain>
```

Where:

```
<architecture> is the target CPU architecture(i.e. avr, msp430, cm0, cm3, cm4f)
<variant> is the part name (i.e. atmega328p, msp430f2274, generic)
<toolchain> is the build toolchain (i.e. gcc)
```

This script is a thin wrapper for the cmake configuration commands, and clears the \mathtt{kbuild} output directory before re-initializing cmake for the selected target.

To build the Mark3 kernel and middleware libraries for a generic ARM Cortex-M0 using a pre-configured arm-none-eabi-gcc toolchain, one would run the following commands:

```
./scripts/set_target.sh cm0 generic gcc
./scripts/build.sh
```

To peform an incremental build, go into the cmake build directory (kbuild) and simply run 'ninja'.

Note that not all libraries/tests/examples will build in all kernel configurations. The default kernel configuration may need adjustment/tweaking to support a specific part. See CMakeLists.txt and mark3cfg.h respectively for more information

4.5 Exporting the kernel source

While the build system is flexible enough to adapt to any toolchain, it may be desireable to integrate the Mark3 kernel and associated drivers/libraries into another build system.

Mark3 provides a script (the aptly-named export.sh) which allow for the source for any supported port to be exported for this purpose. This script will also generate appropriate doxygen documentation, and package the whole of it together in a zip file. The files in the archive are placed in a "flat" heirarchy, and do not require any specific path structure to be maintained when imported into another build system.

As a special feature, if the "arduino" AVR target is specified, additional pre-processing is done on the source to turn the standard Mark3 kernel into a library that can be imported directly into Arudino IDE. This is also how the official Mark3 arduino-compatible releases are generated (hosted on mark3os.com and sourceforge.net)

To exercise the build system, type the following from the main mark3 embedded source directory:

```
> ./scripts/export.sh <target>
```

Where:

Target is one of the following:

```
atmega328p
atmega644
atmega1280
atmega2560
atmega1284p
atxmega256a3
arduino
arduino2560
cortex_m0
cortex_m3
cortex_m4f
msp430f2274
```

If successful, the generated artifacats will be placed in an output folder under the ./export directory.

Additionally, if doxygen is found on the host system's PATH, a copy of the manual (using the specific port's source code) will be generated and archived with the source release. If pdflatex is also found on the host's PATH, a PDF copy of the manual will be generated, tailored to the selected target.

14 Building Mark3

Chapter 5

Getting Started With The Mark3 API

5.1 Kernel Setup

This section details the process of defining threads, initializing the kernel, and adding threads to the scheduler.

If you're at all familiar with real-time operating systems, then these setup and initialization steps should be familiar. I've tried very hard to ensure that as much of the heavy lifting is hidden from the user, so that only the bare minimum of calls are required to get things started.

The examples presented in this chapter are real, working examples taken from the ATmega328p port.

First, you'll need to create the necessary data structures and functions for the threads:

- 1. Create a Thread object for all of the "root" or "initial" tasks.
- 2. Allocate stacks for each of the Threads
- 3. Define an entry-point function for each Thread

This is shown in the example code below:

```
#include "thread.h"
#include "kernel.h"

//1) Create a thread object for all of the "root" or "initial" tasks
static Thread AppThread;
static Thread IdleThread;

//2) Allocate stacks for each thread
#define STACK_SIZE_APP (192)
#define STACK_SIZE_IDLE (128)

static uint8_t aucAppStack[STACK_SIZE_APP];
static uint8_t aucIdleStack[STACK_SIZE_IDLE];

//3) Define entry point functions for each thread
void AppThread(void);
void IdleThread(void);
```

Next, we'll need to add the required kernel initialization code to main. This consists of running the Kernel's init routine, initializing all of the threads we defined, adding the threads to the scheduler, and finally calling Kernel::

Start(), which transfers control of the system to the RTOS.

These steps are illustrated in the following example.

```
int main (void)
    //1) Initialize the kernel prior to use
    Kernel::Init();
                                     // MUST be before other kernel ops
    //2) Initialize all of the threads we've defined
                       uneappStack, // Pointer to the stack STACK_SIZE_APP, // Size of the
    AppThread.Init( aucAppStack,
                                     // Thread priority
                       (void*)AppEntry, // Entry function
NULL); // Entry function argument
                       NULL );
                        aucIdleStack, // Pointer to the stack STACK_SIZE_IDLE, // Size of the stack
    IdleThread.Init(aucIdleStack,
                                     // Thread priority
                        (void*)IdleEntry, // Entry function
NULL); // Entry function argument
                        NULL );
    //3) Add the threads to the scheduler
    AppThread.Start();
                                    // Actively schedule the threads
    IdleThread.Start();
    //4) Give control of the system to the kernel
    Kernel::Start();
                                     // Start the kernel!
```

Not much to it, is there? There are a few noteworthy points in this code, though.

In order for the kernel to work properly, a system must always contain an idle thread; that is, a thread at priority level 0 that never blocks. This thread is responsible for performing any of the low-level power management on the CPU in order to maximize battery life in an embedded device. The idle thread must also never block, and it must never exit. Either of these operations will cause undefined behavior in the system.

The App thread is at a priority level greater-than 0. This ensures that as long as the App thread has something useful to do, it will be given control of the CPU. In this case, if the app thread blocks, control will be given back to the Idle thread, which will put the CPU into a power-saving mode until an interrupt occurs.

Stack sizes must be large enough to accommodate not only the requirements of the threads, but also the requirements of interrupts - up to the maximum interrupt-nesting level used. Stack overflows are super-easy to run into in an embedded system; if you encounter strange and unexplained behavior in your code, chances are good that one of your threads is blowing its stack.

5.2 Threads

Mark3 Threads act as independent tasks in the system. While they share the same address-space, global data, device-drivers, and system peripherals, each thread has its own set of CPU registers and stack, collectively known as the thread's **context**. The context is what allows the RTOS kernel to rapidly switch between threads at a high rate, giving the illusion that multiple things are happening in a system, when really, only one thread is executing at a time.

5.2.1 Thread Setup

Each instance of the Thread class represents a thread, its stack, its CPU context, and all of the state and metadata maintained by the kernel. Before a Thread will be scheduled to run, it must first be initialized with the necessary configuration data.

The Init function gives the user the opportunity to set the stack, stack size, thread priority, entry-point function, entry-function argument, and round-robin time quantum:

Thread stacks are pointers to blobs of memory (usually char arrays) carved out of the system's address space. Each thread must have a stack defined that's large enough to handle not only the requirements of local variables in the thread's code path, but also the maximum depth of the ISR stack.

5.2 Threads

Priorities should be chosen carefully such that the shortest tasks with the most strict determinism requirements are executed first - and are thus located in the highest priorities. Tasks that take the longest to execute (and require the least degree of responsiveness) must occupy the lower thread priorities. The idle thread must be the only thread occupying the lowest priority level.

The thread quantum only aplies when there are multiple threads in the ready queue at the same priority level. This interval is used to kick-off a timer that will cycle execution between the threads in the priority list so that they each get a fair chance to execute.

The entry function is the function that the kernel calls first when the thread instance is first started. Entry functions have at most one argument - a pointer to a data-object specified by the user during initialization.

An example thread initallization is shown below:

Once a thread has been initialized, it can be added to the scheduler by calling:

```
clMyThread.Start();
```

The thread will be placed into the Scheduler's queue at the designated priority, where it will wait its turn for execution.

5.2.2 Entry Functions

Mark3 Threads should not run-to-completion - they should execute as infinite loops that perform a series of tasks, appropriately partitioned to provide the responsiveness characteristics desired in the system.

The most basic Thread loop is shown below:

Threads can interact with eachother in the system by means of synchronization objects (Semaphore), mutual-exclusion objects (Mutex), Inter-process messaging (MessageQueue), and timers (Timer).

Threads can suspend their own execution for a predetermined period of time by using the static Thread::Sleep() method. Calling this will block the Thread's executin until the amount of time specified has ellapsed. Upon expiry, the thread will be placed back into the ready queue for its priority level, where it awaits its next turn to run.

5.3 Timers

Timer objects are used to trigger callback events periodic or on a one-shot (alarm) basis.

While extremely simple to use, they provide one of the most powerful execution contexts in the system. The timer callbacks execute from within the timer callback ISR in an interrupt-enabled context. As such, timer callbacks are considered higher-priority than any thread in the system, but lower priority than other interrupts. Care must be taken to ensure that timer callbacks execute as quickly as possible to minimize the impact of processing on the throughput of tasks in the system. Wherever possible, heavy-lifting should be deferred to the threads by way of semaphores or messages.

Below is an example showing how to start a periodic system timer which will trigger every second:

5.4 Semaphores

Semaphores are used to synchronized execution of threads based on the availability (and quantity) of application-specific resources in the system. They are extremely useful for solving producer-consumer problems, and are the method-of-choice for creating efficient, low latency systems, where ISRs post semaphores that are handled from within the context of individual threads. (Yes, Semaphores can be posted - but not pended - from the interrupt context).

The following is an example of the producer-consumer usage of a binary semaphore:

5.5 Mutexes 19

And an example of using semaphores from the ISR context to perform event- driven processing.

```
Semaphore clSemaphore;
__interrupt__ MyISR()
{
    clSemaphore.Post(); // Post the interrupt. Lightweight when uncontested.
}

void MyThread()
{
    clSemaphore.Init(0, 1); // Ensure this is initialized before the MyISR interrupt is enabled.
    while(1)
    {
        // Wait until we get notification from the interrupt
        clSemaphore.Pend();
        // Interrupt has fired, do the necessary work in this thread's context
        HeavyLifting();
    }
}
```

5.5 Mutexes

Mutexes (Mutual exclusion objects) are provided as a means of creating "protected sections" around a particular resource, allowing for access of these objects to be serialized. Only one thread can hold the mutex at a time - other threads have to wait until the region is released by the owner thread before they can take their turn operating on the protected resource. Note that mutexes can only be owned by threads - they are not available to other contexts (i.e. interrupts). Calling the mutex APIs from an interrupt will cause catastrophic system failures.

Note that these objects are also not recursive- that is, the owner thread can not attempt to claim a mutex more than once.

Prioritiy inheritence is provided with these objects as a means to avoid prioritiy inversions. Whenever a thread at a priority than the mutex owner blocks on a mutex, the priority of the current thread is boosted to the highest-priority waiter to ensure that other tasks at intermediate priorities cannot artificically prevent progress from being made.

Mutex objects are very easy to use, as there are only three operations supported: Initialize, Claim and Release. An example is shown below.

```
Mutex clMutex; // Create a mutex globally.
void Init()
    // Initialize the mutex before use.
    clMutex.Init();
// Some function called from a thread
void Thread1Function()
    clMutex.Claim();
    // Once the mutex is owned, no other thread can
    // enter a block protect by the same mutex
    my_protected_resource.do_something();
    my_protected_resource.do_something_else();
    clMutex.Release();
}
// Some function called from another thread
void Thread2Function()
    clMutex.Claim();
    // Once the mutex is owned, no other thread can
    // enter a block protect by the same mutex
    my_protected_resource.do_something();
    my_protected_resource.do_different_things();
    clMutex.Release();
```

5.6 Event Flags

Event Flags are another synchronization object, conceptually similar to a semaphore.

Unlike a semaphore, however, the condition on which threads are unblocked is determined by a more complex set of rules. Each Event Flag object contains a 16-bit field, and threads block, waiting for combinations of bits within this field to become set.

A thread can wait on any pattern of bits from this field to be set, and any number of threads can wait on any number of different patterns. Threads can wait on a single bit, multiple bits, or bits from within a subset of bits within the field.

As a result, setting a single value in the flag can result in any number of threads becoming unblocked simultaneously. This mechanism is extremely powerful, allowing for all sorts of complex, yet efficient, thread synchronization schemes that can be created using a single shared object.

Note that Event Flags can be set from interrupts, but you cannot wait on an event flag from within an interrupt.

Examples demonstrating the use of event flags are shown below.

```
// Simple example showing a thread blocking on a multiple bits in the
// fields within an event flag.
EventFlag clEventFlag;
int main()
    clEventFlag.Init(); // Initialize event flag prior to use
void MyInterrupt()
    // Some interrupt corresponds to event 0x0020
    clEventFlag.Set(0x0020);
void MyThreadFunc()
    while(1)
         uint16_t u16WakeCondition;
         // Allow this thread to block on multiple flags
         u16WakeCondition = clEventFlag.Wait(0x00FF, EventFlagOperation::Any_Set);
         // Clear the event condition that caused the thread to wake (in this case, // u16WakeCondtion will equal 0x20 when triggered from the interrupt above)
         clEventFlag.Clear(u16WakeCondition);
         // <do something>
```

5.7 Messages

Sending messages between threads is the key means of synchronizing access to data, and the primary mechanism to perform asynchronous data processing operations.

Sending a message consists of the following operations:

Obtain a Message object from the global message pool

5.7 Messages 21

- · Set the message data and event fields
- · Send the message to the destination message queue

While receiving a message consists of the following steps:

- · Wait for a messages in the destination message queue
- · Process the message data
- Return the message back to the global message pool

These operations, and the various data objects involved are discussed in more detail in the following section.

5.7.1 Message Objects

Message objects are used to communicate arbitrary data between threads in a safe and synchronous way.

The message object consists of an event code field and a data field. The event code is used to provide context to the message object, while the data field (essentially a void * data pointer) is used to provide a payload of data corresponding to the particular event.

Access to these fields is marshalled by accessors - the transmitting thread uses the SetData() and SetCode() methods to seed the data, while the receiving thread uses the GetData() and GetCode() methods to retrieve it.

By providing the data as a void data pointer instead of a fixed-size message, we achieve an unprecedented measure of simplicity and flexibility. Data can be either statically or dynamically allocated, and sized appropriately for the event without having to format and reformat data by both sending and receiving threads. The choices here are left to the user - and the kernel doesn't get in the way of efficiency.

It is worth noting that you can send messages to message queues from within ISR context. This helps maintain consistency, since the same APIs can be used to provide event-driven programming facilities throughout the whole of the OS.

5.7.2 Global Message Pool

To maintain efficiency in the messaging system (and to prevent over-allocation of data), a global pool of message objects is provided. The size of this message pool is specified in the implementation, and can be adjusted depending on the requirements of the target application as a compile-time option.

Allocating a message from the message pool is as simple as calling the GlobalMessagePool::Pop() Method.

Messages are returned back to the GlobalMessagePool::Push() method once the message contents are no longer required.

One must be careful to ensure that discarded messages always are returned to the pool, otherwise a resource leak can occur, which may cripple the operating system's ability to pass data between threads.

5.7.3 Message Queues

Message objects specify data with context, but do not specify where the messages will be sent. For this purpose we have a MessageQueue object. Sending an object to a message queue involves calling the MessageQueue::Send() method, passing in a pointer to the Message object as an argument.

When a message is sent to the queue, the first thread blocked on the queue (as a result of calling the Message ← Queue Receive() method) will wake up, with a pointer to the Message object returned.

It's worth noting that multiple threads can block on the same message queue, providing a means for multiple threads to share work in parallel.

5.7.4 Messaging Example

```
// Message queue object shared between threads
MessageQueue clMsgQ;
// Function that initializes the shared message queue
void MsgQInit()
    clMsgQ.Init();
// Function called by one thread to send message data to
void TxMessage()
    // Get a message, initialize its data
Message *pclMesg = GlobalMessagePool::Pop();
    pclMesg->SetCode(0xAB);
    pclMesg->SetData((void*)some_data);
    // Send the data to the message queue
    clMsgQ.Send(pclMesg);
// Function called in the other thread to block until
// a message is received in the message queue.
void RxMessage()
    Message *pclMesg;
    // Block until we have a message in the queue
    pclMesg = clMsgQ.Receive();
    // Do something with the data once the message is received
    pclMesq->GetCode();
     // Free the message once we're done with it.
    GlobalMessagePool::Push(pclMesg);
```

5.8 Mailboxes

Another form of IPC is provided by Mark3, in the form of Mailboxes and Envelopes.

Mailboxes are similar to message queues in that they provide a synchronized interface by which data can be transmitted between threads.

Where Message Queues rely on linked lists of lightweight message objects (containing only message code and a void* data-pointer), which are inherently abstract, Mailboxes use a dedicated blob of memory, which is carved up into fixed-size chunks called Envelopes (defined by the user), which are sent and received. Unlike message queues, mailbox data is copied to and from the mailboxes dedicated pool.

Mailboxes also differ in that they provide not only a blocking "receive" call, but also a blocking "send" call, providing the opportunity for threads to block on "mailbox full" as well as "mailbox empty" conditions.

All send/receive APIs support an optional timeout parameter if the KERNEL_USE_TIMEOUTS option has been configured in mark3cfg.h

5.8.1 Mailbox Example

```
// Create a mailbox object, and define a buffer that will be used to store the
// mailbox' envelopes.
static Mailbox clMbox;
static uint8_t aucMBoxBuffer[128];
void InitMailbox(void)
    // Initialize our mailbox, telling it to use our defined buffer for envelope
    // storage. Pass in the size of the buffer, and set the size of each // envelope to 16 bytes. This gives u16 a mailbox capacity of (128 / 16) = 8 \,
    // envelopes.
    clMbox.Init((void*)aucMBoxBuffer, 128, 16);
void SendThread(void)
    // Define a buffer that we'll eventually send to the
    \ensuremath{//} mailbox. Note the size is the same as that of an
    // envelope.
    uint8_t aucTxBuf[16];
    while(1)
         // Copy some data into aucTxBuf, a 16-byte buffer, the
         \ensuremath{//} same size as a mailbox envelope.
         // Deliver the envelope (our buffer) into the mailbox
        clMbox.Send((void*)aucTxBuf);
}
void RecvThred(void)
    uint8_t aucRxBuf[16];
    while(1)
         // Wait until there's a message in our mailbox. Once
         // there is a message, read it into our local buffer.
         cmMbox.Receive((void*)aucRxBuf);
         // Do something with the contents of aucRxBuf, which now
        \ensuremath{//} contains an envelope of data read from the mailbox.
         . . .
```

5.9 Notification Objects

Notification objects are the most lightweight of all blocking objects supplied by Mark3.

using this blocking primative, one or more threads wait for the notification object to be signalled by code elsewhere in the system (i.e. another thread or interrupt). Once the the notification has been signalled, all threads currently blocked on the object become unblocked.

5.9.1 Notification Example

```
static Notify clNotifier;
...
void MyThread(void *unused_)
{
    // Initialize our notification object before use clNotifier.Init();
    while (1)
```

```
{
    // Wait until our thread has been notified that it
    // can wake up.
    clNotify.Wait();
    ...
    // Thread has woken up now -- do something!
}
}
...
void SignalCallback(void)
{
    // Something in the system (interrupt, thread event, IPC, // etc.,) has called this function. As a result, we need // our other thread to wake up. Call the Notify object's // Signal() method to wake the thread up. Note that this // will have no effect if the thread is not presently // blocked.
    clNotify.Signal();
}
```

5.10 Condition Variables

Condition Variables, implemented in Mark3 with the ConditionVariable class, provide an implementation of the classic Monitor pattern. This object allows a thread to wait for a specific condition to occur, claiming a shared lock once the condition is met. Threads may also choose to signal a single blocking thread to indicate a condition has changed, or broadcast condition changes to all waiting threads.

5.10.1 Condition Variable Example

```
// Define a condition variable object, a shared lock, and
// a piece of common data shared between threads to represent
// a condition.
// Assume Mutex and ConditionVariable are initialized
static ConditionVariable clCondVar;
static Mutex clSharedLock;
static volatile int iCondition = 0;
void CondThread1(void *unused_)
    while (1)
        // Wait until
        clCondVar.Wait(&clSharedLock);
        // Only act on a specific condition if (iCondition == 1337) \{
            // Do something
        clSharedLock.Release();
}
void CondThread2(void *unused_)
    // Assume Mutex and ConditionVariable are initialized
    // prior to use.
    while (1)
        // Wait until
        clCondVar.Wait(&clSharedLock);
        // Act on a *different* condition than the other thread
        if (iCondition == 5454) {
            // Do something
        clSharedLock.Release();
```

5.11 Reader-Write Locks 25

```
void SignalThread(void* unused)
    while (1) {
        // Sleep for a while
        Thread::Sleep(100);
        // Update the condition in a thread-safe manner clSharedLock.Claim();
        iCondition = 1337;
        clSharedLock.Release();
        // Wake one thread to check for the updated condition
        clCondVar.Signal();
         // Sleep for a while
        Thread::Sleep(100);
         // Update the condition in a thread-safe manner
        clSharedLock.Claim();
        iCondition = 1337;
        clSharedLock.Release();
        // Wake all threads to check for the updated condition
        clCondVar.Broadcast();
```

5.11 Reader-Write Locks

Reader-Writer locks are provided in Mark3 to provide an efficient way for multiple threads to share concurrent, non-destructive access to a resource, while preventing concurrent destructive/non-destructive accesses. A single "writer" may hold the lock, or 1-or-more "readers" may hold the lock. In the case that readers hold the lock, writers will block until all readers have relinquished their access to the resource. In the case that a writer holds the lock, all other readers and writers must wait until the lock is relinquished.

5.11.1 Reader-Write Lock Example

```
void WriterTask(void* param)
{
    auto pclRWLock = static_cast<ReaderWriterLock*>(param);

    pclRWLock->AcquireWriter();
    // All other readers and writers will have to wait until
    // the lock is released.
    iNumWrites++;
    ...
    pclRWLock->ReleaseWriter();
}

void ReaderTask(void* param)
{
    auto pclRWLock = static_cast<ReaderWriterLock*>(param);

    pclRWLock->AcquireReader();
    // Any number of reader threads can also acquire the lock
    // without having to block, waiting for this task to release it.
    // Writers must block until all readers have released their references
    // to the lock.
    iNumReads++;
    ...
    pclRWLock->ReleaseReader();
}
```

5.12 Sleep

There are instances where it may be necessary for a thread to poll a resource, or wait a specific amount of time before proceeding to operate on a peripheral or volatile piece of data.

While the Timer object is generally a better choice for performing time-sensitive operations (and certainly a better choice for periodic operations), the Thread::Sleep() method provides a convenient (and efficient) mechanism that allows for a thread to suspend its execution for a specified interval.

Note that when a thread is sleeping it is blocked, during which other threads can operate, or the system can enter its idle state.

```
int GetPeripheralData();
{
    int value;
    // The hardware manual for a peripheral specifies that
    // the "foo()" method will result in data being generated
    // that can be captured using the "bar()" method.
    // However, the value only becomes valid after 10ms

    peripheral.foo();
    Thread::Sleep(10);    // Wait 10ms for data to become valid
    value = peripheral.bar();
    return value;
}
```

5.13 Round-Robin Quantum

Threads at the same thread priority are scheduled using a round-robin scheme. Each thread is given a timeslice (which can be configured) of which it shares time amongst ready threads in the group. Once a thread's timeslice has expired, the next thread in the priority group is chosen to run until its quantum has expired - the cycle continues over and over so long as each thread has work to be done.

By default, the round-robin interval is set at 4ms.

This value can be overridden by calling the thread's SetQuantum() with a new interval specified in milliseconds.

Chapter 6

Why Mark3?

My first job after graduating from university in 2005 was with a small company that had a very old-school, low-budget philosophy when it came to software development.

Every make-or-buy decision ended with "make" when it came to tools. It was the kind of environment where vendors cost us money, but manpower was free. In retrospect, we didn't have a ton of business during the time that I worked there, and that may have had something to do with the fact that we were constantly short on ready cash for things we could code ourselves.

Early on, I asked why we didn't use industry-standard tools - like JTAG debuggers or IDEs. One senior engineer scoffed that debuggers were tools for wimps - and something that a good programmer should be able to do without. After all - we had serial ports, GPIOs, and a bi-color LED on our boards. Since these were built into the hardware, they didn't cost us a thing. We also had a single software "build" server that took 5 minutes to build a 32k binary on its best days, so when we had to debug code, it was a painful process of trial and error, with lots of Youtube between iterations. We complained that tens of thousands of dollars of productivity was being flushed away that could have been solved by implementing a proper build server - and while we eventually got our wish, it took far more time than it should have.

Needless to say, software development was painful at that company. We made life hard on ourselves purely out of pride, and for the right to say that we walked "up-hills both ways through 3 feet of snow, everyday". Our code was tied ever-so-tightly to our hardware platform, and the system code was indistinguishable from the application. While we didn't use an RTOS, we had effectively implemented a 3-priority threading scheme using a carefully designed interrupt nesting scheme with event flags and a while(1) superloop running as a background thread. Nothing was abstracted, and the code was always optimized for the platform, presumably in an effort to save on code size and wasted cycles. I asked why we didn't use an RTOS in any of our systems and received dismissive scoffs - the overhead from thread switching and maintaining multiple threads could not be tolerated in our systems according to our chief engineers. In retrospect, our ad-hoc system was likely as large as my smallest kernel, and had just as much context switching (althrough it was hidden by the compiler).

And every time a new iteration of our product was developed, the firmware took far too long to bring up, because the algorithms and data structures had to be re-tooled to work with the peripherals and sensors attached to the new boards. We worked very hard in an attempt to reinvent the wheel, all in the name of producing "efficient" code.

Regardless, I learned a lot about embedded software development.

Most important, I learned that good design is the key to good software; and good design doesn't have to come at a price. In all but the smallest of projects, the well-designed, well-abstracted code is not only more portable, but it's usually smaller, easier to read, and easier to reuse.

Also, since we had all the time in the world to invest in developing our own tools, I gained a lot of experience building them, and making use of good, free PC tools that could be used to develop and debug a large portion of our code. I ended up writing PC-based device and peripheral simulators, state-machine frameworks, and abstractions for our

28 Why Mark3?

horrible ad-hoc system code. At the end of the day, I had developed enough tools that I could solve a lot of our development problems without having to re-inventing the wheel at each turn. Gaining a background in how these tools worked gave me a better understanding of how to use them - making me more productive at the jobs that I've had since.

I am convinced that designing good software takes honest effort up-front, and that good application code cannot be written unless it is based on a solid framework. Just as the wise man builds his house on rocks, and not on sand, wise developers write applications based on a well-defined platforms. And while you can probably build a house using nothing but a hammer and sheer will, you can certainly build one a lot faster with all the right tools.

This conviction lead me to development my first RTOS kernel in 2009 - FunkOS. It is a small, yet surprisingly full-featured kernel. It has all the basics (semaphores, mutexes, round-robin and preemptive scheduling), and some pretty advanced features as well (device drivers and other middleware). However, it had two major problems - it doesn't scale well, and it doesn't support many devices.

While I had modest success with this kernel (it has been featured on some blogs, and still gets around 125 downloads a month), it was nothing like the success of other RTOS kernels like uC/OS-II and FreeRTOS. To be honest, as a one-man show, I just don't have the resources to support all of the devices, toolchains, and evaluation boards that a real vendor can. I had never expected my kernel to compete with the likes of them, and I don't expect Mark3 to change the embedded landscape either.

My main goal with Mark3 was to solve the technical shortfalls in the FunkOS kernel by applying my experience in kernel development. As a result, Mark3 is better than FunkOS in almost every way; it scales better, has lower interrupt latency, and is generally more thoughtfully designed (all at a small cost to code size).

Another goal I had was to create something easy to understand, that could be documented and serve as a good introduction to RTOS kernel design. The end result of these goals is the kernel as presented in this book - a full source listing of a working OS kernel, with each module completely documented and explained in detail.

Finally, I wanted to prove that a kernel written entirely in C++ could perform just as well as one written in C. Mark3 is fully benchmarked and profiled – you can see exactly how much it costs to call certain APIs or include various features in the kernel.

And in addition, the code is more readable and easier to understand as a result of making use of object-oriented concepts provided by C++. Applications are easier to write because common concepts are encapsulated into objects (Threads, Semaphores, Mutexes, etc.) with their own methods and data, as opposed to APIs which rely on lots of explicit pointer or handle-passing, type casting, and other operations that are typically considered "unsafe" or "advaned" topics in C.

Chapter 7

When should you use an RTOS?

7.1 The reality of system code

System code can be defined as the program logic required to manage, synchronize, and schedule all of the resources (CPU time, memory, peripherals, etc.) used by the application running on the CPU. And it's true that a significant portion of the code running on an embedded system will be system code. No matter how simple a system is, whether or not this logic is embedded directly into the application (bare-metal system), or included as part of a well-defined stack on which an application is written (RTOS-based); system code is still present, and it comes with a cost.

As an embedded systems is being designed, engineers have to decide which approach to take: Bare-metal, or RTOS. There are advantages and disadvantages to each – and a reasonable engineer should always perform a thorough analysis of the pros and cons of each - in the context of the given application - before choosing a path.

The following figure demonstrates the differences between the architecture of a bare-metal system and RTOS based system at a high level:




Figure 7.1 Arch

As can be seen, the RTOS (And associated middleware + libraries) captures a certain fixed size.

As a generalization, bare-metal systems typically have the advantage in that the system code overhead is small to start – but grows significantly as the application grows in complexity. At a certain point, it becomes extremely difficult and error-prone to add more functionality to an application running on such a system. There's a tipping point, where the cost of the code used to work-around the limitations of a bare-metal system outweigh the cost of a capable RTOS. Bare-metal systems also generally take longer to implement, because the system code has to be written from scratch (or derived from existing code) for the application. The resulting code also tend to be less portable, as it takes serious discipline to keep the system-specific elements of the code separated – in an RTOS-based system, once the kernel and drivers are ported, the application code is generally platform agnostic.

Conversely, an RTOS-based system incurs a slightly higher fixed cost up-front, but scales infinitely better than a bare-metal system as application's complexity increases. Using an RTOS for simple systems reduces application development time, but may cause an application not to fit into some extremely size-constrained microcontroller. An RTOS can also cause the size of an application to grow more slowly relative to a bare-metal system – especially as a result of applying synchronization mechanisms and judicious IPC. As a result, an RTOS makes it significantly easier to "go agile" with an application – iteratively adding features and functionality, without having to consider refactoring the underlying system at each turn.

Some of these factors may be more important than others. Requirements, specifications, schedules, chip-selection, and volume projections for a project should all be used to feed into the discussions to decide whether or to go bare-metal or RTOS as a result.

Consider the following questions when making that decision:

- · What is the application?
- · How efficient is efficient enough?
- · How fast is fast enough?
- · How small is small enough?
- · How responsive is responsive enough?
- · How much code space/RAM/etc is available on the target system?
- How much code space/RAM do I need for an RTOS?
- · How much code space/RAM do I think I'll need for my application?
- · How much time do I have to deliver my system?
- · How many units do we plan to sell?

7.2 Superloops, and their limitations

7.2.1 Intro to Superloops

Before we start taking a look at designing a real-time operating system, it's worthwhile taking a look through one of the most-common design patterns that developers use to manage task execution in bare-metal embedded systems - Superloops.

Systems based on superloops favor the system control logic baked directly into the application code, usually under the guise of simplicity, or memory (code and RAM) efficiency. For simple systems, superloops can definitely get the job done. However, they have some serious limitations, and are not suitable for every kind of project. In a lot of cases you can squeak by using superloops - especially in extremely constrained systems, but in general they are not a solid basis for reusable, portable code.

Nonetheless, a variety of examples are presented here- from the extremely simple, to cooperative and liimted-preemptive multitasking systems, all of which are examples are representative of real-world systems that I've either written the firmware for, or have seen in my experience.

7.2.2 The simplest loop

Let's start with the simplest embedded system design possible - an infinite loop that performs a single task repeatedly:

```
int main()
{
    while(1)
    {
        Do_Something();
    }
}
```

Here, the code inside the loop will run a single function forever and ever. Not much to it, is there? But you might be surprised at just how much embedded system firmware is implemented using essentially the same mechanism - there isn't anything wrong with that, but it's just not that interesting.

Despite its simplicity we can see the beginnings of some core OS concepts. Here, the while(1) statement can be logically seen as the he operating system kernel - this one control statement determines what tasks can run in the system, and defines the constraints that could modify their execution. But at the end of the day, that's a big part of what a kernel is - a mechanism that controls the execution of application code.

The second concept here is the task. This is application code provided by the user to perform some useful purpose in a system. In this case Do_something() represents that task - it could be monitoring blood pressure, reading a sensor and writing its data to a terminal, or playing an MP3; anything you can think of for an embedded system to do. A simple round-robin multi-tasking system can be built off of this example by simply adding additional tasks in sequence in the main while-loop. Note that in this example the CPU is always busy running tasks - at no time is the CPU idle, meaning that it is likely burning a lot of power.

While we conceptually have two separate pieces of code involved here (an operating system kernel and a set of running tasks), they are not logically separate. The OS code is indistinguishable from the application. It's like a single-celled organism - everything is crammed together within the walls of an indivisible unit; and specialized to perform its given function relying solely on instinct.

7.2.3 Interrupt-Driven Super-loop

In the previous example, we had a system without any way to control the execution of the task- it just runs forever. There's no way to control when the task can (or more importantly can't) run, which greatly limits the usefulness of the system. Say you only want your task to run every 100 miliseconds - in the previous code, you have to add a hard-coded delay at the end of your task's execution to ensure your code runs only when it should.

Fortunately, there is a much more elegant way to do this. In this example, we introduce the concept of the synchronization object. A Synchronization object is some data structure which works within the bounds of the operating system to tell tasks when they can run, and in many cases includes special data unique to the synchronization event.

There are a whole family of synchronization objects, which we'll get into later. In this example, we make use of the simplest synchronization primitive

the global flag.

With the addition of synchronization brings the addition of event-driven systems. If you're programming a microcontroller system, you generally have scores of peripherals available to you - timers, GPIOs, ADCs, UARTs, ethernet, USB, etc. All of which can be configured to provide a stimulus to your system by means of interrupts. This stimulus gives us the ability not only to program our micros to do_something(), but to do_something() if-and-only-if a corresponding trigger has occurred.

The following concepts are shown in the example below:

```
volatile K_BOOL something_to_do = false;
__interrupt__ My_Interrupt_Source(void)
{
    something_to_do = true;
}
int main()
{
    while (1)
{
        if (something_to_do)
        {
            Do_something();
            something_to_do = false;
        }
        else
        {
             Idle();
        }
}
```

So there you have it - an event driven system which uses a global variable to synchronize the execution of our task based on the occurrence of an interrupt. It's still just a bare-metal, OS-baked-into-the-application system, but it's introduced a whole bunch of added complexity (and control!) into the system.

The first thing to notice in the source is that the global variable, something_to_do, is used as a synchronization object. When an interrupt occurs from some external event, triggering the My_Interrupt_Source() ISR, program flow in main() is interrupted, the interrupt handler is run, and something_to_do is set to true, letting us know that when we get back to main(), that we should run our Do_something() task.

Another new concept at play here is that of the idle function. In general, when running an event driven system, there are times when the CPU has no application tasks to run. In order to minimize power consumption, CPUs usually contain instructions or registers that can be set up to disable non-essential subsets of the system when there's nothing to do. In general, the sleeping system can be re-activated quickly as a result of an interrupt or other external stimulus, allowing normal processing to resume.

Now, we could just call Do_something() from the interrupt itself - but that's generally not a great solution. In general, the more time we spend inside an interrupt, the more time we spend with at least some interrupts disabled. As a result, we end up with interrupt latency. Now, in this system, with only one interrupt source and only one task this might not be a big deal, but say that Do_something() takes several seconds to complete, and in that time several other interrupts occur from other sources. While executing in our long-running interrupt, no other interrupts can be processed - in many cases, if two interrupts of the same type occur before the first is processed, one of these interrupt events will be lost. This can be utterly disastrous in a real-time system and should be avoided at all costs. As a result, it's generally preferable to use synchronization objects whenever possible to defer processing outside of the ISR.

Another OS concept that is implicitly introduced in this example is that of task priority. When an interrupt occurs, the normal execution of code in main() is preempted: control is swapped over to the ISR (which runs to completion), and then control is given back to main() where it left off. The very fact that interrupts take precedence over what's running shows that main is conceptually a "low-priority" task, and that all ISRs are "high-priority" tasks. In this example, our "high-priority" task is setting a variable to tell our "low-priority" task that it can do something useful. We will investigate the concept of task priority further in the next example.

Preemption is another key principle in embedded systems. This is the notion that whatever the CPU is doing when an interrupt occurs, it should stop, cache its current state (referred to as its context), and allow the high-priority event to be processed. The context of the previous task is then restored its state before the interrupt, and resumes processing. We'll come back to preemption frequently, since the concept comes up frequently in RTOS-based systems.

7.2.4 Cooperative multi-tasking

Our next example takes the previous example one step further by introducing cooperative multi-tasking:

```
// Bitfield values used to represent three distinct tasks
#define TASK_1_EVENT (0x01)
#define TASK_2_EVENT (0x02)
#define TASK_3_EVENT (0x04)
volatile K_UCHAR event_flags = 0;
// Interrupt sources used to trigger event execution
 _interrupt__ My_Interrupt_1(void)
    event flags |= TASK 1 EVENT;
 _interrupt__ My_Interrupt_2(void)
    event_flags |= TASK_2_EVENT;
 _interrupt__ My_Interrupt_3(void)
    event_flags |= TASK_3_EVENT;
// Main tasks
int main(void)
    while(1)
       while (event_flags)
            if( event_flags & TASK_1_EVENT)
                Do_Task_1();
                event_flags &= ~TASK_1_EVENT;
            } else if( event_flags & TASK_2_EVENT) {
                Do Task 2();
                event_flags &= ~TASK_2_EVENT;
            } else if( event_flags & TASK_3_EVENT) {
                Do_Task_3();
                event_flags &= ~TASK_3_EVENT;
        Idle();
```

This system is very similar to what we had before - however the differences are worth discussing. First, we have stimulus from multiple interrupt sources: each ISR is responsible for setting a single bit in our global event flag, which is then used to control execution of individual tasks from within main().

Next, we can see that tasks are explicitly given priorities inside the main loop based on the logic of the if/else if structure. As long as there is something set in the event flag, we will always try to execute Task1 first, and only when Task1 isn't set will we attempt to execute Task2, and then Task3. This added logic provides the notion of priority. However, because each of these tasks exist within the same context (they're just different functions called from our main control loop), we don't have the same notion of preemption that we have when dealing with interrupts.

That means that even through we may be running Task2 and an event flag for Task1 is set by an interrupt, the CPU still has to finish processing Task2 to completion before Task1 can be run. And that's why this kind of scheduling is referred to as cooperative multitasking: we can have as many tasks as we want, but unless they cooperate by means of returning back to main, the system can end up with high-priority tasks getting starved for CPU time by lower-priority, long-running tasks.

This is one of the more popular Os-baked-into-the-application approaches, and is widely used in a variety of real-time embedded systems.

7.2.5 Hybrid cooperative/preemptive multi-tasking

The final variation on the superloop design utilizes software-triggered interrupts to simulate a hybrid cooperative/preemptive multitasking system. Consider the example code below.

```
// Bitfields used to represent high-priority tasks. Tasks in this group
// can preempt tasks in the group below - but not eachother.
#define HP_TASK_1(0x01)
#define HP_TASK_2(0x02)
volatile K_UCHAR hp_tasks = 0;
// Bitfields used to represent low-priority tasks.
#define LP_TASK_1(0x01)
#define LP_TASK_2(0x02)
volatile K_UCHAR lp_tasks = 0;
// Interrupt sources, used to trigger both high and low priority tasks.
__interrupt__ System_Interrupt_1(void)
    // Set any of the other tasks from here...
hp_tasks |= HP_TASK_1;
// Trigger the SWI that calls the High_Priority_Tasks interrupt handler
  _interrupt__ System_Interrupt_n...(void)
// Set any of the other tasks from here...
// Interrupt handler that is used to implement the high-priority event context
 _interrupt__ High_Priority_Tasks(void)
    // Enabled every interrupt except this one
    Disable_My_Interrupt();
    Enable_Interrupts();
    while( hp_tasks)
        if( hp_tasks & HP_TASK_1)
        {
            HP_Task1();
            hp_tasks &= ~HP_TASK_1;
        else if (hp_tasks & HP_TASK_2)
            HP_Task2();
            hp_tasks &= ~HP_TASK_2;
    Restore_Interrupts();
    Enable_My_Interrupt();
// Main loop, used to implement the low-priority events
int main(void)
    // Set the function to run when a SWI is triggered
    Set_SWI(High_Priority_Tasks);
    // Run our super-loop
    while(1)
        while (lp_tasks)
             if (lp_tasks & LP_TASK_1)
                 LP_Task1();
                 lp_tasks &= ~LP_TASK_1;
            else if (lp_tasks & LP_TASK_2)
                 LP_Task2();
                 lp_tasks &= ~LP_TASK_2;
        Idle();
}
```

In this example, High_Priority_Tasks() can be triggered at any time as a result of a software interrupt (SWI),. When a high-priority event is set, the code that sets the event calls the SWI as well, which instantly preempts whatever is happening in main, switching to the high-priority interrupt handler. If the CPU is executing in an interrupt handler already, the current ISR completes, at which point control is given to the high priority interrupt handler.

Once inside the HP ISR, all interrupts (except the software interrupt) are re-enabled, which allows this interrupt to be preempted by other interrupt sources, which is called interrupt nesting. As a result, we end up with two distinct execution contexts (main and HighPriorityTasks()), in which all tasks in the high-priority group are guaranteed to preempt main() tasks, and will run to completion before returning control back to tasks in main(). This is a very basic preemptive multitasking scenario, approximating a "real" RTOS system with two threads of different priorities.

7.3 Problems with superloops

As mentioned earlier, a lot of real-world systems are implemented using a superloop design; and while they are simple to understand due to the limited and obvious control logic involved, they are not without their problems.

7.3.1 Hidden Costs

It's difficult to calculate the overhead of the superloop and the code required to implement workarounds for blocking calls, scheduling, and preemption. There's a cost in both the logic used to implement workarounds (usually involving state machines), as well as a cost to maintainability that comes with breaking up into chunks based on execution time instead of logical operations. In moderate firmware systems, this size cost can exceed the overhead of a reasonably well-featured RTOS, and the deficit in maintainability is something that is measurable in terms of lost productivity through debugging and profiling.

7.3.2 Tightly-coupled code

Because the control logic is integrated so closely with the application logic, a lot of care must be taken not to compromise the separation between application and system code. The timing loops, state machines, and architecture-specific control mechanisms used to avoid (or simulate) preemption can all contribute to the problem. As a result, a lot of superloop code ends up being difficult to port without effectively simulating or replicating the underlying system for which the application was written. Abstraction layers can mitigate the risks, but a lot of care should be taken to fully decouple the application code from the system code.

7.3.3 No blocking Calls

In a super-loop environment, there's no such thing as a blocking call or blocking objects. Tasks cannot stop midexecution for event-driven I/O from other contexts - they must always run to completion. If busy-waiting and polling are used as a substitute, it increases latency and wastes cycles. As a result, extra code complexity is often times necessary to work-around this lack of blocking objects, often times through implementing additional state machines. In a large enough system, the added overhead in code size and cycles can add up.

7.3.4 Difficult to guarantee responsiveness

Without multiple levels of priority, it may be difficult to guarantee a certain degree of real-time responsiveness without added profiling and tweaking. The latency of a given task in a priority-based cooperative multitasking system is the length of the longest task. Care must be taken to break tasks up into appropriate sized chunks in order to ensure that higher- priority tasks can run in a timely fashion - a manual process that must be repeated as new tasks are added in the system. Once again, this adds extra complexity that makes code larger, more difficult to understand and maintain due to the artificial subdivision of tasks into time-based components.

7.3.5 Limited preemption capability

As shown in the example code, the way to gain preemption in a superloop is through the use of nested interrupts. While this isn't unwiedly for two levels of priority, adding more levels beyond this is becomes complicated. In this case, it becomes necessary to track interrupt nesting manually, and separate sets of tasks that can run within given priority loops - and deadlock becomes more difficult to avoid.

Chapter 8

Can you afford an RTOS?

8.1 Intro

Of course, since you're reading the manual for an RTOS that I've been developing over the course of the several years, you can guess that the conclusion that I draw.

If your code is of any sort of non-trivial complexity (say, at least a few- thousand lines), then a more appropriate question would be "can you afford not* to use an RTOS in your system?".

In short, there are simply too many benefits of an RTOS to ignore, the most important being:

Threading, along with priority and time-based scheduling Sophisticated synchronization objects and IPC Flexible, powerful Software Timers Ability to write more portable, decoupled code

Sure, these features have a cost in code space and RAM, but from my experience the cost of trying to code around a lack of these features will cost you as much - if not more. The results are often far less maintainable, error prone, and complex. And that simply adds time and cost. Real developers ship, and the RTOS is quickly becoming one of the standard tools that help keep developers shipping.

One of the main arguments against using an RTOS in an embedded project is that the overhead incurred is too great to be justified. Concerns over "wasted" RAM caused by using multiple stacks, added CPU utilization, and the "large" code footprint from the kernel cause a large number of developers to shun using a preemptive RTOS, instead favoring a non-preemptive, application-specific solution.

I believe that not only is the impact negligible in most cases, but that the benefits of writing an application with an RTOS can lead to savings around the board (code size, quality, reliability, and development time). While these other benefits provide the most compelling case for using an RTOS, they are far more challenging to demonstrate in a quantitative way, and are clearly documented in numerous industry-based case studies.

While there is some overhead associated with an RTOS, the typical arguments are largely unfounded when an RTOS is correctly implemented in a system. By measuring the true overhead of a preemptive RTOS in a typical application, we will demonstrate that the impact to code space, RAM, and CPU usage is minimal, and indeed acceptable for a wide range of CPU targets.

To illustrate just how little an RTOS impacts the size of an embedded software design we will look at a typical microcontroller project and analyze the various types of overhead associated with using a pre-emptive realtime kernel versus a similar non-preemptive event-based framework.

RTOS overhead can be broken into three distinct areas:

- Code space: The amount of code space eaten up by the kernel (static)
- Memory overhead: The RAM associated with running the kernel and application threads.
- Runtime overhead: The CPU cycles required for the kernel's functionality (primarily scheduling and thread switching)

While there are other notable reasons to include or avoid the use of an RTOS in certain applications (determinism, responsiveness, and interrupt latency among others), these are not considered in this discussion - as they are difficult to consider for the scope of our "canned" application.

8.2 Application description

For the purpose of this comparison, we first create an application using the standard preemptive Mark3 kernel with 2 system threads running: A foreground thread and a background thread. This gives three total priority levels in the system - the interrupt level (high), and two application priority threads (medium and low), which is quite a common paradigm for microcontroller firmware designs. The foreground thread processes a variety of time-critical events at a fixed frequency, while the background thread processes lower priority, aperiodic events. When there are no background thread events to process, the processor enters its low-power mode until the next interrupt is acknowledged.

The contents of the threads themselves are unimportant for this comparison, but we can assume they perform a variety of realtime I/O functions. As a result, a number of device drivers are also implemented.

Code Space and Memory Overhead:

The application is compiled for an ATMega328p processor which contains 32kB of code space in flash, and 2kB of RAM, which is a lower-mid-range microcontroller in Atmel's 8-bit AVR line of microcontrollers. Using the AVR GCC compiler with -Os level optimizations, an executable is produced with the following code/RAM utilization:

Program: 27914 bytes Data: 1313 bytes

An alternate version of this project is created using a custom "super-loop" kernel, which uses a single application thread and provides 2 levels of priority (interrupt and application). In this case, the event handler processes the different priority application events to completion from highest to lowest priority.

This approach leaves the application itself largely unchanged. Using the same optimization levels as the preemptive kernel, the code compiles as follows:

Program: 24886 bytes Data: 750 bytes

At first glance, the difference in RAM utilization seems quite a lot higher for the preemptive mode version of the application, but the raw numbers don't tell the whole story.

The first issue is that the cooperative-mode total does not take into account the system stack - whereas these values are included in the totals for RTOS version of the project. As a result, some further analysis is required to determine how the stack sizes truly compare.

In cooperative mode, there is only one thread of execution - so considering that multiple event handlers are executed in turn, the stack requirements for cooperative mode is simply determined by those of the most stack-intensive event handler (ignoring stack use contributions due to interrupts).

In contrast, the preemptive kernel requires a separate stack for each active thread, and as a result the stack usage of the system is the sum of the stacks for all threads.

Since the application and idle events are the same for both preemptive and cooperative mode, we know that their (independent) stack requirements will be the same in both cases.

For cooperative mode, we see that the idle thread stack utilization is lower than that of the application thread, and so the application thread's determines the stack size requirement. Again, with the preemptive kernel the stack utilization is the sum of the stacks defined for both threads.

As a result, the difference in overhead between the two cases becomes the extra stack required for the idle thread - which in our case is (a somewhat generous) 128 bytes.

The numbers still don't add up completely, but looking into the linker output we see that the rest of the difference comes from the extra data structures used to manage the kernel in preemptive mode, and the kernel data itself.

Fixed kernel data costs:

8.3 Runtime Overhead 39

```
--- 134 Bytes Kernel data
--- 26 Bytes Kernel Vtables
```

Application (Variable) data costs:

```
--- 24 Bytes Driver Vtables
--- 123 Bytes - statically-allocated kernel objects (semaphores, timers, etc.)
```

With this taken into account, the true memory cost of a 2-thread system ends up being around 428 bytes of $R \leftarrow AM$ - which is about 20% of the total memory available on this particular microcontroller. Whether or not this is reasonable certainly depends on the application, but more importantly, it is not so unreasonable as to eliminate an RTOS-based solution from being considered. Also note that by using the "simulated idle" feature provided in Mark3 R3 and onward, the idle thread (and its associated stack) can be eliminated altogether to reduce the cost in constrained devices.

The difference in code space overhead between the preemptive and cooperative mode solutions is less of an issue. Part of this reason is that both the preemptive and cooperative kernels are relatively small, and even an average target device (like the Atmega328 we've chosen) has plenty of room.

Mark3 can be configured so that only features necessary for the application are included in the RTOS - you only pay for the parts of the system that you use. In this way, we can measure the overhead on a feature-by-feature basis, which is shown below for the kernel as configured for this application:

The configuration tested in this comparison uses the thread/port module with timers, drivers, and semaphores, and mutexes, for a total kernel size of 5052 Bytes, with the rest of the code space occupied by the application.

As can be seen from the compiler's output, the difference in code space between the two versions of the application is 3028 bytes - or about 9% of the available code space on the selected processor. While nearly all of this comes from the added overhead of the kernel, the rest of the difference comes the changes to the application necessary to facilitate the different frameworks. This also demonstrates that the system-software code size in the cooperative case is about 2024 bytes.

8.3 Runtime Overhead

On the cooperative kernel, the overhead associated with running the thread is the time it takes the kernel to notice a pending event flag and launch the appropriate event handler, plus the timer interrupt execution time.

Similarly, on the preemptive kernel, the overhead is the time it takes to switch contexts to the application thread, plus the timer interrupt execution time.

The timer interrupt overhead is similar for both cases, so the overhead then becomes the difference between the following:

Preemptive mode:

- Posting the semaphore that wakes the high-priority thread
- Performing a context switch to the high-priority thread

Cooperative mode:

- · Setting the event flag from the timer interrupt
- · Acknowledging the event from the event loop

coop - 438 cycles preempt - 764 cycles

Using a cycle-accurate AVR simulator (flAVR) running with a simulated speed of 16MHz, we find the end-to-end event sequence time to be 27us for the cooperative mode scheduler and 48us for the preemptive, and a raw difference of 20us.

With a fixed high-priority event frequency of 30Hz, we achieve a runtime overhead of 611us per second, or 0.06% of the total available CPU time. Now, obviously this value would expand at higher event frequencies and/or slower CPU frequencies, but for this typical application we find the difference in runtime overhead to be neglible for a preemptive system.

8.4 Analysis

For the selected test application and platform, including a preemptive RTOS is entirely reasonable, as the costs are low relative to a non-preemptive kernel solution. But these costs scale relative to the speed, memory and code space of the target processor. Because of these variables, there is no "magic bullet" environment suitable for every application, but Mark3 attempts to provide a framework suitable for a wide range of targets.

On the one hand, if these tests had been performed on a higher-end microcontroller such as the ATMega1284p (containing 128kB of code space and 16kB of RAM), the overhead would be in the noise. For this type of resource-rich microcontroller, there would be no reason to avoid using the Mark3 preemptive kernel.

Conversely, using a lower-end microcontroller like an ATMega88pa (which has only 8kB of code space and 1kB of RAM), the added overhead would likely be prohibitive for including a preemptive kernel. In this case, the cooperative-mode kernel would be a better choice.

As a rule of thumb, if one budgets 25% of a microcontroller's code space/RAM for system code, you should only require at minimum a microcontroller with 16k of code space and 2kB of RAM as a base platform for an RTOS. Unless there are serious constraints on the system that require much better latency or responsiveness than can be achieved with RTOS overhead, almost any modern platform is sufficient for hosting a kernel. In the event you find yourself with a microprocessor with external memory, there should be no reason to avoid using an RTOS at all.

Chapter 9

Mark3 Design Goals

9.1 Overview

9.1.1 Services Provided by an RTOS Kernel

At its lowest-levels, an operating system kernel is responsible for managing and scheduling resources within a system according to the application. In a typical thread-based RTOS, the resources involved is CPU time, and the kernel manages this by scheduling threads and timers. But capable RTOS kernels provide much more than just threading and timers.

In the following section, we discuss the Mark3 kernel architecture, all of its features, and a thorough discussion of how the pieces all work together to make an awesome RTOS kernel.

9.1.2 Guiding Principles of Mark3

Mark3 was designed with a number of over-arching principles, coming from years of experience designing, implementing, refining, and experimenting with RTOS kernels. Through that process I not only discovered what features I wanted in an RTOS, but how I wanted to build those features to look, work, and "feel". With that understanding, I started with a clean slate and began designing a new RTOS. Mark3 is the result of that process, and its design goals can be summarized in the following guiding principles.

9.1.3 Be feature competitive

To truly be taken seriously as more than just a toy or educational tool, an RTOS needs to have a certain feature suite. While Mark3 isn't a clone of any existing RTOS, it should at least attempt parity with the most common software in its class.

Looking at its competitors, Mark3 as a kernel supports most, if not all of the compelling features found in modern RTOS kernels, including dynamic threads, tickless timers, efficient message passing, and multiple types of synchronization primatives.

9.1.4 Be highly configuration

Mark3 isn't a one-size-fits-all kernel – and as a result, it provides the means to build a custom kernel to suit your needs. By configuring the kernel at compile-time, Mark3 can be built to contain the optimal feature set for a given application. And since features can be configured individually, you only pay the code/RAM footprint for the features you actually use.

42 Mark3 Design Goals

9.1.5 No external dependencies, no new language features

To maximize portability and promote adoption to new platforms, Mark3 is written in a widely supported subset of C++ that lends itself to embedded applications. It avoids RTTI, exceptions, templates, and libraries (C standard, STL, etc.), with all fundamental data structures and types implemented completely for use by the kernel. As a result, the portable parts of Mark3 should compile for any capable C++ toolchain.

9.1.6 Target the most popular hobbyist platforms available

Realistically, this means supporting the various Arduino-compatible target CPUs, including AVR and ARM Cortex-M series microcontrollers. As a result, the current default target for Mark3 is the atmega328p, which has 32KB of flash and 2KB of RAM. All decisions regarding default features, code size, and performance need to take that target system into account.

Mark3 integrates cleanly as a library into the Arduino IDE to support atmega328-based targets. Other AVR and Cortex-M targets can be supported using the port code provided in the source package.

9.1.7 Maximize determinism – but be pragmatic

Guaranteeing deterministic and predictable behavior is tough to do in an embedded system, and often comes with a heavy price tag in either RAM or code-space. With Mark3, we strive to keep the core kernel APIs and features as lightweight as possible, while avoiding algorithms that don't scale to large numbers of threads. We also achieve minimal latency by keeping interrupts enabled (operating out of the critical section) wherever possible.

In Mark3, the most important parts of the kernel are fixed-time, including thread scheduling and context switching. Operations that are not fixed time can be characterized as a function of their dependent data data. For instances, the Mutex and Semaphore APIs operate in fixed time in the uncontested case, and execute in linear time for the contested case – where the speed of execution is dependent on the number of threads currently waiting on that object.

The caveat here is that while we want to minimize latency and time spent in critical sections, that has to be balanced against increases in code size, and uncontested-case performance.

9.1.8 Apply engineering principles – and that means discipline, measurement and verification

My previous RTOS, FunkOS, was designed to be very ad-hoc. The usage instructions were along the lines of "drag and drop the source files into your IDE and compile". There was no regression/unit testing, no code size/speed profiling, and all documentation was done manually. It worked, but the process was a bit of a mess, and resulted in a lot of re-spins of the software, and a lot of time spent stepping through emulators to measure parameters.

We take a different approach in Mark3. Here, we've designed not only the kernel-code, but the build system, unit tests, profiling code, documentation and reporting that supports the kernel. Each release is built and tested using automation in order to ensure quality and correctness, with supporting documentation containing all critical metrics. Only code that passes testing is submitted to the repos and public forums for distribution. These metrics can be traced from build-to-build to ensure that performance remains consistent from one drop to the next, and that no regressions are introduced by new/refactored code.

And while the kernel code can still be exported into an IDE directly, that takes place with the knowledge that the kernel code has already been rigorously tested and profiled. Exporting source in Mark3 is also supported by scripting to ensure reliable, reproducible results without the possibility for human-error.

9.1 Overview 43

9.1.9 Use Virtualization For Verification

Mark3 was designed to work with automated simulation tools as the primary means to validate changes to the kernel, due to the power and flexibility of automatic tests on virtual hardware. I was also intrigued by the thought of extending the virtual target to support functionality useful for a kernel, but not found on real hardware.

When the project was started, simavr was the tool of choice- however, its simulation was found to be incorrect compared to execution on a real MCU, and it did not provide the degree of extension that I desired for use with kernel development.

The flAVR AVR simulator was written to replace the dependency on that tool, and overcome those limitations. It also provides a GDB interface, as well as its own built-in debugger, profilers, and trace tools.

The example and test code relies heavily on flAVR kernel aware messaging, so it is recommended that you familiarize yourself with that tool if you intend to do any sort of customizations or extensions to the kernel.

flAVR is hosted on sourceforge at http://www.sourceforge.net/projects/flavr/ . In its basic configuration, it builds with minimal external dependencies.

- · On linux, it requires only pthreads.
- On Windows, it rquires pthreads and ws2 32, both satisfied via MinGW.
- Optional SDL builds for both targets (featuring graphics and simulated joystick input) can be built, and rely on libSDL.

44 Mark3 Design Goals

Chapter 10

Mark3 Kernel Architecture

10.1 Overview

At a high level, the Mark3 RTOS is organized into the following features, and layered as shown below:




Figure 10.1 Overview

Everything in the "green" layer represents the Mark3 public API and classes, beneath which lives all hardware abstraction and CPU-specific porting and driver code, which runs on a given target CPU.

The features and concepts introduced in this diagram can be described as follows:

Threads: The ability to multiplex the CPU between multiple tasks to give the perception that multiple programs are running simultaneously. Each thread runs in its own context with its own stack.

Scheduler: Algorithm which determines the thread that gets to run on the CPU at any given time. This algorithm takes into account the priorites (and other execution parameters) associated with the threads in the system.

IPC: Inter-process-communications. Message-passing and Mailbox interfaces used to communicate between threads synchronously or asynchronously.

Synchronization Objects: Ability to schedule thread execution relative to system conditions and events, allowing for sharing global data and resources safely and effectively.

Timers: High-resolution software timers that allow for actions to be triggered on a periodic or one-shot basis.

Profiler: Special timer used to measure the performance of arbitrary blocks of code.

Debugging: Realitme logging and trace functionality, facilitating simplified debugging of systems using the OS.

Atomics: Support for UN-interruptble arithmatic operations.

Driver API: Hardware abstraction interface allowing for device drivers to be written in a consistent, portable manner.

Hardware Abstraction Layer: Class interface definitions to represent threading, context-switching, and timers in a generic, abstracted manner.

Porting Layer: Class interface implementation to support threading, context-switching, and timers for a given CPU.

User Drivers: Code written by the user to implement device-specific peripheral drivers, built to make use of the Mark3 driver API.

Each of these features will be described in more detail in the following sections of this chapter.

The concepts introduced in the above architecture are implemented in a variety of source modules, which are logically broken down into classes (or in some cases, groups of functions/macros). The relationship between objects in the Mark3 kernel is shown below:




Figure 10.2 Overview

The objects shown in the preceding table can be grouped together by feature. In the table below, we group each feature by object, referencing the source module in which they can be found in the Mark3 source tree.

Feature	Kernel Object	Source Files
Profiling	ProfileTimer	profile.cpp/.h
Threads + Scheduling	Thread	thread.cpp/.h
	Scheduler	scheduler.cpp/.h
	PriorityMap	priomap.cpp/.h
	Quantum	quantum.cpp/.h

Feature	Kernel Object	Source Files
	ThreadPort	threadport.cpp/.h **
	KernelSWI	kernelswi.cpp/.h **
Timers	Timer	timer.h/timer.cpp
	TimerScheduler	timerscheduler.h
	TimerList	timerlist.h/cpp
	KernelTimer	kerneltimer.cpp/.h **
Synchronization	BlockingObject	blocking.cpp/.h
	Semaphore	ksemaphore.cpp/.h
	EventFlag	eventflag.cpp/.h
	Mutex	mutex.cpp/.h
	Notify	notify.cpp/.h
	ConditionVariable	condvar.cpp/.h
	ReaderWriterLock	readerwriter.cpp/.h
IPC/Message-passing	Mailbox	mailbox.cpp/.h
	MessageQueue	message.cpp/.h
	GlobalMessagePool	message.cpp/.h
Debugging	Miscellaneous Macros	kerneldebug.h
	KernelAware	kernelaware.cpp/.h
	TraceBuffer	tracebuffer.cpp/.h
	Buffalogger	buffalogger.h
Atomic Operations	Atomic	atomic.cpp/.h
Kernel	Kernel	kernel.cpp/.h

10.2 Threads and Scheduling

The classes involved in threading and scheudling in Mark3 are highlighted in the following diagram, and are discussed in detail in this chapter:

 $[\]star\star$ implementation is platform-dependent, and located under the kernel's

^{** /}cpu/<arch>/<variant>/<toolchain> folder in the source tree




Figure 10.3 Threads and Scheduling

10.2.1 A Bit About Threads

Before we get started talking about the internals of the Mark3 scheduler, it's necessary to go over some background material - starting with: what is a thread, anyway?

Let's look at a very basic CPU without any sort of special multi-threading hardware, and without interrupts. When the CPU is powered up, the program counter is loaded with some default location, at which point the processor core will start executing instructions sequentially - running forever and ever according to whatever has been loaded into program memory. This single instance of a simple program sequence is the only thing that runs on the processor, and the execution of the program can be predicted entirely by looking at the CPU's current register state, its program, and any affected system memory (the CPU's "context").

It's simple enough, and that's exactly the definition we have for a thread in an RTOS.

Each thread contains an instance of a CPU's register context, its own stack, and any other bookkeeping information necessary to define the minimum unique execution state of a system at runtime. It is the job of a RTOS to multiplex the execution of multiple threads on a single physical CPU, thereby creating the illusion that many programs are being executed simultaneously. In reality there can only ever be one thread truly executing at any given moment on a CPU core, so it's up to the scheduler to set and enforce rules about what thread gets to run when, for how long, and under what conditions. As mentioned earlier, any system without an RTOS exeuctes as a single thread, so at least two threads are required for an RTOS to serve any useful purpose.

Note that all of this information is is common to pretty well every RTOS in existence - the implementation details, including the scheduler rules, are all part of what differentiates one RTOS from another.

10.2.2 Thread States and ThreadLists

Since only one thread can run on a CPU at a time, the scheduler relies on thread information to make its decisions. Mark3's scheduler relies on a variety of such information, including:

- · The thread's current priority
- · Round-Robin execution quanta
- · Whether or not the thread is blocked on a synchronization object, such as a mutex or semaphore
- · Whether or not the thread is currently suspended

The scheduler further uses this information to logically place each thread into 1 of 4 possible states:

```
Ready - The thread is currently running
Running - The thread is able to run
Blocked - The thread cannot run until a system condition is met
Stopped - The thread cannot run because its execution has been suspended
.
```

In order to determine a thread's state, threads are placed in "buckets" corresponding to these states. Ready and running threads exist in the scheduler's buckets, blocked threads exist in a bucket belonging to the object they're blocked on, and stopped threads exist in a separate bucket containing all stopped threads.

In reality, the various buckets are just doubly-linked lists of Thread objects - implemented in something called the ThreadList class. To facilitate this, the Thread class directly inherits from a LinkListNode class, which contains the node pointers required to implement a doubly-linked list. As a result, Threads may be effortlessly moved from one state to another using efficient linked-list operations built into the ThreadList class.

10.2.3 Blocking and Unblocking

While many developers new to the concept of an RTOS assume that all threads in a system are entirely separate from eachother, the reality is that practical systems typically involve multiple threads working together, or at the very least sharing resources. In order to synchronize the execution of threads for that purpose, a number of synchronization primatives (blocking objects) are implemented to create specific sets of conditions under which threads can continue execution. The concept of "blocking" a thread until a specific condition is met is fundamental to understanding RTOS applications design, as well as any highly-multithreaded applications.

10.2.4 Blocking Objects

Blocking objects and primatives provided by Mark3 include:

- · Semaphores (binary and counting)
- Mutexes
- Event Flags
- · Thread Notification Objects
- Thread Sleep
- · Message Queues

· Mailboxes

The relationship between these objects in the system are shown below:




Figure 10.4 Blocking Objects

Each of these objects inherit from the BlockingObject class, which itself contains a ThreadList object. This class contains methods to Block() a thread (remove it from the Scheduler's "Ready" or "Running" ThreadLists), as well as UnBlock() a thread (move a thread back to the "Ready" lists). This object handles transitioning threads from list-to-list (and state-to-state), as well as taking care of any other Scheduler bookkeeping required in the process. While each of the Blocking types implement a different condition, they are effectively variations on the same theme. Many simple Blocking objects are also used to build complex blocking objects - for instance, the Thread Sleep mechanism is essentially a binary semaphore and a timer object, while a message queue is a linked-list of message objects combined with a semaphore.

10.3 Inside the Mark3 Scheduler

At this point we've covered the following concepts:

- · Threads
- · Thread States and Thread Lists
- · Blocking and Un-Blocking Threads

Thankfully, this is all the background required to understand how the Mark3 Scheduler works. In technical terms, Mark3 implements "strict priority scheduling, with round-robin scheduling among threads in each priority group". In plain English, this boils down to a scheduler which follows a few simple rules:

```
Find the highest-priority "Ready" list that has at least one Threads. If the first thread in that bucket is not the current thread, select it to run next. Otherwise, rotate the linked list, and choose the next thread in the list to run
```

Since context switching is one of the most common and frequent operation performed by an RTOS, this needs to be as fast and deterministic as possible. While the logic is simple, a lot of care must be put into optimizing the scheduler to achieve those goals. In the section below we discuss the optimization approaches taken in Mark3.

There are a number of ways to find the highest-priority thread. The naive approach would be to simply iterate through the scheduler's array of ThreadLists from highest to lowest, stopping when the first non-empty list is found, such as in the following block of code:

While that would certainly work and be sufficient for a variety of systems, it's a non-deterministic approach (complexity O(n)) whose cost varies substantially based on how many priorities have to be evaluated. It's simple to read and understand, but it's non-optimal.

Fortunatley, a functionally-equivalent and more deterministic approach can be implemented with a few tricks.

In addition to maintaining an array of ThreadLists, Mark3 also maintains a bitmap (one bit per priority level) that indicates which thread lists have ready threads. This bitmap is maintained automatically by the ThreadList class, and is updated every time a thread is moved to/from the Scheduler's ready lists.

By inspecting this bitmap using a technique to count the leading zero bits in the bitmap, we determine which threadlist to choose in fixed time.

Now, to implement the leading-zeros check, this can once again be performed iteratively using bitshifts and compares (which isn't any more efficient than the raw list traversal), but it can also be evaluated using either a lookup table, or via a special CPU instruction to count the leading zeros in a value. In Mark3, we opt for the lookup-table approach since we have a limited number of priorities and not all supported CPU architectures support a count leading zero instruction. To achieve a balance between performance and memory use, we use a 4-bit lookup table (costing 16 bytes) to perform the lookup.

(As a sidenote - this is actually a very common approach in OS schedulers. It's actually part of the reason why modern ARM cores implement a dedicated count-leading-zeros [CLZ] instruction!)

With a 4-bit lookup table and an 8-bit priority-level bitmap, the priority check algorithm looks something like this:

```
// Check the highest 4 priority levels, represented in the
// upper 4 bits in the bitmap
priority = priority_lookup_table[(priority_bitmap >> 4)];

// priority is non-zero if we found something there
if( priority )
{
    // Add 4 because we were looking at the higher levels
    priority += 4;
}
else
{
    // Nothing in the upper 4, look at the lowest 4 priority levels
    // represented by the lowest 4 bits in the bitmap
    priority = priority_lookup_table[priority_bitmap & 0x0F];
}
```

Deconstructing this algorithm, you can see that the priority lookup will have on O(1) complexity - and is extremely low-cost.

This operation is thus fully deterministic and time bound - no matter how many threads are scheduled, the operation will always be time-bound to the most expensive of these two code paths. Even with only 8 priority levels, this is still much faster than iteratively checking the thread lists manually, compared with the previous example implementation.

Once the priority level has been found, selecting the next thread to run is trivial, consisting of something like this:

next_thread = thread_list[prio].get_head();

In the case of the get_head() calls, this evaluates to an inline-load of the "head" pointer in the particular thread list.

One important thing to take away from this analysis is that the scheduler is only responsible for selecting the next-torun thread. In fact, these two operations are totally decoupled - no context switching is performed by the scheduler, and the scheduler isn't called from the context switch. The scheduler simply produces new "next thread" values that are consumed from within the context switch code.

10.3.1 Considerations for Round-Robin Scheduling

One thing that isn't considered directly from the scheduler algorithm is the problem of dealing with multiple threads within a single priority group; all of the alorithms that have been explored above simply look at the first Thread in each group.

Mark3 addresses this issue indirectly, using a software timer to manage round-robin scheduling, as follows.

In some instances where the scheduler is run by the kernel directly (typically as a result of calling Thread::Yield()), the kernel will perfom an additional check after running the Scheduler to determine whether or there are multiple ready Threadsin the priority of the next ready thread.

If there are multiple threads within that priority, the kernel adds a one-shot software timer which is programmed to expire at the next Thread's configured quantum. When this timer expires, the timer's callback function executes to perform two simple operations:

"Pivot" the current Thread's priority list. Set a flag telling the kernel to trigger a Yield after exiting the main Timer Scheduler processing loop

Pivoting the thread list basically moves the head of a circular-linked-list to its next value, which in our case ensures that a new thread will be chosen the next time the scheduler is run (the scheduler only looks at the head node of the priority lists). And by calling Yield, the system forces the scheduler t run, a new round-robin software timer to be installed (if necssary), and triggers a context switch SWI to load the newly-chosen thread. Note that if the thread attached to the round-robin timer is pre-empted, the kernel will take steps to abort and invalidate that round-robin software timer, installing a new one tied to the next thread to run if necessary.

Because the round-robin software timer is dynamically installed when there are multiple ready threads at the highest ready priority level, there is no CPU overhead with this feature unless that condition is met. The cost of round-robin scheduling is also fixed - no matter how many threads there are, and the cost is identical to any other one-shot software timer in the system.

10.4 Timers 53

10.3.2 Context Switching

There's really not much to say about the actual context switch operation at a high level. Context switches are triggered whenever it has been determined that a new thread needs to be swapped into the CPU core when the scheduler is run. Mark3 implements also context switches as a call to a software interrupt - on AVR platforms, we typically use INT0 or INT2 for this (although any pin-change GPIO interrupt can be used), and on ARM we achieve this by triggering a PendSV exception.

However, regardless of the architecture, the contex-switch ISR will perform the following three operations:

Save the current Thread's context to the current Thread stack Make the "next to run" thread the "currently running" thread Restore the context of the next Thread from the Thread stack

The code to implement the context switch is entirely architecture-specific, so it won't be discussed in detail here. It's almost always gory inline-assembly which is used to load and store various CPU registers, and is highly-optimized for speed. We dive into an example implementation for the ARM Cortex-M0 microcontroller in a later section of this book.

10.3.3 Putting It All Together

In short, we can say that the Mark3 scheduler works as follows:

- The scheduler is run whenever a Thread::Yield() is called by a user, as part of blocking calls, or whenever a new thread is started
- The Mark3 scheduler is deterministic, selecting the next thread to run in fixed-time
- The scheduler only chooses the next thread to run, the context switch SWI consumes that information to get that thread running
- Where there are multiple ready threads in the highest populated priority level, a software timer is used to manage round-robin scheduling

While we've covered a lot of ground in this section, there's not a whole lot of code involved. However, the code that performs these operations is nuanced and subtle. If you're interested in seeing how this all works in practice, I suggest reading through the Mark3 source code (which is heavily annotated), and stepping through the code with a simulator/emulator.

10.4 Timers

Mark3 implements one-shot and periodic software-timers via the Timer class. The user configures the timer for duration, repetition, and action, at which point the timer can be activated. When an active timer expires, the kernel calls a user-specified callback function, and then reloads the timer in the case of periodic timers. The same timer objects exposed to the user are also used within the kernel to implement round-robin scheduling, and timeout-based APIs for seamphores, mutexes, events, and messages.

Timers are implemented using the following components in the Mark3 Kernel:




Figure 10.5 Timers

The Timer class provides the basic periodic and one-shot timer functionality used by application code, blocking objects, and IPC.

The TimerList class implements a doubly-linked list of Timer objects, and the logic required to implement a timer tick (tick-based kernel) or timer expiry (tickless kernel) event.

The TimerScheduler class contains a single TimerList object, implementing a single, system-wide list of Timer objects within the kernel. It also provides hooks for the hardware timer, such that when a timer tick or expiry event occurs, the TimerList expiry handler is run.

The KernelTimer class (kerneltimer.cpp/.h) implements the CPU specific hardware timer driver that is used by the kernel and the TimerScheduler to implement software timers.

While extremely simple to use, they provide one of the most powerful execution contexts in the system.

The software timers implemented in Mark3 use interrupt-nesting within the kernel timer's interrupt handler. This context is be considered higher-priority than the highest priority user thread, but lower-priority than other interrupts in the system. As a result, this minimizes critical interrupt latency in the system, albeit at the expense of responsiveness of the user-threads.

For this reason, it's critical to ensure that all timer callback events are kept as short as possible to prevent adding thread-level latency. All heavy-lifting should be left to the threads, so the callback should only implement signalling via IPC or synchronization object.

The time spent in this interrupt context is also dependent on the number of active timers at any given time. However, Mark3 also can be used to minimize the frequency of these interrupts wakeups, by using an optional "tolerance" parameter in the timer API calls. In this way, periodic tasks that have less rigorous real-time constraints can all be grouped together – executing as a group instead of one-after-another.

Mark3 also contains two different timer implementations that can be configured at build-time, each with their own advantages.

10.4 Timers 55

10.4.1 Tick-based Timers

In a tick-based timing scheme, the kernel relies on a system-timer interrupt to fire at a relatively-high frequency, on which all kernel timer events are derived. On modern CPUs and microcontrollers, a 1kHz system tick is common, although quite often lower frequencies such as 60Hz, 100Hz, or 120Hz are used. The resolution of this timer also defines the maximum resolution of timer objects as a result. That is, if the timer frequency is 1kHz, a user cannot specify a timer resolution lowerthan 1ms.

The advantage of a tick-based timer is its sheer simplicity. It typically doesn't take much to set up a timer to trigger an interrupt at a fixed-interval, at which point, all system timer intervals are decremented by 1 count. When each system timer interval reaches zero, a callback is called for the event, and the events are either reset and restarted (repeated timers) or cleared (1-shot).

Unfortunately, that simplicity comes at a cost of increased interrupt count, which cause frequent CPU wakeups and utilization, and power consumption.

10.4.2 Tickless Timers

In a tickless system, the kernel timer only runs when there are active timers pending expiry, and even then, the timer module only generates interrupts when a timer expires, or a timer reaches its maximum count value. Additionally, when there are no active timer objects, the timer can is completely disabled – saving even more cycles, power, and CPU wakeups. These factors make the tickless timer approach a highly-optimal solution, suitable for a wide array of low-power applications.

Also, since tickless timers do not rely on a fixed, periodic clock, they can potentially be higher resolution. The only limitation in timer resolution is the precision of the underlying hardware timer as configured. For example, if a 32kHz hardware timer is being used to drive the timer scheduler, the resolution of timer objects would be in the \sim 33us range.

The only downside of the tickless timer system is an added complexity to the timer code, requiring more code space, and slightly longer execution of the timer routines when the timer interrupt is executed.

10.4.3 Timer Processing Algorithm

Timer interrupts occur at either a fixed-frequency (tick-based), or at the next timer expiry interval (tickless), at which point the timer processing algorithm runs. While the timer count is reset by the timer-interrupt, it is still allowed to accumulate ticks while this algorithm is executed in order to ensure that timer-accuracy is kept in real-time. It is also important to note that round-robin scheduling changes are disabled during the execution of this algorithm to prevent race conditions, as the round-robin code also relies on timer objects.

All active timer objects are stored in a doubly-linked list within the timer-scheduler, and this list is processed in two passes by the alogirthm which runs from the timer-interrupt (with interrupt nesting enabled). The first pass determines which timers have expired and the next timer interval, while the second pass deals with executing the timer callbacks themselves. Both phases are discussed in more detail below.

In the first pass, the active timers are decremented by either 1 tick (tick-based), or by the duration of the last elapsed timer interval (tickless). Timers that have zero (or less-than-zero) time remaining have a "callback" flag set, telling the algorithm to call the timer's callback function in the second pass of the loop. In the event of a periodic timer, the timer's interval is reset to its starting value.

For the tickless case, the next timer interval is also computed in the first-pass by looking for the active timer with the least amount of time remaining in its interval. Note that this calculation is irrelevant in the tick-based timer code, as the timer interrupt fires at a fixed-frequency.

56 Mark3 Kernel Architecture

In the second pass, the algorithms loops through the list of active timers, looking for those with their "callback" flag set in the first pass. The callback function is then executed for each expired timer, and the "callback" flag cleared. In the event that a non-periodic (one-shot) timer expires, the timer is also removed from the timer scheduler at this time.

In a tickless system, once the second pass of the loop has been completed, the hardware timer is checked to see if the next timer interval has expired while processing the expired timer callbacks. In that event, the complete algorithm is re-run to ensure that no expired timers are missed. Once the algorithm has completed without the next timer expiring during processing, the expiry time is programmed into the hardware timer. Round-robin scheduling is re-enabled, and if a new thread has been scheduled as a result of action taken during a timer callback, a context switch takes place on return from the timer interrupt.

10.5 Synchronization and IPC




Figure 10.6 Synchronization and IPC

10.6 Blocking Objects

A Blocking object in Mark3 is essentially a thread list. Any blocking object implementation (being a semaphore, mutex, event flag, etc.) canbe built on top of this class, utilizing the provided functions to manipulate thread location within the Kernel.

Blocking a thread results in that thread becoming de-scheduled, placed in the blocking object's own private list of threads which are waiting on the object.

Unblocking a thread results in the reverse: The thread is moved back to its original location from the blocking list.

The only difference between a blocking object based on this class is the logic used to determine what consitutes a Block or Unblock condition.

10.6 Blocking Objects 57

For instance, a semaphore Pend operation may result in a call to the Block() method with the currently-executing thread in order to make that thread wait for a semaphore Post. That operation would then invoke the UnBlock() method, removing the blocking thread from the semaphore's list, and back into the appropriate thread inside the scheduler.

Care must be taken when implementing blocking objects to ensure that critical sections are used judiciously, otherwise asynchronous events like timers and interrupts could result in non-deterministic and often catastrophic behavior

Mark3 implements a variety of blocking objects including semaphores, mutexes, event flags, and IPC mechanisms that all inherit from the basic Blocking-object class found in blocking.h/cpp, ensuring consistency and a high degree of code-reuse between components.

10.6.1 Semaphores

Semaphores are used to synchronized execution of threads based on the availability (and quantity) of application-specific resources in the system. They are extremely useful for solving producer-consumer problems, and are the method-of-choice for creating efficient, low latency systems, where ISRs post semaphores that are handled from within the context of individual threads. Semaphores can also be posted (but not pended) from within the interrupt context.

10.6.2 Mutex

Mutexes (Mutual exclusion objects) are provided as a means of creating "protected sections" around a particular resource, allowing for access of these objects to be serialized. Only one thread can hold the mutex at a time

• other threads have to wait until the region is released by the owner thread before they can take their turn operating on the protected resource. Note that mutexes can only be owned by threads - they are not available to other contexts (i.e. interrupts). Calling the mutex APIs from an interrupt will cause catastrophic system failures.

Note that these objects are recursive in Mark3 - that is, the owner thread can claim a mutex more than once. The caveat here is that a recursively-held mutex will not be released until a matching "release" call is made for each "claim" call.

Priority inheritence is provided with these objects as a means to avoid priority inversions. Whenever a thread at a priority than the mutex owner blocks on a mutex, the priority of the current thread is boosted to the highest-priority waiter to ensure that other tasks at intermediate priorities cannot artificically prevent progress from being made.

10.6.3 Event Flags

Event Flags are another synchronization object, conceptually similar to a semaphore.

Unlike a semaphore, however, the condition on which threads are unblocked is determined by a more complex set of rules. Each Event Flag object contains a 16-bit field, and threads block, waiting for combinations of bits within this field to become set.

A thread can wait on any pattern of bits from this field to be set, and any number of threads can wait on any number of different patterns. Threads can wait on a single bit, multiple bits, or bits from within a subset of bits within the field.

As a result, setting a single value in the flag can result in any number of threads becoming unblocked simultaneously. This mechanism is extremely powerful, allowing for all sorts of complex, yet efficient, thread synchronization schemes that can be created using a single shared object.

Note that Event Flags can be set from interrupts, but you cannot wait on an event flag from within an interrupt.

10.6.4 Notification Objects

Notification objects are the most lightweight of all blocking objects supplied by Mark3.

using this blocking primative, one or more threads wait for the notification object to be signalled by code elsewhere in the system (i.e. another thread or interrupt). Once the notification has been signalled, all threads currently blocked on the object become unblocked and moved into the ready list.

Signalling a notification object that has no actively-waiting threads has no effect.

10.7 Messages and Global Message Queue

10.7.1 Messages

Sending messages between threads is the key means of synchronizing access to data, and the primary mechanism to perform asynchronous data processing operations.

Sending a message consists of the following operations:

- · Obtain a Message object from the global message pool
- · Set the message data and event fields
- · Send the message to the destination message queue

While receiving a message consists of the following steps:

- · Wait for a messages in the destination message queue
- · Process the message data
- Return the message back to the global message pool

These operations, and the various data objects involved are discussed in more detail in the following section.

10.7.2 Message Objects

Message objects are used to communicate arbitrary data between threads in a safe and synchronous way.

The message object consists of an event code field and a data field. The event code is used to provide context to the message object, while the data field (essentially a void * data pointer) is used to provide a payload of data corresponding to the particular event.

Access to these fields is marshalled by accessors - the transmitting thread uses the SetData() and SetCode() methods to seed the data, while the receiving thread uses the GetData() and GetCode() methods to retrieve it.

By providing the data as a void data pointer instead of a fixed-size message, we achieve an unprecedented measure of simplicity and flexibility. Data can be either statically or dynamically allocated, and sized appropriately for the event without having to format and reformat data by both sending and receiving threads. The choices here are left to the user - and the kernel doesn't get in the way of efficiency.

It is worth noting that you can send messages to message queues from within ISR context. This helps maintain consistency, since the same APIs can be used to provide event-driven programming facilities throughout the whole of the OS.

10.7.3 Global Message Pool

To maintain efficiency in the messaging system (and to prevent over-allocation of data), a global pool of message objects is provided. The size of this message pool is specified in the implementation, and can be adjusted depending on the requirements of the target application as a compile-time option.

Allocating a message from the message pool is as simple as calling the

GlobalMessagePool::Pop() Method.

Messages are returned back to the GlobalMessagePool::Push() method once the message contents are no longer required.

One must be careful to ensure that discarded messages always are returned to the pool, otherwise a resource leak will occur, which may cripple the operating system's ability to pass data between threads.

10.7.4 Message Queues

Message objects specify data with context, but do not specify where the messages will be sent. For this purpose we have a MessageQueue object. Sending an object to a message queue involves calling the MessageQueue::Send() method, passing in a pointer to the Message object as an argument.

When a message is sent to the queue, the first thread blocked on the queue (as a result of calling the Message ← Queue Receive() method) will wake up, with a pointer to the Message object returned.

It's worth noting that multiple threads can block on the same message queue, providing a means for multiple threads to share work in parallel.

10.7.5 Mailboxes

Another form of IPC is provided by Mark3, in the form of Mailboxes and Envelopes. Mailboxes are similar to message queues in that they provide a synchronized interface by which data can be transmitted between threads.

Where Message Queues rely on linked lists of lightweight message objects (containing only message code and a void* data-pointer), which are inherently abstract, Mailboxes use a dedicated blob of memory, which is carved up into fixed-size chunks called Envelopes (defined by the user), which are sent and received. Unlike message queues, mailbox data is copied to and from the mailboxes dedicated pool.

Mailboxes also differ in that they provide not only a blocking "receive" call, but also a blocking "send" call, providing the opportunity for threads to block on "mailbox full" as well as "mailbox empty" conditions.

All send/receive APIs support an optional timeout parameter if the KERNEL_USE_TIMEOUTS option has been configured in mark3cfg.h

10.7.6 Atomic Operations




Figure 10.7 Atomic operations

This utility class provides primatives for atomic operations - that is, operations that are guaranteed to execute uninterrupted. Basic atomic primatives provided here include Set/Add/Delete for 8, 16, and 32-bit integer types, as well as an atomic test-and-set.

10.7.7 Atomic Operations

10.7.8 Drivers




Figure 10.8 Drivers

This is the basis of the driver framework. In the context of Mark3, drivers don't necessarily have to be based on physical hardware peripherals. They can be used to represent algorithms (such as random number generators), files, or protocol stacks. Unlike FunkOS, where driver IO is protected automatically by a mutex, we do not use this kind of protection - we leave it up to the driver implementor to do what's right in its own context. This also frees up the driver to implement all sorts of other neat stuff, like sending messages to threads associated with the driver. Drivers are implemented as character devices, with the standard array of posix-style accessor methods for reading, writing, and general driver control.

A global driver list is provided as a convenient and minimal "filesystem" structure, in which devices can be accessed by name.

Driver Design

A device driver needs to be able to perform the following operations:

- · Initialize a peripheral
- · Start/stop a peripheral
- · Handle I/O control operations
- · Perform various read/write operations

At the end of the day, that's pretty much all a device driver has to do, and all of the functionality that needs to be presented to the developer.

We abstract all device drivers using a base-class which implements the following methods:

- · Start/Open
- · Stop/Close
- Control
- Read
- Write

A basic driver framework and API can thus be implemented in five function calls - that's it! You could even reduce that further by handling the initialize, start, and stop operations inside the "control" operation.

Driver API

In C++, we can implement this as a class to abstract these event handlers, with virtual void functions in the base class overridden by the inherited objects.

To add and remove device drivers from the global table, we use the following methods:

```
void DriverList::Add( Driver *pclDriver_ );
void DriverList::Remove( Driver *pclDriver_ );
```

DriverList::Add()/Remove() takes a single argument - the pointer to the object to operate on.

Once a driver has been added to the table, drivers are opened by NAME using DriverList::FindBy Name("/dev/name"). This function returns a pointer to the specified driver if successful, or to a built in /dev/null device if the path name is invalid. After a driver is open, that pointer is used for all other driver access functions.

This abstraction is incredibly useful - any peripheral or service can be accessed through a consistent set of APIs, that make it easy to substitute implementations from one platform to another. Portability is ensured, the overhead is negligible, and it emphasizes the reuse of both driver and application code as separate entities.

Consider a system with drivers for I2C, SPI, and UART peripherals - under our driver framework, an application can initialize these peripherals and write a greeting to each using the same simple API functions for all drivers:

```
pclI2C = DriverList::FindByName("/dev/i2c");
pclUART = DriverList::FindByName("/dev/tty0");
pclSPI = DriverList::FindByName("/dev/spi");
pclI2C->Write(12, "Hello World!");
pclUART->Write(12, "Hello World!");
pclSPI->Write(12, "Hello World!");
```

10.8 Kernel Proper and Porting




Figure 10.9 Kernel Proper and Porting

The Kernel class is a static class with methods to handle the initialization and startup of the RTOS, manage errors, and provide user-hooks for fatal error handling (functions called when Kernel::Panic() conditions are encountered), or when the Idle function is run.

Internally, Kernel::Init() calls the initialization routines for various kernel objects, providing a single interface by which all RTOS-related system initialization takes place.

Kernel::Start() is called to begin running OS funcitonality, and does not return. Control of the CPU is handed over to the scheduler, and the highest-priority ready thread begins execution in the RTOS environment.

Harware Abstraction Layer

Almost all of the Mark3 kernel (and middleware) is completely platform independent, and should compile cleanly on any platform with a modern C++ compiler. However, there are a few areas within Mark3 that can only be implemented by touching hardware directly.

These interfaces generally cover four features:

- · Thread initializaiton and context-switching logic
- Software interrupt control (used to generate context switches)
- Hardware timer control (support for time-based functionlity, such as Sleep())
- Code-execution profiling timer (not necessary to port if code-profiling is not compiled into the kernel)

The hardware abstraction layer in Mark3 provides a consistent interface for each of these four features. Mark3 is ported to new target architectures by providing an implementation for all of the interfaces declared in the abstraction layer. In the following section, we will explore how this was used to port the kernel to ARM Cortex-M0.

Real-world Porting Example - Cortex M0

This section serves as a real-world example of how Mark3 can be ported to new architectures, how the Mark3 abstraction layer works, and as a practical reference for using the RTOS support functionality baked in modern $A \leftarrow RM$ Cortex-M series microcontrollers. Most of this documentation here is taken directly from the source code found in the /kernel/cpu/cm0/ ports directory, with additional annotations to explain the port in more detail. Note that a familiarity with Cortex-M series parts will go a long way to understanding the subject matter presented, especially a basic understanding of the ARM CPU registers, exception models, and OS support features (PendSV, SysTick and SVC). If you're unfamiliar with ARM architecture, pay attention to the comments more than the source itself to illustrate the concepts.

Porting Mark3 to a new architecture consists of a few basic pieces; for developers familiar with the target architecture and the porting process, it's not a tremendously onerous endeavour to get Mark3 up-and-running somewhere new. For starters, all non-portable components are completely isolated in the source-tree under:

/embedded/kernel/CPU/VARIANT/TOOLCHAIN/,

where CPU is the architecture, VARIANT is the vendor/part, and TOOLCHAIN is the compiler tool suite used to build the code.

From within the specific port folder, a developer needs only implement a few classes and headers that define the port-specific behavior of Mark3:

- KernelSWI (kernelswi.cpp/kernelswi.h) Provides a maskable software-triggered interrupt used to perform context switching.
- KernelTimer (kerneltimer.cpp/kerneltimer.h) Provides either a fixed-frequency or programmable-interval timer, which triggers an interrupt on expiry. This is used for implementing round-robin scheduling, thread-sleeps, and generic software timers.
- Profiler (kprofile.cpp/kprofile.h) Contains code for runtime code-profiling. This is optional and may be stubbed out if left unimplemented (we won't cover profiling timers here).
- ThreadPort (threadport.cpp/threadport.h) The meat-and-potatoes of the port code lives here. This class contains architecture/part-specific code used to initialize threads, implement critical-sections, perform context-switching, and start the kernel. Most of the time spent in this article focuses on the code found here.

Summarizing the above, these modules provide the following list of functionality:

```
Thread stack initialization
Kernel startup and first thread entry
Context switch and SWI
Kernel timers
Critical Sections
```

The implementation of each of these pieces will be analyzed in detail in the sections that follow.

Thread Stack Initialization

Before a thread can be used, its stack must first be initialized to its default state. This default state ensures that when the thread is scheduled for the first time and its context restored, that it will cause the CPU to jump to the user's specified entry-point function.

All of the platform independent thread setup is handled by the generic kernel code. However, since every CPU architecture has its own register set, and stacks different information as part of an interrupt/exception, we have to implement this thread setup code for each platform we want the kernel to support (Combination of Architecture + Variant + Toolchain).

In the ARM Cortex-M0 architecture, the stack frame consists of the following information:

a) Exception Stack Frame

Contains the 8 registers which the ARM Cortex-M0 CPU automatically pushes to the stack when entering an exception. The following registers are included (in stack'd order):

```
[ XPSR ] <-- Highest address in context
[ PC     ]
[ LR     ]
[ R12     ]
[ R3     ]
[ R2     ]
[ R1     ]
[ R0     ]</pre>
```

XPSR – This is the CPU's status register. We need to set this to 0x01000000 (the "T" bit), which indicates that the CPU is executing in "thumb" mode. Note that ARMv6m and ARMv7m processors only run thumb2 instructions, so an exception is liable to occur if this bit ever gets cleared.

PC – Program Counter. This should be set with the initial entry point (function pointer) for that the user wishes to start executing with this thread.

LR - The base link register. Normally, this register contains the return address of the calling function, which is where the CPU jumps when a function returns. However, our threads generally don't return (and if they do, they're placed into the stop state). As a result we can leave this as 0.

The other registers in the stack frame are generic working registers, and have no special meaning, with the exception that R0 will hold the user's argument value passed into the entrypoint.

b) Complimentary CPU Register Context

```
[ R11 ]
...
[ R4 ] <-- Lowest address in context</pre>
```

These are the other general-purpose CPU registers that need to be backed up/ restored on a context switch, but aren't stacked by default on a Cortex-M0 exception. If there were any additional hardware registers to back up, then we'd also have to include them in this part of the context as well.

As a result, these registers all need to be manually pushed to the stack on stack creation, and will need to be explicitly pushed and pop as part of a normal context switch.

With this default exception state in mind, the following code is used to initialize a thread's stack for a Cortex-M0.

```
void ThreadPort::InitStack(Thread *pclThread_)
   K_ULONG *pulStack;
   K_ULONG *pulTemp;
   K ULONG ulAddr:
   K USHORT i:
   // Get the entrypoint for the thread
   ulAddr = (K_ULONG) (pclThread_->m_pfEntryPoint);
   // Get the top-of-stack pointer for the thread
   pulStack = (K_ULONG*)pclThread_->m_pwStackTop;
    // Initialize the stack to all FF's to aid in stack depth checking
   pulTemp = (K_ULONG*)pclThread_->m_pwStack;
   for (i = 0; i < pclThread_->m_usStackSize / sizeof(K_ULONG); i++)
       pulTemp[i] = 0xFFFFFFF;
   PUSH_TO_STACK(pulStack, 0);
                                          // Apply one word of padding
   //-- Simulated Exception Stack Frame --
                                         // XSPR; set "T" bit for thumb-mode
   PUSH_TO_STACK(pulStack, 0x01000000);
   PUSH_TO_STACK(pulStack, ulAddr);
   PUSH_TO_STACK(pulStack, 0);
   PUSH_TO_STACK(pulStack, 0x12);
   PUSH_TO_STACK(pulStack, 0x3);
   PUSH_TO_STACK(pulStack, 0x2);
   PUSH_TO_STACK(pulStack, 0x1);
   //-- Simulated Manually-Stacked Registers --
   PUSH_TO_STACK(pulStack, 0x11);
   PUSH_TO_STACK(pulStack, 0x10);
   PUSH_TO_STACK (pulStack, 0x09);
   PUSH TO STACK (pulStack, 0x08);
   PUSH_TO_STACK(pulStack, 0x07);
   PUSH_TO_STACK (pulStack, 0x06);
   PUSH_TO_STACK(pulStack, 0x05);
   PUSH_TO_STACK (pulStack, 0x04);
   pulStack++;
   pclThread_->m_pwStackTop = pulStack;
```

Kernel Startup

The same general process applies to starting the kernel on an ARM Cortex-M0 as on other platforms. Here, we initialize and start the platform specific timer and software-interrupt modules, find the first thread to run, and then jump to that first thread.

Now, to perform that last step, we have two options:

1) Simulate a return from an exception manually to start the first thread, or.. 2) Use a software interrupt to trigger the first "Context Restore/Return from Interrupt"

For 1), we basically have to restore the whole stack manually, not relying on the CPU to do any of this for us. That's certainly doable, but not all Cortex parts support this (other members of the family support privileged modes, etc.). That, and the code required to do this is generally more complex due to all of the exception-state simulation. So, we will opt for the second option instead.

To implement a software to start our first thread, we will use the SVC instruction to generate an exception. From that exception, we can then restore the context from our first thread, set the CPU up to use the right "process" stack, and return-from-exception back to our first thread. We'll explore the code for that later.

But, before we can call the SVC exception, we're going to do a couple of things.

First, we're going to reset the default MSP stack pointer to its original top-of-stack value. The rationale here is that we no longer care about the data on the MSP stack, since calling the SVC instruction triggers a chain of events from which we never return. The MSP is also used by all exception-handling, so regaining a few words of stack here can be useful. We'll also enable all maskable exceptions at this point, since this code results in the kernel being started with the CPU executing the RTOS threads, at which point a user would expect interrupts to be enabled.

Note, the default stack pointer location is stored at address 0x00000000 on all ARM Cortex M0 parts. That explains the code below...

```
void ThreadPort_StartFirstThread( void )
{
    asm(
        " ldr r1, [r0] \n" // Reset the MSP to the default base address
        " msr msp, r1 \n"
        " cpsie i \n" // Enable interrupts
        " svc 0 \n" // Jump to SVC Call
        );
}
```

First Thread Entry

This handler has the job of taking the first thread object's stack, and restoring the default state data in a way that ensures that the thread starts executing when returning from the call.

We also keep in mind that there's an 8-byte offset from the beginning of the thread object to the location of the thread stack pointer. This offset is a result of the thread object inheriting from the linked-list node class, which has 8-bytes of data. This is stored first in the object, before the first element of the class, which is the "stack top" pointer.

The following assembly code shows how the SVC call is implemented in Mark3 for the purpose of starting the first thread.

```
get thread stack:
    ; Get the stack pointer for the current thread
    ldr r0, g_pstCurrent
    ldr r1, [r0]
    add r1, #8
   ldr r2, [r1]
                         : r2 contains the current stack-top
load_manually_placed_context_r11_r8:
   ; Handle the bottom 32-bytes of the stack frame
    ; Start with r11-r8, because only r0-r7 can be used
    ; with ldmia on CMO.
    add r2. #16
    ldmia r2!, {r4-r7}
    mov r11, r7
    mov r10, r6
    mov r9, r5
   mov r8, r4
set psp:
   ; Since r2 is coincidentally back to where the stack pointer should be,
    ; Set the program stack pointer such that returning from the exception handler
load_manually_placed_context_r7_r4:
    ; Get back to the bottom of the manually stacked registers and pop.
    sub r2, #32
    ldmia r2!, {r4-r7} ; Register r4-r11 are restored.
set_thread_and_privilege_modes:
    ; Also modify the control register to force use of thread mode as well
    ; For CM3 forward-compatibility, also set user mode.
    mrs r0, control
   mov r1, #0x03
    orr r0, r1
    control, r0
    ; Set up the link register such that on return, the code operates
    ; in thread mode using the PSP. To do this, we or 0x0D to the value stored
    ; in the lr by the exception hardware EXC_RETURN. Alternately, we could
    ; just force lr to be 0xFFFFFFFD (we know that's what we want from the
    ; hardware, anyway)
   mov r0, #0x0D
mov r1, lr
    orr r0, r1
   ; Return from the exception handler.
    ; The CPU will automagically unstack R0-R3, R12, PC, LR, and xPSR \,
              If all goes well, our thread will start execution at the
    : for us.
    ; entrypoint, with the us-specified argument.
    bx r0
```

68 Mark3 Kernel Architecture

On ARM Cortex parts, there's dedicated hardware that's used primarily to support RTOS (or RTOS-like) funcationlity. This functionality includes the SysTick timer, and the PendSV Exception. SysTick is used for a tick-based kernel timer, while the PendSV exception is used for performing context switches. In reality, it's a "special SVC" call that's designed to be lower-overhead, in that it isn't mux'd with a bunch of other system or application functionality.

So how do we go about actually implementing a context switch here? There are a lot of different parts involved, but it essentially comes down to 3 steps:

1) Saving the context.

```
Thread's top-of-stack value is stored, all registers are stacked. We're good to go!
```

2) Swap threads

```
We swap the Scheduler's "next" thread with the "current" thread.
```

3) Restore Context

```
This is more or less identical to what we did when restoring the first context. Some operations may be optimized for data already stored in registers.
```

The code used to implement these steps on Cortex-M0 is presented below:

```
void PendSV_Handler(void)
     // Thread_SaveContext()
" ldr r1, CURR_ \n"
" ldr r1, [r1] \n "
" mov r3, r1 \n "
" add r3, #8 \n "
     // Grab the psp and adjust it by 32 based on extra registers we're going
     // to be manually stacking. " mrs r2, psp \n " sub r2, #32 \n "
     // While we're here, store the new top-of-stack value
     " str r2, [r3] \n
     // And, while r2 is at the bottom of the stack frame, stack r7-r4
     " stmia r2!, {r4-r7} n "
     // Stack r11-r8
     " mov r7, r11 \n "
     " mov r6, r10 \n "
     " mov r5, r9 \n "
     " mov r4, r8 \n "
     " stmia r2!, {r4-r7} \n "
     // Equivalent of Thread_Swap() - performs g_pstCurrent = g_pstNext
     " ldr r1, CURR_ \n"
" ldr r0, NEXT_ \n"
" ldr r0, [r0] \n"
" str r0, [r1] \n"
     // Thread_RestoreContext()
     // Get the pointer to the next thread's stack
     " add r0, #8 \n "
" ldr r2, [r0] \n "
     // Stack pointer is in r2, start loading registers from // the "manually-stacked" set \ensuremath{\mbox{\sc loading}}
     // Start with r\bar{1}1-r8, since these can't be accessed directly.
     " add r2, #16 \n "
     " ldmia r2!, {r4-r7} \n "
" mov r11, r7 \n "
" mov r10, r6 \n "
     " mov r9, r5 \n "
     " mov r8, r4 \n "
```

```
// After subbing R2 #16 manually, and #16 through ldmia, our PSP is where it
// needs to be when we return from the exception handler
" msr psp, r2 \n "

// Pop manually-stacked R4-R7
" sub r2, #32 \n "
" ldmia r2!, {r4-r7} \n "

// Ir contains the proper EXC_RETURN value
// we're done with the exception, so return back to newly-chosen thread
" bx lr \n "
" nop \n "

// Must be 4-byte aligned.
" NEXT_: .word g_pstNext \n"
" CURR_: .word g_pstCurrent \n"
);
```

Kernel Timers

ARM Cortex-M series microcontrollers each contain a SysTick timer, which was designed to facilitate a fixed-interval RTOS timer-tick. This timer is a precise 24-bit down-count timer, run at the main CPU clock frequency, that can be programmed to trigger an exception when the timer expires. The handler for this exception can thus be used to drive software timers throughout the system on a fixed interval.

Unfortunately, this hardware is extremely simple, and does not offer the flexibility of other timer hardware commonly implemented by MCU vendors - specifically a suitable timer prescalar that can be used to generate efficient, long-counting intervals. As a result, while the "generic" port of Mark3 for Cortex-M0 leverages the common SysTick timer interface, it only supports the tick-based version of the kernel's timer (note that specific Cortex-M0 ports such as the Atmel SAMD20 do have tickless timers).

Setting up a tick-based KernelTimer class to use the SysTick timer is, however, extremely easy, as is illustrated below:

```
void KernelTimer::Start(void)
    SysTick Config(PORT SYSTEM FREO / 1000); // 1KHz fixed clock...
    NVIC_EnableIRQ(SysTick_IRQn);
In this instance, the call to SysTick_Config() generates a 1kHz system-tick
signal, and the NVIC\_EnableIRQ() call ensures that a SysTick exception is
generated for each tick. All other functions in the Cortex version of the
KernelTimer class are essentially stubbed out (see the source for more details).
Note that the functions used in this call are part of the ARM Cortex
\hbox{\tt Microcontroller Software Interface Standard (cmsis), and are supplied by all}\\
parts vendors selling Cortex hardware. This greatly simplifies the design
of our port-code, since we can be reasonably assured that these APIs will
work the same on all devices.
The handler code called when a SysTick exception occurs is basically the
same as on other platforms (such as AVR), except that we explicitly clear the
"exception pending" bit before returning. This is implemented in the
following code:
\code{.cpp}
void SysTick_Handler(void)
#if KERNEL USE TIMERS
   TimerScheduler::Process();
#endif
#if KERNEL_USE_QUANTUM
    Quantum::UpdateTimer();
#endif
    // Clear the systick interrupt pending bit.
    SCB->ICSR |= SCB_ICSR_PENDSTCLR_Msk;
```

Critical Sections

A "critical section" is a block of code whose execution cannot be interrupted by means of context switches or an interrupt. In a traditional single-core operating system, it is typically implemented as a block of code where the interrupts are disabled - this is also the approach taken by Mark3. Given that every CPU has its own means of disabling/enabling interrupts, the implementation of the critical section APIs is also non-portable.

In the Cortex-M0 port, we implement the two critical section APIs (CS_ENTER() and CS_EXIT()) as function-like macros containing inline assembly. All uses of these calls are called in pairs within a function and must take place at the same level-of-scope. Also, as nesting may occur (critical section within a critical section), this must be taken into account in the code.

In general, CS_ENTER() performs the following tasks:

```
Cache the current interrupt-enabled state within a local variable in the thread's state
Disable interrupts
```

Conversely, CS_EXIT() performs the following tasks:

```
    Read the original interrupt-enabled state from the cached value
    Restore interrupts to the original value
```

On Cortex-M series microntrollers, the PRIMASK special register contains a single status bit which can be used to enable/disable all maskable interrupts at once. This register can be read directly to examine or modify its state. For convenience, ARMv6m provides two instructions to enable/disable interrupts

 cpsid (disable interrupts) and cpsie (enable interrupts). Mark3 Implements these steps according to the following code:

Summary

In this section we have investigated how the main non-portable areas of the Mark3 RTOS are implemented on a Cortex-M0 microcontroller. Mark3 leverages all of the hardware blocks designed to enable RTOS functionality on ARM Cortex-M series microcontrollers: the SVC call provides the mechanism by which we start the kernel, the PendSV exception provides the necessary software interrupt, and the SysTick timer provides an RTOS tick. As a result, Mark3 is a perfect fit for these devices - and as a result of this approach, the same RTOS port code should work with little to no modification on all ARM Cortex-M parts.

We have discussed what functionality in the RTOS is not portable, and what interfaces must be implemented in order to complete a fully-functional port. The five specific areas which are non-portable (stack initialization, kernel startup/entry, kernel timers, context switching, and critical sections) have been discussed in detail, with the platform-specific source provided as a practical reference to ARM-specific OS features, as well as Mark3's porting infrastructure. From this example (and the accompanying source), it should be possible for an experienced developers to create a port Mark3 to other microcontroller targets.

Chapter 11

Mark3C - C-language API bindings for the Mark3 Kernel.

Mark3 now includes an optional additional library with C language bindings for all core kernel APIs, known as Mark3C.

This library alllows applications to be written in C, while still enjoying all of the benefits of the clean, modular design of the core RTOS kernel.

The C-language Mark3C APIs map directly to their Mark3 counterparts using a simple set of conventions, documented below. As a result, explicit API documentation for Mark3C is not necessary, as the functions map 1-1 to their C++ counterparts.

11.1 API Conventions

1) Static Methods:

2) Kernel Object Methods:

In short, any class instance is represented using an object handle, and is always passed into the relevant APIs as the first argument. Further, any method that returns a pointer to an object in the C++ implementation now returns a handle to that object.

3) Overloaded Methods:

a) Methods overloaded with a Timeout parameter:

b) Methods overloaded based on number of arguments:

```
<Object>.<MethodName>()
                                          Becomes
                                                      <ClassName>_<MethodName>(<ObjectHandle>)
<Object>.<MethodName>(<arg1>)
                                                      <ClassName>_<MethodName>1(<ObjectHandle>, <arg1>)
                                          Becomes
<Object>.<MethodName>(<arg1>, <arg2>)
                                          Becomes
                                                      <ClassName>_<MethodName>2(<ObjectHandle>, <arg1>, <arg2>
                                                      <ClassName>_<MethodName>(<ObjectHandle>)
<ClassName>::<MethodName>()
                                          Becomes
                                                      <ClassName>_<MethodName>1(<ObjectHandle>, <argl>)
<ClassName>::<MethodName>(<arg1>)
                                          Becomes
<ClassName>::<MethodName>(<arq1>, <arq2>) Becomes
                                                      <ClassName>_<MethodName>2(<ObjectHandle>, <arg1>, <arg2>
```

c) Methods overloaded base on parameter types:

```
<Object>.<MethodName>(<arg type_a>)
Becomes <ClassName>=<MethodName>(type_a>)(cobjectHandle>, <arg type_b>)
ClassName>::<MethodName>((carg type_a>))
Becomes <ClassName>=<MethodName>(type_b>)(cobjectHandle>, <arg type_a>)
ClassName>::<MethodName>((carg type_a>))
Becomes <ClassName>=<MethodName>(type_a>)(carg type_a>)
ClassName>=<MethodName>(type_a>)(carg type_a>)
<ClassName>=<MethodName>(type_b>)(carg type_b>)
```

d) Allocate-once memory allocation APIs

```
AutoAlloc::New<ObjectName> Becomes Alloc_<ObjectName> AutoAlloc::Allocate(uint16_t u16Size_) Becomes AutoAlloc(uint16_t u16Size_)
```

11.2 Allocating Objects

Aside from the API name translations, the object allocation scheme is the major different between Mark3C and Mark3. Instead of instantiating objects of the various kernel types, kernel objects must be declared using Declaration macros, which serve the purpose of reserving memory for the kernel object, and provide an opaque handle to that object memory. This is the case for statically-allocated objects, and objects allocated on the stack.

Example: Declaring a thread

```
#include "mark3c.h"

// Statically-allocated
DECLARE_THREAD(hMyThread1);
...

// On stack
int main(void)
{
    DECLARE_THREAD(hMyThread2);
    ...
}

Where:

hMyThread1 - is a handle to a statically-allocated thread
hMyThread2 - is a handle to a thread allocated from the main stack.
```

Alternatively, the AutoAlloc APIs can be used to dynamically allocate objects, as demonstrated in the following example.

```
void Allocate_Example(void)
{
    Thread_t hMyThread = AutoAlloc_Thread();

    Thread_Init(hMyThread, awMyStack, sizeof(awMyStack), 1, MyFunction, 0);
}
```

Note that the relevant kernel-object Init() function *must* be called prior to using any kernel object, whether or not they have been allocated statically, or dynamically.

Chapter 12

Release Notes

12.1 R7 Release

- · Re-focusing project on kernel integrating with 3rd party code instead of 1st party middleware
- · New: Refactored codebase to C++14 standard
- New: Moved non-kernel code, drivers, libs, and BSPs to separate repos from kernel
- New: Modular repository-based structure, managed via Android's Repo tool
- · New: ConditionVariable kernel API
- · New: ReaderWriterLock kernel API
- · New: Slab memory allocator
- · New: Bitmap object-allocator
- · New: AutoAlloc redirects to user-defined allocators
- New: Global new() and delete() overrides redirect to AutoAlloc APIs
- · Updated Mark3c for new APIs
- · Moved driver layer out of the kernel

12.2 R6 Release

- · New: Replace recursive-make build system with CMake and Ninja
- · New: Transitioned version control to Git from Subversion.
- · New: Socket library, implementing named "domain-socket" style IPC
- · New: State Machine framework library
- · New: Software I2C library completed, with demo app
- · New: Kernel Timer loop can optionally be run within its own thread instead of a nested interrupt
- · New: UART drivers are all now abstracted throught UartDriver base class for portability
- Experimental: Process library, allowing for the creation of resource-isolated processes
- · Removed: Bare-metal support for Atmel SAMD20 (generic port still works)
- · Cleanup all compiler warnings on atmega328p
- · Various Bugfixes and optimizations
- Various Script changes related to automating the build + release process

74 Release Notes

12.3 R5 Release

- New: Shell library for creating responsive CLIs for embedded applications (M3Shell)
- · New: Stream library for creating thread-safe buffered streams (streamer)
- New: Blocking UART implementation for AVR (drvUARTplus)
- · New: "Extended context" kernel feature, which is used to implement thread-local storage
- · New: "Extra Checks" kernel feature, which enforces safe API usage under pain of Kernel Panic
- · New: Realtime clock library
- New: Example application + bsp for the open-hardware Mark3no development board (mark3no)
- · New: Kernel objects descoped/destroyed while still in active use will now cause kernel panic
- · New: Kernel callouts for thread creation/destruction/context switching, used for time tracking
- · New: Simple power management class
- · New: WIP software-based I2C + SPI drivers
- · Optimized thread scheduling via target-optimized "count-leading-zero" macros
- · Expanded memutil library
- · Various optimizations of ARM Cortex-M assembly code
- · Various bugfixes to Timer code
- · Improved stack overflow checking + warning (stack guard kernel feature)
- · AVR bootloader now supports targets with more than 64K of flash
- Moved some port configuration out of platform.mak into header files in the kernel port code
- · The usual minor bugfixes and "gentle refactoring"

12.4 R4 Release

- · New: C-language bindings for Mark3 kernel (mark3c library)
- · New: Support for ARM Cortex-M3 and Cortex-M4 (floating point) targets
- · New: Support for Atmel AVR atmega2560 and arduino pro mega
- · New: Full-featured, lightweight heap implementation
- · New: Mailbox IPC class
- · New: Notification object class
- · New: lighweight tracelogger/instrumentation implementation (buffalogger), with sample parser
- New: High-performance AVR Software UART implementation
- New: Allocate-once "AutoAlloc" memory allocator
- · New: Fixed-time blocking/unblocking operations added to ThreadList/Blocking class
- Placement-new supported for all kernel objects
- Scheduler now supports up to 1024 levels of thread priority, up from 8 (configurable at build-time)

12.5 R3 Release 75

- Kernel now uses stdint.h types for standard integers (instead of K_CHAR, K_ULONG, etc.)
- · Greatly expanded documentation, with many new examples covering all key kernel features
- · Expanded unit test coverage on AVR
- · Updated build system and scripts for easier kernel configuration
- · Updated builds to only attempt to build tests for supported platforms

12.5 R3 Release

- · New: Added support for MSP430 microcontrollers
- · New: Added Kernel Idle-Function hook to eliminate the need for a dedicated idle-thread (where supported)
- · New: Support for kernel-aware simulation and testing via flAVR AVR simulator
- · Updated AVR driver selection
- · General bugfixes and maintenance
- · Expanded documentation and test coverage

12.6 R2

- Experimental release, using a "kernel transaction queue" for serializing kernel calls
- Works as a proof-of-concept, but abandoned due to overhead of the transaction mechanism in the general case.

12.7 R1 - 2nd Release Candidate

- · New: Added support for ARM Cortex-M0 targets
- · New: Added support for variuos AVR targets
- · New: Timers now support a "tolerance" parameter for grouping timers with close expiry times
- · Expanded scripts and auotmation used in build/test
- · Updated and expanded graphics APIs
- · Large number of bugfixes

12.8 R1 - 1st Release Candidate

· Initial release, with support for AVR microcontrollers

76 Release Notes

Chapter 13

Code Size Profiling

The following report details the size of each module compiled into the kernel.

The size of each component is dependent on the flags specified in mark3cfg.h at compile time. Note that these sizes represent the maximum size of each module before dead code elimination and any additional link-time optimization, and represent the maximum possible size that any module can take.

The results below are for profiling on ARM Cortex-M3 qemu_lm3s6965evb-based targets using gcc. Results are not necessarily indicative of relative or absolute performance on other platforms or toolchains.

13.1 Information

Date Profiled: Mon Jul 2 20:49:30 EDT 2018

13.2 Compiler Version

arm-none-eabi-gcc (15:6.3.1+svn253039-1build1) 6.3.1 20170620 Copyright (C) 2016 Free Software Foundation, Inc. This is free software; see the source for copying conditions. There is NO warranty; not even for MERCHANT ← ABILITY or FITNESS FOR A PARTICULAR PURPOSE.

13.3 Profiling Results

Mark3 Module Size Report:

78 Code Size Profiling

Mark3 Kernel Size Summary:

```
- Kernel : 2332 Bytes
- Synchronization Objects : 1950 Bytes
- Port : 1915 Bytes
- Features : 2065 Bytes
- Total Size : 8262 Bytes
```

Chapter 14

Namespace Index

14.1 Namespace List

Here is a list of all documented namespaces with brief descriptions:

Mark3	
Class providing the software-interrupt required for context-switching in the kernel	89
Mark3::Atomic	
The Atomic class	92
Mark3::KernelAware	
The KernelAware class	94

80 Namespace Index

Chapter 15

Hierarchical Index

15.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

Mark3::BlockingObject
Mark3::EventFlag
Mark3::Mutex
Mark3::Notify
Mark3::Semaphore
Mark3::ConditionVariable
Mark3::FakeThread_t
Mark3::Kernel
Mark3::KernelTimer
Mark3::LinkList
Mark3::CircularLinkList
Mark3::ThreadList
Mark3::DoubleLinkList
Mark3::TimerList
Mark3::LinkListNode
Mark3::Message
Mark3::Thread
Mark3::Timer
Mark3::LockGuard
Mark3::Mailbox
Mark3::MessagePool
Mark3::MessageQueue
Mark3::PriorityMap
Mark3::ProfileTimer
Mark3::Quantum
Mark3::ReaderWriterLock
Mark3::Scheduler
Mark3::ThreadPort
Mark3::TimerScheduler

82 Hierarchical Index

Chapter 16

Class Index

16.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

Mark3::BlockingObject	
Class implementing thread-blocking primatives	99
Mark3::CircularLinkList	
Circular-linked-list data type, inherited from the base LinkList type	102
Mark3::ConditionVariable	
The Condition Variable class This class implements a condition variable	104
Mark3::DoubleLinkList	
Doubly-linked-list data type, inherited from the base LinkList type	106
Mark3::EventFlag	
Blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system	108
Mark3::FakeThread_t	
If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system	113
Mark3::Kernel	
Class that encapsulates all of the kernel startup functions	114
Mark3::KernelTimer	
Hardware timer interface, used by all scheduling/timer subsystems	120
Mark3::LinkList	
Abstract-data-type from which all other linked-lists are derived	125
Mark3::LinkListNode	
Basic linked-list node data structure	127
Mark3::LockGuard	129
Mark3::Mailbox	
Implements an IPC mechnism based on envelopes containing data of a fixed size (configured at	
initialization) that reside within a buffer of memory provided by the user	130
Mark3::Message	
Class to provide message-based IPC services in the kernel	140
Mark3::MessagePool	
Implements a list of message objects	143
Mark3::MessageQueue	
List of messages, used as the channel for sending and receiving messages between threads .	145
Mark3::Mutex	
Mutual-exclusion locks, based on BlockingObject	148

84 Class Index

Mark3::Notify	
Blocking object type, that allows one or more threads to wait for an event to occur before resuming operation	152
Mark3::PriorityMap	
The PriorityMap class	154
Mark3::ProfileTimer	
Profiling timer	156
Mark3::Quantum	
Static-class used to implement Thread quantum functionality, which is a key part of round-robin	
scheduling	159
Mark3::ReaderWriterLock	
The ReaderWriterLock class This class implements an object that marshalls access to a resource	
based on the intended usage of the resource	161
Mark3::Scheduler	
Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping	164
Mark3::Semaphore	
Binary & Counting semaphores, based on BlockingObject base class	170
Mark3::Thread	
Object providing fundamental multitasking support in the kernel	174
Mark3::ThreadList	
This class is used for building thread-management facilities, such as schedulers, and blocking objects	190
Mark3::ThreadPort	
Class defining the architecture specific functions required by the kernel	194
Mark3::Timer	
Kernel-managed software timers	196
Mark3::TimerList	
TimerList class - a doubly-linked-list of timer objects	204
Mark3::TimerScheduler	
"Static" Class used to interface a global Timerl ist with the rest of the kernel	206

Chapter 17

File Index

17.1 File List

Here is a list of all documented files with brief descriptions:

/home/moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/ mark3c.cpp	??
C-struct definitions that mirror	209
/home/moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/public/mark3c.h	200
Implementation of C-language wrappers for the Mark3 kernel	212
/home/moslevin/projects/github/m3-repo/kernel/src/atomic.cpp	212
Basic Atomic Operations	247
/home/moslevin/projects/github/m3-repo/kernel/src/autoalloc.cpp	241
Automatic memory allocation for kernel objects	249
/home/moslevin/projects/github/m3-repo/kernel/src/blocking.cpp	240
Implementation of base class for blocking objects	253
/home/moslevin/projects/github/m3-repo/kernel/src/condvar.cpp	200
Condition Variable implementation	255
/home/moslevin/projects/github/m3-repo/kernel/src/eventflag.cpp	233
Event Flag Blocking Object/IPC-Object implementation	256
/home/moslevin/projects/github/m3-repo/kernel/src/kernel.cpp	230
Kernel initialization and startup code	261
/home/moslevin/projects/github/m3-repo/kernel/src/kernelaware.cpp	201
Kernel aware simulation support	263
/home/moslevin/projects/github/m3-repo/kernel/src/ksemaphore.cpp	200
Semaphore Blocking-Object Implemenation	265
/home/moslevin/projects/github/m3-repo/kernel/src/ll.cpp	200
Core Linked-List implementation, from which all kernel objects are derived	269
/home/moslevin/projects/github/m3-repo/kernel/src/lockguard.cpp	203
Mutex RAII helper class	271
/home/moslevin/projects/github/m3-repo/kernel/src/mailbox.cpp	2/1
Mailbox + Envelope IPC mechanism	272
/home/moslevin/projects/github/m3-repo/kernel/src/message.cpp	212
	276
	2/0
/home/moslevin/projects/github/m3-repo/kernel/src/mutex.cpp	278
Mutual-exclusion object	2/0
/home/moslevin/projects/github/m3-repo/kernel/src/notify.cpp	000
Lightweight thread notification - blocking object	282
/home/moslevin/projects/github/m3-repo/kernel/src/priomap.cpp	005
Priority map data structure	285

86 File Index

/home/moslevin/projects/github/m3-repo/kernel/src/profile.cpp	
Code profiling utilities	287
/home/moslevin/projects/github/m3-repo/kernel/src/quantum.cpp	
Thread Quantum Implementation for Round-Robin Scheduling	353
/home/moslevin/projects/github/m3-repo/kernel/src/readerwriter.cpp	
Reader-writer lock implementation	355
/home/moslevin/projects/github/m3-repo/kernel/src/scheduler.cpp	
Strict-Priority + Round-Robin thread scheduler implementation	357
/home/moslevin/projects/github/m3-repo/kernel/src/thread.cpp	
Platform-Independent thread class Definition	359
/home/moslevin/projects/github/m3-repo/kernel/src/threadlist.cpp	
Thread linked-list definitions	366
/home/moslevin/projects/github/m3-repo/kernel/src/timer.cpp	
Timer implementations	368
/home/moslevin/projects/github/m3-repo/kernel/src/timerlist.cpp	
Implements timer list processing algorithms, responsible for all timer tick and expiry logic	371
/home/moslevin/projects/github/m3-repo/kernel/src/tracebuffer.cpp	
Kernel trace buffer class definition	375
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kernelprofile.cpp	
ATMega328p Profiling timer implementation	228
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kernelswi.cpp	
Kernel Software interrupt implementation for ATMega328p	230
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kerneltimer.cpp	004
Kernel Timer Implementation for ATMega328p	231
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/threadport.cpp	
ATMega1284p Multithreading	244
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kernelprofile.h	004
Profiling timer hardware interface	234
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kernelswi.h	005
Kernel Software interrupt declarations	235
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kerneltimer.h	000
Kernel Timer Class declaration	236
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/portcfg.h	007
	237
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/threadport.h ATMega328p Multithreading support	240
	240
/home/moslevin/projects/github/m3-repo/kernel/src/public/atomic.h Basic Atomic Operations	289
/home/moslevin/projects/github/m3-repo/kernel/src/public/autoalloc.h	209
Automatic memory allocation for kernel objects	290
/home/moslevin/projects/github/m3-repo/kernel/src/public/blocking.h	230
Blocking object base class declarations	293
/home/moslevin/projects/github/m3-repo/kernel/src/public/buffalogger.h	200
Super-efficient, super-secure logging routines	294
/home/moslevin/projects/github/m3-repo/kernel/src/public/condvar.h	204
Condition Variable implementation	295
/home/moslevin/projects/github/m3-repo/kernel/src/public/ dbg_file_list.h	??
/home/moslevin/projects/github/m3-repo/kernel/src/public/eventflag.h	• • •
Event Flag Blocking Object/IPC-Object definition	296
/home/moslevin/projects/github/m3-repo/kernel/src/public/kernel.h	
Kernel initialization and startup class	298
/home/moslevin/projects/github/m3-repo/kernel/src/public/kernelaware.h	
Kernel aware simulation support	299
/home/moslevin/projects/github/m3-repo/kernel/src/public/kerneldebug.h	
Macros and functions used for assertions, kernel traces, etc	301
/home/moslevin/projects/github/m3-repo/kernel/src/public/kerneltypes.h	
Basic data type primatives used throughout the OS	307

17.1 File List 87

/home/moslevin/projects/github/m3-repo/kernel/src/public/ksemaphore.h	
Semaphore Blocking Object class declarations	309
/home/moslevin/projects/github/m3-repo/kernel/src/public/ll.h	
Core linked-list declarations, used by all kernel list types	310
/home/moslevin/projects/github/m3-repo/kernel/src/public/lockguard.h	
Mutex RAII helper class	312
/home/moslevin/projects/github/m3-repo/kernel/src/public/mailbox.h	
Mailbox + Envelope IPC Mechanism	313
/home/moslevin/projects/github/m3-repo/kernel/src/public/manual.h	
/brief Ascii-format documentation, used by doxygen to create various printable and viewable	
forms	316
/home/moslevin/projects/github/m3-repo/kernel/src/public/mark3.h	
Single include file given to users of the Mark3 Kernel API	316
/home/moslevin/projects/github/m3-repo/kernel/src/public/mark3cfg.h	
Mark3 Kernel Configuration	318
/home/moslevin/projects/github/m3-repo/kernel/src/public/message.h	
Inter-thread communication via message-passing	328
/home/moslevin/projects/github/m3-repo/kernel/src/public/mutex.h	
Mutual exclusion class declaration	330
/home/moslevin/projects/github/m3-repo/kernel/src/public/notify.h	
Lightweight thread notification - blocking object	332
/home/moslevin/projects/github/m3-repo/kernel/src/public/paniccodes.h	
Defines the reason codes thrown when a kernel panic occurs	334
/home/moslevin/projects/github/m3-repo/kernel/src/public/priomap.h	
Priority map data structure	334
/home/moslevin/projects/github/m3-repo/kernel/src/public/profile.h	
High-precision profiling timers	336
/home/moslevin/projects/github/m3-repo/kernel/src/public/ profiling_results.h	??
/home/moslevin/projects/github/m3-repo/kernel/src/public/quantum.h	
Thread Quantum declarations for Round-Robin Scheduling	337
/home/moslevin/projects/github/m3-repo/kernel/src/public/readerwriter.h	
Reader-Writer lock implementation	339
/home/moslevin/projects/github/m3-repo/kernel/src/public/scheduler.h	
Thread scheduler function declarations	340
/home/moslevin/projects/github/m3-repo/kernel/src/public/sizeprofile.h	??
/home/moslevin/projects/github/m3-repo/kernel/src/public/thread.h	
Platform independent thread class declarations	342
/home/moslevin/projects/github/m3-repo/kernel/src/public/threadlist.h	
Thread linked-list declarations	345
/home/moslevin/projects/github/m3-repo/kernel/src/public/timer.h	0.47
Timer object declarations	346
/home/moslevin/projects/github/m3-repo/kernel/src/public/timerlist.h	0.46
Timer list declarations	349
/home/moslevin/projects/github/m3-repo/kernel/src/public/timerscheduler.h	054
Timer scheduler declarations	351
/home/moslevin/projects/github/m3-repo/kernel/src/public/tracebuffer.h	051
Kernel trace buffer class declaration	352

88 File Index

Chapter 18

Namespace Documentation

18.1 Mark3 Namespace Reference

Class providing the software-interrupt required for context-switching in the kernel.

Namespaces

Atomic

The Atomic class.

KernelAware

The KernelAware class.

Classes

· class BlockingObject

Class implementing thread-blocking primatives.

class CircularLinkList

Circular-linked-list data type, inherited from the base LinkList type.

· class ConditionVariable

The ConditionVariable class This class implements a condition variable.

class DoubleLinkList

Doubly-linked-list data type, inherited from the base LinkList type.

· class EventFlag

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

struct FakeThread_t

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

· class Kernel

Class that encapsulates all of the kernel startup functions.

class KernelTimer

Hardware timer interface, used by all scheduling/timer subsystems.

class LinkList

Abstract-data-type from which all other linked-lists are derived.

· class LinkListNode

Basic linked-list node data structure.

- class LockGuard
- class Mailbox

The Mailbox class implements an IPC mechnism based on envelopes containing data of a fixed size (configured at initialization) that reside within a buffer of memory provided by the user.

class Message

Class to provide message-based IPC services in the kernel.

class MessagePool

Implements a list of message objects.

• class MessageQueue

List of messages, used as the channel for sending and receiving messages between threads.

class Mutex

Mutual-exclusion locks, based on BlockingObject.

class Notify

The Notify class is a blocking object type, that allows one or more threads to wait for an event to occur before resuming operation.

class PriorityMap

The PriorityMap class.

class ProfileTimer

Profiling timer.

· class Quantum

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

class ReaderWriterLock

The ReaderWriterLock class This class implements an object that marshalls access to a resource based on the intended usage of the resource.

· class Scheduler

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

class Semaphore

Binary & Counting semaphores, based on BlockingObject base class.

· class Thread

Object providing fundamental multitasking support in the kernel.

class ThreadList

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

· class ThreadPort

Class defining the architecture specific functions required by the kernel.

class Timer

Kernel-managed software timers.

class TimerList

TimerList class - a doubly-linked-list of timer objects.

• class TimerScheduler

"Static" Class used to interface a global TimerList with the rest of the kernel.

Typedefs

using PanicFunc = void(*)(uint16_t u16PanicCode_)

Function pointer type used to implement kernel-panic handlers.

using IdleFunc = void(*)()

Function pointer type used to implement the idle function, where support for an idle function (as opposed to an idle thread) exists.

using ThreadEntryFunc = void(*)(void *pvArg_)

Function pointer type used for thread entrypoint functions.

using TimerCallback = void(*)(Thread *pclOwner_, void *pvData_)

This type defines the callback function type for timer events.

Enumerations

enum EventFlagOperation::uint8_t {
 EventFlagOperation::All_Set = 0, EventFlagOperation::Any_Set, EventFlagOperation::All_Clear, EventFlag
 Operation::Any_Clear,
 EventFlagOperation::Pending_Unblock }

This enumeration describes the different operations supported by the event flag blocking object.

• enum ThreadState: uint8 t

Enumeration representing the different states a thread can exist in.

Functions

 ISR (INT2_vect) __attribute__((signal ISR(INT2_vect) SWI using INT2 - used to trigger a context switch.

18.1.1 Detailed Description

Class providing the software-interrupt required for context-switching in the kernel.

18.1.2 Typedef Documentation

18.1.2.1 TimerCallback

```
using Mark3::TimerCallback = typedef void (*) (Thread* pclOwner_, void* pvData_)
```

This type defines the callback function type for timer events.

Since these are called from an interrupt context, they do not operate from within a thread or object context directly – as a result, the context must be manually passed into the calls.

pclOwner_ is a pointer to the thread that owns the timer pvData_ is a pointer to some data or object that needs to know about the timer's expiry from within the timer interrupt context.

Definition at line 94 of file timer.h.

18.1.3 Enumeration Type Documentation

18.1.3.1 EventFlagOperation

```
enum Mark3::EventFlagOperation : uint8_t [strong]
```

This enumeration describes the different operations supported by the event flag blocking object.

Enumerator

All_Set	Block until all bits in the specified bitmask are set.
Any_Set	Block until any bits in the specified bitmask are set.
All_Clear	Block until all bits in the specified bitmask are cleared.
Any_Clear	Block until any bits in the specified bitmask are cleared.
Pending_Unblock	Special code. Not used by user

Definition at line 50 of file kerneltypes.h.

18.2 Mark3::Atomic Namespace Reference

The Atomic class.

Functions

```
    uint8_t Set (uint8_t *pu8Source_, uint8_t u8Val_)
    Set Set a variable to a given value in an uninterruptable operation.
```

uint8_t Add (uint8_t *pu8Source_, uint8_t u8Val_)

Add Add a value to a variable in an uninterruptable operation.

• uint8_t Sub (uint8_t *pu8Source_, uint8_t u8Val_)

Sub Subtract a value from a variable in an uninterruptable operation.

bool TestAndSet (bool *pbLock)

TestAndSet Test to see if a variable is set, and set it if is not already set.

18.2.1 Detailed Description

The Atomic class.

This utility class provides primatives for atomic operations - that is, operations that are guaranteed to execute uninterrupted. Basic atomic primatives provided here include Set/Add/Delete for 8, 16, and 32-bit integer types, as well as an atomic test-and-set.

18.2.2 Function Documentation

18.2.2.1 Add()

Add Add a value to a variable in an uninterruptable operation.

Parameters

pu8←	Pointer to a variable
Source_	
u8Val_	Value to add to the variable

Returns

Previously-held value in pu8Source_

18.2.2.2 Set()

Set Set a variable to a given value in an uninterruptable operation.

Parameters

pu8← Source_	Pointer to a variable to set the value of
u8Val_	New value to set in the variable

Returns

Previously-set value

18.2.2.3 Sub()

Sub Subtract a value from a variable in an uninterruptable operation.

Parameters

pu8⇔	Pointer to a variable
Source_	Malua da audatua at fua un de a conside la
u8Val_	Value to subtract from the variable

Returns

Previously-held value in pu8Source_

18.2.2.4 TestAndSet()

TestAndSet Test to see if a variable is set, and set it if is not already set.

This is an uninterruptable operation.

```
If the value is false, set the variable to true, and return the previously-held value.

If the value is already true, return true.
```

Parameters

pbLock

Pointer to a value to test against. This will always be set to "true" at the end of a call to TestAndSet.

Returns

true - Lock value was "true" on entry, false - Lock was set

18.3 Mark3::KernelAware Namespace Reference

The KernelAware class.

Functions

```
    void ProfileInit (const char *szStr )
```

ProfileInit.

void ProfileStart (void)

ProfileStart.

void ProfileStop (void)

ProfileStop.

void ProfileReport (void)

ProfileReport.

• void ExitSimulator (void)

ExitSimulator.

• void Print (const char *szStr_)

Print

void Trace (uint16_t u16File_, uint16_t u16Line_)

Trace.

```
    void Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_)
        Trace.
    void Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_)
        Trace.
    bool IsSimulatorAware (void)
```

18.3.1 Detailed Description

IsSimulatorAware.

The KernelAware class.

This class contains functions that are used to trigger kernel-aware functionality within a supported simulation environment (i.e. flAVR).

These static methods operate on a singleton set of global variables, which are monitored for changes from within the simulator. The simulator hooks into these variables by looking for the correctly-named symbols in an elf-formatted binary being run and registering callbacks that are called whenever the variables are changed. On each change of the command variable, the kernel-aware data is analyzed and interpreted appropriately.

If these methods are run in an unsupported simulator or on actual hardware the commands generally have no effect (except for the exit-on-reset command, which will result in a jump-to-0 reset).

18.3.2 Function Documentation

18.3.2.1 ExitSimulator()

ExitSimulator.

Instruct the kernel-aware simulator to terminate (destroying the virtual CPU).

18.3.2.2 IsSimulatorAware()

IsSimulatorAware.

use this function to determine whether or not the code is running on a simulator that is aware of the kernel.

Returns

true - the application is being run in a kernel-aware simulator. false - otherwise.

18.3.2.3 Print()

Print.

Instruct the kernel-aware simulator to print a char string

Parameters

```
sz⊷
Str_
```

Examples:

lab10_notifications/main.cpp, lab11_mailboxes/main.cpp, lab1_kernel_setup/main.cpp, lab2_idle_← function/main.cpp, lab3_round_robin/main.cpp, lab4_semaphores/main.cpp, lab5_mutexes/main.cpp, lab6← __timers/main.cpp, lab7_events/main.cpp, lab8_messages/main.cpp, and lab9_dynamic_threads/main.cpp.

18.3.2.4 ProfileInit()

ProfileInit.

Initializes the kernel-aware profiler. This function instructs the kernel-aware simulator to reset its accounting variables, and prepare to start counting profiling data tagged to the given string. How this is handled is the responsibility of the simulator.

Parameters

<i>SZ</i> ⇔	String to use as a tag for the profilng session.
Str_	

18.3.2.5 ProfileReport()

ProfileReport.

Instruct the kernel-aware simulator to print a report for its current profiling data.

18.3.2.6 ProfileStart()

ProfileStart.

Instruct the kernel-aware simulator to begin counting cycles towards the current profiling counter.

18.3.2.7 ProfileStop()

ProfileStop.

Instruct the kernel-aware simulator to end counting cycles relative to the current profiling counter's iteration.

Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

Parameters

u16⊷ File	16-bit code representing the file
u16↔ Line	16-bit code representing the line in the file

Examples:

lab11_mailboxes/main.cpp, lab8_messages/main.cpp, and lab9_dynamic_threads/main.cpp.

18.3.2.9 Trace() [2/3]

Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

Parameters

u16File⊷	16-bit code representing the file
_	
u16⇔	16-bit code representing the line in the file
Line_	
u16⇔	16-bit argument to the format string.
Arg1	_

18.3.2.10 Trace() [3/3]

Trace.

Insert a kernel trace statement into the kernel-aware simulator's debug data stream.

Parameters

u16File←	16-bit code representing the file
_	
u16⇔	16-bit code representing the line in the file
Line_	
<i>u</i> 16⇔	16-bit argument to the format string.
Arg1_	
<i>u</i> 16⇔	16-bit argument to the format string.
Arg2_	

Chapter 19


Class Documentation

19.1 Mark3::BlockingObject Class Reference

Class implementing thread-blocking primatives.

#include <blocking.h>

Inheritance diagram for Mark3::BlockingObject:



Protected Member Functions

void Block (Thread *pclThread_)

Block.

void BlockPriority (Thread *pclThread_)

BlockPriority.

void UnBlock (Thread *pclThread_)

UnBlock.

void SetInitialized (void)

SetInitialized.

• bool IsInitialized (void)

IsInitialized.

Protected Attributes

• ThreadList m_clBlockList

ThreadList which is used to hold the list of threads blocked on a given object.

• uint8_t m_u8Initialized

Token used to check whether or not the object has been initialized prior to use.

19.1.1 Detailed Description

Class implementing thread-blocking primatives.

used for implementing things like semaphores, mutexes, message queues, or anything else that could cause a thread to suspend execution on some external stimulus.

Definition at line 69 of file blocking.h.

19.1.2 Member Function Documentation

```
19.1.2.1 Block()
```

Block.

Blocks a thread on this object. This is the fundamental operation performed by any sort of blocking operation in the operating system. All semaphores/mutexes/sleeping/messaging/etc ends up going through the blocking code at some point as part of the code that manages a transition from an "active" or "waiting" thread to a "blocked" thread.

The steps involved in blocking a thread (which are performed in the function itself) are as follows;

1) Remove the specified thread from the current owner's list (which is likely one of the scheduler's thread lists) 2) Add the thread to this object's thread list 3) Setting the thread's "current thread-list" point to reference this object's threadlist.

Parameters

pcl⇔	Pointer to the thread object that will be blocked.
Thread_	

Definition at line 42 of file blocking.cpp.

19.1.2.2 BlockPriority()

BlockPriority.

Same as Block(), but ensures that threads are added to the block-list in priority-order, which optimizes the unblock procedure.

Parameters

pcl←	Pointer to the Thread to Block.
Thread_	

Definition at line 58 of file blocking.cpp.

19.1.2.3 IsInitialized()

IsInitialized.

Returns

Definition at line 145 of file blocking.h.

19.1.2.4 UnBlock()

UnBlock.

Unblock a thread that is already blocked on this object, returning it to the "ready" state by performing the following steps:

Parameters

pcl←	Pointer to the thread to unblock.
Thread	

1) Removing the thread from this object's threadlist 2) Restoring the thread to its "original" owner's list

Definition at line 74 of file blocking.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/github/m3-repo/kernel/src/public/blocking.h
- /home/moslevin/projects/github/m3-repo/kernel/src/blocking.cpp

19.2 Mark3::CircularLinkList Class Reference

Circular-linked-list data type, inherited from the base LinkList type.

```
#include <11.h>
```

Inheritance diagram for Mark3::CircularLinkList:



Public Member Functions

void Add (LinkListNode *node_)

Add the linked list node to this linked list.

void Remove (LinkListNode *node_)

Remove.

void PivotForward ()

PivotForward.

void PivotBackward ()

PivotBackward.

void InsertNodeBefore (LinkListNode *node_, LinkListNode *insert_)
 InsertNodeBefore.

Additional Inherited Members

19.2.1 Detailed Description

Circular-linked-list data type, inherited from the base LinkList type.

Definition at line 182 of file II.h.

19.2.2 Member Function Documentation

```
19.2.2.1 Add()
```

Add the linked list node to this linked list.

Parameters

node↩	Pointer to the node to add
_	

Definition at line 100 of file II.cpp.

19.2.2.2 InsertNodeBefore()

InsertNodeBefore.

Insert a linked-list node into the list before the specified insertion point.

Parameters

node⊷	Node to insert into the list
_ insert←	Insert point.
_	

Definition at line 174 of file II.cpp.

19.2.2.3 PivotBackward()

```
void Mark3::CircularLinkList::PivotBackward ( )
```

PivotBackward.

Pivot the head of the circularly linked list backward (Head = Head->prev, Tail = Tail->prev)

Definition at line 165 of file II.cpp.

19.2.2.4 PivotForward()

```
void Mark3::CircularLinkList::PivotForward ( )
```

PivotForward.

Pivot the head of the circularly linked list forward (Head = Head->next, Tail = Tail->next)

Definition at line 156 of file II.cpp.

19.2.2.5 Remove()

Remove.

Add the linked list node to this linked list

Parameters

node⊷	Pointer to the node to remove

Definition at line 122 of file II.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/github/m3-repo/kernel/src/public/ll.h
- /home/moslevin/projects/github/m3-repo/kernel/src/II.cpp

19.3 Mark3::ConditionVariable Class Reference

The Condition Variable class This class implements a condition variable.

```
#include <condvar.h>
```

Public Member Functions

· void Init ()

Init Initialize the condition variable prior to use.

void Wait (Mutex *pclMutex)

Wait Block the current thread, and wait for the object to be signalled.

• bool Wait (Mutex *pclMutex_, uint32_t u32WaitTimeMS_)

Wait Block the current thread, and wait for the object to be signalled.

• void Signal ()

Signal Signal/Unblock the next thread currently blocked on this condition variable.

· void Broadcast ()

Broadcast Unblock all threads currently blocked on this condition variable.

19.3.1 Detailed Description

The Condition Variable class This class implements a condition variable.

This is a synchronization object that allows multiple threads to block, each waiting for specific signals unique to them. Access to the specified condition is guarded by a mutex that is supplied by the caller. This object can permit multiple waiters that can be unblocked one-at-a-time via signalling, or unblocked all at once via broadcasting. This object is built upon lower-level primatives, and is somewhat more heavyweight than the primative types supplied by the kernel.

Definition at line 38 of file condvar.h.

19.3.2 Member Function Documentation

19.3.2.1 Init()

Init Initialize the condition variable prior to use.

Must be called before the object can be used

Definition at line 38 of file condvar.cpp.

Wait Block the current thread, and wait for the object to be signalled.

The specified mutex will be locked when the thread returns.

Parameters

pcl←	Mutex to claim once the calling thread has access to the condvar
Mutex_	

Definition at line 46 of file condvar.cpp.

Wait Block the current thread, and wait for the object to be signalled.

The specified mutex will be locked when the thread returns.

Parameters

pclMutex_	Mutex to claim once the calling thread has access to the condvar
u32WaitTimeM⊷	Maximum time in ms to wait before abandoning the operation
S_	

Returns

true on success, false on timeout

The documentation for this class was generated from the following files:


- /home/moslevin/projects/github/m3-repo/kernel/src/public/condvar.h
- /home/moslevin/projects/github/m3-repo/kernel/src/condvar.cpp

19.4 Mark3::DoubleLinkList Class Reference

Doubly-linked-list data type, inherited from the base LinkList type.

```
#include <ll.h>
```

Inheritance diagram for Mark3::DoubleLinkList:



Public Member Functions

- DoubleLinkList ()
 - DoubleLinkList.
- void Add (LinkListNode *node_)

Ada

• void Remove (LinkListNode *node_)

Remove.

Additional Inherited Members

19.4.1 Detailed Description

Doubly-linked-list data type, inherited from the base LinkList type.

Definition at line 144 of file II.h.

19.4.2 Constructor & Destructor Documentation

19.4.2.1 DoubleLinkList()

```
Mark3::DoubleLinkList::DoubleLinkList ( ) [inline]
```

DoubleLinkList.

Default constructor - initializes the head/tail nodes to NULL

Definition at line 153 of file II.h.

19.4.3 Member Function Documentation

19.4.3.1 Add()

Add.

Add the linked list node to this linked list

Parameters

node⊷	Pointer to the node to add
_	

Definition at line 49 of file II.cpp.

19.4.3.2 Remove()

Remove.

Add the linked list node to this linked list

Parameters

node⊷	Pointer to the node to remove

Definition at line 70 of file II.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/github/m3-repo/kernel/src/public/II.h
- /home/moslevin/projects/github/m3-repo/kernel/src/ll.cpp

19.5 Mark3::EventFlag Class Reference

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

```
#include <eventflag.h>
```

Inheritance diagram for Mark3::EventFlag:



Public Member Functions

• void Init ()

Init Initializes the EventFlag object prior to use.

uint16_t Wait (uint16_t u16Mask_, EventFlagOperation eMode_)

Wait - Block a thread on the specific flags in this event flag group.

• uint16_t Wait (uint16_t u16Mask_, EventFlagOperation eMode_, uint32_t u32TimeMS_)

Wait - Block a thread on the specific flags in this event flag group.

void WakeMe (Thread *pclChosenOne_)

WakeMe.

• void Set (uint16_t u16Mask_)

Set - Set additional flags in this object (logical OR).

void Clear (uint16_t u16Mask_)

ClearFlags - Clear a specific set of flags within this object, specific by bitmask.

uint16_t GetMask ()

GetMask Returns the state of the 16-bit bitmask within this object.

Private Member Functions

```
    uint16_t Wait_i (uint16_t u16Mask_, EventFlagOperation eMode_, uint32_t u32TimeMS_)
    Wait_i.
```

Private Attributes

• uint16_t m_u16SetMask

Event flags currently set in this object.

Additional Inherited Members

19.5.1 Detailed Description

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

Each EventFlag object contains a 16-bit bitmask, which is used to trigger events on associated threads. Threads wishing to block, waiting for a specific event to occur can wait on any pattern within this 16-bit bitmask to be set. Here, we provide the ability for a thread to block, waiting for ANY bits in a specified mask to be set, or for ALL bits within a specific mask to be set. Depending on how the object is configured, the bits that triggered the wakeup can be automatically cleared once a match has occurred.

Examples:

```
lab7_events/main.cpp.
```

Definition at line 45 of file eventflag.h.

19.5.2 Member Function Documentation

19.5.2.1 Clear()

ClearFlags - Clear a specific set of flags within this object, specific by bitmask.

Parameters

<i>u</i> 16⇔	- Bitmask of flags to clear
Mask_	

Examples:

lab7_events/main.cpp.

19.5.2.2 GetMask()

```
uint16_t Mark3::EventFlag::GetMask ( )
```

GetMask Returns the state of the 16-bit bitmask within this object.

Returns

The state of the 16-bit bitmask

19.5.2.3 Set()

Set - Set additional flags in this object (logical OR).

This API can potentially result in threads blocked on Wait() to be unblocked.

Parameters

<i>u</i> 16⇔	- Bitmask of flags to set.
Mask_	

Examples:

lab7_events/main.cpp.

```
19.5.2.4 Wait() [1/2]
```

Wait - Block a thread on the specific flags in this event flag group.

Parameters

u16← Mask_	- 16-bit bitmask to block on
eMode_	- EventFlagOperation::Any_Set: Thread will block on any of the bits in the mask
	EventFlagOperation::All_Set: Thread will block on all of the bits in the mask

Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

Examples:

lab7_events/main.cpp.

```
19.5.2.5 Wait() [2/2]
```

```
EventFlagOperation eMode_,
uint32_t u32TimeMS_ )
```

Wait - Block a thread on the specific flags in this event flag group.

Parameters

u16Mask_	- 16-bit bitmask to block on	
eMode_	- EventFlagOperation::Any_Set: Thread will block on any of the bits in the mask	
	EventFlagOperation::All_Set: Thread will block on all of the bits in the mask	
u32TimeM⊷	- Time to block (in ms)	
S_		

Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

19.5.2.6 Wait_i()

Wait_i.

Interal abstraction used to manage both timed and untimed wait operations

Parameters

u16Mask_	- 16-bit bitmask to block on	
eMode_	- EventFlagOperation::Any_Set: Thread will block on any of the bits in the mask	
	EventFlagOperation::All_Set: Thread will block on all of the bits in the mask	
u32TimeM↔ S_	- Time to block (in ms)	

Returns

Bitmask condition that caused the thread to unblock, or 0 on error or timeout

19.5.2.7 WakeMe()

WakeMe.

Wake the given thread, currently blocking on this object

Parameters

pcl←	Pointer to the owner thread to unblock.
Owner_	

The documentation for this class was generated from the following file:

• /home/moslevin/projects/github/m3-repo/kernel/src/public/eventflag.h

19.6 Mark3::FakeThread_t Struct Reference

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

```
#include <thread.h>
```

Public Attributes

K_WORD * m_pwStackTop

Pointer to the top of the thread's stack.

K WORD * m pwStack

Pointer to the thread's stack.

• uint8_t m_u8ThreadID

Thread ID.

PORT_PRIO_TYPE m_uXPriority

Default priority of the thread.

PORT_PRIO_TYPE m_uXCurPriority

Current priority of the thread (priority inheritence)

• ThreadState m_eState

Enum indicating the thread's current state.

void * m_pvExtendedContext

Pointer provided to a Thread to implement thread-local storage.

19.6.1 Detailed Description

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

When cast to a Thread, this data structure will still result in GetPriority() calls being valid, which is all that is needed to support the tick-based/tickless times – while saving a fairly decent chunk of RAM on a small micro.

Note that this struct must have the same memory layout as the Thread class up to the last item.

Definition at line 535 of file thread.h.

The documentation for this struct was generated from the following file:

• /home/moslevin/projects/github/m3-repo/kernel/src/public/thread.h

19.7 Mark3::Kernel Class Reference

Class that encapsulates all of the kernel startup functions.

```
#include <kernel.h>
```

Static Public Member Functions

static void Init (void)

Kernel Initialization Function, call before any other OS function.

static void Start (void)

Start the operating system kernel - the current execution context is cancelled, all kernel services are started, and the processor resumes execution at the entrypoint for the highest-priority thread.

static bool IsStarted ()

IsStarted.

• static void SetPanic (PanicFunc pfPanic)

SetPanic Set a function to be called when a kernel panic occurs, giving the user to determine the behavior when a catastrophic failure is observed.

• static bool IsPanic ()

IsPanic Returns whether or not the kernel is in a panic state.

static void Panic (uint16_t u16Cause_)

Panic Cause the kernel to enter its panic state.

• static void SetIdleFunc (IdleFunc pfIdle_)

SetIdleFunc Set the function to be called when no active threads are available to be scheduled by the scheduler.

• static void Idle (void)

IdleFunc Call the low-priority idle function when no active threads are available to be scheduled.

static Thread * GetIdleThread (void)

GetIdleThread Return a pointer to the Kernel's idle thread object to the user.

• static void SetThreadCreateCallout (ThreadCreateCallout pfCreate)

SetThreadCreateCallout.

static void SetThreadExitCallout (ThreadExitCallout pfExit)

SetThreadExitCallout.

• static void SetThreadContextSwitchCallout (ThreadContextCallout pfContext_)

SetThreadContextSwitchCallout.

static ThreadCreateCallout GetThreadCreateCallout (void)

GetThreadCreateCallout.

static ThreadExitCallout GetThreadExitCallout (void)

GetThreadExitCallout.

• static ThreadContextCallout GetThreadContextSwitchCallout (void)

GetThreadContextSwitchCallout.

Static Private Attributes

static bool m blsStarted

true if kernel is running, false otherwise

• static bool m_blsPanic

true if kernel is in panic state, false otherwise

· static PanicFunc m pfPanic

set panic function

• static IdleFunc m_pfldle

set idle function

static FakeThread_t m_clldle

Idle thread object (note: not a real thread)

static ThreadCreateCallout m_pfThreadCreateCallout

Function to call on thread creation.

static ThreadExitCallout m_pfThreadExitCallout

Function to call on thread exit.

static ThreadContextCallout m pfThreadContextCallout

Function to call on context switch.

19.7.1 Detailed Description

Class that encapsulates all of the kernel startup functions.

Definition at line 45 of file kernel.h.

19.7.2 Member Function Documentation

19.7.2.1 GetIdleThread()

GetIdleThread Return a pointer to the Kernel's idle thread object to the user.

Note that the Thread object involved is to be used for comparisons only – the thread itself is "virtual", and doesn't represent a unique execution context with its own stack.

Returns

Pointer to the Kernel's idle thread object

Definition at line 124 of file kernel.h.

19.7.2.2 GetThreadContextSwitchCallout()

GetThreadContextSwitchCallout.

Return the current function called on every Thread::ContextSwitchSWI()

Returns

Pointer to the currently-installed callout function, or NULL if not set.

Definition at line 192 of file kernel.h.

19.7.2.3 GetThreadCreateCallout()

GetThreadCreateCallout.

Return the current function called on every Thread::Init();

Returns

Pointer to the currently-installed callout function, or NULL if not set.

Definition at line 174 of file kernel.h.

19.7.2.4 GetThreadExitCallout()

GetThreadExitCallout.

Return the current function called on every Thread::Exit();

Returns

Pointer to the currently-installed callout function, or NULL if not set.

Definition at line 183 of file kernel.h.

19.7.2.5 Init()

Kernel Initialization Function, call before any other OS function.

Initializes all global resources used by the operating system. This must be called before any other kernel function is invoked.

Examples:

lab10_notifications/main.cpp, lab11_mailboxes/main.cpp, lab1_kernel_setup/main.cpp, lab2_idle_ ← function/main.cpp, lab3_round_robin/main.cpp, lab4_semaphores/main.cpp, lab5_mutexes/main.cpp, lab6 ← __timers/main.cpp, lab7_events/main.cpp, lab8_messages/main.cpp, and lab9_dynamic_threads/main.cpp.

Definition at line 75 of file kernel.cpp.

19.7.2.6 IsPanic()

```
static bool Mark3::Kernel::IsPanic ( ) [inline], [static]
```

IsPanic Returns whether or not the kernel is in a panic state.

Returns

Whether or not the kernel is in a panic state

Definition at line 92 of file kernel.h.

19.7.2.7 IsStarted()

```
static bool Mark3::Kernel::IsStarted ( ) [inline], [static]
```

IsStarted.

Returns

Whether or not the kernel has started - true = running, false = not started

Definition at line 79 of file kernel.h.

19.7.2.8 Panic()

Panic Cause the kernel to enter its panic state.

Parameters

u16⇔	Reason for the kernel panic
Cause_	

Definition at line 109 of file kernel.cpp.

19.7.2.9 SetIdleFunc()

SetIdleFunc Set the function to be called when no active threads are available to be scheduled by the scheduler.

Parameters

pf⇔	Pointer to the idle function
ldle←	

Examples:

lab2_idle_function/main.cpp.

Definition at line 105 of file kernel.h.

19.7.2.10 SetPanic()

SetPanic Set a function to be called when a kernel panic occurs, giving the user to determine the behavior when a catastrophic failure is observed.

Parameters

pf⇔	Panic function pointer
Panic⊷	

Definition at line 87 of file kernel.h.

19.7.2.11 SetThreadContextSwitchCallout()

SetThreadContextSwitchCallout.

Set a function to be called on each context switch.

A callout is only executed if this method has been called to set a valid handler function.

pf⇔	Pointer to a function to call on context switch
Context←	
_	

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 161 of file kernel.h.

19.7.2.12 SetThreadCreateCallout()

SetThreadCreateCallout.

Set a function to be called on creation of a new thread. This callout is executed on the successful completion of a Thread::Init() call. A callout is only executed if this method has been called to set a valid handler function.

Parameters

pf⇔	Pointer to a function to call on thread creation
Create←	

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 138 of file kernel.h.

19.7.2.13 SetThreadExitCallout()

SetThreadExitCallout.

Set a function to be called on thread exit. This callout is executed from the beginning of Thread::Exit().

A callout is only executed if this method has been called to set a valid handler function.

pf⊷	Pointer to a function to call on thread exit
Create←	

Examples:

lab9 dynamic threads/main.cpp.

Definition at line 150 of file kernel.h.

19.7.2.14 Start()

Start the operating system kernel - the current execution context is cancelled, all kernel services are started, and the processor resumes execution at the entrypoint for the highest-priority thread.

You must have at least one thread added to the kernel before calling this function, otherwise the behavior is undefined. The exception to this is if the system is configured to use the threadless idle hook, in which case the kernel is allowed to run without any ready threads.

Examples:

 $lab10_notifications/main.cpp, \quad lab11_mailboxes/main.cpp, \quad lab1_kernel_setup/main.cpp, \quad lab2_idle_ {\leftarrow} \\ function/main.cpp, \\ lab3_round_robin/main.cpp, \\ lab4_semaphores/main.cpp, \\ lab5_mutexes/main.cpp, \\ lab6 {\leftarrow} \\ _timers/main.cpp, \\ lab7_events/main.cpp, \\ lab8_messages/main.cpp, \\ and \\ lab9_dynamic_threads/main.cpp.$

Definition at line 100 of file kernel.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/github/m3-repo/kernel/src/public/kernel.h
- /home/moslevin/projects/github/m3-repo/kernel/src/kernel.cpp

19.8 Mark3::KernelTimer Class Reference

Hardware timer interface, used by all scheduling/timer subsystems.

#include <kerneltimer.h>

Static Public Member Functions

```
    static void Config (void)

     Config.
• static void Start (void)
     Start.

    static void Stop (void)

     Stop.
• static uint8 t DI (void)

    static void RI (bool bEnable_)

• static void EI (void)
     EI.
• static PORT_TIMER_COUNT_TYPE SubtractExpiry (PORT_TIMER_COUNT_TYPE uInterval_)
     SubtractExpiry.

    static PORT_TIMER_COUNT_TYPE TimeToExpiry (void)

     TimeToExpiry.
• static PORT_TIMER_COUNT_TYPE SetExpiry (uint32_t u32Interval_)
     SetExpiry.

    static PORT_TIMER_COUNT_TYPE GetOvertime (void)

     GetOvertime.

    static void ClearExpiry (void)

     ClearExpiry.
• static PORT_TIMER_COUNT_TYPE Read (void)
```

19.8.1 Detailed Description

Read.

Hardware timer interface, used by all scheduling/timer subsystems.

Definition at line 32 of file kerneltimer.h.

19.8.2 Member Function Documentation

19.8.2.1 ClearExpiry()

ClearExpiry.

Clear the hardware timer expiry register

Definition at line 179 of file kerneltimer.cpp.

19.8.2.2 Config()

Config.

Initializes the kernel timer before use

Definition at line 66 of file kerneltimer.cpp.

19.8.2.3 DI()

DI.

Disable the kernel timer's expiry interrupt

Definition at line 187 of file kerneltimer.cpp.

19.8.2.4 EI()

EI.

Enable the kernel timer's expiry interrupt

Definition at line 200 of file kerneltimer.cpp.

19.8.2.5 GetOvertime()

GetOvertime.

Return the number of ticks that have elapsed since the last expiry.

Returns

Number of ticks that have elapsed after last timer expiration

Definition at line 155 of file kerneltimer.cpp.

19.8.2.6 Read()

Read.

Safely read the current value in the timer register

Returns

Value held in the timer register

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 109 of file kerneltimer.cpp.

19.8.2.7 RI()

```
void Mark3::KernelTimer::RI (
          bool bEnable_ ) [static]
```

RI.

Retstore the state of the kernel timer's expiry interrupt.

Parameters

b⇔	1 enable, 0 disable
Enable⇔	
_	

Definition at line 206 of file kerneltimer.cpp.

19.8.2.8 SetExpiry()

SetExpiry.

Resets the kernel timer's expiry interval to the specified value

Parameters

<i>u32</i> ⇔	Desired interval in ticks to set the timer for
Interval_	

Returns

Actual number of ticks set (may be less than desired)

Definition at line 161 of file kerneltimer.cpp.

19.8.2.9 Start()

Start.

Starts the kernel time (must be configured first)

Definition at line 82 of file kerneltimer.cpp.

19.8.2.10 Stop()

Stop.

Shut down the kernel timer, used when no timers are scheduled

Definition at line 97 of file kerneltimer.cpp.

19.8.2.11 SubtractExpiry()

SubtractExpiry.

Subtract the specified number of ticks from the timer's expiry count register. Returns the new expiry value stored in the register.

Parameters

<i>u32</i> ⇔	Time (in HW-specific) ticks to subtract
Interval_	

Returns

Value in ticks stored in the timer's expiry register

Definition at line 127 of file kerneltimer.cpp.

19.8.2.12 TimeToExpiry()

TimeToExpiry.

Returns the number of ticks remaining before the next timer expiry.

Returns

Time before next expiry in platform-specific ticks

Definition at line 138 of file kerneltimer.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kerneltimer.h
- /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kerneltimer.cpp

19.9 Mark3::LinkList Class Reference

Abstract-data-type from which all other linked-lists are derived.

```
#include <11.h>
```

Inheritance diagram for Mark3::LinkList:



Public Member Functions

```
    void Init ()
        Init.

    LinkListNode * GetHead ()
        GetHead.

    LinkListNode * GetTail ()
```

Protected Attributes

GetTail.

LinkListNode * m_pclHead
 Pointer to the head node in the list.

• LinkListNode * m_pclTail

Pointer to the tail node in the list.

19.9.1 Detailed Description

Abstract-data-type from which all other linked-lists are derived.

Definition at line 104 of file II.h.

19.9.2 Member Function Documentation

```
19.9.2.1 GetHead()
```

```
LinkListNode* Mark3::LinkList::GetHead ( ) [inline]
```

GetHead.

Get the head node in the linked list

Returns

Pointer to the head node in the list

Definition at line 129 of file II.h.

19.9.2.2 GetTail()

```
LinkListNode* Mark3::LinkList::GetTail ( ) [inline]
```

GetTail.

Get the tail node of the linked list

Returns

Pointer to the tail node in the list

Definition at line 137 of file II.h.

19.9.2.3 Init()

Init.

Clear the linked list.

Definition at line 116 of file II.h.

The documentation for this class was generated from the following file:

• /home/moslevin/projects/github/m3-repo/kernel/src/public/II.h

19.10 Mark3::LinkListNode Class Reference

Basic linked-list node data structure.

```
#include <11.h>
```

Inheritance diagram for Mark3::LinkListNode:



Public Member Functions

```
    LinkListNode * GetNext (void)
```

GetNext

LinkListNode * GetPrev (void)

GetPrev.

Protected Member Functions

```
• void ClearNode () 
ClearNode.
```

Protected Attributes

LinkListNode * next

Pointer to the next node in the list.

LinkListNode * prev

Pointer to the previous node in the list.

19.10.1 Detailed Description

Basic linked-list node data structure.

This data is managed by the linked-list class types, and can be used transparently between them.

Definition at line 63 of file II.h.

19.10.2 Member Function Documentation

```
19.10.2.1 ClearNode()
```

```
void Mark3::LinkListNode::ClearNode ( ) [protected]
```

ClearNode.

Initialize the linked list node, clearing its next and previous node.

Definition at line 42 of file II.cpp.

19.10.2.2 GetNext()

GetNext.

Returns a pointer to the next node in the list.

Returns

a pointer to the next node in the list.

Definition at line 85 of file II.h.

19.10.2.3 GetPrev()

GetPrev.

Returns a pointer to the previous node in the list.

Returns

a pointer to the previous node in the list.

Definition at line 93 of file II.h.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/github/m3-repo/kernel/src/public/II.h
- /home/moslevin/projects/github/m3-repo/kernel/src/ll.cpp

19.11 Mark3::LockGuard Class Reference

```
#include <lockguard.h>
```

Public Member Functions

- LockGuard (Mutex *pclMutex)
- LockGuard (Mutex *pclMutex, uint32_t u32TimeoutMs_)
- bool isAcquired ()

19.11.1 Detailed Description

Implement RAII-style locks based on Mark3's kernel Mutex object. Note that Mark3 does not support exceptions, so

Definition at line 32 of file lockguard.h.

19.11.2 Constructor & Destructor Documentation

Parameters

Mutex mutex to lock during construction

Definition at line 23 of file lockguard.cpp.

```
19.11.2.2 LockGuard() [2/2]
```

Parameters

pclMutex	mutex to lock during construction
u32Timeout⊷	timeout (in ms) to wait before bailing
Ms_	

19.11.3 Member Function Documentation

19.11.3.1 isAcquired()

```
bool Mark3::LockGuard::isAcquired ( ) [inline]
```

Verify that lock was correctly initialized and locked during acquisition. This is used to provide error-checking for timed RAII locks, where Mark3 does not use exceptions, and a kernel-panic is too heavy-handed.

Returns

true if the lock was initialed correctly, false on error

Definition at line 56 of file lockguard.h.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/github/m3-repo/kernel/src/public/lockguard.h
- /home/moslevin/projects/github/m3-repo/kernel/src/lockguard.cpp

19.12 Mark3::Mailbox Class Reference

The Mailbox class implements an IPC mechnism based on envelopes containing data of a fixed size (configured at initialization) that reside within a buffer of memory provided by the user.

```
#include <mailbox.h>
```

Public Member Functions

```
• void Init (void *pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_)

    bool Send (void *pvData_)

     Send.

    bool SendTail (void *pvData_)

     SendTail.

    bool Send (void *pvData , uint32 t u32TimeoutMS )

     Send.

    bool SendTail (void *pvData_, uint32_t u32TimeoutMS_)

     SendTail.

    void Receive (void *pvData_)

     Receive.

    void ReceiveTail (void *pvData )

     ReceiveTail.

    bool Receive (void *pvData_, uint32_t u32TimeoutMS_)
```

Static Public Member Functions

ReceiveTail.

 static Mailbox * Init (uint16_t u16BufferSize_, uint16_t u16ElementSize_) Init.

bool ReceiveTail (void *pvData , uint32 t u32TimeoutMS)

Private Member Functions

```
GetHeadPointer.

    void * GetTailPointer (void)

      GetTailPointer.

    void CopyData (const void *src_, const void *dst_, uint16_t len_)

      CopyData.

    void MoveTailForward (void)
```

void * GetHeadPointer (void)

MoveTailForward.

void MoveHeadForward (void)

MoveHeadForward.

void MoveTailBackward (void)

MoveTailBackward.

void MoveHeadBackward (void)

MoveHeadBackward.

bool Send_i (const void *pvData_, bool bTail_, uint32_t u32TimeoutMS_)

 bool Receive_i (const void *pvData_, bool bTail_, uint32_t u32WaitTimeMS_) Receive_i.

Private Attributes

uint16_t m_u16Head

Current head index.

uint16_t m_u16Tail

Current tail index.

• uint16_t m_u16Count

Count of items in the mailbox.

• volatile uint16_t m_u16Free

Current number of free slots in the mailbox.

• uint16_t m_u16ElementSize

Size of the objects tracked in this mailbox.

const void * m_pvBuffer

Pointer to the data-buffer managed by this mailbox.

• Semaphore m_clRecvSem

Counting semaphore used to synchronize threads on the object.

• Semaphore m_clSendSem

Binary semaphore for send-blocked threads.

19.12.1 Detailed Description

The Mailbox class implements an IPC mechnism based on envelopes containing data of a fixed size (configured at initialization) that reside within a buffer of memory provided by the user.

Examples:

```
lab11 mailboxes/main.cpp.
```

Definition at line 35 of file mailbox.h.

19.12.2 Member Function Documentation

19.12.2.1 CopyData()

CopyData.

Perform a direct byte-copy from a source to a destination object.

Parameters

src⊷ _	Pointer to an object to read from
dst⊷	Pointer to an object to write to
	•
len⊷	Length to copy (in bytes)
ıcıı—	Longin to copy (in bytes)
_	

Generated by Doxygen

Definition at line 238 of file mailbox.h.

19.12.2.2 GetHeadPointer()

GetHeadPointer.

Return a pointer to the current head of the mailbox's internal circular buffer.

Returns

pointer to the head element in the mailbox

Definition at line 207 of file mailbox.h.

19.12.2.3 GetTailPointer()

GetTailPointer.

Return a pointer to the current tail of the mailbox's internal circular buffer.

Returns

pointer to the tail element in the mailbox

Definition at line 222 of file mailbox.h.

uint16_t u16ElementSize_)

Init.

Initialize the mailbox object prior to its use. This must be called before any calls can be made to the object.

Parameters

pvBuffer_	Pointer to the static buffer to use for the mailbox
u16BufferSize_	Size of the mailbox buffer, in bytes
u16Element⊷	Size of each envelope, in bytes
Size_	

Init.

Create and initialize the mailbox object prior to its use. This must be called before any calls can be made to the object. This version of the API alloctes the buffer space from the kernel's Auto-Allocation heap, which cannot be returned back. As a result, this is only suitable for cases where the mailbox will be created once on startup, and persist for the duration of the system.

Parameters

u16BufferSize_	Size of the mailbox buffer, in bytes
u16Element <i>⊷</i>	Size of each envelope, in bytes
Size_	

19.12.2.6 MoveHeadBackward()

MoveHeadBackward.

Move the head index backward one element

Definition at line 291 of file mailbox.h.

19.12.2.7 MoveHeadForward()

MoveHeadForward.

Move the head index forward one element

Definition at line 265 of file mailbox.h.

19.12.2.8 MoveTailBackward()

MoveTailBackward.

Move the tail index backward one element

Definition at line 278 of file mailbox.h.

19.12.2.9 MoveTailForward()

MoveTailForward.

Move the tail index forward one element

Definition at line 252 of file mailbox.h.

19.12.2.10 Receive() [1/2]

Receive.

Read one envelope from the head of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered.

Parameters

pv⊷	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
Data	

Examples:

lab11_mailboxes/main.cpp.

19.12.2.11 Receive() [2/2]

Receive.

Read one envelope from the head of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered, or the specified time has elapsed without delivery.

Parameters

pvData_	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
u32TimeoutM⊷	Maximum time to wait for delivery.
S_	

Returns

true - envelope was delivered, false - delivery timed out.

19.12.2.12 Receive_i()

Receive_i.

Internal method which implements all Read() methods in the class.

Parameters

pvData_	Pointer to the envelope data
bTail_	true - read from tail, false - read from head
u32WaitTimeM⊷ S_	Time to wait before timeout (in ms).

Returns

true - read successfully, false - timeout.

19.12.2.13 ReceiveTail() [1/2]

ReceiveTail.

Read one envelope from the tail of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered.

Parameters

pv⊷	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
Data_	

19.12.2.14 ReceiveTail() [2/2]

ReceiveTail.

Read one envelope from the tail of the mailbox. If the mailbox is currently empty, the calling thread will block until an envelope is delivered, or the specified time has elapsed without delivery.

Parameters

pvData_	Pointer to a buffer that will have the envelope's contents copied into upon delivery.
u32TimeoutM⇔	Maximum time to wait for delivery.
S_	

Returns

true - envelope was delivered, false - delivery timed out.

```
19.12.2.15 Send() [1/2]
```

Send.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the head of the mailbox.

pv⊷	Pointer to the data object to send to the mailbox.
Data_	

Returns

true - envelope was delivered, false - mailbox is full.

Examples:

lab11_mailboxes/main.cpp.

Send.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the head of the mailbox.

Parameters

pvData_	Pointer to the data object to send to the mailbox.
u32TimeoutM⊷	Maximum time to wait for a free transmit slot
<i>S</i> _	

Returns

true - envelope was delivered, false - mailbox is full.

19.12.2.17 Send_i()

Send_i.

Internal method which implements all Send() methods in the class.

pvData_	Pointer to the envelope data
bTail_	true - write to tail, false - write to head
u32WaitTimeM←	Time to wait before timeout (in ms).
<u>-S_</u>	

Returns

true - data successfully written, false - buffer full

SendTail.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the tail of the mailbox.

Parameters

pv⊷	Pointer to the data object to send to the mailbox.
Data_	

Returns

true - envelope was delivered, false - mailbox is full.

SendTail.

Send an envelope to the mailbox. This safely copies the data contents of the datastructure to the previously-initialized mailbox buffer. If there is a thread already blocking, awaiting delivery to the mailbox, it will be unblocked at this time.

This method delivers the envelope at the tail of the mailbox.

pvData_	Pointer to the data object to send to the mailbox.
u32TimeoutM⊷	Maximum time to wait for a free transmit slot
S	

Returns

true - envelope was delivered, false - mailbox is full.

19.12.3 Member Data Documentation

```
19.12.3.1 m_clSendSem
```

```
Semaphore Mark3::Mailbox::m_clSendSem [private]
```

Binary semaphore for send-blocked threads.

Definition at line 360 of file mailbox.h.

The documentation for this class was generated from the following file:

• /home/moslevin/projects/github/m3-repo/kernel/src/public/mailbox.h

19.13 Mark3::Message Class Reference

Class to provide message-based IPC services in the kernel.

```
#include <message.h>
```

Inheritance diagram for Mark3::Message:



Public Member Functions

```
• void Init ()

Init.
```

void SetData (void *pvData_)

SetData.

void * GetData ()

GetData.

void SetCode (uint16_t u16Code_)

SetCode.

• uint16_t GetCode ()

GetCode.

Private Attributes

void * m_pvData

Pointer to the message data.

• uint16_t m_u16Code

Message code, providing context for the message.

Additional Inherited Members

19.13.1 Detailed Description

Class to provide message-based IPC services in the kernel.

Examples:

lab8_messages/main.cpp.

Definition at line 98 of file message.h.

19.13.2 Member Function Documentation

```
19.13.2.1 GetCode()
```

```
uint16_t Mark3::Message::GetCode ( ) [inline]
```

GetCode.

Return the code set in the message upon receipt

Returns

user code set in the object

Definition at line 145 of file message.h.

19.13.2.2 GetData()

```
void* Mark3::Message::GetData ( ) [inline]
```

GetData.

Get the data pointer stored in the message upon receipt

Returns

Pointer to the data set in the message object

Definition at line 129 of file message.h.

19.13.2.3 Init()

Init.

Initialize the data and code in the message.

Definition at line 107 of file message.h.

19.13.2.4 SetCode()

SetCode.

Set the code in the message before transmission

Parameters

u16⇔	Data code to set in the object
Code_	

Examples:

lab8_messages/main.cpp.

Definition at line 137 of file message.h.

19.13.2.5 SetData()

SetData.

Set the data pointer for the message before transmission.

Parameters

DV⇔	Pointer to the data object to send in the message	1
, <i>'</i>	Folitier to the data object to send in the message	l
Data		l

Definition at line 121 of file message.h.

The documentation for this class was generated from the following file:

• /home/moslevin/projects/github/m3-repo/kernel/src/public/message.h

19.14 Mark3::MessagePool Class Reference

Implements a list of message objects.

```
#include <message.h>
```

Public Member Functions

Private Attributes

• DoubleLinkList m_clList

Linked list used to manage the Message objects.

19.14.1 Detailed Description

Implements a list of message objects.

Examples:

lab8_messages/main.cpp.

Definition at line 158 of file message.h.

19.14.2 Member Function Documentation

```
19.14.2.1 GetHead()
```

```
Message* Mark3::MessagePool::GetHead ( )
```

GetHead.

Return a pointer to the first element in the message list

Returns

```
19.14.2.2 Init()
```

```
void Mark3::MessagePool::Init ( )
```

Init.

Initialize the message queue prior to use

```
19.14.2.3 Pop()
```

```
Message* Mark3::MessagePool::Pop ( )
```

Pop.

Pop a message from the queue, returning it to the user to be popu32ated before sending by a transmitter.

Returns

Pointer to a Message object

Examples:

lab8_messages/main.cpp.

19.14.2.4 Push()

Push.

Return a previously-claimed message object back to the queue. used once the message has been processed by a receiver.

Parameters

pcl←	Pointer to the Message object to return back to the queue]
Message_		

Examples:

lab8_messages/main.cpp.

The documentation for this class was generated from the following file:

• /home/moslevin/projects/github/m3-repo/kernel/src/public/message.h

19.15 Mark3::MessageQueue Class Reference

List of messages, used as the channel for sending and receiving messages between threads.

```
#include <message.h>
```

Public Member Functions

```
• void Init ()
```

Init.

• Message * Receive ()

Receive.

Message * Receive (uint32_t u32TimeWaitMS_)

Receive.

void Send (Message *pclSrc_)

Send.

· uint16_t GetCount ()

GetCount.

Private Member Functions

```
    Message * Receive_i (uint32_t u32TimeWaitMS_)
    Receive_i.
```

Private Attributes

· Semaphore m_clSemaphore

Counting semaphore used to manage thread blocking.

• DoubleLinkList m_clLinkList

List object used to store messages.

19.15.1 Detailed Description

List of messages, used as the channel for sending and receiving messages between threads.

Examples:

```
lab8_messages/main.cpp.
```

Definition at line 210 of file message.h.

19.15.2 Member Function Documentation

```
19.15.2.1 GetCount()
uint16_t Mark3::MessageQueue::GetCount ( )
```

GetCount.

Return the number of messages pending in the "receive" queue.

Returns

Count of pending messages in the queue.

```
19.15.2.2 Init()
void Mark3::MessageQueue::Init ( )
Init.
```

Initialize the message queue prior to use.

```
19.15.2.3 Receive() [1/2]
Message* Mark3::MessageQueue::Receive ( )
```

Receive.

Receive a message from the message queue. If the message queue is empty, the thread will block until a message is available.

Returns

Pointer to a message object at the head of the queue

Examples:

lab8_messages/main.cpp.

Receive.

Receive a message from the message queue. If the message queue is empty, the thread will block until a message is available for the duration specified. If no message arrives within that duration, the call will return with NULL.

Parameters

u32TimeWaitM⊷	The amount of time in ms to wait for a message before timing out and unblocking the	Ì
S_	waiting thread.	

Returns

Pointer to a message object at the head of the queue or NULL on timeout.

19.15.2.5 Receive_i()

Receive_i.

Internal function used to abstract timed and un-timed Receive calls.

Parameters

u32TimeWaitM⊷	Time (in ms) to block, 0 for un-timed call.
S_	

Returns

Pointer to a message, or 0 on timeout.

19.15.2.6 Send()

Send.

Send a message object into this message queue. Will un-block the first waiting thread blocked on this queue if that occurs.

Parameters

pcl←	Pointer to the message object to add to the queue]
Src_		

Examples:

lab8_messages/main.cpp.

The documentation for this class was generated from the following file:


• /home/moslevin/projects/github/m3-repo/kernel/src/public/message.h

19.16 Mark3::Mutex Class Reference

Mutual-exclusion locks, based on BlockingObject.

```
#include <mutex.h>
```

Inheritance diagram for Mark3::Mutex:



Public Member Functions

```
• void Init (bool bRecursive_=true)
```

Init.

· void Claim ()

Claim

• bool Claim (uint32_t u32WaitTimeMS_)

Claim

void WakeMe (Thread *pclOwner_)

WakeMe.

· void Release ()

Release.

Private Member Functions

```
• uint8_t WakeNext ()
```

WakeNext.

bool Claim_i (uint32_t u32WaitTimeMS_)

Claim i.

Private Attributes

• uint8 t m u8Recurse

The recursive lock-count when a mutex is claimed multiple times by the same owner.

bool m_bReady

State of the mutex - true = ready, false = claimed.

bool m bRecursive

Whether or not the lock is recursive.

uint8_t m_u8MaxPri

Maximum priority of thread in queue, used for priority inheritence.

• Thread * m_pclOwner

Pointer to the thread that owns the mutex (when claimed)

Additional Inherited Members

19.16.1 Detailed Description

Mutual-exclusion locks, based on BlockingObject.

Examples:

```
lab5_mutexes/main.cpp.
```

Definition at line 64 of file mutex.h.

19.16.2 Member Function Documentation

```
19.16.2.1 Claim() [1/2]
void Mark3::Mutex::Claim ( )
```

Claim.

Claim the mutex. When the mutex is claimed, no other thread can claim a region protected by the object. If another Thread currently holds the Mutex when the Claim method is called, that Thread will block until the current owner of the mutex releases the Mutex.

If the calling Thread's priority is lower than that of a Thread that currently owns the Mutex object, then the priority of that Thread will be elevated to that of the highest-priority calling object until the Mutex is released. This property is known as "Priority Inheritence"

Note: A single thread can recursively claim a mutex up to a count of

1. Attempting to claim a mutex beyond that will cause a kernel panic.

Examples:

lab5_mutexes/main.cpp.

Claim.

Claim a mutex, with timeout.

Parameters

```
u32WaitTimeM←
S_
```

Returns

true - mutex was claimed within the time period specified false - mutex operation timed-out before the claim operation.

19.16.2.3 Claim_i()

Claim_i.

Abstracts out timed/non-timed mutex claim operations.

Parameters

u32WaitTimeM⊷	Time in MS to wait, 0 for infinite
S_	

Returns

true on successful claim, false otherwise

19.16.2.4 Init()

```
void Mark3::Mutex::Init (
          bool bRecursive_ = true )
```

Init.

Initialize a mutex object for use - must call this function before using the object.

bRecursieve	Whether or not the mutex can be recursively locked.
-------------	---

19.16.2.5 Release()

```
void Mark3::Mutex::Release ( )
```

Release.

Release the mutex. When the mutex is released, another object can enter the mutex-protected region.

If there are Threads waiting for the Mutex to become available, then the highest priority Thread will be unblocked at this time and will claim the Mutex lock immediately - this may result in an immediate context switch, depending on relative priorities.

If the calling Thread's priority was boosted as a result of priority inheritence, the Thread's previous priority will also be restored at this time.

Note that if a Mutex is held recursively, it must be Release'd the same number of times that it was Claim'd before it will be availabel for use by another Thread.

Examples:

lab5_mutexes/main.cpp.

19.16.2.6 WakeMe()

WakeMe.

Wake a thread blocked on the mutex. This is an internal function used for implementing timed mutexes relying on timer callbacks. Since these do not have access to the private data of the mutex and its base classes, we have to wrap this as a public method - do not use this for any other purposes.

Parameters

pcl⇔	Thread to unblock from this object.
Owner_	

19.16.2.7 WakeNext()

```
uint8_t Mark3::Mutex::WakeNext ( ) [private]
```

WakeNext.

Wake the next thread waiting on the Mutex.

The documentation for this class was generated from the following file:

• /home/moslevin/projects/github/m3-repo/kernel/src/public/mutex.h

19.17 Mark3::Notify Class Reference

The Notify class is a blocking object type, that allows one or more threads to wait for an event to occur before resuming operation.

```
#include <notify.h>
```

Inheritance diagram for Mark3::Notify:



Public Member Functions

void Init (void)

Init

void Signal (void)

Signal.

void Wait (bool *pbFlag_)

Wait.

• bool Wait (uint32_t u32WaitTimeMS_, bool *pbFlag_)

Wait

void WakeMe (Thread *pclChosenOne_)

WakeMe.

Additional Inherited Members

19.17.1 Detailed Description

The Notify class is a blocking object type, that allows one or more threads to wait for an event to occur before resuming operation.

Examples:

lab10_notifications/main.cpp.

Definition at line 33 of file notify.h.

19.17.2 Member Function Documentation

19.17.2.1 Init()

Init.

Initialze the Notification object prior to use.

19.17.2.2 Signal()

Signal.

Signal the notification object. This will cause the highest priority thread currently blocking on the object to wake. If no threads are currently blocked on the object, the call has no effect.

Examples:

lab10_notifications/main.cpp.

```
19.17.2.3 Wait() [1/2]
void Mark3::Notify::Wait (
```

Wait.

Block the current thread, waiting for a signal on the object.

bool * pbFlag_)

Parameters

pb⇔	Flag set to false on block, and true upon wakeup.
Flag_	

Examples:

lab10_notifications/main.cpp.

19.17.2.4 Wait() [2/2]

Wait.

Block the current thread, waiting for a signal on the object.

Parameters

u32WaitTimeM⊷ S_	Time to wait for the notification event.
pbFlag_	Flag set to false on block, and true upon wakeup.

Returns

true on notification, false on timeout

19.17.2.5 WakeMe()

WakeMe.

Wake the specified thread from its current blocking queue. Note that this is only public in order to be accessible from a timer callack.

Parameters

pclChosen←	Thread to wake up
One	

The documentation for this class was generated from the following file:

/home/moslevin/projects/github/m3-repo/kernel/src/public/notify.h

19.18 Mark3::PriorityMap Class Reference

The PriorityMap class.

```
#include <priomap.h>
```

Public Member Functions

• PriorityMap ()

PriorityMap.

void Set (PORT_PRIO_TYPE uXPrio_)

Set Set the priority map bitmap data, at all levels, for the given priority.

• void Clear (PORT_PRIO_TYPE uXPrio_)

Clear Clear the priority map bitmap data, at all levels, for the given priority.

PORT_PRIO_TYPE HighestPriority (void)

HighestPriority.

19.18.1 Detailed Description

The PriorityMap class.

Definition at line 70 of file priomap.h.

19.18.2 Constructor & Destructor Documentation

19.18.2.1 PriorityMap()

```
Mark3::PriorityMap::PriorityMap ( )
```

PriorityMap.

Initialize the priority map object, clearing the bitamp data to all 0's.

Definition at line 54 of file priomap.cpp.

19.18.3 Member Function Documentation

19.18.3.1 Clear()

Clear Clear the priority map bitmap data, at all levels, for the given priority.

Parameters

uX⊷	Priority level to clear the bitmap data for.
Prio_	

Definition at line 81 of file priomap.cpp.

19.18.3.2 HighestPriority()

HighestPriority.

Computes the numeric priority of the highest-priority thread represented in the priority map.

Returns

Highest priority ready-thread's number.

Definition at line 97 of file priomap.cpp.

Set Set the priority map bitmap data, at all levels, for the given priority.

Parameters

uX⊷	Priority level to set the bitmap data for.
Prio_	

Definition at line 67 of file priomap.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/github/m3-repo/kernel/src/public/priomap.h
- /home/moslevin/projects/github/m3-repo/kernel/src/priomap.cpp

19.19 Mark3::ProfileTimer Class Reference

Profiling timer.

```
#include file.h>
```

Public Member Functions

GetCurrent.

Private Member Functions

uint32_t ComputeCurrentTicks (uint16_t u16Current_, uint32_t u32Epoch_)
 ComputeCurrentTicks.

Private Attributes

• uint32_t m_u32Cumulative

Cumulative tick-count for this timer.

• uint32_t m_u32CurrentIteration

Tick-count for the current iteration.

• uint16_t m_u16Initial

Initial count.

• uint32_t m_u32InitialEpoch

Initial Epoch.

• uint16_t m_u16Iterations

Number of iterations executed for this profiling timer.

bool m bActive

Wheter or not the timer is active or stopped.

19.19.1 Detailed Description

Profiling timer.

This class is used to perform high-performance profiling of code to see how int32_t certain operations take. useful in instrumenting the performance of key algorithms and time-critical operations to ensure real-timer behavior.

Definition at line 69 of file profile.h.

19.19.2 Member Function Documentation

19.19.2.1 ComputeCurrentTicks()

ComputeCurrentTicks.

Figure out how many ticks have elapsed in this iteration

Parameters

<i>u</i> 16⇔	Current timer count
Count_	
<i>u32</i> ⇔	Current timer epoch
Epoch_	

Returns

Current tick count

19.19.2.2 GetAverage()

```
uint32_t Mark3::ProfileTimer::GetAverage ( )
```

GetAverage.

Get the average time associated with this operation.

Returns

Average tick count normalized over all iterations

19.19.2.3 GetCurrent()

```
uint32_t Mark3::ProfileTimer::GetCurrent ( )
```

GetCurrent.

Return the current tick count held by the profiler. Valid for both active and stopped timers.

Returns

The currently held tick count.

19.19.2.4 Init()

```
void Mark3::ProfileTimer::Init ( )
```

Init.

Initialize the profiling timer prior to use. Can also be used to reset a timer that's been used previously.

19.19.2.5 Start()

```
void Mark3::ProfileTimer::Start ( )
```

Start.

Start a profiling session, if the timer is not already active. Has no effect if the timer is already active.

19.19.2.6 Stop()

```
void Mark3::ProfileTimer::Stop ( )
```

Stop.

Stop the current profiling session, adding to the cumulative time for this timer, and the total iteration count.

The documentation for this class was generated from the following file:

/home/moslevin/projects/github/m3-repo/kernel/src/public/profile.h

19.20 Mark3::Quantum Class Reference

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

```
#include <quantum.h>
```

Static Public Member Functions

• static void UpdateTimer ()

UpdateTimer.

static void AddThread (Thread *pclThread_)

AddThread.

• static void RemoveThread ()

Remove Thread.

• static void SetInTimer (void)

SetInTimer.

• static void ClearInTimer (void)

ClearInTimer.

Static Private Member Functions

```
    static void SetTimer (Thread *pclThread_)
    SetTimer.
```

19.20.1 Detailed Description

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

Definition at line 42 of file quantum.h.

19.20.2 Member Function Documentation

19.20.2.1 AddThread()

AddThread.

Add the thread to the quantum timer. Only one thread can own the quantum, since only one thread can be running on a core at a time.

19.20.2.2 ClearInTimer()

ClearInTimer.

Clear the flag once the timer callback function has been completed.

Definition at line 84 of file quantum.h.

19.20.2.3 RemoveThread()

```
static void Mark3::Quantum::RemoveThread ( ) [static]
```

RemoveThread.

Remove the thread from the quantum timer. This will cancel the timer.

19.20.2.4 SetInTimer()

SetInTimer.

Set a flag to indicate that the CPU is currently running within the timer-callback routine. This prevents the Quantum timer from being updated in the middle of a callback cycle, potentially resulting in the kernel timer becoming disabled.

Definition at line 78 of file quantum.h.

19.20.2.5 SetTimer()

SetTimer.

Set up the quantum timer in the timer scheduler. This creates a one-shot timer, which calls a static callback in quantum.cpp that on expiry will pivot the head of the threadlist for the thread's priority. This is the mechanism that provides round-robin scheduling in the system.

Parameters

pcl⇔	Pointer to the thread to set the Quantum timer on
Thread_	

19.20.2.6 UpdateTimer()

```
static void Mark3::Quantum::UpdateTimer ( ) [static]
```

UpdateTimer.

This function is called to update the thread quantum timer whenever something in the scheduler has changed. This can result in the timer being re-loaded or started. The timer is never stopped, but if may be ignored on expiry.

The documentation for this class was generated from the following file:

/home/moslevin/projects/github/m3-repo/kernel/src/public/quantum.h

19.21 Mark3::ReaderWriterLock Class Reference

The ReaderWriterLock class This class implements an object that marshalls access to a resource based on the intended usage of the resource.

```
#include <readerwriter.h>
```

Public Member Functions

• void Init ()

Init Initialize the reader-writer lock before use.

void AcquireReader ()

AcquireReader Acquire the object's reader lock.

bool AcquireReader (uint32 t u32TimeoutMs)

AcquireReader Acquire the object's reader lock.

• void ReleaseReader ()

ReleaseReader Release a previously-held reader lock.

• void AcquireWriter ()

AcquireWriter Acquire the writer lock.

bool AcquireWriter (uint32_t u32TimeoutMs_)

AcquireWriter Acquire the writer lock.

• void ReleaseWriter ()

ReleaseWriter Release the currently held writer, allowing other readers/writers to access the object.

Private Member Functions

bool AcquireReader_i (uint32_t u32TimeoutMs_)

AcquireReader_i Internal helper function for AcquireReaer.

bool AcquireWriter_i (uint32_t u32TimeoutMs_)

AcquireWriter_i Internal helper function for AcquireWriter.

Private Attributes

Mutex m_clGlobalMutex

Mutex used to lock the object against concurrent read + write.

Mutex m_clReaderMutex

Mutex used to lock object for readers.

• uint8_t m_u8ReadCount

Number of concurrent readers.

19.21.1 Detailed Description

The ReaderWriterLock class This class implements an object that marshalls access to a resource based on the intended usage of the resource.

A reader-writer lock permits multiple concurrent read access, or single-writer access to a resource. If the object holds a write lock, other writers, and all readers will block until the writer is finished. If the object holds reader locks, all writers will block until all readers are finished before the first writer can take ownership of the resource. This is based upon lower-level synchronization primatives, and is somewhat more heavyweight than primative synchronization types.

Definition at line 41 of file readerwriter.h.

19.21.2 Member Function Documentation

```
19.21.2.1 AcquireReader() [1/2]
void Mark3::ReaderWriterLock::AcquireReader ( )
```

AcquireReader Acquire the object's reader lock.

Multiple concurrent readers are allowed. If the writer lock is currently held, the calling thread will wait until the writer lock is relinquished

AcquireReader Acquire the object's reader lock.

Multiple concurrent readers are allowed. If the writer lock is currently held, the calling thread will wait until the writer lock is relinquished

Parameters

u32Timeout←	Maximum time to wait (in ms) before the operation is aborted]
Ms_		

Returns

true on success, false on timeout

19.21.2.3 AcquireReader_i()

AcquireReader i Internal helper function for AcquireReaer.

Parameters

u32Timeout⊷	Maximum time to wait (in ms) before the operation is aborted
Ms_	

Returns

true on success, false on timeout

19.21.2.4 AcquireWriter() [1/2]

```
void Mark3::ReaderWriterLock::AcquireWriter ( )
```

AcquireWriter Acquire the writer lock.

Only a single writer is allowed to access the object at a time. This will block the currently-runnign thread until all other readers/writers have released their locks.

19.21.2.5 AcquireWriter() [2/2]

AcquireWriter Acquire the writer lock.

Only a single writer is allowed to access the object at a time. This will block the currently-runnign thread until all other readers/writers have released their locks.

Parameters

u32Timeout <i>←</i>	Maximum time to wait (in ms) before the operation is aborted
Ms	

Returns

true on success, false on timeout

19.21.2.6 AcquireWriter_i()

AcquireWriter i Internal helper function for AcquireWriter.

Parameters

u32Timeout <i>←</i>	Maximum time to wait (in ms) before the operation is aborted
Ms	

Returns

true on success, false on timeout

19.21.2.7 Init()

```
void Mark3::ReaderWriterLock::Init ( )
```

Init Initialize the reader-writer lock before use.

Must be called before attempting any other operations on the object.

The documentation for this class was generated from the following file:

 $\bullet \ \ / home/moslevin/projects/github/m3-repo/kernel/src/public/readerwriter.h$

19.22 Mark3::Scheduler Class Reference

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

```
#include <scheduler.h>
```

Static Public Member Functions

• static void Init ()

Init.

• static void Schedule ()

Schedule.

• static void Add (Thread *pclThread_)

Add.

static void Remove (Thread *pclThread_)

Remove

• static bool SetScheduler (bool bEnable_)

SetScheduler.

static Thread * GetCurrentThread ()

GetCurrentThread.

static volatile Thread * GetNextThread ()

GetNextThread.

• static ThreadList * GetThreadList (PORT_PRIO_TYPE uXPriority_)

GetThreadList.

static ThreadList * GetStopList ()

GetStopList.

• static bool IsEnabled ()

IsEnabled.

• static void QueueScheduler ()

QueueScheduler.

Static Private Attributes

• static bool m_bEnabled

Scheduler's state - enabled or disabled.

• static bool m_bQueuedSchedule

Variable representing whether or not there's a queued scheduler operation.

• static ThreadList m_clStopList

ThreadList for all stopped threads.

static ThreadList m_aclPriorities [KERNEL_NUM_PRIORITIES]

ThreadLists for all threads at all priorities.

static PriorityMap m_clPrioMap

Priority bitmap lookup structure, 1-bit per thread priority.

19.22.1 Detailed Description

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

Definition at line 63 of file scheduler.h.

19.22.2 Member Function Documentation

19.22.2.1 Add()

Add.

Add a thread to the scheduler at its current priority level.

Parameters

pcl←	Pointer to the thread to add to the scheduler	
Thread_		

Definition at line 86 of file scheduler.cpp.

19.22.2.2 GetCurrentThread()

```
static Thread* Mark3::Scheduler::GetCurrentThread ( ) [inline], [static]
```

GetCurrentThread.

Return the pointer to the currently-running thread.

Returns

Pointer to the currently-running thread

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 123 of file scheduler.h.

19.22.2.3 GetNextThread()

```
static volatile Thread* Mark3::Scheduler::GetNextThread ( ) [inline], [static]
```

GetNextThread.

Return the pointer to the thread that should run next, according to the last run of the scheduler.

Returns

Pointer to the next-running thread

Definition at line 132 of file scheduler.h.

19.22.2.4 GetStopList()

```
static ThreadList* Mark3::Scheduler::GetStopList ( ) [inline], [static]
```

GetStopList.

Return the pointer to the list of threads that are in the scheduler's stopped state.

Returns

Pointer to the ThreadList containing the stopped threads

Definition at line 152 of file scheduler.h.

19.22.2.5 GetThreadList()

GetThreadList.

Return the pointer to the active list of threads that are at the given priority level in the scheduler.

Parameters

uX⇔	Priority level of the threadlist
Priority_	

Returns

Pointer to the ThreadList for the given priority level

Definition at line 143 of file scheduler.h.

19.22.2.6 Init()

Init.

Intiailize the scheduler, must be called before use.

Definition at line 53 of file scheduler.cpp.

19.22.2.7 IsEnabled()

```
static bool Mark3::Scheduler::IsEnabled ( ) [inline], [static]
```

IsEnabled.

Return the current state of the scheduler - whether or not scheduling is enabled or disabled.

Returns

true - scheduler enabled, false - disabled

Definition at line 161 of file scheduler.h.

19.22.2.8 QueueScheduler()

```
static void Mark3::Scheduler::QueueScheduler ( ) [inline], [static]
```

QueueScheduler.

Tell the kernel to perform a scheduling operation as soon as the scheduler is re-enabled.

Definition at line 168 of file scheduler.h.

19.22.2.9 Remove()

Remove.

Remove a thread from the scheduler at its current priority level.

Parameters

pcl⇔	Pointer to the thread to be removed from the scheduler
Thread_	

Definition at line 92 of file scheduler.cpp.

19.22.2.10 Schedule()

```
void Mark3::Scheduler::Schedule ( ) [static]
```

Schedule.

Run the scheduler, determines the next thread to run based on the current state of the threads. Note that the next-thread chosen from this function is only valid while in a critical section.

Definition at line 62 of file scheduler.cpp.

19.22.2.11 SetScheduler()

SetScheduler.

Set the active state of the scheduler. When the scheduler is disabled, the *next thread* is never set; the currently running thread will run forever until the scheduler is enabled again. Care must be taken to ensure that we don't end up trying to block while the scheduler is disabled, otherwise the system ends up in an unusable state.

Parameters

b⇔	true to enable, false to disable the scheduler
Enable⊷	

Definition at line 98 of file scheduler.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/github/m3-repo/kernel/src/public/scheduler.h
- /home/moslevin/projects/github/m3-repo/kernel/src/scheduler.cpp

19.23 Mark3::Semaphore Class Reference

Binary & Counting semaphores, based on BlockingObject base class.

```
#include <ksemaphore.h>
```

Inheritance diagram for Mark3::Semaphore:



Public Member Functions

```
    void Init (uint16_t u16InitVal_, uint16_t u16MaxVal_)
```

Initialize a semaphore before use.

• bool Post ()

Increment the semaphore count.

• void Pend ()

Decrement the semaphore count.

• uint16_t GetCount ()

Return the current semaphore counter.

bool Pend (uint32_t u32WaitTimeMS_)

Decrement the semaphore count.

void WakeMe (Thread *pclChosenOne)

Wake a thread blocked on the semaphore.

Private Member Functions

• uint8_t WakeNext ()

Wake the next thread waiting on the semaphore.

bool Pend_i (uint32_t u32WaitTimeMS_)
 Pend i.

Private Attributes

• uint16_t m_u16Value

Current count held by the semaphore.

• uint16_t m_u16MaxValue

Maximum count that can be held by this semaphore.

Additional Inherited Members

19.23.1 Detailed Description

Binary & Counting semaphores, based on BlockingObject base class.

Examples:

lab4_semaphores/main.cpp, lab6_timers/main.cpp, and lab9_dynamic_threads/main.cpp.

Definition at line 36 of file ksemaphore.h.

19.23.2 Member Function Documentation

19.23.2.1 GetCount()

```
uint16_t Mark3::Semaphore::GetCount ( )
```

Return the current semaphore counter.

This can be usedd by a thread to bypass blocking on a semaphore - allowing it to do other things until a non-zero count is returned, instead of blocking until the semaphore is posted.

Returns

The current semaphore counter value.

19.23.2.2 Init()

Initialize a semaphore before use.

Must be called before attempting post/pend operations on the object.

This initialization is required to configure the behavior of the semaphore with regards to the initial and maximum values held by the semaphore. By providing access to the raw initial and maximum count elements of the semaphore, these objects are able to be used as either counting or binary semaphores.

To configure a semaphore object for use as a binary semaphore, set values of 0 and 1 respectively for the initial/maximum value parameters.

Any other combination of values can be used to implement a counting semaphore.

Parameters

u16InitVal←	Initial value held by the semaphore
_	
u16Max⇔	Maximum value for the semaphore. Must be nonzero.
Val_	

Examples:

lab6 timers/main.cpp, and lab9 dynamic threads/main.cpp.

```
19.23.2.3 Pend() [1/2]
```

```
void Mark3::Semaphore::Pend ( )
```

Decrement the semaphore count.

If the count is zero, the calling Thread will block until the semaphore is posted, and the Thread's priority is higher than that of any other Thread blocked on the object.

Examples:

lab4_semaphores/main.cpp.

```
19.23.2.4 Pend() [2/2]
bool Mark3::Semaphore::Pend (
```

uint32_t u32WaitTimeMS_)

Decrement the semaphore count.

If the count is zero, the thread will block until the semaphore is pended. If the specified interval expires before the thread is unblocked, then the status is returned back to the user.

Returns

true - semaphore was acquired before the timeout false - timeout occurred before the semaphore was claimed.

19.23.2.5 Pend_i()

Pend_i.

Internal function used to abstract timed and untimed semaphore pend operations.

Parameters

u32WaitTimeM⊷	Time in MS to wait
S_	

Returns

true on success, false on failure.

19.23.2.6 Post()

```
bool Mark3::Semaphore::Post ( )
```

Increment the semaphore count.

If the semaphore count is zero at the time this is called, and there are threads blocked on the object, this will immediately unblock the highest-priority blocked Thread.

Note that if the priority of that Thread is higher than the current thread's priority, a context switch will occur and control will be relinquished to that Thread.

Returns

true if the semaphore was posted, false if the count is already maxed out.

Examples:

lab4_semaphores/main.cpp, and lab6_timers/main.cpp.

19.23.2.7 WakeMe()

Wake a thread blocked on the semaphore.

This is an internal function used for implementing timed semaphores relying on timer callbacks. Since these do not have access to the private data of the semaphore and its base classes, we have to wrap this as a public method - do not used this for any other purposes.

19.23.2.8 WakeNext()

```
uint8_t Mark3::Semaphore::WakeNext ( ) [private]
```

Wake the next thread waiting on the semaphore.

Used internally.

The documentation for this class was generated from the following file:

/home/moslevin/projects/github/m3-repo/kernel/src/public/ksemaphore.h

19.24 Mark3::Thread Class Reference

Object providing fundamental multitasking support in the kernel.

```
#include <thread.h>
```

Inheritance diagram for Mark3::Thread:



Public Member Functions

```
    void Init (K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_, ThreadEntryFunc

  pfEntryPoint_, void *pvArg_)

    void Start ()

     Start.
• void Stop ()
     Stop.

    ThreadList * GetOwner (void)

     GetOwner.

    ThreadList * GetCurrent (void)

     GetCurrent.

    PORT_PRIO_TYPE GetPriority (void)

     GetPriority.

    PORT_PRIO_TYPE GetCurPriority (void)

      GetCurPriority.

    void SetQuantum (uint16_t u16Quantum_)

     SetQuantum.

    uint16_t GetQuantum (void)

     GetQuantum.

    void SetCurrent (ThreadList *pclNewList_)

     SetCurrent.

    void SetOwner (ThreadList *pclNewList_)

     SetOwner.

    void SetPriority (PORT_PRIO_TYPE uXPriority_)

     SetPriority.

    void InheritPriority (PORT_PRIO_TYPE uXPriority_)

     InheritPriority.
• void Exit ()

    void SetID (uint8_t u8ID_)

     SetID.
• uint8_t GetID ()
     GetID.

    uint16_t GetStackSlack ()

     GetStackSlack.
· uint16 t GetEventFlagMask ()
     GetEventFlagMask returns the thread's current event-flag mask, which is used in conjunction with the EventFlag
     blocking object type.

    void SetEventFlagMask (uint16_t u16Mask_)

     SetEventFlagMask Sets the active event flag bitfield mask.

    void SetEventFlagMode (EventFlagOperation eMode )

     SetEventFlagMode Sets the active event flag operation mode.

    EventFlagOperation GetEventFlagMode ()

     GetEventFlagMode Returns the thread's event flag's operating mode.

    Timer * GetTimer ()

     Return a pointer to the thread's timer object.

    void SetExpired (bool bExpired_)

     SetExpired.

    bool GetExpired ()
```

```
GetExpired.
```

· void InitIdle ()

InitIdle Initialize this Thread object as the Kernel's idle thread.

void * GetExtendedContext ()

GetExtendedContext.

void SetExtendedContext (void *pvData_)

SetExtendedContext.

ThreadState GetState ()

GetState Returns the current state of the thread to the caller.

void SetState (ThreadState eState_)

SetState Set the thread's state to a new value.

K_WORD * GetStack ()

GetStack.

• uint16_t GetStackSize ()

GetStackSize.

Static Public Member Functions

```
    static Thread * Init (uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_, ThreadEntryFunc pfEntry← Point_, void *pvArg_)
```

Init.

static void Sleep (uint32_t u32TimeMs_)

Sleep

• static void USleep (uint32_t u32TimeUs_)

USleep.

• static void Yield (void)

Yield.

Private Member Functions

void SetPriorityBase (PORT_PRIO_TYPE uXPriority_)
 SetPriorityBase.

Static Private Member Functions

static void ContextSwitchSWI (void)

ContextSwitchSWI.

Private Attributes

K_WORD * m_pwStackTop

Pointer to the top of the thread's stack.

K_WORD * m_pwStack

Pointer to the thread's stack.

uint8_t m_u8ThreadID

Thread ID.

• PORT PRIO TYPE m uXPriority

Default priority of the thread.

• PORT_PRIO_TYPE m_uXCurPriority

Current priority of the thread (priority inheritence)

• ThreadState m_eState

Enum indicating the thread's current state.

void * m_pvExtendedContext

Pointer provided to a Thread to implement thread-local storage.

• uint16_t m_u16StackSize

Size of the stack (in bytes)

• ThreadList * m_pclCurrent

Pointer to the thread-list where the thread currently resides.

• ThreadList * m_pclOwner

Pointer to the thread-list where the thread resides when active.

ThreadEntryFunc m pfEntryPoint

The entry-point function called when the thread starts.

void * m_pvArg

Pointer to the argument passed into the thread's entrypoint.

• uint16 t m u16Quantum

Thread quantum (in milliseconds)

uint16_t m_u16FlagMask

Event-flag mask.

EventFlagOperation m_eFlagMode

Event-flag mode.

· Timer m clTimer

Timer used for blocking-object timeouts.

bool m_bExpired

Indicate whether or not a blocking-object timeout has occurred.

Additional Inherited Members

19.24.1 Detailed Description

Object providing fundamental multitasking support in the kernel.

Examples:

lab10_notifications/main.cpp, lab11_mailboxes/main.cpp, lab1_kernel_setup/main.cpp, lab2_idle_← function/main.cpp, lab3_round_robin/main.cpp, lab4_semaphores/main.cpp, lab5_mutexes/main.cpp, lab6← _timers/main.cpp, lab7_events/main.cpp, lab8_messages/main.cpp, and lab9_dynamic_threads/main.cpp.

Definition at line 62 of file thread.h.

19.24.2 Member Function Documentation

19.24.2.1 ContextSwitchSWI()

ContextSwitchSWI.

This code is used to trigger the context switch interrupt. Called whenever the kernel decides that it is necessary to swap out the current thread for the "next" thread.

Definition at line 493 of file thread.cpp.

19.24.2.2 Exit()

```
void Mark3::Thread::Exit ( )
```

Exit.

Remove the thread from being scheduled again. The thread is effectively destroyed when this occurs. This is extremely useful for cases where a thread encounters an unrecoverable error and needs to be restarted, or in the context of systems where threads need to be created and destroyed dynamically.

This must not be called on the idle thread.

Examples:

lab9_dynamic_threads/main.cpp.

19.24.2.3 GetCurPriority()

GetCurPriority.

Return the priority of the current thread

Returns

Priority of the current thread

Definition at line 184 of file thread.h.

19.24.2.4 GetCurrent()

GetCurrent.

Return the ThreadList where the thread is currently located

Returns

Pointer to the thread's current list

Definition at line 167 of file thread.h.

19.24.2.5 GetEventFlagMask()

```
uint16_t Mark3::Thread::GetEventFlagMask ( ) [inline]
```

GetEventFlagMask returns the thread's current event-flag mask, which is used in conjunction with the EventFlag blocking object type.

Returns

A copy of the thread's event flag mask

Definition at line 329 of file thread.h.

19.24.2.6 GetEventFlagMode()

```
EventFlagOperation Mark3::Thread::GetEventFlagMode ( ) [inline]
```

GetEventFlagMode Returns the thread's event flag's operating mode.

Returns

The thread's event flag mode.

Definition at line 345 of file thread.h.

19.24.2.7 GetExpired()

```
bool Mark3::Thread::GetExpired ( )
```

GetExpired.

Return the status of the most-recent blocking call on the thread.

Returns

true - call expired, false - call did not expire

19.24.2.8 GetExtendedContext()

```
void* Mark3::Thread::GetExtendedContext ( ) [inline]
```

GetExtendedContext.

Return the Thread object's extended-context data pointer. Used by code implementing a user-defined thread-local storage model. Pointer exists only for the lifespan of the Thread.

Returns

Thread's extended context data pointer.

Definition at line 393 of file thread.h.

19.24.2.9 GetID()

```
uint8_t Mark3::Thread::GetID ( ) [inline]
```

GetID.

Return the 8-bit ID corresponding to this thread.

Returns

Thread's 8-bit ID, set by the user

Definition at line 306 of file thread.h.

19.24.2.10 GetOwner()

GetOwner.

Return the ThreadList where the thread belongs when it's in the active/ready state in the scheduler.

Returns

Pointer to the Thread's owner list

Definition at line 159 of file thread.h.

19.24.2.11 GetPriority()

GetPriority.

Return the priority of the current thread

Returns

Priority of the current thread

Definition at line 176 of file thread.h.

19.24.2.12 GetQuantum()

Get Quantum.

Get the thread's round-robin execution quantum.

Returns

The thread's quantum

Definition at line 201 of file thread.h.

19.24.2.13 GetStack()

```
K_WORD* Mark3::Thread::GetStack ( ) [inline]
```

GetStack.

Returns

Pointer to the blob of memory used as the thread's stack

Definition at line 429 of file thread.h.

19.24.2.14 GetStackSize()

```
uint16_t Mark3::Thread::GetStackSize ( ) [inline]
```

GetStackSize.

Returns

Size of the thread's stack in bytes

Definition at line 435 of file thread.h.

19.24.2.15 GetStackSlack()

```
uint16_t Mark3::Thread::GetStackSlack ( )
```

GetStackSlack.

Performs a (somewhat lengthy) check on the thread stack to check the amount of stack margin (or "slack") remaining on the stack. If you're having problems with blowing your stack, you can run this function at points in your code during development to see what operations cause problems. Also useful during development as a tool to optimally size thread stacks.

Returns

The amount of slack (unused bytes) on the stack

ToDo: Reverse the logic for MCUs where stack grows UP instead of down

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 352 of file thread.cpp.

19.24.2.16 GetState()

```
ThreadState Mark3::Thread::GetState ( ) [inline]
```

GetState Returns the current state of the thread to the caller.

Can be used to determine whether or not a thread is ready (or running), stopped, or terminated/exit'd.

Returns

ThreadState_t representing the thread's current state

Examples:

```
lab9_dynamic_threads/main.cpp.
```

Definition at line 415 of file thread.h.

19.24.2.17 InheritPriority()

InheritPriority.

Allow the thread to run at a different priority level (temporarily) for the purpose of avoiding priority inversions. This should only be called from within the implementation of blocking-objects.

Parameters

uX⊷	New Priority to boost to.
Priority_	

Definition at line 482 of file thread.cpp.

void * pvArg_)

Init.

Initialize a thread prior to its use. Initialized threads are placed in the stopped state, and are not scheduled until the thread's start method has been invoked first.

Parameters

pwStack_	Pointer to the stack to use for the thread
u16Stack⇔	Size of the stack (in bytes)
Size_	
uXPriority_	Priority of the thread $(0 = idle, 7 = max)$
pfEntryPoint⇔	This is the function that gets called when the thread is started
_	
pvArg_	Pointer to the argument passed into the thread's entrypoint function.

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 72 of file thread.cpp.

Init.

Create and initialize a new thread, using memory from the auto-allocated heap region to supply both the thread object and its stack. The thread returned can then be started using the Start() method directly. Note that the memory used to create this thread cannot be reclaimed, and so this API is only suitable for threads that exist for the duration of runtime.

Parameters

u16Stack⊷ Size_	Size of the stack (in bytes)
uXPriority_	Priority of the thread (0 = idle, 7 = max)
pfEntryPoint⇔ –	This is the function that gets called when the thread is started
pvArg_	Pointer to the argument passed into the thread's entrypoint function.

Returns

Pointer to a newly-created thread.

19.24.2.20 InitIdle()

```
void Mark3::Thread::InitIdle ( )
```

InitIdle Initialize this Thread object as the Kernel's idle thread.

There should only be one of these, maximum, in a given system.

19.24.2.21 SetCurrent()

SetCurrent.

Set the thread's current to the specified thread list

Parameters

pclNew⊷	Pointer to the threadlist to apply thread ownership
List_	

Definition at line 211 of file thread.h.

19.24.2.22 SetEventFlagMask()

```
void Mark3::Thread::SetEventFlagMask ( \label{eq:mark3} \mbox{uint16\_t} \ u16\mbox{\it Mask} \ \ ) \ \ \mbox{[inline]}
```

SetEventFlagMask Sets the active event flag bitfield mask.

Parameters



Definition at line 334 of file thread.h.

19.24.2.23 SetEventFlagMode()

SetEventFlagMode Sets the active event flag operation mode.

Parameters

e⇔ Mode⇔	Event flag operation mode, defines the logical operator to apply to the event flag.
Mode⊷	

Definition at line 340 of file thread.h.

19.24.2.24 SetExpired()

```
void Mark3::Thread::SetExpired (
          bool bExpired_)
```

SetExpired.

Set the status of the current blocking call on the thread.

Parameters

b⇔	true - call expired, false - call did not expire
Expired←	

19.24.2.25 SetExtendedContext()

SetExtendedContext.

Assign the Thread object's extended-context data pointer. Used by code implementing a user-defined thread-local storage model.

Object assigned to the context pointer should persist for the duration of the Thread.

Parameters

pv⊷	Object to assign to the extended data pointer.+
Data_	

Definition at line 406 of file thread.h.

19.24.2.26 SetID()

SetID.

Set an 8-bit ID to uniquely identify this thread.

Parameters

u8l⊷	8-bit Thread ID, set by the user
D_	

Definition at line 298 of file thread.h.

19.24.2.27 SetOwner()

SetOwner.

Set the thread's owner to the specified thread list

Parameters

pclNew⊷	Pointer to the threadlist to apply thread ownership
List_	

Definition at line 219 of file thread.h.

19.24.2.28 SetPriority()

SetPriority.

Set the priority of the Thread (running or otherwise) to a different level. This activity involves re-scheduling, and must be done so with due caution, as it may effect the determinism of the system.

This should *always* be called from within a critical section to prevent system issues.

Parameters

uX⊷	New priority of the thread
Priority_	

Definition at line 433 of file thread.cpp.

19.24.2.29 SetPriorityBase()

SetPriorityBase.

Parameters

```
uX←
Priority_
```

Definition at line 419 of file thread.cpp.

19.24.2.30 SetQuantum()

SetQuantum.

Set the thread's round-robin execution quantum.

Parameters

u16 	Thread's execution quantum (in milliseconds)
Quantum_	

Definition at line 193 of file thread.h.

19.24.2.31 SetState()

SetState Set the thread's state to a new value.

This is only to be used by code within the kernel, and is not indended for use by an end-user.

Parameters

<i>e</i> ←	New thread state to set.
State←	
_	

Definition at line 423 of file thread.h.

19.24.2.32 Sleep()

Sleep.

Put the thread to sleep for the specified time (in milliseconds). Actual time slept may be longer (but not less than) the interval specified.

Parameters

u32Time←	Time to sleep (in ms)
Ms_	

Examples:

lab10_notifications/main.cpp, lab11_mailboxes/main.cpp, lab1_kernel_setup/main.cpp, lab2_idle_← function/main.cpp, lab7_events/main.cpp, lab8_messages/main.cpp, and lab9_dynamic_threads/main.cpp.

19.24.2.33 Start()

Start.

Start the thread - remove it from the stopped list, add it to the scheduler's list of threads (at the thread's set priority), and continue along.

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 147 of file thread.cpp.

19.24.2.34 Stop()

```
void Mark3::Thread::Stop ( )
```

Stop.

Stop a thread that's actively scheduled without destroying its stacks. Stopped threads can be restarted using the Start() API.

Definition at line 189 of file thread.cpp.

19.24.2.35 USleep()

USleep.

Put the thread to sleep for the specified time (in microseconds). Actual time slept may be longer (but not less than) the interval specified.

Parameters

u32Time←	Time to sleep (in microseconds)
Us_	

19.24.2.36 Yield()

Yield.

Yield the thread - this forces the system to call the scheduler and determine what thread should run next. This is typically used when threads are moved in and out of the scheduler.

Definition at line 387 of file thread.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/github/m3-repo/kernel/src/public/thread.h
- /home/moslevin/projects/github/m3-repo/kernel/src/thread.cpp

19.25 Mark3::ThreadList Class Reference

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

```
#include <threadlist.h>
```

Inheritance diagram for Mark3::ThreadList:



Public Member Functions

• ThreadList ()

ThreadList.

void SetPriority (PORT_PRIO_TYPE uXPriority_)

SetPriority.

void SetMapPointer (PriorityMap *pclMap_)

SetMapPointer.

void Add (LinkListNode *node_)

Add

• void Add (LinkListNode *node_, PriorityMap *pclMap_, PORT_PRIO_TYPE uXPriority_)

Add

void AddPriority (LinkListNode *node_)

AddPriority.

void Remove (LinkListNode *node_)

Remove.

Thread * HighestWaiter ()

HighestWaiter.

Private Attributes

• PORT_PRIO_TYPE m_uXPriority

Priority of the threadlist.

• PriorityMap * m_pclMap

Pointer to the bitmap/flag to set when used for scheduling.

Additional Inherited Members

19.25.1 Detailed Description

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

Definition at line 36 of file threadlist.h.

19.25.2 Constructor & Destructor Documentation

19.25.2.1 ThreadList()

```
Mark3::ThreadList::ThreadList ( ) [inline]
```

ThreadList.

Default constructor - zero-initializes the data.

Definition at line 45 of file threadlist.h.

19.25.3 Member Function Documentation

Add.

Add a thread to the threadlist.

Parameters

node⊷	Pointer to the thread (link list node) to add to the list	1
_		

Definition at line 53 of file threadlist.cpp.

Add.

Add a thread to the threadlist, specifying the flag and priority at the same time.

Parameters

node_	Pointer to the thread to add (link list node)
pclMap_	Pointer to the bitmap flag to set (if used in a scheduler context), or NULL for non-scheduler.
uX⊷	Priority of the threadlist
Priority_	

Definition at line 102 of file threadlist.cpp.

19.25.3.3 AddPriority()

AddPriority.

Add a thread to the list such that threads are ordered from highest to lowest priority from the head of the list.

Parameters

node↩	Pointer to a thread to add to the list.

Definition at line 66 of file threadlist.cpp.

19.25.3.4 HighestWaiter()

```
Thread * Mark3::ThreadList::HighestWaiter ( )
```

HighestWaiter.

Return a pointer to the highest-priority thread in the thread-list.

Returns

Pointer to the highest-priority thread

Definition at line 125 of file threadlist.cpp.

19.25.3.5 Remove()

Remove.

Remove the specified thread from the threadlist

Parameters

node⊷	Pointer to the thread to remove

Definition at line 112 of file threadlist.cpp.

19.25.3.6 SetMapPointer()

SetMapPointer.

Set the pointer to a bitmap to use for this threadlist. Once again, only needed when the threadlist is being used for scheduling purposes.

Parameters

pcl←	Pointer to the priority map object used to track this thread.
Мар_	

Definition at line 47 of file threadlist.cpp.

19.25.3.7 SetPriority()

SetPriority.

Set the priority of this threadlist (if used for a scheduler).

Parameters

uX⊷	Priority level of the thread list
Priority_	

Definition at line 41 of file threadlist.cpp.

The documentation for this class was generated from the following files:

- /home/moslevin/projects/github/m3-repo/kernel/src/public/threadlist.h
- /home/moslevin/projects/github/m3-repo/kernel/src/threadlist.cpp

19.26 Mark3::ThreadPort Class Reference

Class defining the architecture specific functions required by the kernel.

```
#include <threadport.h>
```

Static Public Member Functions

static void StartThreads ()
 StartThreads.

Static Private Member Functions

static void InitStack (Thread *pstThread_)
 InitStack.

19.26.1 Detailed Description

Class defining the architecture specific functions required by the kernel.

This is limited (at this point) to a function to start the scheduler, and a function to initialize the default stack-frame for a thread.

Definition at line 187 of file threadport.h.

19.26.2 Member Function Documentation

19.26.2.1 InitStack()

InitStack.

Initialize the thread's stack.

Parameters

pst←	Pointer to the thread to initialize
Thread_	

Definition at line 40 of file threadport.cpp.

19.26.2.2 StartThreads()

```
void Mark3::ThreadPort::StartThreads ( ) [static]
```

StartThreads.

Function to start the scheduler, initial threads, etc.

Definition at line 134 of file threadport.cpp.

The documentation for this class was generated from the following files:


- /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/threadport.h
- /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/threadport.cpp

Mark3::Timer Class Reference 19.27

Kernel-managed software timers.

```
#include <timer.h>
```

Inheritance diagram for Mark3::Timer:



Public Member Functions

SetIntervalUSeconds.

SetTolerance.

void SetTolerance (uint32_t u32Ticks_)

```
• Timer ()
      Timer.
· void Init ()
     Init.

    void Start (bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback pfCallback_, void *pvData_)

    void Start (bool bRepeat , uint32 t u32IntervalMs , uint32 t u32ToleranceMs , TimerCallback pfCallback ,

 void *pvData_)
     Start.
• void Start ()
     Start.
• void Stop ()
     Stop.

    void SetFlags (uint8_t u8Flags_)

    void SetCallback (TimerCallback pfCallback_)

     SetCallback.

    void SetData (void *pvData_)

     SetData.
void SetOwner (Thread *pclOwner_)
     SetOwner.

    void SetIntervalTicks (uint32 t u32Ticks )

     SetIntervalTicks.

    void SetIntervalSeconds (uint32_t u32Seconds_)

     SetIntervalSeconds.
• uint32_t GetInterval ()
     GetInterval.

    void SetIntervalMSeconds (uint32_t u32MSeconds_)

     SetIntervalMSeconds.

    void SetIntervalUSeconds (uint32_t u32USeconds_)
```

Private Member Functions

void SetInitialized ()

SetInitialized.

• bool IsInitialized (void)

IsInitialized.

Private Attributes

· uint8 t m u8Initialized

Cookie used to determine whether or not the timer is initialized.

uint8_t m_u8Flags

Flags for the timer, defining if the timer is one-shot or repeated.

· TimerCallback m pfCallback

Pointer to the callback function.

· uint32 t m u32Interval

Interval of the timer in timer ticks.

• uint32_t m_u32TimeLeft

Time remaining on the timer.

uint32_t m_u32TimerTolerance

Maximum tolerance (usedd for timer harmonization)

• Thread * m pclOwner

Pointer to the owner thread.

void * m_pvData

Pointer to the callback data.

Additional Inherited Members

19.27.1 Detailed Description

Kernel-managed software timers.

Kernel-managed timers, used to provide high-precision high-resolution delays. Functionality is useful to both usercode, and is used extensively within the kernel and its blocking objects to implement round-robin scheduling, thread sleep, and timeouts. Relies on a single hardware timer, which is multiplexed through the kernel.

Examples:

lab6_timers/main.cpp.

Definition at line 111 of file timer.h.

19.27.2 Constructor & Destructor Documentation

19.27.2.1 Timer()

```
Mark3::Timer::Timer ( )
```

Timer.

Default Constructor - Do nothing. Allow the init call to perform the necessary object initialization prior to use.

19.27.3 Member Function Documentation

```
19.27.3.1 GetInterval()
```

```
uint32_t Mark3::Timer::GetInterval ( ) [inline]
```

GetInterval.

Return the timer's configured interval in ticks

Returns

Timer interval in ticks.

Definition at line 239 of file timer.h.

```
19.27.3.2 Init()
```

```
void Mark3::Timer::Init ( )
```

Init.

Re-initialize the Timer to default values.

19.27.3.3 IsInitialized()

IsInitialized.

Returns

Definition at line 281 of file timer.h.

19.27.3.4 SetCallback()

SetCallback.

Define the callback function to be executed on expiry of the timer

Parameters

pf⇔	Pointer to the callback function to call
Callback⊷	

Definition at line 196 of file timer.h.

19.27.3.5 SetData()

SetData.

Define a pointer to be sent to the timer callbcak on timer expiry

Parameters

pv⊷	Pointer to data to pass as argument into the callback
Data	

Definition at line 204 of file timer.h.

19.27.3.6 SetFlags()

SetFlags.

Set the timer's flags based on the bits in the u8Flags_ argument

Parameters

и8⇔	Flags to assign to the timer object. TIMERLIST_FLAG_ONE_SHOT for a one-shot timer, 0 for a
Flags_	continuous timer.

Definition at line 188 of file timer.h.

19.27.3.7 SetIntervalMSeconds()

SetIntervalMSeconds.

Set the timer expiry interval in milliseconds (platform agnostic)

Parameters

<i>u32M</i> ←	Time in milliseconds
Seconds_	

19.27.3.8 SetIntervalSeconds()

SetIntervalSeconds.

Set the timer expiry interval in seconds (platform agnostic)

Parameters

<i>u32</i> ⇔	Time in seconds
Seconds_	

19.27.3.9 SetIntervalTicks()

SetIntervalTicks.

Set the timer expiry in system-ticks (platform specific!)

Parameters

<i>u32</i> ⇔	Time in ticks
Ticks_	

19.27.3.10 SetIntervalUSeconds()

SetIntervalUSeconds.

Set the timer expiry interval in microseconds (platform agnostic)

Parameters

<i>u32U</i>	Time in microseconds
Seconds_	

19.27.3.11 SetOwner()

SetOwner.

Set the owner-thread of this timer object (all timers must be owned by a thread).

Parameters

pcl⇔	Owner thread of this timer object
Owner_	

Definition at line 213 of file timer.h.

19.27.3.12 SetTolerance()

SetTolerance.

Set the timer's maximum tolerance in order to synchronize timer processing with other timers in the system.

Parameters

<i>u32</i> ⇔	Maximum tolerance in ticks
Ticks_	

19.27.3.13 Start() [1/3]

Start.

Start a timer using default ownership, using repeats as an option, and millisecond resolution.

Parameters

bRepeat_	0 - timer is one-shot. 1 - timer is repeating.
u32Interval⊷	- Interval of the timer in miliseconds
Ms_	
pfCallback_	- Function to call on timer expiry
pvData_	- Data to pass into the callback function

Examples:

lab6_timers/main.cpp.

Start.

Start a timer using default ownership, using repeats as an option, and millisecond resolution.

Parameters

bRepeat_	0 - timer is one-shot. 1 - timer is repeating.
u32IntervalMs_	- Interval of the timer in miliseconds
u32Tolerance⊷	- Allow the timer expiry to be delayed by an additional maximum time, in order to have as
Ms_	many timers expire at the same time as possible.
pfCallback_	- Function to call on timer expiry
pvData_	- Data to pass into the callback function

```
19.27.3.15 Start() [3/3]
void Mark3::Timer::Start ( )
```

Start.

Start or restart a timer using parameters previously configured via calls to Start(<with args>), or via the a-la-carte parameter setter methods. This is especially useful for retriggering one-shot timers that have previously expired, using the timer's previous configuration.

```
19.27.3.16 Stop()
```

```
void Mark3::Timer::Stop ( )
```

Stop.

Stop a timer already in progress. Has no effect on timers that have already been stopped.

The documentation for this class was generated from the following file:


• /home/moslevin/projects/github/m3-repo/kernel/src/public/timer.h

19.28 Mark3::TimerList Class Reference

TimerList class - a doubly-linked-list of timer objects.

```
#include <timerlist.h>
```

Inheritance diagram for Mark3::TimerList:



Public Member Functions

```
• void Init ()
```

Init.

void Add (Timer *pclListNode_)

Add

• void Remove (Timer *pclLinkListNode_)

Remove.

void Process ()

Process.

Private Attributes

uint32_t m_u32NextWakeup

The time (in system clock ticks) of the next wakeup event.

• bool m_bTimerActive

Whether or not the timer is active.

Additional Inherited Members

19.28.1 Detailed Description

TimerList class - a doubly-linked-list of timer objects.

Definition at line 39 of file timerlist.h.

19.28.2 Member Function Documentation

19.28.2.1 Add()

Add.

Add a timer to the TimerList.

Parameters

pclList←	Pointer to the Timer to Add
Node_	

19.28.2.2 Init()

```
void Mark3::TimerList::Init ( )
```

Init.

Initialize the TimerList object. Must be called before using the object.

19.28.2.3 Process()

```
void Mark3::TimerList::Process ( )
```

Process.

Process all timers in the timerlist as a result of the timer expiring. This will select a new timer epoch based on the next timer to expire.

19.28.2.4 Remove()

Remove.

Remove a timer from the TimerList, cancelling its expiry.

Parameters

pclList←	Pointer to the Timer to remove
Node_	

The documentation for this class was generated from the following file:

/home/moslevin/projects/github/m3-repo/kernel/src/public/timerlist.h

19.29 Mark3::TimerScheduler Class Reference

"Static" Class used to interface a global TimerList with the rest of the kernel.

```
#include <timerscheduler.h>
```

Static Public Member Functions

```
• static void Init ()
```

Init

• static void Add (Timer *pclListNode_)

Add

• static void Remove (Timer *pclListNode_)

Remove.

• static void Process ()

Process.

Static Private Attributes

· static TimerList m clTimerList

TimerList object manipu32ated by the Timer Scheduler.

19.29.1 Detailed Description

"Static" Class used to interface a global TimerList with the rest of the kernel.

Definition at line 38 of file timerscheduler.h.

19.29.2 Member Function Documentation

```
19.29.2.1 Add()
```

Add.

Add a timer to the timer scheduler. Adding a timer implicitly starts the timer as well.

Parameters

pclList←	Pointer to the timer list node to add
Node_	

Definition at line 56 of file timerscheduler.h.

19.29.2.2 Init()

Init.

Initialize the timer scheduler. Must be called before any timer, or timer-derived functions are used.

Definition at line 47 of file timerscheduler.h.

19.29.2.3 Process()

```
static void Mark3::TimerScheduler::Process ( ) [inline], [static]
```

Process.

This function must be called on timer expiry (from the timer's ISR context). This will result in all timers being updated based on the epoch that just elapsed. The next timer epoch is set based on the next Timer object to expire.

Definition at line 74 of file timerscheduler.h.

19.29.2.4 Remove()

Remove.

Remove a timer from the timer scheduler. May implicitly stop the timer if this is the only active timer scheduled.

Parameters

pclList←	Pointer to the timer list node to remove
Node_	

Definition at line 65 of file timerscheduler.h.

The documentation for this class was generated from the following file:

 $\bullet \ \ / home/moslevin/projects/github/m3-repo/kernel/src/public/timerscheduler.h$

Chapter 20

File Documentation

20.1 /home/moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/public/fake_types.h File Reference

C-struct definitions that mirror.

```
#include <stdint.h>
#include <stddef.h>
#include <stdbool.h>
#include "mark3cfg.h"
```

20.1.1 Detailed Description

C-struct definitions that mirror.

This header contains a set of "fake" structures that have the same memory layout as the kernel objects in C++ (taking into account inheritence, etc.). These are used for sizing the opaque data blobs that are declared in C, which then become instantiated as C++ kernel objects via the bindings provided.

Definition in file fake_types.h.

20.2 fake_types.h

```
00030
00031 #pragma once
00032
00033 #if defined(__cplusplus)
00033 #11 dollars.
00035 #endif
00037 //---
00038 typedef struct {
          void* prev;
void* next;
00039
00040
00041 } Fake_LinkedListNode;
00042
00043 //----
00044 typedef struct {
00045 void* head;
00046 void* tail;
00047 } Fake_LinkedList;
00049 //----
00050 typedef struct {
00051 Fake_LinkedList fake_list;
00052
          PORT_PRIO_TYPE m_uXPriority;
00053
          void*
                           m_pclMap;
00054 } Fake_ThreadList;
00055
00056 //----
00057 typedef struct {
00058
          Fake_LinkedListNode m_ll_node;
00059 #if KERNEL_EXTRA_CHECKS
00060
        uint8_t
                               m u8Initialized:
00061 #endif
                             m_u8Flags;
m_pfCallback;
m_u32Interval;
m_u32TimeLeft;
m_u32TimerTolerance;
m_pclOwner;
m_pvData;
      uint8_t
00062
00063
          void*
00064
          uint32_t
00065
          uint32_t
00066
          uint32 t
00067
          void*
00068
          void*
00069 } Fake_Timer;
00070
00071 //----
00072 typedef struct {
       Fake_LinkedListNode m_ll_node;
K_WORD* m_pwStackTop;
K_WORD* m_pwStack;
00073
00074
00075
                                m_pwStack;
00076 uint8_t m_u8ThreadID;
00077 PORT_PRIO_TYPE m_uXPriority;
00078 PORT_PRIO_TYPE m_uXCurPriority;
00079 uint8 t m_eState:
00079
          uint8 t
                               m eState:
00080 #if KERNEL_USE_EXTENDED_CONTEXT
00081
          void*
                  m_pvExtendedContext;
00082 #endif
00083 #if KERNEL_USE_THREADNAME
00084
          const char* m_szName;
00085 #endif
00086 uint16_t m_u16StackSize;
          void* m_pclCurrent;
void* m_pclOwner;
00087
00088
        void*
void*
                  m_pfEntryPoint;
00089
00090
          void*
                   m_pvArg;
00091 #if KERNEL_USE_QUANTUM
00092
         uint16_t m_u16Quantum;
00093 #endif
00094 #if KERNEL_USE_EVENTFLAG
00095
       uint16_t m_u16FlagMask;
00096
          uint8_t m_eFlagMode;
00097 #endif
00098 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
          Fake_Timer m_clTimer;
00100 #endif
00101 #if KERNEL_USE_TIMEOUTS
00102
        bool m_bExpired;
00103 #endif
00104 } Fake_Thread;
00105
00106 //----
00107 typedef struct {
00108
          Fake_ThreadList thread_list;
00109 #if KERNEL_EXTRA_CHECKS
         uint8_t m_u8Initialized;
00110
00111 #endif
          uint16_t
00112
00113
00114 } Fake_Semaphore;
00115
00116 //----
```

20.2 fake_types.h 211

```
00117 typedef struct {
00118 Fake_ThreadList thread_list;
00119 #if KERNEL_EXTRA_CHECKS
        uint8_t
                        m_u8Initialized;
00120
00121 #endif
       uint8_t
bool
                         m_u8Recurse;
m_bReady;
00122
00123
        uint8_t
void*
00124
                          m_u8MaxPri;
                         m_pclOwner;
00125
00126 } Fake_Mutex;
00127
00128 //----
00129 typedef struct {
00130 Fake_LinkedListNode list_node;
                    m_pvData;
m_u16Code;
00131
          void*
         uint16_t
00132
00133 } Fake_Message;
00134
00135 //----
00136 typedef struct {
00137 Fake_Semaphore m_clSemaphore;
          Fake_LinkedList m_clLinkList;
00138
00139 } Fake_MessageQueue;
00140
00141 //---
00142 typedef struct {
00143
          Fake_LinkedList m_clList;
00144 } Fake_MessagePool;
00145
00146 //----
00147 typedef struct {
       uint16_t
00148
                          m_u16Head;
                      m_ul6Head;
m_ul6Tail;
m_ul6Count;
m_ul6Free;
m_ul6ElementSize;
m_pvBuffer:
00149
          uint16_t
00150
          uint16_t
00151
          uint16 t
00152
          uint16_t
00153
                          m_pvBuffer;
          void*
         Fake_Semaphore m_clRecvSem;
00154
00155 #if KERNEL_USE_TIMEOUTS
00156
         Fake_Semaphore m_clSendSem;
00157 #endif
00158 } Fake_Mailbox;
00159
00160 //----
00161 typedef struct {
00162
          Fake_ThreadList thread_list;
00163 #if KERNEL_EXTRA_CHECKS
                       m_u8Initialized;
00164
       uint8_t
00165 #endif
         bool
00166
                          m bPending;
00167 } Fake_Notify;
00168
00169 //----
00170 typedef struct {
00171 Fake_ThreadList thread_list;
00172 #if KERNEL_EXTRA_CHECKS
                        m_u8Initialized;
          uint8_t
00174 #endif
                         m_u16EventFlag;
00175
          uint16_t
00176 } Fake_EventFlag;
00177
00178 //----
00179 typedef struct {
00180 Fake_Mutex m_clGlobalMutex;
00181 Fake_Mutex m_clReaderMutex;
00182 uint8_t m_u8ReadCount;
00183 } Fake_ConditionVariable;
00184
00185 //----
00186 typedef struct {
00187 Fake_Mutex m_clMutex;
00188 Fake_Semaphore m_clSemaphore;
00189
          uint8_t m_u8Waiters;
00190 } Fake_ReaderWriterLock;
00191
00192 #if defined(__cplusplus)
00193
00194 #endif
```

20.3 /home/moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/public/mark3c.h File Reference

Implementation of C-language wrappers for the Mark3 kernel.

```
#include "mark3cfg.h"
#include "fake_types.h"
#include <stdint.h>
#include <stdbool.h>
```

Typedefs

```
    typedef void * EventFlag_t
```

EventFlag opaque handle data type.

typedef void * Mailbox_t

Mailbox opaque handle data type.

typedef void * Message_t

Message opaque handle data type.

typedef void * MessagePool_t

MessagePool opaque handle data type.

typedef void * MessageQueue_t

MessageQueue opaque handle data type.

typedef void * Mutex_t

Mutex opaque handle data type.

typedef void * Notify_t

Notification object opaque handle data type.

typedef void * Semaphore_t

Semaphore opaque handle data type.

typedef void * Thread_t

Thread opaque handle data type.

typedef void * Timer_t

Timer opaque handle data type.

typedef void * ConditionVariable_t

Condition Variable opaque handle data type.

typedef void * ReaderWriterLock_t

Reader-writer-lock opaque handle data type.

Enumerations

```
    enum event_flag_operation_t {
        EVENT_FLAG_ALL_SET, EVENT_FLAG_ANY_SET, EVENT_FLAG_ALL_CLEAR, EVENT_FIAG_ANY_
        CLEAR,
        EVENT_FLAG_PENDING_UNBLOCK }
```

Functions

```
    void Kernel_Init (void)

     Kernel_Init.

    void Kernel Start (void)

     Kernel_Start.

    bool Kernel_IsStarted (void)

     Kernel IsStarted.

    void Kernel_SetPanic (panic_func_t pfPanic_)

     Kernel_SetPanic.

    bool Kernel_IsPanic (void)

     Kernel_IsPanic.

    void Kernel_Panic (uint16_t u16Cause_)

     Kernel_Panic.

    void Scheduler_Enable (bool bEnable_)

     Scheduler Enable.

    bool Scheduler_IsEnabled (void)

     Scheduler_IsEnabled.

    Thread_t Scheduler_GetCurrentThread (void)

     Scheduler_GetCurrentThread.

    void Thread_Init (Thread_t handle, K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE u←

 XPriority_, thread_entry_func_t pfEntryPoint_, void *pvArg_)
• void Thread_Start (Thread_t handle)
     Thread_Start.

    void Thread_Stop (Thread_t handle)

      Thread_Stop.
• PORT PRIO TYPE Thread GetPriority (Thread t handle)
     Thread GetPriority.

    PORT_PRIO_TYPE Thread_GetCurPriority (Thread_t handle)

      Thread GetCurPriority.

    void Thread_SetPriority (Thread_t handle, PORT_PRIO_TYPE uXPriority_)

      Thread_SetPriority.

    void Thread_Yield (void)

      Thread_Yield.

    void Thread_SetID (Thread_t handle, uint8_t u8ID_)

      Thread_SetID.

    uint8_t Thread_GetID (Thread_t handle)

      Thread GetID.

    uint16 t Thread GetStackSlack (Thread t handle)

      Thread_GetStackSlack.

    thread_state_t Thread_GetState (Thread_t handle)
```

20.3.1 Detailed Description

Thread_GetState.

Implementation of C-language wrappers for the Mark3 kernel.

Header providing C-language API bindings for the Mark3 kernel.

Definition in file mark3c.h.

20.3.2 Enumeration Type Documentation

20.3.2.1 event_flag_operation_t

```
enum event_flag_operation_t
```

Enumerator

EVENT_FLAG_ALL_SET	Block until all bits in the specified bitmask are set.
EVENT_FLAG_ANY_SET	Block until any bits in the specified bitmask are set.
EVENT_FLAG_ALL_CLEAR	Block until all bits in the specified bitmask are cleared.
EVENT_FIAG_ANY_CLEAR	Block until any bits in the specified bitmask are cleared.
EVENT_FLAG_PENDING_UNBLOCK	Special code. Not used by user

Definition at line 72 of file mark3c.h.

20.3.3 Function Documentation

20.3.3.1 Kernel_Init()

```
void Kernel_Init (
     void )
```

Kernel_Init.

See also

void Kernel::Init()

Definition at line 204 of file mark3c.cpp.

20.3.3.2 Kernel_IsPanic()

 $Kernel_IsPanic.$

See also

bool Kernel::IsPanic()

Returns

Whether or not the kernel is in a panic state

Definition at line 228 of file mark3c.cpp.

20.3.3.3 Kernel_IsStarted()

 $Kernel_IsStarted.$

See also

bool Kernel::IsStarted()

Returns

Whether or not the kernel has started - true = running, false = not started

Definition at line 216 of file mark3c.cpp.

20.3.3.4 Kernel_Panic()

Kernel_Panic.

See also

void Kernel::Panic(uint16_t u16Cause_)

Parameters

u16⇔	Reason for the kernel panic
Cause_	

Definition at line 234 of file mark3c.cpp.

20.3.3.5 Kernel_SetPanic()

 $Kernel_SetPanic.$

See also

void Kernel::SetPanic(PanicFunc_t pfPanic_)

Parameters

pf⇔	Panic function pointer
Panic⊷	
_	

Definition at line 222 of file mark3c.cpp.

```
20.3.3.6 Kernel_Start()
```

```
void Kernel_Start (
     void )
```

Kernel_Start.

See also

void Kernel::Start()

Definition at line 210 of file mark3c.cpp.

20.3.3.7 Scheduler_Enable()

```
void Scheduler_Enable (
          bool bEnable_ )
```

Scheduler_Enable.

See also

void Scheduler::SetScheduler(bool bEnable_)

Parameters

bEnable_true to enable, false to disable the scheduler

Definition at line 303 of file mark3c.cpp.

20.3.3.8 Scheduler_GetCurrentThread()

 $Scheduler_GetCurrentThread.$

See also

Thread* Scheduler::GetCurrentThread()

Returns

Handle of the currently-running thread

Definition at line 315 of file mark3c.cpp.

20.3.3.9 Scheduler_IsEnabled()

```
bool Scheduler_IsEnabled ( \mbox{void} \quad \mbox{)}
```

Scheduler_IsEnabled.

See also

bool Scheduler::IsEnabled()

Returns

true - scheduler enabled, false - disabled

Definition at line 309 of file mark3c.cpp.

20.3.3.10 Thread_GetCurPriority()

Thread_GetCurPriority.

See also

PORT_PRIO_TYPE Thread::GetCurPriority()

Parameters

handle Handle of the thread

Returns

Current priority of the thread considering priority inheritence

Definition at line 370 of file mark3c.cpp.

```
20.3.3.11 Thread_GetID()
```

Thread_GetID.

See also

uint8_t Thread::GetID()

Parameters

handle	Handle of the thread
--------	----------------------

Returns

Return ID assigned to the thread

Definition at line 449 of file mark3c.cpp.

20.3.3.12 Thread_GetPriority()

Thread_GetPriority.

See also

```
PORT_PRIO_TYPE Thread::GetPriority()
```

Parameters

handle	Handle of the thread
--------	----------------------

Returns

Current priority of the thread not considering priority inheritence

Definition at line 364 of file mark3c.cpp.

20.3.3.13 Thread_GetStackSlack()

 $Thread_GetStackSlack.$

See also

uint16_t Thread::GetStackSlack()

Parameters

Returns

Return the amount of unused stack on the given thread

Definition at line 455 of file mark3c.cpp.

20.3.3.14 Thread_GetState()

Thread_GetState.

See also

ThreadState Thread::GetState()

Parameters

handle Handle of the thread

Returns

The thread's current execution state

Definition at line 461 of file mark3c.cpp.

20.3.3.15 Thread_Init()

Thread_Init.

See also

```
void Thread::Init(K_WORD *pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_, Thread← Entry_t pfEntryPoint_, void *pvArg_)
```

Parameters

handle	Handle of the thread to initialize
pwStack_	Pointer to the stack to use for the thread
u16Stack⊷ Size_	Size of the stack (in bytes)
uXPriority_	Priority of the thread (0 = idle, 7 = max)
pfEntryPoint↔ _	This is the function that gets called when the thread is started
pvArg_	Pointer to the argument passed into the thread's entrypoint function.

Definition at line 324 of file mark3c.cpp.

20.3.3.16 Thread_SetID()

Thread_SetID.

See also

void Thread::SetID(uint8_t u8ID_)

Parameters

handle	Handle of the thread
u8l⊷	ID To assign to the thread
D	

Definition at line 443 of file mark3c.cpp.

20.3.3.17 Thread_SetPriority()

Thread_SetPriority.

See also

void Thread::SetPriority(PORT_PRIO_TYPE uXPriority_)

Parameters

handle	Handle of the thread
uX⇔	New priority level
Priority_	

Definition at line 391 of file mark3c.cpp.

20.3.3.18 Thread_Start()

Thread_Start.

See also

void Thread::Start()

Parameters

, ,,	11 11 (11 11 11 1 1
handle	Handle of the thread to start
Hariaic	Transic of the thread to start

Definition at line 336 of file mark3c.cpp.

20.3.3.19 Thread_Stop()

Thread_Stop.

See also

void Thread::Stop()

Parameters

handle	Handle of the thread to stop
--------	------------------------------

Definition at line 343 of file mark3c.cpp.

20.3.3.20 Thread_Yield()

```
void Thread_Yield (
     void )
```

Thread_Yield.

See also

void Thread::Yield()

Definition at line 438 of file mark3c.cpp.

20.4 mark3c.h

```
00001 /*==
00002
00003
00004 |
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00021 #pragma once
00022
00023 #include "mark3cfg.h"
00024 #include "fake_types.h"
00025
00026 #include <stdint.h>
00027 #include <stdbool.h>
00028
00029 #if defined(__cplusplus)
00030 extern "C" {
00031 #endif
00032
00033 //--
00034 ^{\prime\prime} Define a series of handle types to be used in place of the underlying classes 00035 ^{\prime\prime} of Mark3.
00036 typedef void* EventFlag_t;
00037 typedef void* Mailbox_t;
00038 typedef void* Message_t;
00039 typedef void* MessagePool_t;
00040 typedef void* MessageQueue_t;
00041 typedef void* Mutex_t;
00042 typedef void* Notify_t;
00043 typedef void* Semaphore_t;
00044 typedef void* Thread_t;
00045 typedef void* Timer_t;
```

20.4 mark3c.h 223

```
00046 typedef void* ConditionVariable_t;
00047 typedef void* ReaderWriterLock_t;
00048
00049 //-
00050 // Function pointer types used by Kernel APIs
00051 typedef void (*thread_create_callout_t)(Thread_t hThread_);
00052 typedef void (*thread_exit_callout_t)(Thread_t hThread_);
00053 typedef void (*thread_context_callout_t)(Thread_t hThread_);
00054
00055
00056 // Use the sizes of the structs in fake_types.h to generate opaque object-blobs
00057 // that get instantiated as kernel objects (from the C++ code) later. 00058 #define THREAD_SIZE (sizeof(Fake_Thread))
00059 #define TIMER_SIZE (sizeof(Fake_Timer))
00060 #define SEMAPHORE_SIZE (sizeof(Fake_Semaphore))
00061 #define MUTEX_SIZE (sizeof(Fake_Mutex))
00062 #define MESSAGE_SIZE (sizeof(Fake_Message))
00063 #define MESSAGEQUEUE_SIZE (sizeof(Fake_MessageQueue))
00064 #define MAILBOX_SIZE (sizeof(Fake_Mailbox))
00065 #define NOTIFY_SIZE (sizeof(Fake_Notify))
00066 #define EVENTFLAG_SIZE (sizeof(Fake_EventFlag))
00067 #define MESSAGEPOOL_SIZE (sizeof(Fake_MessagePool))
00068 #define CONDITIONVARIABLE_SIZE (sizeof(Fake_ConditionVariable))
{\tt 00069~\#define~READERWRITERLOCK\_SIZE~(size of (Fake\_ReaderWriterLock))}
00070
00071 //-
00072 typedef enum {
00073
          EVENT_FLAG_ALL_SET,
00074
          EVENT_FLAG_ANY_SET
00075
          EVENT_FLAG_ALL_CLEAR,
          EVENT_F1AG_ANY_CLEAR,
00076
          EVENT_FLAG_PENDING_UNBLOCK
00078 } event_flag_operation_t;
00079
00080 //---
00081 typedef enum {
          THREAD_STATE_EXIT = 0,
00082
           THREAD_STATE_READY,
00084
           THREAD_STATE_BLOCKED,
00085
           THREAD_STATE_STOP
00086
          THREAD_STATE_INVALID
00087 } thread_state_t;
00088 //---
00089 ^{\prime\prime} Macros for declaring opaque buffers of an appropriate size for the given
00090 // kernel objects
00091 #define TOKEN_1(x, y) x##y
00092 #define TOKEN_2(x, y) TOKEN_1(x, y)
00093
00094 // Ensure that opaque buffers are sized to the nearest word - which is
00095 // a platform-dependent value.
00096 #define WORD_ROUND(x) (((x) + (sizeof(K_WORD) - 1)) / sizeof(K_WORD))
00097
00098 #define DECLARE_THREAD(name)
00099
                    TOKEN_2(__thread_, name)[WORD_ROUND(THREAD SIZE)];
          K WORD
00100
           Thread_t name = (Thread_t)TOKEN_2(__thread_, name);
00101
00102 #define DECLARE_TIMER(name)
00103
          K WORD
                   TOKEN_2 (__timer_, name) [WORD_ROUND (TIMER_SIZE)];
00104
           Timer_t name = (Timer_t)TOKEN_2(__timer_, name);
00106 #define DECLARE_SEMAPHORE(name)
00107
           K WORD
                        TOKEN_2(__semaphore_, name)[WORD_ROUND(SEMAPHORE_SIZE)];
00108
           Semaphore t name = (Semaphore t) TOKEN 2( semaphore , name);
00109
00110 #define DECLARE_MUTEX(name)
00111
          K WORD
                   TOKEN_2 (__mutex_, name) [WORD_ROUND (MUTEX_SIZE)];
00112
          Mutex t name = (Mutex t) TOKEN 2 ( mutex , name);
00113
00114 #define DECLARE_MESSAGE(name)
00115
           K WORD
                     TOKEN_2(__message_, name)[WORD_ROUND(MESSAGE_SIZE)];
00116
           Message_t name = (Message_t)TOKEN_2(__message_, name);
00117
00118 #define DECLARE MESSAGEPOOL (name)
           K_WORD
00119
                          TOKEN_2(__messagepool_, name)[WORD_ROUND(MESSAGEPOOL_SIZE)];
00120
          MessagePool t name = (MessagePool t)TOKEN 2( messagepool , name);
```

```
00121
00122 #define DECLARE_MESSAGEQUEUE(name)
00123
          K WORD
                         TOKEN_2(__messagequeue_, name)[WORD_ROUND(MESSAGEQUEUE_SIZE)];
00124
          MessageOueue t name = (MessageOueue t) TOKEN 2( messagegueue , name);
00125
00126 #define DECLARE_MAILBOX(name)
00127
          K WORD
                    TOKEN_2(__mailbox_, name)[WORD_ROUND(MAILBOX_SIZE)];
00128
          Mailbox t name = (Mailbox t) TOKEN 2( mailbox , name);
00129
00130 #define DECLARE_NOTIFY(name)
00131
          K WORD
                   TOKEN_2(__notify_, name)[WORD_ROUND(NOTIFY_SIZE)];
00132
          Notify_t name = (Notify_t)TOKEN_2(__notify_, name);
00133
00134 #define DECLARE_EVENTFLAG(name)
          K_WORD
00135
                      TOKEN_2(__eventflag_, name)[WORD_ROUND(EVENTFLAG_SIZE)];
00136
          EventFlag_t name = (EventFlag_t)TOKEN_2(__eventflag_, name);
00137
00138 #define DECLARE_CONDITIONVARIABLE(name)
00139
          K WORD
                      TOKEN_2(__condvar_, name)[WORD_ROUND(EVENTFLAG_SIZE)];
00140
          ConditionVariable_t name = (ConditionVariable_t) TOKEN_2 (__condvar_, name);
00141
00142 #define DECLARE_READERWRITERLOCK(name)
00143
          K_WORD
                      TOKEN_2(__readerwriterlock_, name)[WORD_ROUND(EVENTFLAG_SIZE)];
00144
          ReaderWriterLock_t name = (ReaderWriterLock_t)TOKEN_2(__readerwriterlock_, name);
00145
00147 // Allocate-once Memory managment APIs
00148 #if defined KERNEL_USE_AUTO_ALLOC
00149
00155 void* Alloc Memory(size t eSize );
00156
00161 void Free_Memory(void* pvObject_);
00162
00163 #if KERNEL USE SEMAPHORE
00164
00169 Semaphore_t Alloc_Semaphore(void);
00170 void Free_Semaphore (Semaphore_t handle);
00171
00172 #endif
00173 #if KERNEL_USE_MUTEX
00174
00179 Mutex_t Alloc_Mutex(void);
00180 void Free_Mutex(Mutex_t handle);
00181
00182 #endif
00183 #if KERNEL_USE_EVENTFLAG
00184
00189 EventFlag_t Alloc_EventFlag(void);
00190 void Free_EventFlag(EventFlag_t handle);
00191
00192 #endif
00193 #if KERNEL_USE_MESSAGE
00194
00199 Message_t Alloc_Message(void);
00200 void Free_Message (Message_t handle);
00201
00207 MessageQueue_t Alloc_MessageQueue(void);
00208 void Free_MessageQueue(MessageQueue_t handle);
00209
00210 MessagePool_t Alloc_MessagePool(void);
00211 void Free_MessagePool(MessagePool_t handle);
00212
00213
00214 #endif
00215 #if KERNEL_USE_NOTIFY
00216
00221 Notify_t Alloc_Notify(void);
00222 void Free_Notify(Notify_t handle);
00223
00224 #endif
00225 #if KERNEL_USE_MAILBOX
00226
00231 Mailbox_t Alloc_Mailbox(void);
00232 void Free_Mailbox(Mailbox_t handle);
00233 #endif
```

20.4 mark3c.h 225

```
00234
00239 Thread_t Alloc_Thread(void);
00240 void Free_Thread(Thread_t handle);
00241
00242 #if KERNEL USE TIMERS
00243
00248 Timer_t Alloc_Timer(void);
00249 void Free_Timer(Timer_t handle);
00250
00251 #endif
00252 #endif
00253
00254 //
00255 // Kernel APIs
00260 void Kernel_Init(void);
00265 void Kernel_Start (void);
00272 bool Kernel_IsStarted(void);
00273
00274 typedef void (*panic_func_t)(uint16_t u16PanicCode_);
00280 void Kernel_SetPanic(panic_func_t pfPanic_);
00286 bool Kernel_IsPanic(void);
00292 void Kernel_Panic(uint16_t u16Cause_);
00293 #if KERNEL USE IDLE FUNC
00294 typedef void (*idle_func_t)(void);
00295
00301 void Kernel_SetIdleFunc(idle_func_t pfIdle_);
00302 #endif
00303
00304 #if KERNEL USE THREAD CALLOUTS
00305
00310 void Kernel SetThreadCreateCallout(thread create callout t pfCreate):
00316 void Kernel_SetThreadExitCallout(thread_exit_callout_t pfExit_);
00317
00323 void Kernel_SetThreadContextSwitchCallout(thread_context_callout_t pfContext_);
00324
00330 thread_create_callout_t Kernel_GetThreadCreateCallout(void);
00331
00337 thread_exit_callout_t Kernel_GetThreadExitCallout(void);
00338
00344 thread_context_callout_t Kernel_GetThreadContextSwitchCallout(void);
00345 #endif
00346
00347 #if KERNEL USE STACK GUARD
00348
00354 void Kernel_SetStackGuardThreshold(uint16_t u16Threshold_);
00355
00361 uint16_t Kernel_GetStackGuardThreshold(void);
00362 #endif
00363 //----
00364 // Scheduler APIs
00370 void Scheduler_Enable(bool bEnable_);
00376 bool Scheduler_IsEnabled(void);
00382 Thread_t Scheduler_GetCurrentThread(void);
00383
00384 typedef void (*thread_entry_func_t) (void* pvArg_);
00385 //
00386 // Thread APIs
00400 void Thread_Init(Thread_t
                                    pwStack_,
00401
                       K_WORD*
00402
                       uint16 t
                                     u16StackSize_
                       PORT PRIO TYPE
00403
                                          uXPriority
                       thread_entry_func_t pfEntryPoint_,
00404
00405
                       void*
                                     pvArq_);
00411 void Thread_Start (Thread_t handle);
00417 void Thread_Stop(Thread_t handle);
00418 #if KERNEL_USE_THREADNAME
00419
00425 void Thread_SetName(Thread_t handle, const char* szName_);
00432 const char* Thread_GetName(Thread_t handle);
00433 #endif
00434
00440 PORT_PRIO_TYPE Thread_GetPriority(Thread_t handle);
00447 PORT_PRIO_TYPE Thread_GetCurPriority(Thread_t handle);
00448 #if KERNEL USE OUANTUM
00449
00455 void Thread_SetQuantum(Thread_t handle, uint16_t u16Quantum_);
00462 uint16_t Thread_GetQuantum(Thread_t handle);
00463 #endif
00464
00470 void Thread_SetPriority(Thread_t handle, PORT_PRIO_TYPE uXPriority_);
00471 #if KERNEL_USE_DYNAMIC_THREADS
00472
00477 void Thread_Exit(Thread_t handle);
00478 #endif
00479 #if KERNEL_USE_SLEEP
00480
00485 void Thread Sleep (uint32 t u32TimeMs );
```

```
00491 void Thread_USleep(uint32_t u32TimeUs_);
00493 #if KERNEL_USE_EXTENDED_CONTEXT
00494
00500 void* Thread_GetExtendedContext(Thread_t handle);
00501
00508 void Thread_SetExtendedContext(Thread_t handle, void* pvData_);
00509
00510 #endif
00511
00515 void Thread_Yield(void);
00522 void Thread_SetID (Thread_t handle, uint8_t u8ID_);
00529 uint8_t Thread_GetID(Thread_t handle);
00536 uint16_t Thread_GetStackSlack(Thread_t handle);
00543 thread_state_t Thread_GetState(Thread_t handle);
00544
00545 //----
00546 // Timer APIs
00547 #if KERNEL_USE_TIMERS
00548 typedef void (*timer_callback_t)(Thread_t hOwner_, void* pvData_);
00554 void Timer_Init(Timer_t handle);
00566 void Timer_Start(Timer_t
                                                                                          handle,
                                                                                          bRepeat_
00567
                                                   bool
00568
                                                   uint32 t
                                                                                          u32IntervalMs .
00569
                                                   uint32_t
                                                                                          u32ToleranceMs_,
00570
                                                   timer_callback_t pfCallback_,
00571
                                                    void*
                                                                                          pvData_);
00572
00578 void Timer_Restart(Timer_t handle);
00579
00585 void Timer_Stop(Timer_t handle);
00586 #endif
00587
00588 //-
00589 // Semaphore APIs
00590 #if KERNEL_USE_SEMAPHORE
00591
00598 void Semaphore_Init(Semaphore_t handle, uint16_t u16InitVal_, uint16_t u16MaxVal_);
00604 void Semaphore_Post(Semaphore_t handle);
00610 void Semaphore_Pend(Semaphore_t handle);
00611 #if KERNEL_USE_TIMEOUTS
00612
00619 bool Semaphore TimedPend(Semaphore t handle, uint32 t u32WaitTimeMS );
00620 #endif
00621 #endif
00622
00623 //----
00624 // Mutex APIs
00625 #if KERNEL USE MUTEX
00626
00631 void Mutex_Init(Mutex_t handle);
00637 void Mutex_Claim(Mutex_t handle);
00643 void Mutex_Release(Mutex_t handle);
00644 #if KERNEL_USE_TIMEOUTS
00645
00652 bool Mutex TimedClaim (Mutex t handle, uint32 t u32WaitTimeMS );
00653 #endif
00654 #endif
00655
00656 //---
00657 // EventFlag APIs
00658 #if KERNEL_USE_EVENTFLAG
00664 void EventFlag_Init(EventFlag_t handle);
00673 uint16_t EventFlag_Wait(EventFlag_t handle, uint16_t u16Mask_, event_flag_operation_t eMode_);
00674 #if KERNEL_USE_TIMEOUTS
00675
00684 \ \mathtt{uint16\_t} \ \mathtt{EventFlag\_TimedWait} (\mathtt{EventFlag\_t} \ \mathtt{handle,} \ \mathtt{uint16\_t} \ \mathtt{u16Mask\_,} \ \mathtt{event\_flag\_operation\_t} \ \mathtt{eMode\_,} \ \mathtt{uint32\_t} \\ \mathtt{uint30\_t} \ \mathtt{emode\_t} \ \mathtt{uint30\_t} \ \mathtt{emode\_t} \ \mathtt{uint30\_t} \ \mathtt{emode\_t} \ \mathtt{emode\_t
              u32TimeMS );
00685 #endif
00686
00692 void EventFlag_Set(EventFlag_t handle, uint16_t u16Mask_);
00699 void EventFlag_Clear(EventFlag_t handle, uint16_t u16Mask_);
00706 uint16_t EventFlag_GetMask(EventFlag_t handle);
00707 #endif
00708
00709 //--
00710 // Notification APIs
00711 #if KERNEL_USE_NOTIFY
00712
00717 void Notify_Init(Notify_t handle);
00723 void Notify_Signal(Notify_t handle);
00730 void Notify_Wait(Notify_t handle, bool* pbFlag_);
00731 #if KERNEL_USE_TIMEOUT
00732
00740 bool Notify_TimedWait(Notify_t handle, uint32_t u32WaitTimeMS_, bool* pbFlag_);
00741 #endif
```

20.4 mark3c.h 227

```
00742 #endif
00743
00744 /
00745 // Atomic Functions
00746 #if KERNEL USE ATOMIC
00747
00754 uint8_t Atomic_Set8(uint8_t* pu8Source_, uint8_t u8Val_);
00762 uint16_t Atomic_Set16(uint16_t* pu16Source_, uint16_t u16Val_);
00770 uint32_t Atomic_Set32(uint32_t* pu32Source_, uint32_t u32Val_);
00778 uint8_t Atomic_Add8(uint8_t* pu8Source_, uint8_t u8Val_);
00786 uint16_t Atomic_Add16(uint16_t* pu16Source_, uint16_t u16Val_);
00794 uint32_t Atomic_Add32(uint32_t* pu32Source_, uint32_t u32Val_);
00802 uint8_t Atomic_Sub8(uint8_t* pu8Source_, uint8_t u8Val_);
00810 uint16_t Atomic_Sub16(uint16_t* pu16Source_, uint16_t u16Val_);
00818 uint32_t Atomic_Sub32(uint32_t* pu32Source_, uint32_t u32Val_);
00827 bool Atomic_TestAndSet(bool* pbLock);
00828 #endif
00829
00830 //-
00831 // Message/Message Queue APIs
00832 #if KERNEL_USE_MESSAGE
00833
00838 void Message_Init(Message_t handle);
00845 void Message_SetData(Message_t handle, void* pvData_);
00852 void* Message_GetData(Message_t handle);
00859 void Message_SetCode(Message_t handle, uint16_t u16Code_);
00866 uint16_t Message_GetCode(Message_t handle);
00872 void MessageQueue_Init(MessageQueue_t handle);
00879 Message_t MessageQueue_Receive(MessageQueue_t handle);
00880 #if KERNEL_USE_TIMEOUTS
00881
00891 Message_t MessageQueue_TimedReceive(MessageQueue_t handle, uint32_t u32TimeWaitMS_);
00892 #endif
00893
00900 void MessageQueue_Send(MessageQueue_t handle, Message_t hMessage_);
00901
00907 uint16 t MessageQueue GetCount (MessageQueue t handle);
00914 void MessagePool_Init(MessagePool_t handle);
00915
00922 void MessagePool_Push(MessagePool_t handle, Message_t msg);
00923
00930 Message_t MessagePool_Pop(MessagePool_t handle);
00931
00932 #endif
00933
00934 //--
00935 // Mailbox APIs
00936 #if KERNEL USE MAILBOX
00937
00946 void Mailbox_Init(Mailbox_t handle, void* pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_);
00947
00955 bool Mailbox_Send(Mailbox_t handle, void* pvData_);
00956
00964 bool Mailbox_SendTail(Mailbox_t handle, void* pvData_);
00965
00974 bool Mailbox_TimedSend(Mailbox_t handle, void* pvData_, uint32_t u32TimeoutMS_);
00975
00984 bool Mailbox_TimedSendTail(Mailbox_t handle, void* pvData_, uint32_t u32TimeoutMS_);
00985
00993 void Mailbox_Receive(Mailbox_t handle, void* pvData_);
00994
01002 void Mailbox_ReceiveTail(Mailbox_t handle, void* pvData_);
01003 #if KERNEL USE TIMEOUTS
01004
01014 bool Mailbox_TimedReceive(Mailbox_t handle, void* pvData_, uint32_t u32TimeoutMS_);
01015
01025 bool Mailbox TimedReceiveTail(Mailbox t handle, void* pvData, uint32 t u32TimeoutMS);
01026
01033 uint16_t Mailbox_GetFreeSlots(Mailbox_t handle);
01034
01041 bool Mailbox_IsFull(Mailbox_t handle);
01042
01049 bool Mailbox_IsEmpty(Mailbox_t handle);
01050 #endif
01051 #endif
01052
01053 //--
01054 // Condition Variables
01055 #if KERNEL USE CONDVAR
01056
01061 void ConditionVariable_Init(ConditionVariable_t handle);
01062
01069 void ConditionVariable_Wait(ConditionVariable_t handle, Mutex_t hMutex_);
01070
01076 void ConditionVariable_Signal(ConditionVariable_t handle);
01077
```

```
01083 void ConditionVariable_Broadcast(ConditionVariable_t handle);
01084 #if KERNEL USE TIMEOUTS
01085
01093 bool ConditionVariable_TimedWait(ConditionVariable_t handle, Mutex_t hMutex_, uint32_t u32WaitTimeMS_);
01094 #endif
01095 #endif
01097 //--
01098 // Reader-writer locks
01099 #if KERNEL_USE_READERWRITER
01100
01105 void ReaderWriterLock Init (ReaderWriterLock t handle);
01106
01112 void ReaderWriterLock_AcquireReader(ReaderWriterLock_t handle);
01113
01119 void ReaderWriterLock_ReleaseReader(ReaderWriterLock_t handle);
01120
01126 void ReaderWriterLock AcquireWriter(ReaderWriterLock t handle);
01133 void ReaderWriterLock_ReleaseWriter(ReaderWriterLock_t handle);
01134 #if KERNEL_USE_TIMEOUTS
01135
01142 bool ReaderWriterLock_TimedAcquireWriter(ReaderWriterLock_t handle, uint32_t u32TimeoutMs_);
01143
01151 bool ReaderWriterLock_TimedAcquireReader(ReaderWriterLock_t handle, uint32_t u32TimeoutMs_);
01152 #endif
01153 #endif
01154
01155 //---
01156 // Kernel-Aware Simulation APIs
01157 #if KERNEL_AWARE_SIMULATION
01158
01164 void KernelAware_ProfileInit(const char* szStr_);
01165
01170 void KernelAware_ProfileStart(void);
01171
01176 void KernelAware ProfileStop(void);
01177
01182 void KernelAware_ProfileReport(void);
01183
01189 void KernelAware_ExitSimulator(void);
01190
01196 void KernelAware Print(const char* szStr );
01197
01204 void KernelAware_Trace(uint16_t u16File_, uint16_t u16Line_);
01205
01213 void KernelAware_Tracel(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_);
01222 void KernelAware_Trace2(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_);
01232 bool KernelAware_IsSimulatorAware(void);
01233 #endif
01235 #if defined(__cplusplus)
01236
01237 #endif
```

20.5 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kernelprofile.cpp File Reference

ATMega328p Profiling timer implementation.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "profile.h"
#include "kernelprofile.h"
#include "threadport.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

20.5.1 Detailed Description

ATMega328p Profiling timer implementation.

Definition in file kernelprofile.cpp.

20.6 kernelprofile.cpp 229

20.6 kernelprofile.cpp

```
00002
00003
00004
00005
00006
00007
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 m0slevin, all rights reserved.
00012 See license.txt for more information
00013 =
00020 #include "kerneltypes.h"
00021 #include "mark3cfg.h"
00022 #include "profile.h"
00023 #include "kernelprofile.h"
00024 #include "threadport.h"
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028 #if KERNEL_USE_PROFILER
00029 namespace Mark3
00030 {
00031 uint32_t Profiler::m_u32Epoch;
00032
00034 void Profiler::Init()
00035 {
00036
           TCCR0A
                       = 0;
00037
           TCCR0B
                       = 0;
00038
           TIFR0
                       = 0;
00039
           TIMSK0
                       = 0;
00040
           m_u32Epoch = 0;
00041 }
00042
00043 //---
00044 void Profiler::Start()
00045 {
00046
           TIFR0 = 0;
00047
           TCNT0 = 0;
           TCCR0B |= (1 << CS01);
TIMSK0 |= (1 << TOIE0);
00048
00049
00050 }
00051
00052 //--
00053 void Profiler::Stop()
00054 {
           TIFR0 = 0;
TCCR0B &= ~(1 << CS01);
00055
00056
           TIMSKO &= \sim (1 << TOIE0);
00057
00059 //---
00060 uint16_t Profiler::Read()
00061 {
          uint16_t u16Ret;
CS_ENTER();
TCCROB &= ~(1 << CSO1);
u16Ret = TCNTO;
00062
00063
00064
00065
00066
           TCCR0B \mid = (1 << CS01);
00067
           CS_EXIT();
00068
           return u16Ret;
00069 }
00071 //--
00072 void Profiler::Process()
00073 {
00074
           CS ENTER();
00075
           m_u32Epoch++;
00076
           CS_EXIT();
00077 }
00078
00079 //--
00080 ISR(TIMERO_OVF_vect)
00081 {
00082
           Profiler::Process();
00083 }
00084 } //namespace Mark3
00085 #endif
```

20.7 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kernelswi.cpp File Reference

Kernel Software interrupt implementation for ATMega328p.

```
#include "kerneltypes.h"
#include "kernelswi.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.7.1 Detailed Description

Kernel Software interrupt implementation for ATMega328p.

Definition in file kernelswi.cpp.

20.8 kernelswi.cpp

```
00001 /
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h"
00023 #include "kernelswi.h"
00024
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028
00029 namespace Mark3
00030 {
00031 //--
00032 void KernelSWI::Config(void)
00033 {
00034
          PORTB &= ~0x04;
                                                 // Clear INT2
                                                 // Set PortB, bit 2 (INT2) As Output
00035
          DDRB |= 0x04;
00036
          EICRA |= (1 << ISC20) | (1 << ISC21); // Rising edge on INT2
00037 }
00038
00039 //--
00040 void KernelSWI::Start(void)
00041 {
00042
          EIFR &= \sim (1 << INTF2); // Clear any pending interrupts on INT2
00043
          EIMSK |= (1 << INT2); // Enable INT2 interrupt (as int32_t as I-bit is set)</pre>
00044 }
00045
00046 //--
00047 void KernelSWI::Stop(void)
00048 {
```

```
00049
          EIMSK &= ~(1 << INT2); // Disable INTO interrupts</pre>
00050 }
00051
00052 //----
00053 uint8_t KernelSWI::DI()
00054 {
         bool bEnabled = ((EIMSK & (1 << INT2)) != 0);</pre>
00056 EIMSK &= ~(1 << INT2);
00057 return bEnabled;
00058 }
00059
00060 //---
00061 void KernelSWI::RI(bool bEnable_)
00062 {
        if (bEnable_) {
00063
00064
             EIMSK \mid = (1 << INT2);
00068 }
00069
00070 //----
00071 void KernelSWI::Clear(void)
00072 {
00073
         EIFR &= ~(1 << INTF2); // Clear the interrupt flag for INTO
00074 }
00075
00076 //---
00077 void KernelSWI::Trigger(void)
00078 {
00079
         // if (Thread IsSchedulerEnabled())
00079
00080
00081
00082
00083
}
             PORTB &= ~0x04;
             PORTB |= 0x04;
00084 }
00085 } //namespace Mark3
```

20.9 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/kerneltimer.cpp File Reference

Kernel Timer Implementation for ATMega328p.

```
#include "kerneltypes.h"
#include "kerneltimer.h"
#include "mark3cfg.h"
#include "ksemaphore.h"
#include "thread.h"
#include <avr/common.h>
#include <avr/io.h>
#include <avr/interrupt.h>
```

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.9.1 Detailed Description

Kernel Timer Implementation for ATMega328p.

Definition in file kerneltimer.cpp.

20.10 kerneltimer.cpp

```
00001 /*=======
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ========
00021 #include "kerneltypes.h"
00022 #include "kerneltimer.h"
00023 #include "mark3cfg.h"
00024
00025 #include "ksemaphore.h" 00026 #include "thread.h"
00027
00028 #include <avr/common.h>
00029 #include <avr/io.h>
00030 #include <avr/interrupt.h>
00031
00032 #define TCCR1B_INIT ((1 << WGM12) | (1 << CS12))
00033 #define TIMER_IMSK (1 << OCIE1A)
00034 #define TIMER_IFR (1 << OCF1A)
00035
00036 namespace {
00037 using namespace Mark3;
00038 //--
00039 // Static objects implementing the timer thread and its synchronization objects
00040 #if KERNEL_TIMERS_THREADED
00041 Thread s_clTimerThread;
00042 K_WORD s_clTimerThreadStack[PORT_KERNEL_TIMERS_THREAD_STACK];
00043 Semaphore s_clTimerSemaphore;
00044 #endif
00045 }
00046
00047 namespace Mark3 {
00048 //--
00049 #if KERNEL_TIMERS_THREADED
00050 static void KernelTimer_Task(void* unused)
00051 {
00052
          (void) unused:
         while(1) {
00054
              s_clTimerSemaphore.Pend();
00055 #if KERNEL_USE_TIMERS
00056
              TimerScheduler::Process();
00057 #endif
00058 #if KERNEL_USE_QUANTUM
00059
              Quantum::UpdateTimer();
00060 #endif
00061
00062 }
00063 #endif
00064
00065 //
00066 void KernelTimer::Config(void)
00067 {
00068
          TCCR1B = TCCR1B_INIT;
00069 #if KERNEL TIMERS THREADED
00070
          s_clTimerSemaphore.Init(0, 1);
00071
          s_clTimerThread.Init(s_clTimerThreadStack,
                               sizeof(s_clTimerThreadStack) / sizeof(K_WORD),
00073
                               KERNEL_TIMERS_THREAD_PRIORITY,
00074
                               KernelTimer_Task,
00075
                               0);
00076
          Ouantum::SetTimerThread(&s clTimerThread);
00077
          s_clTimerThread.Start();
00078 #endif
00079 }
08000
00081 //---
00082 void KernelTimer::Start(void)
00083 {
00084 #if !KERNEL_TIMERS_TICKLESS
00085
          TCCR1B = ((1 << WGM12) | (1 << CS11) | (1 << CS10));
00086
          OCR1A = ((PORT_SYSTEM_FREQ / 1000) / 64);
00087 #else
00088
        TCCR1B |= (1 << CS12);
00089 #endif
00090
00091
          TCNT1 = 0;
```

20.10 kerneltimer.cpp 233

```
TIFR1 &= ~TIMER_IFR;
00093
          TIMSK1 |= TIMER_IMSK;
00094 }
00095
00096 //---
00097 void KernelTimer::Stop(void)
00099 #if KERNEL_TIMERS_TICKLESS
       TIFR1 &= ~TIMER_IFR;
TIMSK1 &= ~TIMER_IMSK;
00100
00101
          TCCR1B &= ~(1 << CS12); // Disable count...
00102
         TCNT1 = 0:
00103
00104
          OCR1A = 0;
00105 #endif
00106 }
00107
00108 //---
00109 PORT_TIMER_COUNT_TYPE KernelTimer::Read(void)
00110 {
00111 #if KERNEL_TIMERS_TICKLESS
00112
         volatile uint16_t u16Read1;
00113
          volatile uint16_t u16Read2;
00114
00115
         u16Read1 = TCNT1;
u16Read2 = TCNT1;
00116
00117
00118
         } while (u16Read1 != u16Read2);
00119
00120
         return u16Read1;
00121 #else
00122 return 0;
00123 #endif
00124 }
00125
00126 //---
00127 PORT_TIMER_COUNT_TYPE KernelTimer::SubtractExpiry(
      PORT_TIMER_COUNT_TYPE uInterval)
00129 #if KERNEL_TIMERS_TICKLESS
00130 OCR1A -= uInterval;
00131 return OCR1A;
00132 #else
00133 return 0:
00134 #endif
00135 }
00136
00137 //----
00138 PORT_TIMER_COUNT_TYPE KernelTimer::TimeToExpiry(void)
00139 {
00140 #if KERNEL_TIMERS_TICKLESS
         uint16_t u16Read = KernelTimer::Read();
uint16_t u16OCR1A = OCR1A;
00141
00142
00143
00144
        if (u16Read >= u16OCR1A) {
00145
              return 0;
00146
         } else {
            return (u160CR1A - u16Read);
00148
00149 #else
00150
         return 0;
00151 #endif
00152 }
00153
00155 PORT_TIMER_COUNT_TYPE KernelTimer::GetOvertime(void)
00156 {
00157
          return KernelTimer::Read();
00158 }
00159
00160 //--
00161 PORT_TIMER_COUNT_TYPE KernelTimer::SetExpiry(uint32_t
      u32Interval_)
00162 {
00163 #if KERNEL_TIMERS_TICKLESS
       uint16_t u16SetInterval;
if (u32Interval_ > 65535)
00164
00166
              u16SetInterval = 65535;
00167
00168
             u16SetInterval = static_cast<uint16_t>(u32Interval_);
        }
00169
00170
         OCR1A = u16SetInterval;
00172
          return u16SetInterval;
00173 #else
00174
         return 0;
00175 #endif
00176 }
```

```
00178 //----
00179 void KernelTimer::ClearExpiry(void)
00180 {
00181 #if KERNEL_TIMERS_TICKLESS
00182 OCR1A = 65535; // Clear the compare value
00183 #endif
00184 }
00185
00186 //----
00187 uint8_t KernelTimer::DI(void)
00188 {
00189 #if KERNEL_TIMERS_TICKLESS
00190 bool benabled = ((TIMSK1 & (TIMER_IMSK)) != 0);

00191 TIFR1 &= ~TIMER_IFR; // Clear interrupt flags

00192 TIMSK1 &= ~TIMER_IMSK; // Disable interrupt
00193
          return bEnabled:
00194 #else
00195
        return 0;
00196 #endif
00197 }
00198
00199 //---
00200 void KernelTimer::EI(void)
00201 {
          KernelTimer::RI(0);
00203 }
00204
00205 //---
00206 void KernelTimer::RI(bool bEnable )
00207 {
00208 #if KERNEL_TIMERS_TICKLESS
TIMSK1 |= (1 << OCIE1A); // Enable interrupt</pre>
00210
00214 #endif
00215 }
00216 } //namespace Mark3
00217
00218 //----
00223 //-----
00224 using namespace Mark3;
00225 ISR(TIMER1_COMPA_vect)
00226 {
00227 #if KERNEL_TIMERS_THREADED
00228 KernelTimer::ClearExpiry();
00229 s_clTimerSemaphore.Post();
00230 #else
00231 #if KERNEL_USE_TIMERS
00232 TimerScheduler::P:
               TimerScheduler::Process();
00232 #endif
00233 #endif
00234 #if KERNEL_USE_QUANTUM
00235 Quantum::UpdateTime
00236 #endif
              Quantum::UpdateTimer();
00237 #endif
00238 }
```

20.11 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kernelprofil File Reference

Profiling timer hardware interface.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

20.11.1 Detailed Description

Profiling timer hardware interface.

Definition in file kernelprofile.h.

20.12 kernelprofile.h

20.12 kernelprofile.h

```
00001 /*==
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 m0slevin, all rights reserved.
00012 See license.txt for more information
00020 #pragma once
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024 #include "ll.h"
00025
00026 #if KERNEL_USE_PROFILER
00027
00028 //--
00029 #define TICKS_PER_OVERFLOW (256)
00030 #define CLOCK_DIVIDE (8)
00031 namespace Mark3
00032 {
00033 //--
00037 class Profiler
00038 {
00039 public:
         static void Init();
00046
00047
00053
         static void Start();
00054
00060
         static void Stop();
00061
00067
         static uint16_t Read();
00068
00074
         static void Process();
00075
00081
         static uint32_t GetEpoch() { return m_u32Epoch; }
00082 private:
00083
         static uint32_t m_u32Epoch;
00084 };
00085
00086 #endif // KERNEL_USE_PROFILER
00087 } //namespace Mark3
```

20.13 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kernelswi.h File Reference

Kernel Software interrupt declarations.

```
#include "kerneltypes.h"
```

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.13.1 Detailed Description

Kernel Software interrupt declarations.

Definition in file kernelswi.h.

20.14 kernelswi.h

```
00001 /
00002
00003
00004
00005
00006
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 -----
00021 #pragma once
00022 #include "kerneltypes.h"
00023
00024 //----
00029 namespace Mark3
00030 {
00031 class KernelSWI
00032 {
00033 public:
00040
         static void Config(void);
00041
00047
         static void Start (void);
00048
00054
         static void Stop(void);
00055
00061
         static void Clear (void);
00062
00069
         static void Trigger (void);
00070
00078
         static uint8_t DI();
00079
00087
         static void RI(bool bEnable_);
00088 };
00089 } // namespace Mark3
```

20.15 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/kerneltimer File Reference

Kernel Timer Class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

Classes

class Mark3::KernelTimer

Hardware timer interface, used by all scheduling/timer subsystems.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.15.1 Detailed Description

Kernel Timer Class declaration.

Definition in file kerneltimer.h.

20.16 kerneltimer.h

20.16 kerneltimer.h

```
00001 /
00002
00004
00005
00006
00007
00008
00009
        -[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ===
00021 #pragma once
00022
00023 #include "kerneltypes.h"
00024 #include "mark3cfg.h"
00025
00026 namespace Mark3
00027 {
00028 //---
00032 class KernelTimer
00033 {
00034 public:
          static void Config(void);
00040
00041
00047
          static void Start (void);
00048
00054
          static void Stop(void);
00055
00061
          static uint8_t DI (void);
00062
00070
          static void RI(bool bEnable_);
00071
00077
          static void EI(void);
00078
00089
          static PORT_TIMER_COUNT_TYPE SubtractExpiry(
      PORT_TIMER_COUNT_TYPE uInterval_);
00090
00099
          static PORT_TIMER_COUNT_TYPE TimeToExpiry(void);
00100
00109
          static PORT_TIMER_COUNT_TYPE SetExpiry(uint32_t u32Interval_);
00110
00119
          static PORT_TIMER_COUNT_TYPE GetOvertime(void);
00120
00126
          static void ClearExpiry(void);
00127
00135
          static PORT_TIMER_COUNT_TYPE Read(void);
00136 };
00137 } //namespace Mark3
```

20.17 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/portcfg.h File Reference

Mark3 Port Configuration.

Macros

• #define AVR (1)

Define a macro indicating the CPU architecture for which this port belongs.

#define K_WORD uint8_t

Define types that map to the CPU Architecture's default data-word and address size.

#define K_ADDR uint16_t

Size of an address (pointer size)

#define PORT_PRIO_TYPE uint8_t

Set a base datatype used to represent each element of the scheduler's priority bitmap.

• #define PORT_PRIO_MAP_WORD_SIZE (1)

size of PORT_PRIO_TYPE in bytes

• #define PORT_SYSTEM_FREQ ((uint32_t)16000000)

Define the running CPU frequency.

• #define PORT_TIMER_FREQ ((uint32_t)(PORT_SYSTEM_FREQ / 1000))

Set the timer frequency.

#define PORT_KERNEL_DEFAULT_STACK_SIZE ((K_ADDR)256)

Define the default/minimum size of a thread stack.

#define PORT KERNEL TIMERS THREAD STACK ((K ADDR)256)

Define the size of the kernel-timer thread stack (if one is configured)

• #define PORT_TIMER_COUNT_TYPE uint16_t

Define the native type corresponding to the kernel timer hardware's counter register.

• #define PORT_MIN_TIMER_TICKS (0)

Minimum number of timer ticks for any delay or sleep, required to ensure that a timer cannot be initialized to a negative value.

20.17.1 Detailed Description

Mark3 Port Configuration.

This file is used to configure the kernel for your specific target CPU in order to provide the optimal set of features for a given use case.

!! NOTE: This file must ONLY be included from mark3cfg.h

Definition in file portcfg.h.

20.17.2 Macro Definition Documentation

20.17.2.1 AVR

#define AVR (1)

Define a macro indicating the CPU architecture for which this port belongs.

This may also be set by the toolchain, but that's not guaranteed.

Definition at line 32 of file portcfg.h.

```
20.17.2.2 K_WORD
```

```
#define K_WORD uint8_t
```

Define types that map to the CPU Architecture's default data-word and address size.

Size of a data word

Examples:

lab10_notifications/main.cpp, lab11_mailboxes/main.cpp, lab1_kernel_setup/main.cpp, lab2_idle_← function/main.cpp, lab3_round_robin/main.cpp, lab4_semaphores/main.cpp, lab5_mutexes/main.cpp, lab6← __timers/main.cpp, lab7_events/main.cpp, lab8_messages/main.cpp, and lab9_dynamic_threads/main.cpp.

Definition at line 39 of file portcfg.h.

```
20.17.2.3 PORT_PRIO_TYPE
```

```
#define PORT_PRIO_TYPE uint8_t
```

Set a base datatype used to represent each element of the scheduler's priority bitmap.

PORT_PRIO_MAP_WORD_SIZE should map to the *size* of an element of type PORT_PROI_TYPE.Type used for bitmap in the PriorityMap class

Definition at line 49 of file portcfg.h.

20.17.2.4 PORT_SYSTEM_FREQ

```
#define PORT_SYSTEM_FREQ ((uint32_t)16000000)
```

Define the running CPU frequency.

This may be an integer constant, or an alias for another variable which holds the CPU's current running frequency. ← CPU Frequency in Hz

Definition at line 57 of file portcfg.h.

20.17.2.5 PORT_TIMER_COUNT_TYPE

```
#define PORT_TIMER_COUNT_TYPE uint16_t
```

Define the native type corresponding to the kernel timer hardware's counter register.

Timer counter type

Definition at line 86 of file portcfg.h.

20.17.2.6 PORT_TIMER_FREQ

```
#define PORT_TIMER_FREQ ((uint32_t)(PORT_SYSTEM_FREQ / 1000))
```

Set the timer frequency.

If running in tickless mode, this is simply the frequency at which the free-running kernel timer increments.

In tick-based mode, this is the frequency at which the fixed-frequency kernel tick interrupt occurs. Fixed timer interrupt frequency

Definition at line 70 of file portcfg.h.

20.18 portcfg.h

```
00001 /
00002
00003
00004
00005
00006
00007
80000
00009
       -[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ===
00024 #pragma once
00025
00031 #ifndef AVR
00032 # define AVR
                                           (1)
00033 #endif
00034
00039 #define K_WORD
                                           uint8_t
00040 #define K_ADDR
                                           uint16_t
00041
00042
00049 #define PORT_PRIO_TYPE
                                           uint8 t
00050 #define PORT_PRIO_MAP_WORD_SIZE
00051
00052
00056 #if !defined(PORT_SYSTEM_FREQ)
00057 #define PORT_SYSTEM_FREQ
                                           ((uint32_t)16000000)
00058 #endif
00059
00067 #if KERNEL_TIMERS_TICKLESS
00068 #define PORT_TIMER_FREQ
                                           ((uint32_t)(PORT_SYSTEM_FREQ / 256))
00069 #else
00070 #define PORT_TIMER_FREQ
                                           ((uint32_t)(PORT_SYSTEM_FREQ / 1000))
00071 #endif
00072
00076 #define PORT_KERNEL_DEFAULT_STACK_SIZE
                                                  ((K ADDR) 256)
00077
00081 #define PORT_KERNEL_TIMERS_THREAD_STACK
                                                   ((K_ADDR)256)
00082
00086 #define PORT_TIMER_COUNT_TYPE
                                          uint16_t
00087
00088
00092 #define PORT MIN TIMER TICKS
```

20.19 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/public/threadport. File Reference

ATMega328p Multithreading support.

```
#include "kerneltypes.h"
#include "thread.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

Classes

class Mark3::ThreadPort

Class defining the architecture specific functions required by the kernel.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

Macros

• #define ASM(x) asm volatile(x);

ASM Macro - simplify the use of ASM directive in C.

• #define SR_ 0x3F

Status register define - map to 0x003F.

#define SPH_ 0x3E

Stack pointer define.

#define TOP_OF_STACK(x, y) (reinterpret_cast<K_WORD*>(reinterpret_cast<K_ADDR>(x) + (static_
 cast<K_ADDR>(y) - 1)))

Macro to find the top of a stack given its size and top address.

• #define PUSH_TO_STACK(x, y) *x = y; x--;

Push a value y to the stack pointer x and decrement the stack pointer.

#define Thread SaveContext()

Save the context of the Thread.

#define Thread_RestoreContext()

Restore the context of the Thread.

• #define CS_ENTER()

These macros must be used in pairs!

#define CS EXIT()

Exit critical section (restore status register)

• #define ENABLE_INTS() ASM("sei");

Initiate a contex switch without using the SWI.

20.19.1 Detailed Description

ATMega328p Multithreading support.

Definition in file threadport.h.

20.19.2 Macro Definition Documentation

20.19.2.1 CS_ENTER

```
#define CS_ENTER( )
```

Value:

```
{ \
  uint8_t __x = _SFR_IO8(SR_); \
  ASM("cli");
```

These macros *must* be used in pairs!

Enter critical section (copy status register, disable interrupts)

Examples:

lab9_dynamic_threads/main.cpp.

Definition at line 163 of file threadport.h.

20.20 threadport.h

```
00001 /*=========
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ===
00020 #pragma once
00021
00022 #include "kerneltypes.h"
00023 #include "thread.h"
00024
00025 #include <avr/io.h>
00026 #include <avr/interrupt.h>
00027
00028 namespace Mark3 {
00029
00030 // clang-format off
00031 //----
                       asm volatile(x);
00033 #define ASM(x)
00034 #define SR_
                        0x3F
00036 #define SPH_
                        0x3E
00038 #define SPL_
00039
00040 //----
(reinterpret_cast<K_WORD*>(reinterpret_cast<K_ADDR>(x) +
                                       *x = y; x--;
00045 #define STACK_GROWS_DOWN
                                       (1)
00046
00047 //--
00048 // Lookup table based count-leading zeros implementation.
00049 inline uint8_t __mark3_clz8(uint8_t in_)
00050 {
00051
         static const uint8_t u8Lookup[] = {4, 3, 2, 2, 1, 1, 1, 1, 0, 0, 0, 0, 0, 0, 0};
00052
         uint8_t hi = __builtin_avr_swap(in_) & 0x0F;
00053
00054
             return u8Lookup[hi];
00055
00056
         return 4 + u8Lookup[in_];
00057 }
00058
```

20.20 threadport.h 243

```
00060 #define HW_CLZ (1)
00061 #define CLZ(x) __mark3_clz8(x)
00062
00063 //----
00065 #define Thread_SaveContext() \
00066 ASM("push r0"); \
00067 ASM("in r0, __SREG__"); \
00068 ASM("cli"); \
00069 ASM("push r0"); \
00070 ASM("push r1"); \
00071 ASM("clr r1"); \
00072 ASM("push r2");
00073 ASM("push r3");
00074 ASM("push r4");
00075 ASM("push r5");
00076 ASM("push r6");
00077 ASM("push r7");
00078 ASM("push r8");
00079 ASM("push r9");
00080 ASM("push r10");
00081 ASM("push r11");
00082 ASM("push r12");
00083 ASM("push r13");
00084 ASM("push r14");
00085 ASM("push r15");
00086 ASM("push r16");
00087 ASM("push r17");
00088 ASM("push r18");
00089 ASM("push r19");
00090 ASM("push r20");
00091 ASM("push r21");
00092 ASM("push r22");
00093 ASM("push r23");
00094 ASM("push r24");
00095 ASM("push r25");
00096 ASM("push r26");
00097 ASM("push r27");
00098 ASM("push r28");
00099 ASM("push r29");
00100 ASM("push r30");
00101 ASM("push r31");
00102 ASM("in r0, 0x3B"); \
00103 ASM("push r0"); \
00104 ASM("lds r26, g_pclCurrent"); \
00105 ASM("lds r27, g_pclCurrent + 1"); \
00106 ASM("adiw r26, 4"); \
00107 ASM("in r0, 0x3D"); \
00108 ASM("st x+, r0"); \
00109 ASM("in r0, 0x3E"); \
00110 ASM("st x+, r0"); \
00111
00112 //----
00114 #define Thread_RestoreContext() \
00115 ASM("lds r26, g_pclCurrent"); \
00116 ASM("lds r27, g_pclCurrent + 1"); \
00117 ASM("adiw r26, 4"); \
00118 ASM("ld r28, x+");
00110 ASM("aut 0x3D, r28"); \
00120 ASM("ld r29, x+");
00121 ASM("out 0x3E, r29"); \
00121 ASM( Out 0X3E, 129 ),

00122 ASM("pop r0"); \

00123 ASM("out 0X3E, r0"); \
00124 ASM("pop r31");
00125 ASM("pop r30");
00126 ASM("pop r29");
00127 ASM("pop r28");
00128 ASM("pop r27");
00129 ASM("pop r26");
00130 ASM("pop r25");
00131 ASM("pop r24");
00132 ASM("pop r23");
00133 ASM("pop r22");
00134 ASM("pop r21");
00135 ASM("pop r20");
00136 ASM("pop r19");
00137 ASM("pop r18");
00138 ASM("pop r17");
00139 ASM("pop r16");
00140 ASM("pop r15");
00141 ASM("pop r14");
00142 ASM("pop r13");
00143 ASM("pop r12");
00144 ASM("pop r11");
00145 ASM("pop r10");
00146 ASM("pop r9"); \
00147 ASM("pop r8"); \
```

```
00148 ASM("pop r7");
00149 ASM("pop r6");
00150 ASM("pop r5");
00151 ASM("pop r4");
00152 ASM("pop r3");
00153 ASM("pop r2");
00154 ASM("pop r1");
00155 ASM("pop r0"); \
00156 ASM("out __SREG__, r0"); \
00157 ASM("pop r0");
00158
00159 //----
00161 //----
00163 #define CS_ENTER() \
00164 { \
00165 uint8_t __x
00166 ASM("cli");
                 _x = _SFR_IO8(SR_); \setminus
00167 //----
00169 #define CS_EXIT() \
00170 _SFR_IO8(SR_) = __x;\
00171 }
00172
00173 //-----
00175 #define ENABLE_INTS() ASM("sei");
00176 #define DISABLE_INTS() ASM("cli");
00178 //----
00179 class Thread;
00187 class ThreadPort
00188 {
00189 public:
        static void StartThreads();
00195
00196
          friend class Thread;
00197 private:
00198
00206
          static void InitStack(Thread *pstThread_);
00207 };
00209 } // namespace Mark3
```

20.21 /home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1284p/gcc/threadport.cpp File Reference

ATMega1284p Multithreading.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "threadport.h"
#include "kernelprofile.h"
#include "kernelswi.h"
#include "kerneltimer.h"
#include "timerlist.h"
#include "quantum.h"
#include "kernel.h"
#include "kernelaware.h"
#include <avr/io.h>
#include <avr/interrupt.h>
```

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.22 threadport.cpp 245

Functions

Mark3::ISR (INT2_vect) __attribute__((signal ISR(INT2_vect) SWI using INT2 - used to trigger a context switch.

20.21.1 Detailed Description

ATMega1284p Multithreading.

Definition in file threadport.cpp.

20.22 threadport.cpp

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =========
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024 #include "thread.h"
00025 #include "threadport.h"
00026 #include "kernelprofile.h"
00027 #include "kernelswi.h"
00028 #include "kerneltimer.h"
00029 #include "timerlist.h"
00030 #include "quantum.h"
00031 #include "kernel.h"
00032 #include "kernelaware.h"
00033 #include <avr/io.h>
00034 #include <avr/interrupt.h>
00035
00036 //---
00037 namespace Mark3
00038 {
00039 //---
00040 void ThreadPort::InitStack(Thread* pclThread_)
00041 {
00042
           // Initialize the stack for a Thread
00043
           uint16_t u16Addr;
00044
           uint8_t* pu8Stack;
00045
           uint16_t i;
00046
00047
           // Get the address of the thread's entry function
00048
           u16Addr = (uint16_t)(pclThread_->m_pfEntryPoint);
00049
00050
           // Start by finding the bottom of the stack
00051
           pu8Stack = (uint8_t*)pclThread_->m_pwStackTop;
00052
           // clear the stack, and initialize it to a known-default value (easier // to debug when things go sour with stack corruption or overflow) for (i = 0; i < pclThread_->m_u16StackSize; i++) {
00053
00054
00055
00056
               pclThread_->m_pwStack[i] = 0xFF;
00057
00058
00059
            // Our context starts with the entry function
           PUSH_TO_STACK(pu8Stack, (uint8_t)(u16Addr & 0x00FF));
PUSH_TO_STACK(pu8Stack, (uint8_t)((u16Addr >> 8) & 0x00FF));
00060
00061
00062
00063
00064
           PUSH_TO_STACK(pu8Stack, 0x00); // R0
00065
            ^{\prime\prime} Push status register and R1 (which is used as a constant zero)
00066
00067
           PUSH_TO_STACK(pu8Stack, 0x80); // SR
00068
           PUSH_TO_STACK(pu8Stack, 0x00); // R1
00069
```

```
// Push other registers
00071
          for (i = 2; i <= 23; i++) // R2-R23
00072
00073
              PUSH_TO_STACK(pu8Stack, i);
00074
00075
00076
          // Assume that the argument is the only stack variable
00077
          PUSH_TO_STACK(pu8Stack, (uint8_t)(((uint16_t)(pclThread_->
         ovArg)) & 0x00FF)); // R24
PUSH_TO_STACK(pu8Stack, (uint8_t)((((uint16_t)(pc1Thread_->
      m_pvArg)) & 0x00FF));
00078
     m_pvArg)) >> 8) & 0x00FF)); // R25
00079
08000
          // Push the rest of the registers in the context
00081
          for (i = 26; i <= 31; i++) {
00082
             PUSH_TO_STACK(pu8Stack, i);
00083
00084
00085
          PUSH TO STACK (pu8Stack, 0x00); // RAMPZ
          // Set the top o' the stack.
00086
          pclThread_->m_pwStackTop = (uint8_t*)pu8Stack;
00087
00088
00089
          // That's it! the thread is ready to run now.
00090 }
00091
00092 //-
00093 static void Thread_Switch(void)
00094 {
00095 #if KERNEL_USE_IDLE_FUNC
00096
          // If there's no next-thread-to-run...
          if (g_pclNext == Kernel::GetIdleThread()) {
00097
00098
              g_pclCurrent = Kernel::GetIdleThread();
00099
00100
              // Disable the SWI, and re-enable interrupts -- enter nested interrupt
00101
              // mode.
00102
              KernelSWI::DI();
00103
00104
              g pclCurrent = Kernel::GetIdleThread();
00105
00106
              uint8 t u8SR = SFR IO8(SR);
00107
00108
              // So long as there's no "next-to-run" thread, keep executing the Idle
              // function to conclusion...
00109
00110
00111
              while (g_pclNext == Kernel::GetIdleThread()) {
                 // Ensure that we run this block in an interrupt enabled context (but
00112
00113
                  // with the rest of the checks being performed in an interrupt disabled
00114
                   // context).
00115
                  ASM("sei");
00116
                  Kernel::Idle();
00117
                  ASM("cli");
00118
              }
00119
00120
              // Progress has been achieved -- an interrupt-triggered event has caused
              // the scheduler to run, and choose a new thread. Since we've already // saved the context of the thread we've hijacked to run idle, we can
00121
00122
              \ensuremath{//} proceed to disable the nested interrupt context and switch to the
00123
              // new thread.
00124
00125
00126
              \_SFR\_IO8(SR\_) = u8SR;
00127
              KernelSWI::RI(true);
00128
00129 #endif
00130
          g_pclCurrent = (Thread*)g_pclNext;
00131 }
00132
00133 //----
00134 void ThreadPort::StartThreads()
00135 {
00136
                                 // configure the task switch SWI
          KernelSWI::Config();
          KernelTimer::Config(); // configure the kernel timer
00137
00138 #if KERNEL_USE_PROFILER
00139
          Profiler::Init();
00140 #endif
          Scheduler::SetScheduler(1); // enable the scheduler
00141
                                       // run the scheduler - determine the first thread to run
00142
          Scheduler::Schedule();
00143
00144
          Thread_Switch(); // Set the next scheduled thread to the current thread
00145
          KernelTimer::Start(); // enable the kernel timer
00146
                                // enable the task switch SWI
00147
          KernelSWI::Start();
00148
00149 #if KERNEL_USE_QUANTUM
00150
          // Restart the thread quantum timer, as any value held prior to starting
00151
          // the kernel will be invalid. This fixes a bug where multiple threads
          ^{\prime\prime} started with the highest priority before starting the kernel causes problems
00152
          // until the running thread voluntarily blocks.
00153
00154
          Ouantum::RemoveThread();
```

```
Quantum::AddThread(g_pclCurrent);
00156 #endif
00157
          // Restore the context...
00158
          Thread_RestoreContext(); // restore the context of the first running thread
ASM("reti"); // return from interrupt - will return to the first scheduled thread
00159
          ASM("reti");
00160
00161 }
00162
00163 //
00168 //---
00169 ISR(INT2_vect) __attribute__((signal, naked));
00170 ISR(INT2_vect)
00171 {
00172
          00173
          Thread_Switch();
                                    // Switch to the next task
          Thread_RestoreContext(); // Pop the context (registers) of the next task ASM("reti"); // Return to the next task
00174
          ASM("reti");
00175
00176 }
00177 } //namespace Mark3
00178
```

20.23 /home/moslevin/projects/github/m3-repo/kernel/src/atomic.cpp File Reference

Basic Atomic Operations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "atomic.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

20.23.1 Detailed Description

Basic Atomic Operations.

Definition in file atomic.cpp.

20.24 atomic.cpp

```
00001 /*
00002
00003
00004 |
00005 1
00006 |_
00007
80000
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "atomic.h"
00024 #include "threadport.h"
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]------
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
```

```
00033 #define DBG_FILE _DBG___KERNEL_ATOMIC_CPP
00035 //--[End Autogenerated content]------
00036
00037 #if KERNEL USE ATOMIC
00038 namespace Mark3
00039 {
00040 //---
00041 uint8_t Atomic::Set(uint8_t* pu8Source_, uint8_t u8Val_)
00042 {
00043
         uint8 t u8Ret:
         CS_ENTER();
u8Ret = *pu8Source_;
00044
00045
00046
         *pu8Source_ = u8Val_;
00047
         CS_EXIT();
00048
         return u8Ret;
00049 3
00050 //-
00051 uint16_t Atomic::Set(uint16_t* pu16Source_, uint16_t u16Val_)
00052 {
         uint16_t u16Ret;
00053
         00054
00055
         u16Ret
         *pul6Source_ = ul6Val_;
00056
00057
         CS_EXIT();
00058
         return u16Ret;
00059 }
00060 //---
00061 uint32_t Atomic::Set(uint32_t* pu32Source_, uint32_t u32Val_)
00062 {
00063
         uint32_t u32Ret;
         uinusz_c
CS_ENTER();
coppot = *pu32Source_;
00064
00065
00066
         *pu32Source_ = u32Val_;
00067
         CS_EXIT();
00068
         return u32Ret;
00069 }
00070
00071 //---
00072 uint8_t Atomic::Add(uint8_t* pu8Source_, uint8_t u8Val_)
00073 {
00074
         uint8 t u8Ret;
00075
         CS ENTER();
00076
         u8Ret = *pu8Source_;
00077
         *pu8Source_ += u8Val_;
00078
         CS_EXIT();
00079
         return u8Ret;
00080 }
00081
00082 //--
00083 uint16_t Atomic::Add(uint16_t* pu16Source_, uint16_t u16Val_)
00084 {
00085
         uint16_t u16Ret;
00086
         CS_ENTER();
         u16Ret = *pu16Source_;
00087
         *pul6Source_ += ul6Val_;
00088
00089
         CS_EXIT();
         return u16Ret;
00090
00091 }
00092
00093 //-----
00094 uint32_t Atomic::Add(uint32_t* pu32Source_, uint32_t u32Val_)
00095 {
00096
         uint32_t u32Ret;
00097
         CS_ENTER();
00098
         u32Ret = *pu32Source_;
00099
         *pu32Source_ += u32Val_;
00100
         CS EXIT();
00101
         return u32Ret:
00102 }
00103
00104 //----
00105 uint8_t Atomic::Sub(uint8_t* pu8Source_, uint8_t u8Val_)
00106 {
         uint8_t u8Ret;
00107
00108
         CS_ENTER();
00109
         u8Ret = *pu8Source_;
00110
         *pu8Source_ -= u8Val_;
00111
         CS_EXIT();
00112
         return u8Ret:
00113 }
00114
00115 //--
00116 uint16_t Atomic::Sub(uint16_t* pu16Source_, uint16_t u16Val_)
00117 {
        uint16_t u16Ret;
CS_ENTER();
00118
00119
```

```
00120
          u16Ret = *pu16Source_;
00121
          *pul6Source_ -= ul6Val_;
00122
          CS_EXIT();
00123
          return u16Ret;
00124 }
00125
00126 //-
00127 uint32_t Atomic::Sub(uint32_t* pu32Source_, uint32_t u32Val_)
00128 {
00129
          uint32_t u32Ret;
00130
          CS_ENTER();
00131
         u32Ret = *pu32Source_;
         *pu32Source_ -= u32Val_;
00132
00133
         CS_EXIT();
00134
          return u32Ret;
00135 }
00136
00137 //--
00138 bool Atomic::TestAndSet(bool* pbLock_)
00139 {
00140
          uint8_t u8Ret;
00141
          CS_ENTER();
         u8Ret = *pbLock_;
00142
         if (!u8Ret) {
00143
00144
             *pbLock_ = 1;
00145
00146
         CS_EXIT();
00147
         return u8Ret;
00148 }
00149 \} //namespace Mark3
00150 #endif // KERNEL USE ATOMIC
```

20.25 /home/moslevin/projects/github/m3-repo/kernel/src/autoalloc.cpp File Reference

Automatic memory allocation for kernel objects.

```
#include "mark3cfg.h"
#include "mark3.h"
#include "autoalloc.h"
#include "threadport.h"
#include "kernel.h"
#include <stdint.h>
```

20.25.1 Detailed Description

Automatic memory allocation for kernel objects.

Definition in file autoalloc.cpp.

20.26 autoalloc.cpp

```
00021 #include "mark3.h"
00022 #include "autoalloc.h"
00023 #include "threadport.h"
00024 #include "kernel.h"
00025
00026 #include <stdint.h>
00027
00028 #if KERNEL_USE_AUTO_ALLOC
00029 using namespace Mark3;
00030 //--
00031 // Override new() and delete() using functions provided to AutoAlloc
00032 //---
00033 void* operator new(size_t n)
00034 {
00035
          return AutoAlloc::NewRawData(n);
00036 }
00037
00038 //--
00039 void* operator new[](size_t n)
00040 {
00041
          return AutoAlloc::NewRawData(n);
00042 }
00043
00044 //----
00045 void operator delete(void * p)
00046 {
00047
         AutoAlloc::DestroyRawData(p);
00048 }
00049
00050 //----
00051 void operator delete[](void * p)
00052 {
00053
         AutoAlloc::DestroyRawData(p);
00054 }
00055
00056 //----
00057 namespace Mark3
00059 AutoAllocAllocator_t AutoAlloc::m_pfAllocator;
00060 AutoAllocFree_t AutoAlloc::m_pfFree;
00061
00062 //---
00063 void AutoAlloc::Init()
00064 {
00065
         m_pfAllocator = NULL;
         m_pfFree = NULL;
00066
00067 }
00068
00069 //---
00070 void* AutoAlloc::Allocate(AutoAllocType eType_, size_t sSize_)
00071 {
00072
          if (!m_pfAllocator) {
         return NULL;
00073
00074
00075
         return m_pfAllocator(eType_, sSize_);
00076 }
00077
00078 //---
00079 void AutoAlloc::Free(AutoAllocType eType_, void* pvObj_)
) 08000
00081
          if (!m_pfFree) {
         return;
00082
00083
00084
         m_pfFree(eType_, pvObj_);
00085 }
00086
00087 #if KERNEL_USE_SEMAPHORE
00088 //----
00089 Semaphore* AutoAlloc::NewSemaphore(void)
00090 {
00091
          void* pvObj = Allocate(AutoAllocType::Semaphore, sizeof(Semaphore));
00092
         return new (pvObj) Semaphore();
}
          if (pvObj) {
00093
00094
00095
          return 0;
00096 }
00097 //--
00098 void AutoAlloc::DestroySemaphore(Semaphore *pclSemaphore_)
00099 {
00100
          pclSemaphore ->~Semaphore():
00101
         Free (AutoAllocType::Semaphore, pclSemaphore_);
00102 }
00103 #endif
00104
00105 #if KERNEL_USE_MUTEX
00106 //----
00107 Mutex* AutoAlloc::NewMutex(void)
```

20.26 autoalloc.cpp 251

```
00108 {
00109
          void* pvObj = Allocate(AutoAllocType::Mutex, sizeof(Mutex));
00110
         return new (pvObj) Mutex();
}
          if (pvObj) {
00111
00112
00113
          return 0;
00114 }
00115 //---
00116 void AutoAlloc::DestroyMutex(Mutex *pclMutex_)
00117 {
00118
          pclMutex_->~Mutex();
00119
         Free(AutoAllocType::Mutex, pclMutex_);
00120 }
00121 #endif
00122
00123 #if KERNEL_USE_EVENTFLAG
00124 //--
00125 EventFlag* AutoAlloc::NewEventFlag(void)
00126 {
00127
          void* pvObj = Allocate(AutoAllocType::EventFlag, sizeof(EventFlag));
00128
         return new (pvObj) EventFlag();
}
          if (pvObj) {
00129
00130
00131
         return 0:
00132 }
00133 //--
00134 void AutoAlloc::DestroyEventFlag(EventFlag *pclEventFlag_)
00135 {
00136
          pclEventFlag_->~EventFlag();
00137
          Free(AutoAllocType::EventFlag, pclEventFlag_);
00138 }
00139 #endif
00140
00141 #if KERNEL_USE_MESSAGE
00142 //--
00143 Message* AutoAlloc::NewMessage(void)
00144 {
00145
          void* pvObj = Allocate(AutoAllocType::Message, sizeof(Message));
00146
         if (pvObj) {
00147
            return new (pvObj) Message();
00148
00149
          return 0:
00150 }
00151 //----
00152 void AutoAlloc::DestroyMessage(Message *pclMessage_)
00153 {
00154
          pclMessage_->~Message();
00155
         Free(AutoAllocType::Message, pclMessage_);
00156 }
00157 //-
00158 MessagePool* AutoAlloc::NewMessagePool(void)
00159 {
00160
          void* pvObj = Allocate(AutoAllocType::MessagePool, sizeof(MessagePool));
00161
         if (pvObj) {
              return new (pvObj) MessagePool();
00162
00163
         }
00164
         return 0;
00165 }
00166 //---
00167 void AutoAlloc::DestroyMessagePool(MessagePool *pclMessagePool_)
00168 {
00169
          pclMessagePool ->~MessagePool();
00170
          Free (AutoAllocType::MessagePool, pclMessagePool_);
00171 }
00172
00173 //----
00174 MessageQueue* AutoAlloc::NewMessageQueue(void)
00175 {
00176
          void* pvObj = Allocate(AutoAllocType::MessageQueue, sizeof(MessageQueue));
00177
         if (pvObj) {
00178
             return new (pvObj) MessageQueue();
00179
00180
          return 0;
00181 }
00182 //---
00183 void AutoAlloc::DestroyMessageQueue (MessageQueue *pclMessageQ_)
00184 {
00185
          pclMessageQ_->~MessageQueue();
00186
         Free(AutoAllocType::MessageQueue, pclMessageQ_);
00187 }
00188 #endif
00189
00190 #if KERNEL_USE_NOTIFY
00191 //-
00192 Notify* AutoAlloc::NewNotify(void)
00193 {
00194
          void* pvObj = Allocate(AutoAllocType::Notify, sizeof(Notify));
```

```
00195
         if (pvObj) {
         return new (pvObj) Notify();
}
00196
00197
          return 0:
00198
00199 }
00200 //----
00201 void AutoAlloc::DestroyNotify(Notify *pclNotify_)
00202 {
00203
          pclNotify_->~Notify();
00204
         Free(AutoAllocType::Notify, pclNotify_);
00205 }
00206 #endif
00207
00208 #if KERNEL_USE_MAILBOX
00209 //-
00210 Mailbox* AutoAlloc::NewMailbox(void)
00211 {
00212
          void* pvObj = Allocate(AutoAllocType::MailBox, sizeof(Mailbox));
         if (pvObj) {
            return new (pvObj) Mailbox();
00214
00215
00216
          return 0:
00217 }
00218 //---
00219 void AutoAlloc::DestroyMailbox(Mailbox *pclMailbox_)
00220 {
00221
          pclMailbox_->~Mailbox();
00222
         Free(AutoAllocType::MailBox, pclMailbox_);
00223 }
00224 #endif
00225
00226 #if KERNEL_USE_CONDVAR
00227 //-
00228 ConditionVariable* AutoAlloc::NewConditionVariable()
00229 {
          void* pvObj = Allocate(AutoAllocType::ConditionVariable, sizeof(
00230
     ConditionVariable));
00231
         return new (pvObj) ConditionVariable();
}
        if (pvObj) {
00232
00233
00234
          return 0;
00235 }
00236 //--
00237 void AutoAlloc::DestroyConditionVariable (ConditionVariable* pclCondvar_)
00238 {
00239
          pclCondvar_->~ConditionVariable();
00240
         Free(AutoAllocType::ConditionVariable, pclCondvar_);
00241 }
00242 #endif
00243
00244 #if KERNEL_USE_READERWRITER
00245 //--
00246 ReaderWriterLock* AutoAlloc::NewReaderWriterLock()
00247 {
          void* pvObj = Allocate(AutoAllocType::ReaderWriterLock, sizeof(
00248
     ReaderWriterLock));
00249
       if (pvObj) {
00250
            return new (pvObj) ReaderWriterLock();
00251
00252
          return 0:
00253 }
00254 //-
00255 void AutoAlloc::DestroyReaderWriterLock (ReaderWriterLock *pclReaderWriterLock_)
00256 {
00257
          pclReaderWriterLock_->~ReaderWriterLock();
00258
         Free(AutoAllocType::ReaderWriterLock, pclReaderWriterLock_);
00259 }
00260 #endif
00261
00262 //--
00263 Thread* AutoAlloc::NewThread(void)
00264 {
00265
          void* pvObj = Allocate(AutoAllocType::Thread, sizeof(Thread));
00266
         if (pvObj) {
            return new (pvObj) Thread();
00267
00268
00269
          return 0;
00270 }
00271 //---
00272 void AutoAlloc::DestroyThread(Thread *pclThread)
00273 {
00274
          pclThread_->~Thread();
00275
         Free (AutoAllocType::Thread, pclThread_);
00276 }
00277
00278 #if KERNEL_USE_TIMERS
00279 //----
```

```
00280 Timer* AutoAlloc::NewTimer(void)
00282
         void* pvObj = Allocate(AutoAllocType::Timer, sizeof(Timer));
        return new (pvObj) Timer();
}
return 0;
        if (pvObj) {
00283
00284
00285
00287 }
00288 //---
00289 void AutoAlloc::DestroyTimer(Timer *pclTimer_)
00290 {
00291
         pclTimer ->~Timer();
       pclTimer_->~Timer();
Free(AutoAllocType::Timer, pclTimer_);
00292
00293 }
00294 #endif
00295
00296 //--
00297 void* AutoAlloc::NewUserTypeAllocation(uint8_t eType_)
00299
         return Allocate(static_cast<AutoAllocType>(eType_), 0);
00300 }
00301 //---
00302 void AutoAlloc::DestroyUserTypeAllocation(uint8_t eUserType_, void *pvObj_)
00303 {
00304
         Free(AutoAllocType::User, pvObj_);
00306 //----
00307 void* AutoAlloc::NewRawData(size_t sSize_)
00308 {
00309
         return Allocate(AutoAllocType::Raw, sSize_);
00310 }
00311 //--
00312 void AutoAlloc::DestroyRawData(void *pvData_)
00313 {
00314
         Free (AutoAllocType::Raw, pvData_);
00315 }
00316 } //namespace Mark3
00317 #endif
```

20.27 /home/moslevin/projects/github/m3-repo/kernel/src/blocking.cpp File Reference

Implementation of base class for blocking objects.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "thread.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.27.1 Detailed Description

Implementation of base class for blocking objects.

Definition in file blocking.cpp.

20.28 blocking.cpp

```
00001 /*======
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023
00024 #include "blocking.h"
00025 #include "thread.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]------
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_BLOCKING_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037 #include "kerneldebug.h"
00038
00039 namespace Mark3
00040 {
00041 //---
00042 void BlockingObject::Block(Thread* pclThread_)
00043 {
          KERNEL_ASSERT(pclThread_);
KERNEL_TRACE_1("Blocking Thread %d", static_cast<uint16_t>(pclThread_->
00044
00045
     GetID()));
00046
00047
           // Remove the thread from its current thread list (the "owner" list)
00048
          // ... And add the thread to this object's block list
00049
          Scheduler::Remove(pclThread_);
00050
          m_clBlockList.Add(pclThread_);
00051
00052
          // Set the "current" list location to the blocklist for this thread
          pclThread_->SetCurrent(&m_clBlockList);
00053
00054
          pclThread_->SetState(ThreadState::Blocked);
00055 }
00056
00057 //-
00058 void BlockingObject::BlockPriority(Thread* pclThread_)
00059 {
00060
          KERNEL_ASSERT (pclThread_);
          KERNEL_TRACE_1("Blocking Thread %d", static_cast<uint16_t>(pclThread_->
00061
      GetID()));
00062
00063
             Remove the thread from its current thread list (the "owner" list)
          // ... And add the thread to this object's block list
00064
00065
          Scheduler::Remove(pclThread_);
00066
          m_clBlockList.AddPriority(pclThread_);
00067
          // Set the "current" list location to the blocklist for this thread
00068
00069
          pclThread_->SetCurrent(&m_clBlockList);
00070
          pclThread_->SetState(ThreadState::Blocked);
00071 }
00072
00073 //--
00074 void BlockingObject::UnBlock(Thread* pclThread_)
00075 {
00076
          KERNEL_ASSERT (pclThread_);
00077
          KERNEL_TRACE_1("Unblocking Thread %d", static_cast<uint16_t>(pclThread_->
      GetID()));
00078
00079
          // Remove the thread from its current thread list (the "owner" list)
pclThread_->GetCurrent()->Remove(pclThread_);
00080
00081
00082
          // Put the thread back in its active owner's list. This is usually
00083
           // the ready-queue at the thread's original priority.
00084
          Scheduler::Add(pclThread_);
00085
00086
          // Tag the thread's current list location to its owner
00087
          pclThread_->SetCurrent(pclThread_->GetOwner());
00088
          pclThread_->SetState(ThreadState::Ready);
```

```
00089 } 00090 } //namespace Mark3
```

20.29 /home/moslevin/projects/github/m3-repo/kernel/src/condvar.cpp File Reference

Condition Variable implementation.

```
#include "mark3cfg.h"
#include "condvar.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.29.1 Detailed Description

Condition Variable implementation.

Definition in file condvar.cpp.

20.30 condvar.cpp

```
00001
00002 /
                                            _____
00003
00004
00005
00006
00007
80000
00009
00010 -- [Mark3 Realtime Platform] -
00011
00012 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00013 See license.txt for more information
00014 -----
00021 #include "mark3cfg.h"
00022 #include "condvar.h"
00024 #define _CAN_HAS_DEBUG
00025 //--[Autogenerated - Do Not Modify]------
00026 #include "dbg_file_list.h"
00027 #include "buffalogger.h"
00028 #if defined(DBG_FILE)
00029 # error "Debug logging file token already defined! Bailing."
00030 #else
00031 # define DBG_FILE _DBG___KERNEL_CONDVAR_CPP
00032 #endif
00033 //--[End Autogenerated content]-----
00034
00035 namespace Mark3 {
00036
00037 //---
00038 void ConditionVariable::Init()
00039
00040 {
00041
        m_clMutex.Init();
        m_clSemaphore.Init(0, 255);
```

```
00043 }
00044
00045 //--
00046 void ConditionVariable::Wait (Mutex* pclMutex_)
00047 {
00048
         m clMutex.Claim();
00050
00051
         m_u8Waiters++;
00052
         m_clMutex.Release();
00053
00054
00055
         m_clSemaphore.Pend();
00056
         pclMutex_->Claim();
00057 }
00058
00059 #if KERNEL USE_TIMEOUTS
00060 //-
00061 bool ConditionVariable::Wait(Mutex* pclMutex_, uint32_t u32WaitTimeMS_)
00063
00064
        pclMutex_->Release();
00065
00066
         m_u8Waiters++;
00067
00068
         m_clMutex.Release();
00069
00070
         if (!m_clSemaphore.Pend(u32WaitTimeMS_)) {
         return false;
00071
00072
00073
         return pclMutex_->Claim(u32WaitTimeMS_);
00074 }
00075 #endif
00076
00077 //--
00078 void ConditionVariable::Signal()
00079 {
          m_clMutex.Claim();
         if (m_u8Waiters) {
00082
          m_u8Waiters--;
00083
             m_clSemaphore.Post();
00084
00085
         m clMutex.Release();
00086 }
00088 //--
00089 void ConditionVariable::Broadcast()
00090 {
00091
         m clMutex.Claim();
00092
         while (m_u8Waiters > 0) {
00093
00094
             m_u8Waiters--;
00095
             m_clSemaphore.Post();
00096
         }
00097
00098
         m clMutex.Release();
00099 }
00100
00101 } // namespace Mark3
```

20.31 /home/moslevin/projects/github/m3-repo/kernel/src/eventflag.cpp File Reference

Event Flag Blocking Object/IPC-Object implementation.

```
#include "mark3cfg.h"
#include "blocking.h"
#include "kernel.h"
#include "thread.h"
#include "eventflag.h"
#include "kernelaware.h"
#include "kerneldebug.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

20.32 eventflag.cpp 257

20.31.1 Detailed Description

Event Flag Blocking Object/IPC-Object implementation.

Definition in file eventflag.cpp.

20.32 eventflag.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009
      --[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ======
00019 #include "mark3cfg.h"
00020 #include "blocking.h"
00021 #include "kernel.h'
00022 #include "thread.h"
00022 #include "eventflag.h"
00024 #include "kernelaware.h
00025 #include "kerneldebug.h'
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]-----
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_EVENTFLAG_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037
00038 #if KERNEL_USE_EVENTFLAG
00039
00040 #if KERNEL_USE_TIMEOUTS
00041 #include "timerlist.h"
00042 namespace Mark3 {
00043 namespace {
00044 //-
00056 void TimedEventFlag_Callback(Thread* pclOwner_, void* pvData_)
00057 {
00058
          auto* pclEventFlag = static_cast<EventFlag*>(pvData_);
00059
00060
          pclEventFlag->WakeMe(pclOwner_);
          pclOwner_->SetExpired(true);
00061
00062
          pclOwner_->SetEventFlagMask(0);
00063
00064
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread()->
     GetCurPriority()) {
00065
              Thread::Yield();
00066
00067 }
00068 }
        // anonymous namespace
00069 //--
00070 EventFlag::~EventFlag()
00071 {
00072
          // If there are any threads waiting on this object when it goes out
          // of scope, set a kernel panic.
00073
00074
          if (m_clBlockList.HighestWaiter() != nullptr) {
00075
              Kernel::Panic(PANIC_ACTIVE_EVENTFLAG_DESCOPED);
00076
00077 }
00078
00079 //-
00080 void EventFlag::Init()
00081 {
00082 #if KERNEL_EXTRA_CHECKS
          KERNEL_ASSERT(!m_clBlockList.GetHead());
00083
00084 #endif
00085
          m_u16SetMask = 0;
00086 #if KERNEL_EXTRA_CHECKS
```

```
SetInitialized();
00088 #endif
00089 }
00090
00091 //--
00092 void EventFlag::WakeMe(Thread* pclChosenOne_)
00094 #if KERNEL_EXTRA_CHECKS
00095
         KERNEL_ASSERT(IsInitialized());
00096 #endif
00097
         UnBlock (pclChosenOne_);
00098
00099 }
00100 #endif
00101
00102 //--
00103 #if KERNEL_USE_TIMEOUTS
00104 uint16_t EventFlag::Wait_i(uint16_t u16Mask_,
     EventFlagOperation eMode_, uint32_t u32TimeMS_)
00105 #else
00106 uint16_t EventFlag::Wait_i(uint16_t u16Mask_,
     EventFlagOperation eMode_)
00107 #endif
00108 {
00109 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00110
00111 #endif
00112
00113
         auto bThreadYield = false;
00114
         auto bMatch
                         = false:
00115
00116 #if KERNEL_USE_TIMEOUTS
      Timer clEventTimer;
00117
00118
         auto bUseTimer = false;
00119 #endif
00120
00121
          // Ensure we're operating in a critical section while we determine
         // whether or not we need to block the current thread on this object.
00123
         CS ENTER();
00124
00125
         \ensuremath{//} Check to see whether or not the current mask matches any of the
         // desired bits.
00126
         g_pclCurrent->SetEventFlagMask(u16Mask_);
00127
00128
00129
         if ((eMode_ == EventFlagOperation::All_Set) || (eMode_ ==
     EventFlagOperation::All_Clear)) {
00130
              // Check to see if the flags in their current state match all of
00131
              \ensuremath{//} the set flags in the event flag group, with this mask.
             if ((m_u16SetMask & u16Mask_) == u16Mask_) {
00132
00133
                 bMatch = true;
00134
                 g_pclCurrent->SetEventFlagMask(u16Mask_);
00135
00136
         } else if ((eMode_ == EventFlagOperation::Any_Set) || (eMode_ ==
00139
             if ((m_u16SetMask & u16Mask_) != 0) {
00140
                 bMatch = true;
00141
                 g_pclCurrent->SetEventFlagMask(m_u16SetMask & u16Mask_);
00142
             }
00143
         }
00144
00145
         // We're unable to match this pattern as-is, so we must block.
00146
         if (!bMatch) {
00147
              // Reset the current thread's event flag mask & mode
00148
             g_pclCurrent->SetEventFlagMask(u16Mask_);
00149
             g_pclCurrent->SetEventFlagMode(eMode_);
00150
00151 #if KERNEL_USE_TIMEOUTS
             if (u32TimeMS_ != 0u) {
00152
00153
                 g_pclCurrent->SetExpired(false);
00154
                 clEventTimer.Init();
00155
                 clEventTimer.Start(false, u32TimeMS_, TimedEventFlag_Callback, this);
00156
                 bUseTimer = true;
00157
             }
00158 #endif
00159
00160
              // Add the thread to the object's block-list.
00161
             BlockPriority(g_pclCurrent);
00162
00163
              // Trigger that
00164
             bThreadYield = true;
00165
00166
00167
         // If bThreadYield is set, it means that we've blocked the current thread,
00168
         // and must therefore rerun the scheduler to determine what thread to
00169
         // switch to.
```

20.32 eventflag.cpp 259

```
if (bThreadYield) {
             // Switch threads immediately
00171
00172
              Thread::Yield();
00173
         }
00174
00175
          // Exit the critical section and return back to normal execution
00176
         CS EXIT();
00177
00182 #if KERNEL_USE_TIMEOUTS
       if (bUseTimer && bThreadYield) {
00183
00184
             clEventTimer.Stop();
00185
00186 #endif
00187
          return g_pclCurrent->GetEventFlagMask();
00188
00189 }
00190
00191 //--
00192 uint16_t EventFlag::Wait(uint16_t u16Mask_, EventFlagOperation eMode_)
00194 #if KERNEL_USE_TIMEOUTS
00195
         return Wait_i(u16Mask_, eMode_, 0);
00196 #else
00197
       return Wait_i (u16Mask_, eMode_);
00198 #endif
00199 }
00200
00201 #if KERNEL_USE_TIMEOUTS
00202 //---
00203 uint16_t EventFlag::Wait(uint16_t u16Mask_, EventFlagOperation eMode_,
     uint32 t u32TimeMS )
00204 {
00205
          return Wait_i(u16Mask_, eMode_, u32TimeMS_);
00206 }
00207 #endif
00208
00209 //--
00210 void EventFlag::Set(uint16_t u16Mask_)
00211 {
00212 #if KERNEL_EXTRA_CHECKS
00213
        KERNEL_ASSERT(IsInitialized());
00214 #endif
00215
00216
          Thread* pclPrev;
         Thread* pclCurrent;
00217
00218
          auto
                 bReschedule = false;
00219
         uint16_t u16NewMask;
00220
00221
         CS ENTER();
00222
00223
          // Walk through the whole block list, checking to see whether or not
00224
          // the current flag set now matches any/all of the masks and modes of
00225
          // the threads involved.
00226
          m_u16SetMask |= u16Mask_;
00227
00228
         u16NewMask = m u16SetMask;
00230
          // Start at the head of the list, and iterate through until we hit the
00231
          // "head" element in the list again. Ensure that we handle the case where
00232
          // we remove the first or last elements in the list, or if there's only
          // one element in the list.
00233
00234
         pclCurrent = static_cast<Thread*>(m_clBlockList.GetHead());
00235
00236
          \ensuremath{//} Do nothing when there are no objects blocking.
00237
          if (pclCurrent != nullptr) {
00238
              // First loop - process every thread in the block-list and check to
00239
              \ensuremath{//} see whether or not the current flags match the event-flag conditions
00240
              // on the thread.
00241
              do {
                 pclPrev
00242
                            = pclCurrent;
00243
                  pclCurrent = static_cast<Thread*>(pclCurrent->GetNext());
00244
00245
                  // Read the thread's event {\tt mask/mode}
                                      u16ThreadMask = pclPrev->GetEventFlagMask();
00246
                  uint16 t
                  auto eThreadMode = pclPrev->GetEventFlagMode();
00247
00248
00249
                  // For the "any" mode - unblock the blocked threads if one or more bits
                  // in the thread's bitmask match the object's bitmask
00250
00251
                  if ((EventFlagOperation::Any_Set == eThreadMode) || (
     EventFlagOperation::Any Clear == eThreadMode)) {
          if ((u16ThreadMask & m_u16SetMask) != 0) {
00252
00253
                          pclPrev->SetEventFlagMode(
      EventFlagOperation::Pending_Unblock);
00254
                          pclPrev->SetEventFlagMask(m_u16SetMask & u16ThreadMask);
00255
                          bReschedule = true;
00256
00257
                          // If the "clear" variant is set, then clear the bits in the {\tt mask}
```

```
// that caused the thread to unblock.
00259
                           if (EventFlagOperation::Any_Clear == eThreadMode) {
00260
                                u16NewMask &= ~(u16ThreadMask & u16Mask_);
00261
00262
00263
                   // For the "all" mode, every set bit in the thread's requested bitmask must // match the object's flag mask.
00264
00265
00266
                   else if ((EventFlagOperation::All_Set == eThreadMode) || (
     EventFlagOperation::All_Clear == eThreadMode)) {
00267
                       if ((u16ThreadMask & m_u16SetMask) == u16ThreadMask) {
                           pclPrev->SetEventFlagMode(
00268
     EventFlagOperation::Pending_Unblock);
00269
                           pclPrev->SetEventFlagMask(u16ThreadMask);
00270
                           bReschedule = true;
00271
                           // If the "clear" variant is set, then clear the bits in the mask
00272
00273
                           // that caused the thread to unblock.
                           if (EventFlagOperation::All_Clear == eThreadMode) {
00275
                                u16NewMask &= ~(u16ThreadMask & u16Mask_);
00276
00277
00278
                  }
00279
00280
               // To keep looping, ensure that there's something in the list, and
               // that the next item isn't the head of the list.
00281
00282
               while (pclPrev != m_clBlockList.GetTail());
00283
00284
              \ensuremath{//} Second loop - go through and unblock all of the threads that
              // were tagged for unblocking.
00285
00286
              pclCurrent = static_cast<Thread*>(m_clBlockList.GetHead());
00287
              auto bIsTail = false;
00288
              do {
                  pclPrev = pclCurrent;
pclCurrent = static_cast<Thread*>(pclCurrent->GetNext());
00289
00290
00291
                  // Check to see if this is the condition to terminate the loop if (pclPrev == m_clBlockList.GetTail()) {
00292
00293
00294
                       bIsTail = true;
00295
00296
00297
                   // If the first pass indicated that this thread should be
00298
                   // unblocked, then unblock the thread
                   if (pclPrev->GetEventFlagMode() ==
00299
     EventFlagOperation::Pending_Unblock) {
00300
                       UnBlock (pclPrev);
00301
00302
              } while (!bIsTail);
         }
00303
00304
00305
          // If we awoke any threads, re-run the scheduler
00306
          if (bReschedule)
00307
              Thread::Yield();
00308
          }
00309
00310
          // Update the bitmask based on any "clear" operations performed along
00311
00312
          m_u16SetMask = u16NewMask;
00313
          // Restore interrupts - will potentially cause a context switch if a
00314
          // thread is unblocked.
00315
00316
          CS EXIT();
00317 }
00318
00319 //--
00320 void EventFlag::Clear(uint16_t u16Mask_)
00321 {
00322 #if KERNEL_EXTRA_CHECKS
00323
        KERNEL_ASSERT(IsInitialized());
00324 #endif
00325
00326
          \ensuremath{//} Just clear the bitfields in the local object.
00327
          CS_ENTER();
          m u16SetMask &= ~u16Mask ;
00328
00329
          CS EXIT();
00330 }
00331
00332 //----
00333 uint16_t EventFlag::GetMask()
00334 {
00335 #if KERNEL_EXTRA_CHECKS
00336
          KERNEL_ASSERT(IsInitialized());
00337 #endif
00338
00339
           // Return the presently held event flag values in this object. Ensure
          \ensuremath{//} we get this within a critical section to guarantee atomicity.
00340
00341
          uint16 t u16Return;
```

20.33 /home/moslevin/projects/github/m3-repo/kernel/src/kernel.cpp File Reference

Kernel initialization and startup code.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "kernel.h"
#include "scheduler.h"
#include "thread.h"
#include "threadport.h"
#include "timerlist.h"
#include "message.h"
#include "profile.h"
#include "kernelprofile.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
#include "tracebuffer.h"
```

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.33.1 Detailed Description

Kernel initialization and startup code.

Definition in file kernel.cpp.

20.34 kernel.cpp

```
00022 #include "mark3cfg.h"
00023
00024 #include "kernel.h"
00025 #include "scheduler.h"
00026 #include "thread.h"
00027 #include "threadport.h"
00028 #include "timerlist.h'
00029 #include "message.h"
00030 #include "profile.h"
00031 #include "kernelprofile.h"
00032 #include "autoalloc.h"
00033
00034 #define _CAN_HAS_DEBUG
00035 //--[Autogenerated - Do Not Modify]-----
00036 #include "dbg_file_list.h"
00037 #include "buffalogger.h"
00038 #if defined(DBG_FILE)
00039 #error "Debug logging file token already defined! Bailing."
00040 #else
00041 #define DBG_FILE _DBG___KERNEL_KERNEL_CPP
00042 #endif
00043 //--[End Autogenerated content]-----
00044 #include "kerneldebug.h"
00045 #include "tracebuffer.h"
00046
00047 extern "C" {
00048 int __cxa_guard_acquire(long long int* wha) { return 0; }
00049 void __cxa_guard_release(long long int* wha) {}
00050 void atexit(void) {}
00051 }
00052
00053 namespace Mark3
00054 {
00055
00056 bool Kernel::m_bIsStarted;
00057 bool Kernel::m_bIsPanic;
00058 PanicFunc Kernel::m_pfPanic;
00059 #if KERNEL_USE_IDLE_FUNC
00060 IdleFunc Kernel::m_pfIdle;
00061 FakeThread_t Kernel::m_clIdle;
00062 #endif
00063
00064 #if KERNEL_USE_THREAD_CALLOUTS
00065 ThreadCreateCallout Kernel::m_pfThreadCreateCallout;
00066 ThreadExitCallout Kernel::m_pfThreadExitCallout;
00067 ThreadContextCallout Kernel::m_pfThreadContextCallout;
00068 #endif
00069
00070 #if KERNEL_USE_STACK_GUARD
00071 uint16_t Kernel::m_u16GuardThreshold;
00072 #endif
00073
00074 //--
00075 void Kernel::Init(void)
00076 {
00077 #if KERNEL_USE_AUTO_ALLOC
         AutoAlloc::Init();
00079 #endif
00080 #if KERNEL_USE_IDLE_FUNC
00081
          (reinterpret_cast<Thread*>(&m_clIdle))->InitIdle();
00082 #endif
00083 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
00084
          TraceBuffer::Init();
00085 #endif
00086
          KERNEL_TRACE("Initializing Mark3 Kernel");
00087
00088
          // Initialize the global kernel data - scheduler, timer-scheduler, and
          // the global message pool.
00089
00090
          Scheduler::Init();
00091 #if KERNEL_USE_TIMERS
00092
          TimerScheduler::Init();
00093 #endif
00094 #if KERNEL_USE_STACK_GUARD
         m_u16GuardThreshold = KERNEL_STACK_GUARD_DEFAULT;
00095
00096 #endif
00097 }
00098
00099 //---
00100 void Kernel::Start(void)
00101 {
          KERNEL_TRACE("Starting Mark3 Scheduler");
00102
00103
          m_bIsStarted = true;
00104
          ThreadPort::StartThreads();
00105
          KERNEL_TRACE("Error starting Mark3 Scheduler");
00106 }
00107
00108 //----
```

```
00109 void Kernel::Panic(uint16_t u16Cause_)
00111
         m_bIsPanic = true;
         if (m_pfPanic != nullptr) {
00112
00113
             m_pfPanic(u16Cause_);
       } else {
00114
00115 #if KERNEL_AWARE_SIMULATION
00116 KernelAware::Print("Panic\n");
00117
             KernelAware::Trace(0, 0, u16Cause_, g_pclCurrent->
     GetID());
00118
             KernelAware::ExitSimulator();
00119 #endif
00120
             while (true) { }
00121
00122 }
00123 } //namespace Mark3
00124
```

20.35 /home/moslevin/projects/github/m3-repo/kernel/src/kernelaware.cpp File Reference

Kernel aware simulation support.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "kernelaware.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

20.35.1 Detailed Description

Kernel aware simulation support.

Definition in file kernelaware.cpp.

20.36 kernelaware.cpp

```
00001 /*
00002
00003
00004
                  1 11
00005 1
00006
80000
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ==
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "kernelaware.h"
00024 #include "threadport.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 #error "Debug logging file token already defined! Bailing."
00033 #define DBG_FILE _DBG___KERNEL_KERNELAWARE_CPP
```

```
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL AWARE SIMULATION
00038
00039 //---
00044 typedef enum {
00045
         KA\_COMMAND\_IDLE = 0,
00046
          KA_COMMAND_PROFILE_INIT,
00047
          KA COMMAND PROFILE START,
00048
         KA_COMMAND_PROFILE_STOP,
         KA_COMMAND_PROFILE_REPORT,
00049
00050
          KA_COMMAND_EXIT_SIMULATOR,
00051
         KA_COMMAND_TRACE_0,
00052
          KA_COMMAND_TRACE_1,
00053
          KA_COMMAND_TRACE_2,
00054
          KA COMMAND PRINT
00055 } KernelAwareCommand_t;
00056
00057 //--
00066 typedef union {
00067
          volatile uint16_t au16Buffer[5];
00068
00072
          struct {
00073
              volatile const char* szName;
00074
         } Profiler;
00079
         struct {
           volatile uint16_t u16File;
00080
00081
              volatile uint16_t u16Line;
            volatile uint16_t u16Arg1;
volatile uint16_t u16Arg2;
00082
00083
00084
         } Trace;
00089
         struct {
00090
              volatile const char* szString;
         } Print;
00091
00092 } KernelAwareData_t;
00093
00095 // Must not live in Mark3 namespace
00096 using namespace Mark3;
00097 volatile bool g_bIsKernelAware;
00098 volatile uint8_t g_u8KACommand;
00099 KernelAwareData_t g_stKAData;
00100
00101 namespace Mark3
00102 {
00103 //----
00104 void Trace_i(
          uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_, KernelAwareCommand_t eCmd_)
00105
00106 {
00107
          CS_ENTER();
00108
          g_stKAData.Trace.u16File = u16File_;
00109
          g_stKAData.Trace.u16Line = u16Line_;
          g_stKAData.Trace.u16Arg1 = u16Arg1_;
00110
          g_stKAData.Trace.ul6Arg2 = ul6Arg2_;
00111
          g_u8KACommand
CS_EXIT();
00112
                                    = eCmd ;
00113
00114 }
00115
00116 //---
00117 void KernelAware::ProfileInit(const char* szStr_)
00118 {
00119
          CS_ENTER();
00120
          g_stKAData.Profiler.szName = szStr_;
          g_u8KACommand
00121
                                     = KA_COMMAND_PROFILE_INIT;
00122
          CS_EXIT();
00123 }
00124
00125 //-
00126 void KernelAware::ProfileStart(void)
00127 {
00128
          g_u8KACommand = KA_COMMAND_PROFILE_START;
00129 }
00130
00131 //-
00132 void KernelAware::ProfileStop(void)
00133 {
00134
          g_u8KACommand = KA_COMMAND_PROFILE_STOP;
00135 }
00136
00137 //-
00138 void KernelAware::ProfileReport(void)
00139 {
00140
          g_u8KACommand = KA_COMMAND_PROFILE_REPORT;
00141 }
00142
00143 //----
```

```
00144 void KernelAware::ExitSimulator(void)
00146
         g_u8KACommand = KA_COMMAND_EXIT_SIMULATOR;
00147 }
00148
00149 //-
00150 void KernelAware::Trace(uint16_t u16File_, uint16_t u16Line_)
00152
         Trace_i(u16File_, u16Line_, 0, 0, KA_COMMAND_TRACE_0);
00153 }
00154
00155 //-
00156 void KernelAware::Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_)
00158
         Trace_i(u16File_, u16Line_, u16Arg1_, 0, KA_COMMAND_TRACE_1);
00159
00160 //-
00161 void KernelAware::Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t
      u16Arg2_)
00162 {
00163
          Trace_i(u16File_, u16Line_, u16Arg1_, u16Arg2_, KA_COMMAND_TRACE_2);
00164 }
00165
00166 //---
00167 void KernelAware::Print(const char* szStr_)
00168 {
00169
         CS_ENTER();
00170
       g_stKAData.Print.szString = szStr_;
        g_u8KACommand = KA_COMMAND_PRINT;
CS_EXIT();
00171
00172
00173 }
00174
00175 //----
00176 bool KernelAware::IsSimulatorAware(void)
00177 {
00178
         return g_bIsKernelAware;
00179 }
00180 } //namespace Mark3
```

20.37 /home/moslevin/projects/github/m3-repo/kernel/src/ksemaphore.cpp File Reference

Semaphore Blocking-Object Implemenation.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ksemaphore.h"
#include "blocking.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.37.1 Detailed Description

Semaphore Blocking-Object Implemenation.

Definition in file ksemaphore.cpp.

20.38 ksemaphore.cpp

```
00001 /*=======
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 m0slevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "ksemaphore.h"
00026 #include "blocking.h"
00027
00028 #define _CAN_HAS_DEBUG
00029 //--[Autogenerated - Do Not Modify]-----
00030 #include "dbg_file_list.h"
00031 #include "buffalogger.h"
00032 #if defined(DBG_FILE)
00033 #error "Debug logging file token already defined! Bailing."
00034 #else
00035 #define DBG_FILE _DBG___KERNEL_KSEMAPHORE_CPP
00036 #endif
00037 //--[End Autogenerated content]-----
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL_USE_SEMAPHORE
00041
00042 #if KERNEL_USE_TIMEOUTS
00043 #include "timerlist.h"
00044 namespace Mark3
00045 (
00046 namespace
00047 {
00048 //--
00059 void TimedSemaphore_Callback(Thread* pclOwner_, void* pvData_)
00060 {
00061
          auto* pclSemaphore = static_cast<Semaphore*>(pvData_);
00062
00063
          // Indicate that the semaphore has expired on the thread
00064
          pclOwner_->SetExpired(true);
00065
00066
          // Wake up the thread that was blocked on this semaphore.
00067
          pclSemaphore->WakeMe(pclOwner_);
00068
00069
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread()->
      GetCurPriority()) {
00070
              Thread::Yield();
00071
00072 3
00073 } //anonymous namespace
00074
00076 Semaphore::~Semaphore()
00077 {
00078
           // If there are any threads waiting on this object when it goes out
00079
          // of scope, set a kernel panic.
if (m_clBlockList.GetHead() != nullptr) {
08000
00081
              Kernel::Panic (PANIC_ACTIVE_SEMAPHORE_DESCOPED);
00082
00083 }
00084
00085 //---
00086 void Semaphore::WakeMe(Thread* pclChosenOne_)
00087 {
00088 #if KERNEL_EXTRA_CHECKS
00089
          KERNEL_ASSERT(IsInitialized());
00090 #endif
00091
00092
           // Remove from the semaphore waitlist and back to its ready list.
00093
          UnBlock (pclChosenOne_);
00094 }
00095
00096 #endif // KERNEL_USE_TIMEOUTS
00097
00098 //
00099 uint8_t Semaphore::WakeNext()
00100 {
00101
          auto* pclChosenOne = m_clBlockList.HighestWaiter();
```

```
00103
           // Remove from the semaphore waitlist and back to its ready list.
00104
          UnBlock (pclChosenOne);
00105
          // Call a task switch if higher or equal priority thread \,
00106
           if (pclChosenOne->GetCurPriority() >= Scheduler::GetCurrentThread()->
00107
      GetCurPriority()) {
00108
00109
00110
          return 0;
00111 }
00112
00113 //--
00114 void Semaphore::Init(uint16_t u16InitVal_, uint16_t u16MaxVal_)
00115 {
00116 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(!m_clBlockList.GetHead());
00117
00118 #endif
00120
          // Copy the paramters into the object - set the maximum value for this
00121
          // semaphore to implement either binary or counting semaphores, and set
          /// the initial count. Clear the wait list for this object.
m_ul6Value = ul6InitVal_;
00122
00123
          m_u16MaxValue = u16MaxVal_;
00124
00125
00126 #if KERNEL_EXTRA_CHECKS
00127
          SetInitialized();
00128 #endif
00129
00130 }
00131
00132 //
00133 bool Semaphore::Post()
00134
00135 #if KERNEL_EXTRA_CHECKS
          KERNEL_ASSERT(IsInitialized());
00136
00137 #endif
00138
00139
           KERNEL_TRACE_1("Posting semaphore, Thread %d", static_cast<uint16_t>(g_pclCurrent->
00140
00141
          auto bThreadWake = false;
                           = false;
00142
          auto bBail
00143
          // Increment the semaphore count - we can mess with threads so ensure this
          // is in a critical section. We don't just disable the scheudler since
00144
00145
           // we want to be able to do this from within an interrupt context as well.
00146
          CS_ENTER();
00147
00148
          // If nothing is waiting for the semaphore
00149
          if (m_clBlockList.GetHead() == NULL) {
00150
               // Check so see if we've reached the maximum value in the semaphore
00151
               if (m_u16Value < m_u16MaxValue) {</pre>
00152
                   // Increment the count value
00153
                   m u16Value++;
              } else {
    // Maximum value has been reached, bail out.
00154
00155
00156
                   bBail = true;
00157
          } else {
00158
00159
             // Otherwise, there are threads waiting for the semaphore to be
              // otherwise, there are threads watting for the semaphore to b. // posted, so wake the next one (highest priority goes first). bThreadWake = (WakeNext() != 0u);
00160
00161
00162
          }
00163
00164
          CS_EXIT();
00165
          // If we weren't able to increment the semaphore count, fail out.
00166
00167
          if (bBail) {
00168
              return false:
00169
          }
00170
00171
          // if bThreadWake was set, it means that a higher-priority thread was
00172
          \ensuremath{//} woken. Trigger a context switch to ensure that this thread gets
00173
          // to execute next.
00174
          if (bThreadWake)
00175
              Thread::Yield();
00176
00177
          return true;
00178 }
00179
00180 //-
00181 #if KERNEL_USE_TIMEOUTS
00182 bool Semaphore::Pend_i(uint32_t u32WaitTimeMS_)
00183 #else
00184 void Semaphore::Pend_i(void)
00185 #endif
00186 {
```

```
00187 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00189 #endif
00190
00191
          KERNEL_TRACE_1("Pending semaphore, Thread %d", static_cast<uint16_t>(g_pclCurrent->
     GetID()));
00192
00193 #if KERNEL_USE_TIMEOUTS
00194
       Timer clSemTimer;
00195
         auto bUseTimer = false;
00196 #endif
00197
          // Once again, messing with thread data — ensure // we're doing all of these operations from within a thread-safe context.
00198
00199
00200
         CS_ENTER();
00201
         // Check to see if we need to take any action based on the semaphore count
00202
         if (m_u16Value != 0) {
00203
              // The semaphore count is non-zero, we can just decrement the count
00205
              // and go along our merry way.
              m_u16Value--;
00206
00207
          } else {
00208 // The semaphore count is zero - we need to block the current thread
00209 // and wait until the semaphore is posted from elsewhere. 00210 #if KERNEL_USE_TIMEOUTS
00211
             if (u32WaitTimeMS_ != 0u) {
00212
                  g_pclCurrent->SetExpired(false);
00213
                  clSemTimer.Init();
00214
                  clSemTimer.Start(false, u32WaitTimeMS_, TimedSemaphore_Callback, this);
00215
                  bUseTimer = true;
00216
              }
00217 #endif
00218
              BlockPriority(g_pclCurrent);
00219
00220
              // Switch Threads immediately
              Thread::Yield();
00221
00222
        }
00224
        CS_EXIT();
00225
00226 #if KERNEL_USE_TIMEOUTS
      if (bUseTimer) {
00227
00228
             clSemTimer.Stop():
00229
              return (static_cast<int>(g_pclCurrent->GetExpired()) == 0);
00230
00231
          return true;
00232 #endif
00233 }
00234
00235 //
00236 // Redirect the untimed pend API to the timed pend, with a null timeout.
00237 void Semaphore::Pend()
00238 {
00239 #if KERNEL_USE_TIMEOUTS
00240
         Pend_i(0);
00241 #else
00242
        Pend_i();
00243 #endif
00244 }
00245
00246 #if KERNEL USE TIMEOUTS
00247 //---
00248 bool Semaphore::Pend(uint32_t u32WaitTimeMS_)
00249 {
00250
          return Pend_i (u32WaitTimeMS_);
00251 }
00252 #endif
00253
00254 //---
00255 uint16_t Semaphore::GetCount()
00256 {
00257 #if KERNEL_EXTRA_CHECKS
00258
         KERNEL_ASSERT(IsInitialized());
00259 #endif
00260 uint16_t u16Ret;
00261 CS_ENTER();
00262
         u16Ret = m_u16Value;
00263
         CS_EXIT();
00264
         return u16Ret;
00265 }
00266 } //namespace Mark3
00267 #endif
```

20.39 /home/moslevin/projects/github/m3-repo/kernel/src/II.cpp File Reference

Core Linked-List implementation, from which all kernel objects are derived.

```
#include "kerneltypes.h"
#include "kernel.h"
#include "ll.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.39.1 Detailed Description

Core Linked-List implementation, from which all kernel objects are derived.

Definition in file II.cpp.

20.40 II.cpp

```
00001 /*==
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00022 #include "kerneltypes.h"
00023 #include "kernel.h"
00024 #include "11.h"
00025
00026 #define CAN HAS DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
00033 #define DBG_FILE _DBG___KERNEL_LL_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 namespace Mark3
00040 {
00041 //---
00042 void LinkListNode::ClearNode()
00043 {
00044
         next = NULL;
00045
         prev = NULL;
00046 }
00047
00048 //-
```

```
00049 void DoubleLinkList::Add(LinkListNode* node_)
00050 {
00051
          KERNEL_ASSERT (node_);
00052
          node_->prev = m_pclTail;
00053
          node_->next = NULL;
00054
00055
00056
          \ensuremath{//} If the list is empty, initilize the head
00057
          if (m_pclHead == nullptr) {
              m_pclHead = node_;
00058
00059
          // Otherwise, adjust the tail's next pointer
00060
00061
          else {
            m_pclTail->next = node_;
00062
00063
00064
          \ensuremath{//} Move the tail node, and assign it to the new node just passed in
00065
00066
          m_pclTail = node_;
00067 }
00068
00069 //--
00070 void DoubleLinkList::Remove(LinkListNode* node_)
00071 {
00072
          KERNEL ASSERT (node ):
00073
00074
          if (node_->prev != nullptr) {
00075 #if SAFE_UNLINK
00076
             if (node_->prev->next != node_) {
                  Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00077
00078
             }
00079 #endif
08000
             node_->prev->next = node_->next;
00081
        if (node_->next != nullptr) {
00082
00083 #if SAFE_UNLINK
              if (node_->next->prev != node_) {
00084
00085
                  Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00087 #endif
88000
              node_->next->prev = node_->prev;
00089
00090
         if (node_ == m_pclHead) {
             m_pclHead = node_->next;
00091
00092
00093
          if (node_ == m_pclTail) {
00094
            m_pclTail = node_->prev;
00095
00096
          node ->ClearNode();
00097 }
00098
00100 void CircularLinkList::Add(LinkListNode* node_)
00101 {
00102
          KERNEL_ASSERT (node_);
00103
00104
          if (m pclHead == nullptr) {
             // If the list is empty, initilize the nodes
              m_pclHead = node_;
00106
              m_pclTail = node_;
00107
         } else {
    // Move the tail node, and assign it to the new node just passed in
00108
00109
00110
              m_pclTail->next = node_;
00111
00112
00113
          // Add a node to the end of the linked list.
         node_->prev = m_pclTail;
node_->next = m_pclHead;
00114
00115
00116
00117
          m_pclTail
                          = node :
          m_pclHead->prev = node_;
00118
00119 }
00120
00121 //--
00122 void CircularLinkList::Remove(LinkListNode* node_)
00123 {
00124
          KERNEL_ASSERT (node_);
00125
00126
          // Check to see if this is the head of the list..
00127
          if ((node_ == m_pclHead) && (m_pclHead == m_pclTail)) {
              // Clear the head and tail pointers - nothing else left.
00128
              m_pclHead = NULL;
00129
              m_pclTail = NULL;
00130
00131
00132
         }
00133
00134 #if SAFE_UNLINK
00135
         // Verify that all nodes are properly connected
```

```
if ((node_->prev->next != node_) || (node_->next->prev != node_)) {
              Kernel::Panic(PANIC_LIST_UNLINK_FAILED);
00138
00139 #endif
00140
         // This is a circularly linked list - no need to check for connection,
00141
         // just remove the node.
00143
         node_->next->prev = node_->prev;
00144
         node_->prev->next = node_->next;
00145
00146
         if (node_ == m_pclHead) {
            m_pclHead = m_pclHead->next;
00147
00148
00149
         if (node_ == m_pclTail) {
         m_pclTail = m_pclTail->prev;
}
00150
00151
         node ->ClearNode();
00152
00153 }
00156 void CircularLinkList::PivotForward()
00157 {
00158
         if (m_pclHead != nullptr) {
00159
             m_pclHead = m_pclHead->next;
        m_pc:Head = m_pc:Head->next;
m_pc!Tail = m_pc!Tail->next;
00160
00161 }
00162 }
00163
00164 //---
00165 void CircularLinkList::PivotBackward()
00166 {
00167
         if (m_pclHead != nullptr) {
        m_pclHead = m_pclHead->prev;
m_pclTail
00168
00169
             m_pclTail = m_pclTail->prev;
00170
00171 }
00172
00174 void CircularLinkList::InsertNodeBefore(
     LinkListNode* node_, LinkListNode* insert_)
00175 {
00176
        KERNEL ASSERT (node );
00177
00178
         node_->next = insert_;
00179
         node_->prev = insert_->prev;
00180
00181
         if (insert_->prev != nullptr) {
         insert_->prev := nullptr) {
  insert_->prev->next = node_;
}
00182
00183
00184
         insert ->prev = node ;
00185 }
00186 } //namespace Mark3
```

20.41 /home/moslevin/projects/github/m3-repo/kernel/src/lockguard.cpp File Reference

Mutex RAII helper class.

```
#include "lockguard.h"
```

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.41.1 Detailed Description

Mutex RAII helper class.

Definition in file lockguard.cpp.

20.42 lockguard.cpp

```
00001 /
00002
00003
00004
00005
00006
00007
80000
      --[Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00020 #include "lockguard.h"
00021
00022 namespace Mark3 {
00023 LockGuard::LockGuard(Mutex *pclMutex_)
00024 : m_bIsAcquired{true}
00025 , m_pclMutex{pclMutex_} 00026 {
00027
          m_pclMutex->Claim();
00028 }
00029
00030 #if KERNEL_USE_TIMEOUTS
00031 LockGuard::LockGuard(Mutex* pclMutex_, uint32_t u32TimeoutMs_)
00032 : m_pclMutex{pclMutex_}
00033 {
          m_bIsAcquired = m_pclMutex->Claim(u32TimeoutMs_);
00035 }
00036 #endif
00037
00038 LockGuard::~LockGuard()
00039 {
00040
          if (m bIsAcquired) {
00041
              m_pclMutex->Release();
00042
00043 }
00044
00045 } // namespace Mark3
```

20.43 /home/moslevin/projects/github/m3-repo/kernel/src/mailbox.cpp File Reference

Mailbox + Envelope IPC mechanism.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "ksemaphore.h"
#include "mailbox.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.43.1 Detailed Description

Mailbox + Envelope IPC mechanism.

Definition in file mailbox.cpp.

20.44 mailbox.cpp 273

20.44 mailbox.cpp

```
00001 /*========
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =========
00021 #include "mark3cfg.h"
00022 #include "kerneltypes.h"
00023 #include "ksemaphore.h"
00024 #include "mailbox.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]-----
00028 #include "dbg_file_list.h"
00029 #include "buffalogger.h
00030 #if defined(DBG_FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
00033 #define DBG FILE DBG KERNEL MAILBOX CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 #if KERNEL_USE_MAILBOX
00040 namespace Mark3
00041 {
00042 //----
00043 Mailbox::~Mailbox()
00044 {
          // If the mailbox isn't empty on destruction, kernel panic.
00045
         if (m_u16Free != m_u16Count)
00046
00047
              Kernel::Panic(PANIC_ACTIVE_MAILBOX_DESCOPED);
00048
00049 }
00050
00051 //---
00052 void Mailbox::Init(void* pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_)
00053 {
00054
          KERNEL_ASSERT (u16BufferSize_);
00055
          KERNEL_ASSERT (u16ElementSize_);
00056
          KERNEL_ASSERT (pvBuffer_);
00057
00058
          m pvBuffer
                           = pvBuffer ;
          m_u16ElementSize = u16ElementSize_;
00059
00060
00061
          m_u16Count = (u16BufferSize_ / u16ElementSize_);
          m_u16Free = m_u16Count;
00062
00063
00064
          m u16Head = 0;
00065
          m_u16Tail = 0;
00066
00067
          // We use the counting semaphore to implement blocking - with one element
00068
          // in the mailbox corresponding to a post/pend operation in the semaphore.
00069
          m_clRecvSem.Init(0, m_u16Free);
00070
00071 #if KERNEL_USE_TIMEOUTS
         // Binary semaphore is used to track any threads that are blocked on a // "send" due to lack of free slots.
00073
00074
         m_clSendSem.Init(0, 1);
00075 #endif
00076 }
00077
00078 /
00079 #if KERNEL_USE_AUTO_ALLOC
00080 Mailbox* Mailbox::Init(uint16_t u16BufferSize_, uint16_t u16ElementSize_)
00081 {
00082
          auto* pclNew
                        = AutoAlloc::NewMailbox();
         auto* pvBuffer = AutoAlloc::NewRawData(u16BufferSize_);
00083
00084
         pclNew->Init(pvBuffer, u16BufferSize_, u16ElementSize_);
00085
          return pclNew;
00086 }
00087 #endif
00088
00089 //
00090 void Mailbox::Receive(void* pvData_)
00091 {
```

```
00092
         KERNEL_ASSERT (pvData_);
00093
00094 #if KERNEL_USE_TIMEOUTS
00095
         Receive_i(pvData_, false, 0);
00096 #else
00097
         Receive_i(pvData_, false);
00098 #endif
00099 }
00100
00101 #if KERNEL_USE_TIMEOUTS
00102 //----
00103 bool Mailbox::Receive(void* pvData_, uint32_t u32TimeoutMS_)
00104 {
00105
         KERNEL_ASSERT (pvData_);
00106
         return Receive_i(pvData_, false, u32TimeoutMS_);
00107 }
00108 #endif
00109
00110 //---
00111 void Mailbox::ReceiveTail(void* pvData_)
00112 {
00113
         KERNEL_ASSERT (pvData_);
00114
00115 #if KERNEL_USE_TIMEOUTS
00116
         Receive_i (pvData_, true, 0);
00117 #else
00118
        Receive_i (pvData_, true);
00119 #endif
00120 }
00121
00122 #if KERNEL USE TIMEOUTS
00123 //-
00124 bool Mailbox::ReceiveTail(void* pvData_, uint32_t u32TimeoutMS_)
00125 {
00126
         KERNEL_ASSERT (pvData_);
         return Receive_i(pvData_, true, u32TimeoutMS_);
00127
00128 }
00129 #endif
00130
00131 //----
00132 bool Mailbox::Send(void* pvData_)
00133 {
         KERNEL_ASSERT (pvData_);
00134
00135
00136 #if KERNEL_USE_TIMEOUTS
00137
         return Send_i(pvData_, false, 0);
00138 #else
00139
       return Send_i(pvData_, false);
00140 #endif
00141 }
00142
00143 //----
00144 bool Mailbox::SendTail(void* pvData_)
00145 {
         KERNEL_ASSERT (pvData_);
00146
00147
00148 #if KERNEL_USE_TIMEOUTS
00149
         return Send_i (pvData_, true, 0);
00150 #else
00151
         return Send_i(pvData_, true);
00152 #endif
00153 }
00154
00155 #if KERNEL_USE_TIMEOUTS
00156 //--
00157 bool Mailbox::Send(void* pvData_, uint32_t u32TimeoutMS_)
00158 {
00159
         KERNEL ASSERT (pvData );
00160
00161
         return Send_i (pvData_, false, u32TimeoutMS_);
00162 }
00163
00164 //--
00165 bool Mailbox::SendTail(void* pvData_, uint32_t u32TimeoutMS_)
00166 {
00167
         KERNEL_ASSERT (pvData_);
00168
00169
         return Send_i (pvData_, true, u32TimeoutMS_);
00170 }
00171 #endif
00172
00174 #if KERNEL_USE_TIMEOUTS
00175 bool Mailbox::Send_i(const void* pvData_, bool bTail_, uint32_t u32TimeoutMS_)
00176 #else
00177 bool Mailbox::Send_i(const void* pvData_, bool bTail_)
00178 #endif
```

20.44 mailbox.cpp 275

```
00179 {
00180
          const void* pvDst = NULL;
00181
                      = false;
00182
          auto bRet
          auto bSchedState = Scheduler::SetScheduler(false);
00183
00184
00185 #if KERNEL_USE_TIMEOUTS
00186
         auto bBlock = false;
00187
          auto bDone = false;
          while (!bDone) {
    // Try to claim a slot first before resorting to blocking.
00188
00189
00190
              if (bBlock) {
00191
                  bDone = true;
00192
                  Scheduler::SetScheduler(bSchedState);
00193
                  m_clSendSem.Pend(u32TimeoutMS_);
00194
                  Scheduler::SetScheduler(false);
00195
00196 #endif
00197
00198
              CS_ENTER();
00199
              // Ensure we have a free slot before we attempt to write data
00200
              if (m_u16Free != 0u) {
00201
                  m_u16Free--;
00202
00203
                  if (bTail_) {
                      pvDst = GetTailPointer();
00205
                       MoveTailBackward();
00206
                   } else {
00207
                      MoveHeadForward();
                      pvDst = GetHeadPointer();
00208
00209
00210
                  bRet = true;
00211 #if KERNEL_USE_TIMEOUTS
00212
                  bDone = true;
00213 #endif
00214
00215 #if KERNEL_USE_TIMEOUTS
00216 else if (u32TimeoutMS_ != 0u) {
00217
                 bBlock = true;
00218
              } else {
00219
                  bDone = true;
              }
00220
00221 #endif
00222
             CS_EXIT();
00224
00225 #if KERNEL_USE_TIMEOUTS
00226
00227 #endif
00228
          // Copy data to the claimed slot, and post the counting semaphore
00230
00231
              CopyData(pvData_, pvDst, m_u16ElementSize);
00232
00233
00234
         Scheduler::SetScheduler(bSchedState);
00236
            m_clRecvSem.Post();
00237
          }
00238
00239
00240
          return bRet;
00241 }
00242
00243 //---
00244 #if KERNEL_USE_TIMEOUTS
00245 bool Mailbox::Receive_i(const void* pvData_, bool bTail_, uint32_t u32WaitTimeMS_)
00246 #else
00247 void Mailbox::Receive_i(const void* pvData_, bool bTail_)
00248 #endif
00249 {
00250
          const void* pvSrc;
00251
00252 #if KERNEL_USE_TIMEOUTS
       if (!m_clRecvSem.Pend(u32WaitTimeMS_)) {
00253
              // Failed to get the notification from the counting semaphore in the
              // time allotted. Bail.
00255
00256
              return false;
00257
00258 #else
        m_clRecvSem.Pend();
00259
00260 #endif
00261
00262
          // Disable the scheduler while we do this -- this ensures we don't have
         // multiple concurrent readers off the same queue, which could be problematic // if multiple writes occur during reads, etc.
00263
00264
00265
          auto bSchedState = Scheduler::SetScheduler(false);
```

```
00266
00267
          // Update the head/tail indexes, and get the associated data pointer for
00268
          // the read operation.
          CS_ENTER();
00269
00270
00271
          m_u16Free++;
00272
          if (bTail_) {
00273
              MoveTailForward();
              pvSrc = GetTailPointer();
00274
00275
00276
              pvSrc = GetHeadPointer();
00277
              MoveHeadBackward():
00278
          }
00279
00280
          CS_EXIT();
00281
00282
          CopyData(pvSrc, pvData_, m_u16ElementSize);
00283
00284
          Scheduler::SetScheduler(bSchedState);
00285
00286 #if KERNEL_USE_TIMEOUTS
00287
          // Unblock a thread waiting for a free slot to send to
00288
          m_clSendSem.Post();
00289
00290
          return true;
00291 #endif
00292 }
00293 } //namespace Mark3
00294 #endif
```

20.45 /home/moslevin/projects/github/m3-repo/kernel/src/message.cpp File Reference

Inter-thread communications via message passing.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "message.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.45.1 Detailed Description

Inter-thread communications via message passing.

Definition in file message.cpp.

20.46 message.cpp

20.46 message.cpp 277

```
00023 #include "mark3cfg.h"
00024
00025 #include "message.h"
00025 #Include "threadport.h"
00027
00028 #define _CAN_HAS_DEBUG
00029 //--[Autogenerated - Do Not Modify]-----
00030 #include "dbg_file_list.h"
00031 #include "buffalogger.h"
00032 #if defined(DBG_FILE)
00033 #error "Debug logging file token already defined! Bailing."
00034 #else
00035 #define DBG_FILE _DBG___KERNEL_MESSAGE_CPP
00036 #endif
00037 //--[End Autogenerated content]-----
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL USE MESSAGE
00041
00042 #if KERNEL_USE_TIMEOUTS
00043 #include "timerlist.h"
00044 #endif
00045 namespace Mark3
00046 {
00047 //-
00048 void MessagePool::Init()
00049 {
00050
          m_clList.Init();
00051 }
00052
00053 //
00054 void MessagePool::Push(Message* pclMessage_)
00055 {
00056
          KERNEL_ASSERT (pclMessage_);
00057
00058
          CS_ENTER();
00059
00060
         m_clList.Add(pclMessage_);
00061
00062
          CS_EXIT();
00063 }
00064
00065 //--
00066 Message* MessagePool::Pop()
00067 {
00068
          Message* pclRet;
00069
         CS_ENTER();
00070
00071
          pclRet = static_cast<Message*>(m_clList.GetHead());
          if (0 != pclRet) {
00072
            m_clList.Remove(static_cast<LinkListNode*>(pclRet));
00073
00074
00075
00076
          CS_EXIT();
00077
          return pclRet;
00078 }
00079
00080 //--
00081 Message* MessagePool::GetHead()
00082 {
00083
          return static_cast<Message*>(m_clList.GetHead());
00084 }
00085
00086 //--
00087 void MessageQueue::Init()
} 88000
00089
          m_clSemaphore.Init(0, GLOBAL_MESSAGE_POOL_SIZE);
00090 }
00091
00092
00093 Message* MessageQueue::Receive()
00094 {
00095 #if KERNEL_USE_TIMEOUTS
00096
         return Receive_i(0);
00097 #else
00098
        return Receive_i();
00099 #endif
00100 }
00101
00102 //---
00103 #if KERNEL_USE_TIMEOUTS
00104 Message* MessageQueue::Receive(uint32_t u32TimeWaitMS_)
00105 {
00106
          return Receive_i(u32TimeWaitMS_);
00107 }
00108 #endif
00109
```

```
00111 #if KERNEL_USE_TIMEOUTS
00112 Message* MessageQueue::Receive_i(uint32_t u32TimeWaitMS_)
00113 #else
00114 Message* MessageQueue::Receive_i(void)
00115 #endif
00116 {
00117
          Message* pclRet;
00118
00119 // Block the current thread on the counting semaphore
00120 #if KERNEL_USE_TIMEOUTS
00121    if (!m_clSemaphore.Pend(u32TimeWaitMS_)) {
00122
             return NULL;
00123
00124 #else
00125
         m_clSemaphore.Pend();
00126 #endif
00127
         CS_ENTER();
00129
00130
         // Pop the head of the message queue and return it
00131
         pclRet = static_cast<Message*>(m_clLinkList.GetHead());
         m_clLinkList.Remove(static_cast<Message*>(pclRet));
00132
00133
00134
         CS_EXIT();
00135
00136
          return pclRet;
00137 }
00138
00139 //---
00140 void MessageQueue::Send(Message* pclSrc_)
00141 {
00142
         KERNEL_ASSERT (pclSrc_);
00143
00144
         CS_ENTER();
00145
00146
         // Add the message to the head of the linked list
         m_clLinkList.Add(pclSrc_);
00148
00149
         // Post the semaphore, waking the blocking thread for the queue.
00150
         m_clSemaphore.Post();
00151
         CS EXIT():
00152
00153 }
00154
00155 //--
00156 uint16_t MessageQueue::GetCount()
00157 {
00158
          return m_clSemaphore.GetCount();
00159 }
00160 } //namespace Mark3
00161 #endif // KERNEL_USE_MESSAGE
```

20.47 /home/moslevin/projects/github/m3-repo/kernel/src/mutex.cpp File Reference

Mutual-exclusion object.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "mutex.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.47.1 Detailed Description

Mutual-exclusion object.

Definition in file mutex.cpp.

20.48 mutex.cpp 279

20.48 mutex.cpp

```
00001 /*=======
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 m0slevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00020 #include "kerneltypes.h"
00021 #include "mark3cfg.h"
00022
00023 #include "blocking.h"
00024 #include "mutex.h"
00025
00026 #define _CAN_HAS_DEBUG
00027 //--[Autogenerated - Do Not Modify]--
00028 #include "dbg_file_list.h
00029 #include "buffalogger.h"
00030 #if defined(DBG_FILE)
00031 #error "Debug logging file token already defined! Bailing."
00032 #else
00033 #define DBG_FILE _DBG___KERNEL_MUTEX_CPP
00034 #endif
00035 //--[End Autogenerated content]-----
00036
00037 #include "kerneldebug.h"
00038
00039 #if KERNEL_USE_MUTEX
00040
00041 #if KERNEL_USE_TIMEOUTS
00042 namespace Mark3
00043 (
00044 namespace
00045 {
00046 //--
00057 void TimedMutex_Callback(Thread* pclOwner_, void* pvData_)
00058 {
00059
          auto* pclMutex = static_cast<Mutex*>(pvData_);
00060
00061
          // Indicate that the semaphore has expired on the thread
00062
          pclOwner_->SetExpired(true);
00063
00064
           \ensuremath{//} Wake up the thread that was blocked on this semaphore.
00065
          pclMutex->WakeMe(pclOwner_);
00066
           if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread()->
00067
      GetCurPriority()) {
00068
              Thread::Yield();
00069
00070 3
00071 } // anonymous namespace
00072
00073 //-
00074 Mutex::~Mutex()
00075 {
00076
           // If there are any threads waiting on this object when it goes out
00077
          // of scope, set a kernel panic.
if (m_clBlockList.GetHead() != nullptr) {
00078
00079
               Kernel::Panic(PANIC_ACTIVE_MUTEX_DESCOPED);
08000
00081 }
00082
00083 //--
00084 void Mutex::WakeMe(Thread* pclOwner_)
00085 {
00086
            // Remove from the semaphore waitlist and back to its ready list.
00087
          UnBlock (pclOwner_);
00088 }
00089
00090 #endif
00091
00092 //-
00093 uint8_t Mutex::WakeNext()
00094 {
00095
           // Get the highest priority waiter thread
00096
          auto* pclChosenOne = m_clBlockList.HighestWaiter();
00097
00098
          // Unblock the thread
00099
          UnBlock (pclChosenOne);
```

```
\ensuremath{//} The chosen one now owns the mutex
00101
00102
           m_pclOwner = pclChosenOne;
00103
          // Signal a context switch if it's a greater than or equal to the current priority
if (pclChosenOne->GetCurPriority() >= Scheduler::GetCurrentThread()->
00104
00105
      GetCurPriority()) {
00106
00107
00108
           return 0;
00109 }
00110
00111 //---
00112 void Mutex::Init(bool bRecursive_)
00113 {
00114
           // Cannot re-init a mutex which has threads blocked on it
00115 #if KERNEL_EXTRA_CHECKS
          KERNEL_ASSERT(!m_clBlockList.GetHead());
00116
00117 #endif
00118
00119
           // Reset the data in the mutex
          m_bReady = true; // The mutex is free.
m_u8MaxPri = 0; // Set the maximum priority inheritence state
00120
00121
          m_usMaxrii - 0, // Clear the mutex owner
m_pclOwner = NULL; // Clear the mutex owner
m_usRecurse = 0; // Reset recurse count
00122
00123
          m_u8Recurse = 0;
           m_bRecursive = bRecursive_;
00125 #if KERNEL_EXTRA_CHECKS
00126
        SetInitialized();
00127 #endif
00128 }
00129
00130 //-
00131 #if KERNEL_USE_TIMEOUTS
00132 bool Mutex::Claim_i (uint32_t u32WaitTimeMS_)
00133 #else
00134 void Mutex::Claim_i(void)
00135 #endif
00137 #if KERNEL_EXTRA_CHECKS
00138
          KERNEL_ASSERT(IsInitialized());
00139 #endif
00140
           KERNEL_TRACE_1("Claiming Mutex, Thread %d", static_cast<uint16_t>(g_pclCurrent->
00141
      GetID()));
00142
00143 #if KERNEL_USE_TIMEOUTS
00144 Timer clTimer;
00145
          auto bUseTimer = false;
00146 #endif
00147
00148
           // Disable the scheduler while claiming the mutex - we're dealing with all
00149
          // sorts of private thread data, can't have a thread switch while messing
           // with internal data structures.
00150
00151
          Scheduler::SetScheduler(false);
00152
00153
           // Check to see if the mutex is claimed or not
          if (static_cast<int>(m_bReady) != 0) {
00155
               // Mutex isn't claimed, claim it.
00156
               m_bReady = false;
               m_u8Recurse = 0;
00157
               m_u8MaxPri = g_pclCurrent->GetPriority();
m_pclOwner = g_pclCurrent;
00158
00159
00160
00161
               Scheduler::SetScheduler(true);
00162
00163 #if KERNEL_USE_TIMEOUTS
00164
               return true;
00165 #else
00166
               return:
00167 #endif
00168
00169
00170
          // If the mutex is already claimed, check to see if this is the owner thread,
          // since we allow the mutex to be claimed recursively.
if (m_bRecursive && (g_pclCurrent == m_pclOwner)) {
00171
00172
00173
               // Ensure that we haven't exceeded the maximum recursive-lock count
00174
               KERNEL_ASSERT((m_u8Recurse < 255));</pre>
00175
               m_u8Recurse++;
00176
00177
               // Increment the lock count and bail
               Scheduler::SetScheduler(true);
00178
00179 #if KERNEL_USE_TIMEOUTS
00180
               return true;
00181 #else
00182
               return;
00183 #endif
00184
```

20.48 mutex.cpp 281

```
00186 // The mutex is claimed already - we have to block now. Move the
00187 // current thread to the list of threads waiting on the mutex.
00188 #if KERNEL_USE_TIMEOUTS
         if (u32WaitTimeMS__!= 0u) {
    g_pclCurrent->SetExpired(false);
00189
00190
00191
              clTimer.Init();
00192
              clTimer.Start(false, u32WaitTimeMS_, (TimerCallback)TimedMutex_Callback, this);
00193
              bUseTimer = true;
00194
00195 #endif
00196
         BlockPriority(q_pclCurrent);
00197
00198
          // Check if priority inheritence is necessary. We do this in order
00199
          // to ensure that we don't end up with priority inversions in case
00200
          \ensuremath{//} multiple threads are waiting on the same resource.
          if (m_u8MaxPri <= g_pclCurrent->GetPriority()) {
00201
              m_u8MaxPri = g_pclCurrent->GetPriority();
00202
00203
00204
              auto* pclTemp = static_cast<Thread*>(m_clBlockList.GetHead());
00205
              while (pclTemp != nullptr) {
00206
                 pclTemp->InheritPriority(m_u8MaxPri);
00207
                  if (pclTemp == static_cast<Thread*>(m_clBlockList.
     GetTail())) {
00208
                      break;
00209
                  pclTemp = static_cast<Thread*>(pclTemp->GetNext());
00210
00211
00212
              m_pclOwner->InheritPriority(m_u8MaxPri);
00213
         }
00214
00215
          // Done with thread data -reenable the scheduler
00216
          Scheduler::SetScheduler(true);
00217
00218
          // Switch threads if this thread acquired the mutex
00219
         Thread::Yield();
00220
00221 #if KERNEL_USE_TIMEOUTS
00222
       if (bUseTimer) {
00223
           clTimer.Stop();
00224
              return (static_cast<int>(g_pclCurrent->GetExpired()) == 0);
00225
         }
00226
          return true:
00227 #endif
00228 }
00229
00230 //----
00231 void Mutex::Claim(void)
00232 {
00233 #if KERNEL_USE_TIMEOUTS
00234
         Claim_i(0);
00235 #else
00236
        Claim_i();
00237 #endif
00238 }
00239
00240 //-
00241 #if KERNEL_USE_TIMEOUTS
00242 bool Mutex::Claim(uint32_t u32WaitTimeMS_)
00243 {
00244
          return Claim i(u32WaitTimeMS);
00245 }
00246 #endif
00247
00248 //-
00249 void Mutex::Release()
00250 {
00251 #if KERNEL_EXTRA_CHECKS
00252
        KERNEL_ASSERT(IsInitialized());
00253 #endif
00254
00255
         KERNEL_TRACE_1("Releasing Mutex, Thread %d", static_cast<uint16_t>(g_pclCurrent->
     GetID()));
00256
00257
          auto bSchedule = false;
00258
00259
          // Disable the scheduler while we deal with internal data structures.
00260
          Scheduler::SetScheduler(false);
00261
00262
          // This thread had better be the one that owns the mutex currently...
          KERNEL_ASSERT((g_pclCurrent == m_pclOwner));
00263
00264
00265
          // If the owner had claimed the lock multiple times, decrease the lock
00266
          // count and return immediately.
00267
          if (m_bRecursive && (m_u8Recurse != 0u)) {
00268
              m u8Recurse--;
00269
              Scheduler::SetScheduler(true);
```

```
return;
00271
00272
          // Restore the thread's original priority
00273
00274
          if (g_pclCurrent->GetCurPriority() != g_pclCurrent->
     GetPriority()) {
00275
             g_pclCurrent->SetPriority(g_pclCurrent->GetPriority());
00276
00277
              // In this case, we want to reschedule
00278
              bSchedule = true;
00279
          }
00280
00281
          // No threads are waiting on this semaphore?
00282
          if (m_clBlockList.GetHead() == NULL) {
00283
              // Re-initialize the mutex to its default values
              m_bReady = true;
m_u8MaxPri = 0;
00284
00285
00286
              m_pclOwner = NULL;
00287
          } else {
00288
              // Wake the highest priority Thread pending on the mutex
00289
              if (WakeNext() != 0u) {
00290
                   // Switch threads if it's higher or equal priority than the current thread
00291
                  bSchedule = true;
00292
              }
00293
          }
00294
00295
          // Must enable the scheduler again in order to switch threads.
00296
          Scheduler::SetScheduler(true);
00297
          if (bSchedule) {
              // Switch threads if a higher-priority thread was woken
00298
00299
              Thread::Yield();
00300
00301 }
00302 } //namespace Mark3
00303 #endif // KERNEL_USE_MUTEX
```

20.49 /home/moslevin/projects/github/m3-repo/kernel/src/notify.cpp File Reference

Lightweight thread notification - blocking object.

```
#include "mark3cfg.h"
#include "notify.h"
#include "mark3.h"
#include "kerneldebug.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

20.49.1 Detailed Description

Lightweight thread notification - blocking object.

Definition in file notify.cpp.

20.50 notify.cpp

20.50 notify.cpp 283

```
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =======
00022 #include "mark3cfg.h"
00023 #include "notify.h"
00024 #include "mark3.h"
00025 #include "kerneldebug.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]------
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_NOTIFY_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037
00038 #if KERNEL_USE_NOTIFY
00039
00040 #if KERNEL_USE_TIMEOUTS
00041 namespace Mark3
00042 {
00043 namespace
00044 {
00045 //--
00046 void TimedNotify_Callback(Thread* pclOwner_, void* pvData_)
00047 {
00048
          auto* pclNotify = static_cast<Notify*>(pvData_);
00049
00050
           // Indicate that the semaphore has expired on the thread
00051
          pclOwner_->SetExpired(true);
00052
00053
          \ensuremath{//} Wake up the thread that was blocked on this semaphore.
00054
          pclNotify->WakeMe (pclOwner_);
00055
00056
          if (pclOwner_->GetCurPriority() >= Scheduler::GetCurrentThread()->
      GetCurPriority()) {
00057
             Thread::Yield();
00058
00059 }
00060 } // anonymous namespace
00061 #endif
00062 //---
00063 Notify::~Notify()
00064 {
          \ensuremath{//} If there are any threads waiting on this object when it goes out
00065
00066
          // of scope, set a kernel panic.
if (m_clBlockList.GetHead() != nullptr) {
00067
00068
               Kernel::Panic(PANIC_ACTIVE_NOTIFY_DESCOPED);
00069
00070 }
00071
00072 //----
00073 void Notify::Init(void)
00075 #if KERNEL_EXTRA_CHECKS
00076
          KERNEL_ASSERT(!m_clBlockList.GetHead());
00077
          SetInitialized();
00078 #endif
00079
          m_bPending = false;
00080 }
00081
00082 //----
00083 void Notify::Signal(void)
00084 {
00085 #if KERNEL EXTRA CHECKS
00086
         KERNEL_ASSERT(IsInitialized());
00087 #endif
88000
00089
          auto bReschedule = false;
00090
00091
          CS ENTER();
          auto* pclCurrent = static_cast<Thread*>(m_clBlockList.GetHead());
if (pclCurrent == nullptr) {
00092
00093
              m_bPending = true;
00094
00095
00096
              while (pclCurrent != NULL) {
00097
                  UnBlock (pclCurrent);
                   if (!bReschedule && (pclCurrent->GetCurPriority() >=
00098
      Scheduler::GetCurrentThread()->GetCurPriority())) {
                      bReschedule = true;
00099
00100
00101
                   pclCurrent = (Thread*)m_clBlockList.GetHead();
00102
00103
              m bPending = false;
```

```
00104
00105
          CS_EXIT();
00106
          if (bReschedule) {
00107
00108
              Thread::Yield();
00109
00110 }
00111
00112 //---
00113 void Notify::Wait(bool* pbFlag_)
00114 {
00115 #if KERNEL_EXTRA_CHECKS
          KERNEL_ASSERT(IsInitialized());
00116
00117 #endif
00118
00119
          auto bEarlyExit = false;
00120
          CS_ENTER();
          if (!m_bPending) {
00121
              Block(g_pclCurrent);
              if (pbFlag_ != nullptr) {
   *pbFlag_ = false;
00123
00124
00125
          } else {
00126
              m_bPending = false;
bEarlyExit = true;
00127
00128
00129
00130
          CS_EXIT();
00131
          if (bEarlyExit) {
00132
00133
              return;
00134
          }
00135
00136
          Thread::Yield();
          if (pbFlag_ != nullptr) {
   *pbFlag_ = true;
00137
00138
00139
00140 }
00142 //--
00143 #if KERNEL_USE_TIMEOUTS
00144 bool Notify::Wait(uint32_t u32WaitTimeMS_, bool* pbFlag_)
00145 {
00146 #if KERNEL_EXTRA_CHECKS
          KERNEL_ASSERT(IsInitialized());
00147
00148 #endif
        auto bUseTimer = false;
00149
00150
          auto bEarlyExit = false;
00151
          Timer clNotifyTimer;
00152
00153
          CS_ENTER();
          if (!m_bPending) {
00154
00155
              if (u32WaitTimeMS_ != 0u) {
00156
                   bUseTimer = true;
00157
                   g_pclCurrent->SetExpired(false);
00158
00159
                   clNotifyTimer.Init();
                   clNotifyTimer.Start(false, u32WaitTimeMS_, TimedNotify_Callback, this);
00161
00162
00163
              Block(g_pclCurrent);
00164
               if (pbFlag_ != nullptr) {
00165
                   *pbFlag_ = false;
00166
00167
00168
          } else {
              m_bPending = false;
bEarlyExit = true;
00169
00170
00171
00172
          CS_EXIT();
00173
00174
          if (bEarlyExit) {
00175
              return true;
00176
          }
00177
00178
          Thread::Yield();
00179
00180
          if (bUseTimer) {
00181
              clNotifyTimer.Stop();
00182
               return (static_cast<int>(g_pclCurrent->GetExpired()) == 0);
00183
          }
00184
          if (pbFlag_ != nullptr) {
   *pbFlag_ = true;
00185
00186
          }
00187
00188
          return true;
00189
00190 }
```

20.51 /home/moslevin/projects/github/m3-repo/kernel/src/priomap.cpp File Reference

Priority map data structure.

```
#include "mark3.h"
#include "priomap.h"
#include "threadport.h"
#include <stdint.h>
#include <stdbool.h>
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.51.1 Detailed Description

Priority map data structure.

Definition in file priomap.cpp.

20.52 priomap.cpp

```
00001 /
00002
00003
00004 |
00005 1
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00019 #include "mark3.h"
00020 #include "priomap.h"
00021 #include "threadport.h"
00022
00023 #include <stdint.h>
00024 #include <stdbool.h>
00025 namespace Mark3
00026 { 00027 //-----
00028 namespace {
00029 inline uint8_t priority_from_bitmap(PORT_PRIO_TYPE uXPrio_)
00030 {
```

```
00031 #if HW_CLZ
       // Support hardware-accelerated Count-leading-zeros instruction
00032
00033
          uint8_t rc = PRIO_MAP_BITS - CLZ(uXPrio_);
00034
          return rc;
00035 #else
       // Default un-optimized count-leading zeros operation
PORT_PRIO_TYPE uXMask = (1 << (PRIO_MAP_BITS - 1));</pre>
00036
00038
         uint8_t
                    u8Zeros = 0;
00039
         while (uXMask) {
   if (uXMask & uXPrio_) {
00040
00041
                 return (PRIO_MAP_BITS - u8Zeros);
00042
00043
00044
00045
              uXMask >>= 1;
00046
             u8Zeros++;
         }
00047
00048
          return 0;
00049 #endif
00050 }
00051 } // anonymous namespace
00052
00053 //----
00054 PriorityMap::PriorityMap()
00055 {
00056 #if PRIO_MAP_MULTI_LEVEL
       m_uXPriorityMapL2 = 0;
00057
00058
         for (int i = 0; i < PRIO_MAP_NUM_WORDS; i++) {</pre>
00059
             m_auXPriorityMap[i] = 0;
00060
00061 #else
00062
         m_uXPriorityMap = 0;
00063 #endif
00064 }
00065
00066 //---
00067 void PriorityMap::Set(PORT_PRIO_TYPE uXPrio_)
00068 {
00069
          PORT_PRIO_TYPE uXPrioBit = PRIO_BIT(uXPrio_);
00070 #if PRIO_MAP_MULTI_LEVEL
         PORT_PRIO_TYPE uXWordIdx = PRIO_MAP_WORD_INDEX(uXPrio_);
00071
00072
         m_auXPriorityMap[uXWordIdx] |= (1 << uXPrioBit);</pre>
00073
00074
         m_uXPriorityMapL2 |= (1 << uXWordIdx);</pre>
00075 #else
00076
         m_uXPriorityMap |= (1 << uXPrioBit);</pre>
00077 #endif
00078 }
00079
00080 //-
00081 void PriorityMap::Clear(PORT_PRIO_TYPE uXPrio_)
00082 {
00083
          PORT_PRIO_TYPE uXPrioBit = PRIO_BIT(uXPrio_);
00084 #if PRIO_MAP_MULTI_LEVEL
         PORT_PRIO_TYPE uXWordIdx = PRIO_MAP_WORD_INDEX(uXPrio_);
00085
00086
          m_auXPriorityMap[uXWordIdx] &= ~(1 << uXPrioBit);</pre>
00088
         if (!m_auXPriorityMap[uXWordIdx]) {
00089
             m_uXPriorityMapL2 &= ~(1 << uXWordIdx);</pre>
00090
00091 #else
00092
        m_uXPriorityMap &= ~(1 << uXPrioBit);</pre>
00093 #endif
00094 }
00095
00096 //-----
00097 PORT_PRIO_TYPE PriorityMap::HighestPriority(void)
00098 {
00099 #if PRIO_MAP_MULTI_LEVEL
         PORT_PRIO_TYPE uXMapIdx = priority_from_bitmap(m_uXPriorityMapL2);
00101
          if (!uXMapIdx) {
00102
              return 0;
00103
          uXMapIdx--;
00104
          PORT_PRIO_TYPE uXPrio = priority_from_bitmap(m_auXPriorityMap[uXMapIdx]);
00105
          uXPrio += (uXMapIdx * PRIO_MAP_BITS);
00106
00107 #else
00108
         PORT_PRIO_TYPE uXPrio = priority_from_bitmap(m_uXPriorityMap);
00109 #endif
          return uXPrio:
00110
00111 }
00112 } //namespace Mark3
```

20.53 /home/moslevin/projects/github/m3-repo/kernel/src/profile.cpp File Reference

Code profiling utilities.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "profile.h"
#include "kernelprofile.h"
#include "threadport.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.53.1 Detailed Description

Code profiling utilities.

Definition in file profile.cpp.

20.54 profile.cpp

```
00001 /*=
00004
00005 1
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ========
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023 #include "profile.h"
00024 #include "kernelprofile.h"
00025 #include "threadport.h"
00026
00027 #define CAN HAS DEBUG
00028 //--[Autogenerated - Do Not Modify]-----
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_PROFILE_CPP
00035 #endif
00036 //--[End Autogenerated content]-----
00037
00038 #include "kerneldebug.h"
00039
00040 #if KERNEL_USE_PROFILER
00041 namespace Mark3
00042 {
00043 //----
00044 void ProfileTimer::Init()
00045 {
         m_u32Cumulative
00046
00047
         m_u32CurrentIteration = 0;
00048
         m_u16Iterations = 0;
         m_bActive
00049
                                = false;
00050 }
00051
00052 //---
00053 void ProfileTimer::Start()
00054 {
```

```
if (!m_bActive) {
00056
             CS_ENTER();
00057
             m_u32CurrentIteration = 0;
             00058
00059
00060
              CS_EXIT();
             m_bActive = true;
00062
         }
00063 }
00064
00065 //-----
00066 void ProfileTimer::Stop()
00067 {
00068
          if (m_bActive) {
00069
             uint16_t u16Final;
00070
              uint32_t u32Epoch;
00071
             CS_ENTER();
             u16Final = Profiler::Read();
u32Epoch = Profiler::GetEpoch();
00072
00074
              // Compute total for current iteration...
00075
              m_u32CurrentIteration = ComputeCurrentTicks(u16Final,
00077
              m u16Iterations++;
00078
              CS_EXIT();
00079
             m_bActive = false;
08000
         }
00081 }
00082
00083 //-----
00084 uint32_t ProfileTimer::GetAverage()
00085 {
00086
         . ______ {
    return m_u32Cumulative / (uint32_t)m_u16Iterations;
}
          if (m_u16Iterations != 0u) {
00087
00088
          return 0:
00089
00090 }
00092 //--
00093 uint32_t ProfileTimer::GetCurrent()
00094 {
00095
         if (m bActive) {
             uint16_t u16Current;
uint32_t u32Epoch;
00096
00097
             CS_ENTER();
u16Current = Profiler::Read();
00098
00099
00100
             u32Epoch = Profiler::GetEpoch();
00101
             CS EXIT();
00102
             return ComputeCurrentTicks(u16Current, u32Epoch);
00103
00104
          return m_u32CurrentIteration;
00105 }
00106
00107 //---
00108 uint32_t ProfileTimer::ComputeCurrentTicks(uint16_t u16Current_, uint32_t
     u32Epoch )
00109 {
00110
          uint32_t u32Total;
00111
          uint32_t u320verflows;
00112
          u32Overflows = u32Epoch_ - m_u32InitialEpoch;
00113
00114
00115
          // More than one overflow...
00116
          if (u320verflows > 1)
00117
              u32Total = ((uint32_t)(u32Overflows - 1) * TICKS_PER_OVERFLOW) + (uint32_t)(TICKS_PER_OVERFLOW -
     m_u16Initial)
00118
                        + (uint32 t)u16Current;
00119
00120
          // Only one overflow, or one overflow that has yet to be processed
         else if ((u32Overflows != 0u) || (u16Current_ < m_u16Initial)) {
    u32Total = (uint32_t)(TICKS_PER_OVERFLOW - m_u16Initial) + (uint32_t)u16Current_;
00121
00122
00123
          \ensuremath{//} No overflows, none pending.
00124
00125
          else {
00126
             u32Total = (uint32_t) (u16Current_ - m_u16Initial);
00127
00128
00129
         return u32Total;
00130 }
00131 } //namespace Mark3
00132 #endif
```

20.55 /home/moslevin/projects/github/m3-repo/kernel/src/public/atomic.h File Reference

Basic Atomic Operations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "threadport.h"
```

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

· Mark3::Atomic

The Atomic class.

Functions

```
    uint8_t Mark3::Atomic::Set (uint8_t *pu8Source_, uint8_t u8Val_)
    Set Set a variable to a given value in an uninterruptable operation.
```

• uint8_t Mark3::Atomic::Add (uint8_t *pu8Source_, uint8_t u8Val_)

Add Add a value to a variable in an uninterruptable operation.

• uint8_t Mark3::Atomic::Sub (uint8_t *pu8Source_, uint8_t u8Val_)

Sub Subtract a value from a variable in an uninterruptable operation.

bool Mark3::Atomic::TestAndSet (bool *pbLock)

TestAndSet Test to see if a variable is set, and set it if is not already set.

20.55.1 Detailed Description

Basic Atomic Operations.

Definition in file atomic.h.

20.56 atomic.h

```
00001 /
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =======
00021 #pragma once
00022
00023 #include "kerneltypes.h"
00024 #include "mark3cfg.h"
00025 #include "threadport.h"
00026
00027 #if KERNEL_USE_ATOMIC
00028 namespace Mark3
```

```
00029 {
00039 namespace Atomic
00040 {
                uint8_t Set(uint8_t* pu8Source_, uint8_t u8Val_);
uint16_t Set(uint16_t* pu16Source_, uint16_t u16Val_);
uint32_t Set(uint32_t* pu32Source_, uint32_t u32Val_);
00047
00048
00049
00050
00057
                uint8_t Add(uint8_t* pu8Source_, uint8_t u8Val_);
                uint16_t Add(uint16_t* pu16Source_, uint16_t u16Val_);
uint32_t Add(uint32_t* pu32Source_, uint32_t u32Val_);
00058
00059
00060
                uint8_t Sub(uint8_t* pu8Source_, uint8_t u8Va1_);
uint16_t Sub(uint16_t* pu16Source_, uint16_t u16Va1_);
uint32_t Sub(uint32_t* pu32Source_, uint32_t u32Va1_);
00067
00068
00069
00070
00085
                bool TestAndSet(bool* pbLock);
00086 } // namespace Atomic
00087 } //namespace Mark3
00088 #endif // KERNEL_USE_ATOMIC
```

20.57 /home/moslevin/projects/github/m3-repo/kernel/src/public/autoalloc.h File Reference

Automatic memory allocation for kernel objects.

```
#include <stdint.h>
#include <stdbool.h>
#include "mark3cfq.h"
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.57.1 Detailed Description

Automatic memory allocation for kernel objects.

Definition in file autoalloc.h.

20.58 autoalloc.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00020 #pragma once
00021
00022 #include <stdint.h>
00023 #include <stdbool.h>
00024 #include "mark3cfg.h"
```

20.58 autoalloc.h

```
00026 #if KERNEL_USE_AUTO_ALLOC
00027 namespace Mark3
00028 {
00029
00030 //-
00031 // Define function pointer types used for interfacing with an external heap.
00032
00033 //----
00034 enum class AutoAllocType : uint8_t {
00035 //-- Kernel object types
        EventFlag,
00036
00037
         MailBox,
00038
         Message,
00039
         MessagePool,
00040
         MessageQueue,
00041
         Mutex.
00042
         Notify,
          Semaphore,
00043
00044
          Thread,
          Timer,
00045
          ConditionVariable,
00046
00047
         ReaderWriterLock,
00048 //-- Allow for users to define their own object types beginning with AutoAllocType_t::User
00049
         User,
00050 //--
00051
         Raw = 0xFF
00052 };
00053
00054 //-----
00055 using AutoAllocAllocator_t = void* (*)(AutoAllocType eType_, size_t sSize_);
00056 using AutoAllocFree_t = void* (*)(AutoAllocType eType_, void* pvObj_);
00057
00058 //--
00059 // Forward declaration of kernel objects that can be auotomatically allocated.
00060 #if KERNEL USE EVENTFLAG
00061 class EventFlag;
00062 #endif
00063
00064 #if KERNEL_USE_MAILBOX
00065 class Mailbox;
00066 #endif
00067
00068 #if KERNEL_USE_MESSAGE
00069 class Message;
00070 class MessagePool;
00071 class MessageQueue;
00072 #endif
00073
00074 #if KERNEL_USE_MUTEX
00075 class Mutex;
00076 #endif
00077
00078 #if KERNEL_USE_NOTIFY
00079 class Notify;
00080 #endif
00081
00082 #if KERNEL_USE_SEMAPHORE
00083 class Semaphore;
00084 #endif
00085
00086 class Thread;
00087
00088 #if KERNEL_USE_TIMERS
00089 class Timer;
00090 #endif
00091
00092 #if KERNEL_USE_READERWRITER
00093 class ReaderWriterLock;
00094 #endif
00095
00096 #if KERNEL USE CONDVAR
00097 class ConditionVariable; 00098 #endif
00099
00100 class AutoAlloc
00101 {
00102 public:
00103
00110
         static void Init (void):
00111
00118
         static void SetAllocatorFunctions(AutoAllocAllocator_t pfAllocator_, AutoAllocFree_t pfFree_)
00119
              {m_pfAllocator = pfAllocator_; m_pfFree = pfFree_; }
00120
00121 #if KERNEL_USE_SEMAPHORE
00122
00127
          static Semaphore* NewSemaphore();
```

```
00128
00134
          static void DestroySemaphore(Semaphore* pclSemaphore_);
00135 #endif
00136 #if KERNEL USE MUTEX
00137
00142
         static Mutex* NewMutex();
00143
00149
         static void DestroyMutex(Mutex* pclMutex_);
00150 #endif
00151 #if KERNEL_USE_EVENTFLAG
00152
00157
          static EventFlag* NewEventFlag();
00158
00164
          static void DestroyEventFlag(EventFlag* pclEventFlag_);
00165 #endif
00166 #if KERNEL_USE_TIMERS
00167
00172
          static Timer* NewTimer();
00179
         static void DestroyTimer(Timer* pclTimer_);
00180 #endif
00181 #if KERNEL_USE_NOTIFY
00182
00187
          static Notify* NewNotify();
00188
00194
         static void DestroyNotify(Notify* pclNotify_);
00195 #endif
00196 #if KERNEL_USE_MAILBOX
00197
00202
          static Mailbox* NewMailbox();
00203
00209
         static void DestroyMailbox(Mailbox* pclMailbox_);
00210 #endif
00211 #if KERNEL_USE_MESSAGE
00212
00217
          static Message* NewMessage();
00218
         static MessagePool* NewMessagePool();
00225
00231
          static MessageQueue* NewMessageQueue();
00232
00238
          static void DestroyMessage (Message* pclMessage_);
00239
00245
          static void DestroyMessagePool(MessagePool *pclMessagePool_);
00246
00252
          static void DestroyMessageQueue (MessageQueue* pclMessageQ_);
00253 #endif
00254 #if KERNEL_USE_CONDVAR
00255
00260
          static ConditionVariable * NewConditionVariable();
00261
00267
          static void DestroyConditionVariable(ConditionVariable* pclConditionVariable_);
00268 #endif
00269 #if KERNEL USE READERWRITER
00270
00275
          static ReaderWriterLock * NewReaderWriterLock();
00276
00282
          static void DestroyReaderWriterLock (ReaderWriterLock* pclReaderWriterLock_);
00283 #endif
00284
00289
          static Thread* NewThread():
00290
00296
          static void DestroyThread(Thread* pclThread_);
00297
00304
          static void* NewUserTypeAllocation(uint8_t eUserType_);
00305
00312
          static void DestroyUserTypeAllocation(uint8_t eUserType_, void* pvObj_);
00313
00320
          static void* NewRawData(size t sSize );
00321
00327
          static void DestroyRawData(void* pvData_);
00328
00329 private:
00330
          static void* Allocate(AutoAllocType eType_, size_t sSize_);
00331
00332
         static void Free(AutoAllocType eType_, void* pvObj_);
00333
00334
          static AutoAllocatlocator_t m_pfAllocator;
00335
          static AutoAllocFree_t
                                      m_pfFree;
00336 };
00337 } //namespace Mark3
00338 #endif
```

20.59 /home/moslevin/projects/github/m3-repo/kernel/src/public/blocking.h File Reference

Blocking object base class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "threadlist.h"
```

Classes

class Mark3::BlockingObject

Class implementing thread-blocking primatives.

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.59.1 Detailed Description

Blocking object base class declarations.

A Blocking object in Mark3 is essentially a thread list. Any blocking object implementation (being a semaphore, mutex, event flag, etc.) can be built on top of this class, utilizing the provided functions to manipu32ate thread location within the Kernel.

Blocking a thread results in that thread becoming de-scheduled, placed in the blocking object's own private list of threads which are waiting on the object.

Unblocking a thread results in the reverse: The thread is moved back to its original location from the blocking list.

The only difference between a blocking object based on this class is the logic used to determine what consitutes a Block or Unblock condition.

For instance, a semaphore Pend operation may result in a call to the Block() method with the currently-executing thread in order to make that thread wait for a semaphore Post. That operation would then invoke the UnBlock() method, removing the blocking thread from the semaphore's list, and back into the the appropriate thread inside the scheduler.

Care must be taken when implementing blocking objects to ensure that critical sections are used judiciously, otherwise asynchronous events like timers and interrupts could result in non-deterministic and often catastrophic behavior.

Definition in file blocking.h.

20.60 blocking.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00046 #pragma once
00047
00048 #include "kerneltypes.h"
00049 #include "mark3cfg.h"
00050
00051 #include "11.h"
00052 #include "threadlist.h"
00053
00054 namespace Mark3
00055 {
00056 //-
00057 // Cookies used to determine whether or not an object has been initialized
00058 #define BLOCKING_INVALID_COOKIE
                                               (0x3C)
00059 #define BLOCKING_INIT_COOKIE
                                               (0xC3)
00060
00061 class Thread;
00062
00063 //---
00069 class BlockingObject
00070 {
00071 public:
00072 #if KERNEL_EXTRA_CHECKS
       BlockingObject() { m_u8Initialized = BLOCKING_INVALID_COOKIE; }
00073
00074
          ~BlockingObject() { m_u8Initialized = BLOCKING_INVALID_COOKIE; }
00075 #endif
00076
00077 protected:
00098
         void Block(Thread* pclThread_);
00099
00108
          void BlockPriority(Thread* pclThread_);
00109
00121
          void UnBlock(Thread* pclThread_);
00122
00127
          ThreadList m_clBlockList;
00128
00129 #if KERNEL_EXTRA_CHECKS
00130
00134
          uint8_t m_u8Initialized;
00135
00139
          void SetInitialized(void) { m u8Initialized = BLOCKING INIT COOKIE; }
00140
00145
          bool IsInitialized(void) { return (m_u8Initialized == BLOCKING_INIT_COOKIE); }
00146
00147 #endif
00148 };
00149 } //namespace Mark3
```

20.61 /home/moslevin/projects/github/m3-repo/kernel/src/public/buffalogger.h File Reference

Super-efficient, super-secure logging routines.

```
#include <stdint.h>
```

20.61.1 Detailed Description

Super-efficient, super-secure logging routines.

Uses offline processing to ensure performance.

Definition in file buffalogger.h.

20.62 buffalogger.h

20.62 buffalogger.h

```
00001 /*=====
00002
00003
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =========
00020 #pragma once
00021 #include <stdint.h>
00023 //----
00024 #define STR1(s) #s
00025 #define STR(s) STR1(s)
00026
00027 //--
00028 #define EMIT_DBG_STRING(str)
00029
             const static volatile char
00030
                                            log_str[] __attribute__((section(".logger")))
        _attribute__((unused)) = str;
              const static volatile uint16_t line_id __attribute__((section(".logger"))) __attribute__((unused))
00031
00032
              const static volatile uint16_t file_id __attribute__((section(".logger"))) __attribute__((unused))
        = DBG_FILE;
00033
              const static volatile uint16_t sync __attribute__((section(".logger"))) __attribute__((unused))
        = 0xCAFE;
00034
         } while (0);
```

20.63 /home/moslevin/projects/github/m3-repo/kernel/src/public/condvar.h File Reference

Condition Variable implementation.

```
#include "mark3cfg.h"
#include "ksemaphore.h"
#include "mutex.h"
```

Classes

· class Mark3::ConditionVariable

The ConditionVariable class This class implements a condition variable.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.63.1 Detailed Description

Condition Variable implementation.

Definition in file condvar.h.

20.64 condvar.h

```
00001 #pragma once
00002
00003 /
00004
00005
00006
00007
00008
00009
00010
00011 -- [Mark3 Realtime Platform]
00012
00013 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00014 See license.txt for more information
00015 ==========
00022 #include "mark3cfg.h"
00023 #include "ksemaphore.h"
00024 #include "mutex.h"
00025
00026 namespace Mark3 {
00027
00038 class ConditionVariable {
00039 public:
00040
          void* operator new(size_t sz, void*pv) { return (ConditionVariable*)pv; }
00041
00047
          void Init();
00048
00055
          void Wait (Mutex* pclMutex_);
00056
00057 #if KERNEL_USE_TIMEOUTS
00058
00066
          bool Wait(Mutex* pclMutex_, uint32_t u32WaitTimeMS_);
00067 #endif
00068
00073
          void Signal();
00074
00079
          void Broadcast();
08000
00081 private:
00082
          Mutex m clMutex:
          Semaphore m_clSemaphore;
00084
          uint8_t m_u8Waiters;
00085 };
00086
00087
00088 } // namespace Mark3
```

20.65 /home/moslevin/projects/github/m3-repo/kernel/src/public/eventflag.h File Reference

Event Flag Blocking Object/IPC-Object definition.

```
#include "mark3cfg.h"
#include "kernel.h"
#include "kerneltypes.h"
#include "blocking.h"
#include "thread.h"
```

Classes

· class Mark3::EventFlag

The EventFlag class is a blocking object, similar to a semaphore or mutex, commonly used for synchronizing thread execution based on events occurring within the system.

20.66 eventflag.h

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.65.1 Detailed Description

Event Flag Blocking Object/IPC-Object definition.

Definition in file eventflag.h.

20.66 eventflag.h

```
00001
00002
00003
00004
                  1.11
00005
                  1.11
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00018 #pragma once
00019
00020 #include "mark3cfg.h"
00021 #include "kernel.h"
00022 #include "kerneltypes.h"
00023 #include "blocking.h"
00024 #include "thread.h"
00025
00026 #if KERNEL_USE_EVENTFLAG
00027 namespace Mark3
00028 {
00029 //---
00045 class EventFlag : public BlockingObject
00046 {
00047 public:
00048
          void* operator new(size_t sz, void* pv) { return (EventFlag*)pv; };
00049
          ~EventFlag();
00050
00054
          void Init();
00055
00063
          uint16_t Wait(uint16_t u16Mask_, EventFlagOperation eMode_);
00064
00065 #if KERNEL USE TIMEOUTS
00066
00074
          uint16_t Wait(uint16_t u16Mask_, EventFlagOperation eMode_, uint32_t u32TimeMS_);
00075
00083
          void WakeMe(Thread* pclChosenOne_);
00084
00085 #endif
00086
00092
          void Set(uint16_t u16Mask_);
00093
00098
          void Clear(uint16_t u16Mask_);
00099
00104
          uint16_t GetMask();
00105
00106 private:
00107 #if KERNEL_USE_TIMEOUTS
00108
00120
          uint16_t Wait_i(uint16_t u16Mask_, EventFlagOperation eMode_, uint32_t
      u32TimeMS_);
00121 #else
00122
00132
          uint16_t Wait_i(uint16_t u16Mask_, EventFlagOperation eMode_);
00133 #endif
00134
          uint16_t m_u16SetMask;
00136 };
00137 } //namespace Mark3
00138 #endif // KERNEL_USE_EVENTFLAG
```

20.67 /home/moslevin/projects/github/m3-repo/kernel/src/public/kernel.h File Reference

Kernel initialization and startup class.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "paniccodes.h"
#include "thread.h"
```

Classes

· class Mark3::Kernel

Class that encapsulates all of the kernel startup functions.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.67.1 Detailed Description

Kernel initialization and startup class.

The Kernel namespace provides functions related to initializing and starting up the kernel.

The Kernel::Init() function must be called before any of the other functions in the kernel can be used.

Once the initial kernel configuration has been completed (i.e. first threads have been added to the scheduler), the Kernel::Start() function can then be called, which will transition code execution from the "main()" context to the threads in the scheduler.

Definition in file kernel.h.

20.68 kernel.h

```
00001 /
00003
00004
00005
00006
00007
80000
00009
        -[Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00032 #pragma once
00033
00034 #include "mark3cfg.h"
00035 #include "kerneltypes.h"
00036 #include "paniccodes.h"
00037 #include "thread.h"
00038
00039 namespace Mark3
```

```
00040 {
00041 //--
00045 class Kernel
00046 {
00047 public:
00048
          static void Init(void);
00058
00071
          static void Start (void);
00072
00079
          static bool IsStarted() { return m bIsStarted; }
          static void SetPanic(PanicFunc pfPanic_) { m_pfPanic = pfPanic_; }
static bool IsPanic() { return m_bIsPanic; }
00087
00097
          static void Panic (uint16_t u16Cause_);
00098
00099 #if KERNEL_USE_IDLE_FUNC
00100
          static void SetIdleFunc(IdleFunc pfIdle_) { m_pfIdle = pfIdle_; }
00105
00110
          static void Idle(void)
         {
               if (m_pfIdle != 0) {
00112
00113
                   m_pfIdle();
00114
          }
00115
00116
00124
          static Thread* GetIdleThread(void) { return (Thread*)&
      m_clIdle; }
00125 #endif
00126
00127 #if KERNEL USE THREAD CALLOUTS
00128
          static void SetThreadCreateCallout(ThreadCreateCallout pfCreate_) {
00138
      m_pfThreadCreateCallout = pfCreate_; }
00150
          static void SetThreadExitCallout (ThreadExitCallout pfExit_) {
m_pfThreadExitCallout = pfExit_; }
00161     static void SetThere 12
          static void SetThreadContextSwitchCallout (ThreadContextCallout pfContext_)
00162
00163
              m_pfThreadContextCallout = pfContext_;
00165
00174
          static ThreadCreateCallout GetThreadCreateCallout(void) { return
      m_pfThreadCreateCallout; }
          static ThreadExitCallout GetThreadExitCallout(void) { return
     m_pfThreadExitCallout; }
          static ThreadContextCallout GetThreadContextSwitchCallout(void) { return
     m_pfThreadContextCallout; }
00193 #endif
00194
00195 #if KERNEL USE STACK GUARD
00196 static void SetStackGuardThreshold(uint16_t u16Threshold_) { m_u16GuardThreshold = u16Threshold_; }
00197
          static uint16_t
                                                          GetStackGuardThreshold(void) { return m_u16GuardThreshold;
00198 #endif
00199
00200 private:
                            m_bIsStarted;
00201 static bool
                              m_bIsPanic;
          static bool
00203
          static PanicFunc m_pfPanic;
00204 #if KERNEL_USE_IDLE_FUNC
00205 static IdleFunc m_pfIdle;
00206 static FakeThread_t m_clIdle;
00207 #endif
00208
00209 #if KERNEL_USE_THREAD_CALLOUTS
00210 static ThreadCreateCallout m_pfThreadCreateCallout;
00211 static ThreadExitCallout m_pfThreadExitCallout;
00212
          static ThreadContextCallout m_pfThreadContextCallout;
00213 #endif
00214
00215 #if KERNEL_USE_STACK_GUARD
00216
          static uint16_t m_u16GuardThreshold;
00217 #endif
00218 };
00219
00220 } //namespace Mark3
```

20.69 /home/moslevin/projects/github/m3-repo/kernel/src/public/kernelaware.h File Reference

Kernel aware simulation support.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

• Mark3::KernelAware

The KernelAware class.

Functions

void Mark3::KernelAware::ProfileInit (const char *szStr_)

ProfileInit.

• void Mark3::KernelAware::ProfileStart (void)

ProfileStart.

void Mark3::KernelAware::ProfileStop (void)

ProfileStop.

void Mark3::KernelAware::ProfileReport (void)

ProfileReport.

void Mark3::KernelAware::ExitSimulator (void)

ExitSimulator.

void Mark3::KernelAware::Print (const char *szStr_)

Print.

void Mark3::KernelAware::Trace (uint16_t u16File_, uint16_t u16Line_)

Trace.

• void Mark3::KernelAware::Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_)

Trace.

void Mark3::KernelAware::Trace (uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16← Arg2_)

Trace.

bool Mark3::KernelAware::IsSimulatorAware (void)

IsSimulatorAware.

20.69.1 Detailed Description

Kernel aware simulation support.

Definition in file kernelaware.h.

20.70 kernelaware.h

20.70 kernelaware.h

```
00001 /
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00020 #pragma once
00021
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #if KERNEL AWARE SIMULATION
00026 namespace Mark3
00027 {
00028 //----
00046 namespace KernelAware
00047 {
00048
00059
          void ProfileInit(const char* szStr_);
00060
00061
00069
          void ProfileStart(void);
00070
00071
00078
          void ProfileStop(void);
00079
08000
88000
          void ProfileReport(void);
00089
00090
00098
          void ExitSimulator(void);
00099
00100
00108
          void Print(const char* szStr_);
00109
00110
          void Trace(uint16_t u16File_, uint16_t u16Line_);
00120
00121
00122
00133
          void Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_);
00134
00135
00147
          void Trace(uint16_t u16File_, uint16_t u16Line_, uint16_t u16Arg1_, uint16_t u16Arg2_);
00148
00159
          bool IsSimulatorAware(void);
00160 } // namespace KernelAware
00161 } //namespace Mark3
00162 #endif
```

20.71 /home/moslevin/projects/github/m3-repo/kernel/src/public/kerneldebug.h File Reference

Macros and functions used for assertions, kernel traces, etc.

```
#include "mark3cfg.h"
#include "tracebuffer.h"
#include "kernelaware.h"
#include "paniccodes.h"
#include "kernel.h"
#include "buffalogger.h"
#include "dbg_file_list.h"
```

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

Macros

```
• #define KERNEL_TRACE(x)
```

Null Kernel Trace Macro.

#define KERNEL_TRACE_1(x, arg1)

Null Kernel Trace Macro.

• #define KERNEL_TRACE_2(x, arg1, arg2)

Null Kernel Trace Macro.

#define KERNEL_ASSERT(x)

Null Kernel Assert Macro.

#define USER TRACE(x)

Null Kernel Trace Macro.

#define USER_TRACE_1(x, arg1)

Null Kernel Trace Macro.

#define USER_TRACE_2(x, arg1, arg2)

Null Kernel Trace Macro.

• #define USER_ASSERT(x)

Null Kernel Assert Macro.

20.71.1 Detailed Description

Macros and functions used for assertions, kernel traces, etc.

Definition in file kerneldebug.h.

20.72 kerneldebug.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved. 00012 See license.txt for more information
00013 =
00019 #pragma once
00020
00021 #include "mark3cfg.h"
00022 #include "tracebuffer.h"
00023 #include "kernelaware.h"
00024 #include "paniccodes.h"
00025 #include "kernel.h"
00026 #include "buffalogger.h"
00027 #include "dbg_file_list.h"
00028
00029 //----
00030 namespace Mark3
00031 {
00032 #if (KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_LOGGING)
```

20.72 kerneldebug.h

```
00033 //-
00034 #define KERNEL_TRACE(x)
00035
00036
00037
              EMIT_DBG_STRING(x);
00038
              uint16_t au16Msg__[4];
00039
              au16Msg_{[0]} = 0xACDC;
00040
              au16Msg__[1] = DBG_FILE;
00041
              au16Msg__[2] = __LINE__;
              au16Msg__[3] = TraceBuffer::Increment();
00042
00043
              TraceBuffer::Write(au16Msg___, 4);
00044
00045 };
00046
00047 /
00048 #define KERNEL_TRACE_1(x, argl)
00049
00050 {
00051
              EMIT_DBG_STRING(x);
00052
              uint16_t au16Msg__[5];
00053
              au16Msg_{[0]} = 0xACDC;
00054
              au16Msg__[1] = DBG_FILE;
00055
              au16Msg__[2] = __LINE__;
00056
              au16Msg__[3] = TraceBuffer::Increment();
              au16Msg__[4] = arg1;
00057
00058
              TraceBuffer::Write(au16Msg___, 5);
00059
00060 }
00061
00062 //--
00063 #define KERNEL_TRACE_2(x, arg1, arg2)
00064
00065
00066
              EMIT_DBG_STRING(x);
00067
              uint16_t au16Msg__[6];
00068
              au16Msg_{[0]} = 0xACDC;
00069
              au16Msg__[1] = DBG_FILE;
00070
              au16Msg__[2] = __LINE__;
00071
              au16Msg__[3] = TraceBuffer::Increment();
              au16Msg__[4] = arg1;
00072
00073
              au16Msq_{[5]} = arg2;
00074
              TraceBuffer::Write(au16Msg___, 6);
00075
00076
00077
00079 #define KERNEL_ASSERT(x)
00080
00081 {
00082
              if ((x) == false) {
00083
                   EMIT_DBG_STRING("ASSERT FAILED");
00084
                   uint16_t au16Msg__[4];
```

```
00085
                  au16Msg_{[0]} = 0xACDC;
00086
                   au16Msg__[1] = DBG_FILE;
00087
                   au16Msg_{[2]} = _{LINE}
00088
                   au16Msg__[3] = TraceBuffer::Increment();
00089
                   TraceBuffer::Write(au16Msg___, 4);
00090
                  Kernel::Panic(PANIC_ASSERT_FAILED);
00091
00092
00093
00094 #elif (KERNEL USE_DEBUG && KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_LOGGING)
00095
00096 /
00097 #define KERNEL_TRACE(x)
00098
00099 {
00100
              EMIT_DBG_STRING(x);
00101
              KernelAware::Trace(DBG_FILE, __LINE__);
00102
00103 };
00104
00105 /
00106 #define KERNEL_TRACE_1(x, arg1)
00107
00108 {
00109
              EMIT_DBG_STRING(x);
00110
              KernelAware::Trace(DBG_FILE, __LINE__, arg1);
00111
00112
00113
00115 #define KERNEL_TRACE_2(x, arg1, arg2)
00116
00117 {
00118
              EMIT_DBG_STRING(x);
00119
              KernelAware::Trace(DBG_FILE, __LINE__, arg1, arg2);
00120
00121 }
00123 //--
00124 #define KERNEL_ASSERT(x)
00125
00126 {
00127
              if ((x) == false) {
00128
                  EMIT_DBG_STRING("ASSERT FAILED");
00129
                  KernelAware::Trace(DBG_FILE, __LINE__);
00130
                  Kernel::Panic(PANIC_ASSERT_FAILED);
00131
00132
00133
00134 #elif KERNEL_USE_DEBUG
00135 // If running KERNEL_USE_DEBUG without any logging, ensure that we provide
00136 // at least a basic KERNEL_ASSERT().
00137 //--
00138 #define KERNEL TRACE(x)
00139 //
00140 #define KERNEL_TRACE_1(x, arg1)
00141 /
00142 #define KERNEL_TRACE_2(x, arg1, arg2)
00143 //-
00144 #define KERNEL_ASSERT(x) \
00145 {
```

20.72 kerneldebug.h

```
00146
          if(x) == false) {
               Kernel::Panic(PANIC_ASSERT_FAILED);
00147
00148
00149 }
00150 #else
00151 //--
00152 // Note -- when kernel-debugging is disabled, we still have to define the
00153 \ // \ \text{macros} to ensure that the expressions compile (albeit, by elimination
00154 // during pre-processing).
00155 //--
00156 #define KERNEL_TRACE(x)
00157 //
00158 #define KERNEL_TRACE_1(x, arg1)
00159 /
00160 #define KERNEL_TRACE_2(x, arg1, arg2)
00161 /
00162 #define KERNEL_ASSERT(x)
00163
00164 #endif // KERNEL USE DEBUG
00165
00166 //-
00167 #if (KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_USER_LOGGING)
00168
00169 //--
00170 #define USER_TRACE(x)
00171
00172 {
00173
              {\tt EMIT\_DBG\_STRING(x);}
00174
              uint16_t au16Msg__[4];
00175
               au16Msg_{[0]} = 0xACDC;
00176
               au16Msg__[1] = DBG_FILE;
00177
               au16Msg__[2] = __LINE__;
00178
               au16Msg__[3] = TraceBuffer::Increment();
00179
               TraceBuffer::Write(au16Msg__, 4);
00180
00181 };
00182
00183 /
00184 #define USER_TRACE_1(x, arg1)
00185
00186 {
00187
               EMIT_DBG_STRING(x);
00188
               uint16_t au16Msg__[5];
00189
               au16Msg_{[0]} = 0xACDC;
00190
               au16Msg__[1] = DBG_FILE;
00191
               au16Msg__[2] = __LINE__;
00192
               au16Msg__[3] = TraceBuffer::Increment();
00193
               au16Msq_{4} = arg1;
00194
               TraceBuffer::Write(au16Msg___, 5);
00195
00196
00197
00199 #define USER_TRACE_2(x, arg1, arg2)
00200
00201 {
00202
              EMIT_DBG_STRING(x);
00203
               uint16_t au16Msg__[6];
00204
               au16Msg_{[0]} = 0xACDC;
```

```
00205
              au16Msg__[1] = DBG_FILE;
00206
              au16Msg__[2] = __LINE__;
00207
              au16Msg__[3] = TraceBuffer::Increment();
00208
              au16Msg_{[4]} = arg1;
00209
              au16Msg_{[5]} = arg2;
00210
              TraceBuffer::Write(au16Msg___, 6);
00211
00212 }
00213
00214 //--
00215 #define USER_ASSERT(x)
00216
00217 {
00218
              if ((x) == false) {
00219
                  EMIT_DBG_STRING("ASSERT FAILED");
00220
                   uint16_t au16Msg__[4];
00221
                   au16Msg_{[0]} = 0xACDC;
00222
                  au16Msg__[1] = DBG_FILE;
00223
                  au16Msg__[2] = __LINE__;
00224
                   au16Msg__[3] = TraceBuffer::Increment();
00225
                  TraceBuffer::Write(au16Msg___, 4);
00226
                  Kernel::Panic(PANIC_ASSERT_FAILED);
00227
00228
00229
00230 #elif (KERNEL_USE_DEBUG && KERNEL_AWARE_SIMULATION && KERNEL_ENABLE_USER_LOGGING)
00232 //-
00233 #define USER_TRACE(x)
00234
00235 {
00236
              EMIT_DBG_STRING(x);
00237
              KernelAware::Trace(DBG_FILE, __LINE__);
00238
00239 };
00240
00241 //--
00242 #define USER_TRACE_1(x, arg1)
00243
00244 {
00245
              EMIT_DBG_STRING(x);
00246
              KernelAware::Trace(DBG_FILE, __LINE__, arg1);
00247
00248 }
00249
00250 //--
00251 #define USER_TRACE_2(x, arg1, arg2)
00252
00253 {
00254
              EMIT_DBG_STRING(x);
00255
              KernelAware::Trace(DBG_FILE, __LINE__, arg1, arg2);
00256
00257 }
00258
00259 //--
00260 #define USER_ASSERT(x)
```

```
00261
00262 {
00263
              if ((x) == false) {
00264
                  EMIT_DBG_STRING("ASSERT FAILED");
00265
                  KernelAware::Trace(DBG_FILE, __LINE__);
                  Kernel::Panic(PANIC_ASSERT_FAILED);
00266
00267
00268
00269 }
00270
00271 #else
00272 //-
00273 // Note -- when kernel-debugging is disabled, we still have to define the
00274 // macros to ensure that the expressions compile (albeit, by elimination
00275 // during pre-processing).
00276 //--
00277 #define USER TRACE(x)
00278 //-
00279 #define USER_TRACE_1(x, arg1)
00281 #define USER_TRACE_2(x, arg1, arg2)
00282 //--
00283 #define USER_ASSERT(x)
00284
00285 #endif // KERNEL_USE_DEBUG
00286 } //namespace Mark3
```

20.73 /home/moslevin/projects/github/m3-repo/kernel/src/public/kerneltypes.h File Reference

Basic data type primatives used throughout the OS.

```
#include <stdint.h>
#include <stdbool.h>
#include <stddef.h>
```

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

Typedefs

- using Mark3::PanicFunc = void(*)(uint16_t u16PanicCode_)
 - Function pointer type used to implement kernel-panic handlers.
- using Mark3::IdleFunc = void(*)()

Function pointer type used to implement the idle function, where support for an idle function (as opposed to an idle thread) exists.

using Mark3::ThreadEntryFunc = void(*)(void *pvArg_)

Function pointer type used for thread entrypoint functions.

Enumerations

enum Mark3::EventFlagOperation : uint8_t {
 Mark3::EventFlagOperation::All_Set = 0, Mark3::EventFlagOperation::Any_Set, Mark3::EventFlagOperation::All_Clear, Mark3::EventFlagOperation::Any_Clear,
 Mark3::EventFlagOperation::Pending_Unblock }

This enumeration describes the different operations supported by the event flag blocking object.

• enum Mark3::ThreadState : uint8_t

Enumeration representing the different states a thread can exist in.

20.73.1 Detailed Description

Basic data type primatives used throughout the OS.

Definition in file kerneltypes.h.

20.74 kerneltypes.h

```
00001 /*=========
00002
00003
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]-
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ===
00019 #include <stdint.h>
00020 #include <stdbool.h>
00021 #include <stddef.h>
00022
00023 #pragma once
00024 namespace Mark3
00025 (
00026 //----
00030 using PanicFunc = void (*)(uint16_t u16PanicCode_);
00031
00032 //----
00037 using IdleFunc = void (*)();
00038
00039 //----
00043 using ThreadEntryFunc = void (*) (void* pvArq_);
00045 //----
00050 enum class EventFlagOperation : uint8_t {
00051
       All\_Set = 0,
00052
         Any_Set,
00053
         All_Clear,
         Any_Clear,
00054
00055
         Pending_Unblock
00056 };
00057
00058 //----
00062 enum class ThreadState : uint8_t {
00063
         Exit = 0,
00064
         Ready,
00065
         Blocked,
00066
         Stop,
00067
         Invalid
00068 };
00069
00070 } //namespace Mark3
```

20.75 /home/moslevin/projects/github/m3-repo/kernel/src/public/ksemaphore.h File Reference

Semaphore Blocking Object class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "blocking.h"
#include "threadlist.h"
```

Classes

class Mark3::Semaphore

Binary & Counting semaphores, based on BlockingObject base class.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.75.1 Detailed Description

Semaphore Blocking Object class declarations.

Definition in file ksemaphore.h.

20.76 ksemaphore.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00021 #pragma once
00022
00023 #include "kerneltypes.h"
00024 #include "mark3cfg.h'
00025
00026 #include "blocking.h"
00027 #include "threadlist.h"
00028
00029 #if KERNEL_USE_SEMAPHORE
00030 namespace Mark3
00031 {
00032 //---
00036 class Semaphore : public BlockingObject
00037 {
00038 public:
          void* operator new(size_t sz, void* pv) { return (Semaphore*)pv; };
00039
00040
          ~Semaphore();
00041
```

```
void Init(uint16_t u16InitVal_, uint16_t u16MaxVal_);
00079
          bool Post();
00080
00088
          void Pend();
00089
          uint16_t GetCount();
00102
00103 #if KERNEL_USE_TIMEOUTS
00104
          bool Pend(uint32_t u32WaitTimeMS_);
00115
00116
00127
          void WakeMe (Thread* pclChosenOne_);
00128 #endif
00129
00130 private:
          uint8_t WakeNext();
00136
00137
00138 #if KERNEL_USE_TIMEOUTS
00147
          bool Pend_i (uint32_t u32WaitTimeMS_);
00148 #else
00149
          void Pend_i(void);
00155
00156 #endif
00157
00158
          uint16_t m_u16Value;
00159
         uint16_t m_u16MaxValue;
00160 };
00161 } //namespace Mark3
00162 #endif // KERNEL_USE_SEMAPHORE
```

20.77 /home/moslevin/projects/github/m3-repo/kernel/src/public/II.h File Reference

Core linked-list declarations, used by all kernel list types.

```
#include "kerneltypes.h"
```

Classes

· class Mark3::LinkListNode

Basic linked-list node data structure.

· class Mark3::LinkList

Abstract-data-type from which all other linked-lists are derived.

· class Mark3::DoubleLinkList

Doubly-linked-list data type, inherited from the base LinkList type.

class Mark3::CircularLinkList

Circular-linked-list data type, inherited from the base LinkList type.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.78 II.h 311

20.77.1 Detailed Description

Core linked-list declarations, used by all kernel list types.

At the heart of RTOS data structures are linked lists. Having a robust and efficient set of linked-list types that we can use as a foundation for building the rest of our kernel types allows u16 to keep our RTOS code efficient and logically-separated.

So what data types rely on these linked-list classes?

-Threads -ThreadLists -The Scheduler -Timers, -The Timer Scheduler -Blocking objects (Semaphores, Mutexes, etc...)

Pretty much everything in the kernel uses these linked lists. By having objects inherit from the base linked-list node type, we're able to leverage the double and circular linked-list classes to manager virtually every object type in the system without duplicating code. These functions are very efficient as well, allowing for very deterministic behavior in our code.

Definition in file II.h.

20.78 II.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ===
00042 #pragma once
00043 #include "kerneltypes.h"
00044
00045 namespace Mark3
00046 {
00047
00048 //---
00054 class LinkList;
00055 class DoubleLinkList:
00056 class CircularLinkList;
00057
00058 //--
00063 class LinkListNode
00064 {
00065 protected:
          LinkListNode* next:
00066
00067
          LinkListNode* prev:
00068
00069
          LinkListNode() {}
00075
          void ClearNode();
00076
00077 public:
00085
          LinkListNode* GetNext(void) { return next; }
          LinkListNode* GetPrev(void) { return prev; }
00094
          friend class LinkList;
00095
          friend class DoubleLinkList;
00096
          friend class CircularLinkList;
00097
          friend class ThreadList:
00098 };
00099
00100 //--
00104 class LinkList
00105 (
00106 protected:
          LinkListNode* m pclHead:
00107
00108
          LinkListNode* m_pclTail;
00109
```

```
00110 public:
00116 void Init()
00117
             m_pclHead = NULL;
m_pclTail = NULL;
00118
00119
00120
00121
00129
         LinkListNode* GetHead() { return m_pclHead; }
00137
         LinkListNode* GetTail() { return m_pclTail; }
00138 };
00139
00140 //---
00144 class DoubleLinkList : public LinkList
00145 {
00146 public:
00147
          void* operator new(size_t sz, void* pv) { return (DoubleLinkList*)pv; };
00153
          DoubleLinkList()
00154
              m_pclHead = NULL;
00155
             m_pclTail = NULL;
00157
00158
         void Add(LinkListNode* node_);
00166
00167
00175
          void Remove(LinkListNode* node_);
00176 };
00177
00178 //---
00182 class CircularLinkList : public LinkList
00183 {
00184 public:
00185
          void* operator new(size_t sz, void* pv) { return (CircularLinkList*)pv; };
00186
          CircularLinkList()
00187
              m_pclHead = NULL;
m_pclTail = NULL;
00188
00189
00190
          }
00191
00199
          void Add(LinkListNode* node_);
00200
00208
          void Remove(LinkListNode* node_);
00209
00216
          void PivotForward():
00217
00224
          void PivotBackward();
00225
00235
          void InsertNodeBefore(LinkListNode* node_, LinkListNode* insert_);
00236 };
00237 } //namespace Mark3
```

20.79 /home/moslevin/projects/github/m3-repo/kernel/src/public/lockguard.h File Reference

Mutex RAII helper class.

```
#include "mark3.h"
```

Classes

· class Mark3::LockGuard

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.80 lockguard.h 313

20.79.1 Detailed Description

Mutex RAII helper class.

Definition in file lockguard.h.

20.80 lockguard.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ==
00020 #pragma once
00021
00022 #include "mark3.h"
00024 #if KERNEL_USE_MUTEX
00025
00026 namespace Mark3 {
00027
00032 class LockGuard {
00033 public:
00037
          LockGuard(Mutex* pclMutex);
00038
00039 #if KERNEL_USE_TIMEOUTS
00040
00045
          LockGuard(Mutex* pclMutex, uint32_t u32TimeoutMs_);
00046 #endif
00047
00048
          ~LockGuard();
00049
00056
          bool isAcquired() { return m_bIsAcquired; }
00057
00058 private:
00059
          bool m_bIsAcquired;
00060
          Mutex* m_pclMutex;
00061 };
00062 } // namespace Mark3
00063
00064 #endif // KERNEL_USE_MUTEX
```

20.81 /home/moslevin/projects/github/m3-repo/kernel/src/public/mailbox.h File Reference

Mailbox + Envelope IPC Mechanism.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "threadport.h"
#include "ksemaphore.h"
```

Classes

class Mark3::Mailbox

The Mailbox class implements an IPC mechnism based on envelopes containing data of a fixed size (configured at initialization) that reside within a buffer of memory provided by the user.

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.81.1 Detailed Description

Mailbox + Envelope IPC Mechanism.

Definition in file mailbox.h.

20.82 mailbox.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =======
00020 #pragma once
00021
00022 #include "mark3cfg.h"
00023 #include "kerneltypes.h"
00024 #include "threadport.h"
00025 #include "ksemaphore.h"
00026
00027 #if KERNEL USE MAILBOX
00028 namespace Mark3
00029 {
00035 class Mailbox
00036 {
00037 public:
00038
          void* operator new(size_t sz, void* pv) { return (Mailbox*)pv; }
00039
          ~Mailbox();
00040
00051
          void Init(void* pvBuffer_, uint16_t u16BufferSize_, uint16_t u16ElementSize_);
00052
00053 #if KERNEL_USE_AUTO_ALLOC
00054
          static Mailbox* Init(uint16_t u16BufferSize_, uint16_t u16ElementSize_);
00067
00068
00069 #endif
00070
00084
          bool Send(void* pvData_);
00085
00099
          bool SendTail(void* pvData_);
00100
00101 #if KERNEL_USE_TIMEOUTS
00102
00116
          bool Send(void* pvData_, uint32_t u32TimeoutMS_);
00117
00132
          bool SendTail(void* pvData_, uint32_t u32TimeoutMS_);
00133 #endif
00134
00144
          void Receive(void* pvData_);
00145
00155
          void ReceiveTail(void* pvData_);
00156
00157 #if KERNEL_USE_TIMEOUTS
00158
00170
          bool Receive(void* pvData_, uint32_t u32TimeoutMS_);
00171
00184
          bool ReceiveTail(void* pvData_, uint32_t u32TimeoutMS_);
00185 #endif
00186
00187
          uint16_t GetFreeSlots(void)
00188
          {
```

20.82 mailbox.h 315

```
00189
              uint16_t rc;
00190
              CS_ENTER();
00191
              rc = m_u16Free;
              CS EXIT();
00192
00193
              return rc;
00194
         }
00195
00196
         bool IsFull(void) { return (GetFreeSlots() == 0); }
00197
         bool IsEmpty(void) { return (GetFreeSlots() == m_u16Count); }
00198 private:
00207
          void* GetHeadPointer(void)
00208
          {
00209
              K_ADDR uAddr = (K_ADDR)m_pvBuffer;
              uAddr += (K_ADDR) (m_u16ElementSize) * (K_ADDR) (
     m_u16Head);
00211
            return (void*)uAddr;
00212
00213
00222
         void* GetTailPointer(void)
00223
         {
00224
              K_ADDR uAddr = (K_ADDR)m_pvBuffer;
00225
              uAddr += (K_ADDR) (m_u16ElementSize) * (K_ADDR) (
     m_u16Tail);
00226
             return (void*)uAddr;
00227
         }
00228
00238
          void CopyData(const void* src_, const void* dst_, uint16_t len_)
00239
              uint8_t* u8Src = (uint8_t*)src_;
00240
             uint8_t* u8Dst = (uint8_t*)dst_;
while (len_--) {
00241
00242
00243
                 *u8Dst++ = *u8Src++;
00244
00245
          }
00246
          void MoveTailForward(void)
00252
00253
              m_u16Tail++;
00255
              if (m_u16Tail == m_u16Count) {
00256
                 m_u16Tail = 0;
00257
00258
          }
00259
00265
          void MoveHeadForward(void)
00266
         {
00267
              m_u16Head++;
00268
              if (m_u16Head == m_u16Count) {
                  m_u16Head = 0;
00269
              }
00270
00271
          }
00272
00278
          void MoveTailBackward(void)
00279
              if (m_u16Tail == 0) {
    m_u16Tail = m_u16Count;
00280
00281
00282
00283
              m_u16Tail--;
00284
          }
00285
00291
          void MoveHeadBackward (void)
00292
              if (m_u16Head == 0) {
00293
00294
                  m_u16Head = m_u16Count;
00295
00296
              m_u16Head--;
00297
         }
00298
00299 #if KERNEL_USE_TIMEOUTS
00300
00310
          bool Send_i(const void* pvData_, bool bTail_, uint32_t u32TimeoutMS_);
00311 #else
00312
00321
         bool Send_i(const void* pvData_, bool bTail_);
00322 #endif
00323
00324 #if KERNEL_USE_TIMEOUTS
00325
00335
          bool Receive_i(const void* pvData_, bool bTail_, uint32_t u32WaitTimeMS_);
00336 #else
00337
00345
          void Receive_i(const void* pvData_, bool bTail_);
00346 #endif
00347
00348
          uint16_t m_u16Head;
00349
          uint16_t m_u16Tail;
00350
          uint16 t
                          m_u16Count;
00351
```

```
volatile uint16_t m_u16Free;
00354
         uint16_t
                    m_u16ElementSize;
         const void* m_pvBuffer;
00355
00356
00357
          Semaphore m clRecvSem:
00358
00359 #if KERNEL_USE_TIMEOUTS
00360
         Semaphore m_clSendSem;
00361 #endif
00362 };
00363 } //namespace Mark3
00364 #endif
```

20.83 /home/moslevin/projects/github/m3-repo/kernel/src/public/manual.h File Reference

/brief Ascii-format documentation, used by doxygen to create various printable and viewable forms.

20.83.1 Detailed Description

/brief Ascii-format documentation, used by doxygen to create various printable and viewable forms.

Definition in file manual.h.

20.84 manual.h

20.85 /home/moslevin/projects/github/m3-repo/kernel/src/public/mark3.h File Reference

Single include file given to users of the Mark3 Kernel API.

```
#include "mark3cfg.h"
#include "kerneltypes.h"
#include "threadport.h"
#include "kernelswi.h"
#include "kerneltimer.h"
#include "kernelprofile.h"
#include "thread.h"
#include "timerlist.h"
#include "ksemaphore.h"
#include "mutex.h"
```

20.86 mark3.h 317

```
#include "eventflag.h"
#include "message.h"
#include "notify.h"
#include "mailbox.h"
#include "readerwriter.h"
#include "condvar.h"
#include "atomic.h"
#include "kernelaware.h"
#include "profile.h"
#include "autoalloc.h"
#include "priomap.h"
```

20.85.1 Detailed Description

Single include file given to users of the Mark3 Kernel API.

Definition in file mark3.h.

20.86 mark3.h

```
00001
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =========
00020 #pragma once
00021
00022 #include "mark3cfg.h"
00023 #include "kerneltypes.h"
00024
00025 #include "threadport.h"
00026 #include "kernelswi.h"
00027 #include "kerneltimer.h"
00028 #include "kernelprofile.h"
00030 #include "kernel.h"
00031 #include "thread.h"
00032 #include "timerlist.h"
00033
00034 #include "ksemaphore.h"
00035 #include "mutex.h"
00036 #include "eventflag.h"
00037 #include "message.h"
00038 #include "notify.h"
00030 #Include "mailbox.h"
00040 #include "readerwriter.h"
00041 #include "condvar.h"
00042
00043 #include "atomic.h"
00044 #include "kernelaware.h"
00045
00046 #include "profile.h"
00047 #include "autoalloc.h"
00048 #include "priomap.h"
```

20.87 /home/moslevin/projects/github/m3-repo/kernel/src/public/mark3cfg.h File Reference

Mark3 Kernel Configuration.

```
#include "portcfg.h"
```

Macros

#define KERNEL NUM PRIORITIES (8)

Define the number of thread priorities that the kernel's scheduler will support.

• #define KERNEL_USE_TIMERS (1)

The following options is related to all kernel time-tracking.

• #define KERNEL TIMERS TICKLESS (1)

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

• #define KERNEL_TIMERS_MINIMUM_DELAY_US (25)

When using tickless timers, it is useful to define a minimum sleep value.

#define KERNEL TIMERS THREADED (0)

When timers are enabled, configure whether or not a dedicated thread is used to service timer maintenance.

#define KERNEL USE TIMEOUTS (1)

Set the priority of the timer thread, if the kernel is configured to use a dedicated timer thread.

#define KERNEL USE QUANTUM (1)

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way.

#define THREAD QUANTUM DEFAULT (4)

This value defines the default thread quantum when KERNEL_USE_QUANTUM is enabled.

#define KERNEL_USE_NOTIFY (1)

This is a simple blocking object, where a thread (or threads) are guaranteed to block until an asynchronous event signals the object.

• #define KERNEL USE SEMAPHORE (1)

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h.

#define KERNEL_USE_MUTEX (1)

Do you want the ability to use mutual exclusion semaphores (mutex) for resource/block protection? Enabling this feature provides mutexes, with priority inheritence, as declared in mutex.h.

• #define KERNEL USE EVENTFLAG (1)

Provides additional event-flag based blocking.

#define KERNEL_USE_READERWRITER (1)

Provides reader-writer locks.

• #define KERNEL_USE_CONDVAR (1)

Provides condition variables.

#define KERNEL_USE_MESSAGE (1)

Enable inter-thread messaging using message queues.

• #define GLOBAL MESSAGE POOL SIZE (8)

If Messages are enabled, define the size of the default kernel message pool.

#define KERNEL_USE_MAILBOX (1)

Enable inter-thread messaging using mailboxes.

• #define KERNEL_USE_SLEEP (1)

Do you want to be able to set threads to sleep for a specified time? This enables the Thread::Sleep() API.

#define KERNEL_USE_THREADNAME (0)

Provide Thread method to allow the user to set a name for each thread in the system.

#define KERNEL USE EXTENDED CONTEXT (1)

Allocate an extra pointer's worth of storage within a Thread object (and corresponding accessor methods) to provide the user with a means to implement arbitrary Thread-local storage.

• #define KERNEL USE DYNAMIC THREADS (1)

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime.

• #define KERNEL USE PROFILER (1)

Provides extra classes for profiling the performance of code.

• #define KERNEL USE DEBUG (0)

Provides extra logic for kernel debugging, and instruments the kernel with extra asserts, and kernel trace functionality.

#define KERNEL USE ATOMIC (1)

Provides support for atomic operations, including addition, subtraction, set, and test-and-set.

• #define SAFE UNLINK (0)

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists.

• #define KERNEL_AWARE_SIMULATION (1)

Include support for kernel-aware simulation.

• #define KERNEL USE IDLE FUNC (1)

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality.

#define KERNEL USE AUTO ALLOC (1)

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory).

• #define KERNEL_USE_THREAD_CALLOUTS (1)

This feature provides additional kernel APIs to register callout functions that are activated when threads are created or exited.

• #define KERNEL_USE_STACK_GUARD (1)

This feature, when enabled, tells the kernel to check whether any Thread's stack has been exhausted (or slack falls below a certain safety threshold) before executing each context switch.

• #define KERNEL EXTRA CHECKS (1)

This option provides extra safety checks within the kernel APIs in order to minimize the potential for unsafe operations.

20.87.1 Detailed Description

Mark3 Kernel Configuration.

This file is used to configure the kernel for your specific application in order to provide the optimal set of features for a given use case.

Since you only pay the price (code space/RAM) for the features you use, you can usually find a sweet spot between features and resource usage by picking and choosing features a-la-carte. This config file is written in an "interactive" way, in order to minimize confusion about what each option provides, and to make dependencies obvious.

Definition in file mark3cfg.h.

20.87.2 Macro Definition Documentation

20.87.2.1 GLOBAL_MESSAGE_POOL_SIZE

```
#define GLOBAL_MESSAGE_POOL_SIZE (8)
```

If Messages are enabled, define the size of the default kernel message pool.

Messages can be manually added to the message pool, but this mechansims is more convenient and automatic. All message queues share their message objects from this global pool to maximize efficiency and simplify data management.

Definition at line 211 of file mark3cfg.h.

20.87.2.2 KERNEL AWARE SIMULATION

```
#define KERNEL_AWARE_SIMULATION (1)
```

Include support for kernel-aware simulation.

Enabling this feature adds advanced profiling, trace, and environment-aware debugging and diagnostic functionality when Mark3-based applications are run on the flavr AVR simulator.

Definition at line 315 of file mark3cfg.h.

20.87.2.3 KERNEL_EXTRA_CHECKS

```
#define KERNEL_EXTRA_CHECKS (1)
```

This option provides extra safety checks within the kernel APIs in order to minimize the potential for unsafe operations.

This is especially helpful during development, and can help catch problems at development time, instead of in the field.include CPU/Port specific configuration options

Definition at line 370 of file mark3cfg.h.

20.87.2.4 KERNEL_NUM_PRIORITIES

```
#define KERNEL_NUM_PRIORITIES (8)
```

Define the number of thread priorities that the kernel's scheduler will support.

The number of thread priorities is limited only by the memory of the host CPU, as a ThreadList object is statically-allocated for each thread priority.

In practice, systems rarely need more than 32 priority levels, with the most complex having the capacity for 256.

Definition at line 39 of file mark3cfg.h.

20.87.2.5 KERNEL_TIMERS_MINIMUM_DELAY_US

```
#define KERNEL_TIMERS_MINIMUM_DELAY_US (25)
```

When using tickless timers, it is useful to define a minimum sleep value.

In the event that a delay/sleep/timeout value lower than this is provided to a timer-based API, the minimum value will be substituted.

Definition at line 84 of file mark3cfg.h.

20.87.2.6 KERNEL_TIMERS_THREADED

```
#define KERNEL_TIMERS_THREADED (0)
```

When timers are enabled, configure whether or not a dedicated thread is used to service timer maintenance.

If set to 0, timer handlers are executed from a nested interrupt context.

Definition at line 93 of file mark3cfg.h.

20.87.2.7 KERNEL_TIMERS_TICKLESS

```
#define KERNEL_TIMERS_TICKLESS (1)
```

If you've opted to use the kernel timers module, you have an option as to which timer implementation to use: Tick-based or Tick-less.

Tick-based timers provide a "traditional" RTOS timer implementation based on a fixed-frequency timer interrupt. While this provides very accurate, reliable timing, it also means that the CPU is being interrupted far more often than may be necessary (as not all timer ticks result in "real work" being done).

Tick-less timers still rely on a hardware timer interrupt, but uses a dynamic expiry interval to ensure that the interrupt is only called when the next timer expires. This increases the complexity of the timer interrupt handler, but reduces the number and frequency.

Note that the CPU port (kerneltimer.cpp) must be implemented for the particular timer variant desired.

Definition at line 75 of file mark3cfg.h.

20.87.2.8 KERNEL_USE_ATOMIC

```
#define KERNEL_USE_ATOMIC (1)
```

Provides support for atomic operations, including addition, subtraction, set, and test-and-set.

Add/Sub/Set contain 8, 16, and 32-bit variants.

Definition at line 299 of file mark3cfg.h.

20.87.2.9 KERNEL_USE_AUTO_ALLOC

```
#define KERNEL_USE_AUTO_ALLOC (1)
```

This feature enables an additional set of APIs that allow for objects to be created on-the-fly out of a special heap, without having to explicitly allocate them (from stack, heap, or static memory).

Note that auto-alloc memory cannot be reclaimed.

Definition at line 336 of file mark3cfg.h.

20.87.2.10 KERNEL_USE_CONDVAR

```
#define KERNEL_USE_CONDVAR (1)
```

Provides condition variables.

Allows a thread to wait for a specific condition to be true before proceeding.

Definition at line 187 of file mark3cfg.h.

20.87.2.11 KERNEL_USE_DYNAMIC_THREADS

```
#define KERNEL_USE_DYNAMIC_THREADS (1)
```

Provide extra Thread methods to allow the application to create (and more importantly destroy) threads at runtime.

useful for designs implementing worker threads, or threads that can be restarted after encountering error conditions.

Definition at line 259 of file mark3cfg.h.

20.87.2.12 KERNEL_USE_EVENTFLAG

```
#define KERNEL_USE_EVENTFLAG (1)
```

Provides additional event-flag based blocking.

This relies on an additional per-thread flag-mask to be allocated, which adds 2 bytes to the size of each thread object.

Definition at line 168 of file mark3cfg.h.

20.87.2.13 KERNEL_USE_IDLE_FUNC

```
#define KERNEL_USE_IDLE_FUNC (1)
```

Enabling this feature removes the necessity for the user to dedicate a complete thread for idle functionality.

This saves a full thread stack, but also requires a bit extra static data. This also adds a slight overhead to the context switch and scheduler, as a special case has to be taken into account.

Definition at line 325 of file mark3cfg.h.

20.87.2.14 KERNEL_USE_MAILBOX

```
#define KERNEL_USE_MAILBOX (1)
```

Enable inter-thread messaging using mailboxes.

A mailbox manages a blob of data provided by the user, that is partitioned into fixed-size blocks called envelopes. The size of an envelope is set by the user when the mailbox is initialized. Any number of threads can read-from and write-to the mailbox. Envelopes can be sent-to or received-from the mailbox at the head or tail. In this way, mailboxes essentially act as a circular buffer that can be used as a blocking FIFO or LIFO queue.

Definition at line 224 of file mark3cfg.h.

20.87.2.15 KERNEL_USE_MESSAGE

```
#define KERNEL_USE_MESSAGE (1)
```

Enable inter-thread messaging using message queues.

This is the preferred mechanism for IPC for serious multi-threaded communications; generally anywhere a semaphore or event-flag is insufficient.

Definition at line 198 of file mark3cfg.h.

20.87.2.16 KERNEL_USE_PROFILER

```
#define KERNEL_USE_PROFILER (1)
```

Provides extra classes for profiling the performance of code.

useful for debugging and development, but uses an additional hardware timer.

Definition at line 265 of file mark3cfg.h.

20.87.2.17 KERNEL_USE_QUANTUM

```
#define KERNEL_USE_QUANTUM (1)
```

Do you want to enable time quanta? This is useful when you want to have tasks in the same priority group share time in a controlled way.

This allows equal tasks to use unequal amounts of the CPU, which is a great way to set up CPU budgets per thread in a round-robin scheduling system. If enabled, you can specify a number of ticks that serves as the default time period (quantum). Unless otherwise specified, every thread in a priority will get the default quantum.

Definition at line 131 of file mark3cfg.h.

20.87.2.18 KERNEL_USE_READERWRITER

```
#define KERNEL_USE_READERWRITER (1)
```

Provides reader-writer locks.

Allows current read access, or single write-access to a resource. Readers wait for the writer to release the lock, and writers wait for all readers to release the lock before acquiring the resource.

Definition at line 177 of file mark3cfg.h.

20.87.2.19 KERNEL_USE_SEMAPHORE

```
#define KERNEL_USE_SEMAPHORE (1)
```

Do you want the ability to use counting/binary semaphores for thread synchronization? Enabling this features provides fully-blocking semaphores and enables all API functions declared in semaphore.h.

If you have to pick one blocking mechanism, this is the one to choose.

Definition at line 154 of file mark3cfg.h.

20.87.2.20 KERNEL_USE_STACK_GUARD

```
#define KERNEL_USE_STACK_GUARD (1)
```

This feature, when enabled, tells the kernel to check whether any Thread's stack has been exhausted (or slack falls below a certain safety threshold) before executing each context switch.

Enabling this is the most effective means to guard against stack corruption and stack overflow in the kernel, at the cost of increased context switch latency.

Definition at line 358 of file mark3cfg.h.

20.87.2.21 KERNEL_USE_THREAD_CALLOUTS

```
#define KERNEL_USE_THREAD_CALLOUTS (1)
```

This feature provides additional kernel APIs to register callout functions that are activated when threads are created or exited.

This is useful for implementing low-level instrumentation based on information held in the threads.

Definition at line 348 of file mark3cfg.h.

20.87.2.22 KERNEL_USE_THREADNAME

```
#define KERNEL_USE_THREADNAME (0)
```

Provide Thread method to allow the user to set a name for each thread in the system.

Adds a const char* pointer to the size of the thread object.

Definition at line 244 of file mark3cfg.h.

20.87.2.23 KERNEL USE TIMEOUTS

```
#define KERNEL_USE_TIMEOUTS (1)
```

Set the priority of the timer thread, if the kernel is configured to use a dedicated timer thread.

By default, if you opt to enable kernel timers, you also get timeout- enabled versions of the blocking object APIs along with it. This support comes at a small cost to code size, but a slightly larger cost to realtime performance - as checking for the use of timers in the underlying internal code costs some cycles.

As a result, the option is given to the user here to manually disable these timeout-based APIs if desired by the user for performance and code-size reasons.

Definition at line 116 of file mark3cfg.h.

20.87.2.24 KERNEL_USE_TIMERS

```
#define KERNEL_USE_TIMERS (1)
```

The following options is related to all kernel time-tracking.

- -timers provide a way for events to be periodically triggered in a lightweight manner. These can be periodic, or one-shot.
- -Thread Quantum (usedd for round-robin scheduling) is dependent on this module, as is Thread Sleep functionality.

Definition at line 54 of file mark3cfg.h.

20.87.2.25 SAFE_UNLINK

```
#define SAFE_UNLINK (0)
```

"Safe unlinking" performs extra checks on data to make sure that there are no consistencies when performing operations on linked lists.

This goes beyond pointer checks, adding a layer of structural and metadata validation to help detect system corruption early.

Definition at line 307 of file mark3cfg.h.

20.87.2.26 THREAD_QUANTUM_DEFAULT

```
#define THREAD_QUANTUM_DEFAULT (4)
```

This value defines the default thread quantum when KERNEL_USE_QUANTUM is enabled.

The thread quantum value is in milliseconds

Definition at line 140 of file mark3cfg.h.

20.88 mark3cfg.h

```
00001 /
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00028 #pragma once
00029
00039 #define KERNEL_NUM_PRIORITIES (8)
00040
00041 #if KERNEL_NUM_PRIORITIES > 1024
00042 #error "Mark3 supports a maximum of 1024 priorities"
00043 #endif
00044
00054 #define KERNEL_USE_TIMERS (1)
00055
00074 #if KERNEL_USE_TIMERS && !defined(ARM)
00075 #define KERNEL_TIMERS_TICKLESS (1)
00076 #endif
00077
00078 #if KERNEL_TIMERS_TICKLESS
00079
00084 #define KERNEL_TIMERS_MINIMUM_DELAY_US (25)
00085 #endif
00086
00092 #if KERNEL USE TIMERS
00093 # define KERNEL_TIMERS_THREADED (0)
00094 #endif
00095
00100 #if KERNEL_TIMERS_THREADED
00101 # define KERNEL_TIMERS_THREAD_PRIORITY (KERNEL_NUM_PRIORITIES - 1)
00102 #endif
00103
00115 #if KERNEL_USE_TIMERS
00116 #define KERNEL_USE_TIMEOUTS (1)
```

20.88 mark3cfg.h 327

```
00117 #else
00118 #define KERNEL_USE_TIMEOUTS (0)
00119 #endif
00120
00130 #if KERNEL USE TIMERS
00131 #define KERNEL USE OUANTUM (1)
00132 #else
00133 #define KERNEL_USE_QUANTUM (0)
00134 #endif
00135
00140 #define THREAD_QUANTUM_DEFAULT (4)
00141
00146 #define KERNEL_USE_NOTIFY (1)
00147
00154 #define KERNEL_USE_SEMAPHORE (1)
00155
00161 #define KERNEL USE MUTEX (1)
00162
00168 #define KERNEL_USE_EVENTFLAG (1)
00169
00176 #if KERNEL_USE_MUTEX
00177 # define KERNEL_USE_READERWRITER (1)
00178 #else
00179 # define KERNEL USE READERWRITER (0)
00180 #endif
00181
00186 #if KERNEL_USE_SEMAPHORE && KERNEL_USE_MUTEX
00187 # define KERNEL_USE_CONDVAR (1)
00188 #else
00189 # define KERNEL USE CONDVAR (0)
00190 #endif
00191
00197 #if KERNEL_USE_SEMAPHORE
00198 #define KERNEL_USE_MESSAGE (1)
00199 #else
00200 #define KERNEL_USE_MESSAGE (0)
00201 #endif
00210 #if KERNEL_USE_MESSAGE
00211 #define GLOBAL_MESSAGE_POOL_SIZE (8)
00212 #endif
00213
00223 #if KERNEL_USE_SEMAPHORE
00224 #define KERNEL_USE_MAILBOX (1)
00225 #else
00226 #define KERNEL_USE_MAILBOX (0)
00227 #endif
00228
00233 #if KERNEL USE TIMERS && KERNEL USE SEMAPHORE
00234 #define KERNEL_USE_SLEEP (1)
00235 #else
00236 #define KERNEL_USE_SLEEP (0)
00237 #endif
00238
00244 #define KERNEL_USE_THREADNAME (0)
00245
00251 #define KERNEL_USE_EXTENDED_CONTEXT
00252
00259 #define KERNEL_USE_DYNAMIC_THREADS (1)
00260
00265 #define KERNEL_USE_PROFILER (1)
00266
00271 #define KERNEL_USE_DEBUG (0)
00272
00273 #if KERNEL_USE_DEBUG
00274
00280 #define KERNEL_ENABLE_LOGGING (0)
00281
00289 #define KERNEL_ENABLE_USER_LOGGING (0)
00290 #else
00291 #define KERNEL_ENABLE_LOGGING (0)
00292 #define KERNEL_ENABLE_USER_LOGGING (0)
00293 #endif
00294
00299 #define KERNEL_USE_ATOMIC (1)
00300
00307 #define SAFE_UNLINK (0)
00308
00315 #define KERNEL_AWARE_SIMULATION (1)
00316
00324 #if !defined(ARM)
00325 #define KERNEL_USE_IDLE_FUNC (1) // Supported everywhere but ARM
00326 #else
00327 #define KERNEL_USE_IDLE_FUNC (0) // Not currently supported on ARM
00328 #endif
00329
00336 #define KERNEL_USE_AUTO_ALLOC (1)
```

```
00337
00338 #if KERNEL_USE_AUTO_ALLOC
00339 #define AUTO_ALLOC_SIZE (512)
00340 #endif
00341
00348 #define KERNEL_USE_THREAD_CALLOUTS (1)
00349
00358 #define KERNEL_USE_STACK_GUARD (1)
00359
00360 #if KERNEL_USE_STACK_GUARD
00361 #define KERNEL_STACK_GUARD_DEFAULT (32) // words
00362 #endif
00363
00370 #define KERNEL_EXTRA_CHECKS (1)
00371
00372 #include "portcfg.h"
```

20.89 /home/moslevin/projects/github/m3-repo/kernel/src/public/message.h File Reference

Inter-thread communication via message-passing.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "ksemaphore.h"
#include "timerlist.h"
```

Classes

· class Mark3::Message

Class to provide message-based IPC services in the kernel.

· class Mark3::MessagePool

Implements a list of message objects.

• class Mark3::MessageQueue

List of messages, used as the channel for sending and receiving messages between threads.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.89.1 Detailed Description

Inter-thread communication via message-passing.

Embedded systems guru Jack Ganssle once said that without a robust form of interprocess communications (IPC), an RTOS is just a toy. Mark3 implements a form of IPC to provide safe and flexible messaging between threads.

using kernel-managed IPC offers significant benefits over other forms of data sharing (i.e. Global variables) in that it avoids synchronization issues and race conditions common to the practice. using IPC also enforces a more disciplined coding style that keeps threads decoupled from one another and minimizes global data, preventing careless and hard-to-debug errors.

20.90 message.h 329

20.89.2 using Messages, Queues, and the Global Message Pool

```
// Declare a message queue shared between two threads
MessageQueue my_queue;
int main()
    // Initialize the message queue
    my_queue.init();
void Thread1()
    // Example TX thread - sends a message every 10ms
    while(1)
        // Grab a message from the global message pool
        Message *tx_message = GlobalMessagePool::Pop();
        // Set the message data/parameters
        tx_message->SetCode(1234);
        tx_message->SetData( NULL );
        // Send the message on the queue.
        my_queue.Send( tx_message );
        Thread::Sleep(10);
}
void Thread2()
        // Blocking receive - wait until we have messages to process
        Message *rx_message = my_queue.Recv();
        // Do something with the message data...
        // Return back into the pool when done
        GlobalMessagePool::Push(rx_message);
}
```

Definition in file message.h.

20.90 message.h

```
00001 /*===
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform] ---
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =========
00079 #pragma once
08000
00081 #include "kerneltypes.h"
00082 #include "mark3cfg.h"
00083
00084 #include "11.h"
00085 #include "ksemaphore.h"
00086
00087 #if KERNEL_USE_MESSAGE
00088
00089 #if KERNEL_USE_TIMEOUTS
00090 #include "timerlist.h"
00091 #endif
00092 namespace Mark3
00093 {
00094 //--
```

```
00098 class Message : public LinkListNode
00100 public:
00101
          void* operator new(size_t sz, void* pv) { return (Message*)pv; }
          void Init()
00108
00109
              ClearNode();
00110
              m_pvData = NULL;
              m_u16Code = 0;
00111
00112
          }
00113
          void SetData(void* pvData_) { m_pvData = pvData_; }
00121
          void SetData() { return m_pvData; }
void SetCode(uint16_t u16Code_) { m_u16Code = u16Code_; }
00129
00137
00145
          uint16_t GetCode() { return m_u16Code; }
00146 private:
          void* m_pvData;
00148
00149
          uint16_t m_u16Code;
00152 };
00153
00154 //---
00158 class MessagePool
00159 {
00160 public:
00161
         void* operator new(size_t sz, void* pv) { return (MessagePool*)pv; }
00162
00168
          void Init();
00169
          void Push (Message* pclMessage_);
00179
00180
00189
         Message* Pop();
00190
00198
          Message* GetHead();
00199
00200 private:
00202
          DoubleLinkList m clList;
00203 };
00204
00205 //---
00210 class MessageQueue
00211 {
00212 public:
00213
          void* operator new(size_t sz, void* pv) { return (MessageQueue*)pv; }
00214
          ~MessageQueue() {}
00215
00221
          void Init();
00222
00231
         Message* Receive();
00232
00233 #if KERNEL_USE_TIMEOUTS
00234
00248
          Message* Receive(uint32_t u32TimeWaitMS_);
00249 #endif
00250
00259
         void Send(Message* pclSrc );
00268
          uint16_t GetCount();
00269
00270 private:
00271 #if KERNEL_USE_TIMEOUTS
00272
00281
          Message* Receive_i(uint32_t u32TimeWaitMS_);
00282 #else
00283
00290
          Message* Receive_i(void);
00291 #endif
00292
00294
          Semaphore m clSemaphore:
00295
00297
         DoubleLinkList m_clLinkList;
00298 };
00299 } //namespace Mark3
00300 #endif // KERNEL_USE_MESSAGE
```

20.91 /home/moslevin/projects/github/m3-repo/kernel/src/public/mutex.h File Reference

Mutual exclusion class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

```
#include "blocking.h"
```

Classes

class Mark3::Mutex

Mutual-exclusion locks, based on BlockingObject.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.91.1 Detailed Description

Mutual exclusion class declaration.

Resource locks are implemented using mutual exclusion semaphores (Mutex_t). Protected blocks can be placed around any resource that may only be accessed by one thread at a time. If additional threads attempt to access the protected resource, they will be placed in a wait queue until the resource becomes available. When the resource becomes available, the thread with the highest original priority claims the resource and is activated. Priority inheritance is included in the implementation to prevent priority inversion. Always ensure that you claim and release your mutex objects consistently, otherwise you may end up with a deadlock scenario that's hard to debug.

20.91.2 Initializing

Initializing a mutex object by calling:

```
clMutex.Init();
```

20.91.3 Resource protection example

```
clMutex.Claim();
...
<resource protected block>
...
clMutex.Release();
```

Definition in file mutex.h.

20.92 mutex.h

```
00001 /*=
00002
00003
                00004
00005
00006
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 m0slevin, all rights reserved.
00012 See license.txt for more information
00013 ----- */
00050 #pragma once
00051
00052 #include "kerneltypes.h"
00053 #include "mark3cfg.h"
00054
00055 #include "blocking.h"
00056
00057 #if KERNEL_USE_MUTEX
00058 namespace Mark3
00059 (
00060 //--
00064 class Mutex : public BlockingObject
00065 {
00066 public:
00067
         void* operator new(size_t sz, void* pv) { return (Mutex*)pv; };
00068
         ~Mutex();
00069
00078
         void Init(bool bRecursive_ = true);
00079
00097
         void Claim();
00098
00099 #if KERNEL_USE_TIMEOUTS
00100
00111
         bool Claim (uint32 t u32WaitTimeMS );
00112
00125
         void WakeMe(Thread* pclOwner_);
00126
00127 #endif
00128
00149
         void Release();
00150
00151 private:
00157
         uint8_t WakeNext();
00158
00159 #if KERNEL USE TIMEOUTS
00160
00168
         bool Claim_i(uint32_t u32WaitTimeMS_);
00169 #else
00170
00176
         void Claim_i(void);
00177 #endif
00178
         uint8_t m_u8Recurse;
00179
00180
                m_bReady;
         bool
00181
         bool
                 m_bRecursive;
00182
         uint8_t m_u8MaxPri;
00183
         Thread* m_pclOwner;
00184 };
00185 } //namespace Mark3
00186 #endif // KERNEL_USE_MUTEX
```

20.93 /home/moslevin/projects/github/m3-repo/kernel/src/public/notify.h File Reference

Lightweight thread notification - blocking object.

```
#include "mark3cfg.h"
#include "blocking.h"
```

20.94 notify.h 333

Classes

· class Mark3::Notify

The Notify class is a blocking object type, that allows one or more threads to wait for an event to occur before resuming operation.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.93.1 Detailed Description

Lightweight thread notification - blocking object.

Definition in file notify.h.

20.94 notify.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 m0slevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00021 #pragma once
00022
00023 #include "mark3cfg.h"
00024 #include "blocking.h"
00025
00026 #if KERNEL_USE_NOTIFY
00027 namespace Mark3
00028 {
00033 class Notify : public BlockingObject
00034 {
00035 public:
00036
          void* operator new(size_t sz, void* pv) { return (Notify*)pv; };
00037
          ~Notify();
00038
00044
          void Init(void);
00045
00055
          void Signal(void);
00056
          void Wait(bool* pbFlag_);
00066
00067
00068 #if KERNEL_USE_TIMEOUTS
00069
00081
          bool Wait(uint32_t u32WaitTimeMS_, bool* pbFlag_);
00082 #endif
00083
00093
          void WakeMe (Thread* pclChosenOne_);
00094
00095 private:
00096
00097
          bool m_bPending;
00098 };
00099 } //namespace Mark3
00100 #endif
00101
```

20.95 /home/moslevin/projects/github/m3-repo/kernel/src/public/paniccodes.h File Reference

Defines the reason codes thrown when a kernel panic occurs.

20.95.1 Detailed Description

Defines the reason codes thrown when a kernel panic occurs.

Definition in file paniccodes.h.

20.96 paniccodes.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00020 #pragma once
00021
00022 #define PANIC_ASSERT_FAILED (1)
00023 #define PANIC_LIST_UNLINK_FAILED (2)
00024 #define PANIC_STACK_SLACK_VIOLATED (3)
00025 #define PANIC_AUTO_HEAP_EXHAUSTED (4)
00026 #define PANIC_POWERMAN_EXHAUSTED (5)
00027 #define PANIC_NO_READY_THREADS (6)
00028 #define PANIC_RUNNING_THREAD_DESCOPED (7) 00029 #define PANIC_ACTIVE_SEMAPHORE_DESCOPED (8)
00030 #define PANIC_ACTIVE_MUTEX_DESCOPED (9)
00031 #define PANIC_ACTIVE_EVENTFLAG_DESCOPED (10)
00032 #define PANIC_ACTIVE_NOTIFY_DESCOPED (11)
00033 #define PANIC_ACTIVE_MAILBOX_DESCOPED (12)
00034 #define PANIC_ACTIVE_TIMER_DESCOPED (13)
```

20.97 /home/moslevin/projects/github/m3-repo/kernel/src/public/priomap.h File Reference

Priority map data structure.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

Classes

class Mark3::PriorityMap
 The PriorityMap class.

20.98 priomap.h 335

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.97.1 Detailed Description

Priority map data structure.

Definition in file priomap.h.

20.98 priomap.h

```
00001 /*
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00019 #pragma once
00020
00021 #include "kerneltypes.h"
00022 #include "mark3cfg.h"
00023
00024 //---
00025 // Define the type used to store the priority map based on the word size of 00026 // the underlying host architecture. 00027 \#if !defined(PORT_PRIO_MAP_WORD_SIZE)
00028 #error "undefined PORT_PRIO_MAP_WORD_SIZE"
00029 #endif
00030
00031 #define PRIO_MAP_WORD_TYPE K_WORD
00032
00033 // Size of the map index type in bits 00034 #define PRIO_MAP_BITS (8 * PORT_PRIO_MAP_WORD_SIZE)
00036 // # of bits in an integer used to represent the number of bits in the map.
00037 // Used for bitshifting the bit index away from the map index. 00038 // i.e. 3 == 8 bits, 4 == 16 bits, 5 == 32 bits, etc...
00039 #define PRIO_MAP_WORD_SHIFT (2 + PORT_PRIO_MAP_WORD_SIZE)
00040
00041 // Bitmask used to separate out the priorities first-level bitmap from its
00042 // second-level map index for a given priority
00043 #define PRIO_MAP_BIT_MASK ((1 << PRIO_MAP_WORD_SHIFT) - 1)
00044
00045 // Get the priority bit for a given thread
00046 #define PRIO_BIT(x) ((x)&PRIO_MAP_BIT_MASK)
00048 \!\!\!// Macro used to get the map index for a given priroity
00049 #define PRIO_MAP_WORD_INDEX(prio) ((prio) >> PRIO_MAP_WORD_SHIFT)
00050
00051 // Required size of the bitmap array in words
00052 #define PRIO_MAP_NUM_WORDS ((KERNEL_NUM_PRIORITIES + (PRIO_MAP_BITS - 1)) / (PRIO_MAP_BITS))
00053
00054 //--
00055 #if (PRIO_MAP_NUM_WORDS == 1)
00056 // If there is only 1 word required to store the priority information, we don't
00057 // need an array, or a secondary bitmap. 00058 #define PRIO_MAP_MULTI_LEVEL (0)
00059 #else
00060 // An array of bitmaps are required, and a secondary index is required to
00061 // efficiently track which priority levels are active.
00062 #define PRIO_MAP_MULTI_LEVEL (1)
00063 #endif
00064 namespace Mark3
00065 {
00066 //--
```

```
00070 class PriorityMap
00071 {
00072 public:
00078
          PriorityMap();
00079
00085
          void Set (PORT_PRIO_TYPE uXPrio_);
00092
          void Clear(PORT_PRIO_TYPE uXPrio_);
00093
          PORT_PRIO_TYPE HighestPriority(void);
00102
00103
00104 private:
00105 #if PRIO_MAP_MULTI_LEVEL
00106 PRIO_MAP_WORD_TYPE m_auXPriorityMap[PRIO_MAP_NUM_WORDS];
00107
          PRIO_MAP_WORD_TYPE m_uXPriorityMapL2;
00108 #else
        PRIO_MAP_WORD_TYPE m_uXPriorityMap;
00109
00110 #endif
00111 };
00112 } //namespace Mark3
```

20.99 /home/moslevin/projects/github/m3-repo/kernel/src/public/profile.h File Reference

High-precision profiling timers.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

Classes

· class Mark3::ProfileTimer

Profiling timer.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.99.1 Detailed Description

High-precision profiling timers.

Enables the profiling and instrumentation of performance-critical code. Multiple timers can be used simultaneously to enable system-wide performance metrics to be computed in a lightweight manner.

Usage:

Definition in file profile.h.

20.100 profile.h 337

20.100 profile.h

```
00002
00003
00004
00005
00006
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00052 #pragma once
00053
00054 #include "kerneltypes.h"
00055 #include "mark3cfg.h"
00056 #include "11.h"
00057
00058 #if KERNEL_USE_PROFILER
00059 namespace Mark3
00060 {
00069 class ProfileTimer
00070 {
00071 public:
00078
          void Init();
00079
00086
          void Start();
00087
00094
          void Stop();
00095
00103
          uint32_t GetAverage();
00104
00113
          uint32_t GetCurrent();
00114
00115 private:
00126
          uint32_t ComputeCurrentTicks(uint16_t u16Current_, uint32_t u32Epoch_);
00127
00128
          uint32_t m_u32Cumulative;
00129
          uint32_t m_u32CurrentIteration;
00130
          uint16_t m_u16Initial;
          uint32_t m_u32InitialEpoch;
uint16_t m_u16Iterations;
00131
00132
00133
                   m_bActive;
          bool
00134 };
00135 }
       //namespace Mark3
00136 #endif // KERNEL_USE_PROFILE
```

20.101 /home/moslevin/projects/github/m3-repo/kernel/src/public/quantum.h File Reference

Thread Quantum declarations for Round-Robin Scheduling.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "timer.h"
#include "timerlist.h"
#include "timerscheduler.h"
```

Classes

• class Mark3::Quantum

Static-class used to implement Thread quantum functionality, which is a key part of round-robin scheduling.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.101.1 Detailed Description

Thread Quantum declarations for Round-Robin Scheduling.

Definition in file quantum.h.

20.102 quantum.h

```
00001 /
00002
00003
00004
00005
00006
00007
00008
00009
        -[Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ===
00022 #pragma once
00023
00024 #include "kerneltypes.h"
00025 #include "mark3cfg.h"
00026
00027 #include "thread.h'
00028 #include "timer.h"
00029 #include "timerlist.h"
00030 #include "timerscheduler.h"
00031
00032 #if KERNEL_USE_QUANTUM
00033 namespace Mark3
00034 {
00035 class Timer;
00036
00042 class Quantum
00043 {
00044 public:
          static void UpdateTimer();
00053
00054
00061
          static void AddThread(Thread* pclThread_);
00062
00068
          static void RemoveThread();
00069
00078
          static void SetInTimer(void) { m_bInTimer = true; }
00084
          static void ClearInTimer(void) { m_bInTimer = false; }
00085
00086 #if KERNEL_TIMERS_THREADED
00087
          void SetTimerThread(Thread* pclTimerThread_);
00088
00089
          Thread* GetTimerThread():
00090 #endif
00091
00092 private:
00104
          static void SetTimer(Thread* pclThread_);
00105
00106 #if KERNEL_TIMERS_THREADED
00107 static Thread* m_pclTimerThread;
00108 #endif
00109
00110
          static Timer m_clQuantumTimer;
00111
          static bool m_bActive;
00112
          static bool m_bInTimer;
00113 };
00114 } //namespace Mark3
00115 #endif // KERNEL_USE_QUANTUM
```

20.103 /home/moslevin/projects/github/m3-repo/kernel/src/public/readerwriter.h File Reference

Reader-Writer lock implementation.

```
#include "mark3cfg.h"
#include "blocking.h"
#include "mutex.h"
```

Classes

class Mark3::ReaderWriterLock

The ReaderWriterLock class This class implements an object that marshalls access to a resource based on the intended usage of the resource.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.103.1 Detailed Description

Reader-Writer lock implementation.

Definition in file readerwriter.h.

20.104 readerwriter.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00021 #pragma once
00022
00023 #include "mark3cfg.h"
00024 #include "blocking.h"
00025 #include "mutex.h"
00026
00027 #if KERNEL_USE_READERWRITER
00028 namespace Mark3 {
00029
00041 class ReaderWriterLock {
00042 public:
00043
          void* operator new(size_t sz, void* pv) { return (ReaderWriterLock*)pv; }
00044
00050
          void Init();
00051
00058
          void AcquireReader();
00059
00060 #if KERNEL_USE_TIMEOUTS
```

```
00069
          bool AcquireReader(uint32_t u32TimeoutMs_);
00070 #endif
00071
00076
          void ReleaseReader();
00077
          void AcquireWriter();
00085
00086 #if KERNEL_USE_TIMEOUTS
00087
          bool AcquireWriter(uint32_t u32TimeoutMs_);
00095
00096 #endif
00097
00102
          void ReleaseWriter();
00103
00104 private:
00105 #if KERNEL_USE_TIMEOUTS
00106
00112
          bool AcquireReader_i(uint32_t u32TimeoutMs_);
00113 #else
00114
00117
          void AcquireReader_i();
00118 #endif
00119
00120 #if KERNEL_USE_TIMEOUTS
00121
00127
          bool AcquireWriter_i(uint32_t u32TimeoutMs_);
00128 #endif
00129
          Mutex m_clGlobalMutex;
00130
00131
        Mutex m_clReaderMutex;
          uint8_t m_u8ReadCount;
00133 };
00134
00135 } // namespace Mark3 00136 #endif
```

20.105 /home/moslevin/projects/github/m3-repo/kernel/src/public/scheduler.h File Reference

Thread scheduler function declarations.

```
#include "kerneltypes.h"
#include "thread.h"
#include "threadport.h"
#include "priomap.h"
```

Classes

class Mark3::Scheduler

Priority-based round-robin Thread scheduling, using ThreadLists for housekeeping.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.106 scheduler.h 341

20.105.1 Detailed Description

Thread scheduler function declarations.

This scheduler implements a very flexible type of scheduling, which has become the defacto industry standard when it comes to real-time operating systems. This scheduling mechanism is referred to as priority round- robin.

From the name, there are two concepts involved here:

1) Priority scheduling:

Threads are each assigned a priority, and the thread with the highest priority which is ready to run gets to execute.

2) Round-robin scheduling:

Where there are multiple ready threads at the highest-priority level, each thread in that group gets to share time, ensuring that progress is made.

The scheduler uses an array of ThreadList objects to provide the necessary housekeeping required to keep track of threads at the various priorities. As s result, the scheduler contains one ThreadList per priority, with an additional list to manage the storage of threads which are in the "stopped" state (either have been stopped, or have not been started yet).

Definition in file scheduler.h.

20.106 scheduler.h

```
00001 /*=========
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] ---
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00046 #pragma once
00047
00048 #include "kerneltypes.h"
00049 #include "thread.h
00050 #include "threadport.h"
00051 #include "priomap.h"
00052
00053 extern volatile Mark3::Thread* g_pclNext;
00054 extern Mark3::Thread*
                                     q_pclCurrent;
00055
00056 namespace Mark3
00057 {
00058 //---
00063 class Scheduler
00064 {
00065 public:
00066
00072
         static void Init();
00073
00081
         static void Schedule();
00082
         static void Add(Thread* pclThread_);
00090
00091
00100
          static void Remove(Thread* pclThread_);
00101
00114
          static bool SetScheduler(bool bEnable_);
00115
         static Thread* GetCurrentThread() { return g_pclCurrent; }
00123
00132
         static volatile Thread* GetNextThread() { return g_pclNext; }
00143
         static ThreadList* GetThreadList(PORT_PRIO_TYPE uXPriority_) {
```

```
return &m_aclPriorities[uXPriority_]; }
00152
        static ThreadList* GetStopList() { return &m_clStopList; }
00161
         static bool IsEnabled() { return m_bEnabled; }
00168
         static void QueueScheduler() { m_bQueuedSchedule = true; }
00169 private:
         static bool m_bEnabled;
00171
00172
00174
         static bool m_bQueuedSchedule;
00175
00177
         static ThreadList m_clStopList;
00178
         static ThreadList m aclPriorities[
00180
     KERNEL_NUM_PRIORITIES];
00181
00183
          static PriorityMap m_clPrioMap;
00184 };
00185 } //namespace Mark3
```

20.107 /home/moslevin/projects/github/m3-repo/kernel/src/public/thread.h File Reference

Platform independent thread class declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "threadlist.h"
#include "scheduler.h"
#include "threadport.h"
#include "quantum.h"
#include "autoalloc.h"
#include "priomap.h"
```

Classes

class Mark3::Thread

Object providing fundamental multitasking support in the kernel.

struct Mark3::FakeThread_t

If the kernel is set up to use an idle function instead of an idle thread, we use a placeholder data structure to "simulate" the effect of having an idle thread in the system.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.107.1 Detailed Description

Platform independent thread class declarations.

Threads are an atomic unit of execution, and each instance of the thread class represents an instance of a program running of the processor. The Thread is the fundmanetal user-facing object in the kernel - it is what makes multiprocessing possible from application code.

In Mark3, threads each have their own context - consisting of a stack, and all of the registers required to multiplex a processor between multiple threads.

The Thread class inherits directly from the LinkListNode class to facilitate efficient thread management using Double, or Double-Circular linked lists.

Definition in file thread.h.

20.108 thread.h 343

20.108 thread.h

```
00001 /*=======
00002
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ====
00035 #pragma once
00036
00037 #include "kerneltypes.h"
00038 #include "mark3cfg.h"
00039
00040 #include "11.h"
00041 #include "threadlist.h"
00042 #include "scheduler.h"
00043 #include "threadport.h"
00044 #include "quantum.h"
00044 #Include quantum:n
00046 #include "priomap.h"
00047
00048 namespace Mark3
00049 {
00050
00051 class Thread;
00052
00053 //---
00054 using ThreadCreateCallout = void (*)(Thread* pclThread_);
00055 using ThreadExitCallout = void (*)(Thread* pclThread_);
00056 using ThreadContextCallout = void (*) (Thread* pclThread_);
00057
00058 //---
00062 class Thread : public LinkListNode
00063 {
00064 public:
00065
          void* operator new(size_t sz, void* pv) { return (Thread*)pv; };
00066
          ~Thread();
00067
00068 #if KERNEL EXTRA CHECKS
          Thread() { m_eState = ThreadState::Invalid; }
00069
00070
00071
          bool IsInitialized() { return (m_eState != ThreadState::Invalid); }
00072 #endif
00073
00089
00090
          Init(K_WORD* pwStack_, uint16_t ul6StackSize_, PORT_PRIO_TYPE uXPriority_,
      ThreadEntryFunc pfEntryPoint_, void* pvArg_);
00091
00092 #if KERNEL_USE_AUTO_ALLOC
00093
00111
          static Thread* Init(uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_,
      ThreadEntryFunc pfEntryPoint_, void* pvArg_);
00112 #endif
00113
00121
          void Start();
00122
00129
          void Stop();
00130
00131 #if KERNEL_USE_THREADNAME
00132
00141
          void SetName(const char* szName_) { m_szName = szName_; }
00148
          const char* GetName() { return m_szName; }
00149 #endif
00150
00159
          ThreadList* GetOwner(void) { return m pclOwner; }
          ThreadList* GetCurrent(void) { return m_pclCurrent; }
00167
          PORT_PRIO_TYPE GetPriority(void) { return
00176
      m_uXPriority; }
00184
         PORT_PRIO_TYPE GetCurPriority(void) { return
      m_uXCurPriority; }
00185 #if KERNEL_USE_QUANTUM
00186
00193
          void SetQuantum(uint16_t u16Quantum_) { m_u16Quantum = u16Quantum_; }
00201
          uint16_t GetQuantum(void) { return m_u16Quantum; }
00202 #endif
00203
00211
          void SetCurrent(ThreadList* pclNewList) { m pclCurrent = pclNewList ;
00219
          void SetOwner(ThreadList* pclNewList_) { m_pclOwner = pclNewList_; }
```

```
00232
         void SetPriority(PORT_PRIO_TYPE uXPriority_);
00233
00243
          void InheritPriority(PORT_PRIO_TYPE uXPriority_);
00244
00245 #if KERNEL USE DYNAMIC THREADS
00246
00257
          void Exit();
00258 #endif
00259
00260 #if KERNEL USE SLEEP
00261
00269
          static void Sleep (uint32 t u32TimeMs );
00270
00279
          static void USleep(uint32_t u32TimeUs_);
00280 #endif
00281
00289
          static void Yield (void):
00290
00298
          void SetID(uint8_t u8ID_) { m_u8ThreadID = u8ID_; }
00306
          uint8_t GetID() { return m_u8ThreadID; }
00319
          uint16_t GetStackSlack();
00320
00321 #if KERNEL USE EVENTFLAG
00322
00329
          uint16_t GetEventFlagMask() { return m_u16FlagMask; }
00334
          void SetEventFlagMask(uint16_t u16Mask_) { m_u16FlagMask = u16Mask_; }
00340
          void SetEventFlagMode(EventFlagOperation eMode_) {
     m_eFlagMode = eMode_; }
00345
         EventFlagOperation GetEventFlagMode() { return
     m_eFlagMode; }
00346 #endif
00347
00348 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
00349
00352
         Timer* GetTimer();
00353 #endif
00354 #if KERNEL_USE_TIMEOUTS
00355
00363
         void SetExpired(bool bExpired_);
00364
00371
        bool GetExpired();
00372 #endif
00373
00374 #if KERNEL_USE_IDLE_FUNC
00375
00380
          void InitIdle();
00381 #endif
00382
00383 #if KERNEL USE EXTENDED CONTEXT
00384
00393
          void* GetExtendedContext() { return m_pvExtendedContext; }
00394
00406
         void SetExtendedContext(void* pvData_) {
      m_pvExtendedContext = pvData_; }
00407 #endif
00408
00415
          ThreadState GetState() { return m_eState; }
00423
          void SetState(ThreadState eState_) { m_eState = eState_; }
00424
00429
          K_WORD* GetStack() { return m_pwStack; }
00430
          uint16_t GetStackSize() { return m_u16StackSize; }
00435
00436
00437
          friend class ThreadPort;
00438 private:
00446
          static void ContextSwitchSWI(void);
00447
00453
          void SetPriorityBase(PORT PRIO TYPE uXPriority );
00454
00456
         K_WORD* m_pwStackTop;
00457
00459
          K_WORD* m_pwStack;
00460
          uint8_t m_u8ThreadID;
00462
00463
          PORT_PRIO_TYPE m_uXPriority;
00465
00466
00468
          PORT_PRIO_TYPE m_uXCurPriority;
00469
00471
          ThreadState m eState:
00472
00473 #if KERNEL_USE_EXTENDED_CONTEXT
00474
         void* m_pvExtendedContext;
00476 #endif
00477
00478 #if KERNEL USE THREADNAME
00479
         const char* m szName;
```

```
00481 #endif
00482
00484
         uint16_t m_u16StackSize;
00485
         ThreadList* m_pclCurrent;
00487
00488
00490
         ThreadList* m_pclOwner;
00491
00493
         ThreadEntryFunc m_pfEntryPoint;
00494
         void* m_pvArg;
00496
00497
00498 #if KERNEL_USE_QUANTUM
00499 uint16_t m_u16Quantum;
00501 #endif
00502
00503 #if KERNEL_USE_EVENTFLAG
00504
        uint16_t m_u16FlagMask;
00506
00508
        EventFlagOperation m_eFlagMode;
00509 #endif
00510
00511 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
00512
        Timer m_clTimer;
00514 #endif
00516 #if KERNEL_USE_TIMEOUTS
00517
        bool m_bExpired;
00519 #endif
00520 };
00521
00522 #if KERNEL_USE_IDLE_FUNC
00523 //--
00535 typedef struct {
00536
          LinkListNode* next;
00537
         LinkListNode* prev;
00538
         K_WORD* m_pwStackTop;
00541
00543
        K_WORD* m_pwStack;
00544
         uint8_t m_u8ThreadID;
00546
00547
00549
         PORT_PRIO_TYPE m_uXPriority;
00550
00552
         PORT_PRIO_TYPE m_uXCurPriority;
00553
00555
         ThreadState m_eState;
00556
00557 #if KERNEL_USE_EXTENDED_CONTEXT
00558
         void* m_pvExtendedContext;
00560 #endif
00561
00562 #if KERNEL_USE_THREADNAME
00563
        const char* m_szName;
00565 #endif
00567 } FakeThread_t;
00568 #endif //KERNEL_USE_IDLE_FUNC
00569 } //namespace Mark3
```

20.109 /home/moslevin/projects/github/m3-repo/kernel/src/public/threadlist.h File Reference

Thread linked-list declarations.

```
#include "kerneltypes.h"
#include "priomap.h"
#include "ll.h"
```

Classes

· class Mark3::ThreadList

This class is used for building thread-management facilities, such as schedulers, and blocking objects.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.109.1 Detailed Description

Thread linked-list declarations.

Definition in file threadlist.h.

20.110 threadlist.h

```
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00022 #pragma once
00023
00024 #include "kerneltypes.h"
00024 #include "priomap.h"
00025 #include "priomap.h"
00028 namespace Mark3
00029
00030 class Thread;
00031
00036 class ThreadList : public CircularLinkList
00038 public:
00039
          void* operator new(size_t sz, void* pv) { return (ThreadList*)pv; };
00045
          ThreadList() : m_uXPriority(0), m_pclMap(NULL)
00046
00047
00055
          void SetPriority(PORT_PRIO_TYPE uXPriority_);
00066
          void SetMapPointer(PriorityMap* pclMap_);
00067
00075
          void Add(LinkListNode* node_);
00076
          void Add(LinkListNode* node_, PriorityMap* pclMap_,
00088
      PORT_PRIO_TYPE uXPriority_);
00089
00098
          void AddPriority(LinkListNode* node_);
00099
00107
          void Remove(LinkListNode* node );
00108
00116
          Thread* HighestWaiter();
00117
00118 private:
00120
          PORT_PRIO_TYPE m_uXPriority;
00121
00123
          PriorityMap* m_pclMap;
00124 };
00125 } //namespace Mark3
```

20.111 /home/moslevin/projects/github/m3-repo/kernel/src/public/timer.h File Reference

Timer object declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
```

Classes

· class Mark3::Timer

Kernel-managed software timers.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

Macros

• #define TIMERLIST_FLAG_ONE_SHOT (0x01)

Timer is one-shot.

#define TIMERLIST_FLAG_ACTIVE (0x02)

Timer is currently active.

• #define TIMERLIST_FLAG_CALLBACK (0x04)

Timer is pending a callback.

• #define TIMERLIST_FLAG_EXPIRED (0x08)

Timer is actually expired.

#define MAX TIMER TICKS (0x7FFFFFFF)

Maximum value to set.

• #define MIN TICKS (3)

The minimum tick value to set.

Typedefs

using Mark3::TimerCallback = void(*)(Thread *pclOwner_, void *pvData_)
 This type defines the callback function type for timer events.

20.111.1 Detailed Description

Timer object declarations.

Definition in file timer.h.

20.111.2 Macro Definition Documentation

20.111.2.1 TIMERLIST_FLAG_EXPIRED

#define TIMERLIST_FLAG_EXPIRED (0x08)

Timer is actually expired.

Definition at line 36 of file timer.h.

20.112 timer.h

```
00001 /*=========
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 m0slevin, all rights reserved.
00012 See license.txt for more information
00013 ========
00021 #pragma once
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "11.h"
00026
00027 #if KERNEL_USE_TIMERS
00028 namespace Mark3
00029 {
00030 class Thread;
00031
00032 //----
00033 #define TIMERLIST_FLAG_ONE_SHOT (0x01)
00034 #define TIMERLIST_FLAG_ACTIVE (0x02)
00035 #define TIMERLIST_FLAG_CALLBACK (0x04)
00036 #define TIMERLIST_FLAG_EXPIRED (0x08)
00037
00038 //----
00038 //-----
00039 #define TIMER_INVALID_COOKIE (0x3C)
00040 #define TIMER_INIT_COOKIE (0xC3)
00041
00042 //---
00043 #define MAX_TIMER_TICKS (0x7FFFFFFF)
00044 #define TIMER_TICKS_INVALID (0x80000000)
00045 //---
00046 #if KERNEL_TIMERS_TICKLESS
00047
00048 //-
00049 /*
          Ugly macros to support a wide resolution of delays. Given a 16-bit timer @ 16MHz & 256 cycle prescaler, this gives u16...
00050
00051
          Max time, SECONDS_TO_TICKS: 68719s
00052
          Max time, MSECONDS_TO_TICKS: 6871.9s
00053
00054
          Max time, USECONDS_TO_TICKS: 6.8719s
00055
00056
           ...With a 16us tick resolution.
00057
00058
          Depending on the system frequency and timer resolution, you may want to
00059
          customize these values to suit your system more appropriately.
00060 */
00061 //---
00062 #define SECONDS_TO_TICKS(x) ((((uint32_t)x) * PORT_TIMER_FREQ))
00063 #define MSECONDS_TO_TICKS(x) (((((uint32_t)x) * (PORT_TIMER_FREQ / 100)) + 5) / 10))
00064 #define USECONDS_TO_TICKS(x) (((((uint32_t)x) * PORT_TIMER_FREQ) + 50000) / 1000000))
00065
00066 //---
00067 #define MIN_TICKS (3)
00068 //----
00069
00070 #else
00071
00073 // add time because we don't know how far in an epoch we are when a call is made.
00074 \#define SECONDS_TO_TICKS(x) (((uint32_t)(x) *1000) + 1)
00075 #define MSECONDS_TO_TICKS(x) ((uint32_t)(x + 1))
00076 #define USECONDS_TO_TICKS(x) (((uint32_t)(x + 999)) / 1000)
00077
00078 //--
00079 #define MIN_TICKS (1)
00080 //---
00081
00082 #endif // KERNEL TIMERS TICKLESS
00083 //---
00094 using TimerCallback = void (*) (Thread* pclOwner_, void* pvData_);
00095
00096 //---
00097 class TimerList;
00098 class TimerScheduler;
00099 class Quantum;
00100
00101 //----
```

```
00111 class Timer : public LinkListNode
00112 {
00113 public:
00114
         void* operator new(size_t sz, void* pv) { return (Timer*)pv; }
00115
         ~Timer() {}
00116
         Timer();
00124
00130
         void Init();
00131
         void Start(bool bRepeat_, uint32_t u32IntervalMs_, TimerCallback pfCallback_, void*
void pvData_);
00143
00158
00159
         Start (bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_,
     TimerCallback pfCallback_, void* pvData_);
00160
00169
          void Start();
00170
00177
         void Stop();
00178
00188
         void SetFlags(uint8_t u8Flags_) { m_u8Flags = u8Flags_; }
00196
         void SetCallback(TimerCallback pfCallback_) {
         void SetData(void* pvData_) { m_pvData = pvData_; }
00213
          void SetOwner(Thread* pclOwner_) { m_pclOwner = pclOwner_; }
00221
         void SetIntervalTicks(uint32_t u32Ticks_);
00222
00230
         void SetIntervalSeconds(uint32_t u32Seconds_);
00231
00239
         uint32_t GetInterval() { return m_u32Interval; }
00247
         void SetIntervalMSeconds(uint32_t u32MSeconds_);
00248
00256
         void SetIntervalUSeconds(uint32_t u32USeconds_);
00257
         void SetTolerance(uint32_t u32Ticks_);
00266
00267
00268 private:
         friend class TimerList;
00270
00271 #if KERNEL_EXTRA_CHECKS
00272
          void SetInitialized() { m_u8Initialized = TIMER_INIT_COOKIE; }
00275
00276
00281
         bool IsInitialized(void) { return (m_u8Initialized == TIMER_INIT_COOKIE); }
00282
00284
         uint8_t m_u8Initialized;
00285 #endif
00286
00288
         uint8 t m u8Flags:
00289
00291
         TimerCallback m_pfCallback;
00292
00294
         uint32_t m_u32Interval;
00295
00297
         uint32 t m u32TimeLeft;
00298
00300
         uint32_t m_u32TimerTolerance;
00301
00303
         Thread* m_pclOwner;
00304
00306
         void* m_pvData;
00307 };
00308 } //namespace Mark3
00309 #endif // KERNEL_USE_TIMERS
00310
```

20.113 /home/moslevin/projects/github/m3-repo/kernel/src/public/timerlist.h File Reference

Timer list declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "mutex.h"
```

Classes

· class Mark3::TimerList

TimerList class - a doubly-linked-list of timer objects.

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.113.1 Detailed Description

Timer list declarations.

These classes implements a linked list of timer objects attached to the global kernel timer scheduler.

Definition in file timerlist.h.

20.114 timerlist.h

```
00001
00002
00003
00004
00005
00006
00007
80000
00009 -- [Mark3 Realtime Platform]
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =
00024 #pragma once
00025
00026 #include "kerneltypes.h"
00027 #include "mark3cfg.h"
00028
00029 #include "mutex.h"
00030 #if KERNEL_USE_TIMERS
00031 namespace Mark3
00032 {
00033 class Timer;
00034
00035 //---
00039 class TimerList : public DoubleLinkList
00040 {
00041 public:
00048
          void Init();
00049
          void Add(Timer* pclListNode_);
00057
00058
00066
          void Remove(Timer* pclLinkListNode_);
00067
00074
          void Process();
00075
00076 private:
          uint32_t m_u32NextWakeup;
00078
00079
00081
          bool m bTimerActive;
00082
00083 #if KERNEL_TIMERS_THREADED
00084
          Mutex m_clMutex;
00086 #endif
00087
00088 };
00089 } //namespace Mark3
00090 #endif // KERNEL_USE_TIMERS
```

20.115 /home/moslevin/projects/github/m3-repo/kernel/src/public/timerscheduler.h File Reference

Timer scheduler declarations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "ll.h"
#include "timer.h"
#include "timerlist.h"
```

Classes

· class Mark3::TimerScheduler

"Static" Class used to interface a global TimerList with the rest of the kernel.

Namespaces

· Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.115.1 Detailed Description

Timer scheduler declarations.

Definition in file timerscheduler.h.

20.116 timerscheduler.h

```
00001 /*=======
00002
00003
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform] --
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ========
00021 #pragma once
00022
00023 #include "kerneltypes.h"
00024 #include "mark3cfg.h"
00025
00026 #include "11.h"
00027 #include "timer.h"
00028 #include "timerlist.h"
00030 #if KERNEL_USE_TIMERS
00031 namespace Mark3
00032 {
00033 //---
00038 class TimerScheduler
00039 {
00040 public:
```

20.117 /home/moslevin/projects/github/m3-repo/kernel/src/public/tracebuffer.h File Reference

Kernel trace buffer class declaration.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
```

20.117.1 Detailed Description

Kernel trace buffer class declaration.

Global kernel trace-buffer. used to instrument the kernel with lightweight encoded print statements. If something goes wrong, the tracebuffer can be examined for debugging purposes. Also, subsets of kernel trace information can be extracted and analyzed to provide information about runtime performance, thread-scheduling, and other nifty things in real-time.

Definition in file tracebuffer.h.

20.118 tracebuffer.h

```
00001 /*===
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform] --
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =====
00025 #pragma once
00026
00027 #include "kerneltypes.h"
00028 #include "mark3cfg.h"
00029
00030 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
00031 namespace Mark3
00032
00033 #define TRACE_BUFFER_SIZE (160)
00034
00035 using TraceBufferCallback_t = void (*)(uint16_t* pu16Source_, uint16_t u16Len_, bool bPingPong_);
00036
00040 class TraceBuffer
00041 {
00042 public:
00048
         static void Init();
```

```
00049
00054
          static uint16_t Increment(void) { return m_u16SyncNumber++; }
00063
          static void Write(uint16_t* pu16Data_, uint16_t u16Size_);
00064
00073
          static void SetCallback(TraceBufferCallback_t pfCallback_) { m_pfCallback = pfCallback_; }
00074 private:
         static TraceBufferCallback_t m_pfCallback;
00076
          static uint16_t
                                      m_u16SyncNumber;
00077
          static uint16_t
                                       m_u16Index;
00078
         static uint16_t
                                      m_au16Buffer[(TRACE_BUFFER_SIZE / sizeof(uint16_t))];
00079 };
08000
00081 } //namespace Mark3
00082 #endif // KERNEL_USE_DEBUG
```

20.119 /home/moslevin/projects/github/m3-repo/kernel/src/quantum.cpp File Reference

Thread Quantum Implementation for Round-Robin Scheduling.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "timerlist.h"
#include "quantum.h"
#include "kernelaware.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.119.1 Detailed Description

Thread Quantum Implementation for Round-Robin Scheduling.

Definition in file quantum.cpp.

20.120 quantum.cpp

```
00001 /*
00002
00003
00004
00005
                    1.11
00006 1
00008
00009 -- [Mark3 Realtime Platform] --
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "thread.h"
00026 #include "timerlist.h"
00027 #include "quantum.h'
00028 #include "kernelaware.h"
00029
00030 #define _CAN_HAS_DEBUG
00031 //--[Autogenerated - Do Not Modify]------
00032 #include "dbg_file_list.h"
00033 #include "buffalogger.h"
00034 #if defined(DBG_FILE)
```

```
00035 #error "Debug logging file token already defined! Bailing."
00037 #define DBG_FILE _DBG___KERNEL_QUANTUM_CPP
00038 #endif
00039 //--[End Autogenerated content]-----
00040 #include "kerneldebug.h"
00042 #if KERNEL_USE_QUANTUM
00043 namespace Mark3
00044 {
00045 namespace
00046 {
00047 volatile bool bAddQuantumTimer; // Indicates that a timer add is pending
00048 } // anonymous namespace
00049
00050 #if KERNEL_TIMERS_THREADED
00051 Thread* Quantum::m_pclTimerThread;
00052 #endif
00054 Timer Quantum::m_clQuantumTimer;
00055 bool Quantum::m_bActive;
00056 bool Quantum::m_bInTimer;
00057
00058 //---
00059 void Quantum::SetTimer(Thread* pclThread_)
00060 {
00061
          auto lQuantumCallback = [](Thread* pclThread_, void* /*pvData_*/) {
00062
           if (pclThread_->GetCurrent()->GetHead() != pclThread_->GetCurrent()->GetTail()) {
00063
                  bAddQuantumTimer = true;
                  pclThread_->GetCurrent()->PivotForward();
00064
00065
             }
00066
         };
00067
00068
          m_clQuantumTimer.SetIntervalMSeconds(pclThread_->GetQuantum());
00069
          m_clQuantumTimer.SetFlags(TIMERLIST_FLAG_ONE_SHOT);
00070
          m_clQuantumTimer.SetData(NULL);
00071
          m_clQuantumTimer.SetCallback(lQuantumCallback);
00072
          m_clQuantumTimer.SetOwner(pclThread_);
00073 }
00074
00075 //----
00076 void Quantum::AddThread(Thread* pclThread_)
00077 {
00078
          if (m_bActive
00079 #if KERNEL_USE_IDLE_FUNC
08000
             || (pclThread_ == Kernel::GetIdleThread())
00081 #endif
00082
                 ) {
00083
              return:
00084
         }
00085
00086
          // If this is called from the timer callback, queue a timer {\tt add}\dots
00087
          if (m_bInTimer) {
00088
             bAddQuantumTimer = true;
00089
              return;
00090
         }
00091
00092
          // If this isn't the only thread in the list.
00093
          if (pclThread_->GetCurrent()->GetHead() != pclThread_->GetCurrent()->GetTail()) {
00094 #if KERNEL_EXTRA_CHECKS
             m_clQuantumTimer.Init();
00095
00096 #endif
00097
              Quantum::SetTimer(pclThread_);
00098
              TimerScheduler::Add(&m_clQuantumTimer);
00099
              m_bActive = true;
00100
         }
00101 }
00102
00103 //-
00104 void Quantum::RemoveThread(void)
00105 {
00106
          if (!m_bActive) {
         ._wact
return;
}
00107
00108
00109
00110
          // Cancel the current timer
00111
          TimerScheduler::Remove(&m_clQuantumTimer);
00112
          m_bActive = false;
00113 }
00114
00115 //-
00116 void Quantum::UpdateTimer(void)
00117 {
00118
          // If we have to re-add the quantum timer (more than 2 threads at the
00119
          // high-priority level...)
00120
          if (bAddQuantumTimer) {
              // Trigger a thread yield - this will also re-schedule the
00121
```

```
// thread *and* reset the round-robin scheduler.
              Thread::Yield();
00123
00124
              bAddQuantumTimer = false;
00125
         }
00126 }
00127
00128 //--
00129 #if KERNEL_TIMERS_THREADED
00130 void Quantum::SetTimerThread(Thread* pclThread_)
00131 {
00132
          m_pclTimerThread = pclThread_;
00133 }
00134
00135 Thread* Quantum::GetTimerThread()
00136 {
00137
          return m_pclTimerThread;
00138 }
00139
00140 #endif // KERNEL_TIMERS_THREADED
00141 } //namespace Mark3
00142 #endif // KERNEL_USE_QUANTUM
```

20.121 /home/moslevin/projects/github/m3-repo/kernel/src/readerwriter.cpp File Reference

Reader-writer lock implementation.

```
#include "mark3.h"
#include "kerneldebug.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

20.121.1 Detailed Description

Reader-writer lock implementation.

Definition in file readerwriter.cpp.

20.122 readerwriter.cpp

```
00001 /
00002
00003
00004 |
00005 1
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00020 #include "mark3.h"
00021 #include "kerneldebug.h"
00022
00023 #define CAN HAS DEBUG
00024 //--[Autogenerated - Do Not Modify]-----
00025 #include "dbg_file_list.h"
00026 #include "buffalogger.h"
00027 #if defined(DBG_FILE)
00028 # error "Debug logging file token already defined! Bailing."
00029 #else
00030 # define DBG_FILE _DBG___KERNEL_READERWRITER_CPP
00031 #endif
```

```
00032 //--[End Autogenerated content]-----
00034 #if KERNEL_USE_READERWRITER
00035
00036 namespace Mark3 {
00037
00038 //----
00039 void ReaderWriterLock::Init()
00040 {
00041
         m u8ReadCount = 0;
         m_clGlobalMutex.Init();
00042
00043
         m_clReaderMutex.Init();
00044 }
00045
00046 //--
00047 void ReaderWriterLock::AcquireReader()
00048 (
00049 #if KERNEL USE TIMEOUTS
00050
         AcquireReader_i(0);
00051 #else
00052
        AcquireReader_i();
00053 #endif
00054 }
00055
00056 //-
00057 #if KERNEL_USE_TIMEOUTS
00058 bool ReaderWriterLock::AcquireReader(uint32_t u32TimeoutMs_)
00059 {
00060
         return AcquireReader_i(u32TimeoutMs_);
00061 }
00062 #endif
00063
00064 //----
00065 void ReaderWriterLock::ReleaseReader()
00066 {
         m clReaderMutex.Claim();
00067
00068
         m u8ReadCount--;
         if (m_u8ReadCount == 0) {
00069
00070
            m_clGlobalMutex.Release();
00071
00072
         m_clReaderMutex.Release();
00073 }
00074
00075 //---
00076 void ReaderWriterLock::AcquireWriter()
00077 {
00078 #if KERNEL_USE_TIMEOUTS
00079
        AcquireWriter_i(0);
00080 #else
00081
       AcquireWriter_i();
00082 #endif
00083 }
00084
00085 //----
00086 #if KERNEL USE TIMEOUTS
00087 bool ReaderWriterLock::AcquireWriter(uint32_t u32TimeoutMs_)
00089
         return AcquireWriter_i(u32TimeoutMs_);
00090 }
00091 #endif
00092
00093 //
00094 void ReaderWriterLock::ReleaseWriter()
00095 {
00096
         m_clGlobalMutex.Release();
00097 }
00098
00099 //--
00100 #if KERNEL_USE_TIMEOUTS
00101 bool ReaderWriterLock::AcquireReader_i(uint32_t u32TimeoutMs_)
00102 {
00103
          auto rc = true;
         if (!m_clReaderMutex.Claim(u32TimeoutMs_)) {
00104
00105
             return false;
00106
         }
00107
00108
         m_u8ReadCount++;
00109
         if (m_u8ReadCount == 1) {
              rc = m_clGlobalMutex.Claim(u32TimeoutMs_);
00110
00111
00112
00113
         m_clReaderMutex.Release();
00114
         return rc;
00115 }
00116 #else
00117 void ReaderWriterLock::AcquireReader_i()
00118 {
```

```
00119
         m_clReaderMutex.Claim();
00120
00121
         m_u8ReadCount++;
00122
        if (m_u8ReadCount == 1) {
         __...cadecount == 1) {
   m_clGlobalMutex.Claim();
}
00123
00124
00125
        m_clReaderMutex.Release();
00126
00127 }
00128 #endif
00129
00130 //---
00131 #if KERNEL_USE_TIMEOUTS
00132 bool ReaderWriterLock::AcquireWriter_i(uint32_t u32TimeoutMs_)
00134
          return m_clGlobalMutex.Claim(u32TimeoutMs_);
00135 }
00136 #else
00137 void ReaderWriterLock::AcquireWriter_i()
00139
          m_clGlobalmutex.Claim();
00140 }
00141 #endif
00142 \} // namespace Mark3
00143
00144 #endif // KERNEL_USE_READERWRITER
00145
```

20.123 /home/moslevin/projects/github/m3-repo/kernel/src/scheduler.cpp File Reference

Strict-Priority + Round-Robin thread scheduler implementation.

```
#include "kerneltypes.h"
#include "ll.h"
#include "scheduler.h"
#include "thread.h"
#include "threadport.h"
#include "kernel.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.123.1 Detailed Description

Strict-Priority + Round-Robin thread scheduler implementation.

Definition in file scheduler.cpp.

20.124 scheduler.cpp

```
00001 /*=======
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 =======
00022 #include "kerneltypes.h"
00022 #include "Kernettypes.n
00023 #include "ll.h"
00024 #include "scheduler.h"
00025 #include "thread.h"
00026 #include "threadport.h"
00027 #include "kernel.h"
00028
00029 #define _CAN_HAS_DEBUG
00030 //--[Autogenerated - Do Not Modify]-----
00031 #include "dbg_file_list.h"
00032 #include "buffalogger.h"
00033 #if defined(DBG FILE)
00034 #error "Debug logging file token already defined! Bailing."
00035 #else
00036 #define DBG_FILE _DBG___KERNEL_SCHEDULER_CPP
00037 #endif
00038 //--[End Autogenerated content]------00039 #include "kerneldebug.h"
00040
00041 volatile Mark3::Thread* g_pclNext;
00042 Mark3::Thread*
                                 g_pclCurrent;
00043
00044 namespace Mark3 {
00045
00046 bool Scheduler::m bEnabled;
00047 bool Scheduler::m_bQueuedSchedule;
00048 ThreadList Scheduler::m_clStopList;
00049 ThreadList Scheduler::m_aclPriorities[
      KERNEL_NUM_PRIORITIES];
00050 PriorityMap Scheduler::m_clPrioMap;
00051
00052 //-
00053 void Scheduler::Init()
00054 {
00055
           for (int i = 0; i < KERNEL_NUM_PRIORITIES; i++) {</pre>
            m_aclPriorities[i].SetPriority(i);
00056
00057
               m_aclPriorities[i].SetMapPointer(&
      m_clPrioMap);
00058
00059 }
00060
00061 //---
00062 void Scheduler::Schedule()
00063 {
00064
           auto uXPrio = m_clPrioMap.HighestPriority();
00065
00066 #if KERNEL_USE_IDLE_FUNC
00067
           if (uXPrio == 0) {
               // There aren't any active threads at all - set g_pclNext to IDLE
g_pclNext = Kernel::GetIdleThread();
00068
00069
00070
           } else
00071 #endif
00072
00073
               if (uXPrio == 0) {
00074
                    Kernel::Panic(PANIC_NO_READY_THREADS);
00075
               // Priorities are one-indexed
00076
               uXPrio--;
00078
00079
               \ensuremath{//} Get the thread node at this priority.
08000
               g_pclNext = static_cast<Thread*>(m_aclPriorities[uXPrio].
      GetHead());
00081
           KERNEL_TRACE_1("Next Thread: %d\n", static_cast<uint16_t>(g_pclNext->
00082
       GetID());
00083 }
00084
00085 //
00086 void Scheduler::Add(Thread* pclThread_)
00087 {
00088
           m_aclPriorities[pclThread_->GetPriority()].Add(pclThread_);
```

```
00089 }
00090
00091 //--
00092 void Scheduler::Remove(Thread* pclThread_)
00093 {
00094
        m_aclPriorities[pclThread_->GetPriority()].Remove(pclThread_);
00096
00097 //-
00098 bool Scheduler::SetScheduler(bool bEnable_)
00099 {
00100
        bool bRet:
00101
        CS_ENTER();
00102
                  = m_bEnabled;
00103
00104
00105
        m_bEnabled = bEnable_;
}
CS_EXIT();
return bRet;
00109
00110
00111
00112 }
00113 } //namespace Mark3
```

20.125 /home/moslevin/projects/github/m3-repo/kernel/src/thread.cpp File Reference

Platform-Independent thread class Definition.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "thread.h"
#include "scheduler.h"
#include "kernelswi.h"
#include "timerlist.h"
#include "ksemaphore.h"
#include "quantum.h"
#include "priomap.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

Namespaces

• Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.125.1 Detailed Description

Platform-Independent thread class Definition.

Definition in file thread.cpp.

20.126 thread.cpp

```
00001 /*=======
00003
00004
00005
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ========
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "thread.h"
00025 #include "scheduler.h"
00026 #include "scheduler.h"
00027 #include "kernelswi.h"
00028 #include "timerlist.h"
00029 #include "ksemaphore.h"
00030 #include "quantum.h"
00031 #include "kernel.h"
00032 #include "priomap.h"
00033
00034 #define CAN HAS DEBUG
00035 //--[Autogenerated - Do Not Modify]-----
00036 #include "dbg_file_list.h"
00037 #include "buffalogger.h"
00038 #if defined(DBG_FILE) 00039 #error "Debug logging file token already defined! Bailing."
00040 #else
00041 #define DBG_FILE _DBG___KERNEL_THREAD_CPP
00042 #endif
00043 //--[End Autogenerated content]-----
00044
00045 #include "kerneldebug.h"
00046 namespace Mark3
00047 {
00048 //---
00049 Thread::~Thread()
00050 {
00051
           // On destruction of a thread located on a stack,
           // ensure that the thread is either stopped, or exited.
00052
          // If the thread is stopped, move it to the exit state.
00053
           // If not in the exit state, kernel panic -- it's catastrophic to have
00055
           // running threads on stack suddenly disappear.
00056
           if (m_eState == ThreadState::Stop) {
00057
               CS_ENTER();
00058
               m_pclCurrent->Remove(this);
              m_pclCurrent = 0;
m_pclOwner = 0;
00059
00060
00061
               m_eState
                             = ThreadState::Exit;
00062
               CS_EXIT();
00063
          } else if (m_eState != ThreadState::Exit) {
00064 #if KERNEL_AWARE_SIMULATION
              KernelAware::Trace(0, 0, m_u8ThreadID, static_cast<uint16_t>(
00065
      m_eState));
00066 #endif
00067
               Kernel::Panic(PANIC_RUNNING_THREAD_DESCOPED);
00068
00069 }
00070
00071 //-
00072 void Thread::Init(
00073
           K_WORD* pwStack_, uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_,
      ThreadEntryFunc pfEntryPoint_, void* pvArg_)
00074 {
00075
           static uint8 t u8ThreadID = 0;
00076
00077
           KERNEL_ASSERT (pwStack_);
00078
           KERNEL_ASSERT (pfEntryPoint_);
00079
08000
          ClearNode();
00081
           m_u8ThreadID = u8ThreadID++;
00082
00083 #if KERNEL_USE_IDLE_FUNC
00084
           if (u8ThreadID == 255)
00085
              u8ThreadID = 0;
00086
00087 #endif
00088
00089
           KERNEL_TRACE_1("Stack Size: %d", u16StackSize_);
00090
          KERNEL_TRACE_1("Thread Pri: %d", uXPriority_);
```

20.126 thread.cpp 361

```
KERNEL_TRACE_1("Thread Id: %d", m_u8ThreadID);
KERNEL_TRACE_1("Entrypoint: %x", static_cast<K_ADDR>(pfEntryPoint_));
00092
00093
00094
          // Initialize the thread parameters to their initial values.
00095
          m_pwStack = pwStack_;
m_pwStackTop = TOP_OF_STACK(pwStack_, u16StackSize_);
00096
00097
00098
          m_u16StackSize = u16StackSize_;
00099
00100 #if KERNEL_USE_QUANTUM
         m_u16Quantum = THREAD_QUANTUM_DEFAULT;
00101
00102 #endif
00103
          m_uXPriority
00104
                          = uXPriority_;
00105
          m_uXCurPriority = m_uXPriority;
         m_pfEntryPoint = pfEntryPoint_;
m_pvArg = pvArg_;
00106
00107
00108
00109 #if KERNEL_USE_THREADNAME
00110
         m_szName = NULL;
00111 #endif
00112 #if KERNEL_USE_TIMERS
00113
         m_clTimer.Init();
00114 #endif
00115
00116
           // Call CPU-specific stack initialization
00117
          ThreadPort::InitStack(this);
00118
00119
          // Add to the global "stop" list.
          CS_ENTER();
00120
          m_pclOwner
                       = Scheduler::GetThreadList(
00121
     m_uXPriority);
00122
        m_pclCurrent = Scheduler::GetStopList();
00123
          m_eState
                       = ThreadState::Stop;
          m_pclCurrent->Add(this);
00124
          CS_EXIT();
00125
00126
00127 #if KERNEL_USE_THREAD_CALLOUTS
00128
      ThreadCreateCallout pfCallout = Kernel::GetThreadCreateCallout();
00129
          if (pfCallout != nullptr) {
00130
              pfCallout(this);
00131
00132 #endif
00133 }
00134
00135 #if KERNEL_USE_AUTO_ALLOC
00136 //----
00137 Thread* Thread::Init(uint16_t u16StackSize_, PORT_PRIO_TYPE uXPriority_,
      ThreadEntryFunc pfEntryPoint_, void* pvArg_)
00138 {
00139
          auto* pclNew = AutoAlloc::NewThread();
00140
          auto* pwStack = static_cast<K_WORD*>(AutoAlloc::NewRawData(u16StackSize_));
00141
          pclNew->Init(pwStack, u16StackSize_, uXPriority_, pfEntryPoint_, pvArg_);
00142
          return pclNew;
00143 }
00144 #endif
00146 //---
00147 void Thread::Start(void)
00148 {
00149 #if KERNEL_EXTRA_CHECKS
00150
        KERNEL ASSERT(IsInitialized());
00151 #endif
00152
00153
          // Remove the thread from the scheduler's "stopped" list, and add it
         // to the scheduler's ready list at the proper priority.
KERNEL_TRACE_1("Starting Thread %d", m_u8ThreadID);
00154
00155
00156
00157
          CS_ENTER();
          Scheduler::GetStopList()->Remove(this);
00158
00159
          Scheduler::Add(this);
00160
          m_pclOwner
                       = Scheduler::GetThreadList(
     m_uXPriority);
00161
         m_pclCurrent = m_pclOwner;
00162
                       = ThreadState::Ready;
          m eState
00163
00164 #if KERNEL_USE_QUANTUM
00166
              if (GetCurPriority() >= Scheduler::GetCurrentThread()->
     GetCurPriority()) {
00167 // Deal with the thread Quantum
00168 #if KERNEL_TIMERS_THREADED
00169
                  if (Quantum::GetTimerThread() != this) {
00170 #endif
00171
                       Quantum::RemoveThread();
00172
                       Quantum::AddThread(this);
00173 #if KERNEL_TIMERS_THREADED
```

```
00174
                  }
00175 #endif
00176
              }
00177
00178 #endif
00179
          if (Kernel::IsStarted()) {
00180
00181
               if (GetCurPriority() >= Scheduler::GetCurrentThread()->
     GetCurPriority()) {
00182
                  Thread::Yield();
              }
00183
00184
00185
          CS_EXIT();
00186 }
00187
00188 //----
00189 void Thread::Stop()
00190 {
00191 #if KERNEL_EXTRA_CHECKS
00192
         KERNEL_ASSERT(IsInitialized());
00193 #endif
00194
00195
          auto bReschedule = false;
00196
          if (m eState == ThreadState::Stop) {
00197
              return;
00198
00199
00200
          CS_ENTER();
00201
00202
          // If a thread is attempting to stop itself, ensure we call the scheduler
00203
          if (this == Scheduler::GetCurrentThread()) {
00204
              bReschedule = true;
00205
00206
00207
          //\ \mbox{Add} this thread to the stop-list (removing it from active scheduling)
          // Remove the thread from scheduling
if (m_eState == ThreadState::Ready) {
00208
00209
              Scheduler::Remove(this);
00210
00211
          } else if (m_eState == ThreadState::Blocked) {
00212
             m_pclCurrent->Remove(this);
00213
00214
          m_pclOwner = Scheduler::GetStopList();
00215
          m_pclCurrent = m_pclOwner;
00216
00217
          m_pclOwner->Add(this);
00218
          m_eState = ThreadState::Stop;
00219
00220 #if KERNEL_USE_TIMERS
         // Just to be safe - attempt to remove the thread's timer
// from the timer-scheduler (does no harm if it isn't
00221
00222
          // in the timer-list)
00223
00224
         TimerScheduler::Remove(&m_clTimer);
00225 #endif
00226
          CS_EXIT();
00227
00228
00229
          if (bReschedule) {
00230
              Thread::Yield();
00231
00232 }
00233
00234 #if KERNEL_USE_DYNAMIC_THREADS
00235 //-
00236 void Thread::Exit()
00237 (
00238 #if KERNEL_EXTRA_CHECKS
00239
         KERNEL_ASSERT(IsInitialized());
00240 #endif
00241
         bool bReschedule = false;
00242
00243
          KERNEL_TRACE_1("Exit Thread %d", m_u8ThreadID);
00244
          if (m_eState == ThreadState::Exit) {
             return;
00245
00246
          }
00247
00248
          CS ENTER();
00249
00250
          // If this thread is the actively-running thread, make sure we run the
          // scheduler again.
if (this == Scheduler::GetCurrentThread()) {
00251
00252
00253
              bReschedule = true;
00254
00255
00256
          // Remove the thread from scheduling
00257
          if (m_eState == ThreadState::Ready) {
              Scheduler::Remove(this);
00258
00259
          } else if ((m_eState == ThreadState::Blocked) || (m_eState == ThreadState::Stop)) {
```

20.126 thread.cpp 363

```
00260
              m_pclCurrent->Remove(this);
00261
00262
00263
          m_pclCurrent = 0;
00264
          m_pclOwner = 0;
00265
                        = ThreadState::Exit;
          m eState
00266
00267
          // We've removed the thread from scheduling, but interrupts might
00268
          // trigger checks against this thread's currently priority before
00269
          \ensuremath{//} we get around to scheduling new threads. As a result, set the
00270
          \ensuremath{//} priority to idle to ensure that we always wind up scheduling
00271
          // new threads.
00272
          m_uXCurPriority = 0;
00273
          m_uXPriority
00274
00275 #if KERNEL_USE_TIMERS
          // Just to be safe - attempt to remove the thread's timer
// from the timer-scheduler (does no harm if it isn't
00276
00277
          // in the timer-list)
00279
          TimerScheduler::Remove(&m_clTimer);
00280 #endif
00281
          CS_EXIT();
00282
00283 #if KERNEL_USE_THREAD_CALLOUTS
00284
          ThreadExitCallout pfCallout = Kernel::GetThreadExitCallout();
          if (pfCallout != nullptr) {
00286
              pfCallout(this);
00287
00288 #endif
00289
00290
          if (bReschedule) {
               // Choose a new "next" thread if we must
00291
00292
               Thread::Yield();
00293
00294 }
00295 #endif
00296
00297 #if KERNEL_USE_SLEEP
00298 //-
00299 void Thread::Sleep(uint32_t u32TimeMs_)
00300 {
00301
          Semaphore clSemaphore;
          auto* pclTimer = g_pclCurrent->GetTimer();
auto lTimerCallback = [](Thread* /*pclOwner*/, void* pvData_) {
00302
00303
00304
              auto* pclSemaphore = static_cast<Semaphore*>(pvData_);
00305
              pclSemaphore->Post();
00306
00307
00308
          \ensuremath{//} Create a semaphore that this thread will block on
00309
          clSemaphore.Init(0, 1);
00310
00311
          // Create a one-shot timer that will call a callback that posts the
00312
          // semaphore, waking our thread.
00313
          pclTimer->Init();
          pclTimer->SetIntervalMSeconds(u32TimeMs);
00314
00315
          pclTimer->SetCallback(lTimerCallback);
00316
          pclTimer->SetData((void*)&clSemaphore);
00317
          pclTimer->SetFlags(TIMERLIST_FLAG_ONE_SHOT);
00318
00319
           // Add the new timer to the timer scheduler, and block the thread
          TimerScheduler::Add(pclTimer);
00320
00321
          clSemaphore.Pend();
00322 }
00323
00324 //--
00325 void Thread::USleep(uint32_t u32TimeUs_)
00326 {
00327
          Semaphore clSemaphore;
          auto* polTimer = g_pclCurrent->GetTimer();
auto lTimerCallback = [](Thread* /*pclOwner*/, void* pvData_) {
00328
00329
00330
            auto* pclSemaphore = static_cast<Semaphore*>(pvData_);
00331
              pclSemaphore->Post();
00332
          };
00333
00334
          \ensuremath{//} Create a semaphore that this thread will block on
00335
          clSemaphore.Init(0, 1);
00336
00337
           // Create a one-shot timer that will call a callback that posts the
00338
          // semaphore, waking our thread.
          pclTimer->Init();
00339
00340
          pclTimer->SetIntervalUSeconds(u32TimeUs);
00341
          pclTimer->SetCallback(lTimerCallback);
00342
          pclTimer->SetData((void*)&clSemaphore);
00343
          pclTimer->SetFlags(TIMERLIST_FLAG_ONE_SHOT);
00344
           // Add the new timer to the timer scheduler, and block the thread
00345
00346
          TimerScheduler::Add(pclTimer);
```

```
clSemaphore.Pend();
00348 }
00349 #endif // KERNEL_USE_SLEEP
00350
00351 //---
00352 uint16_t Thread::GetStackSlack()
00354 #if KERNEL_EXTRA_CHECKS
00355
          KERNEL_ASSERT(IsInitialized());
00356 #endif
00357
00358
          K ADDR wBottom = 0;
          auto wTop = static_cast<K_ADDR>(m_u16StackSize - 1);
auto wMid = ((wTop + wBottom) + 1) / 2;
00359
00360
00361
00362
          CS ENTER();
00363
          // Logarithmic bisection - find the point where the contents of the // stack go from 0xFF's to non 0xFF. Not Definitive, but accurate enough
00364
00365
00366
          while ((wTop - wBottom) > 1) {
00367 #if STACK_GROWS_DOWN
00368
               if (m_pwStack[wMid] != (K_WORD)(-1))
00369 #else
               if (m_pwStack[wMid] == (K_WORD)(-1))
00370
00371 #endif
00372
               {
00374
                  wTop = wMid;
00375
                wBottom = wMid;
00376
00377
00378
              wMid = (wTop + wBottom + 1) / 2;
00379
         }
00380
00381
          CS_EXIT();
00382
00383
          return wMid;
00384 }
00385
00386 //--
00387 void Thread::Yield()
00388 {
00389
          CS_ENTER();
00390
00391
          // Run the scheduler
00392
          if (Scheduler::IsEnabled()) {
00393
               Scheduler::Schedule();
00394
              // Only switch contexts if the new task is different than the old task
if (Scheduler::GetCurrentThread() !=
00395
00396
     Scheduler::GetNextThread()) {
00397 #if KERNEL_USE_QUANTUM
00398 #if KERNEL_TIMERS_THREADED
00399
                   if (Quantum::GetTimerThread() != Scheduler::GetNextThread()) {
00400 #endif
00401
                       \ensuremath{//} new thread scheduled. Stop current quantum timer (if it exists),
00402
                        // and restart it for the new thread (if required).
00403
                        Quantum::RemoveThread();
00404
                        Quantum::AddThread((Thread*)
      Scheduler::GetNextThread());
00405 #if KERNEL_TIMERS_THREADED
00406
                   }
00407 #endif
00408 #endif
00409
                   Thread::ContextSwitchSWI();
00410
             }
00411
          } else {
             Scheduler::QueueScheduler();
00412
          }
00413
00414
          CS_EXIT();
00415
00416 }
00417
00418 //---
00419 void Thread::SetPriorityBase(PORT_PRIO_TYPE /*uXPriority_*/)
00420 {
00421 #if KERNEL_EXTRA_CHECKS
00422
          KERNEL_ASSERT(IsInitialized());
00423 #endif
00424
00425
          GetCurrent() -> Remove(this):
00426
00427
          SetCurrent(Scheduler::GetThreadList(
      m_uXPriority));
00428
00429
          GetCurrent()->Add(this);
00430 }
00431
```

20.126 thread.cpp 365

```
00432 //-
00433 void Thread::SetPriority(PORT_PRIO_TYPE uXPriority_)
00434 (
00435 #if KERNEL_EXTRA_CHECKS
00436
         KERNEL ASSERT(IsInitialized());
00437 #endif
00439
          auto bSchedule = false;
00440
00441
          CS_ENTER();
00442
          // If this is the currently running thread, it's a good idea to reschedule
          // If this is the current framing survey.
// Or, if the new priority is a higher priority than the current thread's.
if ((g_pclCurrent == this) || (uXPriority_ > g_pclCurrent->GetPriority())) {
00443
00444
00445
00446
00447
          Scheduler::Remove(this);
00448
          CS_EXIT();
00449
00450
          m_uXCurPriority = uXPriority_;
00451
          m_uXPriority = uXPriority_;
00452
00453
          CS_ENTER();
          Scheduler::Add(this);
00454
00455
          CS EXIT();
00456
00457
         if (bSchedule) {
          if (Scheduler::IsEnabled()) {
00458
00459
                   CS_ENTER();
00460
                   Scheduler::Schedule();
00461 #if KERNEL_USE_QUANTUM
00462 #if KERNEL_TIMERS_THREADED
00463
                   if (Quantum::GetTimerThread() != Scheduler::GetNextThread()) {
00464 #endif
00465
                       \ensuremath{//} new thread scheduled. Stop current quantum timer (if it exists),
00466
                       \ensuremath{//} and restart it for the new thread (if required).
00467
                       Quantum::RemoveThread();
                       Quantum::AddThread((Thread*)
00468
     Scheduler::GetNextThread());
00469 #if KERNEL_TIMERS_THREADED
00470
00471 #endif
00472 #endif
00473
                  CS EXIT():
00474
                  Thread::ContextSwitchSWI();
00475
              } else {
00476
                  Scheduler::QueueScheduler();
00477
              }
00478
         }
00479 }
00480
00482 void Thread::InheritPriority(PORT_PRIO_TYPE uXPriority_)
00483 {
00484 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00485
00486 #endif
00488
          SetOwner(Scheduler::GetThreadList(uXPriority_));
00489
         m_uXCurPriority = uXPriority_;
00490 }
00491
00492 //-
00493 void Thread::ContextSwitchSWI()
00494 {
00495
          // Call the context switch interrupt if the scheduler is enabled.
00496
          if (static_cast<int>(Scheduler::IsEnabled()) == 1) {
              KERNEL_TRACE_1("Context switch to Thread %d",
00497
     Scheduler::GetNextThread()->GetID());
00498 #if KERNEL_USE_STACK_GUARD
00499 #if KERNEL_USE_IDLE_FUNC
00500
              if ((g_pclCurrent != nullptr) && (g_pclCurrent->GetID() != 255)) {
00501 #endif
00502
                   if (g_pclCurrent->GetStackSlack() <= Kernel::GetStackGuardThreshold()) {</pre>
00503 #if KERNEL_AWARE_SIMULATION
                       KernelAware::Trace(DBG_FILE, __LINE__, g_pclCurrent->
00504
     GetID(), g_pclCurrent->GetStackSlack());
00505 #endif
00506
                       Kernel::Panic(PANIC_STACK_SLACK_VIOLATED);
00507
00508 #if KERNEL_USE_IDLE_FUNC
00509
              }
00510 #endif
00511 #endif
00512
00513 #if KERNEL_USE_THREAD_CALLOUTS
              ThreadContextCallout pfCallout = Kernel::GetThreadContextSwitchCallout
00514
      ();
```

```
if (pfCallout != nullptr) {
00516
                   pfCallout(g_pclCurrent);
00517
               }
00518 #endif
               KernelSWI::Trigger();
00519
00520
00521 }
00522
00523 #if KERNEL_USE_TIMEOUTS || KERNEL_USE_SLEEP
00524 //---
00525 Timer* Thread::GetTimer()
00526 {
00527 #if KERNEL_EXTRA_CHECKS
00528
          KERNEL_ASSERT(IsInitialized());
00529 #endif
00530
00531
          return &m clTimer:
00532 }
00533 #endif
00534 #if KERNEL_USE_TIMEOUTS
00535 //--
00536 void Thread::SetExpired(bool bExpired_)
00537 {
00538 #if KERNEL_EXTRA_CHECKS
00539
          KERNEL_ASSERT(IsInitialized());
00540 #endif
00541
00542
          m_bExpired = bExpired_;
00543 }
00544
00545 //---
00546 bool Thread::GetExpired()
00547 {
00548 #if KERNEL_EXTRA_CHECKS
00549
         KERNEL_ASSERT(IsInitialized());
00550 #endif
00551
          return m_bExpired;
00553 }
00554 #endif
00555
00556 #if KERNEL_USE_IDLE_FUNC
00557 //--
00558 void Thread::InitIdle(void)
00559 {
00560
           m_eState
                            = ThreadState::Ready;
00561
         ClearNode();
00562
00563 m_uXPriority = 0;

00564 m_uXCurPriority = 0;

00565 m_pfEntryPoint = 0;

00566 m_pvArg = 0;
                           = 255;
00567
          m_u8ThreadID
00568 #if KERNEL_USE_THREADNAME
00569 m_szName = "IDLE";
00570 #endif
00571 }
00572 #endif
00573 } //namespace Mark3
00574
```

20.127 /home/moslevin/projects/github/m3-repo/kernel/src/threadlist.cpp File Reference

Thread linked-list definitions.

```
#include "kerneltypes.h"
#include "ll.h"
#include "threadlist.h"
#include "thread.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.128 threadlist.cpp 367

Namespaces

Mark3

Class providing the software-interrupt required for context-switching in the kernel.

20.127.1 Detailed Description

Thread linked-list definitions.

Definition in file threadlist.cpp.

20.128 threadlist.cpp

```
00001 /*=
00002
00003
00004
00005
00006
00007
00008
00009 -- [Mark3 Realtime Platform]
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ========
00022 #include "kerneltypes.h"
00023 #include "11.h"
00024 #include "threadlist.h"
00025 #include "thread.h"
00026
00027 #define _CAN_HAS_DEBUG
00028 //--[Autogenerated - Do Not Modify]-----
00029 #include "dbg_file_list.h"
00030 #include "buffalogger.h"
00031 #if defined(DBG_FILE)
00032 #error "Debug logging file token already defined! Bailing."
00033 #else
00034 #define DBG_FILE _DBG___KERNEL_THREADLIST_CPP
00035 #endif
00036 //--[End Autogenerated content]---
00037 #include "kerneldebug.h'
00038 namespace Mark3
00039 {
00040 //--
00041 void ThreadList::SetPriority(PORT_PRIO_TYPE uXPriority_)
00042 {
00043
          m_uXPriority = uXPriority_;
00044 }
00045
00046 //--
00047 void ThreadList::SetMapPointer(PriorityMap* pclMap_)
00048 {
00049
          m_pclMap = pclMap_;
00050 }
00051
00052 //--
00053 void ThreadList::Add(LinkListNode* node_)
00054 {
00055
           CircularLinkList::Add(node_);
00056
          CircularLinkList::PivotForward();
00057
00058
           // \ensuremath{\text{We'}}\xspace \ensuremath{\text{ve}} specified a bitmap for this threadlist
00059
          if (m_pclMap != nullptr) {
00060
               \ensuremath{//} Set the flag for this priority level
00061
               m_pclMap->Set(m_uXPriority);
00062
          }
00063 }
00064
00065 //---
00066 void ThreadList::AddPriority(LinkListNode* node_)
00067 {
00068
          auto* pclCurr = static_cast<Thread*>(GetHead());
00069
          if (pclCurr == nullptr) {
```

```
Add (node_);
00071
00072
00073
          auto uXHeadPri = pclCurr->GetCurPriority();
00074
00075
          auto* pclTail = static_cast<Thread*>(GetTail());
          auto* pclNode = static_cast<Thread*>(node_);
00077
00078
          // Set the threadlist's priority level, flag pointer, and then add the
          // thread to the threadlist
00079
          auto uXPriority = pclNode->GetCurPriority();
00080
00081
          do {
00082
              if (uXPriority > pclCurr->GetCurPriority()) {
00083
00084
              pclCurr = static_cast<Thread*>(pclCurr->GetNext());
00085
00086
         } while (pclCurr != pclTail);
00087
00088
          // Insert pclNode before pclCurr in the linked list.
00089
          InsertNodeBefore(pclNode, pclCurr);
00090
00091
         // If the priority is greater than current head, reset
00092
          // the head pointer.
         if (uXPriority > uXHeadPri) {
00093
             m_pclHead = pclNode;
m_pclTail = m_pclHead->prev;
00094
00096
         } else if (pclNode->GetNext() == m_pclHead) {
            m_pclTail = pclNode;
00097
00098
00099 }
00100
00101 //-
00102 void ThreadList::Add(LinkListNode* node_, PriorityMap* pclMap_,
      PORT_PRIO_TYPE uXPriority_)
00103 {
          // Set the threadlist's priority level, flag pointer, and then add the
00104
00105
          // thread to the threadlist
         SetPriority(uXPriority_);
00107
          SetMapPointer(pclMap_);
00108
         Add (node_);
00109 }
00110
00111 //--
00112 void ThreadList::Remove(LinkListNode* node_)
00113 {
00114
          // Remove the thread from the list
00115
         CircularLinkList::Remove(node_);
00116
00117
         // If the list is empty...
         if ((m_pclHead == nullptr) && (m_pclMap != nullptr)) {
00118
              // Clear the bit in the bitmap at this priority level
00119
00120
              m_pclMap->Clear(m_uXPriority);
00121
00122 }
00123
00124 //-
00125 Thread* ThreadList::HighestWaiter()
00126 {
00127
          return static_cast<Thread*>(GetHead());
00128 }
00129 } //namespace Mark3
```

20.129 /home/moslevin/projects/github/m3-repo/kernel/src/timer.cpp File Reference

Timer implementations.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timer.h"
#include "timerlist.h"
#include "timerscheduler.h"
#include "kerneltimer.h"
#include "threadport.h"
#include "quantum.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
```

20.130 timer.cpp 369

```
#include "kerneldebug.h"
```

20.129.1 Detailed Description

Timer implementations.

Definition in file timer.cpp.

20.130 timer.cpp

```
00001 /*=
00002
00003
                 | | | | |
| | | | |
00004
00005 1
00006 1
00007
00008
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ===
00022 #include "kerneltypes.h"
00023 #include "mark3cfg.h"
00024
00025 #include "timer.h"
00026 #include "timerlist.h"
00027 #include "timerscheduler.h"
00028 #include "kerneltimer.h"
00029 #include "threadport.h"
00030 #include "quantum.h"
00031
00032 #define _CAN_HAS_DEBUG
00033 //--[Autogenerated - Do Not Modify]-----
00034 #include "dbg_file_list.h"
00035 #include "buffalogger.h"
00036 #if defined(DBG_FILE)
00037 #error "Debug logging file token already defined! Bailing."
00038 #else
00039 #define DBG_FILE _DBG___KERNEL_TIMER_CPP
00040 #endif
00041 //--[End Autogenerated content]-----
00042
00043 #include "kerneldebug.h"
00044
00045 #if KERNEL_USE_TIMERS
00046 namespace Mark3
00047 {
00048 TimerList TimerScheduler::m_clTimerList;
00049
00050 //----
00051 Timer::Timer()
00052 {
00053 #if KERNEL_EXTRA_CHECKS
00054
          m_u8Initialized = TIMER_INVALID_COOKIE;
00055 #endif
00056
        m_u8Flags = 0;
00057 }
00058
00059 //---
00060 void Timer::Init()
00061 {
00062 #if KERNEL_EXTRA_CHECKS
        if (IsInitialized()) {
00063
               KERNEL_ASSERT((m_u8Flags & TIMERLIST_FLAG_ACTIVE) == 0);
00064
00065
00066 #endif
00067
00068
          ClearNode();
00069
          m_u32Interval
          m_u32TimerTolerance = 0;
00070
00071
          m_u32TimeLeft = 0;
00072
          m_u8Flags
```

370 File Documentation

```
00074 #if KERNEL_EXTRA_CHECKS
00075
         SetInitialized();
00076 #endif
00077 }
00078
00079 //---
00080 void Timer::Start(bool bRepeat_, uint32_t u32IntervalMs_,
      TimerCallback pfCallback_, void* pvData_)
00081 {
00082 #if KERNEL_EXTRA_CHECKS
        KERNEL_ASSERT(IsInitialized());
00083
00084 #endif
00085
00086
          if ((m_u8Flags & TIMERLIST_FLAG_ACTIVE) != 0) {
             return;
00087
         }
00088
00089
00090
          SetIntervalMSeconds(u32IntervalMs_);
          m_u32TimerTolerance = 0;
m_pfCallback = pfCallback_;
00091
00092
00093
          m_pvData
                              = pvData_;
00094
         if (!bRepeat_) {
    m_u8Flags = TIMERLIST_FLAG_ONE_SHOT;
00095
00096
00097
          } else {
00098
             m_u8Flags = 0;
          }
00099
00100
00101
          Start();
00102 }
00103
00104 //---
00105 void Timer::Start(
     bool bRepeat_, uint32_t u32IntervalMs_, uint32_t u32ToleranceMs_, TimerCallback pfCallback_, void* pvData_)
00106
00107 {
00108 #if KERNEL_EXTRA_CHECKS
00109
         KERNEL_ASSERT(IsInitialized());
00110 #endif
00111
          if ((m_u8Flags & TIMERLIST_FLAG_ACTIVE) != 0) {
00112
            return;
00113
00114
         }
00115
00116
          m_u32TimerTolerance = MSECONDS_TO_TICKS(u32ToleranceMs_);
00117
         Start(bRepeat_, u32IntervalMs_, pfCallback_, pvData_);
00118 }
00119
00120 //--
00121 void Timer::Start()
00122 {
00123 #if KERNEL_EXTRA_CHECKS
00124
         KERNEL_ASSERT(IsInitialized());
00125 #endif
00126
          if ((m_u8Flags & TIMERLIST_FLAG_ACTIVE) != 0) {
00128
            return;
00129
         }
00130
          m pclOwner = Scheduler::GetCurrentThread():
00131
00132
          TimerScheduler::Add(this);
00133 }
00134
00135 //---
00136 void Timer::Stop()
00137 {
00138 #if KERNEL_EXTRA_CHECKS
00139
        KERNEL_ASSERT(IsInitialized());
00140 #endif
00141
00142
          if ((m_u8Flags & TIMERLIST_FLAG_ACTIVE) == 0) {
00143
                 return;
00144
00145
          TimerScheduler::Remove(this);
00146 }
00147
00148 //---
00149 void Timer::SetIntervalTicks(uint32_t u32Ticks_)
00150 {
00151 #if KERNEL_EXTRA_CHECKS
         KERNEL_ASSERT(IsInitialized());
00152
00153 #endif
00154
00155
          m_u32Interval = u32Ticks_;
00156 }
00157
```

```
00161 void Timer::SetIntervalSeconds(uint32_t u32Seconds_)
00162 {
00163 #if KERNEL_EXTRA_CHECKS
00164
          KERNEL ASSERT(IsInitialized());
00165 #endif
00167
          m_u32Interval = SECONDS_TO_TICKS(u32Seconds_);
00168 }
00169
00170 //--
00171 void Timer::SetIntervalMSeconds(uint32_t u32MSeconds_)
00172 {
00173 #if KERNEL_EXTRA_CHECKS
00174
          KERNEL_ASSERT(IsInitialized());
00175 #endif
00176
          m_u32Interval = MSECONDS_TO_TICKS(u32MSeconds_);
00178 }
00179
00180 //---
00181 void Timer::SetIntervalUSeconds(uint32_t u32USeconds_)
00182 {
00183 #if KERNEL_EXTRA_CHECKS
          KERNEL_ASSERT(IsInitialized());
00185 #endif
00186
00187 #if KERNEL_TIMERS_TICKLESS
00188 if (u32USeconds < KERNEL_TIMERS_MINIMUM_DELAY_US) {
00189 u32USeconds = KERNEL_TIMERS_MINIMUM_DELAY_US;
00190
00191 #endif
00192
00193
          m_u32Interval = USECONDS_TO_TICKS(u32USeconds_);
00194 }
00195
00197 void Timer::SetTolerance(uint32_t u32Ticks_)
00198 {
00199 #if KERNEL_EXTRA_CHECKS
        KERNEL_ASSERT(IsInitialized());
00200
00201 #endif
00202
         m_u32TimerTolerance = u32Ticks_;
00204 } //namespace Mark3
00205 #endif
```

20.131 /home/moslevin/projects/github/m3-repo/kernel/src/timerlist.cpp File Reference

Implements timer list processing algorithms, responsible for all timer tick and expiry logic.

```
#include "kerneltypes.h"
#include "mark3cfg.h"
#include "timerlist.h"
#include "kerneltimer.h"
#include "threadport.h"
#include "quantum.h"
#include "mutex.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.131.1 Detailed Description

Implements timer list processing algorithms, responsible for all timer tick and expiry logic.

Definition in file timerlist.cpp.

372 File Documentation

20.132 timerlist.cpp

```
00001 /*=======
00003
00004
00005
00006 1
00007
80000
00009 -- [Mark3 Realtime Platform] -
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00013 ==========
00023 #include "kerneltypes.h"
00024 #include "mark3cfg.h"
00025
00026 #include "timerlist.h"
00027 #include "kerneltimer.h"
00028 #include "threadport.h"
00029 #include "quantum.h"
00030 #include "mutex.h"
00031
00032 #define _CAN_HAS_DEBUG
00033 //--[Autogenerated - Do Not Modify]------
00034 #include "dbg_file_list.h"
00035 #include "buffalogger.h"
00036 #if defined(DBG_FILE)
00037 #error "Debug logging file token already defined! Bailing."
00038 #else
00039 #define DBG_FILE _DBG___KERNEL_TIMERLIST_CPP
00040 #endif
00041 //--[End Autogenerated content]-----
00042
00043 #include "kerneldebug.h"
00044
00045 #if KERNEL_USE_TIMERS
00046 namespace Mark3
00047 {
00048 //---
00049 #if KERNEL_TIMERS_THREADED
00050 # define TIMERLIST_LOCK()
                                   (m_clMutex.Claim())
00051 # define TIMERLIST_UNLOCK() (m_clMutex.Release())
00052 #else
00053 # define TIMERLIST_LOCK()
                                  CS ENTER()
00054 # define TIMERLIST_UNLOCK() CS_EXIT()
00055 #endif
00056
00057 //--
00058 void TimerList::Init(void)
00059 {
00060
          m bTimerActive = false;
          m_u32NextWakeup = 0;
00061
00062 #if KERNEL_TIMERS_THREADED
00063
        m_clMutex.Init();
00064 #endif
00065 }
00066
00067 //
00068 void TimerList::Add(Timer* pclListNode_)
00069 {
00070 #if KERNEL_TIMERS_TICKLESS
00071
         bool
                 bStart = false;
          int32_t lDelta;
00072
00073 #endif
00074
00075
          TIMERLIST_LOCK();
00076
00077 #if KERNEL_TIMERS_TICKLESS
00078
         if (GetHead() == NULL) {
00079
              bStart = true;
00080
00081
          if (pclListNode_->m_u32Interval < PORT_MIN_TIMER_TICKS) {</pre>
00082
              pclListNode_->m_u32Interval = PORT_MIN_TIMER_TICKS;
00083
00084 #endif
00085
00086
          pclListNode_->ClearNode();
00087
          DoubleLinkList::Add(pclListNode_);
00088
00089
          \ensuremath{//} Set the initial timer value
00090
          pclListNode_->m_u32TimeLeft = pclListNode_->m_u32Interval;
00091
00092 #if KERNEL_TIMERS_TICKLESS
00093
          if (!bStart) {
```

20.132 timerlist.cpp 373

```
\ensuremath{//} If the new interval is less than the amount of time remaining..
              1Delta = (int32_t)((uint32_t)KernelTimer::TimeToExpiry() - pclListNode_->
00095
      m_u32Interval);
00096
00097
              if (1Delta > 0) {
              // Set the new expiry time on the timer.
00098
                  m_u32NextWakeup = (uint32_t)
00099
     KernelTimer::SubtractExpiry((uint32_t)lDelta);
00100
00101
          } else {
             m_u32NextWakeup = pclListNode_->m_u32Interval;
00102
              KernelTimer::SetExpiry(m_u32NextWakeup);
00103
00104
              KernelTimer::Start();
00105
00106 #endif
00107
          // Set the timer as active.
00108
         pclListNode_->m_u8Flags |= TIMERLIST_FLAG_ACTIVE;
00109
00110
00111
          TIMERLIST_UNLOCK();
00112 }
00113
00114 //---
00115 void TimerList::Remove(Timer* pclLinkListNode_)
00116 {
00117
          TIMERLIST_LOCK();
00118
00119
         DoubleLinkList::Remove(pclLinkListNode_);
00120
         pclLinkListNode_->m_u8Flags &= ~TIMERLIST_FLAG_ACTIVE;
00121
00122 #if KERNEL_TIMERS_TICKLESS
00123
        if (this->GetHead() == NULL) {
00124
             KernelTimer::Stop();
00125
00126 #endif
00127
00128
          TIMERLIST UNLOCK();
00130
00131 //---
00132 void TimerList::Process(void)
00133 {
00134 #if KERNEL_TIMERS_TICKLESS
         uint32_t u32NewExpiry;
00135
00136
          uint32_t u320vertime;
00137
          bool
                   bContinue;
00138 #endif
00139
         Timer* pclNode;
Timer* pclPrev;
00140
00141
00142
00143
        TIMERLIST_LOCK();
00144
00145 #if KERNEL_USE_QUANTUM
00146
         Quantum::SetInTimer();
00147 #endif
00148 #if KERNEL_TIMERS_TICKLESS
00149 #if !KERNEL_TIMERS_THREADED
00150 // Clear the timer and its expiry time - keep it running though
00151
         KernelTimer::ClearExpiry();
00152 #endif
00153
       do {
00154 #endif
00155
             pclNode = static_cast<Timer*>(GetHead());
             pclPrev = NULL;
00156
00157
00158 #if KERNEL_TIMERS_TICKLESS
00159
              bContinue
                          = false;
00160
              u32NewExpiry = MAX_TIMER_TICKS; // Used to indicate that no timers are pending
00161 #endif
00162
00163
              \ensuremath{//} Subtract the elapsed time interval from each active timer.
              while (pclNode != 0) {
    // Active timers only...
    if ((pclNode->m_u8Flags & TIMERLIST_FLAG_ACTIVE) != 0) {
00164
00165
00166
00167 // Did the timer expire?
00168 #if KERNEL_TIMERS_TICKLESS
00169
                      if (pclNode->m_u32TimeLeft <= m_u32NextWakeup)</pre>
00170 #else
00171
                      pclNode->m_u32TimeLeft--;
                      if (0 == pclNode->m_u32TimeLeft)
00172
00173 #endif
00174
00175
                           // Yes - set the "callback" flag - we'll execute the callbacks later
00176
                           pclNode->m_u8Flags |= TIMERLIST_FLAG_CALLBACK;
00177
00178
                           if ((pclNode->m_u8Flags & TIMERLIST_FLAG_ONE_SHOT) != 0) {
```

374 File Documentation

```
// If this was a one-shot timer, deactivate the timer.
                                    pclNode->m_u8Flags |= TIMERLIST_FLAG_EXPIRED;
pclNode->m_u8Flags &= ~TIMERLIST_FLAG_ACTIVE;
00180
00181
00182
                               } else {
00183
                                    // Reset the interval timer.
                                    // I think we're good though...
00185
                                    pclNode->m_u32TimeLeft = pclNode->m_u32Interval;
00186
00187
00188 #if KERNEL_TIMERS_TICKLESS
                                    // If the time remaining (plus the length of the tolerance interval)
// is less than the next expiry interval, set the next expiry interval.
uint32_t u32Tmp = pclNode->m_u32TimeLeft + pclNode->m_u32TimeTolerance;
00189
00190
00191
00192
00193
                                    if (u32Tmp < u32NewExpiry) {</pre>
00194
                                         u32NewExpiry = u32Tmp;
00195
00196 #endif
00197
                               }
00199 #if KERNEL_TIMERS_TICKLESS
00200
                          else {
00201
                               \ensuremath{//} Not expiring, but determine how long to run the next timer interval for.
                               pclNode->m_u32TimeLeft -= m_u32NextWakeup;
if (pclNode->m_u32TimeLeft < u32NewExpiry) {</pre>
00202
00203
00204
                                    u32NewExpiry = pclNode->m_u32TimeLeft;
00205
00206
00207 #endif
00208
00209
                     pclNode = static_cast<Timer*>(pclNode->GetNext());
00210
                }
00211
00212
                // Process the expired timers callbacks.
00213
                pclNode = static_cast<Timer*>(GetHead());
                while (pclNode != 0) {
00214
                     pclPrev = pclNode;
00215
                     pclNode = static_cast<Timer*>(pclNode->GetNext());
00216
00217
00218
                     // If the timer expired, run the callbacks now.
00219
                     if ((pclPrev->m_u8Flags & TIMERLIST_FLAG_CALLBACK) != 0) {
00220
                          bool bRemove = false;
                          // If this was a one-shot timer, tag it for removal
if ((pclPrev->m_u8Flags & TIMERLIST_FLAG_ONE_SHOT) != 0) {
00221
00222
00223
                               bRemove = true;
00224
00225
00226
                          // Run the callback. these callbacks must be very fast...
                          pclPrev->m_pfCallback(pclPrev->m_pclOwner, pclPrev->m_pvData);
pclPrev->m_u8Flags &= ~TIMERLIST_FLAG_CALLBACK;
00227
00228
00229
                          // Remove one-shot-timers
00231
                          if (bRemove) {
00232
                               Remove (pclPrev);
00233
00234
                     }
00235
                }
00236
00237 #if KERNEL_TIMERS_TICKLESS
               // Check to see how much time has elapsed since the time we
// acknowledged the interrupt...
u320vertime = (uint32_t)KernelTimer::GetOvertime();
00238
00239
00240
00241
00242
                if (u320vertime >= u32NewExpiry) {
00243
                     m_u32NextWakeup = u32Overtime;
00244
                     bContinue
                                        = true;
00245
00246
00247
                // If it's taken longer to go through this loop than would take us to
00248
                // the next expiry, re-run the timing loop
00249
00250
           } while (bContinue);
00251
00252
            // This timer elapsed, but there's nothing more to do...
            // Turn the timer off.
00253
            if (u32NewExpiry >= MAX_TIMER_TICKS) {
00254
00255
                KernelTimer::Stop();
           } else {
00256
00257
                // Update the timer with the new "Next Wakeup" value, plus whatever
00258
                // overtime has accumulated since the last time we called this handler
00259
                m_u32NextWakeup = (uint32_t)KernelTimer::SetExpiry(
00260
      u32NewExpiry + u32Overtime);
00261
00262 #endif
00263 #if KERNEL_USE_QUANTUM
00264
         Quantum::ClearInTimer();
00265 #endif
```

20.133 /home/moslevin/projects/github/m3-repo/kernel/src/tracebuffer.cpp File Reference

Kernel trace buffer class definition.

```
#include "kerneltypes.h"
#include "tracebuffer.h"
#include "mark3cfg.h"
#include "dbg_file_list.h"
#include "buffalogger.h"
#include "kerneldebug.h"
```

20.133.1 Detailed Description

Kernel trace buffer class definition.

Definition in file tracebuffer.cpp.

20.134 tracebuffer.cpp

```
00001 /*
00002
00003
00004
00005
00006 |
00007
80000
00009 -- [Mark3 Realtime Platform]-
00010
00011 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
00012 See license.txt for more information
00019 #include "kerneltypes.h"
00020 #include "tracebuffer.h"
00021 #include "mark3cfg.h"
00022
00023 #define _CAN_HAS_DEBUG
00024 //--[Autogenerated - Do Not Modify]-----
00025 #include "dbg_file_list.h"
00026 #include "buffalogger.h"
00027 #if defined(DBG_FILE)
00028 #error "Debug logging file token already defined! Bailing."
00029 #else
00030 #define DBG_FILE _DBG___KERNEL_TRACEBUFFER_CPP
00031 #endif
00032
00033 #include "kerneldebug.h"
00034
00035 //--[End Autogenerated content]-----
00036
00037 #if KERNEL_USE_DEBUG && !KERNEL_AWARE_SIMULATION
00038 namespace Mark3
00039 4
00040 TraceBufferCallback_t TraceBuffer::m_pfCallback;
00041 uint16_t
                              TraceBuffer::m_u16SyncNumber;
00042 uint16_t
                              TraceBuffer::m_u16Index;
00043 uint16_t
                              TraceBuffer::m_au16Buffer[(TRACE_BUFFER_SIZE / sizeof(uint16_t))];
```

376 File Documentation

```
00045 //---
00046 void TraceBuffer::Init()
00047 {
00048 }
00049
00051 void TraceBuffer::Write(uint16_t* pu16Data_, uint16_t u16Size_)
00052 {
           \ensuremath{//} Pipe the data directly to the circular buffer
00053
00054
          uint16_t u16Start;
00055
00056
           // Update the circular buffer index in a critical section. The
00057
           // rest of the operations can take place in any context.
00058
           CS_ENTER();
00059
           uint16_t u16NextIndex;
          u16Start = m_u16Index;
u16NextIndex = m_u16Index + u16Size_;
if (u16NextIndex >= (sizeof(m_au16Buffer) / sizeof(uint16_t))) {
00060
00061
00062
00063
               ul6NextIndex -= (sizeof(m_aul6Buffer) / sizeof(uint16_t));
00064
           m_u16Index = u16NextIndex;
00065
00066
          CS_EXIT();
00067
00068
           // Write the data into the circular buffer.
00069
           uint16_t i;
00070
                     bCallback = false;
00071
           bool
                    bPingPong = false;
          for (i = 0; i < ul6Size_; i++) {
    m_aul6Buffer[ul6Start++] = pul6Data_[i];
00072
00073
               if (ul6Start >= (sizeof(m_au16Buffer) / sizeof(uint16_t))) {
  u16Start = 0;
  bCallback = true;
00074
00075
00076
               } else if (u16Start == ((sizeof(m_au16Buffer) / sizeof(uint16_t)) / 2)) {
00077
                    bPingPong = true;
bCallback = true;
00078
00079
08000
               }
          }
00082
00083
          // Done writing - see if there's a 50% or rollover callback
00084
          if (bCallback && m_pfCallback) {
               uint16_t u16Size = (sizeof(m_au16Buffer) / sizeof(uint16_t)) / 2;
00085
00086
               if (bPingPong) {
00087
                    m_pfCallback(m_au16Buffer, u16Size, bPingPong);
00088
               } else {
00089
                    m_pfCallback(m_au16Buffer + u16Size, u16Size, bPingPong);
00090
00091
          }
00092 }
00093 } //namespace Mark3
00094 #endif
```

Chapter 21

Example Documentation

21.1 buffalogger/main.cpp

This example demonstrates how low-overhead logging can be implemented using buffalogger.

21.2 lab10_notifications/main.cpp

This examples demonstrates how to use notification objects as a thread synchronization mechanism.

```
Thread clapp1Thread;
K_WORD awApp1Stack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void ApplMain(void* unused_);
Thread clApp2Thread;
K_WORD awApp2Stack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void App2Main(void* unused_);
// Notification object used in the example.
Notify clNotify;
void ApplMain(void* unused_)
    while (1) {
        auto bNotified = false;
        // Block the thread until the notification object is signalled from
        clNotify.Wait(&bNotified);
        KernelAware::Print("T1: Notified\n");
void App2Main(void* unused_)
    while (1) {
        // Wait a while, then signal the notification object
        KernelAware::Print("T2: Wait 1s\n");
        Thread::Sleep(1000);
        KernelAware::Print("T2: Notify\n");
        clNotify.Signal();
} // anonymous namespace
using namespace Mark3;
int main(void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    // Initialize notifer and notify-ee threads
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApp1Thread.Start();
    \verb|clApp2Thread.Init(awApp2Stack, size of (awApp2Stack), 1, App2Main, 0);|\\
    clApp2Thread.Start();
    // Initialize the Notify objects
    clNotify.Init();
    Kernel::Start();
    return 0:
```

21.3 lab11_mailboxes/main.cpp

This examples shows how to use mailboxes to deliver data between threads in a synchronized way.

```
#include "mark3.h"
/*----
Lab Example 11: Mailboxes
Lessons covered in this example include:
 Initialize a mailbox for use as an IPC mechanism.
- Create and use mailboxes to pass data between threads.
Takeaway:
- Mailboxes are a powerful IPC mechanism used to pass messages of a fixed-size
 between threads.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
Thread clapp1Thread;
K_WORD awApp1Stack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void ApplMain(void* unused_);
Thread clApp2Thread;
K_WORD awApp2Stack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void App2Main(void* unused_);
Mailbox clMailbox;
uint8_t au8MBData[100];
typedef struct {
   uint8_t au8Buffer[10];
} MBType_t;
void ApplMain(void* unused_)
    while (1) {
       MBType_t stMsg;
        // Wait until there is an envelope available in the shared mailbox, and
        \ensuremath{//} then log a trace message.
        clMailbox.Receive(&stMsg);
        KernelAware::Trace(0, __LINE__, stMsg.au8Buffer[0], stMsg.au8Buffer[9]);
    }
}
void App2Main(void* unused_)
    while (1) {
        MBType_t stMsg;
        // Place a bunch of envelopes in the mailbox, and then wait for a
        \ensuremath{//} while. Note that this thread has a higher priority than the other
        \ensuremath{//} thread, so it will keep pushing envelopes to the other thread until
        // it gets to the sleep, at which point the other thread will be allowed
        // to execute.
        KernelAware::Print("Messages Begin\n");
        for (uint8_t i = 0; i < 10; i++) {
   for (uint8_t j = 0; j < 10; j++) {
     stMsg.au8Buffer[j] = (i * 10) + j;</pre>
            clMailbox.Send(&stMsg);
        KernelAware::Print("Messages End\n");
        Thread::Sleep(2000);
} // anonymous namespace
using namespace Mark3;
```

```
int main(void)
{
    // See the annotations in previous labs for details on init.
    Kernel::Init();

    // Initialize the threads used in this example
    clApplThread.Init(awApplStack, sizeof(awApplStack), 1, ApplMain, 0);
    clApplThread.Start();

    clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 2, App2Main, 0);
    clApp2Thread.Start();

    // Initialize the mailbox used in this example
    clMailbox.Init(au8MBData, 100, sizeof(MBType_t));

    Kernel::Start();
    return 0;
}
```

21.4 lab1_kernel_setup/main.cpp

This example demonstrates basic kernel setup with two threads.

```
-- [Mark3 Realtime Platform]
Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
See license.txt for more information
#include "mark3.h"
/*-----
Lab Example 1: Initializing the Mark3 RTOS kernel with two threads.
The following example code presents a working example of how to initialize
the Mark3 RTOS kernel, configure two application threads, and execute the \,
configured tasks. This example also uses the flAVR kernel-aware module to
print out messages when run through the flAVR AVR Simulator. This is a
turnkey-ready example of how to use the Mark3 RTOS at its simplest level,
and should be well understood before moving on to other examples.
Lessons covered in this example include:
- usage of the Kernel class - configuring and starting the kernel - usage of the Thread class - initializing and starting static threads.
- Demonstrate the relationship between Thread objects, stacks, and entry
- usage of Thread::Sleep() to block execution of a thread for a period of time
- When using an idle thread, the idle thread MUST not block.
Exercise:
- Add another application thread that prints a message, flashes an LED, etc.
 using the code below as an example.
Takeawav:
At the end of this example, the reader should be able to use the Mark3
Kernel and Thread APIs to initialize and start the kernel with any number
of static threads.
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
```

```
// This block declares the thread data for the main application thread.
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
Thread clAppThread;
K_WORD awAppStack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void AppMain(void* unused_);
// This block declares the thread data for the idle thread. It defines a
// thread object, stack (in word-array form), and the entry-point function // used by the idle thread.
Thread clidleThread:
K_WORD awIdleStack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void IdleMain(void* unused_);
void AppMain(void* unused_)
    // This function is run from within the application thread. Here, we
    // simply print a friendly greeting and allow the thread to sleep for a
    // while before repeating the message. Note that while the thread is
    \ensuremath{//} sleeping, CPU execution will transition to the Idle thread.
    while (1) {
        KernelAware::Print("Hello World!\n");
        Thread::Sleep(1000);
void IdleMain(void* unused)
           Low priority task + power management routines go here.
        // The actions taken in this context must *not* cause the thread
        // to block, as the kernel requires that at least one thread is
        // schedulable at all times when not using an idle thread.
        // Note that if you have no special power-management code or idle
        // tasks, an empty while(1){} loop is sufficient to guarantee that
        // condition.
} // anonymous namespace
using namespace Mark3;
int main (void)
    // Before any Mark3 RTOS APIs can be called, the user must call Kernel::Init().
    // Note that if you have any hardware-specific init code, it can be called
    // before Kernel::Init, so long as it does not enable interrupts, or
    // rely on hardware peripherals (timer, software interrupt, etc.) used by the
    // kernel.
    Kernel::Init();
    // Once the kernel initialization has been complete, the user can add their
    // application thread(s) and idle thread. Threads added before the kerel
    // is started are refered to as the "static threads" in the system, as they
    \ensuremath{//} are the default working-set of threads that make up the application on
    // kernel startup.
      Initialize the application thread to use a specified word-array as its stack.
    // The thread will run at priority level "1", and start execution the
    // "AppMain" function when it's started.
    clAppThread.Init(awAppStack, sizeof(awAppStack), 1, AppMain, 0);
    // Initialize the idle thread to use a specific word-array as its stack.
    // The thread will run at priority level "0", which is reserved for the idle // priority thread. IdleMain will be run when the thread is started.
    clIdleThread.Init(awIdleStack, sizeof(awIdleStack), 0, IdleMain, 0);
    // Once the static threads have been added, the user must then ensure that the
    // threads are ready to execute. By default, creating a thread is created // in a STOPPED state. All threads must manually be started using the
    // Start() API before they will be scheduled by the system. Here, we are
    // starting the application and idle threads before starting the kernel - and
    // that's OK. When the kernel is started, it will choose which thread to run
    \ensuremath{//} first from the pool of ready threads.
    clAppThread.Start();
    clIdleThread.Start();
    // All threads have been initialized and made ready. The kernel will now
    \ensuremath{//} select the first thread to run, enable the hardware required to run the
    // kernel (Timers, software interrupts, etc.), and then do whatever is
    // necessary to maneuver control of thread execution to the kernel. At this
```

```
// point, execution will transition to the highest-priority ready thread.
// This function will not return.

Kernel::Start();

// As Kernel::Start() results in the operating system being executed, control
// will not be relinquished back to main(). The "return 0" is simply to
// avoid warnings.

return 0;
```

21.5 lab2_idle_function/main.cpp

This example demonstrates how to use the idle function, instead of an idle thread to manage system inactivity.

```
--[Mark3 Realtime Platform]-
Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
See license.txt for more information
/+----
Lab Example 2: Initializing the Mark3 RTOS kernel with one thread.
The following example code presents a working example of how to initialize
the Mark3 RTOS kernel, configured to use an application thread and the special
Kernel-Idle function. This example is functionally identical to labl, although it uses less memory as a result of only requiring one thread. This example also
uses the flAVR kernel-aware module to print out messages when run through the
flAVR AVR Simulator.
Lessons covered in this example include:
- usage of the Kernel::SetIdleFunc() API
- Changing an idle thread into an idle function
- You can save a thread and a stack by using an idle function instead of a
 dedicated idle thread.
The Kernel-Idle context allows you to run the Mark3 RTOS without running
a dedicated idle thread (where supported). This results in a lower overall memory footprint for the application, as you can avoid having to declare
a thread object and stack for Idle functionality.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
\ensuremath{//} This block declares the thread data for the main application thread. It
\ensuremath{//} defines a thread object, stack (in word-array form), and the entry-point
// defines a chical lag.
// function used by the application thread.
Thread clappThread;
K_WORD awAppStack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void AppMain(void* unused_);
// This block declares the special function called from with the special
// Kernel-Idle context. We use the Kernel::SetIdleFunc() API to ensure that
// this function is called to provide our idle context.
```

```
void IdleMain(void);
void AppMain(void* unused_)
    // Same as in lab1.
    while (1) {
         KernelAware::Print("Hello World!\n");
         Thread::Sleep(1000);
void IdleMain(void)
    // Low priority task + power management routines go here.
    // The actions taken in this context must *not* cause a blocking call,
    // similar to the requirements for an idle thread.
    // Note that unlike an idle thread, the idle function must run to
    // completion. As this is also called from a nested interrupt context,
    // it's worthwhile keeping this function brief, limited to absolutely
    \ensuremath{//} necessary functionality, and with minimal stack use.
} // anonymous namespace
using namespace Mark3;
int main(void)
    // See the annotations in lab1.
    Kernel::Init();
    \ensuremath{//} Initialize the main application thread, as in lab1. Note that even
    // though we're using an Idle function and not a dedicated thread, priority
// level 0 is still reserved for idle functionality. Application threads
    // should never be scheduled at priority level 0 when the idle function is // used instead of an idle thread.
    clAppThread.Init(awAppStack, sizeof(awAppStack), 1, AppMain, 0);
    clAppThread.Start();
    \ensuremath{//} This function is used to install our specified idle function to be called
    // whenever there are no ready threads in the system. Note that if no // Idle function is specified, a default will be used. Note that this default
     // function is essentially a null operation.
    Kernel::SetIdleFunc(IdleMain);
    Kernel::Start();
    return 0:
```

21.6 lab3_round_robin/main.cpp

This example demonstrates how to use round-robin thread scheduling with multiple threads of the same priority.

```
Takeaway:
- CPU Scheduling can be achieved using not just strict Thread priority, but
 also with round-robin time-slicing between threads at the same priority.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
Thread clApplThread;
K_WORD awApp1Stack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void App1Main(void* unused_);
\ensuremath{//} This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point // function used by the application thread.
Thread clApp2Thread;
K_WORD awApp2Stack[PORT_KERNEL_DEFAULT_STACK_SIZE];
void App2Main(void* unused_);
void ApplMain(void* unused_)
    // Simple loop that increments a volatile counter to 1000000 then resets
    // it while printing a message.
    volatile uint32_t u32Counter = 0;
    while (1) {
        u32Counter++:
        if (u32Counter == 1000000) {
            u32Counter = 0;
             KernelAware::Print("Thread 1 - Did some work\n");
        }
    }
}
void App2Main(void* unused_)
    \ensuremath{//} Same as ApplMain. However, as this thread gets twice as much CPU time
    // as Thread 1, you should see its message printed twice as often as the // above function.
    volatile uint32_t u32Counter = 0;
    while (1) {
        u32Counter++;
        if (u32Counter == 1000000) {
             u32Counter = 0:
             KernelAware::Print("Thread 2 - Did some work\n");
} // anonymous namespace
using namespace Mark3:
int main(void)
    // See the annotations in lab1.
    Kernel::Init();
    // In this exercise, we create two threads at the same priority level. // As a result, the CPU will automatically swap between these threads
    // at runtime to ensure that each get a chance to execute.
    \verb|clApp1Thread.Init(awApp1Stack, size of (awApp1Stack), 1, App1Main, 0);|\\
    clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
    // Set the threads up so that Thread 1 can get 4ms of CPU time uninterrupted,
    // but Thread 2 can get 8ms of CPU time uninterrupted. This means that
    // in an ideal situation, Thread 2 will get to do twice as much work as
    \ensuremath{//} Thread 1 - even though they share the same scheduling priority.
    // Note that if SetQuantum() isn't called on a thread, a default value
```

```
// is set such that each thread gets equal timeslicing in the same
// priority group by default. You can play around with these values and
// observe how it affects the execution of both threads.

clApplThread.SetQuantum(4);
clApp2Thread.SetQuantum(8);

clApplThread.Start();
clApp2Thread.Start();

Kernel::Start();

return 0;
}
```

21.7 lab4_semaphores/main.cpp

This example demonstrates how to use semaphores for Thread synchronization.

```
--[Mark3 Realtime Platform]
Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
 See license.txt for more information
  #include "mark3.h"
  /*-----
Lab Example 4: using binary semaphores
 In this example, we implement two threads, synchronized using a semaphore to
model the classic producer-consumer pattern. One thread does work, and then posts the semaphore indicating that the other thread can consume that work.
 The blocking thread just waits idly until there is data for it to consume.
 Lessons covered in this example include:
 -Use of a binary semaphore to implement the producer-consumer pattern % \left( 1\right) =\left( 1\right) +\left( 1
  -Synchronization of threads (within a single priority, or otherwise)
   using a semaphore
Semaphores can be used to control which threads execute at which time. This
allows threads to work cooperatively to achieve a goal in the system.
  #if !KERNEL_USE_IDLE_FUNC
  #error "This demo requires KERNEL_USE_IDLE_FUNC"
 #endif
 extern "C" {
 void cxa pure virtual (void)
namespace {
using namespace Mark3;
  // This block declares the thread data for one main application thread. It
 // defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP1_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
 Thread clApp1Thread;
 K_WORD awApp1Stack[APP1_STACK_SIZE];
 void ApplMain(void* unused_);
 // This block declares the thread data for one main application thread. It
 // defines a thread object, stack (in word-array form), and the entry-point // function used by the application thread.
  #define APP2_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
```

```
Thread clApp2Thread;
K_WORD awApp2Stack[APP2_STACK_SIZE];
void App2Main(void* unused_);
// This is the semaphore that we'll use to synchronize two threads in this
// demo application
Semaphore clMySem;
void ApplMain(void* unused_)
    while (1) {
        // Wait until the semaphore is posted from the other thread
        KernelAware::Print("Wait\n");
        clMySem.Pend();
        // Producer thread has finished doing its work -- do something to // consume its output. Once again - a contrived example, but we
        // can imagine that printing out the message is "consuming" the output
         // from the other thread.
        KernelAware::Print("Triggered!\n");
    }
void App2Main(void* unused_)
    volatile uint32_t u32Counter = 0;
    while (1) {
        // Do some work. Once the work is complete, post the semaphore.
        // will cause the other thread to wake up and then take some action.
        // It's a bit contrived, but imagine that the results of this process
        // are necessary to drive the work done by that other thread.
        u32Counter++;
        if (u32Counter == 1000000) {
            u32Counter = 0;
             KernelAware::Print("Posted\n");
            clMySem.Post();
} // anonymous namespace
using namespace Mark3;
int main(void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    // In this example we create two threads to illustrate the use of a
    // binary semaphore as a synchronization method between two threads.
    // Thread 1 is a "consumer" thread -- It waits, blocked on the semaphore
    // until thread 2 is done doing some work. Once the semaphore is posted,
    // the thread is unblocked, and does some work.
    // Thread 2 is thus the "producer" thread -- It does work, and once that
    // work is done, the semaphore is posted to indicate that the other thread
    // can use the producer's work product.
    clApp1Thread.Init(awApp1Stack, APP1_STACK_SIZE, 1, App1Main, 0);
clApp2Thread.Init(awApp2Stack, APP2_STACK_SIZE, 1, App2Main, 0);
    clApplThread.Start();
    clApp2Thread.Start();
      Initialize a binary semaphore (maximum value of one, initial value of
    clMySem.Init(0, 1);
    Kernel::Start():
```

21.8 lab5_mutexes/main.cpp

This example demonstrates how to use mutexes to protect against concurrent access to resources.

```
--[Mark3 Realtime Platform]-
Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
See license.txt for more information
#include "mark3.h"
Lab Example 5: using Mutexes.
Lessons covered in this example include:
-You can use mutexes to lock accesses to a shared resource
Takeaway:
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread. #define APP1_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
Thread clapp1Thread;
K_WORD awApp1Stack[APP1_STACK_SIZE];
void ApplMain(void* unused_);
\ensuremath{//} This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point // function used by the application thread. #define APP2_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
Thread clApp2Thread;
K_WORD awApp2Stack[APP2_STACK_SIZE];
void App2Main(void* unused_);
// This is the mutex that we'll use to synchronize two threads in this
// demo application.
Mutex clMyMutex;
// This counter variable is the "shared resource" in the example, protected
// by the mutex. Only one thread should be given access to the counter at
// any time.
volatile uint32_t u32Counter = 0;
void ApplMain(void* unused_)
    while (1) {
        // Claim the mutex. This will prevent any other thread from claiming
         // this lock simulatenously. As a result, the other thread has to
         // wait until we're done before it can do its work. You will notice
        // that the Start/Done prints for the thread will come as a pair (i.e. // you won't see "Thread2: Start" then "Thread1: Start").
        clMyMutex.Claim();
         \ensuremath{//} Start our work (incrementing a counter). Notice that the Start and
        \ensuremath{//} Done prints wind up as a pair when simuated with flAVR.
        KernelAware::Print("Thread1: Start\n");
        u32Counter++;
        while (u32Counter <= 1000000) {</pre>
            u32Counter++;
        u32Counter = 0;
        KernelAware::Print("Thread1: Done\n");
```

```
// Release the lock, allowing the other thread to do its thing.
        clMyMutex.Release();
void App2Main(void* unused_)
    while (1) {
        ^{\prime\prime} Claim the mutex. This will prevent any other thread from claiming
        // this lock simulatenously. As a result, the other thread has to // wait until we're done before it can do its work. You will notice
        // that the Start/Done prints for the thread will come as a pair (i.e.
        // you won't see "Thread2: Start" then "Thread1: Start").
        clMvMutex.Claim();
        // Start our work (incrementing a counter). Notice that the Start and
        // Done prints wind up as a pair when simuated with flAVR.
        KernelAware::Print("Thread2: Start\n");
        u32Counter++;
        while (u32Counter <= 1000000) {</pre>
            u32Counter++;
        u32Counter = 0;
        KernelAware::Print("Thread2: Done\n");
        // Release the lock, allowing the other thread to do its thing.
        clMvMutex.Release();
} // anonymous namespace
using namespace Mark3;
int main(void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
    clApp1Thread.Start();
    clApp2Thread.Start();
    // Initialize the mutex used in this example.
    clMyMutex.Init();
    Kernel::Start();
    return 0:
```

21.9 lab6_timers/main.cpp

This example demonstrates how to create and use software timers.

```
Lessons covered in this example include:
Takeaway:
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point // function used by the application thread. #define APP1_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
Thread clApplThread;
K_WORD awApp1Stack[APP1_STACK_SIZE];
void ApplMain(void* unused_);
void PeriodicCallback(Thread* owner, void* pvData_)
    \ensuremath{//} Timer callback function used to post a semaphore. Posting the semaphore
    // will wake up a thread that's pending on that semaphore.
    auto* pclSem = static_cast<Semaphore*>(pvData_);
    pclSem->Post();
void OneShotCallback(Thread* owner, void* pvData )
    KernelAware::Print("One-shot timer expired.\n");
void App1Main(void* unused_)
    Timer clMyTimer; // Periodic timer object
    Timer clOneShot; // One-shot timer object
    Semaphore clMySem; // Semaphore used to wake this thread
    \ensuremath{//} Initialize a binary semaphore (maximum value of one, initial value of
     // zero).
    clMySem.Init(0, 1);
    // Start a timer that triggers every 500ms that will call PeriodicCallback. // This timer simulates an external stimulus or event that would require // an action to be taken by this thread, but would be serviced by an
    // interrupt or other high-priority context.
    // PeriodicCallback will post the semaphore which wakes the thread
    // up to perform an action. Here that action consists of a trivial message
    // print.
    clMyTimer.Start(true, 500, PeriodicCallback, (void*)&clMySem);
    // Set up a one-shot timer to print a message after 2.5 seconds, asynchronously
    // from the execution of this thread.
    clOneShot.Start(false, 2500, OneShotCallback, 0);
    while (1) {
         // Wait until the semaphore is posted from the timer expiry
         clMySem.Pend();
         // Take some action after the timer posts the semaphore to wake this
         // thread.
         KernelAware::Print("Thread Triggered.\n");
} // anonymous namespace
using namespace Mark3;
int main(void)
     // See the annotations in previous labs for details on init.
    Kernel::Init();
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
```

```
clApp1Thread.Start();
Kernel::Start();
return 0;
```

21.10 lab7_events/main.cpp

This example demonstrates how to create and use event groups

```
-- [Mark3 Realtime Platform]-
Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
See license.txt for more information
#include "mark3.h"
Lab Example 7: using Event Flags
Lessons covered in this example include:
-Using the EventFlag Class to synchronize thread execution
-Explore the behavior of the EventFlagOperation::Any_Set and EventFlagOperation::All_Set, and the
 event-mask bitfield.
Takeaway:
Like Semaphores and Mutexes, EventFlag objects can be used to synchronize the execution of threads in a system. The EventFlag class allows for many
threads to share the same object, blocking on different event combinations.
This provides an efficient, robust way for threads to process asynchronous
system events that occur with a unified interface.
#if !KERNEL_USE_IDLE_FUNC
#error "This demo requires KERNEL_USE_IDLE_FUNC"
#endif
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP1_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
Thread clApp1Thread;
K_WORD awApp1Stack[APP1_STACK_SIZE];
void ApplMain(void* unused_);
\ensuremath{//} This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP2_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
Thread clapp2Thread;
K_WORD awApp2Stack[APP2_STACK_SIZE];
void App2Main(void* unused_);
EventFlag clFlags;
```

```
void ApplMain(void* unused_)
    while (1) {
        // Block this thread until any of the event flags have been set by
         // some outside force (here, we use Thread 2). As an exercise to the // user, try playing around with the event mask to see the effect it
         // has on which events get processed. Different threads can block on
         // different bitmasks - this allows events with different real-time
         // priorities to be handled in different threads, while still using
         // the same event-flag object.
         // Also note that EventFlagOperation::Any_Set indicates that the thread will be
         // unblocked whenever any of the flags in the mask are selected. If
         // you wanted to trigger an action that only takes place once multiple
         // bits are set, you could block the thread waiting for a specific
         // event bitmask with EventFlagOperation::All_Set specified.
         auto u16Flags = clFlags.Wait(0xFFFF, EventFlagOperation::Any_Set);
         // Print a message indicaating which bit was set this time.
         switch (u16Flags) {
             case 0x0001: KernelAware::Print("Event1\n"); break;
             case 0x0002: KernelAware::Print("Event2\n"); break;
case 0x0004: KernelAware::Print("Event3\n"); break;
             case 0x0008: KernelAware::Print("Event4\n"); break;
             case 0x0010: KernelAware::Print("Event5\n"); break;
             case 0x0020: KernelAware::Print("Event6\n"); break;
             case 0x0040: KernelAware::Print("Event7\n"); break;
             case 0x0080: KernelAware::Print("Event8\n"); break;
case 0x0100: KernelAware::Print("Event9\n"); break;
             case 0x0200: KernelAware::Print("Event10\n"); break;
             case 0x0400: KernelAware::Print("Event11\n"); break;
             case 0x0800: KernelAware::Print("Event12\n"); break;
             case 0x1000: KernelAware::Print("Event13\n"); break;
             case 0x2000: KernelAware::Print("Event14\n"); break;
case 0x4000: KernelAware::Print("Event15\n"); break;
             case 0x8000: KernelAware::Print("Event16\n"); break;
             default: break;
         // Clear the event-flag that we just printed a message about. This
         // will allow u16 to acknowledge further events in that bit in the future.
        clFlags.Clear(u16Flags);
void App2Main(void* unused_)
    uint16_t u16Flag = 1;
    while (1) {
        Thread::Sleep(100);
         // Event flags essentially map events to bits in a bitmap. Here we
        // set one bit each 100ms. In this loop, we cycle through bits 0-15 // repeatedly. Note that this will wake the other thread, which is // blocked, waiting for *any* of the flags in the bitmap to be set.
         clFlags.Set (u16Flag);
         // Bitshift the flag value to the left. This will be the flag we set
         // the next time this thread runs through its loop.
         if (u16Flag != 0x8000) {
             u16Flag <<= 1;
             u16Flag = 1;
} // anonymous namespace
using namespace Mark3;
int main(void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
    clApplThread.Start();
    clApp2Thread.Start();
    clFlags.Init();
    Kernel::Start();
```

```
return 0;
```

21.11 lab8_messages/main.cpp

This example demonstrates how to pass data between threads using message passing.

```
--[Mark3 Realtime Platform]
 Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
 See license.txt for more information
  #include "mark3.h"
 Lab Example 8: using messages for IPC.
In this example, we present a typical asynchronous producer/consumer pattern % \left( 1\right) =\left( 1\right) \left( 1\right) +\left( 1\right) \left( 1\right) \left( 1\right) +\left( 1\right) \left( 1\right) \left(
using Mark3's message-driven IPC.
Lessons covered in this example include:
 - use of Message and MessageQueue objects to send data between threads
 - use of GlobalMessagePool to allocate and free message objects
 Takeaway:
Unlike cases presented in previous examples that relied on semaphores or
 event flags, messages carry substantial context, specified in its "code" and "data" members. This mechanism can be used to pass data between threads
extremely efficiently, with a simple and flexible API. Any number of threads can write to/block on a single message queue, which give this method of
 IPC even more flexibility.
 #if !KERNEL_USE_IDLE_FUNC
  #error "This demo requires KERNEL_USE_IDLE_FUNC"
 #endif
 extern "C" {
 void __cxa_pure_virtual(void)
namespace {
 using namespace Mark3;
  // This block declares the thread data for one main application thread. It
 // defines a thread object, stack (in word-array form), and the entry-point
// function used by the application thread.
#define APP1_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
  Thread clApp1Thread;
 K_WORD awApp1Stack[APP1_STACK_SIZE];
 void ApplMain(void* unused_);
  // This block declares the thread data for one main application thread. It
 // defines a thread object, stack (in word-array form), and the entry-point // function used by the application thread. #define APP2_STACK_SIZE (PORT_KERNEL_DEFAULT_STACK_SIZE)
Thread clapp2Thread;
K_WORD awApp2Stack[APP2_STACK_SIZE];
 void App2Main(void* unused_);
MessageQueue clMsgQ;
 #define MESSAGE_POOL_SIZE (3)
 MessagePool s_clMessagePool;
Message s_clMessages[MESSAGE_POOL_SIZE];
```

```
void ApplMain(void* unused_)
    auto u16Data = 0;
    while (1) { $}^{'} // This thread grabs a message from the global message pool, sets a
         // code-value and the message data pointer, then sends the message to
         // a message queue object. Another thread (Thread2) is blocked, waiting
         // for a message to arrive in the queue.
         // Get the message object
        auto* pclMsg = s_clMessagePool.Pop();
         // Set the message object's data (contrived in this example)
         pclMsg->SetCode(0x1337);
         1116Data++:
        pclMsg->SetData(&u16Data);
         // Send the message to the shared message queue
         clMsgQ.Send(pclMsg);
         // Wait before sending another message.
        Thread::Sleep(200);
}
void App2Main(void* unused_)
    while (1) {
         // This thread waits until it receives a message on the shared global
         // message queue. When it gets the message, it prints out information
         // about the message's code and data, before returning the messaage object
         // back to the global message pool. In a more practical application, // the user would typically use the code to tell the receiving thread
         // what kind of message was sent, and what type of data to expect in the
         // data field.
         // Wait for a message to arrive on the specified queue. Note that once // this thread receives the message, it is "owned" by the thread, and
         // must be returned back to its source message pool when it is no longer
         // needed.
        auto* pclMsg = clMsgQ.Receive();
         // We received a message, now print out its information
         KernelAware::Print("Received Message\n");
        KernelAware::Trace(0, __LINE__, pclMsg->GetCode(), *((uint16_t*)pclMsg->GetData()
      ));
         // Done with the message, return it back to the global message queue.
         s_clMessagePool.Push(pclMsg);
} // anonymous namespace
using namespace Mark3;
int main(void)
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
clApp2Thread.Init(awApp2Stack, sizeof(awApp2Stack), 1, App2Main, 0);
    clApp1Thread.Start();
    clApp2Thread.Start();
    clMsgQ.Init();
    s_clMessagePool.Init();
    for (int i = 0; i < MESSAGE_POOL_SIZE; i++) {
   s_clMessages[i].Init();</pre>
         s_clMessagePool.Push(&s_clMessages[i]);
    Kernel::Start();
    return 0:
```

21.12 lab9_dynamic_threads/main.cpp

This example demonstrates how to create and destroy threads dynamically at runtime.

```
-- [Mark3 Realtime Platform]
Copyright (c) 2012 - 2018 mOslevin, all rights reserved.
See license.txt for more information
#include "mark3.h"
#include "memutil.h'
Lab Example 9: Dynamic Threading
Lessons covered in this example include:
- Creating, pausing, and destorying dynamically-created threads at runtime
In addition to being able to specify a static set of threads during system
initialization, Mark3 gives the user the ability to create and manipu32ate threads at runtime. These threads can act as "temporary workers" that can
be activated when needed, without impacting the responsiveness of the rest
of the application.
#if !KERNEL USE IDLE FUNC
        "This demo requires KERNEL_USE_IDLE_FUNC"
#error
#if !KERNEL_USE_THREAD_CALLOUTS
#error "This demo requires KERNEL_USE_THREAD_CALLOUTS"
#endif
#if !KERNEL TIMERS TICKLESS
#error "This demo requires KERNEL_TIMERS_TICKLESS"
#endif
extern "C" {
void __cxa_pure_virtual(void)
namespace {
using namespace Mark3;
// This block declares the thread data for one main application thread. It
// defines a thread object, stack (in word-array form), and the entry-poi
// function used by the application thread.
#define APP1_STACK_SIZE (400 / sizeof(K_WORD))
Thread clApp1Thread;
K_WORD awApp1Stack[APP1_STACK_SIZE];
void ApplMain(void* unused_);
// This block declares the thread stack data for a thread that we'll create
// dynamically.
#define APP2_STACK_SIZE (400 / sizeof(K_WORD))
K_WORD awApp2Stack[APP2_STACK_SIZE];
#if KERNEL_USE_THREAD_CALLOUTS
#define MAX_THREADS (10)
Thread* apclActiveThreads[10];
uint32_t au16ActiveTime[10];
void PrintThreadSlack (void)
    KernelAware::Print("Stack Slack");
    for (uint8_t i = 0; i < MAX_THREADS; i++) {
    if (apclActiveThreads[i] != 0) {</pre>
             char szStr[10];
             auto u16Slack = apclActiveThreads[i]->GetStackSlack();
```

```
MemUtil::DecimalToHex((K_ADDR)apclActiveThreads[i], szStr);
             KernelAware::Print(szStr);
KernelAware::Print(" ");
             MemUtil::DecimalToString(u16Slack, szStr);
             KernelAware::Print(szStr);
             KernelAware::Print("\n");
    }
}
void PrintCPUUsage(void)
    KernelAware::Print("Cpu usage\n");
    for (int i = 0; i < MAX_THREADS; i++) {</pre>
       if (apclActiveThreads[i] != 0) {
             KernelAware::Trace(0, __LINE__, (K_ADDR)apclActiveThreads[i],
      au16ActiveTime[i]);
        }
}
void ThreadCreate(Thread* pclThread_)
    KernelAware::Print("TC\n");
    CS_ENTER();
    for (uint8_t i = 0; i < MAX_THREADS; i++) {</pre>
         if (apclActiveThreads[i] == 0)
            apclActiveThreads[i] = pclThread_;
        }
    CS_EXIT();
    PrintThreadSlack();
    PrintCPUUsage();
void ThreadExit (Thread* pclThread_)
    KernelAware::Print("TX\n");
    CS_ENTER();
    for (uint8_t i = 0; i < MAX_THREADS; i++) {</pre>
        if (apclActiveThreads[i] == pclThread_) {
    apclActiveThreads[i] = 0;
             au16ActiveTime[i]
        }
    CS_EXIT();
    PrintThreadSlack();
    PrintCPUUsage();
void ThreadContextSwitch(Thread* pclThread_)
    KernelAware::Print("CS\n");
    static uint16_t u16LastTick = 0;
    auto u16Ticks = KernelTimer::Read();
    CS ENTER():
    for (uint8_t i = 0; i < MAX_THREADS; i++) {</pre>
        if (apclActiveThreads[i] == pclThread_) {
    aul6ActiveTime[i] += ul6Ticks - ul6LastTick;
        }
    CS_EXIT();
    u16LastTick = u16Ticks;
#endif
void WorkerMain1(void* arg_)
    auto* pclSem = static_cast<Semaphore*>(arg_);
    uint32_t u32Count = 0;
    \ensuremath{//} Do some work. Post a semaphore to notify the other thread that the
    // work has been completed.
    while (u32Count < 1000000) {
        u32Count++;
    KernelAware::Print("Worker1 -- Done Work\n");
```

```
pclSem->Post();
    // Work is completed, just spin now. Let another thread destory u16.
void WorkerMain2(void* arg_)
    uint32_t u32Count = 0;
while (u32Count < 1000000) {</pre>
       u32Count++;
    KernelAware::Print("Worker2 -- Done Work\n");
    // A dynamic thread can self-terminate as well:
    Scheduler::GetCurrentThread() ->Exit();
void ApplMain(void* unused_)
    Thread clMyThread;
    Semaphore clMySem;
    clMySem.Init(0, 1);
    while (1) {
    // Example 1 - create a worker thread at our current priority in order to
    ...
        clMyThread.Init(awApp2Stack, sizeof(awApp2Stack), 1, WorkerMain1, (void*)&clMySem);
        clMyThread.Start();
         \ensuremath{//} Do some work of our own in parallel, while the other thread works on its project.
        uint32_t u32Count = 0;
while (u32Count < 100000) {</pre>
            u32Count++;
        KernelAware::Print("Thread -- Done Work\n");
        PrintThreadSlack():
         // Wait for the other thread to finish its job.
        clMySem.Pend();
         // Once the thread has signalled ul6, we can safely call "Exit" on the thread to
         \ensuremath{//} remove it from scheduling and recycle it later.
        clMvThread.Exit();
         // Spin the thread up again to do something else in parallel. This time, the thread
         // will run completely asynchronously to this thread.
        clMyThread.Init(awApp2Stack, sizeof(awApp2Stack), 1, WorkerMain2, 0);
        clMyThread.Start();
        u32Count = 0;
        while (u32Count < 1000000) {</pre>
            u32Count++;
        KernelAware::Print("Thread -- Done Work\n");
         // Check that we're sure the worker thread has terminated before we try running the
         // test loop again.
        while (clMyThread.GetState() != ThreadState::Exit) {
        KernelAware::Print(" Test Done\n");
        Thread::Sleep(1000);
        PrintThreadSlack();
} // anonymous namespace
using namespace Mark3;
    // See the annotations in previous labs for details on init.
    Kernel::Init();
    Kernel::SetThreadCreateCallout(ThreadCreate);
    Kernel::SetThreadExitCallout(ThreadExit);
    Kernel::SetThreadContextSwitchCallout(ThreadContextSwitch);
    clApp1Thread.Init(awApp1Stack, sizeof(awApp1Stack), 1, App1Main, 0);
    clApplThread.Start();
```

```
Kernel::Start();
return 0;
```

Index

```
/home/moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/public/faske282
         types.h, 209
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/priomap. ←
/home/moslevin/projects/github/m3-repo/kernel/libs/mark3c/src/public/ppark36.
         h, 212, 222
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/profile. -
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1224pd/c/kernelprofile. ←
         cpp, 228, 229
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/atomic. ←
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega128246/gcc/kernelswi.
         cpp, 230
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/autoalloc. ←
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega128490gcc/kerneltimer. ←
         cpp, 231, 232
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/blocking. ←
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega12829202394ublic/kernelprofile. ←
         h, 234, 235
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/buffalogger. ←
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1282494ga3fpublic/kernelswi. ←
         h, 235, 236
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/condvar.←
h, 236, 237
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/eventflag. -
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega128496ga96ublic/portcfg. ←
         h, 237, 240
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/kernel. ←
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega128492gcc/public/threadport. ←
         h, 240, 242
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/kernelaware. ←
/home/moslevin/projects/github/m3-repo/kernel/src/arch/avr/atmega1l28499/gct/threadport.←
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/kerneldebug.
         cpp, 244, 245
/home/moslevin/projects/github/m3-repo/kernel/src/atomic. ←
                                                                 h, 301, 302
         cpp, 247
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/kerneltypes. ←
/home/moslevin/projects/github/m3-repo/kernel/src/autoalloc.←
                                                                 h, 307, 308
         cpp, 249
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/ksemaphore. ←
/home/moslevin/projects/github/m3-repo/kernel/src/blocking.
                                                                 h. 309
         cpp, 253, 254
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/II.
/home/moslevin/projects/github/m3-repo/kernel/src/condvar. <
                                                                 h, 310, 311
         cpp, 255
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/lockguard. ←
/home/moslevin/projects/github/m3-repo/kernel/src/eventflag. --
                                                                 h, 312, 313
         cpp, 256, 257
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/mailbox.←
/home/moslevin/projects/github/m3-repo/kernel/src/kernel. ←
                                                                 h, 313, 314
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/manual. -
         cpp, 261
/home/moslevin/projects/github/m3-repo/kernel/src/kernelaware. ← h, 316
         cpp. 263
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/mark3. ←
/home/moslevin/projects/github/m3-repo/kernel/src/ksemaphore. ← h, 316, 317
         cpp, 265, 266
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/mark3cfg. ←
/home/moslevin/projects/github/m3-repo/kernel/src/ll.←
                                                                 h, 318, 326
         cpp, 269
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/message. ←
/home/moslevin/projects/github/m3-repo/kernel/src/lockguard.←
                                                                 h, 328, 329
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/mutex.←
         cpp, 271, 272
/home/moslevin/projects/github/m3-repo/kernel/src/mailbox. ←
                                                                 h, 330, 332
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/notify. -
         cpp, 272, 273
/home/moslevin/projects/github/m3-repo/kernel/src/message. ←
                                                                 h, 332, 333
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/paniccodes. ←
         cpp, 276
/home/moslevin/projects/github/m3-repo/kernel/src/mutex.←
         cpp, 278, 279
                                                       /home/moslevin/projects/github/m3-repo/kernel/src/public/priomap. ←
/home/moslevin/projects/github/m3-repo/kernel/src/notify. ←
                                                                 h, 334, 335
```

/home/moslevin/projects/github/m3-repo/kernel/src/public/	pBrofible.←
h, 336, 337	Mark3::BlockingObject, 100
/home/moslevin/projects/github/m3-repo/kernel/src/public/	ф віаюки?n io ri ty
h, 337, 338	Mark3::BlockingObject, 100
/home/moslevin/projects/github/m3-repo/kernel/src/public/	readerwriter.←
h, 339	CS_ENTER
/home/moslevin/projects/github/m3-repo/kernel/src/public/h, 340, 341	schedihiteradport.h, 241 Claim
/home/moslevin/projects/github/m3-repo/kernel/src/public/	
h, 342, 343	Claim i
/home/moslevin/projects/github/m3-repo/kernel/src/public/h, 345, 346	_
/home/moslevin/projects/github/m3-repo/kernel/src/public/	
h, 346, 348	Mark3::PriorityMap, 155
/home/moslevin/projects/github/m3-repo/kernel/src/public/	• • •
h, 349, 350	Mark3::KernelTimer, 121
/home/moslevin/projects/github/m3-repo/kernel/src/public/	
h, 351	Mark3::Quantum, 160
/home/moslevin/projects/github/m3-repo/kernel/src/public/	
h. 352	Mark3::LinkListNode, 128
/home/moslevin/projects/github/m3-repo/kernel/src/quantu	
срр, 353	Mark3::ProfileTimer, 157
/home/moslevin/projects/github/m3-repo/kernel/src/reader	
	Mark3::KernelTimer, 121
cpp, 355 /home/moslevin/projects/github/m3-repo/kernel/src/schedu	
	Mark3::Thread, 177
cpp, 357, 358	
/home/moslevin/projects/github/m3-repo/kernel/src/thread	
cpp, 359, 360	Mark3::Mailbox, 132
/home/moslevin/projects/github/m3-repo/kernel/src/threadl	list.← DI
cpp, 366, 367	- ·
/home/moslevin/projects/github/m3-repo/kernel/src/timer.	DoubleLinkList
cpp, 368, 369	
/home/moslevin/projects/github/m3-repo/kernel/src/timerliscpp, 371, 372	
/home/moslevin/projects/github/m3-repo/kernel/src/tracebu	uffer.←
cpp, 375	Mark3::KernelTimer, 122
	event_flag_operation_t
AVR	mark3c.h, 214
portcfg.h, 238	EventFlagOperation
AcquireReader	Mark3, 91
Mark3::ReaderWriterLock, 162	Exit
AcquireReader_i	Mark3::Thread, 178
Mark3::ReaderWriterLock, 163	ExitSimulator
AcquireWriter	Mark3::KernelAware, 95
Mark3::ReaderWriterLock, 163	
AcquireWriter_i	GLOBAL_MESSAGE_POOL_SIZE
Mark3::ReaderWriterLock, 164	mark3cfg.h, 319
Add	GetAverage
Mark3::Atomic, 92	Mark3::ProfileTimer, 158
Mark3::CircularLinkList, 102	GetCode
Mark3::DoubleLinkList, 107	Mark3::Message, 141
Mark3::Scheduler, 165	GetCount
Mark3::ThreadList, 192	Mark3::MessageQueue, 146
Mark3::TimerList, 205	Mark3::Semaphore, 171
Mark3::TimerScheduler, 206	GetCurPriority
AddPriority	Mark3::Thread, 178
Mark3::ThreadList, 192	GetCurrent
AddThread	Mark3::ProfileTimer, 158
Mark3::Quantum, 159	Mark3::Thread, 178

0-40	Mark-Oul/arral 440
GetCurrentThread	Mark3::Kernel, 116
Mark3::Scheduler, 167	GetThreadList
GetData	Mark3::Scheduler, 168
Mark3::Message, 141	Highoot Priority
GetEventFlagMask	HighestPriority
Mark3::Thread, 179	Mark3::PriorityMap, 155
GetEventFlagMode	HighestWaiter
Mark3::Thread, 179	Mark3::ThreadList, 193
GetExpired	InheritPriority
Mark3::Thread, 179	Mark3::Thread, 183
GetExtendedContext	Init
Mark3::Thread, 180	Mark3::ConditionVariable, 105
GetHead	Mark3::Kernel, 116
Mark3::LinkList, 126	Mark3::LinkList, 127
Mark3::MessagePool, 143	Mark3::Mailbox, 133, 134
GetHeadPointer	Mark3::Message, 141
Mark3::Mailbox, 133	Mark3::MessagePool, 144
GetID	Mark3::MessageQueue, 146
Mark3::Thread, 180	Mark3::Mutex, 150
GetIdleThread	Mark3::Notify, 152
Mark3::Kernel, 115	Mark3::ProfileTimer, 158
GetInterval	Mark3::ReaderWriterLock, 164
Mark3::Timer, 198	Mark3::Scheduler, 168
GetMask	Mark3::Semaphore, 172
Mark3::EventFlag, 109	Mark3::Thread, 183, 184
GetNext	Mark3::Timer, 198
Mark3::LinkListNode, 128	Mark3::TimerList, 205
GetNextThread	Mark3::TimerScheduler, 207
Mark3::Scheduler, 167	InitIdle
GetOvertime	Mark3::Thread, 184
Mark3::KernelTimer, 122	InitStack
GetOwner	Mark3::ThreadPort, 195
Mark3::Thread, 180	InsertNodeBefore
GetPrev	Mark3::CircularLinkList, 103
Mark3::LinkListNode, 128	isAcquired
GetPriority	Mark3::LockGuard, 130
Mark3::Thread, 181	IsEnabled
GetQuantum	Mark3::Scheduler, 168
Mark3::Thread, 181	IsInitialized
GetStack	Mark3::BlockingObject, 101
Mark3::Thread, 181	Mark3::Timer, 198
GetStackSize	IsPanic
Mark3::Thread, 182	Mark3::Kernel, 116
GetStackSlack	IsSimulatorAware
Mark3::Thread, 182	Mark3::KernelAware, 95
GetState	IsStarted
Mark3::Thread, 182	Mark3::Kernel, 117
GetStopList	
Mark3::Scheduler, 167	K_WORD
GetTail	portcfg.h, 238
Mark3::LinkList, 126	KERNEL_AWARE_SIMULATION
GetTailPointer	mark3cfg.h, 320
Mark3::Mailbox, 133	KERNEL_EXTRA_CHECKS
GetThreadContextSwitchCallout	mark3cfg.h, 320
Mark3::Kernel, 115	KERNEL_NUM_PRIORITIES
GetThreadCreateCallout	mark3cfg.h, 320
Mark3::Kernel, 115	KERNEL_TIMERS_MINIMUM_DELAY_US
GetThreadExitCallout	mark3cfg.h, 320

KERNEL_TIMERS_THREADED	Mark3::Atomic, 92
mark3cfg.h, 321	Add, 92
KERNEL_TIMERS_TICKLESS	Set, 93
mark3cfg.h, 321	Sub, 93
KERNEL USE ATOMIC	TestAndSet, 94
mark3cfg.h, 321	Mark3::BlockingObject, 99
KERNEL_USE_AUTO_ALLOC	Block, 100
mark3cfg.h, 321	BlockPriority, 100
KERNEL USE CONDVAR	Islnitialized, 101
mark3cfg.h, 322	UnBlock, 101
KERNEL_USE_DYNAMIC_THREADS	•
mark3cfg.h, 322	Mark3::CircularLinkList, 102
	Add, 102
KERNEL_USE_EVENTFLAG	InsertNodeBefore, 103
mark3cfg.h, 322	PivotBackward, 103
KERNEL_USE_IDLE_FUNC	PivotForward, 103
mark3cfg.h, 322	Remove, 103
KERNEL_USE_MAILBOX	Mark3::ConditionVariable, 104
mark3cfg.h, 323	Init, 105
KERNEL_USE_MESSAGE	Wait, 105
mark3cfg.h, 323	Mark3::DoubleLinkList, 106
KERNEL_USE_PROFILER	Add, 107
mark3cfg.h, 323	DoubleLinkList, 106
KERNEL_USE_QUANTUM	Remove, 107
mark3cfg.h, 323	Mark3::EventFlag, 108
KERNEL USE READERWRITER	Clear, 109
mark3cfg.h, 324	GetMask, 109
KERNEL_USE_SEMAPHORE	
mark3cfg.h, 324	Set, 109
KERNEL_USE_STACK_GUARD	Wait, 110
mark3cfg.h, 324	Wait_i, 112
KERNEL_USE_THREAD_CALLOUTS	WakeMe, 112
mark3cfg.h, 324	Mark3::FakeThread_t, 113
KERNEL USE THREADNAME	Mark3::Kernel, 114
mark3cfg.h, 325	GetIdleThread, 115
KERNEL USE TIMEOUTS	GetThreadContextSwitchCallout, 115
	GetThreadCreateCallout, 115
mark3cfg.h, 325	GetThreadExitCallout, 116
KERNEL_USE_TIMERS	Init, 116
mark3cfg.h, 325	IsPanic, 116
Kernel_Init	IsStarted, 117
mark3c.h, 214	Panic, 117
Kernel_IsPanic	SetIdleFunc, 117
mark3c.h, 214	SetPanic, 118
Kernel_IsStarted	SetThreadContextSwitchCallout, 118
mark3c.h, 214	SetThreadCreateCallout, 119
Kernel_Panic	SetThreadExitCallout, 119
mark3c.h, 215	•
Kernel_SetPanic	Start, 120
mark3c.h, 215	Mark3::KernelAware, 94
Kernel_Start	ExitSimulator, 95
mark3c.h, 216	IsSimulatorAware, 95
,	Print, 95
LockGuard	ProfileInit, 96
Mark3::LockGuard, 129, 130	ProfileReport, 96
. ,	ProfileStart, 96
m_clSendSem	ProfileStop, 96
Mark3::Mailbox, 140	Trace, 97, 98
Mark3, 89	Mark3::KernelTimer, 120
EventFlagOperation, 91	ClearExpiry, 121
TimerCallback, 91	Config, 121
	····g, ·-·

DI, 122	Release, 150
EI, 122	WakeMe, 151
GetOvertime, 122	WakeNext, 151
Read, 122	Mark3::Notify, 152
RI, 123	Init, 152
SetExpiry, 123	Signal, 153
Start, 124	Wait, 153
Stop, 124	WakeMe, 154
SubtractExpiry, 124	Mark3::PriorityMap, 154
TimeToExpiry, 125	Clear, 155
Mark3::LinkList, 125	HighestPriority, 155
GetHead, 126	PriorityMap, 155
GetTail, 126	Set, 156
Init, 127	Mark3::ProfileTimer, 156
Mark3::LinkListNode, 127	ComputeCurrentTicks, 157
ClearNode, 128	GetAverage, 158
GetNext, 128	GetCurrent, 158
GetPrev, 128	Init, 158
Mark3::LockGuard, 129	Start, 158
isAcquired, 130	
•	Stop, 158
LockGuard, 129, 130	Mark3::Quantum, 159
Mark3::Mailbox, 130	AddThread, 159
CopyData, 132	ClearInTimer, 160
GetHeadPointer, 133	RemoveThread, 160
GetTailPointer, 133	SetInTimer, 160
Init, 133, 134	SetTimer, 160
m_clSendSem, 140	UpdateTimer, 161
MoveHeadBackward, 134	Mark3::ReaderWriterLock, 161
MoveHeadForward, 134	AcquireReader, 162
MoveTailBackward, 134	AcquireReader_i, 163
MoveTailForward, 135	AcquireWriter, 163
Receive, 135	AcquireWriter_i, 164
Receive_i, 136	Init, 164
ReceiveTail, 136, 137	Mark3::Scheduler, 164
Send, 137, 138	Add, 165
Send_i, 138	GetCurrentThread, 167
SendTail, 139	GetNextThread, 167
Mark3::Message, 140	GetStopList, 167
GetCode, 141	GetThreadList, 168
GetData, 141	Init, 168
Init, 141	IsEnabled, 168
SetCode, 142	QueueScheduler, 169
SetData, 142	Remove, 169
Mark3::MessagePool, 143	Schedule, 169
GetHead, 143	SetScheduler, 170
Init, 144	Mark3::Semaphore, 170
Pop, 144	GetCount, 171
Push, 144	Init, 172
Mark3::MessageQueue, 145	Pend, 172, 173
GetCount, 146	Pend i, 173
Init, 146	Post, 173
Receive, 146	WakeMe, 174
Receive, 146 Receive_i, 147	WakeNext, 174
Send, 147	Mark3::Thread, 174
Mark3::Mutex, 148	ContextSwitchSWI, 177
Claim, 149	Exit, 178
Claim_i, 150	GetCurrent 178
Init, 150	GetCurrent, 178

0.15 .15 .4 .4 .50	M to Till the out
GetEventFlagMask, 179	Mark3::TimerList, 204
GetEventFlagMode, 179	Add, 205
GetExpired, 179	Init, 205
GetExtendedContext, 180	Process, 205
GetID, 180	Remove, 205
GetOwner, 180	Mark3::TimerScheduler, 206
GetPriority, 181	Add, 206
GetQuantum, 181	Init, 207
GetStack, 181	Process, 207
GetStackSize, 182	Remove, 207
GetStackSlack, 182	mark3c.h
GetState, 182	event_flag_operation_t, 214
InheritPriority, 183	Kernel JaPania 214
Init, 183, 184	Kernel_IsPanic, 214
InitIdle, 184	Kernel_IsStarted, 214
SetCurrent, 185	Kernel_Panic, 215
SetEventFlagMask, 185	Kernel_SetPanic, 215
SetEventFlagMode, 185	Kernel_Start, 216 Scheduler Enable, 216
SetExpired, 186	— · · · · · · · · · · · · · · · · · · ·
SetExtendedContext, 186	Scheduler_GetCurrentThread, 216 Scheduler IsEnabled, 217
SetOurser 187	_ ·
SetOwner, 187	Thread_GetCurPriority, 217
SetPriority Page 197	Thread Cat Priority 218
SetPriorityBase, 187	Thread_GetPriority, 218
SetQuantum, 188	Thread_GetStackSlack, 218
SetState, 188	Thread_GetState, 219
Sleep, 189	Thread_Init, 219
Start, 189	Thread_SetID, 220
Stop, 189	Thread_SetPriority, 221
USleep, 189	Thread Start, 221
Yield, 190	Thread Viold 200
Mark3::ThreadList, 190	Thread_Yield, 222
Add, 192	mark3cfg.h
AddPriority, 192	GLOBAL_MESSAGE_POOL_SIZE, 319
HighestWaiter, 193	KERNEL_AWARE_SIMULATION, 320
Remove, 193	KERNEL_EXTRA_CHECKS, 320
SetMapPointer, 193	KERNEL_NUM_PRIORITIES, 320
SetPriority, 194	KERNEL_TIMERS_MINIMUM_DELAY_US, 320
ThreadList, 191	KERNEL_TIMERS_THREADED, 321
Mark3::ThreadPort, 194	KERNEL_TIMERS_TICKLESS, 321
InitStack, 195	KERNEL_USE_ATOMIC, 321
StartThreads, 195	KERNEL_USE_AUTO_ALLOC, 321
Mark3::Timer, 196	KERNEL_USE_CONDVAR, 322
GetInterval, 198	KERNEL_USE_DYNAMIC_THREADS, 322
Init, 198	KERNEL_USE_EVENTFLAG, 322
IsInitialized, 198	KERNEL_USE_IDLE_FUNC, 322
SetCallback, 198	KERNEL_USE_MAILBOX, 323
SetData, 199	KERNEL_USE_MESSAGE, 323
SetFlags, 199	KERNEL_USE_PROFILER, 323
SetIntervalMSeconds, 199	KERNEL_USE_QUANTUM, 323
SetIntervalSeconds, 200	KERNEL_USE_READERWRITER, 324
SetIntervalTicks, 200	KERNEL_USE_SEMAPHORE, 324
SetIntervalUSeconds, 200	KERNEL_USE_STACK_GUARD, 324
SetOwner, 201	KERNEL_USE_THREAD_CALLOUTS, 324
SetTolerance, 201	KERNEL_USE_THREADNAME, 325
Start, 201, 203	KERNEL_USE_TIMEOUTS, 325
Stop, 203	KERNEL_USE_TIMERS, 325
Timer, 197	SAFE_UNLINK, 325

THREAD_QUANTUM_DEFAULT, 326	Read
MoveHeadBackward	Mark3::KernelTimer, 122
Mark3::Mailbox, 134	Receive
MoveHeadForward	Mark3::Mailbox, 135
Mark3::Mailbox, 134	Mark3::MessageQueue, 146
MoveTailBackward	Receive_i
Mark3::Mailbox, 134	Mark3::Mailbox, 136
MoveTailForward	Mark3::MessageQueue, 147
Mark3::Mailbox, 135	ReceiveTail
	Mark3::Mailbox, 136, 137
PORT_PRIO_TYPE	Release
portcfg.h, 239	Mark3::Mutex, 150
PORT_SYSTEM_FREQ	Remove
portcfg.h, 239	Mark3::CircularLinkList, 103
PORT TIMER COUNT TYPE	Mark3::DoubleLinkList, 107
portcfg.h, 239	Mark3::Scheduler, 169
PORT TIMER FREQ	Mark3::ThreadList, 193
portcfg.h, 239	Mark3::TimerList, 205
Panic	Mark3::TimerScheduler, 207
Mark3::Kernel, 117	RemoveThread
Pend	Mark3::Quantum, 160
Mark3::Semaphore, 172, 173	RI
Pend i	
Mark3::Semaphore, 173	Mark3::KernelTimer, 123
PivotBackward	SAFE UNLINK
Mark3::CircularLinkList, 103	mark3cfg.h, 325
PivotForward	Schedule
	Mark3::Scheduler, 169
Mark3::CircularLinkList, 103	Scheduler Enable
Pop Mark Sul Manager Page 1 1 1 1 1	mark3c.h, 216
Mark3::MessagePool, 144	Scheduler_GetCurrentThread
portcfg.h	mark3c.h, 216
AVR, 238	
K_WORD, 238	Scheduler_IsEnabled
PORT_PRIO_TYPE, 239	mark3c.h, 217
PORT_SYSTEM_FREQ, 239	Send
PORT_TIMER_COUNT_TYPE, 239	Mark3::Mailbox, 137, 138
PORT_TIMER_FREQ, 239	Mark3::MessageQueue, 147
Post	Send_i
Mark3::Semaphore, 173	Mark3::Mailbox, 138
Print	SendTail
Mark3::KernelAware, 95	Mark3::Mailbox, 139
PriorityMap	Set
Mark3::PriorityMap, 155	Mark3::Atomic, 93
Process	Mark3::EventFlag, 109
Mark3::TimerList, 205	Mark3::PriorityMap, 156
Mark3::TimerScheduler, 207	SetCallback
ProfileInit	Mark3::Timer, 198
Mark3::KernelAware, 96	SetCode
ProfileReport	Mark3::Message, 142
Mark3::KernelAware, 96	SetCurrent
ProfileStart	Mark3::Thread, 185
Mark3::KernelAware, 96	SetData
	M 10 M 440
ProfileStop	Mark3::Message, 142
ProfileStop Mark3::KernelAware, 96	Mark3::Message, 142 Mark3::Timer, 199
Mark3::KernelAware, 96 Push	
Mark3::KernelAware, 96 Push	Mark3::Timer, 199
Mark3::KernelAware, 96	Mark3::Timer, 199 SetEventFlagMask
Mark3::KernelAware, 96 Push	Mark3::Timer, 199 SetEventFlagMask Mark3::Thread, 185
Mark3::KernelAware, 96 Push Mark3::MessagePool, 144	Mark3::Timer, 199 SetEventFlagMask Mark3::Thread, 185 SetEventFlagMode

Mark3::Thread, 186	Mark3::Timer, 201, 203
SetExpiry	StartThreads
Mark3::KernelTimer, 123	Mark3::ThreadPort, 195
SetExtendedContext	Stop
Mark3::Thread, 186	Mark3::KernelTimer, 124
SetFlags 100	Mark3::ProfileTimer, 158
Mark3::Timer, 199	Mark3::Thread, 189
SetID	Mark3::Timer, 203 Sub
Mark3::Thread, 186	
SetIdleFunc	Mark3::Atomic, 93
Mark3::Kernel, 117	SubtractExpiry Mark3::KernelTimer, 124
SetInTimer	MarksKernerriner, 124
Mark3::Quantum, 160	THREAD QUANTUM DEFAULT
SetIntervalMSeconds	mark3cfg.h, 326
Mark3::Timer, 199	TIMERLIST FLAG EXPIRED
SetIntervalSeconds	timer.h, 347
Mark3::Timer, 200	TestAndSet
SetIntervalTicks	Mark3::Atomic, 94
Mark3::Timer, 200	Thread GetCurPriority
SetIntervalUSeconds	mark3c.h, 217
Mark3::Timer, 200	Thread GetID
SetMapPointer	mark3c.h, 218
Mark3::ThreadList, 193	Thread_GetPriority
SetOwner	mark3c.h, 218
Mark3::Thread, 187	Thread GetStackSlack
Mark3::Timer, 201	_ mark3c.h, 218
SetPanic	Thread GetState
Mark3::Kernel, 118	_ mark3c.h, 219
SetPriority	Thread Init
Mark3::Thread, 187	_ mark3c.h, 219
Mark3::ThreadList, 194	Thread SetID
SetPriorityBase	mark3c.h, 220
Mark3::Thread, 187	Thread_SetPriority
SetQuantum	mark3c.h, 221
Mark3::Thread, 188	Thread_Start
SetScheduler	mark3c.h, 221
Mark3::Scheduler, 170	Thread_Stop
SetState	mark3c.h, 221
Mark3::Thread, 188	Thread_Yield
SetThreadContextSwitchCallout	mark3c.h, 222
Mark3::Kernel, 118	ThreadList
SetThreadCreateCallout	Mark3::ThreadList, 191
Mark3::Kernel, 119	threadport.h
SetThreadExitCallout	CS_ENTER, 241
Mark3::Kernel, 119	TimeToExpiry
SetTimer	Mark3::KernelTimer, 125
Mark3::Quantum, 160	Timer
SetTolerance	Mark3::Timer, 197
Mark3::Timer, 201	timer.h
Signal	TIMERLIST_FLAG_EXPIRED, 347
Mark3::Notify, 153	TimerCallback
Sleep	Mark3, 91
Mark3::Thread, 189	Trace
Start Mark Out Cornel 100	Mark3::KernelAware, 97, 98
Mark3::Kernel, 120	1101
Mark3::KernelTimer, 124	USleep
Mark3::ProfileTimer, 158	Mark3::Thread, 189
Mark3::Thread, 189	UnBlock

```
Mark3::BlockingObject, 101
UpdateTimer
    Mark3::Quantum, 161
Wait
    Mark3::ConditionVariable, 105
    Mark3::EventFlag, 110
    Mark3::Notify, 153
Wait i
    Mark3::EventFlag, 112
WakeMe
    Mark3::EventFlag, 112
    Mark3::Mutex, 151
    Mark3::Notify, 154
    Mark3::Semaphore, 174
WakeNext
    Mark3::Mutex, 151
    Mark3::Semaphore, 174
Yield
    Mark3::Thread, 190
```