DNeasy® PowerLyzer® PowerSoil® Kit

The DNeasy PowerLyzer PowerSoil Kit can be stored at room temperature ($15-25^{\circ}$ C) until the expiry date printed on the box label.

Further information

- Safety Data Sheets: www.qiagen.com/safety
- Technical assistance: support.qiagen.com

Notes before starting

- Perform all centrifugation steps at room temperature (15–25°C)
- If Solution C1 has precipitated, heat at 60°C until precipitate dissolves.
- Shake to mix Solution C4 before use
- 1. Add up to 0.25 g of soil sample to the PowerBead Tube provided.
- 2. Add 750 µl of PowerBead Solution to the PowerBead Tube.
- 3. Add 60 µl of Solution C1 and invert several times or vortex briefly.
- 4. Bead beating options:
 - A. PowerLyzer 24 homogenizer: Place the PowerLyzer Glass Bead Tubes into the tube holder for the PowerLyzer 24. The PowerBead Tubes must be balanced on the tube holder. Run the samples for a time and RPM suitable for your soil type.
 Note: For clay soils, 4,000 RPM for 45 s is the best starting point. For loose, granular and high organic soils, 2,500 RPM for 45 s will provide an optimal result
 - B. Vortex: Secure the PowerBead Tubes horizontally using a Vortex Adapter tube holder (cat. no. 13000–V1–24). Vortex at maximum speed for 10 min.
 Note: If you are using the 24 place Vortex Adapter for more than 12 preps, increase the vortex time by 5–10 min.
- 5. Centrifuge Bead Tubes at 10,000 x g for 30 s. **Do not** exceed 10,000 x g. **Note:** Centrifuge for 3 min at 10,000 x g for clay soils or if your soil is not completely pelleted after 30 s.
- 6. Transfer the supernatant to a clean 2 ml collection tube (provided).

Note: Expect 400–500 µl. Supernatant may still contain some soil particles.

7. Add 250 μ l of Solution C2 and vortex for 5 s. Incubate at 2–8°C for 5 min.

Note: You can skip the 5 min incubation. However, if you have already validated the PowerSoil extractions with the incubation we recommend you retain the step.

- 8. Centrifuge the tubes for 1 min at $10,000 \times g$. Avoiding the pellet, transfer up to $600 \, \mu l$ of supernatant to a clean 2 ml collection tube (provided).
- 9. Add 200 µl of Solution C3 and vortex briefly. Incubate at 2-8°C for 5 min.

Note: You can skip the 5 min incubation. However, if you have already validated the PowerSoil extractions with the incubation we recommend you retain the step.

- 10. Centrifuge the tubes for 1 min at $10,000 \times g$. Avoiding the pellet, transfer up to $750 \, \mu$ l of supernatant into a clean 2 ml collection tube (provided).
- 11. Add 1200 μ l of Solution C4 to the supernatant and vortex for 5 s.
- 12. Load 675 μ l of the supernatant onto a MB Spin Column and centrifuge at 10,000 \times g for 1 min. Discard the flow through and add an additional 675 μ l of supernatant.
- 13. Centrifuge at $10,000 \times g$ for 1 minute. Load the remaining supernatant onto the MB Spin Column and centrifuge at $10,000 \times g$ for 1 min.

Note: A total of three loads for each sample processed are required.

- 14. Add 500 μ l of Solution C5 and centrifuge for 30 s at 10,000 \times g.
- 15. Discard the flow through. Centrifuge again for 1 min at $10,000 \times g$.
- 16. Carefully place spin filter in a clean 2 ml collection tube (provided). Avoid splashing any Solution C5 onto the MB Spin Column.
- 17. Add 100 µl of Solution C6 to the center of the white filter membrane. Alternatively, you may use sterile DNA-Free PCR Grade Water or TE buffer (cat. no. 17000-10).
- 18. Centrifuge for 30 s at 10,000 x g. Discard the MB Spin Column
- 19. The DNA is now ready for downstream applications.

Note: We recommend storing DNA frozen (-20° to -80°C) as Solution C6 does not contain EDTA. To concentrate DNA see the Hints & Troubleshooting Guide.

For up-to-date licensing information and product-specific disclaimers, see the respective QIAGEN kit handbook or user manual. Trademarks: QIAGEN®, Sample to Insight®, DNeasy®, PowerLyzer®, PowerSoil® (QIAGEN Group). 1104492 06/2016 HB-2214-001 © 2016 QIAGEN, all rights reserved.