## TTK4130 Formula Sheet

## Part I

# Modeling

## 1 Some useful models

## 1.1 Mass spring damper

$$m\ddot{x} + c\dot{x} + kx = 0 \tag{1}$$

$$\ddot{x} + 2\zeta\omega_0\dot{x} + \omega_0^2 x = 0 \tag{2}$$

Note: A driving force F(t) could be included on the right hand side.

## 1.2 Capacitor and inductor equations

$$i_C(t) = C\frac{dv_C}{dt}(t) \tag{3}$$

$$v_L(t) = L \frac{di_L}{dt}(t) \tag{4}$$

## 1.3 Pendulum equation

$$\ddot{\theta} + \frac{g}{I}\sin(\theta) = 0\tag{5}$$

For  $\theta \ll 1$  we get the approximation

$$\ddot{\theta} + \frac{g}{l}\theta = 0 \tag{6}$$

with period

$$T_0 = \frac{2\pi}{\omega_0} = 2\pi \sqrt{\frac{l}{g}} \tag{7}$$

## 2 Passivity

A system consisting of a parallel or feedback interconnection of passive subsystems, is itself passive.

**Definition:** If the following inequality is satisfied for all u and  $T \geq 0$ , then the system is passive.

$$\int_0^T y(t)u(t)dt \ge -E_0 \tag{8}$$

Note that if the roles of u and y are reversed, i.e. y is taken to be the input and u the output, then the inequality still holds.

Interpretation of this definition based on energy conservation: The product uy has dimension power, thus we can think about the integral as the energy supplied by u or, equivalently, the energy absorbed by the system.

- 1. If  $\int_0^T y(t)u(t)dt \ge 0$ , energy is only absorbed. This inequality will hold for a passive memoryless system (e.g. a circuit with only a resistor).
- 2. If  $\int_0^T y(t)u(t)dt \ge -E_0$ , the system can supply a limited amount of energy to the outside, due to initial conditions of energy storage elements, such as capacitors and inductors.
- 3. If  $\int_0^T y(t)u(t)dt \to -\infty$ , the system is active.

A system is passive iff its transfer function is positive real.

#### Definition of a positive real transfer function:

- 1. All poles of H(s) have real parts less than or equal to zero.
- 2. Re  $H(j\omega) \ge 0 \ \forall \ \omega$  that are not poles of H(s).
- 3. If  $j\omega_0$  is a pole, it is simple and  $\operatorname{Res}_{s=j\omega_0} H(s) = \lim_{s\to j\omega_0} (s-j\omega_0) H(s)$  is real and positive. If H(s) has a pole at infinity, it is simple, and  $R_{\infty} = \lim_{\omega \to \infty} \frac{H(j\omega)}{j\omega}$  exists, and is real and positive.

There is also the *storage function* approach for determining passivity. Consider a state space model  $\dot{x} = f(x, u)$ , y = h(x). If there exists a storage function  $V(x) \geq 0$  and dissipation function  $g(x) \geq 0$ , such that

$$\dot{V} = u^{\top} y - g(x), \tag{9}$$

then the system is passive.

# Part II Motors and actuators

- 3 Electrical motors
- 4 Hydraulic motors
- 5 Friction

## Part III

# **Dynamics**

## 6 Rigid body kinematics

#### 6.1 Rotation matrices

Let  $\{\vec{a}_1, \vec{a}_2, \vec{a}_3\}$  and  $\{\vec{b}_1, \vec{b}_2, \vec{b}_3\}$  be the orthogonal bases of two coordinate frames. Then the coordinate transformation from frame b to frame a is given by

$$\mathbf{R}_b^a = \begin{pmatrix} \mathbf{b}_1^a & \mathbf{b}_2^a & \mathbf{b}_3^a \end{pmatrix} \tag{10}$$

That is,

$$\mathbf{v}^a = \mathbf{R}_b^a \mathbf{v}^b \tag{11}$$

The  $\mathbf{R}_b^a$  matrix can also be thought of simply as a rotation of a vector. For a second, forget that the b frame exists, and think only about the a frame. A simple example is

$$\mathbf{b}_1^a = \mathbf{R}_b^a \mathbf{a}_1^a \tag{12}$$

which shows that the first basis vector of the a frame is rotated to the first basis vector of the b frame, when everything is referred to frame a. In this sense the matrix represents a rotation from a to b.

## 6.2 Homogeneous transformation matrices

$$T_b^a = \begin{pmatrix} R_b^a & r_{ab}^a \\ \mathbf{0}^\top & 1 \end{pmatrix} \tag{13}$$

where  $r_{ab}^a$  is the origin of frame b in a coordinates.

#### 6.3 Differentiation of vectors and matrices

$$\frac{^{a}d}{dt}\vec{u} = \frac{^{b}d}{dt}\vec{u} + \vec{\omega}_{ab} \times \vec{u},\tag{14}$$

Skew-symmetric form of coordinate vector

$$\mathbf{u}^{\times} := \begin{pmatrix} 0 & -u_3 & u_2 \\ u_3 & 0 & -u_1 \\ -u_2 & u_1 & 0 \end{pmatrix} \tag{15}$$

Skew-symmetric form of angular velocity vector

$$(\boldsymbol{\omega}_{ab}^a)^{\times} = \dot{\mathbf{R}}_b^a (\mathbf{R}_b^a)^{\top} \tag{16}$$

Coordinate transformation

$$(\boldsymbol{\omega}_{ab}^a)^{\times} = \mathbf{R}_b^a (\boldsymbol{\omega}_{ab}^b)^{\times} \mathbf{R}_a^b, \quad \mathbf{R}_a^b = (\mathbf{R}_b^a)^{-1} = (\mathbf{R}_b^a)^{\top}$$
 (17)

#### 6.4 Kinematic differential equations

For Euler angles, when the middle rotation is  $\frac{\pi}{2}$  radians, the E matrix in the kinematic differential equation is singular. This is because this rotation moves the third axis of rotation to the first axis of rotation, such that we lose a degree of freedom.

## 6.5 Coordinate systems

Cylindrical coordinates  $(r, \theta, z)$ :

$$x = r\cos(\theta) \tag{18}$$

$$y = r\sin(\theta) \tag{19}$$

$$z = z \tag{20}$$

$$r = \sqrt{x^2 + y^2} \tag{21}$$

$$\theta = \begin{cases} 0 \text{ if } x = 0 \text{ and } y = 0\\ \arctan(\frac{y}{x}) \text{ if } x > 0\\ \arctan(\frac{y}{x}) + \pi \text{ if } x < 0 \text{ and } y \ge 0\\ \arctan(\frac{y}{x}) - \pi \text{ if } x < 0 \text{ and } y < 0\\ \frac{\pi}{2} \text{ if } x = 0 \text{ and } y > 0\\ -\frac{\pi}{2} \text{ if } x = 0 \text{ and } y < 0 \end{cases}$$

$$(22)$$

$$dV = dxdydz = rdrd\theta dz \tag{23}$$

Spherical coordinates  $(r, \varphi, \theta)$ ,  $\varphi$  angle from z-axis:

$$x = r\sin(\varphi)\cos(\theta) \tag{24}$$

$$y = r\sin(\varphi)\sin(\theta) \tag{25}$$

$$z = r\cos(\varphi) \tag{26}$$

$$r = \sqrt{x^2 + y^2 + z^2} \tag{27}$$

$$\theta$$
 defined as above. (28)

$$dV = dxdydz = r^2 \sin(\varphi)drd\varphi d\theta \tag{29}$$

Note that  $r \geq 0$ ,  $0 \leq \theta \leq 2\pi$  and  $0 \leq \varphi \leq \pi$  (typical definition). The definition of  $\theta$  above has the range  $(-\pi, \pi]$ , to obtain only positive results  $2\pi$  can be added to negative values.

Next I list the position, velocity and acceleration vectors for these coordinate systems. Cylindrical first:

$$\vec{r} = r\vec{e}_r + z\vec{e}_z \tag{30}$$

$$\vec{v} = \dot{r}\vec{e_r} + r\dot{\theta}\vec{e_\theta} + \dot{z}\vec{e_z} \tag{31}$$

$$\vec{a} = (\ddot{r} - r\dot{\theta}^2)\vec{e}_r + (r\ddot{\theta} + 2\dot{r}\dot{\theta})\vec{e}_\theta + \ddot{z}\vec{e}_z$$
 (32)

Spherical:

$$\vec{r} = r\vec{e_r} \tag{33}$$

$$\vec{v} = \dot{r}\vec{e}_r + r\,\dot{\theta}\vec{e}_\theta + r\,\dot{\varphi}\,\sin\theta\vec{e}_\varphi \tag{34}$$

$$\vec{a} = \left(a - r\dot{\theta}^2 - r\dot{\varphi}^2 \sin^2\theta\right) \vec{e_r} \tag{35}$$

$$+ \left( r\ddot{\theta} + 2\dot{r}\dot{\theta} - r\dot{\varphi}^2 \sin\theta \cos\theta \right) \vec{e}_{\theta} \tag{36}$$

$$+ \left( r\ddot{\varphi} \sin \theta + 2\dot{r} \dot{\varphi} \sin \theta + 2r \dot{\theta} \dot{\varphi} \cos \theta \right) \vec{e}_{\varphi}$$
 (37)

### 6.6 The center of mass

The mass of a rigid body b is

$$m = \int_{b} dm = \int_{b} \rho(x, y, z) dV \tag{38}$$

The center of mass  $\vec{r}_c$  is defined as

$$\vec{r}_c = \frac{1}{m} \int_b \vec{r}_p dm \tag{39}$$

where  $\vec{r}_p$  is the position of a mass element dm that is fixed in frame b. The x-coordinate of the center of mass is given by

$$x_c = \frac{1}{m} \iiint_b x_p \rho(x, y, z) dV \tag{40}$$

The definitions for y and z are exactly the same. Typically  $(x_p, y_p, z_p) = (x, y, z)$ .

#### 6.7 Other useful formulas

Relation between linear and angular velocity

$$v = \omega r \tag{41}$$

## 7 Newton-Euler equations of motion

## 7.1 Kinetic energy

$$\mathcal{T} = \frac{1}{2} m (\mathbf{v}_c^b)^\top \mathbf{v}_c^b + \frac{1}{2} (\boldsymbol{\omega}_{ib}^b)^\top \mathbf{M}_{b/c}^b \boldsymbol{\omega}_{ib}^b$$
(42)

The subscript c denotes the center of mass and the superscript b denotes a coordinate vector/matrix in frame b.  $\omega_{ib}^b$  is the angular velocity of frame b relative to frame i.  $\mathbf{M}_{b/c}^b$  is the inertia matrix of b about c, i.e. the inertia matrix of the rigid body about the center of mass.

#### 7.2 Inertia matrix

$$\mathbf{M}_{b/c}^{b} = -\int_{b} (\mathbf{r}^{b})^{\times} (\mathbf{r}^{b})^{\times} dm = \int_{b} \left[ (\mathbf{r}^{b})^{\top} \mathbf{r}^{b} \mathbf{I} - \mathbf{r}^{b} (\mathbf{r}^{b})^{\top} \right] dm \tag{43}$$

Fun facts: Swap the *b* superscripts with *i* on the right hand side to get  $\mathbf{M}_{b/c}^i$ .  $\mathbf{M}_{b/c}^b$  is positive definite, since the kinetic energy  $\mathcal{T} \geq 0$ . Note that the integral above is a triple integral of a  $3 \times 3$ -matrix. About a specified axis the formula reduces to

$$I = \int_{b} (\mathbf{r}^{b})^{\top} \mathbf{r}^{b} dm \tag{44}$$

#### 7.3 Parallel axis theorem

The inertia matrix of b about a point o is given by

$$\mathbf{M}_{b/o}^{b} = \mathbf{M}_{b/c}^{b} - m(\mathbf{r}_{g}^{b})^{\times}(\mathbf{r}_{g}^{b})^{\times} = \mathbf{M}_{b/c}^{b} + m\left[(\mathbf{r}_{g}^{b})^{\top}\mathbf{r}_{g}^{b}\mathbf{I} - \mathbf{r}_{g}^{b}(\mathbf{r}_{g}^{b})^{\top}\right]$$
(45)

where  $\mathbf{r}_g^b$  is the vector from the point o to the center of mass c. If o is the origin this corresponds to  $\mathbf{r}_c^b$ . In its simplest form with two parallel axes, the formula reduces to

$$I = I_c + md^2 (46)$$

where  $I_c$  is the moment of inertia about the axis through the center of mass and d is the distance between the axes.

## 7.4 Other useful formulas

Relationships between torque, angular momentum and angular velocity

$$\vec{\tau} = \vec{r} \times \vec{F} \tag{47}$$

$$\vec{\tau} = \frac{d\vec{L}}{dt} \tag{48}$$

$$\vec{\tau} = I\dot{\omega} \tag{49}$$

$$P = \tau \omega \tag{50}$$

## 8 Lagrangian dynamics

Lagrangian

$$\mathcal{L}(\mathbf{q}, \dot{\mathbf{q}}, t) = \mathcal{T}(\mathbf{q}, \dot{\mathbf{q}}, t) - \mathcal{U}(\mathbf{q}) \tag{51}$$

Lagrange's equation of motion

$$\frac{d}{dt} \left( \frac{\partial \mathcal{L}}{\partial \dot{q}_i} \right) - \frac{\partial \mathcal{L}}{\partial q_i} = \tau_i \tag{52}$$

Generalized force

$$Q_i = \sum_{k=1}^{N} \frac{\partial \vec{r_k}}{\partial q_i} \cdot \vec{F_k} \tag{53}$$

## Part IV

# Balance equations

## 9 Kinematics of flow

#### 9.1 Material derivative

Let  $\mathbf{x}$  be the position of some fluid particle, with velocity  $\dot{\mathbf{x}} = \mathbf{v}$ . Further, let  $\varphi$  be some quantity related to the particle, e.g. its temperature. The material derivative of  $\varphi$  is then defined as

$$\frac{D\varphi}{Dt} = \frac{\partial\varphi}{\partial t} + \mathbf{v}^{\mathsf{T}}\nabla\varphi \tag{54}$$

## 10 Mass, momentum and energy balances

#### 10.1 Mass balance

Level of tank

$$\frac{d}{dt}(\rho Ah) = w_1 - w_2 \tag{55}$$

$$\dot{h} = \frac{1}{\rho A}(w1 - w2) \tag{56}$$

Remember that the pressure at the bottom of a (open) tank is  $\rho gh$ .

#### 10.2 Momentum balance

Bernoulli's equation for stationary frictionless flow along a streamline for an incompressible fluid

$$\frac{1}{2}(v_2^2 - v_1^2) + \frac{p_2 - p_1}{\rho} + (z_2 - z_1)g = 0$$
 (57)

See page 426-427 for relevant examples on momentum balances.

#### 10.3 Energy balance

The total energy of a volume element dV is

$$\rho edV,$$
 (58)

where  $e = u + \frac{1}{2}v^2 + \phi$ , i.e. the sum of specific internal, kinetic and potential energy. Internal energy, enthalpy, heat capacities and temperature have the following relationships

$$h = c_p T (59)$$

$$u = c_v T (60)$$

Note that all quantities (except temperature) are specific (per unit mass) in these equations. The specific enthalpy is given by

$$h = u + \frac{p}{\rho},\tag{61}$$

where u is the internal energy. See page 443-445 for relevant examples of energy balances.

## Part V

# Simulation

We are concerned with solving the IVP

$$\dot{y} = f(y, t), \quad y(t_0) = y_0$$
 (62)

The Jacobian of the system is defined as

$$J = \frac{\partial f}{\partial y}(y, t) \tag{63}$$

Note that the Jacobian is A for a linear, time-invariant system  $\dot{x} = Ax + Bu$ .

## 11 Stability functions

The stability of a numerical method is ensured if  $|R(h\lambda_i)| \leq 1$  for all eigenvalues  $\lambda_i$ .

## 11.1 ERK methods

$$R_E(h\lambda) = \det \left[ I - h\lambda(A - \mathbf{1}b^{\top}) \right], \text{ where } \mathbf{1} = (1, ..., 1)^{\top}$$
 (64)

Note that  $R_E(h\lambda)$  will be a polynomial in  $h\lambda$  of order less than or equal to  $\sigma$  (the number of stages).

#### 11.2 IRK methods

$$R(h\lambda) = \left[1 + h\lambda b^{\top} (I - h\lambda A)^{-1} \mathbf{1}\right]$$
 (65)

$$R(h\lambda) = \frac{\det\left[I - h\lambda(A - \mathbf{1}b^{\top})\right]}{\det(I - h\lambda A)}$$
(66)

## 12 Stability of RK methods

#### 12.1 Aliasing

The Nyquist frequency is half of the sampling rate

$$\omega_{\text{Nyquist}} = \frac{1}{2} \cdot \frac{2\pi}{h}, \text{ where } h \text{ is the step size.}$$
(67)

Two systems oscillating at a low frequency  $\omega < \omega_{\rm Nyquist}$  and a high frequency  $\omega + 2k\frac{\pi}{h} > \omega_{\rm Nyquist}$  (k integer) will intercept at all sampling points, and therefore a solver will not be able to distinguish them. More specifically, the solver will believe that the system with higher frequency is the system with lower frequency, when fitting the curve.

## 12.2 A- and L-stability

**Definition:** A method is A-stable if  $|R(h\lambda)| \le 1 \ \forall \ \operatorname{Re} \lambda \le 0$ .

This definitions means that an A-stable method is stable for all stable test systems  $\dot{y} = \lambda y$ . Note also that no ERK method can be A-stable, since  $|R_E(h\lambda)| \to \infty$  as  $|\lambda| \to \infty$ .

**Definition:** A method is L-stable if it is A-stable and  $|R(j\omega h)| \to 0$  when  $\omega \to \infty \ \forall$  systems  $\dot{y} = j\omega y$ .

A-stable methods can suffer from aliasing for systems with fast dynamics (faster than Nyquist frequency), whereas an L-stable method will simply damp out these fast dynamics. This means that the L-stable method might give a better qualitative representation of what the actual solution looks like.

## 12.3 Stiffly accurate methods and algebraic stability

**Definition:** A method is stiffly accurate if

$$\det(A) \neq 0 \text{ and } b = A^{\top}[0, 0, ..., 1]^{\top}$$
 (68)

Note: A-stable and stiffly accurate  $\implies$  L-stable.

**Definition:** A method is algebraically stable if

$$M = \operatorname{diag}(b)A + (\operatorname{diag}(b)A)^{\top} + bb^{\top}$$
(69)

is positive semi-definite. Note: Algebraically stable  $\implies$  A-stable.

## 13 DAEs

A fully implicit ODE,  $F(\dot{x}, x, u) = 0$  is a DAE if  $\frac{\partial F}{\partial \dot{x}}$  is rank deficient (note that the partial derivative is with respect to  $\dot{x}$ , not x).

Method for finding index (one way to go about it):

- Differentiate algebraic equation(s) g(x, z) until you can solve for the algebraic variable(s).
- The DAE system is now index 1. If you differentiated p times in the previous step, the index is p + 1.

## 14 Advanced topics

#### 14.1 Automatic adjustment of step size

The step size h can be selected so that the desired accuracy is obtained. Variable-step methods are useful for stiff systems (large spread in eigenvalues of Jacobian) and systems with strong nonlinearities (eigenvalues of Jacobian of linearization change a lot for each time step).

Idea: Estimate local error and adjust h such that the local error is less than the specified tolerance.

Implementation:

- 1. Compute the next iteration with two different methods:  $y_{n+1}$  with a method of order p and  $\hat{y}_{n+1}$  with a method of order  $\hat{p} = p + 1$ .
- 2. The local exact solution is then

$$y_L(t_n; t_{n+1}) = y_{n+1} + e_{n+1} = \hat{y}_n + \hat{e}_{n+1}$$
(70)

with  $e_{n+1} = O(h^{p+1})$  and  $\hat{e}_{n+1} = O(h^{p+2})$ .

3. Since  $\hat{e}_{n+1} \ll e_{n+1}$ , we get the following

$$y_{n+1} - \hat{y}_n = e_{n+1} - \hat{e}_{n+1} \approx e_{n+1} \tag{71}$$

h can then be chosen such that the local error  $e_{n+1}$  is as small as desired.

Since  $\hat{y}_{n+1}$  is computed with a higher-order method than  $y_{n+1}$ , it would make sense to use that for the next iteration instead, this is called local extrapolation. Whichever solution is chosen as  $\hat{y}_{n+1}$  is called the *embedded solution*.

## 14.2 Event detection

Let the event be given by

$$g(y,t) = 0 (72)$$

e.g. a bouncing ball hitting the floor (crossing the x-axis). By checking for sign changes in g for each iteration, the time  $t_n + \alpha$  of the event can be found by solving

$$g[y_n(\alpha), t_n + \alpha h] = 0 \tag{73}$$

for  $\alpha \in [0, 1]$ , where  $y_n(\alpha)$  is the *dense output* found with interpolation (see page 565).

#### 14.3 Multistep methods

A one-step method only uses the previous value  $y_n$  to compute  $y_{n+1}$ . A multistep method, on the other hand, uses  $y_{n-1}$ ,  $y_{n-2}$ , etc. as well. The scheme looks like this:

$$y_{n+1} = \alpha_1 y_n + \alpha_2 y_{n-1} + \dots + h(\beta_0 f(y_{n+1}, t_{n+1}) + \beta_1 f(y_n, t_n) + \beta_2 f(y_{n-1}, t_{n-1}) + \dots)$$
(74)

The parameters/weights are derived by curve fitting polynomials to the previous time steps. The known stability concepts from one-step methods apply to multistep methods as well.

## Part VI

# Modelica reference

Modelica is an object-oriented, equation-based modeling language. This section shows some example models. An important thing to note is that you need the same number of equations as the number of variables.

```
model Oscillator "Descriptive comment"
    constant Real m = 1; // This comment is ignored by the compiler.
    parameter Real c = 1, k = 1;
    Real x(start=1); // 'start' is a hint to the compiler.
    Real vx;
equation
    der(x) = vx;
    m*der(vx) + c*vx + k*x = 0;
    // Could also add algebraic equations to make it a DAE.
intial equation
    vx = 0; // This is an actual constraint, unlike 'start'.
end Oscillator;
```

Next up, we look at a model which inherits from Oscillator, by use of the keyword extends:

```
model DrivenOscillator
    extends Oscillator;
    Real F;
equation
    F = sin(time);
    m*der(vx) + c*vx + k*x = F;
end DrivenOscillator;
```

The third example deals with the use of connectors.

```
connector Pin "Electrical pin";
   Modelica.SIunits.Voltage v; // Potential/energy level
    flow Modelica.SIunits.Current i; // Flow
end Pin;
partial model TwoPin // partial because of 6 var. and only 5 eq.
    Modelica.SIunits.Voltage v; // Voltage across component
   Modelica.SIunits.Current i; // Current through component
equation
    v = p.v - n.v;
   p.i + n.i = 0 // KCL
    i = p.i // Current into component
end TwoPin;
model Inductor
   extends TwoPin;
   parameter Modelica.SIunits.Inductance L;
equation
    v = L * der(i);
end Inductor;
```

Declaring your own type (based on Real) in Modelica is done in the following way:

```
type Voltage = Real(unit = "V", min = 0, max = 5.0);
```

## Part VII

# **Tables**

## 15 Inverse of 3x3 matrix

$$\begin{pmatrix} a & b & c \\ d & e & f \\ g & h & i \end{pmatrix}^{-1} = \frac{1}{\det} \begin{pmatrix} ei - fh & ch - bi & bf - ce \\ fg - di & ai - cg & cd - af \\ dh - eg & bg - ah & ae - bd \end{pmatrix}$$
(75)

## 16 Trig functions

$$\cot(\theta) = \frac{1}{\tan(\theta)} \tag{76}$$

$$\sec(\theta) = \frac{1}{\cos(\theta)} \tag{77}$$

$$\csc(\theta) = \frac{1}{\sin(\theta)} \tag{78}$$

$$\sin(\theta) = \frac{\text{motstående}}{\text{hypotenus}} \tag{79}$$

$$\cos(\theta) = \frac{\text{hosliggende}}{\text{hypotenus}} \tag{80}$$

$$\tan(\theta) = \frac{\sin(\theta)}{\cos(\theta)} \tag{81}$$

## 17 Trig identities

$$\cos(\theta)\sin(\theta) = \frac{1}{2}\sin(2\theta) \tag{82}$$

$$\cos^2(\theta) - \sin^2(\theta) = \cos(2\theta) \tag{83}$$

$$\sin(\alpha + \beta) = \sin(\alpha)\cos(\beta) + \cos(\alpha)\sin(\beta) \tag{84}$$

$$\cos(\alpha + \beta) = \cos(\alpha)\cos(\beta) - \sin(\alpha)\sin(\beta) \tag{85}$$

$$\sin(\alpha - \beta) = \sin(\alpha)\cos(\beta) - \cos(\alpha)\sin(\beta) \tag{86}$$

$$\cos(\alpha - \beta) = \cos(\alpha)\cos(\beta) + \sin(\alpha)\sin(\beta) \tag{87}$$