



## LipSync Wireless Command List

Command	Success Response	Failure Response	Description
SETTINGS	SUCCESS:SETTINGS	FAIL:SETTINGS	Enter Settings mode
EXIT	SUCCESS:EXIT	FAIL:SETTINGS	Exit Settings mode
MN,0:0	SUCCESS:MN,0:3	FAIL:SETTINGS	Get Model number (3=Wireless)
VN,0:0	SUCCESS:VN,0:V{N.NN}	FAIL:SETTINGS	Get version number (V{N.NN})
SS,0:0	SUCCESS:SS,0:{Level}	FAIL:SETTINGS	Get joystick sensitivity value (Level)
SS,1:1	SUCCESS:SS,1:{Level}	FAIL:SETTINGS	Decrease the speed using command (Level)
	MANUAL:SS,1:{Level}		Decrease the speed using push button (Level)
SS,1:2	SUCCESS:SS,1:{Level}	FAIL:SETTINGS	Increase the speed using command (Level)
	MANUAL:SS,1:{Level}		Increase the speed using push button (Level)
PT,0:0	SUCCESS:PT,0:{Threshold 1% to 50%}:{Nominal Pressure}	FAIL:SETTINGS	Get pressure threshold (threshold 1% to 50%) (Nominal Pressure V)
PT,1:{thresh old 1% to 50%}	SUCCESS:PT,1:{Threshold 1% to 50%}:{Nominal Pressure}	FAIL:SETTINGS	Set pressure threshold (threshold 1% to 50%) (Nominal Pressure V)
DM,0:0	SUCCESS:DM,0:{Debug Mode}	FAIL:SETTINGS	Get debug mode value ( 0=debug mode disabled,1=debug mode enabled)
DM,1:0	SUCCESS:DM,1:0	FAIL:SETTINGS	Set debug mode value to 0 (Disabled)
DM,1:1	SUCCESS:DM,1:1	FAIL:SETTINGS	Set debug mode value to 1 (Enabled)
	LOG:1:{xHighNeutral,xLowNeutral,yHighNeutral,yLowNeutral}		Log initialization values once if debug mode is enabled
	LOG:2:{xHighMax,xLowMax,yHighMax,yLowMax}		Log calibration values once if debug mode is enabled
	LOG:3:{xHigh,xLow,yHigh,yLow}		Log FSR values if debug mode is enabled until debug mode is disabled
RM,0:0	SUCCESS:RM,0:{Raw Mode}	FAIL:SETTINGS	Get Raw mode value ( 0=raw mode disabled,1=raw mode enabled)
RM,1:0	SUCCESS:RM,1:0	FAIL:SETTINGS	Set Raw mode value to 0 (Disabled)
RM,1:1	SUCCESS:RM,1:1	FAIL:SETTINGS	Set Raw mode value to 1 (Enabled)
	RAW:1:{x,y,action}:{xHigh,xLow,yHigh,yLow}	FAIL:SETTINGS	Log raw values if raw mode is enabled until raw mode is disabled
IN,0:0	SUCCESS:IN,0:{xHighNeutral,xLowNeutral,yHighNeutral,yLowNeutral}	FAIL:SETTINGS	Get joystick initialization values (xHighNeutral,xLowNeutral,yHighN eutral,yLowNeutral)
IN,1:1	SUCCESS:IN,1:{xHighNeutral,xLowNeutral,yHighNeutral,yLowNeutral}	FAIL:SETTINGS	Perform joystick initialization using command (xHighNeutral,xLowNeutral,yHighN eutral,yLowNeutral)



## Makers Making Change LipSync Wireless Command List

MANUAL:IN,1:{xHighNeutral,xLowNeutral,yHighNe utral,yLowNeutral}  Perform joystick initialization push button or sip/puff (xHighNeutral,xLowNeutral,yleutral,yLowNeutral)	lighN
CA,0:0 SUCCESS:CA,0:{xHighMax,xLowMax,yHighMax,yLo	
CA,1:1 SUCCESS:CA,1:0 FAIL:SETTINGS Perform joystick calibration u command	sing
SUCCESS:CA,1:1 FAIL:SETTINGS Perform joystick calibration u command (Step 1)	sing
SUCCESS:CA,1:2 FAIL:SETTINGS Perform joystick calibration u command (Step 2)	sing
SUCCESS:CA,1:3 FAIL:SETTINGS Perform joystick calibration u command (Step 3)	sing
SUCCESS:CA,1:4 FAIL:SETTINGS Perform joystick calibration u command (Step 4)	sing
SUCCESS:CA,1:5:{xHighMax,xLowMax,yHighMax,yL owMax}  FAIL:SETTINGS Perform joystick calibration u command (Step 5)  (xHighMax,xLowMax,yHighM wMax)	
MANUAL:CA,1:0 Perform joystick calibration u push button	sing
MANUAL:CA,1:1 Perform joystick calibration u push button (Step 1)	sing
MANUAL:CA,1:2 Perform joystick calibration u push button (Step 2)	sing
MANUAL:CA,1:3 Perform joystick calibration u push button (Step 3)	sing
MANUAL:CA,1:4 Perform joystick calibration u push button (Step 4)	sing
MANUAL:CA,1:5:{xHighMax,xLowMax,yHighMax,yL owMax}  Perform joystick calibration u push button (Step 5) (xHighMax,xLowMax,yHighMwax)	
CT,0:0 SUCCESS:CT,0:{ changePercent, changeTolerance,xHighMax,xLowMax,yHighMax,yL owMax}  FAIL:SETTINGS Get change tolerance value by on max value of FSRs and changeTolerance percentage	
MP,0:0 SUCCESS:MP,0:{NNNNNN} FAIL:SETTINGS Get Button mapping (Example SUCCESS:MP,0:012345)	e:
MP,1:{NNNSUCCESS:MP,1:{NNNNNNN}FAIL:SETTINGSSet Button mapping ( ExampleNNN}MP,1:012345)	2:
BT,0:0 SUCCESS:BT,0:3 FAIL:SETTINGS Get Bluetooth module mode (0=Mouse,1=Keyboard,2=Joy: =Mouse and Keyboard)	tick,3
BT,1:3 SUCCESS:BT,1:{Bluetooth Module Mode} FAIL:SETTINGS Set Bluetooth module mode (0=Mouse,1=Keyboard,2=Joys =Mouse and Keyboard)	
CM,0:0 SUCCESS:CM,0:{N} FAIL:SETTINGS Get Communication mode (0: Bluetooth =1)	USB,
CM,1:{N} SUCCESS:CM,1:{N} FAIL:SETTINGS Set Communication mode (0= Bluetooth =1)	USB,
FR,0:0 SUCCESS:FR,0:0 FAIL:SETTINGS Perform factory reset	





## **Action Mapping Options**

Action Number	Action
0	Left Click
1	Right Click
2	Drag
3	Scroll
4	Middle Click
5	Initialization
6	Calibration

## **Default Action Mapping**

Physical Action	LipSync Wireless Action
Short Puff	0 : Left Click
Short Sip	1 : Right Click
Long Puff	2: Drag
Long Sip	3 : Scroll
Very Long Puff	5: Initialization
Very Long Sip	4: Middle Click