## Question 1(a) [3 marks]

List common features of 8051 microcontroller.

**Answer**:

**Table: Common Features of 8051 Microcontroller** 

Feature	Description
On-chip Oscillator	Built-in clock generator circuit
Program Memory	4KB internal ROM for code storage
Data Memory	128 bytes internal RAM
I/O Ports	4 bidirectional 8-bit ports (P0-P3)
Timers/Counters	Two 16-bit Timer/Counter units
Serial Port	Full duplex UART communication
Interrupts	5 interrupt sources with priority
SFRs	Special Function Registers for control

Mnemonic: "On Program Data I/O Timers Serial Interrupts SFRs"

## Question 1(b) [4 marks]

Define T-State, Machine Cycle, Instruction Cycle and Opcode.

**Answer:** 

**Table: Microprocessor Timing Definitions** 

Term	Definition	Duration
T-State	One clock period of system clock	Basic timing unit
Machine Cycle	Time to complete one memory operation	3-6 T-states
Instruction Cycle	<b>Time to fetch, decode and execute instruction</b> 1-4 N	
Opcode	Operation code specifying instruction type	1-3 bytes

• **T-State**: Smallest unit of time in microprocessor operation

• Machine Cycle: Contains multiple T-states for memory access

• Instruction Cycle: Complete instruction execution time

• **Opcode**: Binary code identifying specific instruction

Mnemonic: "Time Machine Instruction Operation"


## Question 1(c) [7 marks]


**Compare Von-Neumann and Harvard Architecture.** 

**Answer**:

Table: Von-Neumann vs Harvard Architecture Comparison

Parameter	Von-Neumann	Harvard
Memory Organization	Single memory for code and data	Separate memory for code and data
Bus Structure	Single bus system	Dual bus system
Speed	Slower due to bus sharing	Faster parallel access
Cost	Lower cost implementation	Higher cost due to dual memory
Flexibility	More flexible memory usage	Less flexible, fixed allocation
Examples	8085, x86 processors	8051, DSP processors





### **Key Differences:**

- Memory Access: Von-Neumann uses sequential access, Harvard allows simultaneous
- **Performance**: Harvard is faster for embedded applications
- Applications: Von-Neumann for general computing, Harvard for real-time systems


Mnemonic: "Von-Single Harvard-Dual"

# Question 1(c) OR [7 marks]

Explain Microcomputer System with block diagram.

**Answer**:

**Microcomputer System Components:** 



### **Table: Microcomputer System Components**


Component	Function	Examples
СРИ	Central processing and control	8085, 8086
Memory	Program and data storage	RAM, ROM, EPROM
I/O Unit	Interface with external world	Keyboard, Display
System Bus	Data transfer pathway	Address, Data, Control


- **CPU**: Executes instructions and controls system operation
- Memory: Stores programs and data for processing
- I/O: Provides communication with external devices
- **Bus**: Connects all components for data transfer

Mnemonic: "CPU Memory I/O Bus"

# Question 2(a) [3 marks]

Draw Bus organization in 8085 Microprocessor.





**Table: 8085 Bus Organization** 

Bus Type	Width	Function
Address Bus	16-bit	Memory addressing (64KB)
Data Bus	8-bit	Data transfer
Control Bus	Multiple	Control signals

Mnemonic: "Address Data Control"

## Question 2(b) [4 marks]

List Flags used in 8085 and Explain working of each flags.

**Answer**:

Table: 8085 Flags Register

Flag	Name	Bit Position	Function
S	Sign	D7	Set if result is negative
Z	Zero	D6	Set if result is zero
AC	Auxiliary Carry	D4	Set if carry from bit 3 to 4
P	Parity	D2	Set if result has even parity
CY	Carry	D0	Set if carry/borrow occurs

```
D7 D6 D5 D4 D3 D2 D1 D0
+---+---+---+---+---+
| S | Z | - | AC | - | P | - | CY |
+---+---+---+---+
```


- **Sign Flag**: Indicates negative result (MSB = 1)
- Zero Flag: Set when arithmetic result is zero
- Auxiliary Carry: Used for BCD arithmetic operations
- Parity Flag: Checks even number of 1's in result
- Carry Flag: Indicates overflow in arithmetic operations

Mnemonic: "Sign Zero Auxiliary Parity Carry"

## Question 2(c) [7 marks]

Draw and Explain Block Diagram of 8085.

#### **Answer**:



**Table: 8085 Block Components** 

Block	Function	Size
ALU	Arithmetic and logical operations	8-bit
Accumulator	Primary register for operations	8-bit
Registers	Data storage (B,C,D,E,H,L)	8-bit each
Program Counter	Points to next instruction	16-bit
Stack Pointer	Points to stack top	16-bit
Control Unit	Instruction decode and control	-


- Data Flow: Instructions fetched via PC, decoded by CU, executed in ALU
- Register Operations: Accumulator works with ALU, other registers store data
- Address Generation: PC and SP provide 16-bit addresses
- Control Signals: CU generates timing and control signals

Mnemonic: "ALU Accumulator Registers Program Stack Control"

## Question 2(a) OR [3 marks]

**Explain Instruction Fetching, Decoding and Execution Operation in microprocessor.** 

#### **Answer**:



**Table: Instruction Cycle Phases** 


Phase	Operation	Duration
Fetch	Get instruction from memory	1 machine cycle
Decode	Interpret instruction opcode	Part of execute
Execute	Perform required operation	1-3 machine cycles

Mnemonic: "Fetch Decode Execute"

## Question 2(b) OR [4 marks]

What is Demultiplexing of Lower order Address and Data lines in 8085? Explain using neat sketch.

#### **Answer**:



### **Demultiplexing Process:**

• ALE Signal: Controls separation of address and data

• Latch IC: 74LS373 stores address when ALE is high

• **Timing**: Address appears first, then data on same lines

### **Table: Demultiplexing Components**

Component	Function	Timing
ALE	Address Latch Enable signal	High during T1
74LS373	Octal latch IC	Stores A7-A0
AD7-AD0	Multiplexed lines	Address then Data

Mnemonic: "Address Latch Enable Demultiplexes Lines"

# Question 2(c) OR [7 marks]

### Draw and Explain Pin Diagram of 8085.

#### Answer:

	8085 PIN DIAGRAM	
+ X1  1	+ 40   V	7CC
	•	
X2   2	39  F	
RST  3	38  F	
SOD  4	37   0	
SID  5		RESET
TRAP   6	35  F	
RST7   7	34  1	
RST6   8	33   8	51
RST5   9	32  F	RD
INTR   10	31  7	<b>V</b> R
INTA   11	30   A	ALE
AD0  12	29   8	0 0
AD1  13	28   7	15
AD2   14	27   7	A14
AD3   15	26   1	A13
AD4   16	25   7	
AD5   17	24   7	11
AD6  18	23   1	
AD7  19	22   1	
VSS   20	21   7	
	+	

#### **Table: 8085 Pin Functions**

Pin Group	Function	Count
Address Bus	A8-A15 (Higher order)	8 pins
Address/Data	AD0-AD7 (Multiplexed)	8 pins
Control Signals	ALE, RD, WR, IO/M	4 pins
Interrupts	TRAP, RST7.5, RST6.5, RST5.5, INTR	5 pins
Power	VCC, VSS	2 pins
Clock	X1, X2, CLK	3 pins

• Address Lines: 16-bit addressing capability (64KB)

• Data Lines: 8-bit data transfer

• Control Lines: Memory and I/O operation control

• Interrupt Lines: Hardware interrupt handling

Mnemonic: "Address Data Control Interrupt Power Clock"

## Question 3(a) [3 marks]

Draw IP SFR of 8051 and Explain function of each bit.

#### Answer:

```
IP Register (Interrupt Priority) - Address B8H

MSB

LSB

+---+---+---+----+----+

| - | - | PT2| PS| PT1| PX1| PX0|

+---+---+----+----+----+

D7 D6 D5 D4 D3 D2 D1 D0
```

### **Table: IP Register Bit Functions**

Bit	Name	Function
D4	PT2	Timer 2 interrupt priority
D3	PS	Serial port interrupt priority
D2	PT1	Timer 1 interrupt priority
D1	PX1	External interrupt 1 priority
D0	PX0	External interrupt 0 priority

• **Priority Levels**: 1 = High priority, 0 = Low priority


• **Default**: All interrupts have low priority (00H)

• Usage: Set bit to 1 for high priority interrupt

Mnemonic: "Timer2 Serial Timer1 External1 External0"

## Question 3(b) [4 marks]

Draw and explain Timer/Counter Logic diagram for 8051.



### **Table: Timer Components**

Component	Function	Size
TH0/TL0	Timer 0 high/low byte registers	8-bit each
TMOD	Timer mode register	8-bit
TCON	Timer control register	8-bit
TF0	Timer 0 overflow flag	1-bit

• Clock Source: Internal (system clock/12) or External (T0 pin)

• Operation: Counts up from loaded value to FFH


• Overflow: Sets TF0 flag and generates interrupt

• Modes: 4 different timer modes available

Mnemonic: "Timer High-Low Mode Control Flag"

# Question 3(c) [7 marks]

Draw and Explain Block Diagram of 8051.



### **Table: 8051 Block Components**

Block	Function	Specification
CPU	Central processing unit	8-bit processor
Program Memory	Code storage	4KB internal ROM
Data Memory	Variable storage	128 bytes RAM
I/O Ports	External interface	4 ports (32 I/O lines)
Timers	Timing operations	2 × 16-bit timers
Serial Port	Communication	Full duplex UART
Interrupts	Event handling	5 interrupt sources

- Architecture: Harvard architecture with separate program/data memory
- I/O Capability: 32 bidirectional I/O lines
- On-chip Features: Timers, serial port, interrupt system
- Memory: Von-Neumann for data, Harvard for program

Mnemonic: "CPU Program Data I/O Timer Serial Interrupt"

## Question 3(a) OR [3 marks]

Draw PCON SFR of 8051 and Explain function of each bit.

#### Answer:

**Table: PCON Register Bit Functions** 

Bit	Name	Function
D7	SMOD	Serial port mode modifier
D3	GF1	General purpose flag bit 1
D2	GF0	General purpose flag bit 0
D1	PD	Power down mode control
D0	IDL	Idle mode control

• SMOD: Doubles serial port baud rate when set

• **GF1**, **GF0**: User-defined flag bits

• PD: Activates power-down mode

• IDL: Activates idle mode

Mnemonic: "Serial General Power Idle"

## Question 3(b) OR [4 marks]

In 8051 Serial communication Mode 1, For XTAL=11.0592 MHz, find TH1 value needed to have for 9600 and 4800 baud rate.

Answer:

#### Formula for Mode 1 Baud Rate:

```
Baud Rate = (2^SMOD/32) × (Timer1 Overflow Rate)
Timer1 Overflow Rate = XTAL/(12 × (256 - TH1))
```

#### For 9600 Baud Rate:

```
9600 = (1/32) × (11059200/(12 × (256 - TH1)))

9600 = 28800/(256 - TH1)

256 - TH1 = 3

TH1 = 253 = FDH
```

#### For 4800 Baud Rate:

```
4800 = (1/32) × (11059200/(12 × (256 - TH1)))

4800 = 28800/(256 - TH1)

256 - TH1 = 6

TH1 = 250 = FAH
```

**Table: TH1 Values for Baud Rates** 

Baud Rate	TH1 Value (Hex)	TH1 Value (Decimal)
9600	FDH	253
4800	FAH	250

Mnemonic: "Higher Baud Higher TH1"

## Question 4(a) [3 marks]

What are the differences in LCALL and LJMP instructions in 8051?

**Answer**:

**Table: LCALL vs LJMP Comparison** 

Parameter	LCALL	LJMP
Function	Long subroutine call	Long jump
Stack Usage	Pushes return address	No stack operation
Return	RET instruction needed	Direct jump only
Bytes	3 bytes	3 bytes
Address Range	16-bit (64KB)	16-bit (64KB)
PC Action	Saved then loaded	Directly loaded

- LCALL: Calls subroutine, saves return address on stack
- LJMP: Unconditional jump to specified address
- Stack Impact: LCALL uses 2 stack bytes, LJMP uses none
- Usage: LCALL for functions, LJMP for program flow control

Mnemonic: "Call Saves Jump Goes"

## Question 4(b) [4 marks]

Write 8051 Assembly Language Program to generate square wave on port 1.0 using Timer0.

```
ORG 0000H ; Start address

LJMP MAIN ; Jump to main program

ORG 0030H ; Main program start

MAIN:

MOV TMOD, #01H ; Timer0 model (16-bit)

MOV THO, #HIGH(-50000) ; Load high byte

MOV TLO, #LOW(-50000) ; Load low byte
```

```
LOOP:

JNB TF0, LOOP ; Wait for overflow
CLR TF0 ; Clear overflow flag
CPL P1.0 ; Toggle P1.0
MOV TH0, #HIGH(-50000) ; Reload timer
MOV TL0, #LOW(-50000) ; Reload timer
SJMP LOOP ; Repeat
```

### **Program Explanation:**

• Timer Setup: Mode 1 (16-bit timer)

• Count Value: -50000 for specific delay

• Square Wave: Toggle P1.0 on each overflow

• Continuous: Loop maintains square wave

Mnemonic: "Mode Load Start Wait Toggle Reload"

## Question 4(c) [7 marks]

Explain any three Logical and any four Data Transfer Instruction of 8051 with example.

**Answer**:

**Table: Logical Instructions** 

Instruction	Function	Example	Result
ANL	Logical AND	ANL A, #0FH	A = A AND 0FH
ORL	Logical OR	ORL A, #F0H	A = A OR F0H
XRL	Logical XOR	XRL A, #FFH	A = A XOR FFH

### **Table: Data Transfer Instructions**

Instruction	Function	Example	Operation
MOV	Move data	MOV A, #50H	Load 50H into A
MOVX	Move external	MOVX A, @DPTR	Load from external memory
PUSH	Push to stack	PUSH ACC	Push accumulator to stack
POP	Pop from stack	POP ACC	Pop from stack to accumulator

### **Detailed Examples:**

```
; Logical Instructions

ANL A, #0FH ; Mask upper nibble

ORL P1, #80H ; Set bit 7 of Port1

XRL A, #FFH ; Complement accumulator

; Data Transfer Instructions

MOV R0, #30H ; Load immediate data

MOVX @DPTR, A ; Store to external memory

PUSH B ; Save B register

POP PSW ; Restore status word
```

Mnemonic: "AND OR XOR Move External Push Pop"

## Question 4(a) OR [3 marks]

Explain Instructions: (i) RRC A (ii) POP (iii) CLR PSW.7

**Answer:** 

**Table: Instruction Explanations** 

Instruction	Function	Operation	Example
RRC A	Rotate right through carry	A→C, C→A(MSB)	A=85H,C=0 → A=42H,C=1
POP	Pop from stack	SP→Register, SP-1	POP ACC
CLR PSW.7	Clear bit 7 of PSW	PSW.7 = 0	Clear CY flag

```
RRC A Operation:
Before: A = [D7 D6 D5 D4 D3 D2 D1 D0] C = [C]
After: A = [C D7 D6 D5 D4 D3 D2 D1] C = [D0]
```

- RRC A: Rotates accumulator right through carry flag
- POP: Removes top stack element into specified register
- CLR PSW.7: Clears carry flag (bit 7 of Program Status Word)

Mnemonic: "Rotate Pop Clear"

### Question 4(b) OR [4 marks]

Write 8051 Assembly Language Program to Divide data stored in location 30H by data stored in location 31H and store remainder in 40h and quotient in 41h memory location.

```
ORG 0000H
                  ; Program start
LJMP MAIN
ORG 0030H
MAIN:
   MOV A, 30H ; Load dividend
   MOV B, 31H
                 ; Load divisor
   DIV AB
                 ; Divide A by B
   MOV 41H, A
               ; Store quotient
   MOV 40H, B
                ; Store remainder
   SJMP $
                 ; Stop here
END
```

### **Program Steps:**

1. Load Data: Move dividend and divisor to A and B

2. **Division**: Use DIV AB instruction

3. Store Results: Quotient in A, remainder in B

4. Save: Store results in specified memory locations

**Table: DIV AB Instruction** 

Before	After
A = Dividend	A = Quotient
B = Divisor	B = Remainder

Mnemonic: "Load Divide Store"

## Question 4(c) OR [7 marks]

List Addressing Modes of 8051 Microcontroller and Explain each with Example.

**Answer**:

**Table: 8051 Addressing Modes** 

Mode	Description	Example	Explanation
Immediate	Data in instruction	MOV A, #50H	Load 50H into A
Register	Use register	MOV A, R0	Move R0 content to A
Direct	Memory address specified	MOV A, 30H	Load from address 30H
Indirect	Address in register	MOV A, @R0	Load from address in R0
Indexed	Base + offset	MOVC A, @A+DPTR	A = content of (A+DPTR)
Relative	PC + offset	SJMP HERE	Jump relative to PC
Bit	Bit address	SETB P1.0	Set bit 0 of Port 1

### **Detailed Examples:**

```
; Immediate Addressing
MOV A, #25H ; Load immediate value 25H

; Register Addressing
MOV A, R7 ; Move register R7 to A

; Direct Addressing
MOV A, 40H ; Load from memory location 40H

; Indirect Addressing
MOV R0, #50H ; R0 points to address 50H
MOV A, @R0 ; Load from address pointed by R0

; Indexed Addressing
MOV DPTR, #TABLE ; Point to lookup table
MOVC A, @A+DPTR ; Load from table[A]

; Relative Addressing
SJMP NEXT ; Jump to label NEXT


; Bit Addressing
SETB P2.5 ; Set bit 5 of Port 2
```

Mnemonic: "Immediate Register Direct Indirect Indexed Relative Bit"

# Question 5(a) [3 marks]

Draw Interfacing of Relay with 8051 microcontroller.

```
8051 Port Pin
```



#### **Table: Interface Components**

Component	Function	Value
Transistor	Current amplifier	BC547 NPN
Resistor	Base current limiter	2.2ΚΩ
Relay	Electromagnetic switch	12V DC
Diode	Back EMF protection	1N4007

- **Operation**: Port pin HIGH  $\rightarrow$  Transistor ON  $\rightarrow$  Relay energized
- Protection: Diode prevents back EMF damage
- Isolation: Relay provides electrical isolation

Mnemonic: "Transistor Resistor Relay Diode"

# Question 5(b) [4 marks]

Interface 7 Segment display with 8051 microcontroller and write a program to print "1" on it.

```
8051 Port 1
P1.0 ----[330Ω]---- a
P1.1 ----[330Ω]---- b
P1.2 ----[330Ω]---- c
```

```
P1.3 ---[330\Omega]---- d
P1.4 ---[330\Omega]---- e
P1.5 ---[330\Omega]---- f
P1.6 ---[330\Omega]---- g
P1.7 ---[330\Omega]---- dp

7-Segment Display
    aaaa
    f     b
    f     b
    gggg
    e     c
    e     c
    dddd dp
```

#### Program to Display "1":

```
ORG 0000H
LJMP MAIN

ORG 0030H
MAIN:

    MOV P1, #06H  ; Display "1" (segments b,c ON)
    SJMP $  ; Stop here

; Pattern for "1": 00000110 = 06H
; Only segments b and c are ON

END
```

#### **Table: 7-Segment Display Components**

Component	Function	Value
Current Limiting Resistor	Protect LED segments	330Ω
Port Connection	Digital output control	Port 1
Display Pattern	Segment control	Binary pattern

Mnemonic: "Current Limit Segment Pattern"

# Question 5(c) [7 marks]

Interface DAC 0808 with 8051 microcontroller and write a program to generate Square wave.

```
8051 DAC0808

Port 2 +-----+

P2.0 ----> | D0 IOUT |---[10KΩ]---+--> Vout
```

```
P2.1 ---->| D1
P2.2 ----> D2
                    IREF | --- [ 10KΩ ] ---+
P2.3 ----> D3
                     P2.4 ----> D4
                    VCC | --- (+5V)
                    VEE | --- (-5V)
P2.5 ----> | D5
P2.6 ----> D6
                       P2.7 ----> D7
                    GND | --- (GND)
         +----+
                             Op-Amp Buffer
                                Output
```

#### **Program to Generate Square Wave:**

```
ORG 0000H
LJMP MAIN
ORG 0030H
MAIN:
   MOV A, #00H ; Minimum value (0V)
MOV P2, A ; Output to DAC
CALL DELAY ; Wait period
    MOV A, #0FFH ; Maximum value (approx 5V)
    MOV P2, A
                 ; Output to DAC
    CALL DELAY
                   ; Wait period
    SJMP MAIN ; Repeat for square wave
DELAY:
    MOV RO, #200 ; Delay counter
LOOP1:
   MOV R1, #250 ; Inner loop counter
LOOP2:
    DJNZ R1, LOOP2 ; Inner delay loop
    DJNZ RO, LOOP1 ; Outer delay loop
    RET
END
```

**Table: DAC Interface Specifications** 

Parameter	Value	Function
Resolution	8-bit	256 output levels
Reference Voltage	5V	Full scale output
Output Range	0-5V	Analog voltage range
Interface Type	Parallel	8-bit data bus

### **Square Wave Generation:**

• Low Level: 00H produces approximately 0V output

• **High Level**: FFH produces approximately 5V output

• **Frequency**: Determined by delay routine duration

• Output: Clean analog square wave at DAC output

Mnemonic: "Digital Analog Convert Square"

## Question 5(a) OR [3 marks]

Interface of Push button Switch with 8051 microcontroller.

#### Answer:

### **Table: Push Button Interface Components**

Component	Value	Function
Pull-up Resistor	10ΚΩ	Ensures logic HIGH when switch open
Push Button	SPST Momentary	User input device
Logic Levels	HIGH=1, LOW=0	Switch open=1, pressed=0

#### **Sample Program:**

```
CHECK_SWITCH:

JB P1.0, SW_RELEASED ; Jump if switch not pressed

; Switch pressed code here

CALL SWITCH_PRESSED

SJMP CHECK_SWITCH

SW_RELEASED:

; Switch not pressed code here

SJMP CHECK_SWITCH

SWITCH_PRESSED:

; Action when switch is pressed

RET
```

#### **Operation:**

- Switch Open: Pull-up resistor makes pin HIGH (logic 1)
- Switch Pressed: Pin connected to GND, becomes LOW (logic 0)
- **Debouncing**: May require software debouncing for reliable operation

Mnemonic: "Pull-up Switch Ground"

## Question 5(b) OR [4 marks]

Interface DC Motor with 8051 microcontroller.

```
8051 Port Pin (P1.0)
  +---+
| 1K | Base Resistor
+---+
+---+ Base
NPN | Power Transistor
| TIP122 | (Darlington)
+---+
  Collector
  +---+
DC | 12V DC Motor
Motor
+---+
  +VCC (12V)
+---+ Freewheeling Diode
| 1N4007 | (Across Motor)
```

```
+---+
```

#### **Motor Control Program:**

```
MOTOR_ON:
   SETB P1.0
                ; Turn motor ON
   RET
MOTOR_OFF:
   CLR P1.0 ; Turn motor OFF
   RET
MOTOR_SPEED_CONTROL:
   ; PWM for speed control
   SETB P1.0 ; Motor ON
   CALL DELAY ON ; ON time duration
   CLR P1.0 ; Motor OFF
   CALL DELAY OFF ; OFF time duration
DELAY_ON:
   MOV RO, #100 ; ON time delay
   DJNZ RO, $
   RET
DELAY OFF:
   MOV RO, #50 ; OFF time delay
   DJNZ RO, $
   RET
```

#### **Table: DC Motor Interface Components**

Component	Function	Specification
Power Transistor	Current amplification	TIP122 (Darlington pair)
Base Resistor	Current limiting	1ΚΩ
Freewheeling Diode	Back EMF protection	1N4007
DC Motor	Load device	12V DC Motor

### **Operation Principle:**

- **Motor ON**: Port pin HIGH  $\rightarrow$  Transistor saturated  $\rightarrow$  Motor runs
- **Motor OFF**: Port pin LOW → Transistor cut-off → Motor stops
- Speed Control: PWM technique varies average power to motor
- Protection: Diode protects transistor from back EMF

Mnemonic: "Transistor Resistor Diode Motor"

### Question 5(c) OR [7 marks]

Interface LCD with 8051 microcontroller and write a program to display "Hello".

#### Answer:

### **Complete LCD Interface Program:**

```
ORG 0000H
LJMP MAIN
ORG 0030H
MATN:
   CALL LCD INIT ; Initialize LCD
   MOV DPTR, #MESSAGE ; Point to message string
   CALL DISPLAY_STRING ; Display the message
   SJMP $
                     ; Stop execution
LCD INIT:
   CALL DELAY_15MS
                     ; Wait 15ms after power on
   MOV A, #38H
                     ; Function set: 8-bit mode, 2 lines, 5x7 matrix
   CALL COMMAND_WRITE
   MOV A, #0EH
                      ; Display on, cursor on, blink off
   CALL COMMAND WRITE
   MOV A, #01H
                      ; Clear display
   CALL COMMAND_WRITE
   MOV A, #06H
                      ; Entry mode: increment cursor, no shift
   CALL COMMAND WRITE
   RET
COMMAND_WRITE:
   MOV P2, A
                 ; Send command to data lines (D4-D7)
   CLR P3.0
                     ; RS = 0 for command
   SETB P3.1
                     ; Enable pulse high
   CALL DELAY 1MS
   CLR P3.1
                     ; Enable pulse low
   CALL DELAY 1MS
   RET
DATA_WRITE:
   MOV P2, A
                     ; Send data to data lines (D4-D7)
```

```
SETB P3.0 ; RS = 1 for data
   SETB P3.1
                      ; Enable pulse high
   CALL DELAY 1MS
                     ; Enable pulse low
   CLR P3.1
   CALL DELAY_1MS
   RET
DISPLAY STRING:
   CLR A
   MOVC A, @A+DPTR ; Get character from string

JZ STRING_END ; If zero, end of string
   CALL DATA_WRITE
                     ; Display character
                     ; Point to next character
   INC DPTR
   SJMP DISPLAY_STRING ; Continue until end
STRING_END:
   RET
MESSAGE: DB "HELLO", 0 ; Message string with null terminator
DELAY 1MS:
   MOV RO, #4 ; Outer loop counter
DEL1:
   MOV R1, #250 ; Inner loop counter
DEL2:
   DJNZ R1, DEL2 ; Inner delay loop
   DJNZ RO, DEL1
                     ; Outer delay loop
   RET
DELAY 15MS:
   MOV R2, #15 ; 15ms delay counter
DEL15:
   CALL DELAY_1MS ; Call 1ms delay
   DJNZ R2, DEL15
                     ; Repeat 15 times
   RET
END
```

### **Table: LCD Control Signals**

Signal	Pin	Function
RS	P3.0	Register Select (0=Command, 1=Data)
EN	P3.1	Enable pulse for data latch
R/W	GND	Read/Write (tied to GND for write only)
D4-D7	P2.0-P2.3	4-bit data bus (upper nibble)

**Table: Important LCD Commands** 

Command	Hex Code	Function
Function Set	38H	8-bit mode, 2 lines, 5x7 matrix
Display Control	0EH	Display ON, cursor ON, blink OFF
Clear Display	01H	Clear entire display
Entry Mode	06H	Increment cursor, no display shift

### **LCD Display Process:**

1. Initialization: Configure LCD parameters and clear display

2. Command Mode: Send commands with RS=0

3. Data Mode: Send characters with RS=1

4. Enable Pulse: Latch data/command with EN signal

5. String Display: Loop through message characters until null terminator

### **Character Display Steps:**

• Set RS=1 for data mode

• Put character code on data bus

• Generate enable pulse (HIGH to LOW)

• Wait for LCD to process (1ms delay)

• Repeat for next character

Mnemonic: "Initialize Command Data Enable Display"