CS 466/566 Spring 2021

Miller Lowe

Mechanics of Course

Lecture Tuesdays

TEAMS

5:45pm-7:40pm

Lab Thursdays

TEAMS

5:45pm-8:30pm

Course Syllabus


Books Used

- No book required, I will pull some material from "An Embedded Software Primer by David E. Simon" but not enough to force you to buy the book.
- Extra material as needed from other sources
 - Web links
 - Google search

Embedded Systems

- Terminology is not very consistent
- For every word, several subtly different meanings
- Code sizes very from under 500 bytes to many megabytes
- There is always a battle between development velocity and coding elegance.
- Delivery dates are considered cast in stone.

Class Flow



C++

- We will tend to ignore C++ and use C to focus on embedded systems because C++ is more complex and we have enough to learn.
- Embedded C++ is an advanced C++ topic.
- For the nerd in all of us, there can be great mental reward in a solid C++ embedded project but as project size goes down the usefulness of C++ degrades with it. (my opinion)

Code Style

- We will jump all over the place as far as variable naming..
- I do not care what you use as long as you:
 - Stay fairly consistent in your use.
 - Emulate that within an existing module.
 - Make the code readable, readable, readable
 - Did I mention to make the code readable?

More Style, Brace Conventions

Expect an adoption of a consistent style for this class.


```
Typical choices are:
                                              [My preference, takes more space]

    Allman style (extended braces)

    if(a == b)
         cout << a;
         b++;
     }
    One True Brace Style (K & R) (linesaver)
                                               [OK, Popular, can get wierd]
     if(a == b){
         cout << a:
         b++;
     }
   WhiteSmith's Style (indented braces)
                                              *deprecated, still sneaks into C++ class decl
     if(a == b)
         cout << a;
         b++;
```


Lab Embedded CPU Board

Figure 1-1. Tiva C Series TM4C123G LaunchPad Evaluation Board



Tiva Pin-Muxing

(This will cause you heartburn, but it's real..)



Hardware Documentation

- Processor Datasheet, Hardware Reference
 - Our Processor, 8.2 MB .pdf file, Only 1049 Pages
 - By comparison NXP IMX6-Solo is 5789 Pages
 - Learning to Navigate these documents is essential, often I will give contrived exercises that are designed to send you back to the datasheet multiple times.
 - "When in doubt, go read the datasheet again"
- Tiva Users Guide
 - Gives information about the Processor on the dev-board
 - Some debug module information
 - Full Pin Mux table
 - Board Schematics

Hardware Documentation

- Pin-Mux Quick Reference
 - When hunting for pins
 - When hunting for alternate pins
- Tiva Peripheral Driver Library Reference
 - The Tiva Driver Library is a representative library is similar to what most SOC vendors provide to aid development.
 - It's like an old friend that can't fully be trusted. (CAN Example)
 - Once you are familiar with the limitations of a specific vendor library they become quite useful
 - Warning, Most vendor libraries are not re-entrant and may require support by you in a RTOS environment.

Micro-Quiz #1, Buildup (Queue Terror Music)

- It's my responsibility to see that if you pass this class you don't fall flat in an entry-level embedded interview.
- Closed Book, Closed Phone, Closed Computer,
- Get a pencil and a piece of paper

Micro-Quiz #1, Go!

- You are writing 'C' code on a 32 bit embedded processor
- There is a 32 bit Read/Write GPIO data register at physical address 0x40040108
- Without effecting other bits in the register, set bit-3 to 1.
 - Hint: LSB is bit-0, a 32 bit value with only bit-3 set is 0x0000008

```
#define GPIO_DATA_REG (*((volatile uint32_t *) 0x40040108))
GPIO_DATA_REG |= 0x08;
```

Lab 1 Some Information

- What's a register?
- How to locate a register?
- We have an address, How to use it
- Example
 - Want to output to a GPIO
 Table 10-6. GPIO Register Map

| Offset | Name | Туре | Reset | Description | See page |
|--------|----------|------|-------------|---------------------------|-------------|
| 0x000 | GPIODATA | RW | 0x0000.0000 | GPIO Data | 662 |
| 0x400 | GPIODIR | RW | 0x0000.0000 | GPIO Direction | 663 |
| 0x404 | GPIOIS | RW | 0x0000.0000 | GPIO Interrupt Sense | 664 |
| U^4U8 | GPIOIRE | D/W | ∪^∪∪∪∪ ∪∪∪∪ | GPIO Interrunt Roth Edges | 665 |

- GPIO Port A (AHB): 0x4005.8000
- GPIO Port B (APB): 0x4000.5000
- GPIO Port B (AHB): 0x4005.9000
- GPIO Port C (APB): 0x4000.6000
- GPIO Port C (AHB): 0x4005.A000
- GPIO Port D (APB): 0x4000.7000
- ODIO DESED (ALID): OSAGOE DOGO


Address I want is GPIO Port A GPIO Data Register 0x40058000 + offset(0x000)

Lab 1 Introduction

- Bare-Metal Blinky (https://en.wikipedia.org/wiki/Bare_machine)
- Main objective is to get you targeting code, Some concepts are needed to answer the lab questions.
- Do prep-work before you get to lab
- I encourage you to get a development system setup on your personal computer. There limitations on Windows and OSX platforms but most the development chain works.
- We will use Linux in the Lab as our home development. I predominantly use Linux and sometimes Windows.

Lab 1 Some Information

- Address I want is GPIO Port A GPIO Data Register 0x40058000 + offset(0x000)
- The Tiva PinMux shows a couple (but not all GPIOA ports)



- So PA2 is GPIO Port A2.
- To set the PA2 bit to a logical 1 you need to set the 0x00000004 bit in the GPIO Port A Data Register, The los level C code looks like

```
*((volatile uint32_t *)0x4005800)) = *((volatile uint32_t *)0x4005800)) | 0x00000004;
// ...kinda ugly, non-portable...
```

- Would be nice to say
 - PORTA_DATA = (1 << 2);
 - setBit(PA2, 2)
 - bitControl(PA2, BIT2, TRUE);

LAB 1 Process

- I recommend that you get used to looking at the 'Lab Preparation' section of the lab and acting on it some before you show up in lab..
- I am a Cruel and Unfair instructor. I have added an issue with this lab that you will need to discover and overcome.
- Get a your Linux login working
- Install the git repo and build the lab-1 code provided
- Perform the modifications outlined in the lab handout.
 (available on Blackboard and in the git repo)
- I have a strict lab format, (remember the 'Cruel and Unfair' comment above) If you do not address and satisfy all the sections your grade will represent the omissions.

Recurring Examples of Embedded Systems used in the book.

Telegraph

- Allows a printer with only a high speed serial port to connect to a network
- Looks like a little plastic box 2 to 3 inches by ½ inch thick
- Has a pigtail connector for the serial connection and a network connector

Examples of Embedded Systems

Telegraph

- Allows a printer with only a high speed serial port to connect to a network
- Looks like a little plastic box 2 to 3 inches by ½ inch thick
- Has a pigtail connector for the serial connection and a network connector

Telegraph Requirements:

- On the network, data packets sometimes arrive out of order, data gets lost, and sometimes data arrives twice. Telegraph must make order out of chaos
- Multiple computers on the network may want to print at once.
 Telegraph must allow one computer to print and somehow hold off the others.
- Network printers must provide status info to any computer on the network that requires it, even if busy printing a job for some other computer.
- Telegraph has to work with different types of printers.
- Telegraph must respond rapidly to certain events, like various kinds of network frames.
- Telegraph must keep track of time. If a computer which is sending a print job crashes, telegraph must be able to give up on that print job and print from another computer on the network.

Telegraph development challenges

- To satisfy the previous requirements, telegraph has an embedded microprocessor. It must have logically correct performance.
- Throughput telegraph must not be a bottleneck for print data flowing through it.
- Response telegraph must respond to certain network frames within 200 usec, even if it is doing something else. We will talk about throughput and response and avoid speed...
- Testability telegraph must deal with everything without human intervention. It is hard to test "everything" and how do you make something happen to see if the code handles it.

Telegraph Development (cont)

- Debugability telegraph has no screen, no keyboard, no mouse, no speaker, no lights.
 When a bug occurs, it typically stops working...
- Reliability telegraph is not allowed to crash, which is typical of embedded systems. The sw must function without human intervention.
- Memory Space telegraph has limited memory, typically 32 kbytes of memory for its program and another 32 kbytes for its data.
- Program Installation we need special tools to install sw on these kinds of systems.

Cordless Bar Code Scanner

- No problem with throughput...there just isn't that much data
- Power consumption since the scanner is cordless, its battery is its only source of power. It is intended to be handheld, which limits its weight. How long must the battery last? An eight hour shift is probably the least we can tolerate.
- What are some ways that the battery life could be mitigated/extended?

Laser Printer

- Most have fairly substantial microprocessors embedded in them.
- The microprocessor is responsible for getting data from any of various communication ports, sensing when users press front panel buttons, presenting messages to the user on the front panel, sensing paper jams, noticing out of paper, etc.
- It also must deal with the laser engine, which is that part of the printer responsible for putting marks on the paper.

Laser Printer (continued)

 Users expect a nearly instantaneous response when pressing a front panel button, no matter what the microprocessor is doing.

Underground Tank Monitor

- This system watches the levels of gasoline in underground tanks at a gas station.
- Its principal purpose is to detect leaks before the gas station turns into a toxic waste dump by mistake and to set off a loud alarm if it discovers a leak.
- The system has a panel of 16 buttons, a 20 character
 LCD as a display, and a thermal printer.
- The user interacts with various buttons to tell the system to display or print various information such as the gasoline levels or time of day or system status.

Underground Tank Monitor

- The system has two float levels in each tank, namely one that indicates the level of gasoline and the other that indicates the level of water in the tank. (Water always accumulates in such tanks).
- It also reads the temperature at various levels in the tank because gasoline expands and contracts considerable with variations in temperature.
- Cost A gas station owner buys one of the systems because some government agency tells him that he has to. Therefore, we might use a cheap 8 bit microprocessor that can barely add two numbers let alone deal with the expansion coefficient of gasoline in a reasonable way.

Nuclear Reactor Monitor

- A very simple example in which we can learn from a system controlling a hypothetical nuclear reactor.
- It monitors two temperatures, which are always supposed to be equal. It they ever differ, it is supposed to set off the alarm.

Death Ray

- Requirements:
 - Operation:
 - Physical:
 - Power:
 - Safety:

Typical Hardware

| Processor | Bus Width | Ext Memory | Int Memory | Periphials | Speed(MIPS) |
|---------------------|--------------|------------|-----------------|----------------------|-------------|
| Zilog Z8 fam | 8 | 64K | 0 | 2 Timers | 1 |
| Intel 8051 fam | 8 | 64K | 64K | 3 Timers | 1 |
| Zilog Z80 fam | 8 | 64K | 1MB | Various | 2 |
| Intel 80188 | 8 | 1MB | 0 | 3 Timers 2 DMA | 2 |
| Intel 80386 | 16 | 64MB | 0 | 3 Timers 2 DMA Ch | 5 |
| Motorola 68000 | 32 | 4GB | 0 | Varies | 10 |
| Motorola PowerPC | 32 | 64MB | 0 | Many | 75 |
| ARM M4F TM4C123G | 32 | 4GB | 256K/32K F/R | Lots | |

Embedded Systems

- Embedded systems are known for what they do NOT have – note the following
 - Keyboard
 - Screen
 - Disk drive
 - Compact discs, speakers,
 microphones, diskettes, modems, etc.

Embedded Systems

- Embedded systems are known for what they do NOT have – note the following
 - Keyboard
 - Screen
 - Disk drive
 - Compact discs, speakers,
 microphones, diskettes, modems, etc.

Chapter 1 summary

- An embedded system is any computer system hidden inside a product other than a computer.
 - Throughput
 - Response time
 - Testability
 - Debugability
 - Reliability
 - Memory space
 - Program installation
 - Power consumption
 - Processor hogs
 - Cost