

# Microprocessors

Tuba Ayhan

MEF University

## ARM Processor – Adressing modes


Computer Organization and Embedded Systems, Hamacher et. al

# ARM Characteristics


- 32 bits word length, byte-addressable using 32-bit addresses memory, 32 bits long processor registers.
- 7 processor modes of operation. Application programs run in **User mode**. The other six modes are used to handle I/O device interrupts, processor powerup/reset, software interrupts, and memory access violations.
- RISC-style Aspects:
  - All instructions have a fixed length of 32 bits.
  - Only Load and Store instructions access memory.
  - All arithmetic and logic instructions operate on operands in processor registers
- CISC-style Aspects:
  - Autoincrement, Autodecrement, and PC-relative addressing modes are provided.
  - Condition codes (N, Z, V, and C) are used for branching and for conditional execution of instructions.
  - Multiple registers can be loaded from a block of consecutive memory words, or stored in a block, using a single instruction.

# Register Structure

- 15 general-purpose registers: R0 - R14
- Program Counter (PC): R15.
- R13 and R14 are dedicated to the management of the processor stack and subroutines.
- The Current Program Status Register (CPSR), *the Status register*, holds the condition code flags (N, Z, C, V), interrupt-disable bits, and processor mode bits.
- **Banked registers** are duplicates of some of the R0 to R14 registers, to save and restore some User-mode register contents on mode switches.



# Condition bits




**Figure D.2** Format for Load and Store instructions.

- The high-order four bits specify a condition that determines whether or not the instruction is executed. This is a special feature for ARM.
  - An instruction is executed only if the current values of the condition code flags satisfy the condition specified in a 4-bit field of the instruction.
  - Otherwise, the processor proceeds to the next instruction
  - One of the possible conditions → always executed.

# CPSR register

- Interrupt-disable bits, I and F, where
  - I = 1 disables the IRQ interrupts
  - F = 1 disables FIQ interrupts
- Thumb bit,
  - T = 0 indicates ARM execution
  - T = 1 indicates Thumb execution
- Processor mode bits which identify the mode in which the processor is operating.



**Condition Code flags:** based on the results of a previous operation.

- Negative (N) - set to 1 if the result is negative; otherwise, cleared to 0
- Zero (Z) - set to 1 if the result is 0; otherwise, cleared to 0.
- Carry (C) - set to 1 if a carry-out results from the operation; otherwise, cleared to 0.
- Overflow (V) - set to 1 if arithmetic overflow occurs; otherwise cleared to 0.

# Addressing Modes

---


- Basic modes: The Immediate, Register, Absolute, Indirect, and Index addressing modes.
- More complex modes: Relative mode and variants of the Autoincrement and Autodecrement modes
- Many of these modes are derived from different forms of indexed addressing modes.

# Register, Immediate, and Absolute Addressing Modes

**Table 2.1** RISC-type addressing modes.

Name	Assembler syntax	Addressing function
Immediate	#Value	Operand = Value
Register	R <sub>i</sub>	EA = R <sub>i</sub>
Absolute	LOC	EA = LOC

EA = effective address  
Value = a signed number



**Figure D.2** Format for Load and Store instructions.


- The **Register addressing mode** is the main way for accessing operands in arithmetic and logic instructions. Constants are provided as 8-bit immediate values.
- **Immediate** addressing mode – 8-bit
- **Absolute** addressing mode -- 12-bit
- Advanced: The generation and use of 32-bit values as immediate operands or memory addresses.

**Table D.1** ARM indexed addressing modes.

Name	Assembler syntax	Addressing function
With immediate offset:		
Pre-indexed	[Rn, #offset]	$EA = [Rn] + \text{offset}$
Pre-indexed with writeback	[Rn, #offset]!	$EA = [Rn] + \text{offset};$ $Rn \leftarrow [Rn] + \text{offset}$
Post-indexed	[Rn], #offset	$EA = [Rn];$ $Rn \leftarrow [Rn] + \text{offset}$
With offset magnitude in Rm:		
Pre-indexed	[Rn, ± Rm, shift]	$EA = [Rn] \pm [Rm] \text{ shifted}$
Pre-indexed with writeback	[Rn, ± Rm, shift]!	$EA = [Rn] \pm [Rm] \text{ shifted};$ $Rn \leftarrow [Rn] \pm [Rm] \text{ shifted}$
Post-indexed	[Rn], ± Rm, shift	$EA = [Rn];$ $Rn \leftarrow [Rn] \pm [Rm] \text{ shifted}$
Relative (Pre-indexed with immediate offset)	Location	$EA = \text{Location}$ $= [PC] + \text{offset}$

- **EA:** Effective address
- **Offset:** a signed number contained in the instruction
- **Shift:** direction # integer, direction is LSL for left shift or LSR for right shift, integer is 5-bit unsigned number.
- **Rm:** offset magnitude in Rm can be added to subtracted from the contents of the base register Rn.

# Basic Indexed Addressing Mode




**Figure D.2** Format for Load and Store instructions.

- *Pre-indexed mode* – The effective address of the operand is the sum of the contents of a base register, Rn, and a signed offset.
 

LDR Rd, [Rn] LDR Rd, [Rn, #offset] LDR Rd, [Rn, Rm]	$Rd \leftarrow [[Rn]]$ $Rd \leftarrow [[Rn] + \text{offset}]$ $Rd \leftarrow [[Rn] + [Rm]]$
---	---
- The contents of Rm are the magnitude of the offset, Rm is preceded by a minus sign if a negative offset is desired.

# Index Modes with Writeback



**Figure D.2** Format for Load and Store instructions.

- *Pre-indexed with writeback mode* — The effective address of the operand is generated in the same way as in the Pre-indexed mode, then the effective address is written back into Rn. ‘!’ signifies that writeback is to be done.

LDR Rd, [Rn, #offset]!

$$Rd \leftarrow [[Rn] + \text{offset}]$$


LDR Rd, [Rn +- Rm, shift]!

$$Rn \leftarrow [Rn] + \text{offset}$$

$$Rd \leftarrow [[Rn] +- [Rm]\text{shifted}]$$

$$Rn \leftarrow [Rn] +- [Rm]\text{shifted}$$

# Post-indexed mode



**Figure D.2** Format for Load and Store instructions.

- *Post-indexed mode* – The effective address of the operand is the contents of Rn. The offset is then added to this address and the result is written back into Rn.

LDR Rd, [Rn], #offset

$$Rd \leftarrow [[Rn]]$$

$$Rn \leftarrow [Rn] + \text{offset}$$

LDR Rd, [Rn], +-Rm,shift

$$Rd \leftarrow [[Rn]]$$

$$Rn \leftarrow [Rn] +- [Rm]\text{shifted}$$

# Square brackets

- When only the base register is enclosed in square brackets, its contents are used as the effective address. The offset is added to the register contents after the operand is accessed. post-indexing is specified. Ex:

LDR R1, [R2], *offset-is-here*

- When both the base register and the offset are placed inside the square brackets, their sum is used as the effective address of the operand, that is, pre-indexing is used. If writeback is to be performed, it must be indicated by the exclamation character.

STR R1, [R2, *offset-is-here*]!

STR R1, [R2, *offset-is-here*]


## Example 6-4 Examples of addressing modes

---


- (1) LDR R0, [R1] @ address pointed to by R1
  - (2) LDR R0, [R1, R2] @ address pointed to by R1 + R2
  - (3) LDR R0, [R1, R2, LSL #2] @ address is R1 + (R2\*4)
  - (4) LDR R0, [R1, #32]! @ address pointed to by R1 + 32, then R1:=R1 + 32
  - (5) LDR R0, [R1], #32 @ read R0 from address pointed to by R1, then R1:=R1 + 32
-

# Example – Pre-indexed addressing mode


- The offset contained in register R6.
- The base value contained in R5.
- The Store instruction (STR) stores the contents of R3 into the word at memory location 1200.



- A  $25 \times 25$  matrix of numbers is stored in column order.
- Access the numbers in the first row of the matrix: 1000, 1100, 1200....




- R2 is used as the base register: contains the initial address value 1000.
- R10 is used to hold the offset = 25.
- R1 is used to load successive elements of the first row of the matrix in successive passes through the loop



# Example – Post-indexed Addressing

LDR R1, [R2], R10, LSL #2

- First loop:
- EA is  $[R2] = 1000$ .
- The number 6 at address 1000 is loaded into R1.
- The writeback operation changes the contents of R2 from 1000 to 1100:
  - Contents of R10 is shifted right by 2 bits:  $25 \times 4 = 100$ .
  - Contents of R2 is increased by 100.
  - The contents of R10 are not changed.



# Example – Pre-indexed Addressing

- Register R5 is used as the stack pointer.
- Initially R5: TOS (top-of-stack) element = 2012.
- The immediate offset -4 is added to the contents of R5 and the new value is written back into R5.
- EA of store operation = 2008.

STR R0, [R5, #-4]!

