Linear Analysis and Optimization of Stream Programs

Andrew A. Lamb
William Thies
Saman Amarasinghe

The New Laboratory for Computer Science and Artificial Intelligence
Massachusetts Institute of Technology

Streaming Application Domain

- Based on audio, video, or data stream
- Increasingly prevalent and important
 - Embedded systems
 - Cell phones, handheld computers
 - Desktop applications
 - Streaming media
 - Software radio

- Real-time encryption
 - Graphics packages
- High-performance servers
 - Software routers (Example: Click)
 - Cell phone base stations
 - HDTV editing consoles

Properties of Stream Programs

- A large (possibly infinite) amount of data
 - Limited lifetime of each data item
 - Little processing of each data item
- Computation: apply multiple filters to data
 - Each filter takes an input stream, does some processing, and produces an output stream
 - Filters are independent and self-contained
- A regular, static computation pattern
 - Filter graph is relatively constant
 - A lot of opportunities for compiler optimizations

The StreamIt Language

Goals:

- Provide a High-Level Programming Paradigm
- Improve Programmer Productivity
- Match Performance of Hand-Hacked Assembly

Contributions


- Language Design, Structured Streams, Buffer Management (CC 2002)
- Exploiting Wire-Exposed Architectures (ASPLOS 2002)
- Scheduling of Static Dataflow Graphs (LCTES 2003)
- Domain Specific Optimizations (PLDI 2003)

Example: Freq band detection

- Used in...
 - metal detector
 - garage door opener
 - spectrum analyzer

Source:

Application Report SPRA414 Texas Instruments, 1999




```
void->void pipeline FrequencyBand {
 float sFreq = 4000;
 float cFreq = 500/(sFreq*2*pi);
 float wFreq = 100/(sFreq*2*pi);
                                                                      A/D
 add D2ASource(sFreq);
 add BandPassFilter(1, cFreq-wFreq,
                                                                   Band pass
                     cFreq+wFreq, 100);
 add splitjoin {
                                                                   Duplicate
   split duplicate;
   for (int i=0; i<4; i++) {
                                                                                    Detect
                                                   Detect
                                                              Detect
                                                                         Detect
     add Detector(i/4);
     add LEDOutput(i);
                                                    LED
                                                               LED
                                                                          LED
                                                                                     LED
   join roundrobin(0);
```

```
void->void pipeline FrequencyBand {
 float sFreq = 4000;
 float cFreq = 500/(sFreq*2*pi);
 float wFreq = 100/(sFreq*2*pi);
                                                                       A/D
 add D2ASource(sFreq);
  float->float pipeline BandPassFilter(float gain, float ws.
                                                                               pass
                            float wp, int num) {
             add LowPassFilter(1, wp, num);
                                                                    Low pass
                                                                    High pass B
             add HighPassFilter(gain, ws, num);
 add splitjoin {
                                                                    Duplicate
   split duplicate;
   for (int i=0; i<4; i++) {
                                                                                     Detect
                                                    Detect
                                                               Detect
                                                                          Detect
     add Detector(i/4);
     add LEDOutput(i);
                                                     LED
                                                                LED
                                                                           LED
                                                                                      LED
   join roundrobin(0);
```

add LowPassFilter(1, wp, num);


```
float->float filter LowPassFilter(float g,
                       float cFreq, int N)
 float[N] h;
  int OFF = N/2;
  for (int i=0; i<N; i++) {
     h[i] = g*sin(...);
 work peek N pop 1 push 1 {
  float sum = 0;
  for (int i=0; i<N; i++) {
   sum += h[i]*<mark>peek</mark>(i);
  push(sum);
  pop();
```

add LowPassFilter(1, wp, num);



```
float->float filter LowPassFilter(float g,
                     float cFreq, int N)
 float[N] h;
  int OFF = N/2;
  for (int i=0; i<N; i++) {
    h[i] = g*sin(...);
 work peek N pop 1 push 1 {
  float sum = 0;
  for (int i=0; i<N; i++) {
   sum += h[i]*peek(i);
  push(sum);
  pop();
```

Freq band detection on a TI DSP



DSP Implementation

```
; Originator: Digital control systems Apps group - Houston
; Target Sys: 'C24x Evaluation Board
; Description: FIR bandpass filter which detects the presence of a
; 500Hz signal. If the tone is detected an LED is
; lit by using the output port. Sampling Frequency
; forced to be 4kHz.
; Last Update: 9 June 1997
.include f240regs.h
; I/O Mapped EVM Registers
DACO .set 0000h :Input data register for DACO
DAC1 .set 0001h ;Input data register for DAC1
DAC2 .set 0002h :Input data register for DAC2
DAC3 .set 0003h ;Input data register for DAC3
DACUPDATE .set 0004h ;DAC Update Register
; Variable Declarations for B2
.bss GPRO.1 ;General Purpose Register
.bss DACOVAL.1 ;DACO Channel Value
.bss DAC1VAL,1 ;DAC1 Channel Value
.bss DAC2VAL,1 ;DAC2 Channel Value
.bss DAC3VAL.1 ; DAC3 Channel Value
: Vector address declarations
.sect ".vectors"
RSVECT B START ; Reset Vector
INT1 B PHANTOM ; Interrupt Level 1
INT2 B FIR ISR ; Interrupt Level 2
INT3 B PHANTOM ; Interrupt Level 3
INT4 B PHANTOM ; Interrupt Level 4
INT5 B PHANTOM ; Interrupt Level 5
INT6 B PHANTOM ; Interrupt Level 6
RESERVED B PHANTOM ; Reserved
SW_INT8 B PHANTOM ; User S/W Interrupt
SW INT9 B PHANTOM ; User S/W Interrupt
SW INT10 B PHANTOM ; User S/W Interrupt
SW INT11 B PHANTOM ; User S/W Interrupt
SW INT12 B PHANTOM ; User S/W Interrupt
SW INT13 B PHANTOM ; User S/W Interrupt
SW INT14 B PHANTOM ; User S/W Interrupt
SW INT15 B PHANTOM ; User S/W Interrupt
SW INT16 B PHANTOM ; User S/W Interrupt
TRAP B PHANTOM ; Trap vector
NMINT B PHANTOM ; Non-maskable Interrupt
EMU TRAP B PHANTOM ; Emulator Trap
SW INT20 B PHANTOM : User S/W Interrupt
SW INT21 B PHANTOM ; User S/W Interrupt
SW INT22 B PHANTOM ; User S/W Interrupt
SW INT23 B PHANTOM ; User S/W Interrupt
```

```
: M A I N C O D E - starts here
.text
START: SETC INTM ; Disable interrupts
SPLK #0002h, IMR ; Mask all core interrupts
; except INT2
LACC IFR : Read Interrupt flags
SACL IFR ; Clear all interrupt flags
CLRC SXM ; Clear Sign Extension Mode
CLRC OVM : Reset Overflow Mode
CLRC CNF ; Config Block BO to Data mem
; Set up PLL Module
LDP #00E0h :DP = 224; Address for
:7000h - 707Fh
;The following line is necessary if a previous program set the PLL
; to a different setting than the settings which the application
;uses. By disabling the PLL, the CKCR1 register can be modified
; so that the PLL can run at the new settings when it is re-enabled.
SPLK #000000001000001b, CKCR0 ; CLKMD=PLL Disable
:SYSCLK=CPUCLK/2
: 5432109876543210
SPIK #000000010111011b CKCP1
; CLKIN (OSC) =10MHz, CPUCLK=20MHz
:CKCR1 - Clock Control Register 1
:Bits 7-4 (1011)CKINF(3)-CKINF(0) - Crystal or Clock-In Frequency
; Frequency = 10MHz
;Bit 3 (1) PLLDIV(2) - PLL divide by 2 bit
; Divide PLL input by 2
:Bits 2-0 (011) PLLFB(2)-PLLFB(0) - PLL multiplication ratio
; PLL Multiplication Ration = 4
: 5432109876543210
SPLK #0000000011000011b,CKCR0
;CLKMD=PLL Enable, SYSCLK=CPUCLK/2
;CKCR0 - Clock Control Register 0
;Bits 7-6 (11) CLKMD(1),CLKMD(0) - Operational mode of Clock
; PLL Enabled; Run on CLKIN on exiting low power mode
:Bits 5-4 (00) PLLOCK(1), PLLOCK(0) - PLL Status. READ ONLY
;Bits 3-2 (00) PLLPM(1),PLLPM(0) - Low Power Mode
;Bit 0 (1) PLLPS - System Clock Prescale Value
; f(sysclk)=f(cpuclk)/2
: 5432109876543210
SPLK #010000011000000b, SYSCR ; CLKOUT=CPUCLK
:SYSCR - System Control Register
:Bit 15-14 (01) RESET1.RESET0 - Software Reset Bits
; No Action
;Bits 13-8 (000000) Reserved
;Bit 7-6 (11) CLKSRC1, CLKSRC0 - CLKOUT-Pin Source Select
; CPUCLK: CPU clock output mode
;Bit 5-0 (000000) Reserved
SPLK #006Fh, WDCR ; Disable WD if VCCP=5V (JP5 in pos. 2-3)
KICK DOG ; Reset Watchdog
```

```
:- Event Manager Module Reset
:-This section resets all of the Event Manager Module Registers.
*This is necessary for silicon revsion 1.1; however, for
:-silicon revisions 2.0 and later, this is not necessary
LDP #232 ;DP=232 Data Page for the Event
SPLK #0000h, GPTCON ; Clear General Purpose Timer Control
SPLK #0000h,T1CON ;Clear GP Timer 1 Control
SDLK #0000h T2CON .Clear GD Timer 2 Control
SPLK #0000h,T3CON ;Clear GP Timer 3 Control
SPLK #0000h, COMCON ; Clear Compare Control
SPLK #0000h, ACTR ; Clear Full Compare Action Control
SPLK #0000h, SACTR ; Clear Simple Compare Action Control
;Register
SPLK #0000h, DBTCON ; Clear Dead-Band Timer Control
SPLK #0FFFFh, EVIFRA; Clear Interrupt Flag Register A
SPLK #0FFFFh, EVIFRB; Clear Interrupt Flag Register B
SPLK #OFFFFh.EVIFRC: Clear Interrupt Flag Register C
SPLK #0000h, CAPCON ; Clear Capture Control
SPLK #0000h, EVIMRA ; Clear Event Manager Mask Register A
SPLK #0000h, EVIMRB ; Clear Event Manager Mask Register B
SPLK #0000h, EVIMRC ; Clear Event Manager Mask Register C
; End of RESET section for silicon revision 1.1 *
; Set up Event Manager Module
TICOMPARE out 2500
T1PERIOD .set 5000 ; Sets up period for 4kHz frequency
LDP #232 :DP=232, Data Page for Event Manager
Addresses
SPLK #T1COMPARE.T1CMPR; Compare value for 50% duty cycle
; 2109876543210
SPLK #0000001010101b, GPTCON
;GPTCON - GP Timer Control Register
;Bit 15 (0) T3STAT - GP Timer 3 Status. READ ONLY
;Bit 14 (0) T2STAT - GP Timer 2 Status. READ ONLY
;Bit 13 (0) T1STAT - GP Timer 1 Status. READ ONLY
;Bits 12-11 (00) T3TOADC - ADC start by event of GP Timer 3
; No event starts ADC
:Bits 10-9 (00) T2TOADC - ADC start by event of GP Timer 2
; No event starts ADC
;Bits 8-7 (00) T1TOADC - ADC start by event of GP Timer 1
; No event starts ADC
:Bit 6 (1) TCOMPOE - Compare output enable
: Enable all three GP timer compare outputs
;Bits 5-4 (01) T3PIN - Polarity of GP Timer 3 compare output
;Bits 3-2 (01) T2PIN - Polarity of GP Timer 2 compare output
;Bits 1-0 (01) T1PIN - Polarity of GP Timer 1 compare output
SPLK #T1PERIOD.T1PR : Period value for 2kHz signal
SPLK #0000h, T1CNT ; Clear GP Timer 1 Counter
SPLK #0000h, T2CNT ; Clear GP Timer 2 Counter
SPLK #0000h, T3CNT ; Clear GP Timer 3 Counter
; 5432109876543210
SPLK #000100000000010b, T1CON
```

Source: Application Report SPRA414, Texas Instruments, 1999

Cont.

```
:T1CON - GP Timer 1 Control Register
;Bits 15-14(00) FREE, SOFT - Emulation Control Bits
; Stop immediately on emulation suspend
;Bits 13-11(010) TMODE2-TMODE0 - Count Mode Selection
: Continuous-Up Count Mode
;Bits 10-8 (000) TPS2-TPS0 - Input Clock Prescaler
; Divide by 1
;Bit 7 (0) Reserved
;Bit 6 (0) TENABLE - Timer Enable
; Disable timer operations
;Bits 5-4 (00) TCLKS1,TCLKS0 - Clock Source Select
; Internal Clock Source
:Bits 3-2 (00) TCLD1,TCLD0 - Timer Compare Register Reload
; Condition
; When counter is 0
;Bit 1 (1) TECMPR - Timer compare enable
; Enable timer compare operation
;Bit 0 (0) Reserved
: 5432109876543210
SPLK #000000000000000b, T2CON
:GP Timer 2 - Not Used
;T2CON - GP Timer 2 Control Register
;Bits 15-14(00) FREE,SOFT - Emulation Control Bits
; Stop immediately on emulation suspend
:Bits 13-11(000) TMODE2-TMODE0 - Count Mode Selection
; Stop/Hold
:Bits 10-8 (000) TPS2-TPS0 - Input Clock Prescaler
; Divide by 1
:Bit 7 (0) TSWT1 - GP Timer 1 timer enable bit
; Use own TENABLE bit
;Bit 6 (0) TENABLE - Timer Enable
; Disable timer operations
;Bits 5-4 (00) TCLKS1,TCLKS0 - Clock Source Select
; Internal Clock Source
;Bits 3-2 (00) TCLD1,TCLD0 - Timer Compare Register Reload
; Condition
; When counter is 0
;Bit 1 (0) TECMPR - Timer compare enable
; Disable timer compare operation
;Bit 0 (0) SELT1PR - Period Register select
: Use own period register
; 5432109876543210
SPLK #00000000000000b, T3CON
:GP Timer 3 - Not Used
:T3CON - GP Timer 3 Control Register
;Bits 15-14(00) FREE,SOFT - Emulation Control Bits
; Stop immediately on emulation suspend
;Bits 13-11(000) TMODE2-TMODE0 - Count Mode Selection
; Stop/Hold
:Bits 10-8 (000) TPS2-TPS0 - Input Clock Prescaler
; Divide by 1
:Bit 7 (0) TSWT1 - GP Timer 1 timer enable bit
; Use own TENABLE bit
;Bit 6 (0) TENABLE - Timer Enable
; Disable timer operations
;Bits 5-4 (00) TCLKS1,TCLKS0 - Clock Source Select
; Internal Clock Source
;Bits 3-2 (00) TCLD1,TCLD0 - Timer Compare Register Reload
; Condition
; When counter is 0
;Bit 1 (0) TECMPR - Timer compare enable
; Disable timer compare operation
;Bit 0 (0) SELT1PR - Period Register select
: Use own period register
```

```
; Set up Digital I/O Port
LDP #225 ; DP=225. Data Page to Configure OCRA
: 5432109876543210
SPLK #0011100000001111b,OCRA
;OCRA - Output Control Register A
;Bit 15 (0) CRA.15 - IOPB7
;Bit 14 (0) CRA.14 - IOPB6
;Bit 13 (1) CRA.13 - T3PWM/T3CMP
;Bit 12 (1) CRA.12 - T2PWM/T2CMP
;Bit 11 (1) CRA.11 - T1PWM/T1CMP
;Bit 10 (0) CRA.10 - IOPB2
·Bit 9 (0) CPA 9 = TOPB1
;Bit 8 (0) CRA.8 - IOPBO
:Bits 7-4 (0000) Reserved
:Bit 3 (1) CRA.3 - ADCIN8
;Bit 2 (1) CRA.2 - ADCIN9
;Bit 1 (1) CRA.1 - ADCIN1
;Bit 0 (1) CRA.0 - ADCINO
; Set up ADC Module
T.DP #224
: 5432109876543210
SPIK #1000100100000000 ADCTRI1
:ADCTRL1 - ADC Control Register 1
:Bit 15 (1) Suspend-SOFT -
: Complete Conversion before halting emulator
:Bit 14 (0) Suspend-FREE -
; Operations is determined by Suspend-SOFT
;Bit 13 (0) ADCIMSTART - ADC start converting immediately
;Bit 12 (0) ADC2EN - Enable/Disable ADC2
; Disable ADC2
;Bit 11 (1) ADC1EN - Enable/Disable ADC1
; Enable ADC1
;Bit 10 (0) ADCCONRUN - ADC Continuous Conversion Mode
; Disable Continuous Conversion
;Bit 9 (0) ADCINTEN - Enable ADC Interrupt
; Mask ADC Interrupt
;Bit 8 (1) ADCINTFLAG - ADC Interrupt Flag
; Clear Interrupt Flag Bit
;Bit 7 (0) ADCEOC - End of Conversion Bit READ ONLY
;Bits 6-4 (000) ADC2CHSEL - ADC2 Channel Select
; Channel 8
;Bits 3-1 (000) ADC1CHSEL - ADC1 Channel Select
; Channel 0
:Bit 0 (0) ADCSOC - ADC Start of conversion bit
· No Action
: 5432109876543210
SPLK #000000000000101b, ADCTRL2
:ADCTRL2 - ADC Control Register 2
;Bits 15-11 (00000)Reserved
;Bit 10 (0) ADCEVSOC - Event Manager SOC mask bit
; Mask ADCEVSOC
;Bit 9 (0) ADCEXTSOC - External SOC mask bit
: Mask ADCEXTSOC
;Bits 7-6 (00) ADCFIF01 - Data Register FIF01 Status READ
·Bit 5 (A) Reserved
:Bits 4-3 (00) ADCFIFO2 - Data Register FIFO2 Status READ
;Bits 2-0 (101) ADCPSCALE - ADC Input Clock Prescaler
; Prescale Value 16
; SYSCLK Period = 0.1usec
; 0.1usec x 16 x 6 = 9.6 usec >= 6usec
```

```
; Set up DAC Module
:The DAC module requires that wait states be generated for proper
;operation.
LDP #0000h ;Set Data Page Pointer to 0000h, Block B2
SPLK #4h,GPR0 ;Set Wait State Generator for
OUT GPRO, WSGR ; Program Space, OWS
;Date Space, OWS
; MAIN LINE
eact " hlkn"
;Coefficients for 500Hz Bandpass filter for 4kHz Sampling Frequency
BCOEFF .word 0000h,0002h,0002h,0001h
.word 0000h,0000h,0000h,0FFFFh
.word OFFFFh,0000h,0000h,0002h
.word 0002h, 0FFFFh, 0FFF9h, 0FFF7h
.word 0000h,0013h,0025h,0021h
.word OFFFBh, OFFBCh, OFF90h, OFFA7h
.word 0011h,00A4h,00FDh,00BFh
.word OffDeh.OfeC3h.Ofe2Ah.OfeA7h
word 0033h 0206h 02F1h 0220h
.word OFFC2h,OFD19h,OFBD6h,OFD05h
.word 003Ch,03B8h,054Ah,03C5h
.word OFFD4h, OFBB4h, OF9EAh, OFBADh
.word 0010h,0484h,0660h,0484h
.word 0010h, 0FBADh, 0F9EAh, 0FBB4h
.word 0FFD4h,03C5h,054Ah,03B8h
.word 003Ch, 0FD05h, 0FBD6h, 0FD19h
.word 0FFC2h,0220h,02F1h,0206h
.word 0033h,0FEA7h,0FE2Ah,0FEC3h
.word OffDEh, OOBFh, OOFDh, OOA4h
word 0011h, 0FFA7h, 0FF90h, 0FFBCh
.word 0FFFBh,0021h,0025h,0013h
.word 0000h, 0FFF7h, 0FFF9h, 0FFFFh
.word 0002h,0002h,0000h,0000h
.word Offffh, Offffh, 0000h, 0000h
.word 0000h,0001h,0002h,0002h
.word 0000h
LEDS .set 000Ch ;I/O Address for LEDS register
WINDOW .set 500 ; Number of smpls to check before
reset'd MAX values
.bss LEDSOUT,1 ;Variable for which LEDS to light
.bss MAXIN,1 ;Maximum value input value
.bss MAXOUT.1 :Maxumum FIR result value
.bss DIFFIN,1 :Maximum Input Value - DC Offset
; (7ffh)
.bss DIFFOUT, 1 ; Maximum Output value - DC Offset
; (7ffh)
.bss THRESHOLD1,1 ;Threshold value for 1st LED
.bss THRESHOLD2,1 ;Threshold value for 2nd LED
.bss THRESHOLD3,1 ;Threshold value for 3rd LED
.bss THRESHOLD4,1 ; Threshold value for 4th LED
.bss THRESHOLD5,1 ;Threshold value for 5th LED
.bss THRESHOLD6,1 ;Threshold value for 6th LED
.bss THRESHOLD7.1 :Threshold value for 7th LED
.bss THRESHOLD8,1 ;Threshold value for 8th LED
```

.bss RESET MAX.1 ; Counter to determine when to

Source: Application Report SPRA414, Texas Instruments, 1999

Cont. Cont.

```
reset MAX values
.bss TEMP.1 ; Variable for temporary storage
of values
.text
MAIN LAR AR1. #ADCFIF01 ; AR1 = ADCFIF01 address
LAR AR2, #ADCTRL1 ; AR2 = ADCTRL1 address
LAR AR3, #BCOEFF ; AR3 = BCOEFF address
LAR AR5, #LEDS ; AR5 = LEDS Output
LACC EVIFRA ; ACC = Event Module Type A Interrupt
SACL EVIFRA : EVIFRA = ACC: Clears the current
;set flags
SPLK #0080h, EVIMRA ; Enable Timer 1 Period
; Interrunt
MAR *.AR2 :ARP = AR2
LACC * ; ACC = ADCTRL1
ADD #1 ;SET BIT FOR SINGLE CONVERSION
SACL *,0,AR1 ;STARTS ADC CONVERSION
SBIT1 T1CON, B6 MSK ; Sets Bit 6 of T1CON; Starts
LDP #0 ;DP = 0; Addresses 0000h - 007Fh
SPLK #0000h, LEDSOUT ; Clear the LEDS
OUT LEDSOUT, LEDS
SPLK #0E38h, THRESHOLD1; Q15 value for 1/9
SPLK #1C71h, THRESHOLD2; Q15 value for 2/9
SPLK #2AAAh, THRESHOLD3:015 value for 3/9
SPLK #38E3h, THRESHOLD4:015 value for 4/9
SPLK #471Ch, THRESHOLD5;Q15 value for 5/9
SPLK #5555h, THRESHOLD6; Q15 value for 6/9
SPLK #638Eh, THRESHOLD7; Q15 value for 7/9
SPLK #71C7h, THRESHOLD8; Q15 value for 8/9
SPLK #0000h, MAXIN ; Initialize Maxmimum input
SPLK #0000h, MAXOUT ; Initialize Maximum FIR output
SPLK #WINDOW.RESET MAX : Initialize the maximum
reset counter:
CLRC INTM :Enable Interrupts
WAIT B WAIT : Wait for interrupt
; INTERRUPT SERVICE ROUTINES FOR FIR FILTER
FIR ISR LAR AR4. #XVALUE+100 ; AR4 = DATA ADDRESS
MAR *, AR1 ; ARP = AR1 = ADCFIFO1
LACC *,0,AR4 ;ACC = ADCFIFO1; ARP =
LDP #0 :DP = 0
:Addresses 0000h - 007Fh
SACL DACIVAL ; DACIVAL = ADCFIFO1
RPT #7 :Shift ADC value 8 places
; - Reduce to 8 bit value
SFR :Larger bit values produced
;large results
SUB #7Fh ;Subtract the equivalent 8 bit
LDP #04h ;DP = 4; Address 0200h - 027Fh
SACL XVALUE ; XVALUE = ADCFIFO1 / 256;
LACC #0h ;Initialize the ACCUMULATOR
MPY #0h :Initialize the PROD REG
RPT #100 ;Calculate Y
MACD BCOEFF, *- : Multiply X with B, and add
APAC : final accumulation
RPT #7 ;Shift the result 8 places to left
SACH DACOVAL,1 :DACOVAL = Y * 2: shift to
;remove extra sign bit
```

```
;Multiply the values by 5/4 because the maximum gain is 4/5
LT DACOVAL :TREG = DACOVAL
MPY #5 : PREG = DACOVAL * 5
PAC :ACC = PREG = DACOVAL * 5
SFR :ACC = DACOVAL * 5 / 2
SFR ;ACC = DACOVAL * 5 / 4
SACL DACOVAL ; DACOVAL = DACOVAL * 5/4
LACC DACOVAL ; ACC = DACOVAL
RPT #3 ;Shift right 4 times
; = 16 bit value to
SFR :12 bit value because
·DAC is 12hits
ADD #7FFh ; Add DC offset
AND #OFFFh . Engure 12 hits
SACL DACOVAL :Store value for output on the DAC
LDP #7 :DP=7: Address for 0380h to 03FFh
SACL VALUEOUT ; Store value to find maximum
; value of the output values
LAR AR6, # (VALUEOUT+127-1) ; AR6 = End of VALUE OUT
LAR AR7, #126 ;AR7 = 127 - 1; Number of
MAR *, AR6 ; ARP = AR6
SHIFT1 DMOV *-. AR7 : Move all of the values in
.the VALUEOUT
BANZ SHIFT1, *-, AR6 ; Data Buffer to the next
·higher address
LDP #0 :DP = 0: Addresses 0000h - 007Fh
LACC DACIVAL ; ACC = DACIVAL = Input Value
RPT #3 ;Shift the value to the
;right 4 times
SFR ; Convert the value from 16
SACL DACIVAL ; DACIVAL = 12 bit value for DAC
LDP #6 :DP = 6: Addresses 0300h - 037Fh
SACL VALUEIN ; VALUEIN = DAC1VAL
LAR AR6, # (VALUEIN+127-1); AR6 = End of VALUE IN
·huffer
LAR AR7, #126 ; AR7 = 127 - 1; Number of
; values to move
MAR *, AR6 ; ARP = AR6
SHIFT2 DMOV *-, AR7 ; Move all of the values in
BANZ SHIFT2, *-, AR6 ; Data Buffer to the next
;Outputs the FIR results and the original value
;DACO has the FIR results and DAC1 has the original value
OUT DACOVAL, DACO : DACO = DACOVAL; FIR result on
·DAC channel O
OUT DACIVAL, DAC1 : DAC1 = DAC1VAL: Input value
on DAC channel 1
OUT DACOVAL, DACUPDATE
;Update the values on the DAC
; Find the maximum value among VALUEIN and VALUEOUT for the LEDs
LACC RESET MAX ; ACC = RESET MAX
SUB #1 :Decrement by 1
SACL RESET MAX ;Store new value for RESET MAX
BCND NO RESET, GT ; If not WINDOWth value, don't
reset counter:
SDIK #WINDOW DESET MAY
:Else reset the max reset counter
SPLK #0000h,MAXIN : Reset the MAXIN value
SPLK #0000h, MAXOUT : Reset the MAXOUT value
NO RESET LAR AR6, #VALUEIN ; AR6 = VALUEIN; Beginning of
```

```
LAR AR7, #127 ; AR7 = 128 - 1; Counter to find
·may tralue in
MAR *, AR6 ; ARP = AR6
FIND MAXIN LACC *+,0,AR7 ;ACC = Value pointed by AR6
SUB MAXIN ; Subtract MAXIN
BCND RESUME1, LEQ ; If the value results in a
than MAXIN, else the
; value is larger than MAXIN
ADD MAXIN : ACC = Value pointed by AR6
SACL MAXIN :Store new MAXIN value
RESUME1 BANZ FIND MAXIN, *-, AR6 : If smaller than MAXIN,
:decrement loop counter
; (AR7), move to next value in
;buffer
LAR AR7, #127 ; Since VALUEIN buffer is
;adjacent to
;VALUEOUT buffer, only AR7
;ARP is already AR6
FIND MAXOUT LACC *+,0,AR7 ;ACC = Value pointed by AR6
SUB MAXOUT ; Subtract MAXOUT
BCND RESUME2.LEO : If the value results in a
; value less than 0.
then the value is smaller than
:MAXOUT, els
the value is larger than
:MAXOUT
ADD MAXOUT ; ACC = Value pointed by AR6
SACL MAXOUT ;Store new MAXOUT value
RESUME2 BANZ FIND MAXOUT, *-, AR6 ; If smaller than MAXOUT,
;dec loop counter (AR7),
;move to next value in buffer
;The following section determines if the value meets the threshold
:requirement
INP #0 -DP = 0. Addresses 0000b to 007Fb
;All variables used are in B2
; Need to remove the DC offset because if the FIR result is 0 it will
;equal 7ffh which is already 50% of the maximum input value
LACC MAXIN ; ACC = MAXIN
SUB #7FFh ; Subtract the DC offset
SACL DIFFIN ; DIFFIN = MAXIN - 7ffh
LACC MAXOUT ; ACC = MACOUT
SUB #7FFh ;Subtract the DC offset
SACL DIFFOUT ; DIFFOUT = MAXOUT - 7ffh
;Check if the output exceeds the middle threshold value, THRESHOLD4
LT DIFFIN :TREG = DIFFIN
TH4 MPY THRESHOLD4 : PREG = DIFFIN * THRESHOLD4
PAC ; ACC = PREG
SACH TEMP.1 : TEMP = ACC+2: Shift to remove
extra sign bit
LACC TEMP ; ACC = TEMP
SUB DIFFOUT ; Subtract DIFFOUT
BCND ABOVE4.LT : If DIFFOUT is greater than
;greater than VALUEIN * THRESHOLD4,
;else, it is below THRESHOLD4 value
;Output is below THRESHOLD4. Check if above THRESHOLD2
BELOWA IT DIFFIN
THO MOV THRESHOLDS
SACH TEMP, 1
LACC TEMP
SUB DIFFOUT
BCND ABOVE2.LT
;Output is below THRESHOLD4 & THRESHOLD2. Check if above THRESHOLD1
TH1 MPY THRESHOLD1
SACH TEMP 1
TACC TEMP
SUB DIFFOUR
BOND ABOVE 1 LT
```

;Data In Buffer

Source: Application Report SPRA414, Texas Instruments, 1999

;FIR result to output


Cont. Cont. Cont.

```
:Output is below THRESHOLD4, THRESHOLD2, & THRESHOLD1. Turn off LEDS
BELOW1 SPLK #0000h, LEDSOUT
B OUTLEDS
:Output is below THRESHOLD4, THRESHOLD2, but above THRESHOLD1. Turn
on DS1
ABOVE1 SPLK #0001h, LEDSOUT
;Output is below THRESHOLD4, but above THRESHOLD2. Check if above
ABOVE2 LT DIFFIN
TH3 MPY THRESHOLD3
SACH TEMP, 1
TACC TEMP
SUB DIFFOUT
BCND ABOVE3, LT
;Output is below THRESHOLD4 and THRESHOLD3, but above THRESHOLD2.
:Turn on DS1-DS2
BELOW3 SPLK #0003h, LEDSOUT
;Output is below THRESHOLD4, but above THRESHOLD3 and THRESHOLD2.
;Turn on DS1-DS3
ABOVE3 SPLK #0007h, LEDSOUT
B OUTLEDS
;Output is above THRESHOLD4. Check if above THRESHOLD6
ABOVE4 LT DIFFIN
TH6 MPY THRESHOLD6
SACH TEMP, 1
LACC TEMP
SUB DIFFOUT
BCND ABOVE6, LT
;Output is above THRESHOLD4, but below THRESHOLD6. Check if above
BELOW6 LT DIFFIN
TH5 MPY THRESHOLD5
SACH TEMP 1
LACC TEMP
SUB DIFFOUT
BCND ABOVE5, LT
;Output is above THRESHOLD4, but below THRESHOLD6 & THRESHOLD5. Turn
on DS1-DS4
BELOW5 SPLK #000Fh, LEDSOUT
;Output is above THRESHOLD4 & THRESHOLD5, but below THRESHOLD6.
;Turn on DS1-DS5
ABOVE5 SPLK #001Fh.LEDSOUT
B OUTLEDS
;Output is above THRESHOLD4 & THRESHOLD6. Check if above THRESHOLD8.
ABOVE6 LT DIFFIN
TH8 MPY THRESHOLD8
PAC
SACH TEMP, 1
LACC TEMP
;Output is above THRESHOLD4 & THRESHOLD6, but below THRESHOLD8.
;Check if above THRESHOLD7.
BELOWS LT DIFFIN
TH7 MPY THRESHOLD7
SACH TEMP, 1
LACC TEMP
SUB DIFFOUT
BCND ABOVE7,LT
```

```
;Output is above THRESHOLD4 & THRESHOLD6, but below THRESHOLD8 &
;THRESHOLD7. Turn on DS1-DS6
BELOW7 SPLK #003Fh, LEDSOUT
B OUTLEDS
:Output is above THRESHOLD4, THRESHOLD6, & THRESHOLD7, but below
;THRESHOLD8. Turn on ;DS1-DS7
ABOVE7 SPLK #007Fh, LEDSOUT
;Output is above THRESHOLD4, THRESHOLD6, & THRESHOLD8. Turn on
ABOVE8 SPLK #00FFh, LEDSOUT
OUTLEDS OUT LEDSOUT, LEDS ; Turn on the LEDS
RESTART ADC MAR *, AR2 ; ARP = AR2
LACC * ; ACC = ADCTRL1
ADD #1h ; Set bit to restart the ADC
SACL * :Start converting next value
LDP #232
LACC EVIFRA ; Clear the flag register of
;Event Manager
SACL EVIFRA
CLRC INTM ; ENABLE INTERRUPTS
RET ; Return to main line
; Description: Dummy ISR, used to trap spurious interrupts.
; Modifies:
; Last Update: 16-06-95
```


Source: Application Report SPRA414, Texas Instruments, 1999

Conventional DSP Design Flow




Any Design Modifications?


- Center frequency from 500 Hz to 1200 Hz?
 - According to TI, in the conventional design-flow:
 - Redesign filter in MATLAB
 - Cut-and-paste values to EXCEL
 - Recalculate the coefficients
 - Update assembly
 - If using StreamIt
 - Change one constant
 - Recompile



Design Flow with StreamIt



Design Flow with StreamIt



- Benefits of programming in a single, high-level abstraction
 - Modular
 - Composable
 - Portable
 - Malleable
- The Challenge: Maintaining Performance
 - Replacing Expert DSP Engineer
 - Replacing Expert Assembly Hacker

Our Focus: Linear Filters


- Most common target of DSP optimizations
 - FIR filters
 - Compressors
 - Expanders
 - DFT/DCT

Output is weighted sum of inputs

- Example optimizations:
 - Combining Adjacent Nodes
 - Translating to Frequency Domain


Representing Linear Filters

- A linear filter is a tuple <A, b, o>
 - **A**: matrix of coefficients
 - b: vector of constants
 - o: number of items popped



Representing Linear Filters

- A linear filter is a tuple <A, b, o>
 - **A**: matrix of coefficients
 - b: vector of constants
 - o: number of items popped



Extracting Linear Representation

```
work peek N pop 1 push 1 {
  float sum = 0;
  for (int i=0; i<N; i++) {
    sum += h[i]*peek(i);
  }
  push(sum);
  pop();
}</pre>
Linear

Dataflow

Analysis

A, b, o>
```

- Resembles constant propagation
- Maintains linear form <v, b> for each variable
 - Peek expression: generate fresh v
 - Push expression: copy v into A
 - Pop expression: increment o

Optimizations using Linear Analysis


1) Combining adjacent linear structures

2) Shifting from time to the frequency domain


3) Selection of 'optimal' set of transformations


1) Combining Linear Filters

- Pipelines and splitjoins can be collapsed
- Example: pipeline




Combination Example






AB for any A and B??

Linear Expansion




Floating-Point Operations Reduction




2) From Time to Frequency Domain


 Convolutions can be done cheaply in the Frequency Domain



- Painful to do by hand
 - Blocking
 - Coefficient calculations
 - Startup etc.



Floating-Point Operations Reduction




3) Transformation Selection

- When to apply what transformations?
 - Linear filter combination can increase the computation cost
 - Shifting to the Frequency domain is expensive for filters with pop > 1
 - Compute all outputs, then decimate by pop rate
 - Some expensive transformations may later enable other transformations, reducing the overall cost


Selection Algorithm

- Estimate minimal cost for each structure:
 - Linear combination
 - Frequency translation
- Cost function based on profiler feedback

- No transformation
 - If hierarchical, consider all possible groupings of children
- Overlapping sub-problems allows efficient dynamic programming search





First compute cost of individual filters:




First compute cost of individual filters:














First compute cost of individual filters:












1x1

Then, compute cost of 1x2 nodes:







Linear Combination


Frequency

No Transform

1x1









Then, compute cost of 1x2 nodes: low high No Transform **Linear Combination** Frequency min= min≢ 1x1


Then, compute cost of 1x2 nodes:













1x2

1x1







Continue with 1x3 2x1 3x1 4x1


1x4 2x2 3x2 4x2


2x3 3x3 4x3


2x4 3x4(4x4)




Overall solution











Radar




Floating-Point Operations Reduction



Experimental Results

- Fully automatic implementation
 - StreamIt compiler
- StreamIt to C compilation
 - FFTW for shifting to the frequency domain
- Benchmarks all written in StreamIt
- Measurements
 - Dynamic floating-point instruction counting
 - Speedups on a general purpose processor

Execution Speedup



On a Pentium IV

Related Work

- SPIRAL/SPL (Püschel et. al)
 - Automatic derivation of DSP transforms
- FFTW (Friego et. al)
 - Wicked fast FFT
- ADE (Covell, MIT PhD Thesis, 1989)
- Affine Analysis (Karr, Acta Informatica, 1976)
 - Affine relationships among variables of a program
- Linear Analysis (Cousot, Halbwatchs, POPL, 1978)
 - Automatic discovery of linear restraints among variables of a program

Conclusions

- A DSP Program Representation: Linear Filters
 - A dataflow analysis that recognizes linear filters
- Three Optimizations using Linear Information
 - Adjacent Linear Structure Combination
 - Time Domain to Frequency Domain Transformation
 - Automatic Transformation Selection
- Effective in Replacing the DSP Engineer from the Design Flow
 - On the average 90% of the FLOPs eliminated
 - Average performance speedup of 450%
- StreamIt: A Unified High-level Abstraction for DSP Programming
 - Increased abstraction does not have to sacrifice performance

http://cag.lcs.mit.edu/linear/