# Standard Terminology of Building Constructions<sup>1</sup>

This standard is issued under the fixed designation E631; the number immediately following the designation indicates the year of original adoption or, in the case of revision, the year of last revision. A number in parentheses indicates the year of last reapproval. A superscript epsilon  $(\varepsilon)$  indicates an editorial change since the last revision or reapproval.

# 1. Scope

- 1.1 This Terminology consists of terms and definitions pertaining to the subject field of buildings and building construction, and in particular, terms related to the standards generated by ASTM Committee E06 on Performance of Buildings.
- 1.2 The purpose of this Terminology is to provide preferred and admitted designations along with the meanings and explanations of technical concepts applied in the subject field of buildings and construction, written for both the non-expert and the expert user.
- 1.3 This comprehensive Terminology standard contains all ASTM standardized definitions generated in ASTM Committee E06 that are considered general in nature. Beyond this comprehensive terminology, there are also separate terminology standards that have been developed within Committee E06 by a number of technical subcommittees.
- 1.3.1 These separate general terminologies are created relative to specific subject fields and the terminological entries have been grouped for convenient use (see Section 2 and Appendix X1). Some terminology data contained in those other subsidiary terminology standards also appear in this comprehensive standard.
- 1.3.2 The following standards are separate terminologies that have been developed within specific E06 Subcommittees whose term entry lists are provided in Appendix X1:

E833 Terminology of Building Economics

E1480 Terminology of Facility Management (Building-Related)

E1481 Terminology of Railing Systems and Rails for Buildings

E1605 Terminology Relating to Lead in Buildings

E1749 Terminology Relating to Rigid Wall Relocatable Shelters

E2110 Terminology for Exterior Insulation and Finish Systems (EIFS)

E2151 Terminology of Guides for Specifying and Evaluating Performance of Single Family Attached and Detached Dwellings

E2265 Terminology for Anchors and Fasteners in Concrete and Masonry

1.4 Terms are listed in alphabetical sequence. Compound terms appear in the natural spoken order. To show the relation-

<sup>1</sup> This terminology is under the jurisdiction of ASTM Committee E06 on Performance of Buildings and is the direct responsibility of Subcommittee E06.94 on Terminology and Editorial.

Current edition approved March 1, 2015. Published April 2015. Originally approved in 1978. Last previous edition approved in 2014 as E631 - 14. DOI: 10.1520/E0631-15.

Those terms formerly contained in Definitions E540-77 are now contained in this terminology.

ships in certain families of concepts, groups of narrower terms and their definitions are grouped under the definition of the broader term. Each such sub-entry is listed also (*in italics*) with a cross-reference to the special class.

1.5 Certain standard definitions herein are adopted from other sources. Each is an exact copy. The source is identified at the right margin following the definition, and is listed in Section 2.

# 2. Referenced Documents

2.1 ASTM Standards:<sup>2</sup>

C168 Terminology Relating to Thermal Insulation

C755 Practice for Selection of Water Vapor Retarders for Thermal Insulation

E73 Practice for Static Load Testing of Truss Assemblies E96/E96M Test Methods for Water Vapor Transmission of Materials

E456 Terminology Relating to Quality and Statistics

E546 Test Method for Frost/Dew Point of Sealed Insulating Glass Units

E564 Practice for Static Load Test for Shear Resistance of Framed Walls for Buildings

E621 Practice for Use of Metric (SI) Units in Building Design and Construction(Committee E06 Supplement to E380) (Withdrawn 2008)<sup>3</sup>

E774 Specification for the Classification of the Durability of Sealed Insulating Glass Units (Withdrawn 2006)<sup>3</sup>

E779 Test Method for Determining Air Leakage Rate by Fan Pressurization

E859 Test Method for Air Erosion of Sprayed Fire-Resistive Materials (SFRMs) Applied to Structural Members

E997 Test Method for Evaluating Glass Breakage Probability Under the Influence of Uniform Static Loads by Proof Load Testing

E998 Test Method for Structural Performance of Glass in Windows, Curtain Walls, and Doors Under the Influence of Uniform Static Loads by Nondestructive Method

<sup>&</sup>lt;sup>2</sup> For referenced ASTM standards, visit the ASTM website, www.astm.org, or contact ASTM Customer Service at service@astm.org. For *Annual Book of ASTM Standards* volume information, refer to the standard's Document Summary page on the ASTM website.

<sup>&</sup>lt;sup>3</sup> The last approved version of this historical standard is referenced on www.astm.org.

- E1186 Practices for Air Leakage Site Detection in Building Envelopes and Air Barrier Systems
- E1334 Practice for Rating the Serviceability of a Building or Building-Related Facility (Withdrawn 2013)<sup>3</sup>
- E1423 Practice for Determining Steady State Thermal Transmittance of Fenestration Systems
- E1480 Terminology of Facility Management (Building-Related)
- E1553 Practice for Collection of Airborne Particulate Lead During Abatement and Construction Activities (Withdrawn 2002)<sup>3</sup>
- E1554/E1554M Test Methods for Determining Air Leakage of Air Distribution Systems by Fan Pressurization
- E1613 Test Method for Determination of Lead by Inductively Coupled Plasma Atomic Emission Spectrometry (ICP-AES), Flame Atomic Absorption Spectrometry (FAAS), or Graphite Furnace Atomic Absorption Spectrometry (GFAAS) Techniques
- E1644 Practice for Hot Plate Digestion of Dust Wipe Samples for the Determination of Lead
- E1645 Practice for Preparation of Dried Paint Samples by Hotplate or Microwave Digestion for Subsequent Lead Analysis
- E1677 Specification for Air Barrier (AB) Material or System for Low-Rise Framed Building Walls
- E1679 Practice for Setting the Requirements for the Serviceability of a Building or Building-Related Facility, and for Determining What Serviceability is Provided or Proposed
- E1726 Practice for Preparation of Soil Samples by Hotplate Digestion for Subsequent Lead Analysis
- E1727 Practice for Field Collection of Soil Samples for Subsequent Lead Determination (Withdrawn 2014)<sup>3</sup>
- E1728 Practice for Collection of Settled Dust Samples Using Wipe Sampling Methods for Subsequent Lead Determination
- E1729 Practice for Field Collection of Dried Paint Samples for Subsequent Lead Determination (Withdrawn 2014)<sup>3</sup>
- E1753 Practice for Use of Qualitative Chemical Spot Test Kits for Detection of Lead in Dry Paint Films
- E1775 Guide for Evaluating Performance of On-Site Extraction and Field-Portable Electrochemical or Spectrophotometric Analysis for Lead
- E1783/E1783M Specification for Preformed Architectural Strip Seals for Buildings and Parking Structures
- E1792 Specification for Wipe Sampling Materials for Lead in Surface Dust
- E1796 Guide for Selection and Use of Liquid Coating Encapsulation Products for Leaded Paint in Buildings
- E1827 Test Methods for Determining Airtightness of Buildings Using an Orifice Blower Door
- E1828 Practice for Evaluating the Performance Characteristics of Qualitative Chemical Spot Test Kits for Lead in Paint (Withdrawn 2010)<sup>3</sup>
- E1918 Test Method for Measuring Solar Reflectance of Horizontal and Low-Sloped Surfaces in the Field
- E1925 Specification for Engineering and Design Criteria for Rigid Wall Relocatable Structures

# 3. Terminology

- 3.1 Symbols:
- **a**—height of cantilevered shear wall, in metres (feet).
- **b**—length of cantilevered shear wall, in metres (feet).
- C—initial length of the diagonal  $\sqrt{a^2+b^2}$ , in metres (feet).
- **δ**—diagonal elongation, in millimetres (inches).
- **Δ**—total horizontal displacement of the top of the wall measured with respect to the test apparatus, in millimetres (inches). This value includes effects due to panel rotation, translation, and shear.
- E—modulus of elasticity of flange or web material, depending upon which material is held constant in a transformed section analysis, psi (or MPa)
- G—shear modulus of the web material, psi (or MPa)
- **G'**—shear stiffness of the diaphragm obtained from test (includes shear deformation factor for the connection system), lbf/in. (or N/mm)
- **G**—shear stiffness obtained from test, in newtons per metre (pound-force per inch).
- **G'**—global shear stiffness, includes rotation and translational displacements as well as diaphragm shear displacement.
- G'<sub>int</sub>—internal shear stiffness, includes only the shear displacement of the wall in calculation.
- **I**—moment of inertia of the transformed section of the diaphragm based on webs or flanges, in.<sup>4</sup> (or mm<sup>4</sup>)
- L—total span of a simply supported diaphragm, in. (or mm)
- **P**—concentrated load, lbf (or N)
- **P**—concentrated load applied at the top edge of the wall at the selected reference displacement, in newtons (pound-force).
- $P_u$ —highest load level held long enough to record gage measurements, in newtons (pound-force).
- **R**<sub>u</sub>—maximum diaphragm reaction, lbf (or N)
- $S_u$ —ultimate shear strength of the diaphragm, lbf/ft (or N/m)
- a—span length of cantilever diaphragm, in. (or mm)
- **b**—depth of diaphragm, in. (or mm)
- **t**—thickness of web material, in. (or mm)
- w—uniform load, lbf/in. (or N/mm)
- $\Delta_{\mathbf{b}}$ —bending deflection of diaphragm, in. (or mm)
- $\Delta_k$ —empirical expression for that portion of the diaphragm deflection contributed by the shear deformation of the connection system, in. (or mm)
- $\Delta_s$ —pure shear deformation of diaphragm, in. (or mm)
- $\Delta_s$ '—apparent total shear deformation of the diaphragm based on test (see 8.1.2.2), in. (or mm). This factor includes both

the pure shear deformation and that contributed by distortion of the connection system.

 $\Delta_t$ —total deflection of diaphragm, in. (or mm)

 $\Delta_{1,2}$ —deformation measured at Point 1, 2, - - - , in. (or mm)

3.2 Terms and Their Definitions:

**accreditation,** *n*—official authorization, approval, or recognition accorded an individual or organization based upon specific qualification.

DISCUSSION—In specific use, it is necessary to include an identification of the type, scope, and limitations of the accreditation, and by whom granted.

ACH<sub>50</sub>, n—the ratio of the air leakage rate at 50 Pa (0.2 in.  $H_2O$ ), corrected for a standard air density, to the volume of the test zone (1/h).

acid rain—rain having a pH of less than 5.65.

Discussion—The pH of distilled water in equilibrium with carbon dioxide under laboratory conditions is 5.6.

active solar energy system—See building subsystem.<sup>4</sup>

adapt—See building modification.

add—See building modification.

**aged insulation value**—thermal resistance (R-value) of a thermal insulation material as determined after standard conditioning to simulate service exposure.

air-change rate—air-leakage in volume units per hour divided by the building space volume with identical volume units (normally expressed as air changes per hour, ACH or ACPH).

E779

air exfiltration—air leakage out of the building driven by negative pressure.E1677

negative pressure—air pressure on the outdoor side of a building envelope lower than on the indoor side. **E1677** 

**air-handling unit**—the distribution-system fan and portion of the distribution system that is integral to the furnace, air-conditioner, or heat-pump.

E1554/E1554M

air infiltration—air leakage into the building drive by positive pressure.E1677

positive pressure—air pressure on the outdoor side of a building envelope higher than on the indoor side.

E1677

air leakage, n—in buildings, the passage of uncontrolled air through cracks or openings in the building envelope or its components, such as ducts, because of air pressure or temperature difference.

air leakage—the movement/flow of air through the building envelope, which is driven by either or both positive (infiltration) and negative (exfiltration) pressure differences across the envelope.

DISCUSSION—These pressure differences are caused by wind, mechanical systems, and temperature differences (stack effect).

**air-leakage graph**—the graph that shows the relationship of measured air flow rates to the corresponding measured pressure differences (usually plotted on a log-log scale).

E779

air leakage rate,  $Q_{env}$ , n—the total volume of air passing through the test zone envelope per unit of time (m<sup>3</sup>/s, ft<sup>3</sup>/min).

air-leakage rate—the volume of air movement per unit time across the building envelope. E779

Note 1—This movement includes flow through joints, cracks, and porous surfaces, or combination thereof. The driving force for such an air leakage in service can be either mechanical pressurization and depressurization, natural wind pressures, or air temperatures differentials between the building interior and the outdoors, or combination thereof.

- air leakage rate—the time rate of air flow across the air retarder. Expressed as cubic feet per minute per square foot of AR surface at a stated pressure differential across the AR expressed in inches of H<sub>2</sub>O. (Cubic meters per second per square meter of AR surface at a pressure differential in Pascals.)
- air leakage rate—the volume of air movement per unit time across the building envelope. This movement includes flow through joints, cracks, and porous surfaces or combinations thereof. The driving force for such air leakage in buildings can be either mechanical pressurization or evacuation, natural wind pressures, or air temperature differentials between the building interior and the outdoors, or combinations thereof.

  E1186

air-leakage rate—the volume of air movement per unit time across the building envelope or the exterior envelope of the air distribution system.

E1554/E1554M

Discussion—This movement includes flow through joints, cracks, and porous surfaces, or combinations thereof. The driving forces for such air leakage in service can be mechanical pressurization and depressurization, natural wind pressures, and air temperature differentials between the building interior and the outdoors.

air leakage site—a location on the building envelope where air enters or exits the building causing air leakage to occur.

- air retarder (AR)—a material or system in building construction that is designed and installed to reduce air leakage either into or through the opaque wall.E1677
- air sampling pump—a portable, battery-powered air pump that may be attached to a belt on a worker or to a stationary object. The pump is used to draw air through a filter holder that is placed within the personal breathing zone of a worker. Alternatively, the pump may be attached to a stationary object in order that it may be used for area sampling. **E1553**

**airtightness**, *n*—the degree to which a test zone envelope resists the flow of air.

E1827

Note 2— $ACH_{50}$ , air leakage rate, and effective leakage area are examples of measures of building airtightness.

alter—See building modification.

<sup>&</sup>lt;sup>4</sup> Boldface terms are defined in this terminology.

analysis run—a period of measurement time on a given instrument during which data is calculated from a single calibration curve (or single set of curves). Recalibration of a given instrument produces a new analysis run.

**anchor,** *n*—a device used to connect securely a **building component** to adjoining construction, to a supporting member, or to the ground.

**anchorage,** *n*—a means of connecting securely, by using an **anchor**, a **building component** to adjoining construction, supporting member(s), or to the ground.

**anchorage system—**a group of interacting elements, components, and structures.

anchoring system—a group of interacting anchors and elements.

anodic stripping voltammetry—an electroanalytical technique in which the concentration of analyte metal species dissolved in solution is determined in the following manner. The analyte is first deposited (preconcentrated) electrochemically by reducing the dissolved ion in solution to immobilized metal species at a mercury electrode surface. The metal is deposited in the form of an amalgam (with Hg) at an applied potential (voltage) which is negative of the standard oxidation potential for the metal/ion redox couple. After deposition, the preconcentrated metal species is then "stripped" from the mercury electrode by applying a positive potential sweep, which causes anodic oxidation of the analyte metal species to dissolved ion. The current associated with this reoxidation is measured. The peak current is proportional to the original concentration of dissolved analyte species over a wide range of concentrations.

apartment—See dwelling unit.

apartment building—See building.

architectural strip seal—a preformed membrane or tubular extrusion, manufactured from a fully cured elastomeric alloy, having flanges or other means of mechanically or chemically securing it.
 E1783/E1783M

area samples—air samples that are collected at various stationary sites, but not for a person; area samples are therefore to be distinguished from personal air samples.E1553

**artifact,** *n*—an object (as a tool, ornament, or element of a structure) showing human workmanship or modification.

Discussion—Examples of building element artifacts are stained glass windows and fine art finishes.

**as-built,** *adj*—pertaining to the as-constructed, **as-fabricated**, as-manufactured, or as-furnished state of a finished product relating to size, shape, materials, and finish regardless of drawings or specifications.

**as-fabricated,** *adj*—(1) *of a milled metal product*, pertaining to the surface appearance and texture or temper produced by the original forming process. (2) *of a formed metal product*, pertaining to the surface appearance of the product to removal of disfigurations caused by the forming process.

**aspect,** n—of serviceability, a broad component of serviceability, comprising several related topics of serviceability. **E1334** 

Discussion—The serviceability of a building or building-related facility can be rated on each topic for which a scale has been prepared, but not for an aspect.

**aspect ratio**—a ratio of long side to short side of glass plate.

attic—See building space.

average breaking stress (ABS)—the average maximum principal tensile stress (MPTS) at failure, representative of the glass under test. The ABS is dependent on a number of factors including geometry, time history of load, surface condition, etc. Glasses with residual surface stresses, such as heat-strengthened or fully tempered, must have their residual stresses added to the state of stress at the specified load. As defined for use in the standard, the ABS is for annealed glass.

F998

average grade—See grade.

back bedding—See windows and doors.

back putty—See windows and doors.

balance—See windows and doors.

**bar**, *n*—a round, square, rectangular, or other polygonal solid member having a length greater than its width or thickness; and usually of rolled, drawn, or extruded metal (if of steel, having dimensions of 0.204 in. (5.2 mm) or more in thickness, and 8.0 in. (20.3 mm) or less in width).

**bar-size section**—a hot-rolled steel angle, channel, tee, or zee having a maximum cross-section dimension of less than (76 mm) (3.0 in.)

base substrate—a material upon which films, treatments, adhesives, sealants, membranes, and coatings are applied. The base substrate can also be considered to be the actual material of construction that the surface is attached to. This does not refer to the layers of paint under the outermost or surface layer.

basement—See building space.

batch—a group of samples (n > 2) that are obtained in a similar environment (for example, a set of area or personal samples) and are processed together using the same reagents and equipment.
E1553

bathroom—See building space.

bead—See windows and doors.

**beadboard,** *n*—molded **expanded polystyrene thermal insulation board;** also called **MEPS.** 

**beam,** *n*—a structural member intended primarily to resist transverse forces, and subject to bending by these forces.

bearing wall—See wall.

**bias,** *n*—systematic error that contributes to the difference between a population mean of the measurements or test results and an accepted reference or true value. **E456** 

bite—See windows and doors.

**blow hole**—a unintended hole or void in a metal casting resulting from entrained gases.

blower door, n—a fan pressurization device incorporating a controllable fan and instruments for airflow measurement and building pressure difference measurement that mounts securely in a door or other opening.

E1827

**bracket,** *n*—projecting element or hardware attached to the surface of a member to support other members.

**breather finish**—coating system allowing the passage of water vapor.

Discussion—A breather finish has water-vapor permeance greater than that acceptable for a water-vapor retarder.

**builder's model,** *n*—a reference standard of quality for specific building **components**, denoting by example, the level of quality adopted by a builder.

Discussion—The examples, or samples of construction materials, permit examination of quality level.

**building,** *n*—(1) a shelter comprising a partially or totally enclosed space, erected by means of a planned process of forming and combining materials. (2) the act or process of constructing.

*apartment building*—a **building** containing more than two **dwelling units** not intended for individual unit ownership.

condominium, n—an **apartment building**, group of townhouses, or single dwellings in which each **dwelling unit** is individually owned and each owner holds an interest in common areas. Also commonly used to denote an individual unit.

house, n—a building intended in its entirety as a dwelling.

*split-level house*—one divided vertically so that the floor level of rooms in one part is approximately midway between the levels of two successive stories in an adjoining part.

industrialized building—a manufactured building (preferred term).

manufactured building—a structure wholly or substantially made in a manufacturing plant for installation or assembly at the building site.

manufactured home—a manufactured building intended to be used as a dwelling.

Discussion—The U.S. Department of Housing and Urban Development (HUD) defines this term as "A structure, transportable in one or more sections, which, in the traveling mode, is eight body feet or more in length, or, when erected on site, is three hundred twenty or more square feet; and which is built on a permanent chassis and designed to be used as a dwelling with or without a permanent foundation when connected to the required utilities, and includes the plumbing, heating, air conditioning, and electrical systems contained therein." (42USC5402). The 1980 Housing and Community Development Act changed the term, mobile home, to manufactured home.

packaged building—Use manufactured building or precut building.

precut building—a manufactured building produced largely of elements cut to size in a factory and transported for assembly at the erection site.

prefabricated building—Use manufactured building.

building code—See code.

**building component,** *n*—a building element using industrial products that are manufactured as independent units capable of being joined with other elements.

**building construction,** *n*—(1) the act or process of making or forming a **building** by assembling or combining elements, **components,** or systems. (2) the structure or part thereof so formed.

closed construction—a method by which a building, system, assembly, or component is manufactured, in such a manner that portions cannot be readily inspected at the installation site without disassembly or destruction.

*industrialized building process*—the process of constructing manufactured **buildings**.

open construction—a method by which a building, component, assembly or system is manufactured in such a manner that all portions can be readily inspected on site without disassembly or destruction.

panelized construction—a building method using **panels** as major elements.

building enclosure—Use building envelope.

**building envelope**—the outer elements of a **building**, both above and below ground, that divide the external from the internal environments.

**building envelope**—the boundary or barrier separating the interior volume of a building from the outside environment. **E1554/E1554M** 

**building fabric**—(1) elements, components, parts, materials, or systems of a building separately or in combination; (2) loadbearing part of a structure without windows, doors, interior or exterior finishes.

**building modification**—change or activity affecting the materials, structure, operations, or appearance of a building or its systems.

*adapt*, *v*—*in building*, to make suitable for a particular purpose by means of change or modification.

*add*, *v*—*in building*, to extend by means of new construction, or by enclosing an existing structure.

alter, v—in building, to make different, or to rearrange the layout.

improve, v—to enhance the quality or value of land or property.

download from https://elitesafetyglass.com

- *maintain*, v—to keep in working order, or to preserve from decline or failure.
- *modernize*, *v*—*in building*, to adapt to current needs, tastes, or usage by **remodeling** or **repair**.
- *rebuild*, *v*—to return to **building** to its previous state or condition.
- *reconstruct*, v—to reproduce in the exact form and detail a **building**, structure, or **artifact** as it appeared at a specific period in time.
- reconstruction, n—the act or process of reproducing by new construction the exact form and detail of a vanished **building**, other structure, or **artifact** as it appeared at a specific period in time.
- remodel, v—to replace or improve a building or its parts.
- *repair*, *v*—to replace or correct damaged or faulty **components** or **subsystems** of a **building** to **maintain** operating capability.
- *retrofit*, *v—in building*, to add new materials or equipment not provided at the time of original construction.
- **building performance,** *n*—the behavior in service of a construction as a whole, or of the **building components.**
- durability, n—the capability of a **building**, assembly, **component**, product, or construction to maintain **service**-ability over at least a specified time.
- *serviceability*, *n*—the capability of a **building**, assembly, **component**, product, or construction to perform the function(s) for which it is designed and used.
- **building permit,** *n*—an authorization granted by the agency having jurisdiction to an applicant to proceed with construction on a specific project.
- **building preservation,** *n*—measures taken to conserve, protect, rehabilitate, restore, or stabilize a building. See **preservation.**
- **building pressure difference**, *P*, *n*—the pressure difference across the test zone envelope (Pa, in. H<sub>2</sub>O). **E1827**
- building pressure difference—the pressure difference across the building envelope, expressed in pascals (inches of water, pounds-force per square foot, or inches of mercury).

  E1554/E1554M

# building space:

- attic, n—an accessible enclosed space immediately below the roof and wholly or partly within the roof framing.
- basement—a space partly below average grade having less than one half of its clear height (measured from floor level to ceiling level) below average grade.
- bathroom—a room containing a bathtub or shower, or both, and usually a lavatory (wash basin) and toilet (water closet).

- *cellar*—a space wholly or partly below **average grade** having more than one half of its clear height (measured from floor level to ceiling level) below **average grade**.
- *environmental chamber*, *n*—an enclosed space, used for testing designed and constructed to provide control of interior atmosphere to specified conditions.
- habitable space—occupiable space normally used for living, including such activities as sleeping, eating, and cooking.

  Discussion—Bath, lavatory, and toilet rooms are excluded.
- half bath—a room containing a lavatory (wash basin) and a toilet (water closet).
- kitchen—a space containing facilities primarily for the preparation of food.
- occupiable space—space normally used by people.

  Discussion—Corridors, stairways, and spaces used for storage,
- equipment, heating, cooling, and general maintenance are excluded.
- *office*, *n*—a place, such as a room, suite, or building, in which business, clerical, or professional activities are conducted.
- *open-plan workstation*—office workspace for one person, not enclosed by full-height walls.
- primary circulation area—portion of building area dedicated to public corridor, lobby, or atrium; or required for access to stairs, elevators, restroom facilities, or building exits.
- secondary circulation area—portion of building area not defined as **primary circulation area**, but required for access to some subdivision of space, whether or not bounded by **walls**.
  - Discussion—An example may be a circulation area within a tenant or occupant space.
- *story*, *n*—a space excluding **attics**, **basements**, and **cellars**, between successive floor levels or between **floor** and roof.
- *first story*—the lowermost **story** of a **building** entirely above the **average grade** (also used as a synonym for **ground floor**).
- top story—the uppermost story of a building.
- **building subsystem**—a complete, integrated set of parts that functions as a unit within the finished **building**. See also **cladding system**, **hard-coat system**.
- solar energy system—a **building subsystem** to convert solar energy into thermal energy for space heating or cooling, water heating, or process energy.
- active solar energy system—a **building subsystem** in which solar energy is collected and transferred predominantly by mechanical power not derived from solar radiation.
- passive solar energy system—a **building subsystem** in which solar energy is collected and transferred predominantly by natural means, namely, conduction, convection, radiation, or evaporation.
- **building system**—(1) group of structural or non-structural components or assemblies, or both, of a building interacting

to serve a common purpose; (2) method for fabricating or erecting an entire structure. See also **anchorage system**, **anchoring system**, **hard-coat system**, **structural system**, **exterior installation**, **finish system**.

*closed system*—a building system having interchangeability of only its own **subsystems**, subassemblies, and **components**.

industrialized building system—the integration of subsystems and components into an overall process, utilizing factors of production, transportation, and on-site assembly techniques.

open system—a building system, designed to have interchangeability of its subsystems, subassemblies, components, or building elements with like subsystems, subassemblies, components, or elements of other systems.

prefabricated panel system—building-panel system fabricated away from its ultimate position on a building.

Discussion—One example is a system consisting of an **EIFS**, internal integral structural framing, connections, internal sealant, when required, and installation accessories.

butt joint—See joint.

**cantilever,** *n*—an overhanging portion or a member or slab projecting beyond support(s) sufficiently to induce bending and shear stresses in projecting part(s) when subjected to transverse loading including uniform, concentrated, or other load types.

**capillary migration**—of water, movement of water induced by the force of molecular attraction (surface tension) between the water and the material it contacts. Compare **rising damp.** 

**carbonation,** *n*— *building(s)*, a process of chemical weathering whereby minerals that contain sodium oxide, calcium oxide, potassium oxide, or other basic oxides are changed to carbonates by the action of carbonic acid derived from atmospheric carbon dioxide and water.

**caulk,** *v*—to fill joints, **cracks,** or crevices in order to prevent the passage of air or water.

cellar—See building space.

**cellular polystyrene,** *n*—polymerized styrene resin processed to form a rigid foam having a predominately closed-cell structure making it suitable as thermal insulation.

Discussion—The manufacturing process can be an expansion of foamable beads under heat and pressure within a mold, or in-situ foaming of molten resin in an extrusion mode. See also **rigid cellular polystyrene thermal insulation board.** 

**cement,** *n*—a general term for a binding element. See specific terms such as Portland cement, Keene's cement, and adhesive cement.

**certification,** *n*—a written declaration that a particular product or service complies with stated criteria.

Discussion—In specific use, it is necessary to include the scope and limitations of the certification; usually it is provided by the manufacturer, producer, or vendor.

**cladding system,** *n*—material assembly applied to a building as a non-load-bearing wall, or attached to a wall surface as a protective and ornamental covering.

**clip,** *n*—a small fastening device, usually of metal, designed to hold an element or **component** in place.

closed construction—See building construction.

closed system—See building system.

**coating,** *n*—a liquid, liquefiable, or mastic composition that, after application as a thin layer, is converted to a solid protective, or decorative, or functional adherent film.

Discussion—Such coatings are one form of protective or decorative finish for building purposes. Other forms include gold leaf and metals deposited by electroplating or hot dipping.

**code,** *n* (in the Law)—a collection of laws (regulations, ordinances, or statutory requirements) adopted by governmental (legislative) authority.

*building code*, *n*—a **code** applicable to **buildings**, adopted and administered with the primary intent of protecting public health, safety, and welfare.

*model code*, *n*—a proposed **code** that is established within the procedural framework of a group of knowledgeable people, and is designed for adoption by governmental authority.

**coefficient of variation**—the ratio (decimal fraction) of the standard deviation of the maximum principal tensile stress (MPTS) at failure to the ABS. **E998** 

**coefficient of variation,** *v*—ratio of the standard deviation of the failure load to the mean failure load. **E997** 

**coherent unit system**—system in which relations between units contain as numerical factor only the number "one" or "unity," because all derived units have a unity relationship to the constituent base and supplementary units.

*cold joint*—See **joint.** 

colorimetry—an analytical technique that is similar to spectrophotometry except that ultraviolet-visible light of a single, narrow wavelength range is passed through a sample cell containing dissolved analyte, and the absorption measured.

E1775

**column,** *n*—a building member, usually structural and vertical, subjected to longitudinal (axial) compression and also to lateral forces such as bending.

**combination of features,** *n*—*of a facility,* two or more features which, when present together in a facility, affect a level of serviceability of that facility. **E1334** 

component—See building component.

condominium—See building.

**connection**—device or method used to fasten together two or more components of a structural system using mechanical means, welding, adhesives, or a combination of them.

Discussion—connection usually implies a junction of structural members to make a safe, load-carrying system, for example, a truss. Traditionally the term **joint** has been used in place of the term **connection**.

**consensus**, *n*—substantial agreement achieved through a **consensus process**, but not necessarily unanimity.

**consensus process**, *n*—a formal procedure for reaching **concensus** that includes the elements of due process.

Discussion—An example of due process requirements in a consensus procedure is found in 1.4 of the "Regulations Governing ASTM Technical Committees" (September 1982).

conservation—See preservation.

construction joint—See joints.

control joint—See joint.

core module—See module.

**core sample**—a fragment of a dry paint film removed from the substrate with a coring tool which is designed to remove a specified area (that is, a square centimetre) of dry paint film.

E1753

cover plate—Synonym for escutcheon.

**crack** (building defect), *n*—a flaw consisting of complete or incomplete separation within a single element or between contiguous elements of constructions.

Discussion—Occasionally the basic design, or the material characteristics, of a building element will be such that minor cracking may occur. Such cracks are not flaws or defects.

**criterion,** *n*—an established precedent, rule, measure, norm, or **code** upon which a decision may be based.

**curing,** *n*—chemical process of developing ultimate properties of a finish or other material over a specified period of time. Compare **drying.** 

curtain wall—See wall.

**delamination**—separation into constituent layers. **E1925** 

**denier,** *n*—the number of grams per 9000 m. **E859** 

detached dwelling—See dwelling.

**deterministic design,** *n*—design based on the physical and mechanical properties of the materials, elements, and structures involved (compare **probabilistic design**).

Discussion—In this method of design, load and resistance to load are assigned values for each particular situation as provided in the codes for given conditions. Existing variability in and range of these values, probability of failure, residual deformation, shock absorption, damping capacity, as well as load-sharing and torsional rigidity may or may not be given direct consideration. Under given conditions, deterministic design is applicable to statically and dynamically exposed, relatively rigid materials, elements, and structures; but not to those that can absorb the surge of high external forces and return to their original shape without permanent failure, or appearance of failure.

digestate—an acidified aqueous solution that results from digestion of the sample.
E1644

digestion—the sample preparation process that will solubilize (extract) targeted analytes present in the sample and results in an acidified aqueous solution called the digestate. E1613

distribution-system pressure difference—the pressure difference across the exterior air-distribution envelope, expressed in pascals (inches of water, pounds-force per square foot, or inches of mercury).

E1554/E1554M

**door,** *n*—usually swinging or sliding barrier by which an entry is closed and opened.

**drainage hole**—an opening in a construction provided for the escape of unwanted liquid, as in a retaining wall. Compare **vent hole**, **weep hole**.

**drawing,** *n*—an architectural, structural, mechanical, or electrical plan, elevation, or section indicating in isometric perspective or in axonometric perspective the detailed location, dimension, quantity, or extent of material, product, or member to be furnished. Compare **shop drawing, working drawing.** 

duplicate sample—a second portion of a homogenized sample carried through sample digestion. Analysis results for these samples are used to provide information on the precision of the homogenization process.

**drying,** *n*—process of developing, solely by evaporation of volatile ingredients, ultimate properties of a finish or other material over a specified period of time. Compare **curing.** 

duplex dwelling—See dwelling.

**dust wipe sample—**a settled dust sample collected on a moistened disposable towel. **E1644** 

**dwelling**, *n*—a **building** designed or occupied as the living quarters for one or more families or households.

apartment—a separate part of a building intended as a dwelling unit for an individual, family, group, or small household (also used as a synonym for apartment building).

detached dwelling—a dwelling unit standing by itself.

*duplex dwelling*—one of a pair of **dwelling units**, generally joined by a common floor/ceiling.

*modular dwelling*—a manufactured **home** consisting completely or in part of **modules**.

*semi-detached dwelling*—one of a group of **dwelling units** joined by a common sidewall and occasionally by a garage, carport, or similar structure.

**dwelling unit**—a unit providing complete independent living facilities for one or more persons, including permanent provisions for living, sleeping, eating, cooking, and sanitation. (See also **house.**)

environmental chamber—See building space.

EPS, *n*—expanded polystyrene. See **rigid cellular polystyrene thermal insulation board.** See also **cellular polystyrene**.

**equivalent design load**—a magnitude of 60-s duration uniform load selected by specifying authority to represent design loads. **E997** 

expansion joint—See joints.

**exterior air-distribution envelope**—the boundary or barrier separating the interior volume of the air distribution system from the outside environment or unconditioned spaces.

#### E1554/E1554M

Discussion—For the purpose of these test methods, the interior volume is the deliberately conditioned space within a building, generally not including the attic space, basement space, and attached structures, unless such spaces are part of the heating and air conditioning system, such as a crawl space that acts as a plenum.

**extraction**—the dissolution of target analytes from a solid matrix into a liquid form. During sample digestion, target analytes are extracted (solubilized) into an acid solution.

E1644

**fabricate**, *v*—to manufacture, form, construct, or assemble a product or **component**.

**facility,** *n*—a physical setting used to serve a specific purpose.

Discussion—A facility may be within a building, or a whole building, or a building with its site and surrounding environment; or it may be a construction that is not a building. The term encompasses both the physical object and its use.

facility durability, n—the capability of a **facility** to maintain serviceability for a specified time.

Discussion—It may be important that regular maintenance be provided as appropriate, to assist in attaining the desired durability.

facility evaluation, n—comparison of the qualitative and quantitative results of observations, measurements, analyses, or other tests against criteria established for a specified purpose and to a specified precision and reliability.

facility function, n—the purpose or activity for which the facility is designed, used, or required to be used.

facility management—practice of planning and managing workplaces.

Discussion—Included are financial forecasting and budgeting; strategic and tactical (short term) facility planning; real estate acquisition or disposal, or both: architectural and engineering planning and design; new construction or renovation work, or both; interior space planning; workplace specifications, installation, and space management; telecommunications integration; security; maintenance and operations management of the physical plant.

facility performance, n—the behavior in service of a **facility** for a specified use.

DISCUSSION—The scope of this performance is of the facility as a system including its subsystems, components, and materials and their interactions such as acoustical, hydrothermal, air purity, and economic and the relative importance of each performance requirement.

facility project brief (statement of work)—document describing services to be provided by the design consultant (architect, engineer, or interior designer) for a **facility**, in detail sufficient for the design to proceed.

Discussion—In included is general project information specifically related to the project, such as functional, technical, and design requirements; time plan; cost plan; and technical design data.

facility serviceability, n—the capability of a **facility** to perform the function(s) for which it is designed, used, or required to be used.

*facility use*, *n*—the functions and activities that take place in a **facility**.

**facility serviceability profile,** *n*—a graphic representation, usually as a bar chart, of the level of serviceability for each topic of serviceability. **E1679** 

fan airflow rate,  $Q_{fan}$ , n—the volume of airflow through the blower door per unit of time (m<sup>3</sup>/s, ft<sup>3</sup>/min). E1827

feature, n—of a facility, a physical element of a building, building component, building subsystem, unit of furnishing or equipment, or of a location, or of an aspect of design, arrangement, form or color, which helps or hinders the satisfaction of a requirement for serviceability.

E1334

Discussion—A feature may be a physical feature or design feature, or both. For example, a particular sound absorbency in a ceiling may be adequate in a carpeted space but may be inadequate in a space with a hard floor covering.

**feature,** *n*—of a facility, a building element, building component, building subsystem, unit of furnishing or equipment, or aspects of design, arrangement, form of color, which helps or hinders the satisfaction of a requirement for serviceability. **E1334** 

Discussion—A feature may be a physical feature or design feature, or both. It may only have effect on meeting a requirement when some other feature is also present; for example, a wall with a specified sound transmission coefficient may only have effect on meeting a requirement when sound above a specified level is produced in an adjacent space.

combination of features, n—of a facility, features which, when present together in a facility, affect satisfying a requirement for serviceability.

E1334

**field blank**—a wipe that is exposed to the same handling as field samples except that no sample is collected (no surface is actually wiped). Analysis results from field blanks provide information on the analyte background level in the wipe combined with the potential contamination experienced by samples collected within the batch resulting from handling.

E1728

field blank—a sample that is handled in exactly the same way that field samples are handled, except that no air is drawn through it.E1553

**field check**—(1) a survey of existing conditions at a construction site (also called *field observation*). (2) verification of an existing structure and its dimensions compared with those shown on drawings (also called *field measure*).

field joint—See joints.

field measure—See field check.

**fieldstone**, *n*—natural building stone as found in the field.

**filter holder**—a plastic holder that supports the filter medium upon which airborne particulate matter is collected. **E1553** 

**finish,** n—(1) the final treatment or **coating** of a surface, (2) the fine or decorative work required to make a **building** or its parts complete.

finished grade—See grade.

**fire resistance**—as applied to buildings, the property of a material or assembly to withstand fire or to give protection from it, characterized by the ability to confine a fire or to continue to perform a structural function, or both.

first floor—See floor.

first story—See building space.

fixed—See windows and doors.

**flat,** *n*—a rectangular metal bar of width greater than thickness.

**floor,** *n*—*in a building,* a supporting structure (generally horizontal) and constituting the bottom level of each **story.** 

first floor—in a building, (1) (in the United States) the floor of a building that is at, or closest to, finished grade (also used as a synonym for ground floor). (2) (except in the United States) the floor of a building that is next above the floor at, or closest to, finished grade.

*flooring*, *n*—a material used to construct the uppermost layer of a **floor.** 

*sub-floor*, *n*—a part of a **floor** over which one or more components may be added to complete the **floor**.

sub-flooring, n—the material used in constructing a sub-floor.

*underlayment*, *n*—*in flooring*, a layer of material usually placed upon the **sub-floor** that provides a smooth, even base for **flooring**.

# flooring:

gross floor area—the entire area within the inside perimeter of the exterior walls.

 $\label{lem:decomposition} D_{\text{ISCUSSION}}\!\!-\!\!Only\ courts\ and\ shafts\ not\ under\ roof\ are\ excluded.$ 

*net floor area*—that part of the **gross floor area** located within **occupiable space.** 

Discussion—Accessory areas and thicknesses of walls are excluded.

frame—See windows and doors.

frost point—the temperature at which visible frost begins to deposit on the lower air space glass surface of a sealed insulating glass unit in contact with the measuring surface of the frost point apparatus.

E546

frost state—the case where the frost point of a sealed insulating glass unit is above the test temperature specified by the purchaser or user.

E546

gage (also *gauge*), n—(1) in metal products, a number designating a specific thickness of metal sheet, or diameter of wire, cable, or fastener shank tabulated in a standardized series, each of which represents a decimal fraction of an inch (or millimetre). (2) distance in inches (or millimetres) between adjacent lines of holes or fasteners.

galvanic corrosion—the corrosion of metallic objects in the presence of moisture, caused by electrolytic action. E1925

**glass specimen**—the glass to be tested, for example, a single pane, an insulating glass unit, laminated glass, etc. (does not include test frame). **E997** 

**glass specimen failure**—the fracture or cracking of any glass component of a glass specimen.

E997

glaze—See windows and doors.

glazing—See windows and doors.

glazing bead—See windows and doors.

glazing material—See windows and doors.

**glazing**, *n*—material instilled in a window sash, ventilator, or panel such as glass, plastic.

**grade,** *n*—a level or elevation of a land or water surface.

average grade—the arithmetic mean of the elevations of various ground surfaces within a stated area of **building** construction.

*finished grade*—the surface elevation of lawns, walks, drives, or other improved surfaces after completion of construction or grading operations.

*natural grade*—the elevation of the original or undisturbed surface of the ground.

*sub-grade*—the ground elevation established to receive an additional surfacing.

ground floor—See floor. (Synonym for first floor, first story.)

**guideline**, *n*—a written statement or outline of policy, practice, or conduct.

Discussion—Guidelines may propose options to enable a user to satisfy provisions of a **code**, standard, **regulation**, or **recommendation**.

**gusset,** *n*—a plate used to connect two or more members or to reinforce a joint.

habitable space—See building space.

half bath—See building space.

hard-coat system—type of finish system designed to withstand increased impact loads by increasing the strength of the base coat. Also called high-impact system.

Discussion—in EIF systems, the term generally is associated with PM systems.

head—See windows and doors.

**height,** *n*—*of a building,* the vertical distance measured from the **finished grade** to average level of the roof above the level of the highest **wall.** 

**home,** *n*—a place of residence. (See also **dwelling.**)

horizontal sliding window—See windows and doors.

house—See building.

download from https://elitesafetyglass.com

hung window—See windows and doors.

**identification limit,** *n*—for a qualitative chemical spot test kit, this is the lead content that yields a 50 % chance of either a positive or negative test result for a given sample matrix (1).

E1828

improve—See building modification.

industrialized building—See building.

industrialized building system—See building system.

initial calibration blank (ICB)—a standard solution that contains no analyte and is used for the initial calibration and zeroing instrument response.

E1613

DISCUSSION—The ICB must be matrix matched to the acid content present in sample digestates. The ICB must be measured during and after calibration. The measured value is to be less than five times the instrumental detection limit.

initial calibration verification (ICV)—a standard solution (or set of solutions) used to verify calibration standard levels; the concentration of analyte is to be near mid-range of the linear curve that is made from a stock solution having a different manufacturer or manufacturer lot identification than the calibration standards.

DISCUSSION—The ICV must be matrix matched to the acid content present in sample digestates. The ICV must be measured after calibration and before measuring any sample digestates. The measured value is to fall within  $\pm 10~\%$  of the known value.

instrumental detection limit (IDL)—an instrumental measurement value that is used to provide a lower concentration limit for reporting quantitative analysis data for a given instrument.

Discussion—Any sample that generates a lead measurement below the IDL is reported as a less-than value using the IDL value multiplied by the appropriate dilution factors caused by preparing the sample for instrumental analysis. Typical IDLs for FAAS, ICP-AES, and GFAAS are 0.05, 0.03, and 0.002 µg/mL, respectively. However, the IDL for a given instrument must be established prior to reporting analysis data. There are a number of acceptable methods for determining the IDL for a given instrument. One method is to perform repetitive measurements of a single concentration of low-level lead standard (typically between two and five times the estimated IDL) scattered throughout an analysis run. A minimum of five repetitions is generally required to calculate the IDL. Using this method, the IDL is calculated as three times the standard deviation of the lead values (µg/mL) measured for the replicate analyses.

instrumental QC standards—these provide information on measurement performance during the instrumental analysis portion of the overall lead measurement process. They include CCBs, CCVs, ICBs, ICVs, and ICSs.
E1613

interference check standard (ICS)—a standard solution (or set of solutions) used for ICP-AES to verify an accurate analyte response in the presence of possible spectral interferences from other analytes present in samples; the concentration of analyte is to be less than 25 % of the highest calibration standard, and concentrations of the interferant will be 200 μg/mL of aluminum, calcium, iron, and magnesium.

DISCUSSION—The ICS must be matrix matched to the acid content present in sample digestates. The ICS must be analyzed at least twice,

once before and once after all sample digestates. The measured analyte value is expected to be within  $\pm 20$  % of the known value. **E1613** 

interlock—See windows and doors.

interior pipe size (IPS)—See iron pipe size.

**iron pipe size, IPS,** *n*—the nominal inside dimension of **pipe** in inches (or millimetres). (Also called *interior pipe size, standard pipe size.*)

jamb—See windows and doors.

**joint**, *n*—general term. See particular joint of interest. Compare **connection**.

butt joint—a joint having the edge or end of one member matching the edge, end, or face of another member without overlap.

Discussion—An edge-to-face butt joint may also be called a tee joint or an ell joint.

*cold joint*, *n*—boundary between later-applied and previously-applied coatings, plaster, mortar, or concrete.

Discussion—At the boundary there can be less than the desired union of materials

construction joint—in the construction of members intended to be continuous, a predetermined, intentionally created discontinuity between or within constructions and having the ends of the discontinuous members fastened to each other to provide structural continuity.

control joint—in concrete, concrete masonry, stucco, or coating systems; a formed, sawed, or assembled joint acting to regulate the location of cracking, separation, and distress resulting from dimensional or positional change.

*expansion joint*—a discontinuity between two constructed elements, or **components**, allowing for differential movement (such as expansion) between them without damage.

field joint—a connection between adjoining members or parts, made at the time of installation. Compare construction joint.

*slip joint*—a joint allowing axial sliding movement of joined parts.

kitchen—See building space.

**knowledgeable person,** *n*—an individual who has technical knowledge concerning the building or facility, for example, about occupant requirements, building design, mechanical systems, operation, and maintenance. **E1679** 

DISCUSSION—In larger facilities, the senior person who is at a facility full time to manage its operation is unlikely to be an appropriate person to facilitate the setting of required levels of serviceability by the occupant because of that role, but he may be well qualified and appropriate to participate as a knowledgeable person in the process of rating that facility.

**level,** *n*—*of serviceability,* a number indicating the relative serviceability of a building for one topic on a predetermined range, for example, a range from 1 to 9. **E1679** 

light—See windows and doors.

**lite,** *n*—one piece of glazing (preferred term); (also spelled light) (*synonym*—pane).

lite—See windows and doors.

load—See static load.

low-sloped surfaces—surfaces with a slope smaller than 9.5°. The roofing industry has widely accepted a slope of 2:12 or less as a definition of low-sloped roofs. This corresponds to a slop of approximately 9.5° (16.7%).

maintain—See building modification.

manufactured building—See building.

manufactured home—See building.

**masonry**, *n*—construction, usually set in mortar, of natural building stone or manufactured units such as brick, concrete block, adobe, glass block, tile, manufactured stone, or gypsum block.

maximum principal tensile stress (MPTS)—a maximum calculated tensile stress based on strain gage measurements.

E99

**mechanical connection**—a joining of two or more elements by means of mechanical fasteners, such as screws, bolts, or rivets but not by welding or adhesive bonding.

meeting rail—See windows and doors.

MEPS—See rigid cellular polystyrene thermal insulation board.

**mesh-lapping**—process of overlapping one piece of mesh onto another that has been applied to a surface previously.

method blank—a digestate that reflects the maximum treatment given any one sample within a sample batch except that only the sampling medium (such as a blank wipe) is initially placed into the digestion vessel. (The same reagents and processing conditions that are applied to field samples within a batch are also applied to the method blanks.) Analysis results from method blanks provide information on the level of potential contamination resulting from the laboratory and sampling medium sources that are experienced by samples processed within the batch.

method blank—a sample, devoid of analyte, that is analyzed to determine its contribution to the total blank (background) reading.E1645

*mobile home*—Obsolete term. Use **manufactured home.** (See **building.**)

**mockup**, *n*—a section or a structure or assembly, built full-size or to scale, for the purpose of studying construction details, testing performance, judging appearance, or any combination thereof.

modernize—See building modification.

model code—See code.

modular dwelling—See dwelling unit.

**module,** *n*—a unit of structure based on a standard pattern of standard dimensions. (See also **modular dwelling.**)

core module—a module containing electrical, plumbing, heating, and related subsystems.

mull—See windows and doors.

mullion—See windows and doors.

muntin—See windows and doors.

natural grade—See grade.

**negative load**—a load that results in the indoor side of a glass specimen being the high-pressure side. **E997** 

**negative test**—the absence of the characteristics color change within a specified time limit, usually within a few minutes.

E1753

no-frost state—the case where the frost point of a sealed insulating glass unit is below the temperature specified by the purchaser or user.

E546

**nominal airflow rate,**  $Q_{nom}$ , n—the flow rate indicated by the blower door using the manufacturer's calibration coefficients (m<sup>3</sup>/s, ft<sup>3</sup>/min).

nonbearing wall—See wall.

**non-spiked sample**—a sample, devoid of analyte, that is targeted for addition of analyte but is not fortified with all target analytes prior to sample preparation.

Discussion—Analysis results for this sample are used to correct for background levels in the blank medium that is used for spiked and spiked duplicate samples.

E1645

non-spiked sample—a portion of a homogenized sample that is targeted for addition of analyte but that is not fortified (spiked) with all the lead before sample preparation. Analysis results for this sample are used to correct for background levels in soil that are used for the spiked and spiked duplicate samples.

non-spiked sample—a blank wipe sample that was targeted for addition of analyte but was not fortified with all the target analysis before sample preparation.E1644

Discussion—For wipe samples, a non-spiked sample is equivalent to a method blank. Analysis results for this sample are used to correct for background levels in the blank wipes used for spiked and spiked duplicate samples.

numerical value of a quantity—magnitude of a quantity expressed by the product of a number and the unit in which the quantity is measured.E621

"O"—See windows and doors.

occupant, *n*—of a facility, a group, department, agency or corporation, or other organization, or a part thereof, or an individual or individuals thereof, that is or will be occupying space in a particular facility.

E1334

Discussion—Persons who are authorized to be present only temporarily, or in special circumstances as those permitted to pass through during an emergency, are visitors.

occupiable space—See building space.

office—See building space.

office, n—a place, such as an open workspace, room, suite, or building, in which business, clerical, or professional activities are conducted.

E1334

**opaque wall**—all exposed areas of a wall that enclose conditioned space, except openings for windows, doors and building service systems.

open construction—See building constructions.

open-plan workstation—See building space.

open system—See building system.

operable—See windows and doors.

**ordinance,** *n*—a rule or law adopted by local governmental authority.

orifice blower door, n—a blower door in which airflow rate is determined by means of the pressure drop across an orifice or nozzle.

E1827

packaged building—See building.

paint chip sample—a fragment of a dry paint film removed from the substrate.
E1753

paint collection container—a sealable rigid walled container.

Discussion—Use of a resealable plastic bag for holding and transporting dried paint samples is not recommended due to the potential losses of paint chips within the plastic bag during laboratory handling. Quantitative removal and processing of the dried paint samples by the laboratory is significantly improved through the use of sealable rigid walled containers.

paint collection tray—any clean, dry, lead-free container for use in catching paint scrapings.E1729

Discussion—This practice describes the use of letter-size white paper for making a funnel type collection tray. However, other types of collection trays can be utilized.

painted element—a painted architectural or building component.
E1796

pane—See windows and doors.

**panel,** *n*—in a building, (1) a portion of a surface flush with or recessed from, or sunk below the surrounding area, sometimes set off by distinct molding or other decorative measure. (2) a usually flat and rectangular piece of construction material made to form part of a surface (as of a **wall**, ceiling, or **floor**). (See also **windows and doors.**)

panelized construction—See building constructions.

passive solar energy system—See building subsystem.

performance curve, n—for a qualitative chemical spot test kit, this is a plot of the test kit response (positive or negative) versus the lead content in a given sample matrix as determined by quantitative analysis (2).

Discussion—The performance curve may be statistically modeled to yield qualitative test kit performance parameters for lead detection.

performance parameter—for a particular spot test kit and a particular sample matrix, this is the lead content that yields a known degree of confidence in detecting lead. E1828

DISCUSSION—Examples of qualitative test kit performance parameters include the identification limit and the amounts of lead in a given sample matrix yield a desired confidence (for example, 95 %) of a negative and positive test result, respectively.

**performance standard,** *n*—in building constructions, a standard that defines the required **performance** of a building material, element, **subsystem,** or **system.** 

**perm,** *n*—empirical unit of **water-vapor permeance** (mass flow rate), equal to one grain (avoirdupois) of water vapor per hour flowing through one square foot of a material or construction induced by a vapor-pressure difference of one inch of mercury between the two surfaces.

Discussion—This mass flow rate can be stated in other desired or convenient units. (For SI conversion, see Test Methods E96/E96M). A maximum value of one perm is the moisture vapor migration rate below which there is low probability of induced moisture problems in conventional buildings in climates not exceeding 5000 heating degree days (65°F base), and not so hot and humid that continual air conditioning would be required.

permanent set—See residual deflection.

**permanent set of test frame**—a load-induced permanent displacement from an original position of the test frame.

E998

personal air samples—air samples that are collected within the personal breathing zone (PBZ) of a person. E1553

personal breathing zone (PBZ)—an area within approximately 6 in. of a person's face.

E1553

**pick,** *n*—an individual filling yarn.

**pipe,** *n*—a tubular conduit for transport of fluids or finely divided solids; also, a hollow structural member or safety barrier; a hollow product of round cross section.

Discussion—If of metal, its size usually is designated by its nominal inside diameter and schedule which indicates the wall thickness; or by its nominal inside diameter and its exact wall thickness. Compare piping, tube.

**piping**, *n*—a system of **pipes**.

**pitch,** *n*—an inclination or slope measured in degrees, or percent, or by the ratio of rise and run.

**plate,** *n*—a flat, rolled sheet having a width and length much greater than thickness. (If of steel, having dimensions of 0.180 in. (4.6 mm) or greater in thickness, and greater than 8.0 in. (203 mm) in width.)

DISCUSSION—Similar distinctions are made for sheet and plate in other metals. Other specific values apply to nonmetallic products.

**pocket**, *n*—an opening in a structure to accept a construction member.

**positive load**—a load that results in the outdoor side of a glass specimen being the high-pressure side.

E997

**positive test**—the observation of the characteristic color change within a specified time limit, usually within 10 to 30 s.

**precision index of the average,** *n*—the sample standard deviation divided by the square root of the number of samples.

E1827

precut building—See building.

prefabricated building—See building.

prefabricated panel system—See building system.

**preservation,** *n*—the act or process of applying measures to sustain the existing form, integrity, or materials of a **building,** structure, or **artifact** and the existing form or vegetative cover of a cite.

conservation, n—management of a natural resource, structure, or **artifact** to prevent misuse, destruction, or neglect. It may include detailed characterization and recording (technical or inventory) or provenance and history and application of measures.

protection, n—the act or proces of applying measures designed to afect the physical condition of a **building**, structure, or **artifact** by guarding it from deterioration, loss, or attack; or, to cover or shield it from damage.

rehabilitation, n—of a structure, the act or process of returning a sructure to a state of utility through **repair** or **alteration** which makes possible an efficient contemporary use.

Discussion—As applied to historic structures, it may include the preservation of those portions or features of the structure that are significant to its historical, architectural, and cultural values.

restoration, n—the act or process of reestablishing accurately the form and details of a structure, site, or **artifact** as it appeared at a particular period of time, by means of removal of later work or by the **reconstruction** of missing earlier work.

**pressure station,** n—a specified induced change in the building pressure difference from the initial zero-flow building pressure difference (Pa, in.  $H_2O$ ).

primary circulation area—See building space.

**probabilistic design**—design that accounts for the uncertainties due to statistical variabilities in physical and mechanical properties of the materials, elements, or structures, and in the applied loads (compare **deterministic design**).

Discussion—In probabilistic design, the variable characteristics of each component are considered; and design loads and conditions may be based on specific probabilities of occurrence.

probability of failure—the probability that a glass specimen will fail when tested at a given load. General industry practice is to express the probability of failure as lights per 1000 lights.

project record—use as-built, the preferred term.

protection—See preservation.

proof load—a magnitude of uniform load at which glass specimens shall be tested.E997

**proof load factor,** *a*—the constant which, when multiplied by the equivalent design load, determines the proof load. **E997** 

pyranometer—an instrument (radiometer) used to measure the total solar radiant energy incident upon a surface per unit time and unit surface area.

E1918

quantitative analysis—an analysis run on sample digestates (or serial dilutions of sample digestates) that includes instrumental QC standards. Data from this run are used to calculate and report final lead analysis results.

E1613

**quantity**—measurable attribute of a physical phenomenon. There are base units for seven quantities and supplementary units for two quantities upon which units for *all* other quantities are founded. **E621** 

racking—when applied to shear walls, refers to the tendency for a wall frame to distort from rectangular to rhomboid under the action of an in-plane force applied parallel to the wall length.

E564

rail—See windows and doors.

**random sampling**—in statistical sampling, the process of selecting sample units in such a way that all units under consideration have the same probability of being selected.

rater, *n*—a person having primary responsibility for organizing and conducting the rating process for a building or building-related facility.

E1334

rating scale, n—for a topic of facility serviceability, a set of descriptions of combinations of features, in which each description has been selected to indicate a specific level of serviceability on a scale from the lowest to the highest level likely to be encountered.

E1679

**RCRA**—Resource Conservation and Recovery Act of 1976.

reagent blank—a digestate that reflects the maximum treatment given any one sample within a sample batch except that it has no sample initially placed into the digestion vessel. (The same reagents and processing conditons that are applied to field samples within a batch are also applied to the reagent blank.)

E1644

DISCUSSION—Analysis results from reagent blanks provide information on the level of potential contamination resulting from only laboratory sources that are experienced by samples processed within the batch

rebuild—See building modification.

**recommendation,** *n*—*in building constructions*, a written suggestion for policy, practice, conduct, design, or material, implying endorsement but not requiring compliance (see **guideline**).

reconstruct—See building modification.

reconstruction—See building modification.

reference material (standard reference material) (SRM)—a material of known composition where the lead level is certified by the manufacturer.

E1645

**reflectance**—a measurement technique (subset of spectrophotometry; see 3.5) in which light is reflected off of a reflecting

surface and measured by a detector. The amount of reflected light may be a function of analyte concentration.

**regulation,** *n*—a rule prescribing a set of conditions and requirements that have been made mandatory for those under its control, by an executive (administrative) authority.

rehabilitation—See preservation.

remodel—See building modification.

repair—See building modification.

requirement scale, n—for a topic of facility serviceability, a set of descriptions of requirements for serviceability in which each description has been selected to indicate a specific level of serviceability on a scale from the lowest to the highest level likely to be encountered.

E1679

**residual deflection**—permanent deformation of a building element, component, or structure after complete or partial removal of applied force. Also called **permanent set** or **residual deformation.** 

residual deformation—See residual deflection.

**residual stress**—an initial, state of stress on unloaded, unglazed glass resulting from manufacturing process (heatstrenthening, tempering). **E998** 

restoration—See preservation.

retaining wall—See wall.

**re-temper,** *v*—to add more water to a hydraulic-setting compound after the initial mixing, but before partial set has occurred.

retrofit—See building modification.

**rhodizonate spot test method**—for lead detection, the use of a dilute solution of rhodizonate ion to test a painted surface or paint chip for the qualitative presence of lead (1).<sup>3</sup> A color change from yellow/orange to pink or red indicates the presence of lead above the level of detection of the test kit.

rigid cellular polystyrene thermal insulation (RCPS)—rigid thermal insulation board formed by expansion of polystyrene resin beads or granules in a closed mold (EPS), or by the expansion of polystyrene resin in an extrusion process

DISCUSSION—Ad hoc abbreviations such as *MEPS* and *XEPS* are deprecated. The term *beadboard*, should not be used for commercial EPS

**rising damp,** *n*—upward-moving moisture in a **wall** or other structure standing in water or in wet soil. (Compare: **capillary migration,** wicking).

**roofing system**—assembly of interacting components designed to weatherproof, and sometimes to insulate, the roof surface of a building.

**round,** *n*—a solid member, circular in cross section.

sample set—a group of samples (one or more). E1645

sampling device—a filter holder and air sampling pump assembly used to collect airborne particulate lead on a filter.
 The filter holder houses a cellulose ester membrane filter, through which air is drawn by using an air sampling pump; the filter holder is connected to the pump by tubing. E1553

**sampling location**—a specific area within a sampling site that is subjected to sample collection. Multiple sampling locations are commonly designated for a single sampling site.

E1728

sampling site—a local geographical area that contains the sampling locations. A sampling site is generally limited to an area that is easily covered by walking.

sash—See windows and doors.

sealed insulating glass—See windows and doors.

sealed insulating glass unit—a preassembled unit, comprising sealed panes of glass separated by dehydrated space(s), intended for vision areas of buildings. The unit is normally used for windows, window walls, picture windows, sliding doors, patio doors, or other types of windows or doors. E774

secondary circulation area—See building space.

semi-detached dwelling—See dwelling.

semiquantitative screen—an analysis run that is performed on highly diluted sample digestates for tghe purpose of determining the approximate analyte level in the digest. This analysis run is generally performed without inserting instrumental QC standards except for calibration standards. Data from this run are used for determining serial dilution requirements for sample digestates to keep them within the linear range of the instrument.

E1613

**setting,** *n*—process by which, after application, a liquid (wetstate) material changes to a serviceable condition by **curing** or **drying.** 

Discussion—Generally, **curing** implies a chemical reaction, while **drying** implies evaporation of volatile constituents.

serial dilution—a method of producing a less-concentrated solution through one or more consecutive dilution steps. A dilution step for a standard or sample is performed by volumetrically placing a small aliquot of higher concentrated solution into a volumetric flask and diluting to volume with water containing the same acid levels as those found in original sample digestates.

E1613

serviceability—see facility serviceability. E167

**sheet,** *n*—a thin, flat, rolled metal product having mill or cut edges. (If of steel, having dimensions of less than 0.229 in. (5.8 mm) thickness, and greater than 12.0 in. (305 mm) width and length.)

DISCUSSION—Similar distinctions are made for sheet and plate in other metals. Other specific values apply to nonmetallic products.

shear wall—structural subassembly that acts as a cantilever/ diaphragm to transfer horizontal building loads to the foundation in the form of horizontal shear and an overturning moment.
E564 shop drawing—a drawing prepared by the fabricator based on a working drawing and used in a shop or on a site for assembly.

SI—The International System of Units (abbreviation for "le Système International d'Unités) as defined by the General Conference on Weights and Measures (CGPM)—based upon seven base units, two supplementary units, and derived units, which together form a coherent system.

E621

sill—See windows and doors.

single zone, *n*—a space in which the pressure differences between any two places, as indicated on a manometer, differ by no more than 2.5 Pa (0.01 in. H<sub>2</sub>O) during fan pressurization at a building pressure difference of 50 Pa (0.2 in. H<sub>2</sub>O) and by no more than 5 % of the highest building pressure difference achieved.

**sleeve,** *n*—(1) in concrete, masonry, or other construction, a tubular section of sheet metal or other material placed to provide a pocket or opening for the insertion of a railing or other member. (2) an internal or external tubular splice between abutting sections of **pipe, tubing,** or similar members.

sliding glass door—See windows and doors.

slip joint—See joint.

slope, n—See pitch.

soil collection container—a container for holding and transporting the soil sample from the field to the laboratory. A sealable rigid walled container or a resealable plastic bag can be used. The internal volume must be sufficient to hold the entire collected sample.

solar energy—the radiant energy originating from the sun. Approximately 99 % of solar energy lies between wavelengths of 0.3 to 3.5 μm.

solar energy system—See building subsystem.

solar flux—for these measurements, the direct and diffuse radiation from the sun received at ground level over the solar spectrum, expressed in watts per square metre.

solar reflectance—the fraction of solar flux reflected by a surface.
E1918

special tools—tools other than common hand tools or those designed specifically for use with a delivered product.
E1925

**specification,** *n*—precise statement of a set of requirements to be satisfied by a material, product, system, or service.

Discussion—It is desirable that the requirements, together with their limits, should be expressed numerically in appropriate units. **E1480 E631** 

specifying authority—professional(s) responsible for determining and furnishing information required to perform the test.
E997

**specimen thermal conductance,** C<sub>s</sub>—the time rate of heat flow through a unit area of a specimen (window or door), induced by a unit temperature difference between the specimen surfaces. It is calculated as follows:

$$C_{s} = 1/(1/U_{s} - 1/h_{I} - 1/h_{II}) \tag{1}$$

where:

 $C_s$  = thermal conductance of specimen (surface to surface), W/(m<sup>2</sup> · K) [Btu/(ft<sup>2</sup> · h · °F)],

 $U_s$  = thermal transmittance of specimen (air to air under test conditions), W/(m<sup>2</sup> · K) [Btu/ft<sup>2</sup> · h · °F],

 $h_1$  = surface conductance, room side, W/(m<sup>2</sup> · K) [Btu/(ft<sup>2</sup> · h · °F)], and

 $h_{\rm II}$  = surface conductance, weather side, W/(m<sup>2</sup> · K) [Btu/(ft<sup>2</sup> · h · °F)].

Discussion—The test specimen thermal conductance is an approximate value calculated from the measured thermal transmission,  $U_s$ , and the calculated room-side,  $h_{\rm II}$ , and weather-side,  $h_{\rm II}$ , surface conductances. When testing inhomogeneous test specimens, the test specimen surface temperatures and surface conductances will not be exactly the same as those obtained using the calibration transfer standard. Consequently, the surface conductances obtained using the calibration transfer standard cannot be defined unambiguously; hence the test specimen conductance cannot be defined and measured. For inhomogeneous test specimens, only the termal transmittance,  $U_s$ , can be defined and measured. It is therefore essential to test with surface conductances as close as possible to the conventionally accepted values for building design. Likewise, it would be desirable to have a surround panel that closely duplicates the actual wall where the fenestration system would be installed. However, this is not feasible due to the wide variety of fenestration opening designs and constructions. Furthermore, for high-resistance fenestration systems installed in fenestration opening designs and constructions with thermal bridges, the large relative amount of heat transfer through the thermal bridge will cause the relatively small amount of heat transfer through the fenestration system to have an error which is greater than desirable. As a result, the calculation of a specimen thermal conductance or resistance (surface to surface) from a measured thermal transmittance and the calculated surface conductances is not part of the basic measurement procedure. The purpose of this procedure is to arrive at a  $U_{\rm ST}$  value that includes standard film coefficients combined with the specimen thermal conductase,  $C_s$ . In this manner, it becomes easier to compare the thermal transmission of various fenestration systems. E1423

**specimen thermal resistance, R**<sub>c</sub>—the mean temperature difference, at equilibrium, between two defined surfaces of a material or construction that induces a unit heat flow rate through unit area. It is calculated as follows:

$$R_{c} = 1/U_{s} - 1/h_{I} - 1/h_{II} \tag{2}$$

where:

 $R_{\rm c}$  = surface to surface thermal resistance of specimen, m<sup>2</sup> · K/W (ft<sup>2</sup> · h · °F/Btu).

E1423

specimen thermal transmittance,  $U_s$  (sometimes called overall coefficient of heat transfer)—the heat transmission in unit time through unit area of a specimen and its boundary air films, induced by unit temperature difference between the environments on each side. It is calculated as follows when

$$t_{\rm h2} = t_{\rm II} (\pm 0.5^{\circ} C) \text{ and } t_{\rm h1} = t_{\rm I} (\pm 0.5^{\circ} C)$$
 (3)

where:

 $t_{\rm b1}$  = baffle surface temperature, room side, K or °C (°F),

 $t_{b2}$  = baffle surface temperature, weather side, K or °C (°F),

 $t_{\rm I}$  = temperature of room side air, °C (°F), and

 $t_{\rm II}$  = temperature of weather side air, °C (°F).

$$U_{\rm s} = Q_{\rm s}/A_{\rm s} \cdot (t_{\rm I} - t_{\rm II}) \tag{4}$$

where:

 $A_s$  = projected area of specimen (same as open area in surround panel), m<sup>2</sup> (ft<sup>2</sup>), and

 $Q_s$  = time rate of heat flow through the specimen, W (Btu/h).

The transmittance of the specimen can be calculated from the thermal conductance and the surface conductances as follows:

$$1/U_{s} = 1/h_{I} + 1/C_{s} + 1/h_{II}$$
 (5)

where the values of  $h_{\rm I}$  and  $h_{\rm II}$  are calculated using the appropriate equations in 3.1.4.

spectrophotometry—an analytical technique in which a spectrum of analyte species is obtained and used to determine the analyte concentration in the following manner. Light is directed onto or through analyte species, and the absorption of this light across a range of wavelengths is measured by a detector. The amount of absorbed light is a function of the concentration of analyte species.

spiked sample and spiked duplicate sample—a sample portion (split from an original sample) that is spiked with a known amount of analyte. Two portions of a homogenized sample that were targeted for addition of analyte and are fortified with all the target analytes before preparation. Analysis results for these samples are used to provide information on the precision and bias of the overall analysis process.

**spiked sample and spiked duplicate sample—**a spiked sample (or spiked duplicate sample) is a blank wipe that is spiked with a known amount of analyte before preparation.

E1644

Discussion—Analysis results for these samples are used to provide information on accuracy and precision of the overall analysis process.

spiked sample or spiked duplicate sample—a blank medium that contains no purposely added analyte to which a known amount of analyte is added before preparation.

E1645

Discussion—Analysis results for these samples are used to provide information on the precision and accuracy of the overall process.

spiked sample and spiked duplicate sample—each is a portion of a single homogenized sample to which the same known amount of analyte is added (spiked) before sample digestion. Analysis results for these samples are used to provide information on accuracy and precision of the overall analysis process.

**splice plate**—a plate used for fastening and joining members. See also **gusset.** 

split-level house—See building.

**spot test**—the application of reagent solution to a prepared dry paint film sample, paint chip, paint powder, or painted

surface and the subsequent observation for the presence or absence of the characteristic color change. **E1753** 

**square,** *n*—an equal-sided rectangular **bar** or **tube** having sharp or slightly rounded edges.

**stair,** *n*—an uninterrupted series of level steps, or connecting flights of steps, extending between two or more **floors** or landings.

stairway, n—See stair.

standard pipe size—See iron pipe size.

static load—a load or series of loads that are supported by or are applied to a structure so gradually that forces caused by change in momentum of the load and structural elements can be neglected and all parts of the system at any instant are essentially in equilibrium.

**static load,** *n*—an imposed stationary force that is constant in magnitude, direction, and sense.

**stiffener**, *n*—a reinforcing member designed to limit or prevent the deformation of an attaching member.

stile—See windows and doors.

story—See building space.

**strength**, *n*—resistance to external force or load or generation of internal strain, expressed in terms of units of force, lbf, pounds force (N, newtons).

Discussion—Strength is the resistance to tensile, compressive, or shear force, or a combination of these; as compared to stress that is expressed in terms of force per unit area.

ultimate strength, n—maximum resistance to applied force, load, or stress that a material, member, component, or assembly of a structure can withstand without failure.

Discussion—Sometimes referred to as ultimate load, maximum load, or maximum strength. Ultimate strength is expressed in terms of ultimate load resisted, that is, in units of force; as compared to ultimate stress that is expressed in terms of units of force per unit area.

**strip,** *n*—a flat, thin member, much longer than wide, having width greater than thickness (if of steel, having dimensions of 0.229 in. (5.8 mm) or less thickness and 12.0 (305 mm) or less width).

**structural integrity**—for the purpose of this specification, it is the ability of the AR to maintain air leakage performance after exposure to elevated positive and negative pressure (see 5.1.2 for performance).

**structural system**—a combination of load supporting and transmitting construction elements or **components** of an assembly or **building** including connections.

**structural test,** *n*—determination of one or more values for load, stress, and deflection characteristics of a material or assembly.

Discussion—Typical test loads simulate wind load, or seismic load, or gravity load.

sub-floor—See floor.

sub-flooring—See floor.

sub-grade—See grade.

subsurface layers—layers of material that may exist on a base substrate and which are underneath the outermost layer, or surface, on a base substrate.

subsystem—See building subsystem.

sulfide spot test method—for lead detection, the use of a dilute solution of sulfide ion to test a painted surface or paint chip for the qualitative presence of lead (2). A color change from clear to grey or black indicates the presence of lead above the level of detection of the spot test.

E1753

**surface**—the outermost layer of material on a base substrate facing the inspector or occupants.

E1796

**surface conductance, h**—(often called surface or film coefficient)—the time rate of heat flow from a unit area of a surface to its surroundings, induced by a unit temperature difference between the surface and the environment. Subscripts are used to differentiate between room-side (1 or I) and weather-side (2 or II) surface conductances (see Fig. 1). Due to radiation effects, the room-side or weather-side temperatures ( $t_{\rm I}$  and  $t_{\rm II}$ , respectively), or both, can differ from the respective room-side or weather-side baffle temperatures ( $t_{\rm bI}$  and  $t_{\rm bII}$ , respectively). If there is a difference of more than  $\pm 0.5^{\circ}$ C ( $\pm 1.0^{\circ}$ F), either on the room side or the weather side, the radiation effects must be accounted for to maintain accuracy in the calculated surface conductances. The room-side and weather-side surface conductances are calculated as follows:

When

$$t_{\rm I} = t_{\rm b1} \, (\pm 0.5^{\circ} \,{\rm C}),$$
 (6)

$$h_{\rm I} = q_{\rm s} / (t_{\rm I} - t_{\rm I})$$

where:

 $t_1$  = temperature of specimen room-side surface, K or °C (°F), and

 $q_s$  = heat flux through the specimen, W/m<sup>2</sup> [Btu/(h·ft<sup>2</sup>)].

When

$$t_{\mathbf{I}} \neq t_{\mathbf{h}1},\tag{7}$$

$$h_{\rm I} = (q_{\rm r1} + q_{\rm c1})/(t_{\rm I} - t_{\rm I})$$

where:

 $q_{r1}$  = net radiative heat flux to the room side of the specimen, W/m<sup>2</sup> [Btu/(hr · ft<sup>2</sup>)], and

 $q_{c1}$  = convective heat flux to the room side of the specimen, W/m<sup>2</sup> [Btu/(h· ft<sup>2</sup>)].

When

$$t_{\rm II} = t_{\rm b2} \, (\pm 0.5^{\circ} {\rm C}),$$
 (8)

$$h_{\rm II} = q_{\rm s}/(t_2 - t_{\rm II})$$

where:

 $t_2$  = temperature of specimen weather-side surface, K or °C (°F).

When

$$t_{\rm II} \neq t_{\rm h2},\tag{9}$$

$$h_{\rm II} = (q_{r2} + q_{c2})/(t_2 - t_{\rm II})$$

where:

 $q_{\rm r2}$  = net radiative heat flux from the weather side of the specimen, W/m<sup>2</sup> [Btu/(h · ft<sup>2</sup>)], and

 $q_{c2}$  = convective heat flux from the weather side of the specimen, W/m<sup>2</sup> [Btu/(h · ft<sup>2</sup>)].

E1423

**temper,** *v*—in hydraulic-setting compounds, to bring to a usable state by mixing in or adding water.

**template**, n—(1) a pattern used as a guide in fabricating elements. (2) a precise, detailed pattern or layout to provide essential fabrication details.

**test kit**—equipment (for example, a cutting tool, adsorbent applicators, if necessary) and chemicals (for example, sulfide or rhodizonate spot test reagents and any extraction solutions needed) assembled for use during spot testing for lead.

E1753

test pressure difference—the actual pressure difference across the building envelope, expressed in pascals (inches of water or pounds-force per square foot or inches of mercury). **E779** 

**tolerance**, *n*—the allowable deviation from a value or standard; especially the total range of variation permitted in maintenance a specified dimension in machining, fabricating, or constructing a member or assembly.

top story—See building space.

**topic,** *n*—*of serviceability*, a part of the serviceability of a facility for which a paried set of requirements and rating scales can be prepared.

E1679

Discussion—At any level of serviceability, a topic can be expressed in two ways: a statement of a requirement in the normal language of occupants or owners; and a statement in technical performance language describing the combination of features that meet that requirement. Each statement is a translation of the other. Taken together, several related topics typically comprise one aspect of serviceability.

**truss**—a coplanar system of structural elements joined together at their ends usually to construct a series of triangles that form a stable beam-like framework.

E73

**tube,** *n*—a tubular conduit for transport of fluids or finely divided solids; also, a hollow structural member; a hollow product of round or other cross section.

Discussion—A tube is designated by (1) its exact outside diameter, and (2) its exact wall thickness which may be described in gage numbers or other units. An exception exists for copper tubes as used in the plumbing industry which are designated by the nominal size, which for 2-in. diameter or less approximates the inside diameter; while the exact outside diameter is 0.125 in. (3.2 mm) larger than the nominal size. Compare **tubing**, **pipe**.

**tubing,** *n*—a system of **tubes**.

μg—microgram.

ULPA filter—ultra-low-penetration air filter.

ultimate strength—See strength.

unconditioned space—any space that is not intentionally heated or cooled for human occupancy, including attics, crawlspaces, unfinished basements, attached structures (such as a garage), or any space completely outside the building envelope (for example, rooftop ductwork on small commercial buildings).

E1554/E1554M

underlayment—See floor.

unit—reference value of a given quantity as defined by CGPM Resolution or ISO Standards. There is *only one* unit for each quantity in SI.
E621

**unit**—the smallest single portion of material received in any one lot (for example, a single roll of material).

uplift—the vertical displacement measured at the loaded end stud with respect to the test apparatus.E564

utility core—Use core module.

**vapor retarder**—a material or system that adequately impedes the transmission of water vapor under specified conditions.

Discussion—For practical purposes it is assumed that the permeance of a vapor retarder will not exceed one perm in inch-pound units (57.4  $ng/(s \cdot m^2 \cdot Pa)$ ), although at present this value may only be appropriate for residential construction. For certain other types of construction the permeance must be lower.

vent hole—an opening for the escape of gases of relief of pressure, often required in fabricated, immersion-coated, or hot-dip galvanized steel members. Compare drainage hole, weephole.

ventilator—See windows and doors.

**wall,** *n*—a part of a **building** that divides spaces vertically.

bearing wall—a wall supporting a vertical load in addition to its own weight.

*curtain wall*—a **nonbearing** exterior **wall**, secured to and supported by the structural members of the **building**.

nonbearing wall—a wall that does not support a vertical load other than its own weight.

retaining wall—a wall not enclosing portions of a building, designed to resist the lateral displacement of soil or other material.

water leakage—penetration of water onto the exterior plane of framing or cavity insulation under specified conditions of air pressure difference across the AR during a test period.

water-repellant, *n*—a material or treatment for surfaces to provide resistance to penetration by water.

water resistance—the capability of a material or system to retard water leakage. E1677

water vapor barrier—Use water-vapor retarder, the preferred term.

water vapor diffusion—the process by which water vapor spreads or moves through permeable materials caused by a difference in water vapor pressure.

water-vapor permeance—time rate of water-vapor transmission through unit area of a flat material or construction induced by unit vapor-pressure difference between two specified surfaces, under specified temperature and humidity conditions. See perm.
C168

water-vapor retarder, *n*—material or system that impedes the transmission of water vapor under specified conditions.

Discussion—See Practice C755 for guidance on acceptable limits.

**weather sealer**—form of coating applied to the outer surface of a construction to augment its weather resistance.

**weephole,** *n*—a small hole allowing drainage of fluid. Compare **drainage hole, vent hole**.

window—See windows and doors.

# windows and doors:

back bedding—a **bead** of sealant, glazing compound, or putty, applied between the face of glass and the **frame** containing it.

back putty—Use back bedding.

balance, n—a mechanism used in hung window assemblies to provide mechanical assistance in raising the operable **sash** and providing a means of holding the **sash** in the open position.

bead, n—in glazing, (1) a strip of metal or wood used around the periphery of a **pane** of glass to secure it in place (also referred to as a "stop"). (2) a strip of sealant, glazing compound, or putty.

*bite*, *n*—the distance that the surround member (rail or stile) overlaps the **glazing**.

*fixed*, *adj*—describing a **sash**, **panel**, or **glazing** designed not to be opened (antonym: **operable**).

frame, n—an assembly of structural members that surrounds and supports the sash, ventilators, doors, panels, or glazing that is installed into an opening in a building envelope or wall.

glaze, v—to install glazing.

glazing, n—a material installed in a sash, ventilator, or panel such as glass, plastic, etc.

glazing bead, n—a glazing material used in a sash, ventilator, panel, window or door assembly that retains the glazing.

glazing material, n—the **components** used to install **glazing** into its surrounding edge members, such as gaskets, sealants, glazing retainers, etc.

*head, n*—an upper horizontal member of a **window** or door **frame.** 

horizontal sliding window, n—a window assembly in which the operable **sash**(es) moves horizontally in the plane of the **window**.

hung window, n—window assembly in which the operable **sash**(es) moves vertically in the plane of the **window** and having a balance(s) to aid in the operation of the sash.

**Windows** may be single, double, or triple hung depending on the number of **operable sash**(es).

*interlock*, *n*—a set of **meeting rails** or meeting **stiles** that contains a provision for each of the **rails** or **stiles** to physically engage one another over their entire length.

*jamb*, *n*—a vertical member of a **window** or door **frame**. *light*, *n*—Use **lite**.

*lite*, *n*—one piece of **glazing** (preferred term) (also spelled light) (synonym: pane)

meeting rail, n—a rail that overlaps another rail.

*mull*, v—to join or connect **frame** members of **windows** or doors; or a **frame** member to a **mullion**.

*mullion*, *n*—a member used between **windows** or doors as a means of connection, which may or may not be structural.

*muntin*, *n*—a member used between **lites** of **glazing** within a **sash**, **ventilator**, or **panel**.

"O"—in window and door design, a designation used to indicate a **fixed sash, panel,** or **lite.** 

*operable, adj*—describing a **sash, ventilator,** or **panel** designed to be opened and closed (antonym: **fixed**).

pane, n—See lite.

panel, n—an assembly of one or more **lites** of **glazing**, encompassed by surrounding edge members, which when **operable**, slides horizontally in the plane of a sliding door.

*rail*, *n*—a horizontal surrounding edge member of a **sash**, **ventilator**, or **panel**.

sash, n—an assembly of one or more **lites** of **glazing**, encompassed by surrounding edge members, which when **operable**, slides in the plane of the **window**.

DISCUSSION—In the wood window industry, the term "sash" is used regardless of the mode of operation.

sealed insulating glass, n—an assembly of two or more **lites** separated by a dehydrated gaseous space(s), the entire assembly being sealed to resist passage of water vapor or gas.

*sill, n*—a lower horizontal member of a **window** or sliding door **frame**.

*sliding glass door, n*—a door assembly in which the **operable panel**(s) moves horizontally in the plane of the door.

*stile*, n—a vertical surrounding edge member of a **sash**, **ventilator**, or **panel**.

*ventilator*, *n*—an assembly of one or more **lites** encompassed by surrounding edge members, that operates in a manner other than sliding in the plane of the **window**.

DISCUSSION—In the wood window industry, this term is not normally used; the parts of the window described are denoted as "sash."

window, n—an assembly consisting of a surrounding **frame** and one or more **sashes**, **ventilators**, or fixed **lites** of glass, or a combination of these, designed to be installed in a **wall** opening for the purpose of admitting light or air, or both.

"X"—in window and door design, a designation used to indicate an **operable sash**, **ventilator**, or **panel**.

wipe, *n*—a disposable, porous paper (cellulosic) towellette that is moistened with a wetting agent. E1792

Discussion—The towellette is used to collect a sample of settled dust on a smooth, hard surface for subsequent lead analysis.

wipe—disposable twoelettes moistened with a wetting agent.

These towelettes are used for cleaning sampling equipment.

Wipe brands or sources selected for use shall contain insignificant background lead levels.

E1792

Discussion—Laboratory analysis on replicate blank wipes should be used to determine background lead levels prior to use in the field. Brands of wipes that contain aloe should be avoided due to increased potential of significant background lead in these wipes. Brands of wipes that contain lanolin should also be avoided due to potential increased laboratory processing difficulties that have been reported with such wipes. Background lead levels less than 5 µg per wipe are considered insignificant for most investigative purposes.

wipe—disposable towelettes moistened with a wetting agent (see 2.1.5.1 and 2.1.5.2). These towlettes are used to collect the sample and to clean sampling equipment. Wipe brands or sources selected for use shall not contain significant background lead levels (see 2.1.5.1.) Wipe brands or sources selected for use shall be of adequate width and thickness to perform the collection procedure (see 2.1.5.2).

Discussion—Laboratory analysis on replicate blank wipes should be used determine background lead levels prior to use in the field. Brands of wipes that contain aloe should be avoided due to increased potential of significant background lead in these wipes. Background lead levels less than 5  $\mu$ g per wipe are considered insignificant for most investigative purposes.

DISCUSSION—A thin wipe having dimensions of approximately 15 by 15 cm is recommended. Use of multiple or extra-thick wipes can cause problems with laboratory analysis activities. Use of wipes with smaller dimensions may not be capable of holding settled dust contained within the sampling area.

wipe sampling kit—a sealable rigid walled container with 50 mL minimum volume (see 2.1.6.1). The kit must also include a separate container of clean uncontaminated wipes for use in collecting samples. One container of bulk packed wipes is typically used for collection of multiple samples.

E1728

Discussion—Use a resealable plastic bag for holding and transporting the settled dust wipe sample is not recommended due to the potential losses of settled dust within the plastic bag during laboratory handling. Quantitative removal and processing of the settled dust wipe sample by the laboratory is significantly improved through the use of sealable rigid walled containers.

working drawing—a detail drawing, usually produced by a draftsperson under direction of an architect, engineer, or other designer showing form, quantity, and relationship of construction elements and materials; indicating their location, identification, grades, dimensions, and connections. Compare shop drawing.

# XEPS—see rigid cellular polystyrene thermal insulation board.

**yield stress**, *n*—limit to internal force developed by application of external force or load or generation of internal strain to a material, member, connection component, or assembly beyond which a marked increase in the rate of deformation occurs without an increase in load; expressed in terms of units of force per unit area, psi, pounds force per square inch (Mpa, megapascals).

Discussion—When the initial rate of force is non-linear, an agreed-on convention shall apply. Sometimes incorrectly referred to as *yield strength* and as *ultimate strength*.

#### **APPENDIXES**

(Nonmandatory Information)

#### X1. TERM LISTS

# X1.1. Scope

X1.1.1 This appendix section of term lists is provided as a resource and a convenience to aid in providing references to sources of terms and definitions from other general subject terminologies developed by different subcommittees of ASTM E06. The term lists have been compiled from the text of the different terminology standards listed herein.

Note X1.1—Some terms are listed more than once.

# X1.2. Referenced Documents

X1.2.1 ASTM Standards:<sup>2</sup>

B547 Specification for Aluminum and Aluminum-Alloy Formed and Arc-Welded Round Tube

C274 Terminology of Structural Sandwich Constructions

C460 Terminology for Asbestos-Cement (Withdrawn 2001)<sup>3</sup>

C859 Terminology Relating to Nuclear Materials

D16 Terminology for Paint, Related Coatings, Materials, and Applications

D123 Terminology Relating to Textiles

D661 Test Method for Evaluating Degree of Cracking of Exterior Paints

D772 Test Method for Evaluating Degree of Flaking (Scaling) of Exterior Paints

**D883** Terminology Relating to Plastics

D907 Terminology of Adhesives

D1356 Terminology Relating to Sampling and Analysis of Atmospheres

D1566 Terminology Relating to Rubber

D2864 Terminology Relating to Electrical Insulating Liquids and Gases

D4214 Test Methods for Evaluating the Degree of Chalking of Exterior Paint Films

D4538 Terminology Relating to Protective Coating and Lining Work for Power Generation Facilities

E344 Terminology Relating to Thermometry and Hydrometry

E833 Terminology of Building Economics

E874 Practice for Adhesive Bonding of Aluminum Facings to Nonmetallic Honeycomb Core for Shelter Panels

E1227 Terminology for Chemical Analysis of Metals (Withdrawn 1991)<sup>3</sup>

E1481 Terminology of Railing Systems and Rails for Buildings

E1605 Terminology Relating to Lead in Buildings

E1699 Practice for Performing Value Engineering (VE)/ Value Analysis (VA) of Projects, Products and Processes

E1749 Terminology Relating to Rigid Wall Relocatable Shelters

E1908 Guide for Sample Selection of Debris Waste from a Building Renovation or Lead Abatement Project for Toxicity Characteristic Leaching Procedure (TCLP) Testing for Leachable Lead (Pb)

E1979 Practice for Ultrasonic Extraction of Paint, Dust, Soil, and Air Samples for Subsequent Determination of Lead

E2052 Guide for Evaluation, Management, and Control of Lead Hazards in Facilities (Withdrawn 2008)<sup>3</sup>

E2110 Terminology for Exterior Insulation and Finish Systems (EIFS)

E2115 Guide for Conducting Lead Hazard Assessments of Dwellings and of Other Child-Occupied Facilities (Withdrawn 2015)<sup>3</sup>

E2151 Terminology of Guides for Specifying and Evaluating Performance of Single Family Attached and Detached Dwellings

E2239 Practice for Record Keeping and Record Preservation for Lead Hazard Activities

E2255 Practice for Conducting Visual Assessments for Lead Hazards in Buildings (Withdrawn 2013)<sup>3</sup>

E2265 Terminology for Anchors and Fasteners in Concrete and Masonry

E2271 Practice for Clearance Examinations Following Lead Hazard Reduction Activities in Dwellings, and in Other Child-Occupied Facilities

F412 Terminology Relating to Plastic Piping Systems

F1156 Terminology Relating to Product Counterfeit Protection Systems (Withdrawn 2001)<sup>3</sup>

G15 Terminology Relating to Corrosion and Corrosion Testing (Withdrawn 2010)<sup>3</sup>

G40 Terminology Relating to Wear and Erosion

X1.2.2 EPA Document:<sup>5</sup>

40 CFR 745.223 Lead; Identification of Dangerous Levels of Lead

# X1.3 Terminology E833

X1.3.1 The following list provides the preferred and admitted terms related to building economics established by ASTM International Committee E06.81 on Building Economics, at the time of the designated publication. For specific definitions for these general concepts, see the latest edition of Terminology E833.

adjusted internal rate-of-return (AIRR), *n* allowance, *n*—in construction design planning and estimating

annual value, *n* annual worth, *n* annually recurring costs, *n* base date, *n* 

<sup>&</sup>lt;sup>5</sup> Available from United States Environmental Protection Agency (EPA), William Jefferson Clinton Bldg., 1200 Pennsylvania Ave., NW, Washington, DC 20004, http://www.epa.gov.

base time, n	function analysis, <i>n</i>
baseline labor hour budget, n	function, basic, <i>n</i>
baseline plan, n	functional element, n-in construction planning, design,
benefit-cost analysis, n	specification, estimating, and cost analysis
benefit-to-cost ratio (BCR), n (Syn: benefit-cost ratio)	future value, <i>n</i>
break even analysis, n	future worth, <i>n</i>
building decision, n	general overhead, n
building economics, <i>n</i>	group element, n-in construction planning, design
building system, <i>n</i>	specification, estimating, and cost analysis
capital cost, n	hazardous waste, n
cash flow, n	in situ treatment, n
certainty equivalent technique, n	incremental cost (benefit), n
code of accounts, n	inflation, <i>n</i>
Comprehensive Environmental Response, Compensation,	initial cost, <i>n</i>
and Liability Act (CERCLA), n	initial investment cost, n
condition index	internal rate of return (IRR), n
constant dollars, n	investment cost, n
construction contingency, n	labor productivity reference point, n
construction documents, n	life cycle, <i>n</i>
contingency, n-in construction design planning and esti-	life-cycle cost (LLC) method, n
mating	maintenance, <i>n</i>
control signal, n	maintenance and repair cost, n
cost analysis, n	major group element, n—in construction planning, design
cost effective, adj	specification, estimating, and cost analysis
cost limitations, n	marginal cost (benefit), n
cost model, n	MasterFormat, n
cost overruns, n	mathematical/analytical (M/A) technique, n
cost professional, n	mean-variance criterion, n
current dollars, n	minimum acceptable rate of return, n
current replacement value, n	modified internal rate of return (MIRR), n
deactivation, n	needs, n
decision analysis, n	net benefits (savings), n
decommissioning, n	nominal discount rate, n
decontamination, n	non-installation hours, n
design contingency, n	observed percent complete, n
design development, n	office overhead, n-in construction design planning, and
design program, n	estimating
desires, n	operating cost, n
differential price escalation rate, n	opportunity cost of capital, n
discount factor, n	overall rate of return (ORR), n
discounting, n	owner, n
discount rate, n	parameter quantity, n-in construction planning, design,
economic evaluation methods, n	specification, estimating, and cost analysis
economic life, n	payback method, n
element, n—in construction planning, design, specification,	payback (PB) period, n
estimating, and cost analysis	portfolio analysis, n
elemental cost analysis, n—in construction planning,	present value, n
design, specification, estimating, and cost analysis	present value factor, n
elemental cost summary, n-in construction planning,	present worth, n
design, specification, estimating, and cost analysis	present worth factor, n
engineering economics, $n$	productivity differential, n
equivalent uniform annual value, n	program, n
ex situ treatment, n	radioactive waste, n
field requirements, n—in construction design planning, and	rate of return, n
estimating	real discount rate, n
financial management rate-of-return (FMRR), n	real dollars, n
first cost, n	reconciliation, <i>n</i>
function, <i>n</i>	remediation, <i>n</i>

replacement cost, <i>n</i> resale value, <i>n</i>	as-built drawing assignable area
reserve, n—in construction design planning, and estimat-	base building, n
ing	basement, SOURCE E631
Resource Conservation and Recovery Act (RCRA), n	brief (of a facility)
retrofit, n	building, n, SOURCE E631
risk-adjusted discount rate (RADR), n	building component, n, SOURCE E631
risk analysis, n	building construction, n, SOURCE E631
risk attitude, n	building core and service area
risk averse (RA), n	building envelope, n
risk exposure, n	building gross area
risk neutral (RN), n	building occupant
risk taking (RT), n	building performance, n, SOURCE E631
salvage value, n	building projection, n
savings-to-investment ratio (SIR), n	building service area
schematic design, n	building space
sensitivity analysis, n	building subsystem, n, SOURCE E631
simple payback (SPB) period, n	building system, n
stakeholders, n	capital cost, n, SOURCE E833
study period, <i>n</i> sub-element, <i>n</i> —in construction planning, design,	cellar (cave), n, SOURCE E631
specification, estimating, and cost analysis	circulation space
sunk cost, n	classes of buildings, adj
surveillance and long-term monitoring (SLTM), n	combination of features, $n$
surveillance and maintenance, $n$	component
system productivity, <i>n</i>	criterion, SOURCE E631
target cost, n	design program
task outline, n	durability, SOURCE E631
time horizon, <i>n</i>	dwelling, n, SOURCE E631
time value of money, n	engineering economics, <i>n</i> , SOURCE E833
toxic waste, n	evaluate, v
uncertainty, n	evaluation
UNIFORMAT II <i>UII</i> , n	fabric, n
useful life, n	facility, n, SOURCE E631
user, n	facility durability, n, SOURCE E631
utility function, n	facility evaluation, n, SOURCE E631
value, n	facility energtor, n
value analysis, (VA), n	facility operator, <i>n</i> facility performance, <i>n</i> , SOURCE E631
value analysis team leader (VATL), n	
value engineering (VE), n	facility program, <i>n</i> facility project brief (statement of work), <i>n</i> , SOURCE
value methodology, <i>n</i> , SOURCE E1699	E631
work breakdown structure (WBS), n	facility serviceability, <i>n</i> , SOURCE E631
workshop effort, n	facility serviceability profile, <i>n</i>
worth, n	facility use, n, SOURCE E631
X1.4 Terminology E1480	feasibility study, n
X1.4.1 The following list provides the preferred terms,	feature, <i>n</i> , SOURCE E1334
admitted terms, and additional terminological data related to	fit-up, n
facility management established by ASTM International Com-	floor, SOURCE E631
mittee E06.25 on Whole Buildings and Facilities, at the time of	function, n
the designated publication. For specific definitions for these	functional, adj
general concepts and related data, see the latest edition of	functionality, adj
Terminology E1480, except as noted otherwise relative to the	functional program, n
referenced SOURCE.	functional requirement, n
active hours	function performance, <i>n</i>
adjusted serviceability score	glare
ambient light	gross floor area, SOURCE E631
architectural program	guide for rating, n
area	historic fabric

house, n, SOURCE E631 importance factor, n lease (bail) maintainability net assignable area net floor area, SOURCE E631 net programmable area occupancy, n occupancy instrument (OI) occupant overall serviceability score performance performance criterion, of a facility performance test method, of a facility physical protection, nportfolio primary circulation area project project brief, n rating process, n rating scale rating score record set drawing regulation, n, SOURCE E631 reliability, n, SOURCE E344 requirement statement, n, for a facility score, n secondary circulation area serviceability, n, SOURCE E631 serviceability requirement, n serviceability requirements profile (SRP) shop drawing silent hours silent hours, n specification, n, SOURCE E631 support space system—of a building task lighting technical performance tenant test (performance test of a facility) transitional hours, n typical serviceability score usable area use-of a facility visitor working drawing workplace workspace workstation

# X1.5 Terminology E1481

X1.5.1 The following list provides the preferred terms, admitted terms, and additional terminological data related to railing systems and rails for buildings established by ASTM International Committee E06.56 on Performance of Railing Systems and Glass for Floors and Stairs, at the time of the designated publication. For specific definitions for these gen-

eral concepts and related data, see the latest edition of Terminology E1481, except as noted otherwise relative to the referenced SOURCE.

baluster, baluster bar, *n* baluster casting baluster railing system balustrade, *n* 

bottom rail building, *n*, SOURCE E631

cap, *n* cap rail

collar, *n*, SOURCE E631 cover flange, SOURCE E631

cover plate cover ring

drop cap, SOURCE E631

easement, *n* escutcheon, *n* expanded metal

finial, n, SOURCE E631

flange, n

grab bar, SOURCE E631 grab rail, SOURCE E631

guardrail system

handgrip, n, SOURCE E631

handrail. n

handrail bracket, SOURCE E631 handrail height, SOURCE

infill, *n* infill area intermediate rail kick plate lamb's tongue

lateral scroll, SOURCE E631

mid rail, *n* miter ending newel, *n* 

ogee, n, SOURCE E631

panel, *n* picket, *n* 

pineapple, n, SOURCE E631

pipe, n

pipe railing system post, *n*, SOURCE E631 queue-rail system

rail, n

rail cap, SOURCE E631 railing, *n*, SOURCE E631

railing return railing system

railing-system penetration limitation, SOURCE E631

ramp-rail system

screen, *n* scroll, *n* side mount spindle, *n* stair-rail system toe board

competence, n, SOURCE E2239

toe plate, SOURCE E631
traffic-rail, SOURCE E631
traffic-rail system, SOURCE E631
transfer-rail system, SOURCE E631
tube/tubing
urn, n
volute, n, SOURCE E631
wall bracket
wall clip
wall flange
wall handrail
wall rail, SOURCE E631
wall railing return
wire fabric
wire mesh

# X1.6 Terminology E1605

X1.6.1 The following list provides the preferred terms, admitted terms, and additional terminological data related to lead in buildings established by ASTM International Committee E06.23 on Lead Hazards Associated with Buildings, at the time of the designated publication. For specific definitions for these general concepts and related data, see the latest edition of Terminology E1605, except as noted otherwise relative to the referenced SOURCE.

abrasion resistance (coatings) accessible surface accreditation, n, SOURCE E631 accuracy, n action level, n administrative controls administrative removal analyte, n anodic stripping voltammetry Apparent Lead Concentration (ALC) atomic absorption, SOURCE D2864 baluster (picket), n, SOURCE E631 bare soil, n, SOURCE E2255 baseboard, n batch, SOURCE E1726 bias, n, SOURCE E456 biological monitoring blank sample blood-lead level (blood level) calibration curve calibration standard, SOURCE E1613 certification, SOURCE HUD Guidelines Certified Reference Material (CRM), SOURCE E1644 chalking, n, SOURCE D4214 checking (coatings), n chewable surface child-occupied facility chipping resistance (coatings), SOURCE D16 clearance area, n, SOURCE E2271 clearance examination, n clearance level, n coating, n, SOURCE D16

Code of Federal Regulations (CFR)

common area, n, SOURCE 40 CFR 745.223

component, n, E631 (building component) component (of the waste), SOURCE E1908 component replacement (building) concentration, nconformity, n, SOURCE E2239 containment, n continuing calibration blank, SOURCE E1613 continuing calibration verification, SOURCE E1613 coring, SOURCE E1727 cracking (coatings), n, SOURCE D661 data collection objective delamination, n, SOURCE D4538/D907 deleading detection limit deteriorated paint digestate digestion discipline, n dust-lead hazard, n dust-wipe sample, SOURCE E1644 dwelling unit, SOURCE E631 elevated blood lead level (EBL) encapsulation, n enclosure, n engineering controls evaluation, n, SOURCE E2239 extraction, n, SOURCE E1979 facility, n field blank field operation laboratory fixed-site laboratory flaking (scaling), n, SOURCE D772 friction surface, n, SOURCE E2255 glazing, n, SOURCE E631 hazardous waste heat gun HEPA filter high-efficiency particulate air (HEPA) filter impact surface, n, SOURCE E2255 industrial hygienist initial calibration blank, SOURCE E1613 initial calibration verification in situ instrumental detection limit, SOURCE E1613 instrumental QC standard, SOURCE E1613 interference check standard, n, SOURCE E1613 interim controls, SOURCE 40 CFR 745.223 lead-based paint, n lead-based paint activities, SOURCE 40 CFR 745.223 lead-based paint inspection, n, SOURCE E2255 lead-containing paint, n leaded dust hazard, n leaded paint leaded paint characterization, SOURCE E2052

leaded paint hazard, n

leaded soil, n lead-free (deprecated) lead hazard, n lead-free (deprecated) lead hazard activities, n, SOURCE E2255 lead hazard activities, n, SOURCE E2115 lead hazard control lead hazard reduction, n, SOURCE E2052 lead hazard reduction, n, SOURCE E2271 lead hazard screen, SOURCE 40 CFR 745.223 lead paint (deprecated) lead screen (deprecated) maintenance, n, SOURCE E2052 mass concentration, SOURCE G40 mass loading matrix matrix effect MD mean (value) medical removal (of workers) measurement, n, SOURCE D123 method detection limit, SOURCE E1613 molding, n monitoring, n multi-family dwelling, n, SOURCE 40 CFR 745.223 National Lead Laboratory Accreditation Program (NLLAP) needle gun nonconformity, n, SOURCE E2239 non-spiked sample objective evidence, n, SOURCE E2239 painted debris, n, SOURCE E2239 painted debris, n, SOURCE E2231 painting history, n paint-lead hazard, n patch test Permissible Exposure Limit personal air sample personal protective equipment precision procedure, n, SOURCE E2239 professional judgement, n quality system quantitation limit, SOURCE E2271 random sampling, SOURCE C859 range, n reading, n, SOURCE E1227 read-through, n reagent, SOURCE F1156 recognized laboratory	requirement, n, SOURCE E2239 residential dwelling, SOURCE 40 CFR 745.223 risk assessment, SOURCE 40 CFR 745.223 risk assessment screen (deprecated) risk assessor, certified risk screen (deprecated) room equivalent, n, SOURCE E2271 sample, n sample of the waste, n, SOURCE E1908 sampling location, n, SOURCE E1728 sampling site, n, SOURCE E1728 sampling site, n, SOURCE E1728 sampling template (dust), n sash, n scaling SEL settled dust, n, SOURCE E2271 small quantity sodium rhodizonate method sodium sulfide method soil-lead hazard, n, SOURCE E2255 specimen spot test, n, SOURCE E1753 standard deviation (in statistics) substandard dwelling substrate substrate equivalent lead concentration (SEL) surface dust, n test, n test, specimen toxicity characteristic leaching procedure (TCLP) traceability, n treatment TSP unit verification vinyl composition tile, n, SOURCE E1792 visual inspection for clearance testing, SOURCE 40 CFR 745.223 visual inspection for risk assessment, SOURCE 40 CFR 745.223 waste, n, SOURCE E1908 waste stream, n, SOURCE E1908 west stream, n, SOURCE E1908 west stream, n, SOURCE E1792 work area, n X-ray fluorescence instrument, n
•	_
•	X-ray fluorescence instrument, n
·	
record, n, SOURCE E2239 reevaluation	X1.7 Terminology E1749
reference material	X1.7.1 The following list provides the preferred terms,
remodel, v, SOURCE E631	admitted terms, and additional terminological data related to
repair, v, SOURCE E631	rigid wall relocatable shelters established by ASTM Interna-
reporting limit, n	tional Committee E06.53 on Materials and Processes for

Durable Rigid Wall Relocatable Structures, at the time of the

representative sample

designated publication. For specific definitions for these gendebulking eral concepts and related data, see the latest edition of degradation Terminology E1749, except as noted otherwise relative to the delamination, SOURCE D883 referenced SOURCE. density, SOURCE C460 absolute sealing destructive test accelerated test dry strength adhesive, SOURCE D907 durability adhesive working life, SOURCE D907 **ECA** alclad sheet and plate, SOURCE B547 edge closures edgewise compressive strength angle ply electromagnetic interference anisotropic A-stage electromagnetic pulse **EMI** autoclave **EMP** autoclave molding environmentally controlled area bag molding balanced laminate excessive corrosion batch expandable shelters beam shear exotherm bleeder cloth facing block fairing block flow faying surface faying surface seal breakout breather feathering fiber content bridging brittleness fiber orientation broadgoods filament bruch coat filamentary composites fillet seal B-stage burn rate film weight flame resistance, SOURCE D123 button sample carrier floating roller peel test catalyst caul foam core **CBR** foamed adhesive chemical resistance, SOURCE F412 forest products laboratory etch CIAP FPL etch climbing drum peel test fungus resistance close out fuzz balls gage pressure, SOURCE D1356 cocuring cold setting adhesive, SOURCE D907 galvanic corrosion, SOURCE G15 collimate gouge, SOURCE E874 compacting hard edge composite material hard points compressive strength heat sealing adhesive tape conduit highly expandable shelters contact adhesive **HOBE** contact (pressure) adhesive honeycomb before expansion contact pressure honeycomb core controlled flow honeycomb sandwich panel core, SOURCE C274 hot pressing core compressive modulus hygroscopic injection seal core shear core shear modulus integrally mold interference seal core splice adhesive core stabilization interference seal crazing interlaminar C-stage, SOURCE D907 isotropic cure, SOURCE D883

joggle

knockdown shelters stacking sequence laminate, SOURCE D883 storage life, SOURCE D907 large area shelters sulfochromate etch supported film adhesive lay-up surface preparation, SOURCE D907 leak exit symmetrical laminate leak path tap test leak source tape tempest lot thermoplastic mandrel thermoset markoff thixotropy mat tooling matrix unit, SOURCE E631 mold form unsupported film adhesive net molded edge vacuum bag molding node VOC nominal pressure void nominal temperature volatile organic compound nondestructive test volatility nonexpandable shelters water migration resistance nonmetallic honeycomb core wet-installed fastener normalize wet strength oil canning orthotropic X1.8 Terminology E2110 P2 etch X1.8.1 The following list provides the preferred terms peel ply related to exterior insulation and finish systems (EIFS) estabplate shear lished by ASTM International Committee E06.58 on Exterior post cure, SOURCE D1566 Insulation and Finish Systems (EIFS), at the time of the pot-life designated publication. For specific definitions for these genprebleeding eral concepts, see the latest edition of Terminology E2110. prefit accessories, n prepack seal aesthetic joint, n prepreg aesthetic reveal, n pressure sensitive adhesive back wrapping, n primary seal base coat, n primer cold joint, n pultrusion cure, v resin batch drainage mat, n resin content dry, v resite durability, n resitol edge wrap, n resol EIFS, n REX hardness EIFS-clad barrier wall assembly, n sag flow test EIFS-clad drainage wall assembly, n sandwich panel embed, v serim expansion joint, nseal exterior insulation and finish system (EIFS), n seal plane factory mix, n sealant working life flash set (quick set), n secondary bonding field mix, n secondary seal finish coat, n self-sealing fastener framing member, n separator cloth initial grab, n sheet initial set, n shelf life integrally reinforced base coat, nshielding effectivness lamina, n Shore A hardness mechanical fastener, n skin nonmetallic reinforcing mesh, n slump pot life, n

primers, *n*running bond, *n*substrate, *n*surface sealer, *n*temper, *v*texture, *n*thermal insulation board, *n*weather-resistive barrier, *n*wet edge, *n*wet-state materials, *n*wrap, *v* 

# X1.9 Terminology E2151

X1.9.1 The following list provides the preferred terms related to specifying and evaluating the performance of single family attached and detached dwellings established by ASTM International Committee E06.25 on Whole Building and Facilities, at the time of the designated publication. For specific definitions for these general concepts, see the latest edition of Terminology E2151, except as noted otherwise relative to the referenced SOURCE.

attached dwelling, *n* commentary, *n* criteria, *n* dwelling unit, *n*, SOURCE E631 evaluation, *n* objective, *n* performance statement, *n* provider, *n* systems integrator, *n* 

# X1.10 Terminology E2265

adhesive anchor

X1.10.1 The following list provides the preferred terms related to anchors and fasteners in concrete etablished by ASTM International Committee E06.13 on Structural Performance of Connections in Building Construction, at the time of the designated publication. For specific definitions for these general concepts, see the latest edition of Terminology E2265.

allowable load
anchor
anchor loading: axial
anchor loading: bending
anchor loading: combined
anchor loading: shear
anchor spacing
attachment
base material
bond failure
cast-in-place anchor
characteristic value
clamping force

concrete breakout failure connection cracked concrete critical edge distance critical spacing cure time diamond core bit displacement displacement-controlled expansion anchor drill drill bit edge distance effective embedment depth elongation embedment depth expansion anchor expansion sleeve failure mode fastener fatigue test fixture flush installation follow-up expansion gel time grout grouted anchor insert installation torque linear variable differential transformer (LVDT) minimum spacing prestressing force pullout failure pull-through failure relaxation screw anchor seismic test shear test shock test slip spacing sleeve splitting failure standoff installation static load static test steel failure stop-drill

torque-controlled adhesive-bonded anchor

torque-controlled expansion anchor

tensile test

uncracked concrete

undercut anchor



### X2. KEYWORDS

# X2.1 Scope

X2.1.1 This appendix of keywords is provided as a resource and a convenience to aid in providing index terms for standards of Committee E06. It has been compiled from the titles and text of current standards. Other appropriate keywords may be selected; such as terms listed elsewhere in this terminology standard.

Note X2.1—Some keywords herein are listed more than once.

# **X2.2** Resource List of Keywords

abatement contractor accelerated testing accelerated weathering acceptance testing accreditation accuracy of loading acoustic method adhesion adhesive bonding adhesive primer adhesives adjusted internal rate of return agencies capabilities agencies criteria agencies evaluation criteria agencies guidelines agencies testing air capacity air change rate air-erosion testing air flow calibration air infiltration air leakage air-leakage detection air-leakage measurement air-leakage rates air-leakage testing air-pressure difference air-pressure difference testing air-pressure differential test air-pressure testing airflow measurement airflow calibration aluminum alloy panels aluminum facings anchorage anchorage devices testing anchorage systems anchorage system tests

anchorage testing anemometer method

asbestos abatement

annealed glass architectural drawings basic building module beams testing benefit/cost analysis benefit-to-cost ratio bimetallic thermometer bituminous roofing blower-door test bonding strength bond strength building air-change rate building anchors building assemblies data building components life building components evaluation building construction building construction materials building constructions data building construction tests building decisions building design metric practice building economics building elements building envelope building inspection building inspector building materials service life building neutral zone building owner building parts sizing buildings buildings connections data buildings definitions buildings drawings buildings investment buildings life cycle costs buildings modules buildings terminology building thermal envelope building systems building systems costs building systems evaluation built-up roofing

canopies cantilever-beam test cantilever frame carports certainty equivalent factor certification clay flue linings coatings cohesion/adhesion testing comparison techniques complete structure loading compliance assurance

compression testing compressive load compressive loading compressive strength computer programs concentrated load concentrated static load concrete elements testing concrete masonry units concrete slabs connections testing construction terminology control plate tension testing control truss plates core-splice adhesive corrosion corrosion-inhibiting adhesive cost analysis cost-effectiveness of buildings cost evaluation counter flashing crawl spaces curtain walls cyclic static air-pressure cyclic static air-pressure tests

damage data reporting decks deflection charts deflection measurements deflection resistance deflections deglazing loads deglazing resistance density of sprayed material design assumptions destructive testing deterioration dew point/frost point diagonal tension testing diaphragm constructions dimensional coordination dimensional reference system doors doors installation drawings scales drop-bag tests durability durability evaluation

earth covers economic evaluation economic evaluation method economics terminology

durability performance durability of buildings

duration of loading

effective leakage area edge loading elastic modulus engineering data reporting engineering economics equivalent design load exfiltration exterior windows

f-number system facility functionality facility performance facility rating facility serviceability failure criteria failure endpoint failure tests fan-pressurization devices fan pressurization testing fasteners fastener strength fatigue tests field data gathering field determination field inspection monitoring field measurement field testing film adhesives fire-resistive materials flame-spread resistance flashing flatness flat roof testing flexural bond strength

flexural bond strength flexural tests floor flatness floor levelness floor panel testing floor profile numbers floors

floor sheathing floor surface profiles

floor testing fogging test

formaldehyde determination framed floor diaphragm framed walls testing frame stiffness frost point functionality

girders testing glass deflection glass performance glass thickness glass thickness gage glazing grab rails gravity-load testing honeycomb core honeycomb sandwich panels honeycomb shelter panels

impact load
impact loading tests
impact testing
infiltration
infiltration rate
infrared analysis
inspection evaluation
insulated roof deck steel frame
insulating glass units
insulation fasteners
internal rate of return
investment analysis
investments evaluation

laminates large chamber testing lawn buildings leak testing levelness life-cycle cost analysis life-cycle cost method life-cycle costs loading capability loading procedures loading resistance load resistance load resistance of glass load sharing load testing load transmittal lockers low-temperature flexibility

maintainability manufactured buildings manufactured housing manufactured structures masonry anchors masonry assemblages masonry assemblages tests masonry elements testing masonry mortar joints masonry prisms masonry testing masonry tests masonry ties measuring investment payback metal fascia thickness metal railing systems metric practice metric scales selection military shelters modified bitumen sheets

modular coordination modules modulus of elasticity moisture evaluation mortar joints mortar tests multi-glazing multiple-member tests

net benefits for investments net benefits method net present value method net savings nondestructive testing nonhabitable structures nonmetallic honeycomb core nonpermanent structures

orientation orifice plates overall performance overall rate of return

panel construction panel facings panel testing patio covers payback payback for investments payback method performance requirements performance test data performance testing permanent railing systems plastic-flow resistance plumbing powder-actuated fasteners pre-engineered roof structures preformed roof insulation present-value analysis project manager evaluation proof tests pullout resistance tests puncture-resistance testing

quality system assessment agencies

racking load
railing anchorage
railing systems
rate of return
rectilinear building parts
reliability
relocatable shelters
relocatable structures
repeat loadings
repetitive loads
replacement doors

replacement windows return on investment rigidity risk evaluation

#### **Roof Decks**

insulated roof deck steel frame steel roof deck

# **Roofs and Roofing**

bituminous roofing built-up roofing flat roof testing modified bitumen sheets pre-engineered roof structures preformed roof insulation roof drains roof diaphragm roofing adhesives roofing base flashing roofing edge detail roofing equipment support roofing expansion joints roofing mechanical equipment roofing membrane roofing scuppers roofing systems roof maintenance roof panel testing roof relief vent roof sheathing roof-system assemblies roof systems

roof testing

safety considerations sandwich panels savings/investment ratio seal durability sealed insulating glass seismic tests serviceability service-life prediction shear resistance shear resistance testing shear strength tests shear testing sheds shelter panels shock tests SI metric practice in buildings simple-beam diaphragm simple payback simple-span frame simulated load conditions simulated service tests simulated structures

sizing building parts

sliding glass doors smoke-tracer method soil burial testing soil contact testing sprayed materials sprayed fire-resistive material sprayed materials testing stack flashing standard terminology static air-pressure difference static axial strength static load static load testing static shear capacity static tests steel corrosion steel deck deflection tests steel deck insulation steel roof decks steel truss plates storm doors storm sashes storm windows strain gages strength of anchors strength tests stress testing structural adequacy structural applications structural clay units structural film adhesives structural performance structural tests structural tests data surface preparation system analysis

tactical shelters
technical staff evaluation
tensile load
tensile strength properties
tensile testing
tension testing
terminology
test data gathering
vapor retarder
wind uplift resistance

# **Testing**

acceptance testing
accelerated testing
agencies testing
air-erosion testing
air-leakage testing
air-pressure difference testing
air-pressure testing
anchorage devices testing
anchorage testing

beams testing cohesion/adhesion testing compression testing concrete elements testing connections testing control plate tension testing field testing destructive testing diagonal tension testing fan pressurization testing field testing flat roof testing floor panel testing floor testing framed walls testing gravity-load testing girders testing impact testing large chamber testing leak testing load testing masonry elements testing masonry testing nondestructive testing panel testing performance testing puncture-resistance testing roof panel testing roof testing shear resistance testing shear testing soil burial testing soil contact testing sprayed materials testing static load testing stress testing tensile testing tension testing tracer-dilution testing truss assembly testing truss testing wall panel testing wall testing water-vapor transmission testing wear testing wood products testing

## **Tests**

anchorage system tests building construction tests cyclic static air-pressure tests drop-bag tests failure tests fatigue tests flexural tests impact loading tests masonry assemblages tests

testing and inspection agencies

masonry tests mortar tests multiple-member tests proof tests pullout resistance tests seismic tests shear strength tests shock tests simulated service tests static tests steel deck deflection tests strength tests structural tests truss plate tests ultimate load tests unit masonry tests weather-cycle tests

thermal-conductance paths thickness gage thickness of sprayed material third-point loading tracer-dilution testing tracer gas tracer-gas dilution tracer-gas method tracer-gas monitor transverse load truss assemblies truss assembly testing truss plates truss plate tests truss testing

ultimate impact load ultimate load tests ultraviolet light resistance uncertainty evaluation uniform live load uniform loading uniform static loads unit masonry tests utility buildings

validation vapor retarders ventilation verification of design visual inspection

# Walls

curtain walls framed walls testing wall panel testing wall testing water-induced damage water leakage water penetration



water-vapor retarder
water-vapor transmission testing
wear testing
weather-cycle tests
wet tensile strength
wind-driven rain
wind loading
wind pressure

window assemblies window rotary operators windows window sashes windows installation windows performance wood-framed truss assemblies wood products testing

This standard is subject to revision at any time by the responsible technical committee and must be reviewed every five years and if not revised, either reapproved or withdrawn. Your comments are invited either for revision of this standard or for additional standards and should be addressed to ASTM International Headquarters. Your comments will receive careful consideration at a meeting of the responsible technical committee, which you may attend. If you feel that your comments have not received a fair hearing you should make your views known to the ASTM Committee on Standards, at the address shown below.

This standard is copyrighted by ASTM International, 100 Barr Harbor Drive, PO Box C700, West Conshohocken, PA 19428-2959, United States. Individual reprints (single or multiple copies) of this standard may be obtained by contacting ASTM at the above address or at 610-832-9585 (phone), 610-832-9555 (fax), or service@astm.org (e-mail); or through the ASTM website (www.astm.org). Permission rights to photocopy the standard may also be secured from the Copyright Clearance Center, 222 Rosewood Drive, Danvers, MA 01923, Tel: (978) 646-2600; http://www.copyright.com/