# IC Engineering I

Saroj Rout

2025-01-08

## Table of contents

Preface		3
1	Introduction	4
	Passive IC devices 2.1 Resistance	<b>5</b>
References		7

## **Preface**

This is a Quarto book.

To learn more about Quarto books visit https://quarto.org/docs/books.

## 1 Introduction

This book covers basic topics in circuits and devices for Integrated Circuit (IC) engineers.

This is a book created from markdown and executable code.

This is an exmaple of reference citation: Thomas, Rosa, and Toussaint (2016)

#### 2 Passive IC devices

This chapter covers basics principle behind passive IC devices: Resistors, Capcitors and Inductors.

#### 2.1 Resistance

Resistance calculation of metal or semiconductor material is fundamental to IC engineering. Consider a block of metal or semiconductor material with dimensions L, W and h. Let n be the charge per unit volume. To calculate the current  $I_R$  for an applied voltage  $V_R$  across the length of the material, we will consider an incremental cross section of the material with length  $\Delta x$ . The current can be written as the total charge in the incremental volume in time  $\Delta t$ :

$$I_R = \frac{\Delta Q}{\Delta t} = \frac{Q_S \Delta x}{\Delta t} = Q_S v_d$$

 $I_R = SheetCharge \times AverageVelocity \text{ or,}$ 

where,  $Q_S = nWh$  is the sheet-charge or the charge per unit length,

 $\boldsymbol{v}_d$  is the average velocity of the electrons:

$$v_d = \frac{\Delta x}{\Delta t} = \mu E$$
, and

where,  $E = \frac{\Delta v}{\Delta x}$ , and  $\mu$  is the *mobility* of the material.

Therefore, 
$$I_R = \mu Q_S \frac{\Delta v}{\Delta x}$$

The incremental resistance can be expressed as

$$\Delta R = \Delta v / I_R = \rho \Delta x / W$$

where,  $\rho = 1/(Q_S \mu)$  is the *Specific resistivity* ( $\rho$ ) is a property of the material that can be defined as the resistance per unit volume expressed in SI units of  $\Omega m$  but more conveniently as  $\Omega cm$ .

The total resistance of the volume can be found by summing up all incremental resistances  $\Delta R$ :

$$R = \rho L/A$$

where, L is the length and A is the cross-sectional area.

In integrated circuit design, the height of the metal routing is fixed and is typically in the range of 0.1 to 5 micrometers ( $\mu m$ ,  $10^{-6}m$ ) and the resistance is measured in square units as ohms per square or  $\Omega/\Box$ .

$$R = (\rho/h)(L/W)$$

Where,  $\rho/h$  is typically called sheet-rho  $(\rho_{sheet})$ 

The specific resistance (in  $\Omega cm$ ) and unit resistance (in  $\Omega/\square$ ) of typical metals used in integrated circuits such as aluminum (Al), copper (Cu) and gold (Au) are tabulated:

	$\mu - \Omega \text{ cm}$	$m\Omega/\Box$
Al	2.65	26.5
Cu	1.68	16.8
Au	2.44	24.4

#### References

Thomas, Roland E., Albert J. Rosa, and Gregory J. Toussaint. 2016. The Analysis and Design of Linear Circuits. John Wiley & Sons. https://www.dropbox.com/scl/fi/83ygnyynx2sfe x1h7tdhg/Thomas-AnalysisDesignOfLinearCkts-Wiley-2023.pdf?rlkey=4xzk0an1z7r3fcj 936o0enjg4&dl=0.