


Conduction - Thermal Resistance 05

Define the heat transfer resistance R_{tot} for a flat surface with the cross-sectional area A:



The standard expression for conductive thermal resistance is:

$$R_{\rm cond} = \frac{\Delta T_{\rm cond}}{\dot{Q}_{\rm cond}}$$

The temperature difference in the conductive layer can be expressed as:

$$\Delta T_{\rm cond} = T_1 - T_2$$

Where the rate of heat transfer for a plane wall can be stated as follows:

$$\dot{Q}_{\rm cond} = -\lambda A \frac{\partial T}{\partial x} = \lambda A \frac{T_1 - T_2}{\delta}$$

Substitution yields:

$$\rightarrow R_{\rm cond} = \frac{\delta}{\lambda A}$$

The standard expression for convective thermal resistance is:

$$R_{\rm conv} = \frac{\Delta T_{\rm conv}}{\dot{Q}_{\rm conv}}$$

The temperature difference can be expressed as:

$$\Delta T_{\rm conv} = T_2 - T_{\infty}$$

Where the rate of heat transfer for a plane wall can be stated as follows:

$$\dot{Q}_{\rm conv} = \alpha A \left(T_2 - T_{\infty} \right)$$

Substitution yields:

$$\rightarrow R_{\rm conv} = \frac{1}{\alpha A}$$

The expression for the total thermal resistance yields:

$$\rightarrow R_{\rm tot} = \sum R = R_{\rm cond} + R_{\rm conv} = \frac{\delta}{\lambda A} + \frac{1}{\alpha A}$$