GENERAL

There are four main sections to moOde: Configuration, Preferences, Playback and Library.

Switching between Playback and the Library is accomplished by clicking on the cover art in Playback or on any open area of the Playbar in the Library.

CONFIGURATION

The Configuration screens are accessed via the Main Menu and provide options for setting up the music library, configuring audio devices, defining network connections, enabling system services, connecting to peripheral devices, and activating 3rd party audio renderers. Typically these options are configured initially and then infrequently changed.

PREFERENCES

The Preferences screen is accessed via the Main Menu and provide settings for WebUI Appearance, Playback, Cover Art, Library and CoverView. PLAYBACK

The Playback screen includes the play queue (Queue), volume and time knobs, playback controls, cover art and metadata.

LIBRARY

The library provides Radio, Folder, Tag, Album and Playlist views for browsing and selecting content and a Playbar for displaying song information and controlling playback. Options for configuring various aspects of the Library including sort order, recently added and more are located in the

Library section of Preferences. Cover art The Cover Art section of Preferences contains settings for specifying cover art resolution,

whether to search first for embedded image or cover image file and which audio formats are included. NOTE: Some Albums for example "Nine Inch Nails - The Slip" have a main cover image file and

"Embedded" and Prefs > "Audio formats" to "Default+" When the Library is generated it creates a virtual Artist tag that includes Artists, Performers and Conductor, and a virtual Album Artist tag that is set to Album Artist if it exists otherwise to

also embedded covers in each track. To display the covers correctly first add the cover image file

the first element of the virtual Artist tag. The Library section of Preferences contains settings

for specifying how to populate the Artist column in Tag view. Date tags The date tag that is used is determined by the following priority: Original Date, OriginalReleaseDate, Date. The format for the value must be YYYY or YYYYMMDD otherwise any Library sort involving year will not be correct. The year YYYY portion of the date is used for

· Special AlbumDate tag The string "AlbumDate: YYYYMM" at the beginning of the Comment tag can be used to add month to the the sort order. This is to support correct sort order for multiple Albums released by the same artist within a year.

Powerful search features are available that allow the Library to be filtered based on entered text, tag value pairs or special, predefined filters. There is also an Advanced search dialog that enables multiple tag value pairs to be submitted.

Tag and Album views General Searches are not case sensitive and partial matches are the default unless one of the strict comparison operators '==' or '!=' is used. The comparison operators '=~' or '!~' can also be used

to perform searches based on PERL regular expressions. Searches are cleared by clicking on the

"Filtered by" heading. NOTE: The "search" field only supports a single tag value pair or a single Predefined filter. Tag value pairs The following tags are supported: Any, Genre, Artist, Album, Title, Album Artist, Date, Composer, Conductor, Performer, Work, Comment and File.

Examples: genre rock | artist frank sinatra | artist mccartney | any zeppelin

any of the tag or predefined filter names. Examples: yellow submarine | all that you can't leave behind | frank sinatra | 1962 Predefined filters

Examples: encoded 24/96 | encoded 192 | encoded 24 | encoded 6ch | encoded multichannel | hdonly | format .dsf | folder u2/achtung baby | lossy | year 1962 | year 1994-1998

Searches can be saved and subsequently activated using the "Saved searches" item on the

Saved searches

Searches are not case sensitive and partial matches are considered valid. Searches are cleared by clicking on the Home icon. Search results tally

General

Radio and Playlist view

Searches are not case sensitive and a progressive Typedown search method is used on the displayed items.

Click the search tally to display a context menu containing Add, Play, Clear/Play.

Clearing the search Click the Browse by header or the x icon in the "search" field to clear the search.

clock, a Playbar for controlling playback and several backdrop options that can be selected in the

The CoverView screen saver provides a large sized cover art image or optional Analog or Digital

The Queue is displayed in Playback and CoverView and contains all items to be played. It's

COVERVIEW

commands listed on a context menu. It can also be populated automatically by Auto-shuffle. The Queue commands are listed below. Add | Play

The "Add" command adds the item to the end of the Queue. The "Play" command first checks to

see if the item is already in the Queue and then plays the existing item otherwise it does the

populated primarily by selecting an item from the Library and then clicking one of the Queue

same as Add and then begins play. Clear/Play The "Clear/Play" command first clears the Queue then adds the item and begins play.

item. The "Play next" command first checks to see if the item is already in the Queue and then plays the existing item otherwise it does the same as "Add next" then begins play.

 Clear queue This command is available in the ellipsis context menu in Playback view and on the Playbar. For the track list in Library Tag and Album views the Play and Clear/Play actions can be

configured via a Preferences option to either add the selected track to the Queue or the

Creating, editing and managing playlists is done primarily in Library Playlist view. Playlists can also be created via context menu items "Save Queue to playlist", "Set Favorites name" and "Add to playlist".

selected track and all following tracks.

 Set Favorites name The "Set Favorites name" command displays an input form for specifying the name of the playlist that contains items favorited by clicking the Heart \heartsuit button. If the playlist does not already

of the selected playlist or a new playlist if one is specified.

The "Add to playlist" command displays a list of available playlists and adds the item to the end

A multiroom audio system consists of a Sender and Receivers. The Sender should be a dedicated Pi not connected to speakers or headphones. For additional information view the Multiroom setup

Sender and Receiver options are configured in Multiroom Config which is accessed via Menu/Configure or in the ALSA section of Audio Config. Audio sources including MPD, AirPlay

The volume knob on the Sender system provides master volume control by sending the volume

change to the Receivers which apply it to their own volume. Receivers can be configured to opt in or out of Master volume control via Multiroom Config. Receiver control Receivers can be centrally controlled from the Sender system via the Receivers panel which is

Master volume

The performance of the system depends on having low latency, high throughput networking and hosts. Discovery of Receivers relies on Multicast DNS. Addressing for the audio distribution protocol relies on IP Multicast using a default address of 239.0.0.1.

Most menu items are self explanatory but several perform unique functions. **▶▶** Players This item is located on the Main menu. It displays a list of other moOde players discovered on the

சி Audio info This item is located on the Main menu and ellipsis context menu in Playback view and on the Playbar. If it's opened from the Main menu it displays audio format and hardware related

This item is located on the ellipsis context menu in Playback view and on the Playbar. It show number of Queue items, number of those that are Tracks, total Track time and the last Saved

network. Submit an action to apply to all the players listed or click an individual player to open it.

The Submit button will request a second click for confirmation. If a player is functioning as a

Multiroom Receiver the icon will appear next to its name.

Most buttons are self explanatory but several perform unique functions.

↓ Consume

🔁 Repeat

C Single

CoverView. Play randomly selected tracks from the Queue (default) or if Auto-shuffle is on (see Audio

Config) play randomly selected tracks or albums from the entire Music Library.

Repeat the Queue or if Single is enabled then repeat the track.

Used in conjunction with Repeat to repeat a single track.

Toggle between the currently playing item and the last played item.

Select a random album from the Music Library and perform the action specified for the "One touch random album" setting in the Library section of Preferences. ○ Favorite

Clock Radio status A red dot will appear in the upper right corner of the header bar to indicate Clock Radio is on. One touch action

tapped.

Clicking on the button(s) in the center of the Renderer Active screen will perform the indicated action.

Volume knob Clicking on the numeric volume level toggles the mute state. Clicking ahead on the volume ring

Clicking on the extra metadata under the cover art in Playback view opens the Station or Track tab in the Audio info screen.

advances the volume by a maximum number of steps called the Volume step limit. This limit can

In Playback clicking the track title under the cover art launches a search in a separate Browser tab. The search engine used can be selected in the Playback section of Preferences.

Station or Artist name

On Smartphones it scrolls the Queue to that item.

scrolled to the station. Swipe gestures

named so its the last file in the album directory, then set Prefs > "Cover search priority" to Artist and Album Artist

display.

SEARCHING THE LIBRARY

 The Any tag The Any tag performs a search of all tags using an OR relationship. An Any search is automatically invoked when the first word of text entered in the "search" field does not match

The following predefined filters are available: Encoded [bits/rate | Nch | multichannel], Format [.ext], Folder [path], HDonly, Lossless, Lossy and Year [yyyy] or [yyyy-yyyy].

Library dropdown menu. Folder view General

CoverView section of Preferences. QUEUE

 Add next | Play next The "Add next" command adds the item immediately after the currently playing or last played

PLAYLISTS

 Save Queue to playlist The "Save Queue to playlist" command displays a list of available playlists and adds the item to the end of the selected playlist or a new playlist if one is specified.

MULTIROOM AUDIO

Add to playlist

guide

exist it will be created.

 Configuration and Spotify can be distributed by the Sender.

accessed via the 👶 button at the top of Playback view or the Receivers item in the ellipsis context menu in Playback view and on the Playbar. Networking

 Audio format The system uses 16 bit 48 kHz PCM format encoded using the Opus CODEC. Resampling if needed is handled by ALSA using the Speex converter. SPECIAL MENU ITEMS

information about the item currently being played and is divided into three sections including Input/Output, DSP and Audio Device. If its opened from the ellipsis context menu it displays metadata information about the station or track currently being played.

SPECIAL BUTTONS

Playlist that was loaded or "None".

enabled when Auto-shuffle is on.

□ Queue info

 □ CamillaDSP Quick Select Display a menu of available CamillaDSP configurations. This button appears at the top of Playback view when CamillaDSP is On. ☐ CoverView Display full screen CoverView screen saver. clicking anywhere off of the Playbar dismisses

Remove the track from the Queue after it finishes playing. Consume mode is automatically

Select random album Select a random Album for review when in Tag or Album view.

* Play a random album

Add the currently selected item in the Queue to the Favorites playlist. Playlists are listed in Library Playlist view. STATIC INDICATORS AND ACTIVE ELEMENTS

Below are the static indicators and active elements in the WebUI that perform an action when

When clicking a cover in Library Radio or Album view, or clicking the "Play random album" * button in Playback, perform the action specified for the "One touch action" setting. This setting is in the Library section of Preferences.

Renderer Active screens

 Time knob Clicking on the time while a track is playing will toggle between counting the time up or down. Clicking or dragging the time slider moves forward or backward in the track.

be set in Audio Config. Clicking the plus/minus buttons adjusts volume by 1 step. Extra metadata

Song title

In Playback clicking the Radio station name or the Artist name under the cover art switches to Radio or Tag view respectively. In Tag view the artist filter is applied. In Radio view the list is

On Smartphones swiping up scrolls the Queue into view and clicking on the Playbar returns to Playback. In Library tag view swiping sideways shows/hides the Genres column.

Close