# Physical

G54ACC

Lecture 5

richard.mortier@nottingham.ac.uk

## Signals in a Network

- Carries signals from transmitters to receivers
- Signals encode information

```
-... == "SOS" (morse)
```

- 400Hz 3.4kHz == human voice (analogue)
- -0b1000001 == 'A' (digital)
- ⊕ == 'happy'


• ...how?

- Modulation
- QAM
- Coding
- Error Detection

- Modulation
  - Coherent detection
- QAM
- Coding
- Error Detection

# Modulation (reprise)

- Amplitude modulation
- Frequency modulation
- Phase shift modulation
- Amplitude and phase



- Amplitude/Frequency/Phase shift keying
  - Use discrete set of levels/frequencies/phases
  - Just the thing for digital transmission!

### **Coherent Detection**

- Amplitude modulation can be detected/received by simply averaging the signal
  - As simple as a capacitor and a diode




- Frequency and phase modulation
  - Called coherent receivers as they lock on to frequency and phase
  - Phase Locked Loop used to recover phase by feeding back error term

- Modulation
- QAM
  - Constellations
  - Telephones
- Coding
- Error Detection

# Quadrature Amplitude Modulation


#### "Inphase"




#### Phase shift keying

Phase shift
None
¼ or 90°
½ or 180°
¾ or 270°


 $\triangle A A A$ 




#### "Quadrature"




Value	Amp	Phase
000	1	0
001	2	0
010	1	1/4
011	2	1/4
100	1	1/2
101	2	1/2
110	1	3/4
111	2	3/4




### Constellations




Way to visualize QAM schemes  $S(t) = I(t)\cos(2\pi ft) - Q(t)\sin(2\pi ft)$ 



PSK8



Circular QAM8



Circular QAM16

Rectangular QAM16 – gray code


QAM64 – high speed modems QAM256 – digital television

## Telephones

The telephone network was designed to carry

voice

- 0..5000 Hz



- The digital telephone network starts by digitizing the voice signal
  - Sample 12 bits (compressed to 8) at 8kHz
  - Nyquist theorem means we must bandlimit to < 4kHz (actually 3.4kHz is used)</li>

### 33.6k modem

3429Hz carrier and...

1664 QAM code points

This picture is ¼ of the code points

```
408 396 394 400 414
                           398 375 349 339 329 326 335 347 359 386
                   412 371 340 314 290 279 269 265 273 281 302 322 353 390
               401 357 318 282 257 236 224 216 212 218 228 247 270 298 337 378
           406 350 306 266 234 206 185 173 164 162 170 181 197 220 253 288 327 379
           360 310 263 226 193 165 146 133 123 121 125 137 154 179 207 242 289 338 391
       384 324 277 229 189 156 131 110 96 87 83 92 100 117 140 172 208 254 299 354
       355 294 243 201 160 126 98
                                  79 64 58
                                             54 62 71 90 112 141 180 221 271 323 387
13 392 330 274 222 177 135 102 77 55 41
   380 316 255 203 158 119 84
                                                      30 49 72 101 138 182 230 283 348 415
       304 244 194 148 108 75 50
                                                      21 38 63
                                                                 93 127 171 219 275 336 402
   362 296 238 186 142 103 69
                                                          32 56
                                                                 85 122 163 213 267 328 395
       320 261 210 167 128 94 67
                                              23 29
       343 284 232 183 149 115 89
                                                         104 129 157 195 235 285 342 399
       369 311 259 214 175 139 116 95 82 74 70 76
                                                      86
       403 345 292 249 205 176 150 130 114 107 105 109 120 136 161 191 227 268 319 373
-27
           382 332 287 250 215 184 169 153 145 143 151 159 178 202 231 264 308 358 413
-31
               377 333 293 260 233 211 200 192 188 196 204 223 245 278 312 352 404
                   383 346 313 286 262 252 241 239 246 256 276 295 325 363 407
-39
                       405 370 344 321 309 301 297 305 317 334 356 385
                              411 389 374 366 364 368 381 393
   -43 -39 -35 -31 -27 -23 -19 -15 -11 -7 -3 1 5 9 13 17 21 25 29 33 37 41 45
```

- Modulation
- QAM
- Coding
  - Scramblers
  - Block codes
- Error Detection

### Recovering the Bits

- So far looked at schemes to send a series of bits
  - Phase receivers must learn the phase
  - Amplitude receivers must deal with attenuation
  - QAM must do both
- What if all the bits to be sent are zero, or one?
  - We send a constant signal
  - After some time receivers can't tell if they are in phase or whether they are seeing ones or zeros
- Need to ensure the bits change sometimes even if the data to be sent is all ones or zeros...


## Coding – Scramblers

- Take a pseudo-random bit sequence the scrambler
  - e.g., CRC polynomial (more later)
- XOR this scrambler with the data stream at both source and destination
  - But what if someone tried to send the pseudo-random bit sequence as the data!
  - In the phone network the trunks carry audio samples from many different phone calls
  - Very low probability that the data to be carried will conspire to counteract the scrambler
- Scramblers
  - Widely used in the traditional digital telephone network
  - Traditionally not used much in computing

# Coding – Block Codes

Map bit or bits to be transmitted to more bits...

"1b2", Manchester encoding,  $0 \rightarrow 01$ ,  $1 \rightarrow 10$ 



#### 4b5, 16 symbols, 32 code words

- FDDI, 100Mbps Ethernet
- Some other code words used for control (e.g. token)

#### 8b10b, 256 symbols, 1024 code words

 Gigabit Ethernet, PCIExpress (up to v3.0), Serial ATA, USB 3.0, DVB, DVI, HDMI, DAT, ...


64b66b – Actually a scrambler with a 2 bit preamble...

10GigE, actually just about everything 10G...

- Modulation
- QAM
- Coding
- Error Detection
  - Parity
  - Hamming
  - CRCs
  - Reed Solomon


### **Error Detection**

- Think of the 4b5b coding what if I get 10001?
  - Was that a 1 bit error from 10101 or 10011?
  - Or 2 bits...? Or 3...?
- Who knows but I know there was an error



## Parity

- 00100100 0
- Simple bit parity per byte/word spots odd number of bit flips (1 being common!)
  - Common anywhere in a Si chip that you have memory (registers, cache, etc).
- 2D parity can correct single bit errors



### **More Codes**

2-out-of-5 codes – detect single bit errors

#### **Hamming Codes**

- A general class of codes
  - Correct single bit errors or detect single and 2 bit errors
  - Have the rule  $d+p+1 \le 2^p$ , d data bits, p parity bits
  - (7,4) is the canonical one...
- For data bits d<sub>1</sub>d<sub>2</sub>d<sub>3</sub>d<sub>4</sub> transmit p<sub>1</sub>p<sub>2</sub>d<sub>1</sub>p<sub>3</sub>d<sub>2</sub>d<sub>3</sub>d<sub>4</sub> where:
  - $p_1 = d_1 + d_2 + d_4$
  - $p_2 = d_1 + d_3 + d_4$
  - $p_3 = d_2 + d_3 + d_4$
  - You need to change 3 bits to map any valid code to another one
- This is known as the Hamming Distance

SECDED – a (72,64) Hamming code – much used by DRAM...



# Cyclic Redundancy Check, CRC

### Summary

- View data as a binary polynomial, D
- Choose generator polynomial, G of length r+1
- Calculate the remainder R = D.2<sup>r</sup>/G
- Transmit D\*2<sup>r</sup> + R
- At receiver,  $(D*2^r + R)/G = 0$  or there's an error

# **CRC Worked Example**

• G = 1001 (r = 3) can be viewed as:

$$1.x^3 + 0.x^2 + 0.x^1 + 1.x^0 = x^3 + 1$$

- D = 101110
- Hence R = 011

• Transmit 101110011


101011
001/101110000
1001
101
000
1010
1001
<del></del>
000
1100
1001
1010
1001
011

# Why CRCs?

- Good provable properties of error detection
- Easy to implement in hardware
  - CRC-CCITT 16

• 
$$G(x) = x^{16} + x^{12} + x^5 + 1$$

Used in X.25, HDLC



- A bit grim in software
  - Sometimes have CRC instruction
- But very popular, e.g., CRC32

$$G(x) = x^{32} + x^{26} + x^{23} + x^{22} + x^{16} + x^{12} + x^{11} + x^{10} + x^{8} + x^{7} + x^{5} + x^{4} + x^{2} + x + 1$$

All 802.3 (Ethernet, WiFi)

## Another Everyday Code

- Reed Solomon (as originally described)
  - Message is a binary polynomial (again!) of length k
  - Evaluate the polynomial at n distinct points (n > k)
  - Send the *n* values
  - Can recover if I receive any k
  - Hamming distance is n-k+1
- CDs interleave results of two RS codes
  - (32,28) and (28, 24)
  - Can recover from 4000 bit error bursts
  - Or a scratch 2.5mm on the CD
- RS coding used for deep space transmissions to spacecraft

- Modulation
  - Coherent detection
- QAM
  - Constellations
  - Telephones
- Coding
  - Scramblers
  - Block codes
- Error detection
  - Parity
  - Hamming
  - CRCs
  - Reed Solomon

## Summary

- Modulation introducing QAM
  - Widely used in radio and "copper"
  - Uses coherent detection
  - Constellation diagrams
- Underlying demodulator needs signal changes to work
  - Scramblers and block codes can be used
- Block codes get us into error detection and correction
  - e.g., Parity, Hamming Codes, CRC, Reed Solomon

### Quiz

- 1. What purpose does *modulation* serve?
- 2. Give three characteristics of a carrier signal that can be modulated?
- 3. Draw the constellation diagram of a modulation scheme, and describe what the different parts of the diagram mean.
- 4. What purpose does *coding* serve?
- 5. Describe the operation of a simple scrambler coding, using a diagram.
- 6. Show the binary encoding of the string "G54ACC" using ASCII and 1b2.
- 7. What bits would be transmitted when the result of (6) was transmitted using even parity and 2D even parity? What are the trade-offs between each scheme?
- 8. Using the CRC defined with r=3 and  $G=x^3+x+1$ , encode the message 11010011101101.
- 9. What does the CRC allow the receiver to do on receipt of a message? How does Reed-Solomon improve on this?