# Contents

1	Top	Topic Summary			
	1.1	Architecture	1		
	1.2	Labs	1		
		1.2.1 Lab 02	1		
		1.2.2 Lab 03	2		
		1.2.3 Lab 04	2		
		1.2.4 Lab 05	2		
		1.2.5 Lab 06	2		
		1.2.6 Lab 07	2		
	1.3	Other Stuff	2		
2	Lecture 27.01.2020				
3	Lab 29.01.2020				
4	Lecture 03.02.2020				
5	Lecture 10.02.2020				
6	Lab 12.02.2020				
7	Lecture 17.02.2020				

# 1 Topic Summary

## 1.1 Architecture

- registers
- program counter
- condition codes
- status codes
- processing cycle
- pipelining
- forwarding
- cutting in line
- out-of-order execution

## 1.2 Labs

## 1.2.1 Lab 02

• lea <var>(%rip) %<reg>: load effective address, <var>(%rip) 64 bit address of the next instruction, basically loads the memory address of the variable into the specified register

• xor %eax, %eax: this sets the return value of a function to 0, %eax holds the return values of functions, needs to be set before the function returns

#### 1.2.2 Lab 03

• mov <var>(%rip) %<reg>: reads the specified variable from memory and puts it into the register

## 1.2.3 Lab 04

- push %rbp: push the frame pointer of the previous stack frame unto the stack
- mov %rsp, %rbp: move the current stack frame address to the frame pointer, %rsp always points to the stop of the stack
- leave: undoes the two previous steps
- mov %rbp, %rsp, pop %rbp: does the same thing as leave

#### 1.2.4 Lab 05

- sub \$0x8, %rsp: this reserves some space on the stack for local variables to call the functions
- add \$0x8, %rsp: frees the space that was previously allocated
- call scanf@plt: procedural linkage table, contains the address of where scanf is relative to the program, makes function reuse easier

## 1.2.5 Lab 06

- call <func>, ret: call pushes the return address onto the stack, return pops it off again to return to where the function was entered
- cltq: convert long to quad, basically a cast from int to long in c

## 1.2.6 Lab 07

- jmp: jumps to the label specified, can be used with conditions
- cmp: compares two registers, tells if equal, smaller or larger, can be used to condition jump instructions
- different from call, this does not push or pop addresses, it just jumps to different parts of the code
- test vs cmp: test is a bitwise and while cmp is an arithmetic operation test <reg>, <reg> == cmp <reg>, 0

## 1.3 Other Stuff

- .global labels
- %eax being set to zero

- section of assembly code (.section)
- why we need push %rbp to call puts@plt
- push %rbp and then mov %rsp, %rbp
- subtracting 8 from base pointer and then adding it back at the end
- what does lea var(%rip) do exactly
- what does leave do
- what does ret do
- order of registers for arguments to functions
- multi-register operations
- int x 0, 0
- plt
- position independent code
- got (global offset table)
- syscall vs call
- call functions
- jumps
- loops using labels

Chapter 1.1 to 1.10

Chapter 4.1 to 4.3

## 2 Lecture 27.01.2020

Class was cancelled

# 3 Lab 29.01.2020

- logging into the server or setting up the working environment
- we'll work with assembly files and then go ahead with stuff
- well do some linking and just optimizing a bit of asm
- Oplt is some table that allows you to call functions from outside of your program
- topic is position independent code, look that up
- plt table has the locations of all the functions that you might want to call from you program
- got global offset table works with plt to make it happen
- xor %eax, %eax can also be used instead of mov \$0, %rax, xor with itself sets all the bits to zero in %eax
- %eax is half of %rax, meaning that we can set %rax to zero by calling xor on %eax
- well use syscall in lab 3 to do some stuff
- look at the syscall docs linked in lab 3
- number 03 will not be on the exam

## 4 Lecture 03.02.2020

- we are going to try to link the labs and the lectures together
- we're going to chapter 4 and x86-64 architecture
- learning an ISA
  - if you know how the processor works helps you understand how the whole computer works
  - understanding how CPUs work can help you write better code as well
  - helps one make decisions on hardware design
  - maybe some of us will work on actual CPU design
- registers are used as super fast short term storage
- program counter keeps track of the instructions that are being executed at the moment
- condition code
- status code indicates the overall state of the programs execution
- Y86 has immediate to memory, register to memory, memory to register, register to register moves
- logic gates are the basic components of a CPU and a PC in general, how they work
  is not to complicated at the basics, but it gets super complex if you have billions of
  them

```
hello world.c
    #include <stdio.h>
    int main() {
        puts("Hello, World!\n");
        return 0;
    }
hello_world.asm
    main:
                 $8,
                        %rsp
        subq
        movl
                $.LCO, %edi
                puts
        call
                        %eax
        movl
                $0,
                 $8,
                        %rsp
        addq
        ret
sum.c
    long sum(long *start, long count) {
        long sum = 0;
        while (count) {
            sum += *start;
            start++;
            count--;
        return sum;
    }
```

#### sum.asm

```
sum:
    movl
             $0,
                      %eax
              .L2
    jmp
.L2:
             (%rdi), %rax
    addq
                       %rdi
    addq
             $8,
             $1,
                       %rsi
    subq
.L3:
             %rsi,
                       %rsi
    testq
    jne
              .L3
    rep; ret
```

## 5 Lecture 10.02.2020

- every processing cycle does
  - fetch:
    - \* many modern CPUs fetch hundrets of instructions in one go and then runs through all them, they are saved in L1 cache
    - \*
  - decode:
  - execute:
  - memory:
  - write back:
- fetch and write back can be combined into one thing
- each cycle the PC (program counter) is incremented
- pipelining can be somewhat compared to a car factory you perform the first step of the first instruction moving on to the second step, then you perform the first step of the second instruction and so on
- this can be very efficient because there is little time being wasted
- forwarding, pipelining, cutting in line, and the other techniques

## 6 Lab 12.02.2020

- you go to labels for conditionals and simple functions: <name>:
- when you call the function by call <name> it jumps there and executes the code
- two types of jumps: conditional (depends on some condition), unconditional (it jumps in any case)
- why does the lab not work?

## 7 Lecture 17.02.2020

• we will review stuff before the midterm

- midterm will be on chapters 1, 2, 3, and a little bit of 4
- bits and bytes will be the topic for today
- 0x01234567 stored as
  - 01 | 23 | 45 | 67 in big endian
  - 67 | 45 | 23 | 01 in little endian
- three types of notations
  - unsigned notation standard binary or hex encoding
  - signed notation (two's complement) inverting digits and adding one to represent negative numbers
  - floating point mathematical/scientific notation of numbers with rational number and exponent
- types might not be the same length of bits between different machines and operating systems super important to keep that in mind when dealing with this kind of stuff
- we can do bit shifting x >> 4 to the right or x << 4 to the left, for example 0101 0111 >> 4 = 0000 0101
- arithmetic shifting 10010101 >> 4 = 11111001 uses the digit in the left most place to fill the new places
- bit masking using & like 0x25AF3255 & 0x00FF0000 = 0x00AF0000
- remember little and big endian big endian means that the most significant bit comes first, little endian means that the least significant bit is first
- & logical and, | logical or, ^ logical xor, ~ logical not
- read Chapter 2
- overflow is a thing as well two positive numbers added together could yield a negative result for example we need to pay attention to that