

SHOP

BLOG

DOCUMENTATION


FORUMS

The PiWatcher

A watchdog for the Raspberry Pi



The **PiWatcher** is a very small board that helps you fully shut down or reboot a Raspberry Pi, in case of an incident or simply for power saving purposes. You can even program your **PiWatcher** to shut down and automatically reboot your Pi a few minutes or hours later. In essence, the **PiWatcher** is a programmable watchdog circuit for the Raspberry Pi, usable with the humble Pi Zero up to the powerhungry Pi 3. The new version released in January 2020 also works with the Raspberry Pi 4.



The board must be fitted on the first 6 pins of the Raspberry GPIO header and plugged into a micro USB power supply suitable for the Raspberry Pi in use. The board will then switch on or off the power provided to the Raspberry Pi based on instructions it receives through I2C. The board also features a miniature tact switch to allow manual control.

A solution for Raspberry Pi power management

The PiWatcher is designed to solve 2 problems with power management on the Raspberry Pi.

First, if you shut down a Raspberry Pi through software, for example by issuing a shutdown or halt command, your Raspberry Pi will cease to operate, but it does not completely shut down. Instead, it enters a quiescent state where it continues to eat 30 to 50mA, sometimes more depending on connected peripherals. This is wasteful and can become an issue in battery-powered systems.

The **PiWatcher** can be programmed to fully cut power to the Raspberry Pi after a certain delay of inactivity. For For example, you can tell the **PiWatcher** to cut power 10 seconds after a shutdown command has been issued, giving the Raspberry Pi enough time to cleanly power off.

The second issue with power management has to do with the ability to recover from situations where a Raspberry Pi becomes stuck in an unrecoverable state. While in theory, this should not happen, a long-running Raspberry Pi can get 'stuck' or 'freeze', due to software or hardware failures or even environmental factors such as heat. In some cases the least unsatisfactory approach to deal with this issue is to simply switch off and on again the Raspberry Pi, enabling the application to continue and/or send out an alert.

The **PiWatcher** can be programmed to automatically power cycle a Raspberry Pi if it does not receive a 'heartbeat' from the device after a user-selectable delay. This can allow some critical applications to continue to operate without human intervention.

Furthermore, the **PiWatcher** can be programmed to "sleep" for a certain delay after a shutdown, ranging from a few seconds to about 36 hours, before rebooting your Raspberry Pi.

The table below summarizes the power consumption of a PiWatcher connected to a Raspberry Pi (measurements were done with a Pi Zero W).


Situation	Current consumption
PiWatcher is running normally	7mA in addition to the power consumption of the Raspberry Pi (typically >130mA).
PiWatcher is "sleeping" until reboot	3mA
PiWatcher has fully shut down	>0.5mA

It has an LED and a button too!

The **PiWatcher** has an LED. When the Raspberry Pi is powered on, the LED is continuously on. When the Raspberry Pi is "sleeping" for a certain delay, the LED blinks slowly. When the Raspberry Pi is powered off, the LED remains off.

The **PiWatcher** also has a useful micro tact-switch:

- When your Raspberry Pi is running:
 - o a long press (5 seconds) on the button, followed by a button release, will completely power off the Raspberry Pi.
 - o a short press (half a second) on the button will send a software signal that can be exploited for user-defined purposes.
- When your Raspberry Pi is shut down, a short press on the button will restart the Raspberry Pi.




Alternative model with terminal blocks

As an alternative to the classic PiWatcher described in this documentation, we have also released a special version called **PiWatcher TB** where the USB connector has been replaced with a 3-pin 2.54mm screw terminal block connector.

The **PiWatcher TB** depicted in the picture below offers 3 connections:

- GND : power ground
- 5v : 5V power source
- BUTTON_ALT: optionally connect this terminal and GND to an external switch, which will act as an alternative to the on-board micro tact-switch.



Using the PiWatcher

Setup

To start using the PiWatcher, follow these steps.

Plug the **PiWatcher** in the first 6 pins of the Raspberry-Pi GPIO header. For greater mechanical stability it is recommended to secure the **PiWatcher** to the Pi with a standard 11mm standoff (2.5mm).

Next, plug the USB power supply into the PiWatcher. In turn, this will boot the Raspberry Pi.

To use the **PiWatcher** on the Raspberry Pi, you will need to enable I2C on the Raspberry Pi. Use sudo raspi-config for this purpose (as described in this Adafruit tutorial for example).

Download the piwatcher command line tool:

```
wget -N http://omzlo.com/downloads/piwatcher
```

Note: you can also compile the file yourself from source.

You'll need to make sure the file is executable and that it is located in a directory included in your PATH (e.g. /usr/local/bin on a Raspbian system).

```
chmod a+x piwatcher
sudo mv piwatcher /usr/local/bin/
```

The piwatcher tool can then be used to query and configure the PiWatcher.

Typing piwatcher status should return:

```
ОК 0×00
```

If you press the micro-switch on the **PiWatcher** and then re-run piwatcher status, you should see the following output:

```
OK 0x80 button_pressed
```

You can clear this button_press event, resetting the status of the **PiWatcher** by running piwatcher reset. Re-running piwatcher status will show again status 0x00.

Setup on older Raspberry-Pi models

The **PiWatcher** works on all recent Raspberry Pi models, except for the Pi 4. On older Raspberry-Pi models (e.g. The 2012 model B), you may encounter inconsistent behaviors with the piwatcher command because of I2C clock speed issues. To fix this problem on these older models, you will need to slow down the I2C clock from the default 100kHz to 50kHz, by editing the file /boot/config.txt and changing the following line:

```
dtparam=i2c_arm=on
```

dtparam=i2c_arm=on,i2c_arm_baudrate=50000

to:

After modifying the file, reboot your machine and you should be good to go.

Watchdog

We will now program the **PiWatcher** to shut off the Raspberry-Pi after 30 seconds if it does not receive any message from the Raspberry Pi, with the command piwatcher watch 30.

After this command has been issued, the **PiWatcher** will start a 30 second counter. If the counter reaches 0, the power to the Raspberry Pi will be cut off. However, this counter will be reset to 30 seconds each time the **PiWatcher** receives a 'read request' from the Raspberry Pi. A simple way to issue a 'read request' is to issue the command piwatcher status.

In this example, a simple way to keep the Raspberry-Pi form shutting down would be to run the following loop:

```
while true
do
   piwatcher status
   sleep 25
done
```

The sleep 25 assures that the **PiWatcher** is called approximately every 25 seconds, taking a 5-second safety margin from our 30-second deadline. If this loop gets interrupted for any reason, the Raspberry-Pi will reboot after at most 30 seconds.

This feature can be exploited to completely shut off a RaspberryPi after a shutdown. Assuming the Pi takes at most 15 seconds to shut down, we can issue the following commands:

```
piwatcher watch 15
shutdown now
```

Automated rebooting

By default, the **PiWatcher** will shut off the Raspberry Pi until the user presses the button or until USB power is cycled.

We can program the PiWatcher to "wake" the Raspberry Pi after a certain delay (expressed in seconds).

To reboot the Raspberry-Pi 10 minutes after shutdown, we would simply type:

```
piwatcher wake 600
```

A clock under the hood

The **PiWatcher** is based on a Microchip attiny45 8-bit microcontroller, which runs with an 8Mhz internal oscillator.

An internal clock ticks about 25.04 times per second (8.000.000/(8192*39)). Watchdog and reboot time values are converted to internal clock ticks by multiplying their value by 25. Because of variations in temperature and voltage, the accuracy of these timings may be off by +/-10%.

You can view the actual value of the clock by issuing the command piwatcher ticks.

Running piwatcher automatically

In most cases, you don't want to type commands with <code>piwatcher</code> each time your Raspberry Pi boots up. Instead, you will want to run PiWatcher automatically each time the Raspberry Pi boots up, with the correct configuration. Fortunately, this is rather easy thanks to <code>systemd</code>.

As an example, we will consider the case where you want the Raspberry-Pi to fully shut down automatically after 30 seconds of inactivity, either because you've halted it or because it got 'stuck'.

For simplicity, we will assume you are running a recent version of Raspbian Linux and that you have installed the <code>piwatcher</code> binary in the directory <code>/usr/local/bin/</code>.

It takes 3 steps to implement our scenario.

STEP 1. Create a monitoring script

Use your favorite editor to create the file /home/pi/piwatcher.sh with the following content.

```
#!/bin/bash

/usr/local/bin/piwatcher watch 30

while true;
do
    /usr/local/bin/piwatcher status >> /dev/null
    sleep 15
done
```

This will essentially set a 30-second watchdog, and start an infinite loop that sends a message to the piwatcher every 15 seconds to assure that the watchdog is not triggered.

We need to make this script executable as follows.

```
chmod a+x /home/pi/piwatcher.sh
```

STEP 2: Create a new systemd service

Now we will create a systemd service for the previously created script. As we need 'root permission' to create the script, we will use sudo:

```
sudo vim /etc/systemd/system/piwatcher.service
```

You can replace vim with nano or your favorite editor in the line above.

The content of the file should look as follows.

```
[Unit]
Description=PiWatcher Service
StartLimitIntervalSec=0

[Service]
Type=simple
Restart=always
RestartSec=1
User=pi
ExecStart=/home/pi/piwatcher.sh

[Install]
WantedBy=multi-user.target
```

STEP 3: Activate and start the service

Finally, we will activate the service.

sudo systemctl enable piwatcher

This will typically output the following message: "Created symlink /etc/systemd/system/multi-user.target.wants/piwatcher.service \rightarrow /etc/systemd/system/piwatcher.service."

We will also start the service, as follows.

sudo systemctl start piwatcher

The activation (and start) only needs to be performed once. The piwatcher will now be launched automatically each time the machine boots up.

I2C specification

The **PiWatcher** uses an extremely simple communication protocol based on I2C. The board essentially features an 8-byte register array that can you can read to or write from, at I2C address **0x62**.

This register array is structured as follows:

Register	Description
0	Status byte
1	Watchdog timeout in seconds, 0=disabled.
2-3	Wakeup delay in seconds divided by 2 (5 means 10 seconds). LSB first. 0=disabled.
4-7	Internal clock. LSB first.

The status byte has the following structure:

Position	Name	Description
Bit 7	BUTTON_PRESSED	A 1 indicates that the PiWatcher button has been pressed. Writing a 1 will clear the bit.
Bit 6	TIMER_BOOT	A 1 means that the PiWatcher rebooted the Pi after a wake-up period. Writing a 1 will clear the bit. This is unreliable however since the PiWatcher may have reset.
Bit 5	BUTTON_BOOT	A 1 means that the PiWatcher rebooted the Pi because the user pressed the button. Writing a 1 will clear the bit. This is unreliable however since the PiWatcher may have reset.
Bit 4-0	unused	

The command ./piwatcher dump will print the raw content of all registers.

The content of the registers can be manipulated with <code>i2c-tools</code> as well (see instructions here for example). For example, you can get the status byte with the command <code>i2cget -y 1 0x62 0</code>.

Resources

- Buy a PiWatcher from our <u>store</u> or from <u>Tindie</u>.
- Schematics.
- o Source code of PiWatcher command line utility.
- Source code of PiWatcher Attiny45 firmware.
- Troubleshooting guide

Comments

Hi Omzlo,

Got my PiWatcher soldered and installed, confirmed it works. I intend to use the PiWatcher to power down a Raspberry Pi Model 3 B that I'm using as an OctoPrint host for my 3D printer, when I select system shutdown from OctoPrint.

Although I'm a software developer with some Linux experience, I'm a Raspberry Pi novice, so I'm a bit lost as to how/where to save and configure the watchdog script! - can you provide a more complete example, i.e. where to save the script on the Pi so it runs on startup, etc., or point me to online resources/help/tutorial?

Thanks Philip

Philip Steiner, over 1 year ago

@Philip: We added a section to address your question: https://www.omzlo.com/articles/the-piwatcher#running-piwatcher-automatically

Omzlo, over 1 year ago

Brilliant! Script & piwatcher service works just like it says on the tin. Thanks so much for the detailed instructions!

Regards, Philip

Philip Steiner, over 1 year ago

Three days delivery from Grece to Belgium! Just fantastic. Let's try it now. Marc

Marc, over 1 year ago

Hi Omzlo,

I ordered the PiWatcher and have tested it works as you described. It looks very much like the right product to solve my problem. (The problem is that I have a 1-Wire network where the sensors occasionally [sort of once per 45 days] disappears from the network, and the only way of getting them back is to power cycle the whole rPI).

A question: My 1-Wire network master is a full size expansion board to the rPI (Abiowire: https://www.axiris.eu/en/index.php/1-wire/abiowire).

Now, the AbioWire card does not "continue" the 40 expansion pins of the rPI, so I cannot put PiWatcher on top of it. And if I put the PiWatcher under it... then PiWatcher uses only 3 of the 40 pins... and I have no pins to connect the AbioWire to.

How to solve?

The more general form of the question is how to connect multiple expansion boards to the 40 pin expansion bus. In the case with PiWatcher it is slightly different, since it only uses 2x3=6 pins on one side.

Thanks for quite a useful product. Arne S.

Arne Steinarson, over 1 year ago

Hi, Does the PiWatcher fit the Raspberry Pi 4? There could be two issues: 1. heatsink (integrated in case?) on CPU may get in the way. 2. Raspberry Pi 4 current consumption may be too high for the PiWatcher switches (those tiny MOSFETs) ...

I wonder

Arjen Raateland, over 1 year ago

Is PiWatcher with CE marking? kind regards

massimo, over 1 year ago

@Arjen Raateland: We have tested the PiWatcher on the Raspberry Pi 4, running for several days without any issue, but we never used a heatsink. We also did some CPU stress tests, to boost current consumption and again it all worked fine. The Mosfet, which is rated up to 5A, warms just a little. However, we would not recommend pushing the current consumption above 2A, by avoiding to plug too many external peripherals.

Edit: The PiWatcher is not recommended for the Raspberry Pi 4, as it may not perform as expected.

Omzlo, over 1 year ago

@massimo: the PiWatcher is not currently with CE marking.

Omzlo, over 1 year ago

Will this unit work with the pi 1B. Have several of these older units providing remote access to radio recievers. The basic ups installed does a good job of handling momentary power outages which are common but i need something to shut them down safely during longer outages.

Thanks

Keith, over 1 year ago

Ree Pi 4. Do you plan to release a version that will work with the Pi 4?

Scott Butler, over 1 year ago

@Scott Butler: Yes, we have a working prototype that is compatible with the Pi 4.

omzlo, over 1 year ago

What's the longest wake interval?

lan Boag, over 1 year ago

Hello

I have a question, I want to order a product from your webshop. but i can not find it anymore on your site, it looks like this picture on this site http://bit.ly/snowborditems343 Mail me if you are going to sell it again. I'll wait.

Sincerely

"Sent from my iPhone"

Hector Tompson, over 1 year ago

Hi Omzlo, we try to buy others PiWatcher but link to your shop seems not working and PiWatcher on Tindie are out of stock. What the situation? Kind regards.

Massimo Nannizzi, about 1 year ago

@Massimo: We are currently out of stock. We expect to have new stock in two weeks.

omzlo, about 1 year ago

Hi, Purchased a few piWatchers, all my pis have these oled screens wired up to display status in a rack. Any tips as to whether I can use the piWatcher alongside the oled screens?

 $\label{lem:https://www.amazon.co.uk/gp/product/B07BY6QN7Q/ref=ppxyodtbsearchasin title? ie=UTF8 \& psc=1$

Thanks!

Dan, about 1 year ago

The piwatcher page in the store says it works with RPi4. This page says it does not. Which is it?

Michae, 12 months ago

@Michae: Thanks for catching that. The new version we released in January 2020 works with the Pi4. The previous one didn't.

omzlo, 12 months ago

Mechanical engineer here, can you provide length, width, and height of the board, as well as dimensions for the included header?

Catherine, 11 months ago

Dear Sir,

I ordered couple of piwatcher. I installed at Raspberry PI 4. After I executed piwatcher wake and piwatcher watch, the piwatcher dump command always show zero for all bits.

Is there any clue for this?

dwi kristianto, 10 months ago

Hi. Is it possible to schedule it for turning Pi (cm3+ with board with UPS HAT) on after it was turned off by out of battery condition? I have Rpi with dumb UPS (it just provide power and has a power button and that is it - no possible to turn off rpi in case of batteries out energy, 52pi old model UPS EP-0114) and when there is no external power for some time it just cuts power. To turn it on power button should been pressed.

Thanks for your time!

Alex, 9 months ago

1 thing that tripped me up when I first got a piwatcher was I would get

Failed to open i2c device 1

ERR

when running piwatcher status. I do not use the pi default user in my builds so I have to use sudo a lot more. Using sudo piwatcher status I get the correct "OK 0x00"

GeekDom, 8 months ago

Hi, does the piwatcher script has a test feature via CLI?. Would like to simulate a hardware lockup to see if it is actually working before i deploy these all over.

Thanks

Phil, 8 months ago

Was the USB module updated on the new version or it's still micro usb?

Salman, 8 months ago

@Phil: No the PiWatcher does not have a test feature, though that's certainly a good idea to add in the next version.

Omzlo, 8 months ago

@Salman: It's USB micro still. USB-C will likely come in the next version.

Omzlo, 8 months ago

The piwatcher covers pins 1-6. Do the headers allow for expansion so that you can use the power/SDA/SCL pins for your projects? I can't figure this out by looking at the pictures ;-)

Onno, 8 months ago

Hi, happy customer here, using a PiWatcher to control power on a Raspberry Pi 3 Model B+running as an Octoprint server. I plan to set up another Octoprint server, this time using a Raspberry Pi 3 Model A+. It appears to have the same pinouts as the Model B+ and Zero, so do you think PiWatcher will work on the A+? Thanks again!

Philip Steiner, 8 months ago

Just got my order of 2 of the new version piwatchers. Working perfectly! Thanks for such a great product.

Don, 7 months ago

Wow! Excellent, "five star" product for my needs (having some Raspberry Pis running unattended at my home automation system days and nights...) and very good documentation + instructions. So cheap, too :-) I'm very pleased about Your good documentation and guide practice; it definetively plays in a big role when purchasing Raspberry (or Arduino) products. I had absolutely no problems to get PiWatcher up and running :-)

The instruction section "how-to-run-piwatcher-automatically" section is very good, since it is also a good starting point for someone wanting to learn more about the subject when this kind of behaviour is needed with other programs (it's very typical need at unattended systems and systemd is the best choice for the job at Linux based systems).

May I suggest one thing: Could You consider to provide 2 extra holes on the board (next revision?) to make it easier to add an extra button further from the board to replace the function of the micro one?

Yrjö Seppä, 5 months ago

Will this unit work with modification on the pi 1 boards?

Ben, 3 months ago

The command line looks great for the setup of the device. As it appears to be just an I2C interface... One assumes the heartbeat is just a command on the I2C channel that the hardware is monitoring... Is there any python sample that could be used as a demonstration on how this could work. I have no issues with setting it up via command line in a batch at startup - but I would love to send the heartbeat from my python code to ensure that has not hung...

Keith, 3 months ago

Leave a comment

Name
Email (not published)
Your comment
Value and use a subset of markedown horoulinks images and bird are discabled however
You can use a subset of markdown here: links, images and html are dissabled however.

INFORMATION

FOLLOW US

About Omzlo P.C.

POST COMMENT

F9 58 51

(c) Omzlo P.C. 2021 🖺