CENG 355 Microprocessor-Based Systems Lab Project

Tayler Mulligan V00819591 Raymond Bamford V00000000

Nov 24, 2016

Contents

Abbreviations Glossary				
2	Design Solution			
	2.1	Plann	ing	1
			Work Partitioning	1
		2.1.2	Technique and Technologies	1
	2.2	Implei	mentation	2
			ADC Initialization	$\overline{2}$
			DAC Initialization	3
			LCD Initialization	4
		2.2.4	Frequency Monitor Initialization	7
		2.2.5	LCD Implementation	8
	2.3		Procedures	10
3	Disc	Discussion		
$\mathbf{A}_{\mathbf{J}}$	ppen	dices		11
\mathbf{A}	Source Code			
	A.1	Main		11
			g	13
			~ 	18

List of Figures

Abbreviations

 ${f ADC}$ analog-to-digital converter. iv, 1–3

CPHA clock phase. 5, see: SPI

CPOL clock polarity. 5, see: SPI

CR control register. 4

CRC cyclic redundancy check. 6

 \mathbf{DAC} digital-to-analog converter. 1–4

EXTI1 external interrupt line 1. 8

GPIO general purpose input output. 2

GPIOx GPIO port x. 1, see: GPIO

IC integrated circuit. 1

LCD liquid crystal display. iii, 1, 2, 4–6, 9, Glossary: liquid crystal display

LCK lock. 4, 9

MOSI master output, slave input. 4, see: SPI

MSB most significant bit. 6

NVIC nested vector interrupt controller. 8

SCK serial clock. 4, see: SPI

SoC system on a chip. iv

SPI serial peripheral interface. 1, 4–6, 9

TIM2 general purpose timer 2. 7, 8

TIM3 general purpose timer 3. 5, 9

UI user interface. 6

Glossary

HSI14

The 14 MHz high speed interconnect clock supplying the analog-to-digital converter (ADC)'s clock. $3\,$

liquid crystal display

a visual display utilizing a layer of liquid crystal between two electrodes that become opaque when a voltage is applied. iii, $\mathbf{1}$

STM32F0DISCOVERY

A system on a chip (SoC) developed by STMicroelectronics providing a development board based on a Cortex-M0 microprocessor. $1,\,2$

1 Problem description

The purpose of this lab is to design an embedded system to create an open-loop control system, where the position of a potentiometer is measured and a frequency dependent on the measured resistance, with the frequency produced through a 555 timer-based circuit. Systems and components in this lab include embedded programming of an STM32F0 Discovery board, electrical circuit design of the variable-frequency 555 timer-based astable circuit, digital-to-analog and analog-to-digital converters, and serial peripheral interface (SPI) for inter-integrated circuit (IC) communication between the microprocessor and the liquid crystal display (LCD) board; the system was built on an STM32F0DISCOVERY ARM platform.

2 Design Solution

2.1 Planning

2.1.1 Work Partitioning

Based on experience from the first lab, and personal preference, lab work was partitioned accordingly. The project was split into the embedded programming and accessory circuit design/implementation, where the majority of the embedded programming was assigned to Tayler Mulligan and the accessory timer circuit to Raymond Bamford. The partitioning was not strict, with members collaborating where necessary or convenient.

2.1.2 Technique and Technologies

Git and GithHub were utilized for the project to provide team access and syncing between lab computers (see https://github.com/tamul/ceng355-lab-project). The source code was split into three files: main.c (see A.1), containing the main program; analog.c (see A.2), containing ADC, digital-to-analog converter (DAC), and frequency monitoring code; and lcd.c (see A.3), containing code related to the LCD; each with corresponding header files. Each file provided initialization functions for the components and abstracted functions to control the components, such as:

```
void spi_init(void),
void lcd_cmd(uint8_t data),
void lcd_char(char c),

  etc. in lcd.h; and:

void dac_init(void),
void adc_init(void)
uint16_t adc_read(void),
void dac_write(uint16_t),
```

etc. in analog.h. See the attached listings in the appendices for complete definitions and declarations.

2.2 Implementation

The main program called functions provided by analog.h and lcd.h to sequentially initialize each component. Components were initialized in the order of: the ADC, the DAC, the LCD, and the frequency monitor.

Listing 1: Initialization order

```
trace_printf("%s", "Initializing ADC...");
      adc init():
      adc_enable_pot(1);
45
      trace_puts("Done");
      trace_printf("%s", "Initializing DAC...");
      dac_init();
      trace_puts("Done");
50
      trace_printf("%s", "Initializing LCD...");
      lcd_init();
      trace_puts("Done");
      trace_printf("%s", "Initializing frequency monitor...");
55
      freq_init();
      trace_puts("Done");
```

2.2.1 ADC Initialization

Initialization of the glsadc requires initialization of the general purpose input output (GPIO) (port C) interface (to control the POT_EN signal of the Project Board), GPIOC (to read the potentiometer value), and the glsadc. The C code in Listing 2 comprises the initialization of the GPIOC register for the glsadc.

Listing 2: GPIO configuration for ADC

Firstly, the GPIOC clock is ensured to be running, followed by configuration of the pins. The pins are put in a push-pull output configuration at the highest speed, without any pull-up or pull-down resistors. The GPIOA clock is guaranteed to be running as the communication between the computer and STM32F0DISCOVERY are over the parallel A ports. The PA0 pin is set to

"analog" mode.

Listing 3: ADC configuration

```
/* Enable the HSI14 (ADC async) clock */
50
            RCC->CR |= RCC_CR_HSION;
            RCC->APB2ENR |= RCC_APB2ENR_ADCEN;
            /* Start up the ADC */
55
            ADC1->CR = ADC_CR_ADEN;
            /* ---- Configure the ADC ---- */
            /st Set the ADC clock to the dedicated clock st/
            ADC1 -> CFGR2 &= ^{\sim} (0x00);
            /* Select the input channel */
60
            ADC1->CHSELR = ADC_CHSELR_CHSELO;
            /* Set continuous conversion mode */
            ADC1->CFGR1 |= ADC_CFGR1_CONT;
            /* Enable starting with software trigger */
            ADC1 -> CFGR1 &= ~ADC_CFGR1_EXTEN;
65
            /* Disable auto-off */
            ADC1 -> CFGR1 &= ~ADC_CFGR1_AUTOFF;
70
            /* Wait for the ADC to stabilize */
            while(!(ADC1->ISR & ADC_ISR_ADRDY));
            /* Start converting the analog input */
            ADC1->CR |= ADC_CR_ADSTART;
   }
```

Next the ADC proper is initialized: the C code in Listing 3 accomplishes this. The HSI14 clock, which supplies the ADC's clock, is enabled and the glsadc started in preparation for configuration. Lines 57-68 configure the glsadc: setting the clock as the dedicated (HSI14) clock, selecting input channel 0 (corresponding to parallel port A0), continuous conversion mode is enabled to continuously provide the digitized value of the PA0 pin. Finally, the function triggers conversion to start after waiting until the glsadc reports that it has stabilized.

2.2.2 DAC Initialization

Enabling the DAC requires configuration of the PA4 pin and initialization of the DAC clock. Listing 4 shows the C code initializing the DAC.

Listing 4: DAC configuration

```
/* Enable the DAC clock */
RCC->APB1ENR |= RCC_APB1ENR_DACEN;
90     /* Enable the DAC (with output buffering and auto-
triggering */
DAC->CR = DAC_CR_EN1;
}
```

The mode of PA4 is set to an open-drain analog output, allowing a variable voltage to be placed on PA4, with pull-up and pull-down pins disabled, at the highest speed setting to ensure the pin updates quickly. Next, the DAC's clock is enabled and the DAC enabled by writing the DAC's control register (CR)'s enable bit.

2.2.3 LCD Initialization

To initialize the LCD, the spi, GPIOB, and GPIOC clocks are all initialized (Listing 5).

```
Listing 5: SPI, GPIOB, GPIOC clock enable
```

The lock (LCK) pin (PC2) of the SPI shift-register is set to output mode, and the master output, slave input (MOSI) (PB5) and serial clock (SCK) (PB3) SPI pins are set to alternate function mode (Listing 6).

Listing 6: SPI pin mode configuration

Each SPI related pin is set to push-pull mode with pull-up and pull-down resistors disabled and high-speed mode (Listing 7).

Listing 7: SPI pin output configuration

```
/* Set PC2, PB3, PB5 to push-pull mode */
GPIOC->OTYPER &= ~GPIO_OTYPER_OT_2;
GPIOB->OTYPER &= ~GPIO_OTYPER_OT_3;
GPIOB->OTYPER &= ~GPIO_OTYPER_OT_5;

/* Disable pull up/down resistors on SPI pins */
```

```
GPIOB->PUPDR &= ~GPIO_PUPDR_PUPDR3;
GPIOB->PUPDR &= ~GPIO_PUPDR_PUPDR5;

40 GPIOC->PUPDR &= ~GPIO_PUPDR_PUPDR2;

/* Set SPI pins to high-speed */
GPIOB->OSPEEDR |= GPIO_OSPEEDR_OSPEEDR3;
GPIOB->OSPEEDR |= GPIO_OSPEEDR_OSPEEDR5;

45 GPIOC->OSPEEDR |= GPIO_OSPEEDR_OSPEEDR2;
```

After configuring the output pins, general purpose timer 3 (TIM3) is configured, allowing SPI writes to be delayed and the LCD time to complete the commands sent:

Listing 8: TIM3 configuration

```
/* Initialize TIM3 */
             /* Enable the TIM3 clock */
             RCC->APB1ENR |= RCC_APB1ENR_TIM3EN;
             /* Configure TIM3 with buffer auto-reload, count down,
50
              * stop on overflow, and only interrupt on overflow
             TIM3 -> CR1 = 0xC6;
             /* Set clock prescaler value */
             TIM3->PSC = TIM3_PRESCALER;
             /* Set auto-reload delay */
             TIM3->ARR = TIM3_AUTORELOAD_DELAY;
             /* Set timer update configuration (rising edge, etc.) */
             TIM3 \rightarrow EGR = (TIM2 \rightarrow EGR \& ~0x5F) | (0x1 & 0x5F);
60
             /* Load delay value */
             TIM3->CNT = MAX_DELAY;
             TIM3 \rightarrow CR1 \mid = 0x1;
```

The clock for TIM3 is enabled, then the clock is configured to use buffered auto-reload, count down from the set CNT register value, stop in the event of an overflow (which should never occur), and only interrupt in the event of an overflow not when the counter reaches 0. This configuration allows a value to be written to the timer which then counts down to 0, and the timer can be polled until the count is low enough (and enough time has passed), then allowing another command to be sent. This avoids the potential for an overflow if the counter was initialized to zero and counted up to or past the desired value.

The prescaler is set to 0, the auto-reload delay set to the lowest possible, writing to the EGR register is a carry-over from other timer initializations and is not necessary in this case; then, the MAX_DELAY value (the maximum time the LCD will take to execute a command) is loaded into the timer's CNT register, and the timer finally started. This timer is utilized by checking the CNT value rather than the updates generated for the purpose of allowing a potentially shorter delay. In the end this potential for a shorter delay was not utilized, however checking the CNT register rather than an update bit was retained.

Next, in Listing 9, SPI is configured and enabled with: unidirectional transmit, master mode, a data-size of 8 bits, clock polarity (CPOL) and clock phase (CPHA) are set for a falling edge clock pulse, software chip select, a 256 baud-

rate prescaler, most significant bit (MSB) first output, and a 7 bit cyclic redundancy check (CRC) polynomial.

Listing 9: SPI initialization

```
/* Initialize SPI */
65
            SPI_InitTypeDef SPI_InitStructInfo = {
                             .SPI_Direction = SPI_Direction_1Line_Tx,
                             .SPI_Mode = SPI_Mode_Master,
                             .SPI_DataSize = SPI_DataSize_8b,
                             .SPI_CPOL = SPI_CPOL_Low,
70
                             .SPI_CPHA = SPI_CPHA_1Edge,
                             .SPI_NSS = SPI_NSS_Soft,
                             .SPI_BaudRatePrescaler =
       SPI_BaudRatePrescaler_256,
                             .SPI_FirstBit = SPI_FirstBit_MSB,
                             .SPI_CRCPolynomial = 7
75
            SPI_Init(SPI1, &SPI_InitStructInfo);
            SPI_Cmd(SPI1, ENABLE);
```

Finally, in Listing 10, the command interface and the display of the LCD are initialized: the LCD is set to a 4-bit interface with 2 lines, followed by the LCD being cleared and homed with display shift disabled and cursor movement direction set to the right, cursor blinking being disabled. The persistent, unchanging characters of the user interface (UI) are then written to the LCD.

Listing 10: LCD initialization

```
/* Set the LCD to 4 bit interface */
80
             spi_write(0x02, MAX_DELAY);
             spi_write(0x82, MAX_DELAY);
spi_write(0x02, MAX_DELAY);
             /* Set LCD to display 2 lines */
85
             lcd_cmd(0x28);
             /* Clear the LCD */
             lcd_cmd(0x01);
90
             /* Home the cursor */
             lcd_cmd(0x02);
             /* Set cursor move direction and disable display shift */
             lcd_cmd(0x06);
             /* Set the display on, don't show the cursor, don't blink
95
             lcd_cmd(0x0C);
             /* Set the cursor to move right, no display shift */
             lcd_cmd(0x14);
             /* Write 'F:
                              Hz' to first line */
             lcd_cmd(0x80); // Start at very left
100
             lcd_char('F'); //F
             lcd_char(':'); //:
             lcd_cmd(0x86);
             lcd_char('H'); //H
105
             lcd_char('z'); //z
```

2.2.4 Frequency Monitor Initialization

Initialization of the frequency monitor required the GPIOA and general purpose timer 2 (TIM2) clocks to be enabled, GPIOA port 1 configured as an input, and configuration of TIM2.

PA1 is first configured with the C code in Listing 11.

```
Listing 11: GPIOA port 1 configuration
```

The GPIOA clock is first ensured to be enabled, followed by the setting pin PA1 to input mode with pull-up and pull-down resistors disabled. TIM2 is then initialized, seen in Listing 12.

Listing 12: TIM2 initialization

```
/* Enable the TIM2 clock */
RCC->APB1ENR |= RCC_APB1ENR_TIM2EN;
/* Configure TIM2 with buffer auto-reload, count up,
    * stop on overflow, enable update events, and interrupt
    * on overflow only
    */
TIM2->CR1 = 0x8C;

110     /* Set clock prescaler value */
TIM2->PSC = TIM2_PRESCALER;
/* Set auto-reload delay */
TIM2->ARR = TIM2_AUTORELOAD_DELAY;
/* Set timer update configuration (rising edge, etc.) */
TIM2->EGR = (TIM2->EGR & ~0x5F) | (0x1 & 0x5F);
```

TIM2 is configured with a buffered auto-reload in count up mode, with stop on overflow set and updates events enabled with interrupts only enabled for overflow. This allows the timer to notify in the event of an interrupt and avoid erroneous frequencies measurements when the frequency drops below a corresponding period of approximately $90 \, \mathrm{s}$.

Next, the interrupt routines are configured through the nested vector interrupt controller (NVIC) as seen in Listing 13.

Listing 13: NVIC configuration

```
/* Assign TIM2 interrupt priority 0 in NVIC */
             NVIC_SetPriority(TIM2_IRQn, 0);
              /* Enable TIM2 interrupts in NVIC */
120
             NVIC_EnableIRQ(TIM2_IRQn);
             /* Enable update interrupt generation */
             TIM2 \rightarrow DIER \mid = 0x41;
              /* Map EXTI1 line to PA1 */
             SYSCFG->EXTICR[0] = (SYSCFG->EXTICR[0] & ~(0xF)) | (0 & 0xF
125
         );
              /* EXTI1 line interrupts: set rising-edge trigger */
             EXTI \rightarrow RTSR \mid = 0x2;
130
              /* Unmask interrupts from EXTI1 line */
             EXTI \rightarrow IMR \mid = 0x2;
              /* Assign EXTI1 interrupt priority 0 in NVIC */
             NVIC_SetPriority(EXTIO_1_IRQn, 0);
135
              /* Enable EXTI1 interrupts in the NVIC */
             NVIC_EnableIRQ(EXTIO_1_IRQn);
    }
```

The priority of the interrupt is set to 0, as it is one of only two interrupts that should be firing in this system. TIM2 interrupts are enabled in the NVIC to allow notification of overflow, and interrupt generation is enabled in TIM2. The external interrupt line carrying the external waveform, external interrupt line 1 (EXTI1), is mapped to PA1. The external interrupt line has interrupts enabled with a rising-edge trigger and interrupts for EXTI1 unmasked in the NVIC so they are processed. Finally, EXTI1 is configured to have a priority of 0 in the NVIC, and enabled.

2.2.5 LCD Implementation

Utilization of the LCD was accomplished through the void lcd_char(char c) and void lcd_cmd(uint8_t data) functions. lcd_char provides an interface to specify a character which is then translated to the proper LCD command and displayed at the current cursor position. lcd_cmd does not translate it's input, instead implementing the transmission of 8 bits of data to the LCD over the 4 bit interface. Definitions of lcd_char and lcd_cmd can be seen in Listing 14

Listing 14: LCD interface function definitions

```
void spi_write(uint8_t data, uint32_t delay) {
    /* Wait until SPI delay has passed */
    while (TIM3->CNT > ((MAX_DELAY+1) - delay));
    /* Force LCK low */

120     GPIOC->BRR |= GPIO_BRR_BR_2;
    /* Wait until SPI1 is ready */
    while((SPI1->SR & SPI_SR_BSY) && ~(SPI1->SR & SPI_SR_TXE));
```

```
/* Send the data */
             SPI_SendData8(SPI1, data);
             /* Wait until SPI1 is not busy */
125
             while(SPI1->SR & SPI_SR_BSY);
             /* Force LCK signal to 1 */
             GPIOC -> BSRR |= GPIO_BSRR_BS_2;
             /* Reset LCD comm clock */
130
             TIM3->CNT = MAX_DELAY;
             TIM3 \rightarrow CR1 \mid = 0x1;
    }
     * Write to LCD using 4 bit interface. Send 4 high bits
     * by pulsing EN, then do the same for 4 low bits
     */
    void lcd_cmd(uint8_t data) {
             /* Send HIGH bits */
140
             spi_write(0x00 | (data >> 4), MAX_DELAY);
             spi_write(0x80 | (data >> 4), MAX_DELAY);
             spi_write(0x00 | (data >> 4), MAX_DELAY);
             /* Send LOW bits */
             spi_write(0x00 | (data & 0x0F), MAX_DELAY);
145
             spi_write(0x80 | (data & 0x0F), MAX_DELAY);
             spi_write(0x00 | (data & 0x0F), MAX_DELAY);
    }
    /** Write a character to the LCD
     * Inputs:
        c: Character to write
     */
    void lcd char(char c) {
155
             /* Send HIGH bits */
             spi\_write(0x40 | ((uint8_t)c >> 4), CHAR_DELAY);
             spi_write(0xC0 | ((uint8_t)c >> 4), CHAR_DELAY);
             spi_write(0x40 | ((uint8_t)c >> 4), CHAR_DELAY);
             /* Send LOW bits */
160
             spi_write(0x40 | ((uint8_t)c & 0x0F), CHAR_DELAY);
             spi_write(0xC0 | ((uint8_t)c & 0xOF), CHAR_DELAY);
             spi_write(0x40 | ((uint8_t)c & 0x0F), CHAR_DELAY);
    }
```

Both commands split the 8 bits of data to be sent into 4 bit packets to be sent over the 4 bit interface: where 4 bits of the data sent are control bits and 4 bits are data. The difference between the two commands resides in the control bits, where lcd_char has the bit LOW whereas lcd_cmd send a HIGH bit.

Both functions utilize void spi_write(uint8_t data), a function providing an abstracted interface to utilize the 74HC164 serial-in, parallel-out shift register which interfaces with the LCD. The command ensures suitable time has passed by polling TIM3, where it then sets the LCK signal LOW, loads the data into the shift register over SPI before finally setting the LCK pin HIGH again and resets the TIM3 delay counter.

- 2.3 Test Procedures
- 3 Discussion

References

Appendices

A Source Code

A.1 Main

```
src/main.c
   // This file is part of the GNU ARM Eclipse distribution.
   // Copyright (c) 2014 Liviu Ionescu.
   11
   //
   #include <stdio.h>
   #include <stdlib.h>
10 #include "diag/Trace.h"
   #include "stm32f0xx_conf.h"
   #include "analog.h"
15 #include "lcd.h"
   // Sample pragmas to cope with warnings. Please note the related
       line at
    // the end of this function, used to pop the compiler diagnostics
       status.
20 #pragma GCC diagnostic push
   #pragma GCC diagnostic ignored "-Wunused-parameter"
   #pragma GCC diagnostic ignored "-Wmissing-declarations"
   #pragma GCC diagnostic ignored "-Wreturn-type"
25 int main(int argc, char* argv[]) {
     // By customizing <code>__initialize_args()</code> it is possible to pass
       arguments,
     // for example when running tests with semihosting you can pass
       various
      // options to the test.
     // trace_dump_args(argc, argv);
30
     \ensuremath{//} Send a greeting to the trace device (skipped on Release).
     trace_puts("Hello ARM World!");
     // The standard output and the standard error should be forwarded
      // the trace device. For this to work, a redirection in _write.c
35
       is
     // required.
     // At this stage the system clock should have already been
       configured
```

```
// at high speed.
40
     trace_printf("System clock: %u Hz\n", SystemCoreClock);
     trace_printf("%s", "Initializing ADC...");
     adc_init();
     adc_enable_pot(1);
trace_puts("Done");
45
     trace_printf("%s", "Initializing DAC...");
     dac_init();
     trace_puts("Done");
50
     trace_printf("%s", "Initializing LCD...");
     lcd_init();
     trace_puts("Done");
    trace_printf("%s", "Initializing frequency monitor...");
55
     freq_init();
     trace_puts("Done");
     // Infinite loop, wait for interrupts to do anything
60
     while (1) {
     // Infinite loop, never return.
     return 0;
65 }
   #pragma GCC diagnostic pop
              -----
```

A.2 Analog

* Outputs:

*/

```
include/analog.h
1 #ifndef __ANALOG_H__
   #define __ANALOG_H__
   #include <stdio.h>
   #include <stdlib.h>
   #include "stm32f0xx_conf.h"
   /* No prescaler on timer 2 */
   #define TIM2_PRESCALER ((uint16_t)0x0000)
11 /* Maximum possible setting for auto-reload */
   #define TIM2_AUTORELOAD_DELAY ((uint32_t)0xFFFFFFFF)
   /* 48MHz clock speed */
   #define TIMER_CLOCK_FREQ ((uint32_t)48000000)
16 /* Wiring:
          Potentiometer/ADC:
                   - ADC input POT M20 -> PA0
                   - POT_EN M32 -> PC1
           DAC:
                   - DAC output is PA4
21
           Freq. Measurement:
                   - Input is PA1
    */
26 void adc_init(void);
   void dac_init(void);
   void freq_init(void);
   /* Enable or disable the potentiometer value line
   * Inputs:
           state: 1 for enable 0 for disable
    */
   void adc_enable_pot(uint8_t state);
36 /* Read the current value for the potentiometer
    * If POT ENABLE is not high this will return garbage results
    * Outputs:
           uint16_t: right-aligned 12-bit ADC value
    */
41 uint16_t adc_read(void);
    /* Write the output value of the DAC
    * Inputs:
           uint16_t value: 12-bit right-aligned value to set
   */
   void dac_write(uint16_t value);
   /* Returns the current input frequency
```

float: current frequency in Hz

uint32_t period_to_freq(uint32_t count);

```
#endif // __ANALOG_H__
                                 src/analog.c
    #include "analog.h"
   #include "diag/Trace.h"
   #include "lcd.h"
   #define UPDATE_DELAY (800000)
    static uint16_t first_edge = 1;
   static uint16_t adc_value;
   uint16_t adc_read(void) {
            return ADC1->DR;
   }
void adc_enable_pot(uint8_t state) {
            if (state) {
                    GPIOC->BSRR = GPIO_BSRR_BS_1;
            }
            else {
20
                    GPIOC->BRR = GPIO_BRR_BR_1;
            }
   }
    void dac_write(uint16_t value) {
25
            /* Write the provided value to the 12-bit right-aligned DAC
         input */
            DAC->DHR12R1 = (value & DAC_DHR12R1_DACC1DHR);
   }
   uint32_t period_to_freq(uint32_t count) {
30
           return (TIMER_CLOCK_FREQ)/count;
    /* Initialize the ADC
    */
   void adc_init(void) {
            /* Enable clock for GPIOC */
            RCC->AHBENR |= RCC_AHBENR_GPIOCEN;
            /* Configure PC1 as push-pull output */
40
            GPIOC -> MODER |= GPIO_MODER_MODER1_0;
            GPIOC -> OTYPER &= ~GPIO_OTYPER_OT_1;
            /* Ensure high-speed mode for PC1 */
            GPIOC ->OSPEEDR |= GPIO_OSPEEDR_OSPEEDR1;
            /* Disable any pull up/down resistors on PC1 */
            GPIOC -> PUPDR &= ~GPIO_PUPDR_PUPDR1;
45
            /* Configure PAO as an analog pin */
            GPIOA -> MODER |= GPIO_MODER_MODERO;
            /* Enable the HSI14 (ADC async) clock */
50
            RCC->CR |= RCC_CR_HSION;
            RCC->APB2ENR |= RCC_APB2ENR_ADCEN;
```

```
/* Start up the ADC */
55
             ADC1->CR = ADC_CR_ADEN;
             /* ---- Configure the ADC ---- */
             /st Set the ADC clock to the dedicated clock st/
             ADC1->CFGR2 &= ^{\circ}(0x00);
             /* Select the input channel */
60
            ADC1 -> CHSELR = ADC_CHSELR_CHSELO;
             /* Set continuous conversion mode */
             ADC1->CFGR1 |= ADC_CFGR1_CONT;
             /* Enable starting with software trigger */
65
            ADC1->CFGR1 &= ~ADC_CFGR1_EXTEN;
             /* Disable auto-off */
             ADC1->CFGR1 &= ~ADC_CFGR1_AUTOFF;
70
             /* Wait for the ADC to stabilize */
            while(!(ADC1->ISR & ADC_ISR_ADRDY));
             /* Start converting the analog input */
             ADC1->CR |= ADC_CR_ADSTART;
    }
75
    /* Initialize the DAC
    void dac_init(void) {
             /* Set PA4 (DAC output) as analog output pin */
80
            GPIOA->MODER = GPIO_MODER_MODER4;
             /* Set PA4 to open drain */
             GPIOA->OTYPER = GPIO_OTYPER_OT_4;
             /* Disable pull up/down resistors on PA4 */
            GPIOA->PUPDR &= ~GPIO_PUPDR_PUPDR4;
85
             /* Set PA4 to high-speed mode */
             GPIOA -> OSPEEDR |= GPIO_OSPEEDR_OSPEEDR4;
             /* Enable the DAC clock */
            RCC->APB1ENR |= RCC_APB1ENR_DACEN;
90
            /* Enable the DAC (with output buffering and auto-
         triggering */
            DAC->CR = DAC_CR_EN1;
    }
    void freq_init(void) {
95
             /* Enable the GPIOA clock */
             RCC->AHBENR |= RCC_AHBENR_GPIOAEN;
             /* Configure PA1 as an input */
            GPIOA -> MODER &= ~(GPIO_MODER_MODER1);
             /* Ensure no pull up/down for PA1 */
100
            GPIOA -> PUPDR &= ~(GPIO_PUPDR_PUPDR1);
             /* Enable the TIM2 clock */
            RCC->APB1ENR |= RCC_APB1ENR_TIM2EN;
             /* Configure TIM2 with buffer auto-reload, count up,
105
             * stop on overflow, enable update events, and interrupt
             * on overflow only
            TIM2 -> CR1 = 0x8C;
```

```
110
              /* Set clock prescaler value */
             TIM2->PSC = TIM2_PRESCALER;
              /* Set auto-reload delay */
             TIM2->ARR = TIM2_AUTORELOAD_DELAY;
              /* Set timer update configuration (rising edge, etc.) */
115
              TIM2 -> EGR = (TIM2 -> EGR & ~Ox5F) | (Ox1 & Ox5F);
              /* Assign TIM2 interrupt priority 0 in NVIC */
             NVIC_SetPriority(TIM2_IRQn, 0);
              /* Enable TIM2 interrupts in NVIC */
120
              NVIC_EnableIRQ(TIM2_IRQn);
              /* Enable update interrupt generation */
             TIM2 \rightarrow DIER \mid = 0x41;
              /* Map EXTI1 line to PA1 */
              SYSCFG \rightarrow EXTICR[0] = (SYSCFG \rightarrow EXTICR[0] & ~(0xF)) | (0 & 0xF)
125
         );
              /* EXTI1 line interrupts: set rising-edge trigger */
             EXTI \rightarrow RTSR \mid = 0x2;
130
              /* Unmask interrupts from EXTI1 line */
             EXTI \rightarrow IMR \mid = 0x2;
              /* Assign EXTI1 interrupt priority 0 in NVIC */
             NVIC_SetPriority(EXTIO_1_IRQn, 0);
135
              /* Enable EXTI1 interrupts in the NVIC */
              NVIC_EnableIRQ(EXTIO_1_IRQn);
    }
     void TIM2_IRQHandler() {
140
             /* Check if update interrupt flag is set */
              if (TIM2->SR & TIM_SR_UIF) {
                      trace_printf("\n*** Overflow! ***\n");
                       /* Clear update interrupt flag */
145
                      TIM2 \rightarrow SR \mid = 0x1;
                       /* Restart stopped timer */
                      TIM2 \rightarrow CR1 \mid = 0x1;
             }
    }
150
     void EXTIO_1_IRQHandler() {
              /* Check if EXTI1 interrupt pending flag is set */
              // Disable interrupts while servicing
              NVIC_DisableIRQ(EXTIO_1_IRQn);
155
              if (EXTI->PR & EXTI_PR_PR1) {
                      if (first_edge) {
                               first_edge = 0;
                                /* Reset current timer count */
                               TIM2 \rightarrow CNT = 0;
160
                                /* Start the timer */
                               TIM2 \rightarrow CR1 \mid = 0x1;
                      } else {
                                /* Stop the timer */
                               TIM2 -> CR1 &= ~0x1:
165
                                /* Read the current timer count */
```

```
uint32_t count = TIM2->CNT;
                              uint32_t freq_value = period_to_freq(count)
         ;
                              char* freq_ascii = num_to_ascii(freq_value)
170
                              // Write the frequency value to the LCD
                              lcd_cmd(0x82); // Set address to 02
                              for (int i = MAX_DIGITS-1; i >= 0; i--){
                                       lcd_char(*(freq_ascii + i));
175
                              \ensuremath{//} Here we want to obtain the resistance,
         send the result to the DAC
                              // and print it to the LCD. A short wait
         time will also be added so the display doesn't flicker too much
                              adc_value = adc_read();
// Get the string for resistance rounded to
          the 100th
                              dac_write(adc_value); // Send value of ADC
         to DAC
180
                              char* resistance_ascii = num_to_ascii((((
         uint32_t)(adc_value * ((float)5000/4095)) + 50)/ 100)*100);
                              // Write the resistance value to the LCD
                              lcd_cmd(0xC2); // Set address to h42
                              for (int i = MAX_DIGITS-1; i >= 0; i--) {
                                       lcd_char(*(resistance_ascii + i));
185
                              TIM3->CNT = UPDATE_DELAY;
                              TIM3 \rightarrow CR1 \mid = 0x1;
                              while(TIM3->CNT > 1);
190
                              first_edge = 1;
                     }
                      /* Clear the interrupt flag */
                     EXTI->PR = EXTI_PR_PR1;
195
             NVIC_EnableIRQ(EXTIO_1_IRQn);
    }
```

A.3 LCD

include/lcd.h

```
#ifndef __LCD_H__
 2 #define __LCD_H__
   #include "stm32f0xx_conf.h"
   #define MAX_DIGITS (4)
    /* Maximum required delay between SPI writes */
   #define MAX_DELAY ((uint32_t)96000)
    /* Delay between characters */
   #define CHAR_DELAY ((uint32_t)4800)
12
    /** Wiring
    * PC2 - LCK -> M25
    * PB5 - MOSI -> M17
    * PB3 - SCK -> M21
17
   */
    void lcd_init(void);
    void lcd_clear(void);
22
   void lcd_cmd(uint8_t data);
   void lcd_char(char c);
27 char* num_to_ascii(uint32_t num);
   #endif //__LCD_H__
                                  src/lcd.c
 1 #include "lcd.h"
   #define LCD_BAUD_RATE_PRESCALER (16)
    /* No prescaler on timer 3 */
 6 #define TIM3_PRESCALER ((uint16_t)0x0000)
   /* Maximum possible setting for auto-reload */
   #define TIM3_AUTORELOAD_DELAY ((uint32_t)0xFFFFFFFF)
   /* 48MHz clock speed */
   #define TIMER_CLOCK_FREQ ((uint32_t)48000000)
11
    /* Output data to the shift register through SPI */
   void spi_write(uint8_t, uint32_t delay);
    void lcd_init(void) {
           /* Enable SPI1 clock */
16
            RCC->APB2ENR |= RCC_APB2ENR_SPI1EN;
            /* Enable GPIOB clock */
           RCC->AHBENR |= RCC_AHBENR_GPIOBEN;
            /* Enable GPIOC clock */
21
           RCC->AHBENR |= RCC_AHBENR_GPIOCEN;
```

```
/* Set PC2 to output */
            GPIOC->MODER = (GPIOC->MODER & ~GPIO MODER MODER2) | (
        GPIO_MODER_MODER2 & GPIO_MODER_MODER2_0);
            /* Set PB3 to alternate function */
26
            GPIOB->MODER = (GPIOB->MODER & ~GPIO_MODER_MODER3) | (
        GPIO_MODER_MODER3 & GPIO_MODER_MODER3_1);
            GPIOB -> AFR[0] &= ~GPIO_AFRL_AFR3;
            /* Set PB5 to alternate function */
            GPIOB->MODER = (GPIOB->MODER & ~GPIO_MODER_MODER5) | (
        GPIO_MODER_MODER5 & GPIO_MODER_MODER5_1);
            GPIOB -> AFR[0] &= ~GPIO_AFRL_AFR5;
31
            /* Set PC2, PB3, PB5 to push-pull mode */
            GPIOC -> OTYPER &= ~GPIO_OTYPER_OT_2;
            GPIOB->OTYPER &= ~GPIO_OTYPER_OT_3;
            GPIOB->OTYPER &= ~GPIO_OTYPER_OT_5;
36
            /* Disable pull up/down resistors on SPI pins */
            GPIOB->PUPDR &= GPIO_PUPDR_PUPDR3;
GPIOB->PUPDR &= GPIO_PUPDR_PUPDR5;
            GPIOC -> PUPDR &= ~GPIO_PUPDR_PUPDR2;
41
            /* Set SPI pins to high-speed */
            GPIOB -> OSPEEDR |= GPIO_OSPEEDR_OSPEEDR3;
            GPIOB -> OSPEEDR |= GPIO_OSPEEDR_OSPEEDR5;
            GPIOC->OSPEEDR |= GPIO_OSPEEDR_OSPEEDR2;
46
            /* Initialize TIM3 */
            /* Enable the TIM3 clock */
            RCC->APB1ENR |= RCC_APB1ENR_TIM3EN;
            /* Configure TIM3 with buffer auto-reload, count down,
51
             * stop on overflow, and only interrupt on overflow
             */
            TIM3 -> CR1 = 0xC6;
            /* Set clock prescaler value */
            TIM3->PSC = TIM3_PRESCALER;
56
            /* Set auto-reload delay */
            TIM3->ARR = TIM3_AUTORELOAD_DELAY;
            /* Set timer update configuration (rising edge, etc.) */
            TIM3 -> EGR = (TIM2 -> EGR & ~Ox5F) | (Ox1 & Ox5F);
            /* Load delay value */
61
            TIM3->CNT = MAX_DELAY;
            TIM3->CR1 \mid = 0x1;
            /* Initialize SPI */
            SPI_InitTypeDef SPI_InitStructInfo = {
                             .SPI_Direction = SPI_Direction_1Line_Tx,
66
                             .SPI_Mode = SPI_Mode_Master,
                             .SPI_DataSize = SPI_DataSize_8b,
                             .SPI_CPOL = SPI_CPOL_Low,
                             .SPI_CPHA = SPI_CPHA_1Edge,
                             .SPI_NSS = SPI_NSS_Soft,
71
                             .SPI_BaudRatePrescaler =
        SPI_BaudRatePrescaler_256,
                             .SPI_FirstBit = SPI_FirstBit_MSB,
                             .SPI_CRCPolynomial = 7
```

```
};
76
            SPI_Init(SPI1, &SPI_InitStructInfo);
            SPI_Cmd(SPI1, ENABLE);
            /* Set the LCD to 4 bit interface */
            spi_write(0x02, MAX_DELAY);
81
            spi_write(0x82, MAX_DELAY);
            spi_write(0x02, MAX_DELAY);
             /* Set LCD to display 2 lines */
86
            lcd_cmd(0x28);
            /* Clear the LCD */
            lcd_cmd(0x01);
             /* Home the cursor */
91
            1cd_cmd(0x02);
            /* Set cursor move direction and disable display shift */
            lcd_cmd(0x06);
            /* Set the display on, don't show the cursor, don't blink
            lcd_cmd(0x0C);
96
             /* Set the cursor to move right, no display shift */
            lcd_cmd(0x14);
             /* Write 'F:
                            Hz' to first line */
            lcd_cmd(0x80); // Start at very left
101
            lcd_char('F'); //F
            lcd_char(':'); //:
            lcd_cmd(0x86);
            lcd_char('H'); //H
            lcd_char('z'); //z
106
                            Oh' to second line*/
            /* Write 'R:
            lcd_cmd(0xC0); // set address to second line, first
        character
            lcd_char('R'); //R
            lcd_char(':'); //:
            lcd_cmd(0xC6);
111
            lcd_char('0');
            lcd_char('h');
    }
116 void spi_write(uint8_t data, uint32_t delay) {
            /* Wait until SPI delay has passed */
            while (TIM3->CNT > ((MAX_DELAY+1) - delay));
            /* Force LCK low */
            GPIOC->BRR |= GPIO_BRR_BR_2;
121
            /* Wait until SPI1 is ready */
            while((SPI1->SR & SPI_SR_BSY) && ~(SPI1->SR & SPI_SR_TXE));
            /* Send the data */
            SPI_SendData8(SPI1, data);
             /* Wait until SPI1 is not busy */
126
            while(SPI1->SR & SPI_SR_BSY);
            /* Force LCK signal to 1 */
            GPIOC->BSRR |= GPIO_BSRR_BS_2;
            /* Reset LCD comm clock */
```

```
TIM3->CNT = MAX_DELAY;
131
             TIM3 \rightarrow CR1 \mid = 0x1;
    }
     * Write to LCD using 4 bit interface. Send 4 high bits
136
    * by pulsing EN, then do the same for 4 low bits
     */
    void lcd_cmd(uint8_t data) {
             /* Send HIGH bits */
             spi_write(0x00 | (data >> 4), MAX_DELAY);
             spi_write(0x80 | (data >> 4), MAX_DELAY);
141
             spi_write(0x00 | (data >> 4), MAX_DELAY);
             /* Send LOW bits */
             \label{eq:spi_write} \verb"spi_write"(0x00 | (data & 0x0F), MAX_DELAY);
             spi_write(0x80 | (data & 0x0F), MAX_DELAY);
146
             spi_write(0x00 | (data & 0x0F), MAX_DELAY);
    }
    /** Write a character to the LCD
    * Inputs:
     * c: Character to write
     */
    void lcd_char(char c) {
             /* Send HIGH bits */
156
             spi_write(0x40 | ((uint8_t)c >> 4), CHAR_DELAY);
             spi_write(0xC0 | ((uint8_t)c >> 4), CHAR_DELAY);
             \label{eq:spi_write} \verb| (0x40 | ((uint8_t)c >> 4), CHAR_DELAY); \\
             /* Send LOW bits */
             spi_write(0x40 | ((uint8_t)c & 0x0F), CHAR_DELAY);
161
             spi_write(0xC0 | ((uint8_t)c & 0x0F), CHAR_DELAY);
             spi_write(0x40 | ((uint8_t)c & 0x0F), CHAR_DELAY);
    }
    /** Convert a number to ASCII digits (max of 4)
    * Inputs:
     * num: 32 bit unsigned integer to convert
     * Returns:
     * ASCII encoded digits in LSD first order
     */
171 char* num_to_ascii(uint32_t num) {
             static char ascii[MAX_DIGITS] = {0, 0, 0, 0};
             uint8_t i = 0;
             // Get individual digits (in LSD order)
             do {
176
                      ascii[i++] = ('0' + (char)(num % 10));
                     num /= 10;
             } while (num && (i < MAX_DIGITS));</pre>
             // Fill remaining space with blanks
             for (; i < MAX_DIGITS; i++) {</pre>
181
                     ascii[i] = ' ';
             return ascii;
    }
```