

Eidgenössische Technische Hochschule Zü Swiss Federal Institute of Technology Zuri

CAAD Professur Hovestadt

Institute of Technology in Architecture Faculty of Architecture / ETH Zurich


Examples

Practice

Download

Examples - ExampleModules - Photointerrupter

# **Photointerrupter**



A photointerrupter is more or less a simple light barrier. Mostly the light source is an infrared-LED and the receiver is a photo-transistor. Normally you want the status of the light barrier (covered-closed or opened) directly mapped to a digital Low or High. But a simple photo-transistor can also have states between Low and High. To make sure you do not need to filter those value-range by software, it is advisable to use a receiver that includes a Schmitt trigger. A Schmitt trigger does not only use a threshold to decide between Low and High, it also implements a hysteresis that eliminates noise. The important fact is, that a photointerrupter with Schmitt trigger output will provide you a proper square-wave signal. For example GP1A53HR will have this characteristics (search google).

### wire a photointerrupter

Most photointerupters will not need much (<20mA) current. Therefor they can be powered by the arduino-board. I use the following wiring for the **GP1A53HR**:

## pinNo pinDescription connect


- 1 ir-LED Anode via 470 Ohm Resistor to 5V current limited to ~10mA
- 2 ir-LED Cathode to Ground / 0V

3 receiver Vcc to 5V

4 receiver Vo to digital input / MicroController

5 receiver GND to Ground / 0V

### photointerrupter code snippets



A common usage for photointerrupters is to query, if a mechanical component has reached a specific position, or to count the pulses of an encoder wheel.

The linked code examples will show how to count pulses. It is also possible to use an external interrupt to stop a motor at an initial or final position, or to detect a coin dropping through a slot.

**How does the code look:** Of course it is possible to query the Photointerrupter status continuously within the main loop. This approach is not very efficient because you occupy your CPU and you might miss a very short timed event ( for example the dropping coin ) - but to have a complete list here is an **Example simple**.

To have some script timed independent from your main loop, you can cause a function to be called with signal-changes at some special input Pins. This method is called external interrupts and can be accessed via the arduino-function attachInterrupt. This method is nice to react on single events (initial position of a motor, the dropping coin or a switch). It still will consume some CPU and will interrupt the execution of your main loop. **Example interrupt** 

If you just want to **count** events, like the number of stripes of an encoder wheel that passed by, you can use one of Arduinos Timers/Counters and set them to use an external clock. Be aware of using Timer0 which is used for some functions like delay() and millis(). You also have to take account, that each Timer is used to control two PWM-Pins, using a Timer for something else will decrease the number of PWM-Pins. You will find more information about timers in **this article**. Timer1 is a 16-Bit Timer - it can count from 0 to 65535. There are also 8-Bit Timers that only count from 0 to 255. This **Example Timer1** shows, how to count pulses with Timer1 on a ATM168.

#### **Example Project**

In the Embossing Printer Project i made intensive use of photointerrupters.

Article by Tom Pawlofsky Mai 2010

contact

pawlofsky-AT-arch-DOT-ethz-DOT-ch

please feel free to email any comments, misstakes or improvements.

this page is linked to:

Examples /

PhotointerrupterCountInterrupt PhotointerrupterCountSimple PhotointerrupterCountTimer1 TimerDcMotorBackground

Projects /

EmbossingPrinter