EE-421: Digital System Design

Verilog for Verification: Test-Bench

What? I've done the coding and now you want to test it. Why? We haven't got time anyway.



OK, maybe you were right about testing. It looks like a nasty bug made its way into the Live environment and now costumers are complaining.



Testers! you must work harder! Longer! Faster!



1960s - 1980s

Constraint Source: cartoontester.blogspot.com

1990s

Need


2000+

Asset

Instructor: Dr. Rehan Ahmed [rehan.ahmed@seecs.edu.pk]



Where are we Heading?




How Do You Know That A Circuit Work


- You have written the Verilog code of a circuit
 - Does it work correctly?
 - Even if the syntax is correct, it might do what you want?
 - What exactly it is that you want anyway?
- Trial and error can be costly
 - You need to 'test' your circuit in advance
- In modern digital designs, functional verification is the most time-consuming design stage:
 - You want your design to be "bugs" free
 - Bugs have a cost!

Why Should We "FIX" Bugs ASAP?

LIKE MANY LIVING CREATURES, BUGS GROW IN SIZE THROUGHOUT THEIR LIFE. IT IS DESIRABLE TO DISCOVER AND EXTERMINATE BUGS SOON AFTER CONCEPTION.



Why Should We "FIX" Bugs ASAP?






Design integration stage

- Increase in chip NREs make respins an unaffordable proposition
- Average ASIC NRE ~\$122,000
- SoC NREs range from \$300,000 to \$1,000,000 NRE=non-recurring engineering


The Idea Behind a Testbench

- Using a computer simulator to test your circuit:
 - You instantiate your design under test (DUT) inside a testbench
 - A testbench is a Verilog module that provides inputs and possibly monitors outputs, used during testing
 - Never becomes part of your design, therefore does not need to be synthesizable
 - Allows the behavior of the circuit to be verified without actually manufacturing the circuit
 - Supply the circuit with some inputs:
 - See what it does
 - Does it return the "correct" outputs?



Design Under Test [DUT]

- The test bench applies stimulus to the DUT,
 - Therefore must be instantiated in the test bench.
 - A testbench typically does not have inputs or outputs!



Recipe for Expressing Testbench in Verilog

- 1. Declare the module with no interface,
 - i.e module tb (); end module
- 2. Reg and Wire Declaration inside the module:
 - Inputs to the DUT are REG type
 - Outputs from the DUT are wire type
- 3. DUT Instantiation
- 4. Initialization:
 - Signals are undefined at startup.
 - Initialize any reg types in the design to a known value.
 - Use initialize block
 - Clock Generation:
 - Use always block to generate clk

Example: Testbench

Write Verilog code to implement the following function in hardware:

$$y = \overline{(b \cdot c)} + (a \cdot \overline{b})$$

module myblock (input a, b, c, output y);

assign $y = \begin{subarray}{l} & & \begin{subarray}{l} a \& \begin{subarray}{l} & & \begin{subarray}{l} a \& \begin{subarray}{l} & & \begin{subarray}{$

Example: Testbench

```
module testbench(); // 1. Testbench has no inputs and outputs
               // 2. inputs to the DUT are reg type
    reg a, b, c;
                       // 3. outputs from the DUT are wire type
    wire y;
    // 4. instantiate device under test [note argument passing by
        position]
    myblock dut (.a(a), .b(b), .c(c), .y(y) );
   // 5. apply inputs one at a time
   initial begin // sequential block
   a = 0; b = 0; c = 0; #10; // apply inputs, wait 10ns
   c = 1; #10; // apply inputs, wait 10ns
   b = 1; c = 0; #10; // etc... etc...
   c = 1; #10;
   a = 1; b = 0; c = 0; #10;
   end
endmodule
```

Example: Testbench

- Simple testbench instantiates the design under test
- It applies a series of inputs
- The outputs have to be observed and compared using a simulator program.
- This type of testbench does not help with the outputs
- Initial statement is similar to always, it just starts once at the beginning, and does not repeat.
- The statements have to be blocking.

Initial and Always blocks in TB

- Initial and Always blocks inside tb module:
 - Always and initial blocks are two sequential control blocks that operate on reg types in a Verilog simulation.
 - Each initial and always block executes concurrently in every module at the start of simulation.
 - Initial blocks start executing sequentially starting with the first line:
 - between the "begin end pair" each line executes from top to bottom until a delay is reached.

Other Helpful TB Constructs

Generating clocks:

\$display

- is used to print to a line, and enter a carriage return at the end.
- \$display(\$time, "<< count = %d Turning OFF count enable >>",cnt_out);

Recommended Reading

- A Verilog HDL Test Bench Primer Application Note
 - Uploaded on LMS

THANK YOU



