Introduction to the Arduino

May 20, 2020

1 Introduction



Figure 1: The Arduino Uno microprocessor.

In this lab, we will learn to use the Arduino microprocessor, which we will be using for the hands on portion of this course. The model we will use is the Arduino Uno. You should keep a text log file, which you will submit on the course website once you have completed this assignment.

2 Getting Started with the Arduino

Step 1: Your Arduino should have arrived pre-installed with a custom shield. Remove the shield for these initial tests as demonstrated at the end of the hardware checkout video, being careful not to damage the pins.

Step 2: The main Arduino website, which includes lots of supporting documentation, is located at http://arduino.cc. Acquaint yourself with this site.

Step 3: You should have already installed the Arduino software. Follow the instructions for using the "Arduino Desktop IDE" located here: https://www.arduino.cc/en/Guide/ArduinoUno.

Step 4: Compile and upload the LED blink example. Take a close look at the program, which is enough to understand the most important features of an Arduino sketch.

Your Arduino microprocessor runs a single program which you can create, modify, compile, and upload in the Arduino integrated development environment IDE. For this lab, the sketches will have only two function of interest. The setup() function is called once when the program first starts (such as upon reset, or opening a serial connection). This is where you do things that only need to be done once, such as setting the LED pin to an output in the Blink example. The loop() function is run in an endless loop: the program calls loop() immediately after finishing setup, and the program calls loop() again as soon as it finishes. The execution of loop can be momentarily interrupted by special interrupt signals, but we won't be using interrupts directly in this lab. In the Blink example, the loop() function turns on the LED, pauses for one second, turns off the LED, and then pauses for a second. The LED blinks repeadedly because it reenters the loop function immediately on exiting. Each blink you observe is one call to loop()

You'll be starting from example sketches throughout these labs that already define the functions setup() and loop() but you will need to keep their roles in mind when decided where to put your modifications.

Step 5: Adjust the pattern of the LED blink example to a slower rate. Record your modification in your logbook.

Step 6: The Arduino tutorials and built-in-examples are often excellent starting points for you own projects, browse the tutorials here: https://www.arduino.cc/en/Tutorial/HomePage

3 The 116C custom proto-board

The features included in your custom proto-board are shown in Fig. 2. This lab will not use the RC filter, but will make use of the LED, push-button, and potentiometer.




Figure 2: The features already implemented on the custom proto-board. The (a) 220 Ω resistor and (b) capacitor are used for RC filtering in the digital scope lab, the (c) current limited LED is controlled by pin 11, the (d) user switch S pulls pin 2 to ground when pressed, and a (e) 10 k Ω potentiometer has the wiper connected to analog pin A1.

- **Step 1:** While the proto-board is off the Arduino, take some time to see how the various features are implemented. The components are on top, but some connections are made on the bottom with wired connections. Work through the diagrams and make sure you see how each component is connected to the Arduino pins.
- **Step 2:** Carefully reinstall the custom proto-board shield which you removed in the previous section, as demonstrated at the end of the hardware checkout video, being careful not to damage the pins.
- **Step 3:** Modify the LED blink example to make use of the red LED on the proto-board, instead of the built in LED. Record your modifications in your logbook.
- **Step 4:** The DigitalInputPullup example works as provided because it expects a user switch connected to pin 2 exactly as on your protoboard. This sketch will turn on the onboard LED underneath the protoshield while you press the switch. Modify it to blink the red LED on the proto-board instead. Record your modifications in your logbook.

Analog output on the Arduino UNO is accomplished by Pulse Width Modulation (PWM). A PWM output is a digital signal (either 0 or VCC) but with a variable duty cycle. The output for value 0 is always off, and the output for value 255 is always on, but the output for value 123 will be on one half of each cycle and off for one half of each cycle. The **average** voltage is therefore a programmable analog value between 0 and VCC. To get a truly analog value, you need some sort of filtering, such as from an RC filter, appropriate for the PWM rate, which is configurable but around 1 kHz on the UNO.

Your eye is a high-pass filter, you cannot perceive an LED blinking at the PWM rate, so we can use PWM to dim an LED. The LED is always fully on or fully off, but your eye perceives the faction of time it is on for each cycle as brightness.

Step 5: Modify the LED fade example to make use of the red LED on the proto-board, instead of the built in LED. Record your modifications in your logbook.

We'll receive analog inputs from the potentiometer shown in Fig. 2D. The wiper is connected to pin A1 which we will use as input. To function as a potiometer, the end of the variable resistance need to be set to ground and VCC. Since analog pins can be used as digital outputs, we'll simply write a digital 1 to A0 and digital 0 to A2.

Step 6: Run the AnalogReadSerial example on your Arduino. Open the serial monitor tool making certain that the baud rate is set to same value used by sketch (Serial.begin()).

This sketch takes its input from pin A0, so you won't see the values change as you turn the knob on the potiometer.

- Step 7: Change the pin used for analogRead to A1 (from A0). Record your change in your logbook.
- **Step 8:** Add the following lines to the Setup function in your sketch, which setup pins A0 and A1 as ground and VCC for the potiometer:
 - // The potentiometer is installed at AO-A1-A2.

```
// Set AO to VCC and A2 to ground
pinMode(AO, OUTPUT);
pinMode(A2, OUTPUT);
digitalWrite(AO, HIGH);
digitalWrite(A2, LOW);
```

Step 9: Now as you adjust the knob, you should see the serial output range from full scale at 1023 (nominally 5 V) down to 0 (nominally 0 V). For a graphical view, exit the serial monitor and use the serial plotter. You should see the value move around on the plot as you turn the knob. Rename your modified sketch and save it for later... it's a good starting point for the next section.

4 Digital Control System

You now have everything that you need to make a digital control system for the LED. Create a sketch that allows you to dim the LED based on the setting of the potentiometer. Do this digitally!

One approach is to start from the analogRead serial example, as modified to work with our potentiometer as described above. Then, understand and import the parts of the LED fade example that are useful for your purposes.

Keep in mind that analog read values are from 0 to 1023 (10 bit values) while analog write values are from 0 to 244. So convert the value you read from the potiometer to a value you can use in a call to analogWrite(), you will have to divide by four.

This is the main design portion of the lab. Completing the preliminary steps is enough for "B". Completing this design is needed for an "A". Once you have it working, you should upload your single *.ino file with your completed design along with your text file log.

5 Design Improvements

For fun and extra credit, you can develop any or all of these alternative designs. The TA will only provide limited help on these problems and at lower priority than helping with required portions of the labs:

- There is an analog solution for creating the LED dimmer. Instead of controlling the LED by using pin 11 as a PWM output, set pin 11 as an input which will make it high impedance. Then, connect the output of the potentiometer directly to the pin 11.
- Make the LED blink briefly and then remain off for a time controlled by the setting of the potentiometer.
- Use the push button to switch between two or more LED modes, such as dimming and variable rate blinking. You'll want to debounce the switch using a technique like the example DigitalStateChangeDetection.
- These are just ideas... if there's something else you want to try, give it a go!

Don't submit extra credit with your lab. There will be an extra assignment where you can submit extra credit, which can be completed at any time during the quarter.