

Advanced Radio License Notes

Oskar Meszaros (z5636164)

July 2026

Contents

1	Introduction	4
2	Electronics and Circuit Theory	4
2.1	Impedance	4
2.1.1	Introduction	4
2.1.2	Reactance	4
2.1.3	Impedance formula	4
2.2	Resonance	5
2.2.1	Introduction	5
2.2.2	Series and Parallel Resonance	5
2.2.3	Q-Factor	5
2.3	Filters	6
2.3.1	Introduction	6
2.3.2	Types of Filter	6
2.3.3	LC Filter	6
2.3.4	Filter Steepness	6
2.3.5	Crystal Filters	7
2.3.6	Filter Response Shapes	7
2.4	Amplifier Classes	7
2.4.1	Introduction	7
2.4.2	Classes	7
2.4.3	Decibels	8
2.5	Oscillators	8
2.5.1	Introduction	8
2.5.2	Common Types	8
2.5.3	PLL Frequency Synthesiser	9
2.5.4	Mixers	9
2.6	AGC and Power Supplies	9
2.6.1	Introduction	9
2.6.2	Power Supplies for Radio	9
3	Transmitters and Receivers	10
3.1	The Superheterodyne Receiver	10
3.1.1	The Image Problem	10
3.2	SSB	10
3.2.1	Introduction	10
3.2.2	The Phasing Method	11
3.2.3	Balanced Modulator	11
3.3	FM	11
3.3.1	Introduction	11
3.3.2	Pre- and De-emphasis	11

3.4	Receiver Performance	12
3.4.1	Introduction	12
3.4.2	Sensitivity	12
3.4.3	Intermodal Distortion (IMD)	12
3.4.4	Reciprocal Mixing	12
3.4.5	Dynamic Range	12
4	Propagation	13
4.1	The Ionosphere	13
4.1.1	Introduction	13
4.1.2	The Layers	13
4.2	Selecting the Right Frequency	13
4.2.1	Introduction	13
4.2.2	Maximum Usable Frequency (MUF)	13
4.2.3	Minimum Usable Frequency (LUF)	13
4.2.4	Frequency of Optimum Traffic (FOT)	13
4.2.5	Skip Distance and Skip Zone	14
4.3	Special Propagation	14
4.3.1	Sporadic E	14
4.3.2	Grey-Line Propagation	14
4.3.3	Tropospheric Ducting	14
4.3.4	Earth-Moon-Earth (EME/Moonbounce)	14
4.3.5	Satellite Communication	14
5	Antennas and Feedlines	14
5.1	Antenna Basics	14
5.1.1	Introduction	14
5.1.2	The Half-Wave Dipole	15
5.1.3	Gain	15
5.1.4	Other Properties	15
5.2	Directional Antennas	16
5.2.1	Introduction	16
5.2.2	Yagi-Uda Antenna	16
5.2.3	Quad Antenna	16
5.2.4	Log-Period Dipole Array (LPDA)	16
5.3	Coax and Feedlines	16
5.3.1	Introduction	16
5.3.2	Characteristic Impedance	17
5.3.3	Velocity Factor	17
5.3.4	Standing Wave Ratio (SWR)	17
5.4	Impedance Matching and Baluns	18
5.4.1	Introduction	18
5.4.2	Antenna Tuner (transmatch)	18
5.4.3	Quarter-Wave Transformer	18
5.4.4	Baluns	18
5.4.5	The Smith Chart	19
5.5	DIY Antennas	19
5.5.1	Introduction	19
5.5.2	Half-Wave Dipole	19

6	EMC and Interference	19
6.1	Understanding and Fixing Interference	19
6.1.1	Introduction	19
6.1.2	EMC Toolkit	20
6.1.3	Intermodulation	20
6.2	EMR Safety	20
6.2.1	Introduction	20
6.2.2	Australian Requirements	20
6.2.3	Worked EMC Examples	21
7	Measurements and Test Equipment	21
7.1	RF Power and Antenna Measurements	21
7.1.1	Measuring RF Power	21
7.1.2	Power in Decibels	22
7.1.3	Antenna Analyser	22
7.1.4	Frequency Counter	22
7.2	Practical Measurement Scenarios	22
8	Regulations and Operating	23
8.1	Advanced License Privilege	23
8.1.1	Introduction	23
8.1.2	Station Identification	24
8.1.3	Regulating Bodies	24
8.1.4	Third-Party Traffic	24
8.2	Frequency Allocation	24
8.2.1	Band Plans	25
8.3	Operating Practices and Repeaters	26
8.3.1	Introduction	26
8.3.2	Repeater Operation	26
8.3.3	Making a Call	26
8.3.4	Signal Reports	26
8.3.5	Emergency Communications	27
9	Digital Modes and SDR	27
9.1	DSP	27
9.1.1	Introduction	27
9.1.2	Sampling	27
9.1.3	Quantisation	27
9.2	SDR and Digital Modes	28
9.2.1	Introduction	28
9.2.2	Digital Modulation Types	28
9.2.3	Error Correction	29
9.3	Getting Started with Digital Modes	29
9.3.1	Introduction	29
9.3.2	FT8 in Practice	29
9.3.3	Common Digital Mode Frequencies	29
9.3.4	APRS	30
10	Safety	30
10.1	Electrical Safety	30
10.1.1	Essential Safety Rules	30
10.1.2	RF Burns	31
10.2	Lightning Protection and Tower Safety	31
10.2.1	Introduction	31
10.2.2	Grounding	31

10.2.3	Tower Safety	31
10.2.4	Minimum Safe Voltage	31
10.3	Building a Safe Station	32
10.3.1	Introduction	32
10.3.2	Shack Layout	32
10.3.3	Grounding Your Station	32
10.3.4	Portable Operation Safety	32
10.3.5	EMR Compliance Documentation	33

1 Introduction

This are the notes from following the advanced course on HamRadio.au.

2 Electronics and Circuit Theory

2.1 Impedance

2.1.1 Introduction

Impedance is how a circuit stores or resists AC (or any changing) energy. If the impedances within a circuit aren't matched, then power gets reflected back instead of going where it is needed.

Impedance is the combination of resistance and reactance. Resistance is the restriction of the "flow" of energy, and converts that restricted energy to heat. This is measured in Ohms Ω . Reactance can be thought of as a flywheel, it stores energy temporarily and releases it. This is what capacitors and inductors do. This is also measured in Ohms. This means that impedance is the total opposition to current.

Why this matters. The transmitter expects to see 50Ω of impedance. The coax is also 50Ω . If the antenna isn't also close to 50Ω , then the power from the transmitter gets reflected, which is what SWR (standard wave ratio) measures.

2.1.2 Reactance

There are two types of reactance. One is found in inductors, and the other in capacitors.

Inductors (any coil of wire) opposes changes in current, i.e. their reactance increases with frequency

$$X_L = 2\pi fL.$$

This means that the higher the frequency, the more and inductor blocks the signal. This is why they are used in low-pass filters, they all for low frequencies but block high ones.

Capacitors opposes changes in voltage. Their reactance decreases with frequency

$$X_C = \frac{1}{2\pi fC}.$$

The higher the frequency, the easier it passes through the capacitors. This is why a capacitor in series blocks DC but passes RF.

2.1.3 Impedance formula

We can then write impedance as

$$Z = R + jX,$$

where R is the resistance, X is the impedance, and j is used in place of i for imaginary numbers due to i being used for current. The resistance part is where the energy is consumed, and the reactive part is where the energy is stored and returned. The total impedance is then given by the magnitude of this complex number

$$|Z| = \sqrt{R^2 + X^2}$$

Example. An antenna has $R = 50\Omega$ and $X = 25\Omega$. The total impedance magnitude is

$$\begin{aligned} Z &= \sqrt{2500 + 625} \\ &= \sqrt{3125} \\ &\approx 56\Omega \end{aligned}$$

2.2 Resonance

2.2.1 Introduction

When an inductor and capacitor are combined, at one specific frequency their reactances become equal and therefore cancel each other out. This is called resonance, and when this happens the circuit behaves as purely resistive. This is how a single frequency is selected while rejecting everything else.

Radio Example. Tuned circuits within a receiver use this resonance to select a station to hear, and reject everything else. Antennas are resonant at a specific frequency, which is where it works best.

The formula to find the resonant frequency is given by

$$f_r = \frac{1}{2\pi\sqrt{LC}}.$$

This says that for a given inductor L and capacitor C , there's exactly one frequency where they resonate. This is an important formula.

2.2.2 Series and Parallel Resonance

Series and parallel arrangements of L and C result in opposite behaviour at resonance.

Table 1: Behaviour of circuits at resonance		
	Series LC	Parallel LC
Impedance	Minimum (just R)	Maximum
Current	Maximum	Minimum from source
Used for	Passing a desired frequency (band-pass)	Blocking a desired frequency (or selecting it) (band-stop)

Radio Example. A series-resonant circuit in an antenna trap passed the trap's frequency through, while a parallel-resonant circuit in a receiver's IF (intermediate frequency) stage has high-impedance at the desired frequency, which develops a large signal voltage across it.

2.2.3 Q-Factor

The Q-factor describes how selective a resonant circuit is. A higher Q means a very sharp tuning (with narrow bandwidth), and low Q means a very broad tuning (wide bandwidth).

$$Q = \frac{f_r}{\text{Bandwidth}}$$

For a series RLC , $Q = \frac{X_L}{R}$, so less resistance means higher Q.

Bandwidth Rule. Bandwidth is $\frac{f_r}{Q}$, so a circuit with $Q = 100$ at 7 MHz has a bandwidth of 70 kHz, which is enough to cover a portion of the 40m band. A crystal filter with $Q = 50000$ at 9 MHz has a bandwidth of only 180 Hz, which is perfect for CW.

2.3 Filters

2.3.1 Introduction

Filters are extremely important in radio. They are what selects the frequencies that get let through and what get blocked. Without filters, a receiver would hear literally everything at the same time, and the transmitter would spray harmonics all over the spectrum (which happens to be illegal).

2.3.2 Types of Filter

There are four basic types of filter.

Table 2: Basic types of filter

Filter Type	Behaviour	Where it is in radios
Low-pass	Passes low frequencies, blocks high frequencies	After the transmitter PA (power amplifier). It blocks harmonics before reaching the antenna
High-pass	Passes high frequencies, block low frequencies	At a TV antenna input. It blocks HF signals, but lets VHF/UHF TV through
Band-pass	Passes a specific range, blocks everything else	IF (intermediate frequency) filters in a receiver. It selects the signal bandwidth that you want.
Band-stop (notch)	Blocks a specific range, passes everything else	Notch filter to remove an interfering carrier.

2.3.3 LC Filter

Filters use inductors and capacitors in combinations to make a specific filter. From above, we know

- Inductors block high frequencies (reactance increases with frequency)
- Capacitors block low frequencies (reactance decreases with frequency)

Low-pass Filter. A low-pass filter wants to block high frequencies, and allow low frequencies through. This means that the circuit would put an inductor in series (to block high frequencies), and capacitors to ground (short high frequencies to ground).

2.3.4 Filter Steepness

In practice, filters can't instantly go from passing a frequency to blocking another. The change is gradual, and this is affected by the number of LC sections (called a pole). Each pole adds 20 dB/decade of rolloff. The higher this number, the more steep the dropoff, as it is saying that per decade (1 decade is a ratio of 10 between two numbers on a logarithmic scale), the scale drops by 20 dB.

Example. Consider a transmitter that produces a 7 MHz signal. The 2nd harmonic at 14 MHz and 3rd harmonic at 21 MHz must be suppressed. A good 5-element low-pass filter with a cutoff just about 7 MHz can suppress the 2nd harmonic by 40+ dB and the 3rd by 60+ dB. This is the difference between a clean signal and an interference complaint.

A typical transmitter low-pass filter has 5-poles (100 dB/decade, a steep slope). For critical applications, a 7-pole filter is used (140 dB/decade, a very steep slope).

2.3.5 Crystal Filters

Crystal filters have very high Q factors (10 000 to 100 000+). Multiple crystals combined in a so-called ladder filter give the sharp selectivity for IF stages

- 2.4 kHz bandwidth - for SSB reception
- 500 Hz bandwidth - for CW reception
- 6 kHz bandwidth - for AM reception

In modern radios however, crystals are being replaced with DSP (digital signal processing) filters, as they allow changing the bandwidth on the fly.

2.3.6 Filter Response Shapes

Different mathematical designs give different trade-offs. Butterworth designs have a smooth, flat passband with no ripple. This is used where consistent gain across the passband matters. Chebyshev has a steeper rolloff than Butterworth, but some ripple in the passband. This is used where sharp selectivity matters more than a perfectly flat response.

2.4 Amplifier Classes

2.4.1 Introduction

The final stage of a transmitter is a power amplifier. This amplifier will have some bias, and depending on how that bias is configured changes two important things. First is the linearity - how faithfully does the amplifier reproduce the signal shape (critical for SSB and AM). The second is efficiency - how much of the DC power becomes RF (all excess is heat).

2.4.2 Classes

These are the different classes of amplifiers

Table 3: Amplifier classes

Class	How it works	Efficiency	Linearity	Used for
A	Transistor conducts all the time (360°). Always on	25 – 50%	Excellent	Low-power stages, driver stages
AB	Conducts most of the time (180°-360°). Slightly biased below full-on	50 – 65%	Very good	Standard choice for SSB power amplifiers
B	Conducts exactly half the time (180°). Needs push-pull pairs	65 – 78%	OK	Push-pull audio amps
C	Conducts less than half the time (<180°). Very "punchy"	75 – 85%	Poor	FM and CW only

Important. Class C amplifiers are not suitable for SSB or AM. Both of these carry information in the variation in amplitude, so when class C clips the signal information is destroyed. It is fine for FM and CW as these modes have a constant amplitude.

Most HF transceivers use Class AB for the final PA. It is linear enough to handle SSB without excessive distortion, and efficient enough that a 400W output doesn't require a large heatsink. If a Class AB amp is overdriven (i.e. mic gain is too high), it starts producing intermodulation distortion. This is a "splatter" that interferes with adjacent frequencies.

2.4.3 Decibels

Decibels allows for working with ratios by simply adding and subtracting instead of multiplying and dividing.

Table 4: Shortcuts for working with decibels

dB	Power ratio	Voltage ratio	Notes
+3 dB	$\times 2$	$\times 1.41$	Double the power
+6 dB	$\times 4$	$\times 2$	Double the voltage
+10 dB	$\times 10$	$\times 3.16$	Ten times the power
+20 dB	$\times 100$	$\times 10$	Ten times the voltage
-3 dB	$\times 0.5$	$\times 0.71$	Half the power

Example. An amplifier has 13 dB of gain. That is $10 + 3 = \times 10 \times \times 2 = \times 20$ power. Put in 20W, get out 400W.

Info. The factor is 10 for power, 20 for voltage. That is because power is proportional to the voltage squared.

Power formula: $G_{dB} = 10 \log_{10}(P_{out}/P_{in})$.

Voltage formula: $G_{dB} = 20 \log_{10}(P_{out}/P_{in})$.

2.5 Oscillators

2.5.1 Introduction

An oscillator generates a continuous AC signal at a specific frequency. This is what the transmitter uses to generate the carrier signal, and the receiver needs one to convert signals to the IF. An oscillator is an amplifier where some of the output is fed back into the input in-phase (positive feedback).

In order for this to work correctly, two criteria must be met (known as the Barkhausen criteria). The first is that the loop gain must be greater than or equal to 1. The fed-back signal must be at least as strong as what is needed at the input. The second criteria is that the fed-back signal must be in phase so that it can reinforce the original signal.

2.5.2 Common Types

Colpitts Oscillator: uses two capacitors and one inductor. The two capacitors form a voltage divider for the feedback. It is very popular in VFOs (Variable Frequency Oscillators) as it is stable and easy to tune by varying one of the capacitors.

$$f = \frac{1}{2\pi\sqrt{L \cdot \frac{C_1 C_2}{C_1 + C_2}}}$$

Hartley Oscillator: uses one capacitor and a tapped inductor (or two inductors). The tapped inductor provides the feedback. This is less common in modern equipment.

Crystal Oscillator: uses a quartz crystal as the frequency determining element. The crystal has an extremely high Q (10 000+), making it incredibly stable. It is used for reference oscillators in synthesisers, BFO (Beat Frequency Oscillator) in CW/SSB receivers, and any application where frequency accuracy is critical.

Radio Connection. When tuning a HF radio, usually you are not changing the oscillator directly, rather modern radios use a PLL (Phase-Locked Loop) synthesiser. This is a crystal oscillator that provides the stable reference, and the PLL multiplies it to the frequency that you want.

2.5.3 PLL Frequency Synthesiser

The PLL is how modern radios generate precise, tunable frequencies. In simple terms:

1. A crystal reference provides an accurate, stable signal (e.g. 10 kHz)
2. A VCO (Voltage-Controlled Oscillator) generates the output frequency
3. A divider divides the VCO output down
4. A phase detector compares the divided output with the reference
5. If they don't match, it adjusts the VCO until they do.

$$f_{\text{out}} = N \times f_{\text{ref}}$$

Example. Consider a reference $f_{\text{ref}} = 10$ kHz and $N = 1450$. The output is then $f_{\text{out}} = 14.500$ MHz (20 metres). Changing N to 1451 gives $f_{\text{ref}} = 14.510$ MHz. This is how a tuning knob works in 10 kHz steps.

2.5.4 Mixers

A mixer takes two signals and produces their sum and difference frequencies

$$f_{\text{out}} = f_1 + f_2 \quad \text{and} \quad f_{\text{out}} = f_1 - f_2.$$

This is how receivers convert the signal you want to the IF, and how transmitters shift the generated signal to the operating frequency. The best type of mixer is the double-balanced mixer. This makes filtering much easier as it suppresses both input signals at the output, passing mainly the sum and difference products.

2.6 AGC and Power Supplies

2.6.1 Introduction

AGC (automatic gain control) automatically adjusts the gain of a receiver so that the audio level remains roughly constant. It works by

1. The receiver measures the strength of the incoming signal
2. This creates a control voltage
3. The control voltage adjusts the of the RF and IF amplifier stages

This allows for less gain with strong signals, and more gain with weaker signals. AGC can be either fast or slow. Fast AGC has a quick attack and release, which is best for CW and digital modes, and allows for quick recovery between elements. Slow AGC still has quick attack, however the release is slowed. This is best for SSB voice, and doesn't "pump" between syllables. Pumping is volume surging between words.

2.6.2 Power Supplies for Radio

Most amateur HF transceivers need a regulated 13.8V DC supply. There are two main types of power supply.

Linear power supply: simple and electrically quiet. Works by dropping excess voltage across a regulator, which turns into heat. The efficiency is dependent on the input and output voltages, i.e. $\text{efficiency} = V_{\text{out}}/V_{\text{in}}$. The result of all this is that it is preferred for HF because of low noise, however requires a large mains transformer.

Switch-mode power supply (SMPS): much more efficient and lighter, but can generate RF interference. It works by rapidly switching DC on and off (50-500 kHz), which is then usually passed through a filter to reduce noise. This is significantly cheaper and lighter than linear power supplied.

EMC Consideration. If a receiver has buzzing or whining that changes with tuning, the SMPS might be the cause. Ferrite chokes on the DC power leads dampen this, and keep the power leads away from the antenna feedline.

3 Transmitters and Receivers

3.1 The Superheterodyne Receiver

Trying to make a very narrow filter that can be tuned across the entire HF spectrum (3-30 MHz) would result in having to retune the filter each time the frequency changes. Superheterodyne (superhet) receivers solve this problem by instead of adjusting the filter, it modifies the signal such that it falls within the filter.

A superhet receiver is broken down into stages

1. RF Preselector: a broad filter that roughly selects the band of interest, and rejects signals that are obviously out of band.
2. Mixer + Local Oscillator (LO): The mixer combines the signal with the LO. This transforms the signal to match the IF. For example, if you are tuned to 14.200 MHz and the IF is 9 MHz, then the LO runs at 23.200 MHz (23.200-14.200=9.000 MHz)
3. IF Filter: this is fixed at 9 MHz (or whatever IF), and doesn't change when you tune. It provides the sharp selectivity required. Crystal or DSP filters are used here to determine the bandwidth.
4. IF Amplifier: This boosts the filtered signal (controlled by AGC).
5. Detector: Converts the IF signal back to audio. For SSB, this is a product detector (mixer with a BFO).
6. Audio Amplifier: Drives the output audio device.

3.1.1 The Image Problem

Because the mixer doesn't know which signal produced the 9 MHz difference, there is a second "image" of the signal placed at 2 times the IF. For example, if the LO is at 23.2 MHz, both a signal at 14.2 MHz and a signal at 32.2 MHz produce a 9 MHz signal.

$$f_{\text{image}} = f_{\text{signal}} \pm 2 \times f_{\text{IF}}$$

The RF preselector must be good enough to reject the image. A higher IF makes this easier as the separation between the frequencies is higher. High-end receivers combat this by first converting to a high IF (i.e. 45-70 MHz) to create the separation between the signal and the image, then convert to the final IF (9 MHz or 455 MHz), which allows for narrow and affordable crystal filters.

3.2 SSB

3.2.1 Introduction

Regular AM transmits a carrier plus two sidebands, but since the carrier carries no information and the sidebands carry the same information this is wasteful. Instead, SSB (single sideband modulation) removes the carrier and one sideband, which saves power and bandwidth. Generally, the process is

1. Audio amplifier: the amplified output of the microphone
2. Balanced modulator: mixes the audio with a carrier frequency. It still generates both sidebands, but suppresses the carrier. This is now called DSB-SC (Double Sideband, Suppressed Carrier)
3. Crystal filter: a very sharp band-pass filter that passes one of the sidebands and rejects the other

4. Mixer: shift the SSB signal from the filter up to the operating frequency
5. Power amplifier (Class AB): boosts the signal to the desired output power
6. Low-pass filter: removes the harmonics before transmitting

Convention. The global convention on which sideband is used is dependant on the frequency. When it is less than 10 MHz, the LSB (lower sideband) is used, and for 10 MHz and above, USB (upper sideband) is used.

3.2.2 The Phasing Method

Instead of using an expensive crystal oscillator, this method uses phase shifting to cancel one sideband mathematically. It requires precise 90° shifts in both the audio and RF paths. This is popular in SDR (software defined radio) as phase shifting is easy to do in software.

3.2.3 Balanced Modulator

The balanced modulator is a mixer that is specifically designed so that the carrier leaks through as little as possible. The output contains the two sidebands, but almost no carrier. That is why it is called balanced.

3.3 FM

3.3.1 Introduction

Whilst SSB (and AM) modulates the amplitude of the signal to carry voice, FM varies the frequency, and the amplitude remains constant. FM is used for most VHF/UHF communication (2m and 70cm repeaters), as it is simpler, more noise resistant, and sounds better than SSB for local communications.

For FM, there are three important values. The first is deviation (δf), and is a measure of how far the frequency swings from the carrier. For amateur narrow-band FM, this is ± 5 kHz. The next value is modulation index β , and this is the deviation divided by the audio frequency $\beta = \delta f / f_m$. The final value is the bandwidth (Carson's rule), and is given by

$$BW \approx 2(\delta f + f_m).$$

Example. With a ± 5 kHz deviation and 3 kHz maximum audio, bandwidth is given by $2(5 + 3) = 16$ kHz. This is why FM channels on 2m are spaced 12.5 or 25 kHz apart.

One of the biggest advantages of FM is that when two stations transmit on the same frequency, the stronger signal wins completely. The weaker signal is suppressed, not mixed in with the strong one.

Info. The capture effect is why FM works so well for repeaters. If two stations accidentally transmit at the same time, you hear the stronger one clearly and not a mix of both. With SSB, you'd hear both simultaneously.

3.3.2 Pre- and De-emphasis

FM noise gets worse at higher audio frequencies. To prevent this, transmitters (pre-emphasis) boost high audio frequencies before transmission, and receivers (de-emphasis) cut high audio frequencies after demodulation. The boost and cut cancel out for the unwanted signal, but the noise (which was not boosted) gets cut. This results in better signal-to-noise.

3.4 Receiver Performance

3.4.1 Introduction

On a busy HF band, a receiver might be dealing with signals ranging from barely detectable (-130 dBm), to extremely strong (-10 dBm), which is a range of over 100 million to one. Good receivers are able to handle both simultaneously.

3.4.2 Sensitivity

Sensitivity is limited by noise. Every receiver generates some internal noise, and the signal must be stronger than this noise floor to be heard. The noise figure of the front is the key specification, as it tells you how much noise the receiver adds compared to the perfect receiver.

Friis Formula. The noise figure of the first stage dominates, because noise from later stages gets divided by the gain of earlier stages. This is why a low-noise preamp at the antenna makes a big difference.

$$NF_{\text{total}} \approx NF_1 + \frac{NF_2 - 1}{G_1} + \frac{NF_3 - 1}{G_1 G_2} + \dots$$

3.4.3 Intermodal Distortion (IMD)

When two strong signals hit a receiver, any non-linearity creates phantom signals at new frequencies. The most troublesome are third-order products

$$f_{\text{IMD}} = 2f_1 - f_2 \quad \text{and} \quad 2f_2 - f_1.$$

This falls close to the original signals and cannot be filtered out.

Example. Two strong stations on 14.200 and 14.210 MHz create a phantom signal at $2(14.200) - 14.210 = 14.190$ MHz. If you are trying to hear a weaker station at the frequency, you would only be able to hear the IMD product.

IP3 (third-order intercept point) is the key specification from strong signal handling. Higher IP3 is better. This is the theoretical point where the IMD products would equal the wanted signal. This is never reached in practice.

3.4.4 Reciprocal Mixing

In the real world, no oscillator is perfect, they all have some sort of phase noise (random frequency jitter). When a strong off-channel signal mixes with this phase noise, it creates at the IF that buries weak signals. This means that a better oscillator gives better reception, and why more expensive radios perform better on crowded bands.

3.4.5 Dynamic Range

Dynamic range is the difference between the weakest signal the receiver can detect and the strongest signal it can handle without distortion. More dynamic range means better performance on busy bands. A receiver with 90 dB of dynamic range can simultaneously handle signals differing by 90 dB, which is about 1 billion to one in power.

4 Propagation

4.1 The Ionosphere

4.1.1 Introduction

The ionosphere is a layer of charged gas in the upper atmosphere (60-500 km), which is caused by ultraviolet radiation from Sol stripping away electrons. Because of this charge, HF signals are able to bounce off of this layer and travel thousands of kilometres.

4.1.2 The Layers

There are three main layers in the ionosphere.

The D Layer (60-90km) absorbs signals, but only exists during the daylight. It mostly affects signals below 10 MHz, but reflects barely any signals.

The E Layer (90-150km) is able to reflect signals up to 10 MHz (roughly) during the day, but also disappears during the night.

The F Layer (150-500km) is the most important layer for HF communication. During the day it is separated into a F1 and F2 layer, however recombines during the night to a single F layer. The F2 layer is the highest and has the most ionisation, and hence capable of the longest skip distances.

The day/night cycle of HF. During the day, the D layer absorbs low-band signals (80m, 40m), but the F2 layer supports higher bands (20m, 15m, 10m). At night, the D layer vanishes opening up the low bands, while the F layer weakens, which closes the high bands. This affects what bands to use at what times.

4.2 Selecting the Right Frequency

4.2.1 Introduction

For any given path between two stations, there's a range of frequencies that will work. Too high of a frequency and the signal will punch through the ionosphere, too low and the D layer absorbs it.

4.2.2 Maximum Usable Frequency (MUF)

The MUF is the highest frequency the ionosphere will return to Earth for a specific path. Above this, signal passes straight through into space. This frequency varies with time of day, season, solar cycle, and path length.

4.2.3 Minimum Usable Frequency (LUF)

This is the lowest frequency that provides a usable signal. Below this, the D layer absorption is too strong. The LUF is higher during the day and lower during the night.

4.2.4 Frequency of Optimum Traffic (FOT)

This is the most optimum frequency, given by

$$\text{FOT} = 0.85 \times \text{MUF}$$

This is the frequency for the most reliable communication.

Table 5: The best bands for different times		
Time	Best Bands	Notes
Daytime	20m, 17m, 15m, 12m, 10m	High MUF, D-Layer absorbs low bands
Evening	40m, 30m, 20m	D Layer fading, F layer still good
Night	160m, 80m, 40m	No D layer absorption, low MUF
Sunrise/sunset	160m, 80m (grey line)	Special propagation, see below.

4.2.5 Skip Distance and Skip Zone

When a signal goes up to the ionosphere and comes back down, it obviously does not come back down directly next to the transmitter. We call the minimum distance where the skywave signal returns to Earth the skip distance, and the area between where the ground wave fades out and where the skywave returns the skip zone (also known as dead zone). In general, a higher frequency corresponds to a longer skip distance. On 10m, the skip might be 1000+ km, where as 40m it might be 300km.

4.3 Special Propagation

4.3.1 Sporadic E

Sometimes a random patches of ionisation in the E layer can reflect signals well into the VHF range, especially on 6 metres (50 MHz), and even 2m. This is most common in the summer, but is very unpredictable. Single hop distances can be 500-2300 km.

4.3.2 Grey-Line Propagation

The grey-line is the sunset/sunrise boundary on Earth. Along this line, the D layer is either yet to form (sunrise), or has just disappeared (sunset), but the F layer still has enough ionisation to reflect signals. This creates a low-absorption "duct" that reflects signals on the low bands. This is a brief window, and both the transmitting and receiving stations must be on or near the grey line.

4.3.3 Tropospheric Ducting

Not all propagation has to involve the ionosphere. Temperature inversions in the lower atmosphere (troposphere, 0-12km) can create ducts that trap VHF/UHF signals. This is most common over water or flat terrain, and is often accompanied by fog or haze conditions. It can extend VHF/UHF range to 1000+ km.

4.3.4 Earth-Moon-Earth (EME/Moonbounce)

It is possible to bounce signal off of Lunar. This requires high-gain antennas, high power, and very sensitive receivers. The path loss is very high (approx 250+ dB). This is common on 144 MHz, 432 MHz, and 1296 MHz.

4.3.5 Satellite Communication

Amateur radio satellites (OSCAR series, etc) provide a relay capability. This can be difficult due to Doppler shift, and the need to track the satellite and continuously adjust frequency.

5 Antennas and Feedlines

5.1 Antenna Basics

5.1.1 Introduction

An antenna converts electrical energy (RF current from a transmitter) into electromagnetic waves that travel through space. On receive, it does the reverse. The simplest (effective) antenna is a half-wave dipole. This is

just a wire, half a wavelength long, split in the middle, and fed with coax.

5.1.2 The Half-Wave Dipole

The formula to calculate the length of a half-wave dipole is

$$L_{\text{metres}} = \frac{143}{f_{\text{MHz}}}.$$

This formula accounts for the end effect, where the electrical length is slightly shorter than the physical length.

Example Half-Wave Length. These are some common half-wave lengths.

For 40m band (7.1 MHz): $143/7.1 = 20.1$ metres total.

For 20m band (14.2 MHz): $143/14.2 = 10.1$ metres total.

For 2m band (146 MHz): $143/146 = 0.98$ metres total.

5.1.3 Gain

Antenna gain doesn't create extra power, it focuses the existing power in a preferred direction. Because of conservation of energy, this results in less gain the non-focused direction.

Gain is measured in two ways

- dBi: Compared to an imaginary perfect point source (called an isotropic radiator)
- dBd: Compared to a half-wave dipole

$$dBi = dBd + 2.15$$

A dipole has 2.15 dBi (or 0 dBd).

5.1.4 Other Properties

Antennas have a few other properties.

Radiation resistance is the resistance that accounts for the power actually being radiated. For a half-wave dipole in free space, this is

$$R_{\text{rad}} \approx 73\Omega$$

This is close to the 50Ω figure, but not exact. This is why a dipole has a slight SWR when fed with 50Ω coax. This discrepancy isn't enough to make it unusable.

Polarisation is another property. There are three types

- Horizontal: The dipole is mounted horizontally. This is standard for HF as the ionosphere scrambles polarisation anyway.
- Vertical: The dipole is mounted vertically. This is common for VHF/UHF mobile and base antennas.
- Circular: This is a dish, and is used on satellites as it handles random Faraday rotation in the ionosphere.

Cross-polarisation loss (horizontal antenna receiving a vertical signal) is about 20 dB, which is a significant loss. This is why matching polarisation matters.

The final property is effective radiated power (ERP). This is the power that appears to the be transmitter, taking antenna gain and feedline losses into account

$$ERP_{dBW} = P_{tx(dBW)} + G_{dBd} - L_{feedline(dB)}.$$

High-Power Yagi. With a 400W and a 3-element Yagi (7dBd) but a 1 dB feedline loss, the ERP is given by

$$26 + 7 - 1 = 32dBw = 1585W \text{ ERP.}$$

The 400W radio then looks like nearly 1600W in the antenna's main beam direction.

5.2 Directional Antennas

5.2.1 Introduction

A dipole radiates equally in two directions (broadside). If a station is in a specific direction, half the power is going the wrong way. This is why directional antennas are used, they focus the power (and receiving sensitivity) into a single direction.

5.2.2 Yagi-Uda Antenna

The most popular directional antenna for amateur radio is the Yagi-Uda (often called just Yagi) antenna. It has 3 main elements

- Reflector (behind): Slightly longer than $\lambda/2$, and reflects all the energy forward.
- Driven element (middle): This is about $\lambda/2$, and is the only element connected to the feedline.
- Directors (front): These are slightly shorter than $\lambda/2$, and are used to pull energy forward.

Table 6: Specs of Yagi Antennas

Elements	Gain (dBd)	Front-to-back	Notes
2	5	10 dB	Compact, good starter beam
3	7	15 dB	Most popular for 20m/15m/10m
5	9	20 dB	Good for series DX (distance)

Info. The front-to-back ratio is just as important as gain. It tells you how well the antenna rejects signals from behind. A 20 dB front-to-back ratio means stations behind are 100× weaker. This is good too reduce interference from any unwanted directions.

5.2.3 Quad Antenna

A quad antenna used full-wavelength square or diamond loops instead of straight elements. For the same boom length, a quad has significantly more gain than a Yagi and wider bandwidth. The drawback is that it is physically larger and harder to build.

5.2.4 Log-Period Dipole Array (LPDA)

This is the "broadband" directional antenna. Unlike a Yagi (which is designed for one band), and LPDA works across a wide range of frequencies, for example one antenna might be able to do 14-30 MHz. The downside of these is that the gain is lower than a Yagi on any single frequency. An LPDA gives maybe 5 dBd whereas a 3-element Yagi gives 7 dBd, but the LPDA covers many bands without switching.

5.3 Coax and Feedlines

5.3.1 Introduction

Feedlines carries RF from a transmitter to the antenna (and back for received signals). The most common type is a coaxial cable (coax), which is a center conductor surrounded by insulation, then a shield, then a jacket.

5.3.2 Characteristic Impedance

Every feedline has a characteristic impedance (Z_0) that is determined by its physical construction.

Table 7: Types of feedlines			
Type	Z_0	Loss (per 30m @ 150 MHz)	Best for
RG-58	50 Ω	6 dB (high)	Short runs, low power, patch leads
RG-213	50 Ω	3 dB	General HF use, moderate runs
LMR-400	50 Ω	1.5 dB (low)	VHF/UHF where loss matters
450 Ω ladder line	0.3 dB (very low)	Balanced antennas, lowest loss.	

Info. A good rule of thumb for feedline is use the lowest-loss cable possible, especially for VHF/UHF where loss really matters. If 3 dB of a signal is lost in the coax, half of the total power is turned into heat.

5.3.3 Velocity Factor

RF travels slower in a feedline than in free space (by definition). The velocity factor tells you how much slower. Some typical values are

- Solid polyethylene coax: 0.66 (i.e. 66% speed of light)
- Foam dielectric coax: 0.8
- Air-spaced line: 0.95

If you need a quarter-wave matching section of coax, then you must account for the velocity factor. A $\lambda/4$ section at 14 MHz in solid coax is shorter than expected

$$\frac{300}{14/4} \times 0.66 = 3.54m,$$

not the expected 5.36 metres.

5.3.4 Standing Wave Ratio (SWR)

When the impedance isn't matched between the antenna and feedline, some power reflects back. This creates standing waves on the feedline, measured as SWR. High SWR doesn't mean that all the reflected power is

Table 8: Affects of different SWRs		
SWR	Reflected Power	Notes
1.0:1	0%	Perfectly matched, this is theoretical Excellent Good Needs attention (use a tuner)
1.5:1	4%	
2.0:1	11%	
3.0:1	25%	
$\infty : 1$	100%	Open or short circuit, nothing radiates

lost, it just bounces back and forth until its radiated or lost as heat in the feedline. The actual problem is feedline loss. With low-loss feedline, even a high SWR isn't necessarily terrible, but with a lossy one it is much worse.

5.4 Impedance Matching and Baluns

5.4.1 Introduction

A transmitter is designed to deliver power into 50Ω . If the antenna system presents something different, a matching network is needed to transform the impedance. Without one, the transmitter may reduce power (via SWR protection), or produce excessive reflected power.

5.4.2 Antenna Tuner (transmatch)

This is the most common matching device. It sits between a transmitter and feedline, and transforms whatever impedance the antenna presents back to the 50Ω the transmitter wants. There are three common topologies

- L-Network: Two components (series + parallel). This is the simplest, and works well for a moderate mismatch range.
- T-Network: This is three components. It has a wide matching range and is most popular in commercial tuners. Can handle very high SWR.
- Pi-Network: Again three components It can also provide some harmonic filtering, and is common in valve amplifier output stages.

Important. An antenna tuner does not fix a bad antenna, it just tricks the transmitter into think everything is ok. The mismatch (and associated feedline losses) are still there between the tuner and antenna. The best approach is to make sure the antenna is resonant, then use the tuner for fine-tuning.

5.4.3 Quarter-Wave Transformer

A length of coax exactly $\lambda/4$ long with a specific impedance can transform one impedance to another. The require impedance of the matching section is then

$$Z_{\text{match}} = \sqrt{Z_1 \times Z_2}$$

Example. Match 50Ω coax to a 200Ω folded dipole.

$$\begin{aligned} Z &= \sqrt{50 \times 200} \\ &= \sqrt{10000} \\ &= 100\Omega. \end{aligned}$$

This means you want to use a $\lambda/4$ section of 100Ω coax (or two pieces of 50Ω in series).

5.4.4 Baluns

Baluns is BALanced to UNbalanced. A dipole is balanced, i.e. the two halves are symmetrical. Coax is unbalanced because the shield is grounded. Connecting them directly would cause problems. RF current would flow on the outside of the coax shield, the feedline would radiate (distorting the antenna pattern), and RF would get into the shack/station, which would cause interference with other equipment.

This problem is solved using a balun. There are two common types

- 1:1 current balun: No impedance change, just forces balanced currents. This is best for dipoles fed with 50Ω coax.
- 4:1 balun: transforms 200Ω balanced to 50Ω unbalanced. This is good for folded dipoles and some loop antennas.

Tip. A simple and effective 1:1 current balun can be made by winding 10-12 turns of coax through a ferrite toroid at the antenna feedpoint. This chokes off common-mode current on the coax shield.

5.4.5 The Smith Chart

The Smith chart is a graphical tool for impedance matching problems. There are few things to know

- Centre = 50Ω , SWR = 1:1
- Circles around the centre = constant SWR
- Upper half = inductive (positive reactance)
- Lower half = capacitive (negative reactance)
- Moving clockwise = moving towards the transmitter along the feedline.

5.5 DIY Antennas

5.5.1 Introduction

One of the things allowed under the Advanced license is that you can design, build, and modify your own antennas. Home-built antennas can perform just as well as commercial ones, and will provide a greater understanding.

5.5.2 Half-Wave Dipole

This is the simplest effective HF antenna. All it needs is a wire, centre insulator, two end insulators, and some coax. To build it

1. Calculate the length: The total length (as given above) is given by $L = 143/f_{\text{MHz}}$ metres. Each leg of the antenna is half of that
2. Cut the wire: Use insulated or bare copper/steel wire. Cut a little longer than calculated
3. Centre insulator: this is where the coax is connected. Solder the centre conductor to one leg, the shield to the other. Add a 1:1 choke balun

6 EMC and Interference

6.1 Understanding and Fixing Interference

6.1.1 Introduction

With the Advanced license allowing for up to 400W, there are two different sides that are likely to cause issues with EMI. The first is your signal interfering with others, such as TV interference (TVI), affecting neighbouring electronics, etc. The second is other things interfering with you, such as plasma TVs, LED lights, switch mode power supplies, solar inverters, etc.

There are two main paths for interference to get into

- Conducted: interference travels along cables, such as power leads, audio cables, Ethernet cables, antenna feedlines. The cables act as unintentional antennas.
- Radiated: interference travels through air as electromagnetic waves directly into the affected device.

In amateur radio, conducted interference via common-mode currents is usually the culprit. RF gets onto the outside of cables and enters equipment where it's not wanted.

6.1.2 EMC Toolkit

Ferrite chokers are the most common fix. Snap-on or toroidal ferrite cores around cables are the most useful EMC tool. They block common-mode currents while having minimal effect on the wanted signal. They can be used on DC power leads to the radio, coax feedline at the entry to the shack, or cables on affected equipment.

Low-pass filters can be placed after the transmitter to suppress harmonics of the transmitted signal. A 7 MHz signal has harmonics at 14, 21, 28 MHz, etc. These must be suppressed to legal limits. A good LPF gives 40-60 dB suppression.

High-pass filters go on affected devices, such as on a neighbour's TV antenna input to block HF signal.

Band-pass filters can be used for specific problems. They pass only the operating frequency and reject everything else. This is the best filtering, but only works on one band.

6.1.3 Intermodulation

If you overdrive your amplifier, it creates intermodulation product. These are spurious signals that interfere with other users. To prevent this, keep drive levels within the linear range of the PA.

6.2 EMR Safety

6.2.1 Introduction

At 400W with a directional antenna, you are generating significant RF fields near the antenna. Radio waves at sufficient intensity can cause tissue heating, and legally your station has to comply with safety limits.

In the far field, power density follows the inverse square law

$$S = \frac{P \times G}{4\pi d^2} \text{ W/m}^2$$

Where P is power (W), G is the antenna gain (linear, not dB), and d is the distance (m).

Example. 400W into a Yagi with 10 dBi gain (=10 linear):

- At 5 metres: $S = (400 \times 10)/(4\pi \times 25) = 12.7 \text{ W/m}^2$. This potentially exceeds limits.
- At 10 metres: $S = (400 \times 10)/(4\pi \times 100) = 3.2 \text{ W/m}^2$
- At 20 metres: $S = (400 \times 10)/(4\pi \times 400) = 0.8 \text{ W/m}^2$. This is safe for most limits

We can rearrange this for distance to get

$$d = \sqrt{\frac{P \times G}{4\pi \times S_{\text{limit}}}}$$

Rule of thumb for 400W. Keep people at least 10-15 metres from a directional HF antenna during transmission. The exact distance depends on the gain of the antenna and the applicable exposure limit for the frequency.

6.2.2 Australian Requirements

You must comply with ARPANSA RPS3 (Australian Radiation Protection and Nuclear Safety Agency Radiation Protection Standard). Key points from this

- Exposure limits vary with frequency
- General public limits are stricter than occupational limits

- Duty cycle matters. SSB and CW have lower average power than FM because they aren't a continuous transmission.

There are some practical safety measures

- Keep antennas high. This reduces exposure at ground level
- Use minimum power
- Consider duty cycle
- Restrict access to areas near antennas during transmission
- Never touch antenna elements or feedlines during transmission.

Near-field warning. The above formula are for far-field. Close the antenna, fields are complex and can be much stronger than the formula predicts. On 80m, a few wavelengths is 500+ metres, so for HF antennas you may always be in the near field at ground level. Use conservative estimates.

6.2.3 Worked EMC Examples

These are similar to questions on the exam.

Is my antenna safe. Problem: You're running 400W PEP into a 3-element Yagi with 7 dBi gain. Your neighbour's fence is 8 metres from the antenna. The exposure limit for your frequency is $2\text{W}/\text{m}^2$. Is it safe?

Answer

1. Convert gain from dBi to linear: $7\text{dBi} = 10^{(7/10)} = 5.01$
2. Calculate the power density: $S = PG/(4\pi d^2) = (400 \times 5.01)/(4\pi \times 64) = 2.94\text{W}/\text{m}^2$
3. Compare to limit: $2.94 > 2.0\text{W}/\text{m}^2$

This is not safe to operate like this.

What's the safe distance. Problem: Same setup, but now find the minimum safe difference for this limit.

Answer

1. Use the distance formula: $d = \sqrt{PG/(4\pi S_{\text{limit}})}$
2. Substituting the values: $d = \sqrt{(400 \times 5.01)/(4\pi \times 2)} = 8.93$ metres.

How much harmonic suppression is needed. Problem: Your 7 MHz transmitter produces a harmonic at 14 MHz that's 30 dB below the fundamental. The legal limit requires harmonics to be at least 50 dB below. How much additional filtering is needed.

Answer: You need an additional $50 - 30 = 20$ dB of suppression. A simple 3-element low-pass filter (3 poles times -20 dB/decade) would be marginal at one octave above cutoff. A 5-element filter would give a comfortable margin.

7 Measurements and Test Equipment

7.1 RF Power and Antenna Measurements

7.1.1 Measuring RF Power

There are two common pieces of equipment used for measuring RF power.

The first is the directional wattmeter. It measures forward power (power going to the antenna) and reflected power simultaneously. The net power to the antenna is then forward power minus reflected power. This also allows SWR to be calculated.

The other is a dummy load. This is a non-radiating 50Ω resistive load for testing transmitters without going on air. This allows for checking transmitter output power, adjusting drive levels, and testing without causing interference.

7.1.2 Power in Decibels

Instead of saying 0.001 watts or 400 watts, you can also use decibels referenced to a standard power level.

Table 9: Different ways to express power in decibels

dBm (ref: 1 mW)	dBW (ref: 1 W)	Actual Power
0 dBm	-30 dBW	1 mW
+30 dBm	0 dBW	1 W
+40 dBm	+10 dBW	10 W
+50 dBm	+20 dBW	100 W
+56 dBm	+26 dBW	400 W

7.1.3 Antenna Analyser

An antenna analyser sweeps across a frequency range and shows

- SWR vs frequency: shows where the antenna is resonant and how wide the usable bandwidth is
- Impedance: tells you if the antenna needs to be longer (capacitive) or short (inductive)
- Return loss: another way to express how well the antenna matches 50Ω

7.1.4 Frequency Counter

A frequency counter directly measures the frequency of a signal. The gate time determines the resolution. A 1 second gate means 1 Hz resolution, a 10 second gate means 0.1 Hz resolution. GPS-disciplined counters provide the highest accuracy timebase.

7.2 Practical Measurement Scenarios

My SWR is suddenly high on 20m. Tools needed: antenna analyser.

1. Disconnect the coax from the radio and connect the antenna analyser
2. Sweep 13-15 MHz and look at the SWR curve
3. If SWR is high everywhere: possible broken feedline or open connection, check connectors and cable
4. If SWR dip has shifted frequency: something has changed the antenna (i.e. damage). The analyser shows you where the resonance has moved to
5. If the impedance shows high R (e.g. 150Ω): possible feedline issue, water in the coax can change the impedance

Someone reports my signal has splatter. Tools needed: Spectrum analyser or SDR waterfall, dummy load

1. Connect transmitter to dummy load through a directional coupler or use a loose coupling to the

spectrum analyser

2. Transmit into the dummy load while speaking normally
3. Watch the spectrum. The signal should be clean with defined edges
4. If you see broad shoulders spreading beyond signal bandwidth, reduce mic gain or drive level
5. Check that ALC is not being driven excessively

I want to check my transmitter's harmonics. Tools needed: spectrum analyser, dummy load, attenuator

1. Connect transmitter to the dummy load through a low-pass filter, with a tap or coupler to the spectrum analyser
2. Use an attenuator between the coupler and spectrum analyser to avoid overloading it
3. Transmit a carrier and look for signals at 2, 3, and 4 times your fundamental frequency
4. Harmonics should be at least 40-50 dB below the fundamental
5. If they're not, the low-pass filter may be faulty or the wrong cutoff frequency

Table 10: Common power in measurement questions

Power	dBm	dBW
1 mW	0 dBm	-30 dBW
10 mW	+10 dBm	-20 dBW
100 mW	+20 dBm	-10 dBW
1 W	+30 dBm	0 dBW
10 W	+40 dBm	+10 dBW
100 W	50 dBm	+20 dBW
400 W	+56 dBm	+26 dBW

8 Regulations and Operating

8.1 Advanced License Privilege

8.1.1 Introduction

Australia has three amateur radio license grades

Table 11: The Australian radio license grades

Grade	Max power (PEP)	Bands	Other
Foundation	10 W	Limited bands and segments	Must use commercially built equipment
Standard	100 W	Most amateur bands	Can build/modify equipment
Advanced	400 W	All amateur bands, full segments	Full privileges, can supervise others

The max power limit is called PEP (Peak Envelope Power). This is the power at the peak of modulation envelope. For CW this is 400 W during key-down periods, for SSB this is 400 W on voice peaks (average power is much lower), and FM is 400 W continuous.

Warning. Even though you're allowed 400 W, you must always use the minimum power necessary for satisfactory communication. Running full power for a local communication is poor operating practice.

8.1.2 Station Identification

This is a legal requirement

- Identify at the beginning and end of a contact or series of transmissions
- Identify at least every 10 minutes during extended communications
- Use your assigned callsign
- /P suffix for portable operation
- /M suffix for mobile operation

8.1.3 Regulating Bodies

In Australia, amateur radio is regulated by three bodies

- ACMA (Australia Communications and Media Authority): this is the regulator that sets the rules and issues licenses
- WIA (Wireless Institute of Australia): this is the national society. It represents amateurs, administers exams, and publishes band plans
- ARPANSA: they set RF exposure safety standards that amateurs must comply with

8.1.4 Third-Party Traffic

You can pass messages for non-amateurs under the following conditions

- Messages must be personal or emergency-related
- Messages must not be commercial or business traffic
- International third-party messages only to countries with an agreement with Australia

8.2 Frequency Allocation

Advanced licensees have access to all amateur HF bands

Table 12: Available bands		
Band	Frequency	Description
160m	1.800-1.875 MHz	Night-only DX, challenging "top band"
80m	3.500-3.700 MHz	Regional at night, local during day. Aussie ragchew band
40m	7.000-7.300 MHz	Reliable by day and night
30m	10.100-10.150 MHz	CW and digital ONLY, no voice
20m	14.000-14.350 MHz	The main DX band, worldwide by day
17m	18.068-18.168 MHz	WARC band, DX, no contests
15m	21.000-21.450 MHz	Great during solar highs
12m	24.890-24.990 MHz	WARC band, DX, no contests
10m	28.000-29.700 MHz	Wide open during solar max, FM repeaters at top

Below is the full table of available frequencies

Note.

- 30cm is CW/digital only, no voice is permitted
- WARC (World Administrative Radio Conference) bands (30m, 17m, 12m) are not used for contests

Table 13: VHF/UHF Allocations

Band	Frequency	Primary use
6m	50-54 MHz	The magic band, sporadic E DX
2m	144-148 MHz	FM repeaters, SSB, satellites
70cm	420-450 MHz	FM, digital, satellites, ATV
23cm	1240-1300 MHz	Microwave experiments

Table 14: Available frequencies for an advanced qualification

Band	Frequency Range
2200m	135.700-137.800 kHz
630m	472.000-479.000 kHz
160m	1.800-1.875 MHz
80m	3.500-3.800 MHz
40m	7.000-7.300 MHz
30m	10.100-10.150 MHz
20m	14.000-13.350 MHz
17m	18.068-18.168 MHz
15m	21.000-21.450 MHz
12m	24.890-24.990 MHz
10m	28.000-29.700 MHz
6m	50.000-54.000 MHz
2m	144.000-148.000 MHz
70cm	420.000-450.000 MHz
23cm	1.240-1300 GHz
13cm	2.300-2.302 GHz
13cm	2.4-2.450 GHz
9cm	3.300-3.600 GHz
6cm	5.650-5.850 GHz
3cm	10.000-10.500 GHz
12mm	24.000-47.200 GHz
6mm	47.000-47.200 GHz
4mm	76.000-81.000 GHz
	122.250-123.000 GHz
	134.000-141.000 GHz
	241.000-250.000 GHz

- The Australian 2m band extends to 148 MHz, Europe is only 144-146 MHz

8.2.1 Band Plans

Within each band, the WIA publishes recommended band plans showing where different modes should be used

- CW occupies the lower portion of each band
- Digital modes have designated segments
- SSB phone occupies the upper portion
- Specific frequencies are designated for beacons, calling frequencies, and satellite operations

Band plans are voluntary, but following them is good operating practice and avoids conflicts between modes.

8.3 Operating Practices and Repeaters

8.3.1 Introduction

The advanced license has the most privilege, but the most responsibility. These are the important operating practices.

8.3.2 Repeater Operation

Repeaters receive on one frequency and retransmit on another simultaneous, which extends the range of low-power stations.

- Offset: the difference between the repeater's input and output frequencies. On 2m it is typically ± 600 kHz, and on 70cm it is typically ± 5 MHz
- CTCSS (Continuous Tone-Coded Squelch System): A sub-audible tone (eg 91.5 Hz) that your radio transmits alongside voice. The repeater only opens when it detects the correct tone which prevents false triggering from noise or other signals
- Timeout timer: most repeaters have a timer (typically 3-5 minutes), and if you transmit too long the repeater drops the signal. Keep transmissions short and leave gaps for others
- Linked repeaters: multiple repeaters linked together via the internet (IRLP, EchoLink) or microwave links, allowing wide-area coverage

8.3.3 Making a Call

On a repeater (FM):

1. Listen first, make sure the repeater isn't in use
2. Key up briefly and say your callsign: e.g. "VK2ABC listening" or "VK2ABC monitoring"
3. Wait for a response. If calling a specific station e.g. "VK2XYZ this is VK2ABC"

On HF (SSB):

1. Find a clear frequency. Ask "Is this frequency in use?" and listen
2. Call CQ: "CQ CQ CQ, this is VK2ABC, Victor Kilo Two Alpha Bravo Charlie, calling CQ and listening". CQ is a station code to make a general call to any operator listening
3. Or answer someone's CQ: "VK2XYZ, this is VK2ABC"

8.3.4 Signal Reports

There is the RST (Readability, Strength, Tone (CW only)) system. A typical good signal report on SSB is

Table 15: The RST system

Readability	Strength	Tone (CW only)
1 = Unreadable	1 = Faint	1 = Rough/harsh
3 = Readable with difficulty	5 = Fair	5 = Musical
5 = Perfectly readable	9 = Extremely strong	9 = Perfect tone

"59" (perfectly readable, extremely strong). On CW it might be "599" (perfectly readable, extremely strong, perfect tone).

8.3.5 Emergency Communications

Amateur radio can be very important when other communications fail in an emergency

- MAYDAY: Immediate threat to life, all stations must stop and listen
- PAN PAN: Urgent but not life-threatening
- In Australia, WICEN (Wireless Institute Civil Emergency Network) coordinates amateur emergency communication
- You may break frequency allocation rules during a genuine emergency to save a life or property

Note. In a genuine emergency where life is at risk, you are permitted to use any means of radio communication at your disposal, the normal rules about frequency allocation and power are suspended until the emergency is resolved.

9 Digital Modes and SDR

9.1 DSP

9.1.1 Introduction

Digital signal processing (DSP) is very important to modern amateur radio. Modern transceivers convert the RF signal to digital data, process it mathematically, then convert it back. This allows for

- Adjustable filter bandwidth, e.g. change from 2.4 kHz SSB to 500 Hz CW at the press of a button
- Noise reduction that actually works
- Notch filters that automatically find and remove interfering carriers
- All modulation/demodulation done in software

9.1.2 Sampling

To process a signal digitally, it must first be converted from continuously (analogue) to discrete samples (digital). The critical rule is Nyquist theorem

$$f_{\text{sample}} \geq 2 \times f_{\text{max}}.$$

This means you must sample at least twice as fast as the highest frequency in a signal. If the audio goes up to 3 kHz, you must sample at least 6 000 samples per second.

Note. If this is not done you get aliasing. Higher frequencies "fold back" and appear as false lower frequencies in the digital signal and sounds terrible. This is why every ADC has an anti-aliasing filter in front of it. This is low-pass filter that removes any frequencies above half the sample rate.

9.1.3 Quantisation

Each sample is assigned a digital value. More bits means finer resolution means wider dynamic range

$$\text{Dynamic range} \approx 6 \times n \text{ dB},$$

where n is the number of bits. So

- 12-bit ADC = 72 dB dynamic range

- 16-bit ADC = 96 dB dynamic range (CD quality)
- 24-bit ADC = 144 dB dynamic range (high-end audio/radio)

Shannon's channel capacity describes how much data can be squeezed through a noisy channel

$$C = B \log_2(1 + SNR),$$

where C is the maximum bits per second, B is the bandwidth in Hz, and SNR is the signal-to-noise ratio (linear).

Modern digital modes like FT8 approach the Shannon limit by using coding and long integration times. FT8 can decode signals at -24 dB SNR, i.e. sounds buried 250 times below the noise. This is why FT8 can work when you can't even hear the signal by ear.

9.2 SDR and Digital Modes

9.2.1 Introduction

In traditional radio, the signal processing is done by physical components such as crystal filters, analogue mixer, or discrete amplifiers. In a software defined radio (SDR), most of this is done in software. The hardware is simple, it is just an antenna, a few amplifiers, and an analogue-to-digital converter. Everything else is code.

There are two architectures for SDR

- Direct sampling: The ADC samples the RF signal directly. This requires very fast ADCs but is the simplest architecture
- Direct conversion (zero-IF): The RF is mixed down to baseband (0 Hz) and then sampled. Most common in amateur SDRs

SDRs use I (in-phase) and Q (quadrature) signals. These are two versions of the signal with 90 phase difference. Together they capture both the amplitude and phase of the signal, allowing any modulation type to be processed digitally. Think of I and Q as what the signal is doing and how it is changing, and this is enough information to reconstruct everything.

9.2.2 Digital Modulation Types

There are different ways to encode data onto a radio signal

Table 16: Types of digital modulation

Type	What changes	Example
FSK	Frequency	RTTY (170 Hz shift between two tones)
PSK	Phase	PSK31 (31 Hz bandwidth, very narrow)
QAM	Both amplitude and phase	High-speed data modes

Below are some popular amateur digital modes

Table 17: Popular amateur digital modes

Mode	Bandwidth	Can decode at	What it's for
FT8	50 Hz	-24 dB SNR	Weak signal DX
FT4	80 Hz	-17 dB SNR	Faster version for contests
PSK31	31 Hz	-10 dB SNR	Keyboard-to-keyboard chat
RTTY	300 Hz	-5 dB SNR	Classic digital, contesting
JS8Call	50 Hz	-22 dB SNR	Keyboard messaging, store-and-forward
Winlink/VARA	Adaptive	Varies	Email over radio

FT8 uses 15-second transmit/receiver cycles with LDPC error correction coding. Each message is only 77 bits, but it takes 12.6 seconds to send them. By spending a long time on very little data, it achieves incredible sensitivity. This is a practical application of Shannon's theorem.

9.2.3 Error Correction

There are two approaches to dealing with errors

- FEC (Forward Error Correction): Add extra data so the receiver can fix errors without asking for retransmission. Used in FT8, satellite links, anywhere retransmission is impractical
- ARQ (Automatic Repeat Request): If an error is detected (using CRC checks), ask the sender to retransmit. Used in Winlink, packet radio, works when a two-way link is available.

9.3 Getting Started with Digital Modes

9.3.1 Introduction

These are the basic steps to get up for digital modes. Most digital modes use your computer to generate and decode audio, with your radio handling the RF side

1. Radio: set to USB (upper sideband, not the protocol) on all bands for digital modes (even below 10 MHz where voice uses LSB)
2. Sound card interface: connects your computer's audio to the radio. Many modern radios have USB connects that handle audio and CAT control in one cable
3. Software: WSJT-X (for FT4/FT8), fldigi (for PSK31, RTTY, etc), or JS8Call
4. Accurate clock: FT8 requires your computer clock to be accurate to within ± 1 second. Use internet time sync or GPS

9.3.2 FT8 in Practice

FT8 (Franke-Tayler design, 8-FSK modulation) has become the most popular digital mode. Here is how it works operationally

- Transmit/receive periods alternate every 15 seconds, synchronised to the clock
- Each message is exactly 77 it, containing callsigns, grid square, and signal report
- A complete QSO (contact) takes about 75 seconds (5 exchanges)
- Power: 20-50 W is often plenty, FT8's sensitivity means you don't need a big signal

9.3.3 Common Digital Mode Frequencies

Table 18: Common frequencies for digital modes				
Band	FT8	FT4	PSK31	RTTY
40m	7.074 MHz	7.047 MHz	7.040 MHz	7.040 MHz
20m	14.074 MHz	14.080 MHz	14.070 MHz	14.080 MHz
15m	21.074 MHz	21.140 MHz	21.070 MHz	21.080 MHz
10m	28.074 MHz	28.180 MHz	28.120 MHz	28.080 MHz
6m	50.318 MHz	50.318 MHz	50.305 MHz	-

9.3.4 APRS

APRS (Automatic Packet Reporting System) is a real-time tactical communication system using packet radio

- Transmits your GP's position, weather data, or short messages
- on 145.175 MHz in Australia (VK)
- Station appear on maps (`aprs.fi` or similar)
- Useful for tracking during portable operations, SOTA (Summits On The Air), and emergencies

Tip. Know that digital modes conventionally use USB on all bands. Also know the basic FT8 timing (15-second periods) and that FT8 can decode at approximately -24 dB SNR, far below what can be hear by ear.

10 Safety

10.1 Electrical Safety

At 400 W, your equipment handles voltages and currents that can kill. Valve amplifiers in particular have 2000-4000V DC on the plates, this is instantly lethal. Even solid-state equipment at 400 W produces dangerous RF voltages.

At 1mA AC, you can feel tingling. At 10-20mA AC muscles lock up, this is called the let-go threshold because you are physically unable to let go. At 50-100mA AC you get heart fibrillation, which is potentially lethal. Anything greater than this results in cardiac arrest and severe burns.

10.1.1 Essential Safety Rules

- Never work on powered equipment. Always disconnect power before opening enclosures
- Discharge capacitors. Large filter capacitors in power supplies can hold lethal charges for hours after power off. Use a bleeder resistor or insulated discharge probe
- One-hand rule: when near any energised circuit, keep one hand in your pocket. This prevents a current path through your chest (hand-to-hand across the heart is the most dangerous path)
- Use an isolation transformer when working on mains-connected equipment
- Fuse everything properly. The correct fuse rating is your last line of defence
- Earth all equipment cases. If a fault energises the case, the earth path should blow the fuse before you touch it
- Safety interlocks: amplifier cabinets should have interlocks that cut power when opened

If someone gets electrocuted

1. Do not touch them while they are in contact with the electrical source, you will become part of the circuit
2. Disconnect power if possible, or use a non-conducting object (dry wood, plastic) to separate them from the source
3. Call 000
4. Begin CPR if they're not breathing and have no pulse
5. Treat burns if present

10.1.2 RF Burns

Touching an antenna element, feedline connection, or matching component during transmission can cause painful RF burns. These are thermal injuries, the RF heats tissue from the inside. They can be deep and slow to heal. Never touch any part of the antenna system when transmitting.

10.2 Lightning Protection and Tower Safety

10.2.1 Introduction

Amateur antennas, especially towers, are excellent lightning targets. A direct strike carries 20 000-200 000 amps. No surge protector can stop a direct hit. The goal of lightning protection is to provide a safe path to ground and disconnect when a storm is likely.

10.2.2 Grounding

- Single-point ground: all station grounds (radio, amplifier, accessories, feedlines) should connect to one common point, which then connects to the earth ground system
- Ground rods: at least 2.4 metres long, driven into the earth. Multiple rods bonded together are better
- Bond to building ground: your station must connect to the building's electrical earthing system
- Feedline grounding: all coax shields should be grounded where they enter the building, using gas-discharge surge protectors

The single most effective protection is physically disconnecting all antenna feedlines from your equipment and ground them outside the building when storms are approaching. This is the only reliable protection against a direct or nearby strike.

10.2.3 Tower Safety

Tower work is the most physically dangerous activity in amateur radio. Falls are fatal. There are some absolute rules

- Never climb alone, always have someone on the ground who can call for help
- Always use a climbing harness and safety belt properly rated and inspected
- Hard hats for both the climber and ground crew (dropped tools fall fast)
- No climbing in bad weather, wind, rain, or any change of lightning

This is the most critical safety consideration for antenna and tower installation

Warning. If an antenna or tower contacts power lines, the result is likely death. Maintain generous clearance from all power lines. A falling tower or antenna must not be able to reach any power line. Check with the local power authority for specific clearance requirements. When in doubt, increase the distance.

10.2.4 Minimum Safe Voltage

Generally, voltages above 30V AC or 42V DC are considered potentially dangerous. Below these levels, normal dry skin resistance usually prevents dangerous current flow. Above them, take full electrical safety precautions.

10.3 Building a Safe Station

10.3.1 Introduction

Whether you are putting together a home shack or a portable setup, safety should be designed in from the start.

10.3.2 Shack Layout

- Keep high-voltage equipment enclosed. Amplifier cabinets should have covers in place during operation
- Ensure adequate ventilation. 400 W amplifiers generate significant heat. Don't put them in closed cabinets without airflow
- Have a master power switch near the operating position that can cut all power to the station quickly
- No food or drinks near equipment. Spilled liquid on electronics can be dangerous and damaging
- Fire extinguisher. Have a CO2 or dry powder extinguisher rated for electrical fires (Class E/BE) within reach

10.3.3 Grounding Your Station

Good grounding serves three purposes: safety, lightning protection, and RF noise reduction.

- Safety ground: All equipment cases connected to mains earth via the power plug. This is the primary shock protection, if a fault puts voltage on the case, the earth path should trip the breaker
- RF ground: A low-impedance path to earth for RF. Helps with antenna system performance and reduces RF in the shack. Short, heavy copper strap works best
- Lightning ground: Heavy conductors bonded to earth rods at the building entry point. All feedlines grounded here.

All three ground types should connect to a single common point. Having multiple ground paths at different potentials creates dangerous ground loops during a lightning strike and can cause equipment damage.

10.3.4 Portable Operation Safety

Portable operation (field days, SOTA, POTA) brings its own hazards.

- Temporary antennas: Make sure no one can touch antenna wires during transmission. Mark them clearly
- Generators: Keep them outdoors. Use an RCD/safety switch
- Batteries: LiPo batteries can catch fire if damaged or short-circuited. Use proper cases and never leave charging unattended
- Weather awareness: Pack up if there is a threat of lightning, the portable mast is likely the tallest object around
- Sun and heat: Heatstroke can impair judgement

10.3.5 EMR Compliance Documentation

For your home station, you should document

- Antenna type, gain, and height
- Maximum power you'll use on each band
- Calculated power densities at accessible locations
- Comparison to ARPANSA RPS3 limits
- Any mitigation measures (restricted access areas, reduced power, etc)

Keep this documentation on file. If there is ever a complain or injury, these can be used to demonstrate compliance.