Data packet format

uint8 cmd									Member	Description	Reply
uint8 bytes [0]	uint8 bytes [1]	uint8 bytes [2]	uint8 bytes [3]	uint8 bytes [4]	uint8 bytes [5]	uint8 bytes [6]	uint8 bytes [7]	uint8 bytes [8]	uint8 bytes [9]		
uint8 <i>'R'</i>	uint8 addr								struct Register R	Read register	uint8 value
uint8 'W'	uint8 addr	uint8 value							struct Register R	<u>W</u> rite register	OK\n
uint8 <i>'F'</i>	uint16 fluidics_delay_m s								struct Fluidics F	Set <u>F</u> luidics injection delay	OK\n
uint8	uint8 active	uint8 idle	bool ALEX						struct Shutter S	Set <u>L</u> aser shutter states	OK\n
uint8 <i>'C'</i>	uint16 exp_time_n64us		uint16 n_frames						struct Timer1 T1	Start <u>C</u> ontinuous timer	OK\n
uint8 'S'	uint16 exp_time_n64us		uint16 n_frames		uin interfi time_	_	uin timela dela	apse_	struct Timer1 T1	Start <u>S</u> troboscopic timer	OK\n
uint8 'E'	uint16 exp_time_n64us								struct Timer1 T1	Change Exposure time	OK\n
uint8 'Q'										Stop timer (<u>Q</u> uit)	OK\n

Legend

Color shows belonging to a particular data structure.

Normal font shows data type (uint8, uint16).

Bold font shows member names.

Bold italic shows constant values.

Gray hatched areas are filled with ZERO.

Notes

Each data packet is always 9 byte long. If shorter than 9 bytes, pad it with zeros.

On startup, the system prints *Arduino is ready*. *Firmware version:* <x.y.z>\n

Wrong formatted packets are silently ignored (wrong command or shorter than 9 bytes).

If a command has wrong arguments, the reply is $ERR \setminus n$