

# IntelliFlash API Reference

Version 2.8 (Part Number: 96-00591-001)



## **Notice**

# **Legal Disclaimer**

Tintri by DDN, Inc. does not recommend the use of its IntelliFlash products in life support applications wherein a failure or malfunction of the product may directly threaten life or injury.

Accordingly, in any use of IntelliFlash products in life support systems or other applications where failure could cause damage, injury, or loss of life, the products should only be incorporated in systems designed with appropriate redundancy, fault tolerant or back-up features. The user of IntelliFlash products in life support or other such applications assumes all risk of such use and agrees to indemnify, defend, and hold harmless Tintri by DDN, Inc. against all damages.

This document and related material are for information use only and are subject to change without prior notice. Tintri by DDN, Inc. assumes no responsibility for any errors that may appear in this document or related material, nor for any damages or claims resulting from the furnishing, performance, or use of this document or related material. Absent a written agreement signed by Tintri by DDN, Inc. or its authorized representative to the contrary, Tintri by DDN, Inc. explicitly disclaims any express and implied warranties and indemnities of any kind that may, or could, be associated with this document and related material, and any user of this document or related material agrees to such disclaimer as a precondition to receipt and usage hereof.

Each user of this document or any product referred to herein expressly waives all guaranties and warranties of any kind associated with this document any related materials or such product, whether expressed or implied, including without limitation, any implied warranty of merchantability or fitness for a particular purpose or non-infringement. Each user of this document or any product referred to herein also expressly agrees Tintri by DDN, Inc. shall not be liable for any incidental, punitive, indirect, special, or consequential damages, including without limitation physical injury or death, property damage, lost data, loss of profits or costs of procurement of substitute goods, technology, or services, arising out of or related to this document, any related materials or any product referred to herein, regardless of whether such damages are based on tort, warranty, contract, or any other legal theory, even if advised of the possibility of such damages.

This document and its contents, including diagrams, schematics, methodology, work product, and intellectual property rights described in, associated with, or implied by this document, are the sole and exclusive property of Tintri by DDN, Inc. No intellectual property license, express or implied, is granted by Tintri by DDN, Inc. associated with the document recipient's receipt, access and/or use of this document or the products referred to herein; Tintri by DDN, Inc. retains all rights hereto.

#### **Contact information**

#### **Address**

9351 Deering Avenue, Chatsworth, California 91311, USA

#### **Phone**

- +1 800-837-2298 or +1 818-700-4000
- © 2023 Tintri by DDN, Inc. All rights reserved.

#### https://www.tintri.com.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means: electronic, mechanical, photocopying, recording or otherwise, without the prior written consent of Tintri by DDN, Inc.

IntelliCare, IntelliFlash, the IntelliFlash logo, and IntelliShell are registered trademarks or trademarks of Tintri by DDN, Inc. in the US and/or other countries. VMware, VMware ESXi, VMware vSphere, and VMware vCenter are registered trademarks or trademarks of VMware, Inc. in the United States and/or other jurisdictions. All other marks are the property of their respective owners. Product specifications subject to change without notice. Pictures shown may vary from actual products. Not all products are available in all regions of the world.

# **Contents**

Chapter 1: Introduction to th	e IntelliFlash Rest APIs	1
API Version History		2
Scope of the API		11
Error and Exception Handling in	the API	12
curl Syntax		13
Using the API Examples		13
Creating a Volume and Exposing	g It	14
Backing Up a Volume		14
Chapter 2: Sample Programs	S	17
•		
Chanter 3: User and Group	Methods	22
•		
•		
•		
5 ,		
<u>.</u>		
นยเยเยบสเสรยโ		6∠

deleteDatasetdeleteDataset	63
deleteMappingFromProjectdeleteMappingFromProject	65
deletePooldeletePool	68
deletePooldeletePool	70
deleteProjectdeleteProject	71
deleteProjectdeleteProject	73
deleteSharedeleteShare	75
deleteSharedeleteShare	77
deleteSharedeleteShare	79
deleteVolumedeleteVolume	
deleteVolumedeleteVolume	
deleteVolumedeleteVolume	85
exportPool	86
getCopyStatus	
getDatasetSpaceInfo	
getFloatingIPList	
getPoolSpaceInfo	
getProject	
getProject	
getProjectProperty	
getSharegetShare	
getShare	
getShareProperty	
getVolumegetVolume	
getVolume	
getVolumeProperty	
importPool	
inheritPropertyFromProject	
isProjectExposedOverNFS	
isShareExposedOverNFS	
listAllCopyOperations	
listLunsByld	
listPools	
listProjects	
listRunningCopyOperations	
listShares	
listSharesByMountPoints	
listVolumes	
modifyProjectProperties	
modifyProjectProperties	
modifyShareProperties	
modifyShareProperties	
modifyVolumeProperties	
modifyVolumeProperties	
resetPoolError	
setNFSSharingOnProject	
setNFSSharingOnShare	
modifyACLInheritanceOfShare	
netKerherosInfo	161

enableKerberos	164
disableKerberos	165
pter 5: SAN Methods	
addInitiatorToInitiatorGroup	
createFCInitiator	
createInitiatorGroup	
createlscsilnitiator	
createISCSITarget	
createISCSITargetForGroup	
createMappingForVolume	
createMappingForVolume	
createTargetGroupdeleteInitiatorGroup	
deletelSCSIInitiator	
deletelSCSITrittatordeletelSCSITraget	
deleteMappingFromVolume	
deleteTargetGroupdeleteTargetGroup	
getInitiatorGroup	
getProjectDefaultFcITView	
getProjectDefaultIscsiITView	
getVolumeITView	
initiatorGroupExists	
listFCInitiators	
listFCInitiatorGroups	
listFCTargets	
listFCTargetGroups	
listInitiatorGroups	
listISCSIInitiatorGroups	
listISCSIInitiators	209
listInitiatorsInInitiatorGroup	212
listISCSITargetGroups	213
listISCSITargets	
listProjectDefaultIscsiMappings	215
listProjectDefaultFCMappings	217
listTargetGroups	
listTargetsInTargetGroup	
listVolumeMappings	
modifyISCSITargetAlias	
moveTargetToTargetGroup	
moveInitiatorToInitiatorGroup	227
pter 6: Snapshot Methods	231
cloneProjectSnapshot	
cloneReplicaProjectSnapshot	
cloneReplicaSubProjectSnapshot	
cloneShareSnapshot	

	cione voiume Snapshot	239
	cloneVolumeSnapshot	241
	createProjectSnapshot	243
	createShareSnapshot	244
	createSnapshotSchedule	
	createVolumeSnapshot	
	deleteProjectSnapshot	
	deleteSubshareSnapshot	
	deleteShareSnapshot	
	deleteSnapshotSchedule	
	deleteSnapshotSchedule	
	deleteSnapshotSchedules	
	deleteSnapshotSchedules	
	deleteVolumeSnapshot	
	getProjectCloneStatus	
	getProjectSnapshotCreationStatus	
	getShareSnapshotCreationStatusgetShareSnapshotCreationStatus	
	getSnapshotSchedule	
	getVolumeSnapshotCreationStatus	
	inheritSnapshotSettingsFromProject	
	isSnapshotSchedulesInheritedFromProject	
	listDependenciesAndSnapshotCountOnDelete	
	listDependenciesAndSnapshotCountOnRollback	
	listSnapshots	
	rollBackToProjectSnapshot	
	rollBackToShareSnapshot	
	rollBackToVolumeSnapshot	287
Cł	hapter 7: Synchronous Replication Methods	289
	configureSyncReplicationSetUp	
	getSyncReplicationSetUp	
	getSyncReplicationStatus	
	getSyncReplicationPoolPairObjects	
	setSyncReplicationPoolPairObjects	
	startSyncReplication	
	stopSyncReplication	
	unconfigureSyncReplicationSetUp	
C	hapter 8: Asynchronous Replication Methods	
	getReplicationConfigList	306
	getReplicationStatus	307
	startReplication	309
CŁ	hapter 9: NAS Audit Methods	<u>3</u> 11
<b>J</b> .	enableAudit	
	disableAudit	
	MIDUDIO/ MUIL	

	isAuditEnabled	314
	getAuditConfig	315
	setAuditConfig	317
	addAuditDatasetAccessProtocol	319
	removeAuditDatasetAccessProtocols	321
	addNetworkACLForAuditDataset	323
	setNetworkACLForAuditDataset	326
	removeNetworkACLForAuditDataset	328
	modifyAuditShareProperties	330
	bringUserAuditLogsUpToDate	
	getNotificationById	333
CI	hapter 10: System Methods	337
O.	getDiskCount	
	•	
	getDisksgetDisksByChassis	
	getSMBConfig	
	getUpgradeHistory	
	identifyDisk	
	identifyDiskByIndex	
	isProjectExposedOverSMB	
	isShareExposedOverSMBisShareExposedOverSMB	
	listSystemProperties	
	setSMBConfig	
	setSMBSharingOnProject	
	setSMBSharingOnShare	
	fetchContollerStatus	
CI	hapter 11: Network ACL Methods	363
	addNFSNetworkACLOnProject	364
	addNFSNetworkACLOnShare	367
	addSMBNetworkACLOnProject	370
	addSMBNetworkACLOnShare	
	getNFSNetworkACLsOnProject	377
	getNFSNetworkACLsOnShare	
	getSMBNetworkACLsOnProject	381
	getSMBNetworkACLsOnShare	383
	inheritNetworkACLsettingsFromProject	
	removeAllNFSNetworkACLsOnProject	
	removeAllNFSNetworkACLsOnShare	
	removeAllSMBNetworkACLsOnProject	
	removeAllSMBNetworkACLsOnShare	
	removeNFSNetworkACLOnProject	
	removeNFSNetworkACLOnShare	
	removeSMBNetworkACLOnProject	
	removeSMBNetworkACLOnShare	
	setNFSNetworkACLsOnProject	402

setNFSNetworkACLsOnShare	
setSMBNetworkACLsOnProject	410
setSMBNetworkACLsOnShare	413
Chapter 12: SNMP Methods	417
addSNMPTrapListener	418
disableSNMPService	
enableSNMPService	421
getSNMPSettings	423
isSNMPServiceEnabled	
modifySNMPCommunityString	425
recreateSNMPTables	427
removeSNMPTrapListener	428
resyncSNMPTables	430
Chapter 13: Analytics Methods	433
getOneMinuteSystemAnalyticsHistory	
getOneMinuteDataAnalyticsHistory	
Chapter 14: Notification Methods	465
acknowledgeNotifications	
getRecentNotifications	
getRecentCriticalNotifications	
listNotifications	
Chapter 15: Objects	477
ArrayUpgrade_V2_1	
ArrayOpgrade_v2_1 AuditConfig_V2_6	
AuditCoring_vz_oAuditDataset_V2_6	
CopyDestination_V2_1	
CopySource_V2_1	
CopyStatus_V2_1	
DataAnalyticsResult_V2_3	
DatasetProperty_V2_1	
DatasetSpaceInfo_V2_1	
DatasetStatus	
Disk_V2_1	
FCInitiator_V2_1	
FCTarget_V2_1	
FloatingIP_V2_2	
InitiatorGroup_V2_1	
IscsiInitiator_V1_0	
ISCSIInitiator_V2_1	
ISCSITarget_V2_1	
ISCSITargetCreate_V2_1	
ITView_V2_1	

	LocalGroup_V1_2	
	LocalUser_V1_2	490
	LunStatus	491
	Mapping_V2_4	492
	NasAuditState	492
	NetworkACL_V2_1	493
	Notification_V2_3	493
	Notification_V2_6	493
	Pool_V1_0	
	PoolSpaceInfo_V2_1	
	Project_V1_0	
	Project_V1_2	
	Project_V2_1	
	Project_V2_4	
	ProjectCloneProgressStatus_v1_2	
	ReplicationConfig_V1_2	
	ReplicationStatus_v1_2	
	Schedule_V2_1	
	Share_V1_0	
	Share_V2_1	
	Share_V2_4	
	ShareOptions	
	SharePermissions	
	SharePermissions_V2_6	
	SMBConfig_V2_2	
	SnapShotDeletionStatus	
	SnapshotProgressStatus	
	SnapshotSchedule_V2_1	
	SNMP_Setting_V2_1	
	SyncReplicationPeerConfig_V2_5	
	SyncReplicationPoolPairConfig_V2_5	
	SyncReplicationQuorumConfig_V2_5	
	SyncReplicationSetUp_V2_5	
	SyncReplicationStatus_V2_5	
	SystemAnalyticsResult_V2_3	
	TargetGroup_V2_2	
	Volume_V1_0	
	Volume_V2_1	
	Volume_V2_4UserACL (Read Only) v2.1	
	USEIACL (Read Offiy) vz.1	524
Cha	apter 16: Enumerations	525
	CLEANUP_STATUS	
	CLONE_PROGRESS_STATUS	526
	COMMAND_STATUS	
	Mode_enum	
	OVERWRITE_STATUS	
	Permission_type_enum	527

Replication_Scope_Option	528
SNAPSHOT DELETION STATUS	528
	528
	529
	530
Appendix A: Appendix A	531
JSON Quick Reference	

# **Preface**

### **Audience**

The IntelliFlash API Reference contains detailed information about using the IntelliFlash REST APIs.

The IntelliFlash *API Reference* is intended for developers and solution engineers creating applications using the IntelliFlash REST APIs.

### **IntelliFlash Documentation**

The following table lists the technical documentation library available for the IntelliFlash systems.

**Table 1: IntelliFlash Documentation** 

Name	Description	
IntelliFlash N-Series N6100/N6200 NVMe Storage Systems Hardware Guide	Contains detailed descriptions, hardware specifications, and rack installation instructions for the N-Series N6100/N6200 NVMe Storage Systems.	
IntelliFlash H-Series H6100/H6200 Hybrid Storage Systems Hardware Guide	Contains detailed descriptions, hardware specifications, and rack installation instructions for the H-Series H6100/H6200 Hybrid Storage Systems.	
IntelliFlash User Guide	Contains detailed instructions on how to configure, use, and administer IntelliFlash H-Series Hybrid Storage Systems and N-Series NVMe Storage Systems.	
IntelliFlash API Reference	Contains detailed descriptions of the IntelliFlash REST APIs.	
IntelliFlash Configuration Guide	Contains instructions on configuring IntelliFlash arrays.	
IntelliFlash CSI File Driver User Guide	Contains instructions on installing and using the CSI File driver.	
IntelliFlash Release Notes	Contains information about new features, enhancements, fixed issues, and known issues in IntelliFlash releases.	
IntelliFlash PowerShell Toolkit Guide	Contains information about IntelliFlash PowerShell Toolkit.	

#### Webdocs Documentation

The IntelliFlash webdocs are available under the System Information panel at the top right corner of the IntelliFlash Web UI. Click the name of your array, then navigate to **Help** > **User Docs** to access the webdocs landing page.



• **Note:** To update the documentation set, your IntelliFlash array must have access to the Internet.

The IntelliFlash webdocs include the following documents in HTML and PDF formats:

- IntelliFlash User Guide
- IntelliFlash API Reference

You can update the IntelliFlash webdocs from the Software Upgrade page of the IntelliFlash Web UI to access the latest documentation.

To update the webdocs documentation, complete the following steps:

- 1. Log in to the IntelliFlash Web UI.
- 2. Click Settings > Administration > Software Upgrade.
- 3. (Optional) Click **Automatic Download** if it is not already enabled.
- 4. Verify the **Notifications** page for the following notifications:
  - If the latest documentation is available and downloaded:
     Webdocs upgrade download is completed on node '<node\_name>'.
  - If the latest documentation is not available:

No newer upgrade downloads were available for webdocs for node '<node\_name>'.

You may also observe other notifications related to webdocs.

# Support

IntelliFlash support services give you access to online, telephone, and onsite support. IntelliFlash support provides multiple levels of support through a Technical Support team and Field Engineers. For details on support offerings, contact your account team.

# **Document Revision History**

Date	Description	
April 17, 2023	Update for the new APIs included in IntelliFlash REST APIs version 2.8.	
	The following new APIs are included:	
	<ul> <li>deleteShare</li> <li>deleteVolume</li> <li>deletePool</li> <li>deleteProject</li> <li>deleteSnapshotSchedule</li> <li>deleteSnapshotSchedules</li> <li>deleteSubshareSnapshot</li> <li>Revised the API "getVolumeProperty" to update the parameters.</li> </ul>	
December 16, 2022	Update for the new APIs included in IntelliFlash REST APIs version 2.7.	
	The following new APIs are included:	
	modifyACLInheritanceOfShare	
	<ul><li>getKerberosInfo</li><li>enableKerberos</li></ul>	
	disableKerberos	
	fetchContollerStatus	
August 05, 2022	Update for the new APIs included in IntelliFlash REST APIs version 2.6.	
	The following new APIs are included:	
	enableAudit	
	<ul><li>disableAudit</li><li>isAuditEnabled</li></ul>	
	• getAuditConfig	
	<ul><li>setAuditConfig</li><li>addAuditDatatsetAccessProtocol</li></ul>	
	removeAuditDatatsetAccessProtocols	
	addNetworkACLForAuditDataset	
	<ul><li>setNetworkACLForAuditDataset</li><li>removeNetworkACLForAuditDataset</li></ul>	
	modifyAuditShareProperties	
	bringUserAuditLogsUpToDate	
	getNotificationById	

Date	Description
July 24, 2020	Update for the new APIs included in IntelliFlash REST APIs version 2.5.
	The following new APIs are included:
	<ul> <li>configureSyncReplicationSetUp</li> <li>getSyncReplicationStatus</li> <li>getSyncReplicationPoolPairObjects</li> <li>setSyncReplicationPoolPairObjects</li> <li>startSyncReplication</li> <li>stopSyncReplication</li> <li>unconfigureSyncReplicationSetUp</li> </ul>

# **Chapter 1**

## Introduction to the IntelliFlash Rest APIs

#### **Topics:**

- API Version History
- Key Features
- Scope of the API
- Unified APIs
- Error and Exception Handling in the API
- Error Codes
- curl Syntax
- Using the API Examples
- Creating a Volume and Exposing It
- Backing Up a Volume

The IntelliFlash Rest APIs provide an interface to securely configure and provision storage on IntelliFlash using a programming or scripting language. It enables you to integrate IntelliFlash arrays with third-party software. It also allows you to automate common and repetitive tasks, such as retrieving a list of volumes and their status, provisioning new volumes, and creating and managing snapshots.

# **API Version History**

APIs	Introduced in API Version	First Available IntelliFlash Version
deleteShare		
deleteVolume		
deletePool		
deleteProject	2.8	IntelliFlash 3.11.5.0
deleteSnapshotSchedule		
deleteSnapshotSchedules		
deleteSubshareSnapshot		
modifyACLInheritanceOfShare		
getKerberosInfo		
enableKerberos	2.7	IntelliFlash 3.11.4.2
disableKerberos		
fetchContollerStatus		
enableAudit		
disableAudit		
isAuditEnabled		
getAuditConfig		
setAuditConfig		
addAuditDatatsetAccessProtocol		
removeAuditDatatsetAccessProtocols	2.6	IntelliFlash 3.11.4.0
addNetworkACLForAuditDataset		
setNetworkACLForAuditDataset		
removeNetworkACLForAuditDataset		
modifyAuditShareProperties		
bringUserAuditLogsUpToDate		
getNotificationById		

APIs	Introduced in API Version	First Available IntelliFlash Version	
configureSyncReplicationSetUp			
getSyncReplicationSetUp			
getSyncReplicationStatus			
getSyncReplicationPoolPairObjects	2.5	IntelliFlash 3.11.0.0	
setSyncReplicationPoolPairObjects	2.5		
startSyncReplication			
stopSyncReplication			
unconfigureSyncReplicationSetUp			
acknowledgeNotifications			
createVolume			
getProject	2.4	IntelliFlash 3.10.0.0	
getShare			
getVolume			
listNotifications			
listProjectDefaultFcMappings			
listProjectDefaultIscsiMappings			
listVolumeMappings	2.4	IntelliFlash 3.10.0.0	
modifyProjectProperties	2.7		
modifyShareProperties			
modifyVolumeProperties			
getOneMinuteDataAnalyticsHistory			
getOneMinuteSystemAnalyticsHistory	2.3	IntelliFlash 3.9.0.0	
getRecentNotifications	2.3		
getRecentCriticalNotifications			
movelnitiatorToInitiatorGroup			
listTargetGroups			
getSMBConfig	2.2	IntelliFlash 3.7.1.0	
setSMBConfig			
getFloatingIPList			

APIs	Introduced in API Version	First Available IntelliFlash Version
moveTargetToTargetGroup getDisks identifyDisk identifyDiskByIndex Share v2_1	2.1 (introduced) 2.2 (updated)	IntelliFlash 3.7.0.x (introduced) IntelliFlash 3.7.1.0 (updated)
abortCopy addNFSNetworkACLOnProject addNFSNetworkACLOnShare addSMBNetworkACLOnProject addSMBNetworkACLOnShare addSNMPTrapListener checkPoolIntegrity cloneReplicaProjectSnapshot cloneReplicaSubProjectSnapshot copyDataset	2.1	IntelliFlash 3.7.0.x
createFCInitiator createISCSITarget createISCSITargetForGroup createMappingForVolume createProject createMappingForProject createSnapshotSchedule createTargetGroup	2.1	IntelliFlash 3.7.0.x

APIs	Introduced in API Version	First Available IntelliFlash Version
deleteDataset		
deleteInitiatorGroup		
deletelSCSIInitiator		
deletelSCSITarget		
deleteMappingFromProject		
deletePool		
deleteProject		
deleteShare	2.1	IntelliFlash 3.7.0.x
deleteSnapshotSchedule		
deleteSnapshotSchedules		
deleteTargetGroup		
deleteVolume		
disableSNMPService		
enableSNMPService		
exportPool		

APIs	Introduced in API Version	First Available IntelliFlash Version
getCopyStatus		
getDatasetSpaceInfo		
getDiskCount		
getDisksByChassis		
getNFSNetworkACLsOnProject		
getNFSNetworkACLsOnShare		
getPoolSpaceInfo		
getProject		
getProjectDefaultFcITView		
getProjectDefaultIscsilTView		
getProjectProperty	2.1	IntelliFlash 3.7.0.x
getShare		
getShareProperty		
getSMBNetworkACLsOnProject		
getSMBNetworkACLsOnShare		
getSnapshotSchedule		
getSNMPSettings		
getUpgradeHistory		
getVolume		
getVolumeITView		
getVolumeProperty		

APIs	Introduced in API Version	First Available IntelliFlash Version
importPool		
inheritNetworkACLsettingsFromProject		
inheritPropertyFromProject		
inheritSnapshotSettingsFromProject		
isProjectExposedOverNFS	2.1	IntelliFlash 3.7.0.x
isProjectExposedOverSMB	2.1	Intelli lasii 3.7.0.x
isShareExposedOverNFS		
isShareExposedOverSMB		
isSnapshotSchedulesInheritedFromProject		
isSNMPServiceEnabled		
listAllCopyOperations		
listDependenciesAndSnapshotCountOnDelete		
listDependenciesAndSnapshotCountOnRollback		
listFCInitiators		
listFCTargets		
listInitiatorGroups		
listISCSIInitiators		
listISCSITargets	2.1	IntelliFlash 3.7.0.x
listRunningCopyOperations		
listSharesByMountPoints		
modifyISCSITargetAlias		
modifyProjectProperties		
modifyShareProperties		
modifySNMPCommunityString		
modifyVolumeProperties		

APIs	Introduced in API Version	First Available IntelliFlash Version	
recreateSnmpTables			
removeAlINFSNetworkACLsOnProject			
removeAlINFSNetworkACLsOnShare			
removeAllSMBNetworkACLsOnProject			
removeAllSMBNetworkACLsOnShare	2.1	IntelliFlash 3.7.0.x	
removeNFSNetworkACLOnProject	2.1	intelli lasii 5.7.0.x	
removeNFSNetworkACLOnShare			
removeSMBNetworkACLOnProject			
removeSMBNetworkACLOnShare			
removeSNMPTrapListener			
resetPoolError			
resyncSnmpTables		IntelliFlash 3.7.0.x	
setNFSNetworkACLsOnProject			
setNFSNetworkACLsOnShare			
setNFSSharingOnProject	2.1		
setNFSSharingOnShare	2.1		
setSMBNetworkACLsOnProject			
setSMBNetworkACLsOnShare			
setSMBSharingOnProject			
setSMBSharingOnShare			
recreateSNMPTables	2.4	IntelliFlash 3.7.0.x	
resyncSNMPTables	2.1	IntelliFlash 3.5.4.0	
rollBackToProjectSnapshot			
rollBackToShareSnapshot	2.0	IntelliFlash 3.5.0.1	
rollBackToVolumeSnapshot			
cloneVolumeSnapshot	2.0	IntelliFlash 3.5.0.0	

APIs	Introduced in API Version	First Available IntelliFlash Version	
changeUserPassword			
cloneProjectSnapshot			
cloneShareSnapshot			
cloneVolumeSnapshot			
cloneVolumeSnapshot			
createGroup	1.2	IntelliFlash 2.1.2.1	
createProjectSnapshot			
createShareSnapshot			
createUser			
createUserAndGroup			
createVolumeSnapshot			
deleteGroup			
deleteProjectSnapshot			
deleteShareSnapshot			
deleteUser			
deleteVolumeSnapshot			
getProjectCloneStatus		IntelliFlash 2.1.2.1	
getProjectSnapshotCreationStatus	1.2		
getReplicationConfigList	1.2		
getReplicationStatus			
getShareSnapshotCreationStatus			
getVolumeSnapshotCreationStatus			
listGroups			
listUsers			
startReplication			

APIs	Introduced in API Version	First Available IntelliFlash Version
addInitiatorToInitiatorGroup		
cloneSnapshot		
createInitiatorGroup		
createlscsilnitiator		
createMappingForVolume		
createSnapshots		
createVolume	1.0	IntelliFlash 2.1.0.0
deleteDataset		
deleteMappingFromVolume		
deleteSnapshots		
delete Volume		
getInitiatorGroup		
initiatorGroupExists		
listFCInitiatorGroups		
listFCTargetGroups		
listInitiatorsInInitiatorGroup		
listISCSIInitiatorGroups		
listISCSITargetGroups		
listLunsByld		
listPools	1.0	IntelliFlash 2.1.0.0
listProjects		
listShares		
listSnapshots		
listSystemProperties		
listTargetsInTargetGroup		
listVolumes		

# **Key Features**

The key features of the IntelliFlash API are:

- **REST (Representational State Transfer) API**: The API uses HTTP 1.1 request methods. Because HTTP is a well-known protocol and many scripting languages support it, it simplifies the task of building scripts and applications that use the API.
- **JSON (JavaScript Object Notation) data structures**: The API uses JSON as the data exchange format. All parameters in requests sent by the client must use JSON. Similarly, the responses sent by the server (including error responses) are JSON data structures.
- HTTPS: The API uses HTTPS to secure the communication between the client and the server.
- **Basic Authentication**: The API uses HTTP Basic authentication over Transport Layer Security (TLS)/Secure Sockets Layer (SSL). This allows only authorized personnel/programs to securely access the API.
- 1

**Warning:** Because the API requires the IntelliFlash Web UI administrator credentials for authentication, make sure to adequately secure the machine and the user account from which the client programs/scripts are run. Administrators must ensure that the credentials are not compromised by someone reading the script.

### Scope of the API

The IntelliFlash REST APIs enable you to do the following tasks:

- List pools, projects, volumes, users, groups, LUNs, shares, snapshots, initiators, initiator groups, targets, target groups, and system properties.
- Create users, groups, volumes, snapshots, initiator groups, mapping for volumes, and iSCSI initiators.
- Clone snapshots.
- Roll back project, share, and volume snapshots.
- Delete users, groups, snapshots, volumes, shares, mapping for volume, volume snapshot, share snapshot, and other datasets.
- · Check whether an initiator group exists.
- Add an initiator to an initiator group.
- Retrieve the initiator group for an initiator.
- Obtain replication configuration list, status, and to start replication.
- View history of IntelliFlash installations and upgrades to the array.
- Delete, export, import, or expand pools
- Create or delete projects
- View, modify, or manage projects and dataset properties
- Add, set, or modify ACLs on projects and shares
- Create or move target groups
- Clone replica datasets
- Obtain IT views on SAN volumes and projects
- View space info for pools and datasets
- Create or delete mappings for projects and volumes
- View or identify disks
- View, create, inherit, or delete snapshot schedules
- View, create, or delete SAN targets, target groups, and initiators
- Enable or disable SNMP services

- Add or remove SNMP trap listeners
- · Copy datasets, list or abort any ongoing copy operations
- Promote clones before deleting a share or LUN

### **Unified APIs**

IntelliFlash REST APIs run on and obtain results from both controllers in an array. For example, the **listProjects** API returns projects belonging to a pool, irrespective of the controller on which the pool currently resides (Controller-A or Controller-B).



**Note:** The IntelliFlash REST APIs are unified starting from API version 2.0. Previous versions of the IntelliFlash REST APIs—version 1.0 and version 1.2—could access only one controller in an API request.

#### Invoking the Unified API with the array management IP address

You are required to use the array management IP address instead of the controller management IP addresses for the unified API to work correctly.

#### **URL** changes across the API versions

APIs in version 2.x include "/v2/" in the API endpoint. For example:

https://<ArrayManagementHostNameOrIPAddress>/zebi/api/v2/<APIname>

# **Error and Exception Handling in the API**

In situations where a method does not succeed, the API will return one or more of the following responses:

- An HTTP status code that indicates an error. Possible status codes include:
  - 400 (bad request)
  - 404 (not found).
  - 500 (internal server error).
- An integer that indicates an error (for example the values listed in the COMMAND\_STATUS, CLEANUP\_STATUS, and SNAPSHOT\_PROGRESS\_STATUS enumerations.)
- A JSON object that contains a enumeration field that indicates an error.

#### **Error Codes**

The IntelliFlash API uses the following error codes.

Error Code	Description
EZEBI_GENERAL	Indicates a general error.

Error Code	Description
EZEBI_INVALID_ARGUMENT	Indicates invalid arguments.
EZEBI_PERMISSION_DENIED	Indicates that permission is denied.
EZEBI_NOMEMORY	Indicates that no memory is left.
EZEBI_NOSPACE	Indicates that no space is left on device.
EZEBI_RESOURCE_SUSPENDED	Indicates that resource operation is suspended.
EZEBI_RESOURCE_BUSY	Indicates that resource is busy.
EZEBI_RESOURCE_INUSE	Indicates that resource required is being used by others.
EZEBI_RESOURCE_EXIST	Indicates that target already exists.
EZEBI_RESOURCE_CORRUPTED	Indicates that resource is corrupted.
EZEBI_RESOURCE_NOT_FOUND	Indicates that resource is not found.
EZEBI_REQUEST_EXIST	Indicates that request is in progress already.
EZEBI_REQUEST_INTERRUPTED	Indicates that request is interrupted.
EZEBI_REQUEST_TIMEOUT	Indicates that request is timed out.
EZEBI_HOST_UNREACHABLE	Indicates that host is unreachable.
EZEBI_HOST_UNKNOWN	Indicates that host is unknown.

### **curl Syntax**

The examples use the curl command to represent the HTTP requests.

The curl examples include the HTTP headers, the JSON data sent in the request, and the endpoint of the API.

IntelliFlash systems use a self-signed certificate. This may prevent the curl command from working. As a workaround, you can use the -k parameter with the curl command to ignore the warnings/errors generated due to the self-signed certificate.

### **Using the API Examples**

The documentation for each API method includes examples.

The examples use the **curl** command for the requests. The documentation for most API methods includes two types of examples:

- · Working examples with sample responses.
- Erroneous examples with error responses. These examples are erroneous because they use incorrect data for a particular context. The purpose of the erroneous examples is only to illustrate some of the responses that an IntelliFlash Array will return if it receives incorrect data.

Before using the examples in your scripts and programs, ensure that you make the following changes:

 Use the authentication token returned by your IntelliFlash system instead of the dummy token (AUTH\_TOKEN) given in the examples. The authentication token must be encoded as a Base64 string to use the REST API. For example, you can use the following Linux command (that is part of the Linux coreutils package) to convert your credentials to Base64.

```
# echo -n 'username:password' | base64
```

- Use data that is relevant to your environment and requirements instead of the dummy data given in the examples.
- Use the Array Management IP address instead of the dummy IP address given in the examples.

### Creating a Volume and Exposing It

#### **Prerequisites**

You can create a volume and expose it using the IntelliFlash API. To accomplish this, you must first ensure that the IntelliFlash system contains the following:

- A pool
- A project in that pool
- An FC or iSCSI target
- An FC or iSCSI target group
- A mapping between the target and the target group

After ensuring that the prerequisites listed above are met, use the IntelliFlash API to:

- 1. Create a volume using the *createVolume* method.
- Create an iSCSI initiator using the createIscsiInitiator method.
- 3. Create an initiator group using the *createInitiatorGroup* method.



**Note:** You do not need to create FC initiators. If the FC fabric configurations are correct, the initiators automatically log in to the target ports.

- 4. Associate the initiator with the initiator group using the addInitiatorToInitiatorGroup method.
- 5. Map the volume to a target group and an initiator group using the *createMappingForVolume* method.

# **Backing Up a Volume**

You can back up an existing IntelliFlash volume using the IntelliFlash API.

To accomplish this, use the IntelliFlash API to complete the following steps:

- 1. Create a volume snapshot using the *createVolumeSnapshot* method.
- 2. Create a clone from the volume snapshot using the *cloneVolumeSnapshot* method.
- 3. Mount the newly cloned volume and take a backup.
- 4. Clean up the cloned volume using the *deleteVolume* method.
- 5. Clean up the snapshot from which the clone was created using the *deleteVolumeSnapshot* method.

# Chapter 2

# **Sample Programs**

### Topics:

- Sample Perl Script
- Sample Python Program
- Sample PowerShell Program

The following sample programs illustrate how to access the IntelliFlash API using Perl and Python.



Note: The IntelliFlash API uses basic authentication over HTTPS. If you are using self-signed certificates on the IntelliFlash Array, the program that invokes the IntelliFlash APIs must include instructions to trust the SSL certificate.

### Sample Perl Script

The following Perl script illustrates how to authenticate, accept (trust) the self-signed certificate, and invoke the listPools API.

```
use REST::Client;
use JSON;
use Data::Dumper;
use MIME::Base64;
# next line is for ignoring the certificate if it is self-signed.
$ENV{PERL LWP SSL VERIFY HOSTNAME}=0;
$username = 'admin';
$password = 't';
my $host= "https://198.51.100.10";
my $url = "/zebi/api/v2/listPools";
my $json data = "";
# Below line is for basic authentication
my $headers = { Accept => 'application/json',
      Authorization => 'Basic '. encode base64($username . ':' .
$password) };
my $client = REST::Client->new();
$client->setHost($host);
$client->setTimeout(60);
# For API Call
$client->POST($url,($json data,$headers));
print Dumper ($client->responseContent());
```



You must replace the IP address (198.51.100.10) with your Array Management IP address.

# Sample Python Program

The following Python program illustrates how to authenticate, accept (trust) the self-signed certificate, and invoke the following APIs:

- listPools
- listProjects
- listVolumes
- createVolumeSnapshot
- cloneVolumeSnapshot
- getReplicationConfigList

- startReplication
- getReplicationStatus

```
import httplib2;
import base64;
import json;
##h = httplib2.Http();
h = httplib2.Http(disable_ssl_certificate_validation=True);
auth = base64.encodestring('admin' + ":" + "t");
url = "https://198.51.100.10/zebi/api/v2/listPools";
method = "GET";
headerMap = {'content-type':'application/json', 'Authorization' : 'Basic ' +
auth};
resp, content = h.request(url, method, headers=headerMap);
poolArray = json.loads(content);
# List projects inside a the pool
url = "https://198.51.100.10/zebi/api/v2/listProjects";
method = "POST";
poolName = poolArray[0]["name"];
#Prepare Parameter Array
paramArray = [];
paramArray.append(poolName);
paramArray.append(True);
paramJSONData = json.dumps(paramArray);
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
projectArray = json.loads(content);
print resp.status;
print content;
#List Volumes inside a project
url = "https://198.51.100.10/zebi/api/v2/listVolumes";
method = "POST";
projectName = projectArray[0]["name"];
paramArray = [];
paramArray.append(poolName);
paramArray.append(projectName);
paramArray.append(True);
paramJSONData = json.dumps(paramArray);
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
volumeArray = json.loads(content);
#Create a volume snapshot
url = "https://198.51.100.10/zebi/api/v2/createVolumeSnapshot";
method = "POST";
snapName = "API-SNAP";
```

```
firstVolume = volumeArray[0];
paramArray = [];
paramArray.append(firstVolume);
paramArray.append(snapName);
paramArray.append(False);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
print resp.status;
print content;
url = "https://198.51.100.10/zebi/api/v2/cloneVolumeSnapshot";
method = "POST";
snapshotPath = firstVolume["datasetPath"] + "@" + "Manual-V-" + snapName;
volumeCloneName = "API-Clone";
paramArray = [];
paramArray.append(snapshotPath);
paramArray.append(volumeCloneName);
paramArray.append(False);
paramArray.append(True);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
print resp.status;
print content;
#Replication configs
url = "https://198.51.100.10/zebi/api/v2/getReplicationConfigList";
method = "POST";
projectName = "vdi";
paramArray = [];
paramArray.append(poolName);
paramArray.append(projectName);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
replicationConfigArray = json.loads(content);
firstReplicationConfig = replicationConfigArray[0];
#Trigger replication
url = "https://198.51.100.10/zebi/api/v2/startReplication";
method = "POST";
projectName = "vdi";
paramArray = [];
paramArray.append(firstReplicationConfig);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);
print resp.status;
print content;
url = "https://198.51.100.10/zebi/api/v2/getReplicationStatus";
method = "POST";
```

```
projectName = "vdi";

paramArray = [];
paramArray.append(firstReplicationConfig);
paramJSONData = json.dumps(paramArray);
print paramJSONData;
resp, content = h.request(url, method, paramJSONData, headers=headerMap);

print resp.status;
print content;
```



**Note:** You must replace the IP address (198.51.100.10) with the IP address of your IntelliFlash Array.

### Sample PowerShell Program

The following PowerShell program illustrates how to authenticate, accept (trust) the self-signed certificate, and invoke the *createShare* API.

```
$bytes = [System.Text.Encoding]::UTF8.GetBytes("admin:s")
$token = [System.Convert]::ToBase64String($bytes)
$headers = @{"Authorization"="Basic $token"; "Content-Type"="application/
$url = "https://198.51.100.10/zebi/api/v2/createShare"
$method = "POST"
[System.Net.ServicePointManager]::ServerCertificateValidationCallback =
[System.Net.ServicePointManager]::SecurityProtocol =
[System.Net.SecurityProtocolType]::Tls12;
$shareOptions = @{}
$shareOptions.add("blockSize", "64KB")
$shareOptions.add("quota", -1)
$shareOptions.add("reservation", -1)
#This group should already exist on the array.
#A better approach is to obtain the group list using the listGroups API and
then
#use the needed group, instead of hard-coding like below
qroup = Q{}
$group.add("groupName", "group01")
$group.add("groupId", 104)
$groupList = @($group)
$sharePermission = @{}
$sharePermission.add("groupList", $groupList)
$sharePermission.add("sharePermissionEnum", 2) #2 is group permission
$sharePermission.add("sharePermissionMode", 0) #0 is "Allow"
$sharePermissionArray = @($sharePermission)
$parameters = "pool-b","test-project","APIShare",$shareOptions,
$sharePermissionArray
$jsonString = ConvertTo-Json -Compress -Depth 4 $parameters
```

\$jsonString



**Note:** You must replace the IP address (198.51.100.10) with the IP address of your IntelliFlash Array.

# **Chapter 3**

# **User and Group Methods**

## **Topics:**

- changeUserPassword
- createGroup
- createGroup
- createUser
- createUser
- createUserAndGroup
- deleteGroup
- deleteUser
- listGroups
- listUsers

The following sections describe User and Group methods, parameters, return types, and examples.

# changeUserPassword

Sets a new password for the specified user (a "Local User" that was created on the IntelliFlash Array).

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

**listUsers** 

#### **Parameters**

#### userName

Name of the user.

#### password

Password of the new user. The '/' and space characters and the empty and null strings are not allowed in password.

#### Returns

Returns an integer: the number 0 if the request succeeds.

## **Examples**

## Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["UserName", "Password"]' \
https://198.51.100.10/zebi/api/v2/changeUserPassword -k
```

## Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
```

```
-H Content-Type:application/json \
-d '["IncorrectUserName", "Password"]' \
https://198.51.100.10/zebi/api/v2/changeUserPassword -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "User IncorrectUserName does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# createGroup

Creates a user group with the specified group name and group ID.

## **First Available Version**

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

listGroups, createGroup, createUserAndGroup, deleteGroup, listUsers, deleteUser.

#### **Parameters**

## groupName

#### gid

Group ID of the group. The group ID should be a number less than 99999999.

#### Returns

Returns an integer: the number 0 if the request succeeds.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
-d '["NewGroup", 1234]' \
https://198.51.100.10/zebi/api/v2/createGroup -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

## Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewGroup", 1234]' \
  https://198.51.100.10/zebi/api/v2/createGroup -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "The specified group Id already belongs to another group."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# createGroup

Creates a user group with the specified group name. The group ID is generated by the system.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

listGroups, createGroup, createUserAndGroup, deleteGroup, listUsers, deleteUser.

#### **Parameters**

## groupName

#### Returns

Returns an integer: the number 0 if the request succeeds.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["AnotherNewGroup"]' \
  https://198.51.100.10/zebi/api/v2/createGroup -k
```

## Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[""]' https://198.51.100.10/zebi/api/v2/createGroup -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Invalid Group Name."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

## createUser

Creates a user with given username, user ID, group name, and password.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

listUsers, listGroups, createUser, createUserAndGroup, deleteUser.

#### **Parameters**

#### userName

#### uid

User ID of the new user.

## groupName

Name of the group in which the new user will be included. The characters /,  $\$  \, !, @, #, \$, %, ^, \*, (, ), :, ;, \, are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

## password

Password of the new user. The '/' and space characters and the empty and null strings are not allowed in password.

#### **Returns**

Returns an integer: the number 0 if the request succeeds.

## **Examples**

## Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["UserName", 123, "GroupName", "newpwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

## Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["UserName", 123, "IncorrectGroupName", "newpwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Group IncorrectGroupName does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

## createUser

Creates a user with given username, group name, and password. The user ID is generated by the system.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

listUsers, listGroups, createUser, createUserAndGroup, deleteUser.

#### **Parameters**

## userName

Username of the user that will be created. The characters /,  $\setminus$ , !, @, #, %,  $^$ ,  $^*$ ,  $(, ), :, :, \cdot$ , are not allowed in the username. The empty and "guest" strings and the null value are also not allowed in the username.

## groupName

Name of the group in which the new user will be included. The characters /,  $\$  \, !, @, #, \$, %, ^, \*, (, ), :, ;, \, are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

## password

Password of the new user. The '/' and space characters and the empty and null strings are not allowed in password.

#### Returns

Returns an integer: the number 0 if the request succeeds.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewUserName", "ExistingGroupName", "NewUserPwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

## Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewUserName", "NotAGroupName", "NewUserPwd"]' \
  https://198.51.100.10/zebi/api/v2/createUser -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
message: "Group TechPub does not exist."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

# createUserAndGroup

Creates user and group with auto generated user ID and group ID. The group will be created first and then the user. The user will be associated with the group. If the group with given group name already exists, the user will be created and associated with the existing group.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

## Related APIs

listUsers, listGroups, createGroup, createGroup, deleteGroup, createUser, createUser, deleteUser.

#### **Parameters**

#### userName

#### password

Password of the new user.

## groupName

Name of the group in which the new user will be included. The characters /,  $\$  \, !, @, #, \$, %, ^, \*, (, ), :, ;, \, are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

#### Returns

Returns an integer: the number 0 if the request succeeds.

## **Examples**

## Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["testUser2", "testpwd2", "testGroup2"]' \
  https://198.51.100.10/zebi/api/v2/createUserAndGroup -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

#### Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["testUser2", "testpwd2", "testGroup2"]' \
  https://198.51.100.10/zebi/api/v2/createUserAndGroup -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "UX: /usr/sbin/useradd: ERROR: testUser2 is already in use.
Choose another.\ 9"
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# deleteGroup

Deletes the specified user group (a "Local Group" that was created on the IntelliFlash Array). If the group contains existing users, all the users would not be part of this group.



#### Warning:

- The delete operation is not reversible.
- If you do not require the users in this group, it is recommended to delete the users before deleting the group.

#### **First Available Version**

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

listGroups, listUsers, deleteUser, createUserAndGroup.

#### **Parameters**

## groupName

Name of the group that has to be deleted. The characters /,  $\backslash$ , !, @, #, %,  $^$ ,  $^$ , (, ), :, :,  $\backslash$ , are not allowed in the groupname. The empty and "guest" strings and the null value are also not allowed in the groupname.

#### Returns

Returns an integer: the number 0 if the request succeeds.

#### Examples

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth TOKEN" \
```

```
-H Content-Type:application/json \
-d '["NewGroup"]' \
https://198.51.100.10/zebi/api/v2/deleteGroup -k
```

## Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["NewGroup"]' \
  https://198.51.100.10/zebi/api/v2/deleteGroup -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Group NewGroup does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

## deleteUser

Deletes the specified user (a "Local User" that was created on the IntelliFlash Array).



**Warning:** The delete operation is not reversible.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

listUsers, listGroups, deleteGroup.

## **Parameters**

userName

Name of the user. The characters /,  $\setminus$ , !, @, #, \$, %, ^, \*, (, ), :, ;, \, are not allowed in the username. The empty and "guest" strings and the null value are also not allowed in the username.

#### Returns

Returns an integer: the number 0 if the request succeeds.

#### **Examples**

## Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["testUser2"]' \
  https://198.51.100.10/zebi/api/v2/deleteUser -k
```

## Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
0
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["testUser2"]' \
  https://198.51.100.10/zebi/api/v2/deleteUser -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "User testUser2 does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# **listGroups**

Lists all the local groups and the users included in each group. This is an HTTP GET method.

## First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

createGroup, createGroup, deleteGroup, createUserAndGroup, listUsers.

#### **Parameters**

None

#### Returns

Returns an array of JSON objects. Each object has the group name, group ID, and users of a group. The user list itself is a JSON array containing the names of users in a group.

## **Example**

## Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  https://198.51.100.10/zebi/api/v2/listGroups -k
```

## Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
"groupName": "nfsgrp1",
"groupId":104,
"userList":["nfsuser1"]
"groupName": "nfsgrp4",
"groupId":106,
"userList":["nfsuser4"]
"groupName": "nfsgrp5",
"groupId":105,
"userList":["nfsuser5"]
},
"groupName": "nfsgrp2",
"groupId":108,
"userList":["nfsuser2"]
"groupName": "nfsgrp3",
"groupId":107,
"userList":["nfsuser3"]
```

J

# **listUsers**

Lists all the local users with their user ID, group name, and group ID. This is an HTTP GET method.

## First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

listGroups, createUser, createUser, createUserAndGroup, deleteUser.

#### **Parameters**

None

#### Returns

Returns an array of JSON objects. Each object has the user name, user ID, group name, and group ID of a local user.

## **Example**

## Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  https://198.51.100.10/zebi/api/v2/listUsers -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
{
"userName":"nfsuser1",
"groupName":"nfsgrp1",
"userId":104,"groupId":104
}
,
{"userName":"nfsuser5",
"groupName":"nfsgrp5",
"userId":105,
"groupId":105
},
{
"userName":"nfsuser4",
"groupName":"nfsgrp4",
"userId":106,
```

```
"groupId":106},
{
"userName":"nfsuser3",
"groupName":"nfsgrp3",
"userId":107,
"groupId":107
},
{"userName":"nfsuser2",
"groupName":"nfsgrp2",
"userId":108,
"groupId":108
}
]
```

# Chapter 4

# **Dataset Methods**

#### Topics:

- abortCopy
- checkPoolIntegrity
- copyDataset
- createProject
- createMappingForProject
- createShare
- createShare
- createVolume
- createVolume
- deleteDataset
- deleteDataset
- deleteMappingFromProject
- deletePool
- deletePool
- deleteProject
- deleteProject
- deleteShare
- deleteShare
- deleteShare
- deleteVolume
- deleteVolume
- deleteVolume
- exportPool
- getCopyStatus
- getDatasetSpaceInfo
- getFloatingIPList
- getPoolSpaceInfo
- getProject
- getProject
- getProjectProperty
- getShare
- getShare
- getShareProperty
- getVolume
- getVolume
- getVolumeProperty
- importPool

The following sections describe Dataset methods, parameters, return types, and examples.

- inheritPropertyFromProject
- isProjectExposedOverNFS
- isShareExposedOverNFS
- listAllCopyOperations
- listLunsByld
- listPools
- listProjects
- listRunningCopyOperations
- listShares
- listSharesByMountPoints
- listVolumes
- modifyProjectProperties
- modifyProjectProperties
- modifyShareProperties
- modifyShareProperties
- modifyVolumeProperties
- modifyVolumeProperties
- resetPoolError
- setNFSSharingOnProject
- setNFSSharingOnShare
- modifyACLInheritanceOfShare
- getKerberosInfo
- enableKerberos
- disableKerberos

# abortCopy

Aborts a running copy operation.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

copyDataset, getCopyStatus, listRunningCopyOperations, listAllCopyOperations

#### **Parameters**

#### taskGUID

The GUID of the copy operation task to be aborted.

#### **Returns**

Returns the HTTP status code 200 (OK) and return code 0.

## **Exceptions Thrown**

## **EZEBI\_GENERAL**

This exception is thrown if the task GUID is invalid for the array.

#### **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN' \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '["europa:84944c8a-8bc1-4705-809e-144363797a57"]'
https://198.51.100.10/zebi/api/v2/abortCopy -k
```

## Response

The above request returns the HTTP status code 200 (OK).

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["europa1:84944c8a-8bc1-4705-809e-144363797a57"]'
https://198.51.100.10/zebi/api/v2/abortCopy -k
```

## **Error Response**

The above request returns HTTP status code 400 with the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Cannot find copy task
'europ1a:84944c8a-8bc1-4705-809e-144363797a57'
   in pool: europa1.",
   "extendedData": {}
}
```

# checkPoolIntegrity

Validates the integrity of the disks associated with a pool.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

importPoool, exportPool, resetPoolError

#### **Parameters**

## poolName

Name of the pool where you want to clear the errors.

#### start

An integer which specifies whether to start (1) or stop (0) the pool integrity check.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

## **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the pool does not exist.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in the pool name or a start value is not 0 or 1.

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool6a", 1]' \
https://198.51.100.10/zebi/api/v2/checkPoolIntegrity -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["nonExistentPool6a", 1]' \
https://198.51.100.10/zebi/api/v2/checkPoolIntegrity -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "Pool not found.",
"message": "The pool [nonExistentPool6a] was not found.",
"extendedData": {
    "EX_CAUSE_MESSAGE": "Pool not found.",
    "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
}
```

```
}
```

Example 3

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a", 0]' \
https://198.51.100.10/zebi/api/v2/checkPoolIntegrity -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_GENERAL",
  "details": "",
  "message": "Failed to check pool [pool63a] integrity.
  This could be due to an invalid scan pool state transition request",
  "extendedData": {}
}
```

# copyDataset

Starts a copy operation.

## First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getCopyStatus, listRunningCopyOperations, listAllCopyOperations, abortCopy

#### **Parameters**

```
CopySource_V2_1
CopyDestination_V2_1
```

#### **Returns**

A task GUID for the copy operation.

# **Exceptions Thrown**

```
EZEBI_RESOURCE_NOT_FOUND
```

This exception is thrown if the specified source dataset is not available.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If an invalid character is present in the CopySource\_V2\_1 or the CopyDestination\_V2\_1 field.
- If the specified source dataset is not available.
- If the dataset names are invalid.
- If the host is invalid.
- If the start and end subproject suffix numbers are invalid.

## **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN' \
 -H 'cache-control: no-cache' \
 -H 'content-type: application/json' \
 -d '[{"poolName": "europa",
"projectName": "images",
"subProjectName": "template"
"hostName": "10.68.132.120",
"poolName": "napa",
"projectName": "remotecopy",
"subProjectNamePrefix": "prod",
"subProjectNameNumberStart": 1,
"subProjectNameNumberEnd": 3,
"subProjectNameWildcard": ""
]'\
https://198.51.100.10/zebi/api/v2/copyDataset -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a string. The returned string is the copy operation's GUID:

```
'84944c8a-8bc1-4705-809e-144363797a57'
```

## Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
```

```
-H 'cache-control: no-cache'
-H 'content-type: application/json' \
-d '[{"poolName": "europal",
    "projectName": "images",
    "subProjectName": "template"
},
{
    "hostName": "10.68.132.120",
    "poolName": "napa",
    "projectName": "remotecopy",
    "subProjectNamePrefix": "prod",
    "subProjectNameNumberStart": 1,
    "subProjectNameNumberEnd": 3,
    "subProjectNameWildcard": ""
}
]' \
https://198.51.100.10/zebi/api/v2/copyDataset -k
```

## **Error Response**

The above request returns HTTP status code 400 with the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Unable to find project images in europal",
   "extendedData": {}
}
```

## Example 3

## **Erroneous Request (curl)**

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN' \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 -d '[{"poolName": "europal@",
"projectName": "images",
"subProjectName": "template"
},
"hostName": "10.68.132.120",
"poolName": "napa",
"projectName": "remotecopy",
"subProjectNamePrefix": "prod",
"subProjectNameNumberStart": 1,
"subProjectNameNumberEnd": 3,
"subProjectNameWildcard": ""
]'\
https://198.51.100.10/zebi/api/v2/copyDataset -k
```

#### **Error Response**

The above request returns the HTTP status code 400 and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "copyDataset.arg0.poolName value 'europal@':
  Pool name is not in the expected format
  that starts with a letter followed by alpha-numeric,_,-...",
  "message": "Pool name is not in the expected format
  that starts with a letter followed by alpha-numeric,_,-...",
  "extendedData": {
        "EX_CAUSE_MESSAGE": null
    }
}
```

# createProject

Creates a generic project with given parameters.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getProject, modifyProjectProperties, getProjectProperty

#### **Parameters**

## **Project**

A *Project\_V2\_1* object for which project needs to be created.

If the parameters are not specified, default values are used. "poolName", "projectName" are mandatory. You can configure other general properties in \*Project\_V2\_1 that are not marked as "read only".

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

#### **Exceptions Thrown**

## EZEBI\_INVALID\_ARGUMENT

If the parameters are invalid (when the key-value pair is not supported by *Project\_V2\_1*).

#### **Examples**

#### Example 1

## Request (curl)

## Response

The above request returns the HTTP status code 200 (OK) and an integer 0.

## Example 2

## **Erroneous Request (curl)**

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
"details": "createProject.arg0 value
'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$Project_V2_1@1778db80':
Invalid Compression Algorithm, disable compression by passing in 'Off'
```

```
or enable compression by using one of the following: Lzjb, Gzip-2, Gzip,
Gzip-9, Lz4.",
  "message": "Invalid Compression Algorithm, disable compression by passing
in 'Off'
  or enable compression by using one of the following: Lzjb, Gzip-2, Gzip,
Gzip-9, Lz4.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
    }
}
```

## Example 3

## **Erroneous Request (curl)**

## **Error Response**

localDataset: "false" indicates replica project. As the API does not create a project in replica, it returns the following error message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "createProject.arg0 value
  'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$Project_V2_1@1778db80':
  Not allowed to create a replica project.",
  "message": "Not allowed to create a replica project.",
  "extendedData":
    {
        "EX_CAUSE_MESSAGE": null
    }
}
```

# createMappingForProject

Creates a project-level default mapping.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

deleteMappingFromProject, createMappingForVolume

## **Parameters**

#### datasetPath

Path of the project. The format is <poolName/Local/<projectName>.

This operation is not allowed for replica project datasets.

## initiatorGroupName

Name of the initiator group.

## targetGroupName

Name of the target group.

## readOnly

Whether mapping is read-only. The values are True and False.

#### **Returns**

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success or if the desired view already exists.

#### **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project, initiator group, or target group cannot be found.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown for any of the following reasons:

- The path specified belongs to a replica dataset.
- The target group and initiator group have different protocols.
- The target group and initiator group are either iSCSI or FC protocols (unknown).
- The view already exists with the wrong read-only type.
- The mapping for this target group already exists (when trying to make All mapping).
- The mapping with 'All' initiator groups already exists on this target group.

## **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "All", "default-pool-a-iscsi-target-group",
  true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "demoiSCSIInitiatorGroup",
  "demoiSCSITargetGroup", true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

#### **Error Response**

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"",
    "message":"Specified initiator and target groups are not the same
protocol.
    Initiator protocol: Unknown. Target protocol: iSCSI",
    "extendedData":{}
}
```

#### Example 3

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '[
"pool-a/Replica/replicaProject", "All", "default-pool-a-iscsi-target-
group", true
    ]' \
https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

## **Error Response**

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
    "details":"createMappingForProject.arg0 value 'pool-a/Replica/
replicaProject':
    Local dataset path expected. For example, valid formats are 'pool-name/
Local/project-name'
    or 'pool-name/Local/project-name/share-or-lun-name'.",
    "message":"Local dataset path expected. For example, valid formats are
    'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

## Example 4

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject", "All", "default-pool-a-iscsi-target-group", true
   ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

#### **Error Response**

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
For example, valid formats are 'pool-name/Local/project-name' or 
'pool-name/Local/project-name/share-or-lun-name'.",

"extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

## Example 5

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "demoFCInitiatorGroup", "demoiSCSITargetGroup",
  true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForProject -k
```

## **Error Response**

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

## createShare

Creates a share with the specified share options and share permissions.



#### Important:

In the **Virtualization File Services** mode, if a project has both NFS and SMB sharing enabled, creating a share using **createShare** API is not supported. To enable share creation, make sure only one protocol is enabled on the project for Virtualization File Services mode.

In **General File Services** mode, you can create a share using **createShare**, regardless of the number of protocols configured. This mode supports both SMB and NFS file share at the same time.

## **First Available Version**

#### API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

listShares, createShare, deleteShare.

#### **Parameters**

#### poolName

A string: the name of the pool in which the share is created.

## projectName

A string: the name of the project in which the share is created. The characters ,, /,  $\$ , ?, @, <, >, #, \$, ',%, ^,\*,(, ), ~,+, =, },|, :, {, [, ], ;, \', \", & are not allowed in projectname. The empty and space characters and the null values are not allowed in projectname.

#### shareName

A string: the share name.

## shareOptions

A *ShareOptions* object that specifies the mount point, block size, quota, and reservation. This parameter is optional. If some of the settings included in this parameter are not specified, the defaults are as follows:

- If Block Size is null or is an empty string ("") then the block size of the new share is set to 32KB and the override record (Block) size flag is set to false.
- If the Mount Point is not specified or is an empty string ("") then the default mountpoint is used and the override mountpoint flag is set to false.
- If the Quota and Reservation are not specified or is set to "-1" then no quota or reservation is applied to the new share.

#### sharePermissions

An array of the *SharePermissions* object that defines permissions for the new share using ACLs.

#### Returns

Returns an integer: the number 0, if the request succeeds.

#### **Examples**

#### Example 1

## Request (curl)

## Response

HTTP Status Code: 200

```
0
```

#### Example 2

#### **Erroneous Request**

#### **Error Response**

## HTTP Status Code: 400

```
"message": "Error while saving: shareName.
    Reason: Unable to open BadPoolName/Local/projectName:
    dataset does not exist",
    "extendedData": { },
    "details": "",
    "code": "EZEBI_GENERAL"
}
```

## createShare

Creates a share with the default share properties (A block size of 32 KB; no quota; no reservation).



## Important:

In the **Virtualization File Services** mode, if a project has both NFS and SMB sharing enabled, creating a share using **createShare** API is not supported. To enable share creation, make sure only one protocol is enabled on the project for Virtualization File Services mode.

In **General File Services** mode, you can create a share using **createShare**, regardless of the number of protocols configured. This mode supports both SMB and NFS file share at the same time.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

listShares, createShare, deleteShare.

#### **Parameters**

#### poolName

A string: the name of the pool in which the share is created.

## projectName

A string: the name of the project in which the share is created. The characters ,, /,  $\$ , ?, @, <, >, #, \$, ',%, ^,\*,(, ), ~,+, =, }, $\$ , :, {, [, ], ;, \', \", & are not allowed in projectname. The empty and space characters and the null values are not allowed in projectname.

#### shareName

A string: the share name.

#### sharePermissions

An array of the *SharePermissions* object that defines permissions for the new share using ACLs.

#### Returns

An integer: The number 0 if the request succeeds.

## **Examples**

## Example 1

## Request (curl)

## Response

HTTP Status Code: 200

```
0
```

## Example 2

## **Erroneous Request**

#### **Error Response**

HTTP Status Code: 400

```
{
       "message": "Error while saving: shareName.
        Reason: Unable to open BadPoolName/Local/projectName:
         dataset does not exist",
      "extendedData": { },
"details": "",
"code": "EZEBI_GENERAL"
```

# createVolume

Creates a volume with the specified settings.

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

#### **Parameters**

#### Volume

The parameter to this API is a JSON object of type Volume\_V2\_1. The object contains all parameters required to create a volume.

To use this API, pass the following unique fields for *Volume\_V2\_1*:

- localDataset
- purpose



Note: Depending on the specified purpose, the system will pick the appropriate blockSize for that volume. The volume purpose is optional and defaults to "Generic" if not specified.

zfsDatasetName

In addition, use the following minimum required parameters:

- poolName
- projectName
- name
- volSize
- thinProvisioning
- protocol

## inheritSANViewSettingsFromProject

This parameter indicates whether to copy the "view" settings related to the intended protocol (iSCSI or FC) from the project. The default views created on the project are copied over if this parameter is true. If this parameter is false, then volume is created with NO views attached to it.

#### Returns

If the API is successful, 0 is returned.

If the API is not attempted, 1 is returned.

If the API fails, 2 is returned.

#### **Examples**

#### Example 1

#### Request

## Response

```
0
```

## Example 2

#### **Erroneous Request**

```
"poolName":"pool-a",
    "projectName":"sqlServerProj",
    "name":"sqlServerProjLUN_REST_API_1",
    "volSize" : 1048576,
    "purpose": "Zero Purpose",
    "protocol" :"iSCSI",
    "thinProvisioning" : true,
    "localDataset" : true
    },
    true
    ]'
https://198.51.100.10/zebi/api/v2/createVolume -k
```

## **Error Response**

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "",
  "message": "Invalid Volume Purpose. Given the specified project,
  please set the volume purpose to one of the following values:
    Generic, SQL Data, SQL Log, SQL Backup, SQL TempDB Data, SQL TempDB Log,
SQL Large Object",
    "extendedData": {}
}
```

## createVolume

Creates a volume with the specified settings.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

initiatorGroupExists, addInitiatorToInitiatorGroup

#### **Parameters**

#### volume

A JSON object of type *Volume\_V1\_0* that contains the parameters required to create the volume.

## inheritSANViewSettingsFromProject

Indicates whether to copy the view settings related to the intended protocol (iSCSI or FC) from the project. The default views created on the project are copied over if this parameter is true. If this parameter is false, then the volume is created with no views attached to it. This is a boolean value.

#### Returns

Returns an integer, where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

## **Examples**

#### **Example 1**

## Request (curl)

## Response

0

## Example 2

#### **Erroneous Request**

#### **Error Response**

```
HTTP Status Code: 400
{
   "message": "A volume/share with the same name pool1/Local/TechPubs/
   api_createVolume_name already exists.",
   "extendedData": {},
   "details": "",
   "code": "EZEBI_GENERAL"
}
```

## deleteDataset

Deletes the specified dataset.



**Caution:** If the **recursive** parameter is set to **true** all dependent objects are deleted. For example, if the **datasetPath** points to a project all shares and LUNs in the project, and their snapshots and clones are deleted.



**Warning:** The delete operation is not reversible.

#### **First Available Version**

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

**listVolumes** 

#### **Parameters**

#### datasetPath

A string: the path to the dataset. The dataset path has the format: PoolName/Local/ProjectName/VolumeName.

#### recursive

A boolean value: indicates whether the dependents (for example clones of the dataset) of this dataset should be removed (if true) before trying to delete the dataset or not (if false). Deletion might fail if the dataset has dependents.

#### errorlfNotExist

A boolean value: indicates whether to raise (if true) an exception if the path specified by datasetPath does not exist.

#### Returns

Returns no data.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/TechPubsTest",true, true]' \
  https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

#### Response

On success, the above request returns the HTTP status code 200 (OK) and no data.

#### **Example 2**

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/ \
  -d '["pool1/Local/TechPubs/api_createVolume_name", \
    false, false]' \
  https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"message": "Unable to delete pool1/Local/TechPubs/api_createVolume_name",
    "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_BUSY",
        "EX_CAUSE_MESSAGE": "dataset is busy",
        "ex_CAUSE_CODE_NUMBER": "2007"
        },
        "details": "dataset is busy",
        "code": "EZEBI_GENERAL"
}
```

## deleteDataset

Promotes dependents as specified, and deletes the dataset whose path is supplied as an argument.

Dependents are deleted as well if promote is false.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

deleteShare, deleteVolume

#### **Parameters**

#### datasetPath

This string uniquely identifies the dataset on the IntelliFlash array.

#### recursive

Defines whether to remove the dependants (clones for example) and LUN of the dataset before trying to delete it. Deletion might fail if there are dependants or a LUN exists on a dataset.

#### errorlfNotExist

Defines whether to raise an exception if the datasetPath to delete doesn't exist.

#### promote

Defines whether to promote dependents.

#### Returns

COMMAND STATUS.COMMAND SUCCEED(0) on success.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This error is thrown if the specified dataset doesn't exist.

#### **EZEBI RESOURCE INUSE**

This error is thrown for the following conditions:

- If replication is currently running
- If replication configuration exists and the project to delete is local
- If deleting replication configuration fails

## EZEBI\_RESOURCE\_SUSPENDED

This error is thrown if the pool is suspended.

#### **EZEBI INVALID ARGUMENT**

This error is thrown for the following conditions:

- If the dataset is empty
- If the dataset length is greater than the maximum length
- · If the dataset contains invalid characters

#### EZEBI\_GENERAL

This error is thrown if deletion failed.

#### **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-dataset", false, true, true
        ]'
https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-dataset", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteDataset -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "No such dataset exists.",
  "extendedData": {}
}
```

# deleteMappingFromProject

Deletes an existing project mapping.

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createMappingForProject, createMappingForVolume

## **Parameters**

#### datasetPath

Path of the project. The format is <poolName/Local/<projectName>.

## initiatorGroupName

Name of the initiator group in the existing mapping.

## targetGroupName

Name of the target group in the existing mapping.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

### **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project, initiator group, or target group cannot be found.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown for any of the following reasons:

- The target group and initiator group have different protocols.
- The target group and initiator group are either iSCSI or FC protocols (unknown).
- The view or mapping does not exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '[
   "pool-a/Local/demoProject", "demoiSCSIInitiatorGroup",
   "demoiSCSITargetGroup"
    ]' \
   https://198.51.100.10/zebi/api/v2/deleteMappingFromProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

### Example 2

#### **Erroneous Request (curl)**

#### **Error Response**

In this example, the request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"",
   "message":"Did not find the view to delete.
   Project=pool-a/Local/demoProject.
   Initiator group=demoiSCSIInitiatorGroup .Target
group=demoiSCSITargetGroup",
   "extendedData":{}
}
```

#### Example 3

#### **Erroneous Request**

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
```

```
"code": "EZEBI RESOURCE NOT FOUND",
"details":"",
"message": "Specified target group 'UNKNOWNiSCSITargetGroup' does not
"extendedData":{}
```

## deletePool

Moves the pool to an exported state, and it uses Two Factor Authentication (2FA) to validate the user. It does not delete the pool. When a pool is exported; all shares, LUNs, and the pool itself are unmounted and hosts cannot access data from the pool.



Note: 2FA is supported in API version V2.8 and above. So, you need to send a delete pool request along with a valid verification code. For users with 2FA enabled on their user array login account, earlier (e.g. V1) versions of this API will not support 2FA.

#### First Available Version

API v2.8, IntelliFlash 3.11.5.0

# **Parameters**

## poolName

Name of the pool to delete.

#### force

A boolean, which specifies whether to force the deletion of the pool with its dependents.

#### verificationCode

Six digit 2FA verification code to validate the Two-Factor Authentication for an array user who has that feature enabled. Refer to IntelliFlash User Guide for more details on how to get this verification code (application code) from your mobile device authenticator.

## Returns

The API returns an integer '0' if the request succeeds.

# **Exceptions Thrown EZEBI GENERAL**

The API returns this error if:

 Invalid request, while 2FA is enabled for user. The API version V2.8 supports 2FA, so you need to send a request along with the valid verification code.

Invalid verification code provided for user.

## **EZEBI\_PERMISSION\_DENIED**

This exception is thrown if access is denied.

#### EZEBI\_RESOURCE\_NOT\_FOUND

If the pool does not exist.

#### **EZEBI INVALID ARGUMENT**

If an invalid character is detected in the pool name.

#### **Examples**

## Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-2", true, "396205" ]' \
https://10.200.245.4/zebi/api/v2/deletePool -k
```

### Response

The API returns the HTTP status code 200 (OK) and '0' as integer indicating a successful operation.

```
0
```

## Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-2", true ]' \
https://10.200.245.4/zebi/api/v2/deletePool -k
```

#### **Error Response**

The API returns the EZEBI\_GENERAL error code and the following message when you send a request without valid verification code.

```
code.",
   "extendedData": {}
}
```

## deletePool

This API does not delete a pool, but moves the specified pool to the exported state. When a pool is exported, all shares, LUNs, and the pool itself are unmounted and hosts cannot access data from the pool.

## **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

importPool, exportPool, resetPoolError, checkPoolIntegrity

#### **Parameters**

#### poolName

Name of the pool to delete.

#### force

A boolean, which specifies whether to force the deletion of the pool with its dependents.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

#### **Exceptions Thrown**

#### **EZEBI RESOURCE NOT FOUND**

If the pool does not exist.

## EZEBI\_INVALID\_ARGUMENT

If an invalid character is detected in the pool name.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
 -H 'authorization: Basic AUTH TOKEN' \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 -d '["pool6a", false]' \
https://198.51.100.10/zebi/api/v2/deletePool -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
 -H 'authorization: Basic AUTH TOKEN' \
 -H 'cache-control: no-cache' \
 -H 'content-type: application/json' \
  -d '["nonExistentPool6a", false]' \
https://198.51.100.10/zebi/api/v2/deletePool -k
```

## **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI RESOURCE NOT FOUND",
"details": "Pool not found.",
"message": "The pool [nonExistentPool63a] was not found.",
"extendedData": {
 "EX CAUSE MESSAGE": "Pool not found.",
  "EX CAUSE CODE NAME": "EZEBI RESOURCE NOT FOUND"
}
```

# deleteProject

Deletes a project with Two-Factor Authentication (2FA) if it is enabled for the user specified in the header.



Note: 2FA is supported in API version V2.8 and above. So, you need to send a delete project request along with a valid verification code. For users with 2FA enabled on their user array login account, earlier (e.g. V1) versions of this API will not support 2FA.

#### First Available Version

## API v2.8, IntelliFlash 3.11.5.0

#### **Parameters**

## projectDatasetpath

The path for the project dataset.

#### verificationCode

Six digit 2FA verification code to validate the Two-Factor Authentication for an array user who has that feature enabled. Refer to *IntelliFlash User Guide* for more details on how to get this verification code (application code) from your mobile device authenticator.

#### Returns

The API returns an integer '0' if the request succeeds.

# **Exceptions Thrown**

## **EZEBI\_GENERAL**

The API returns this error if:

- Invalid request, while 2FA is enabled for user. The API version V2.8 supports 2FA, so you need to send a request along with the valid verification code.
- Invalid verification code provided for user.
- Deletion of project failed.

#### EZEBI\_PERMISSION\_DENIED

This exception is thrown if access is denied.

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project doesn't exist.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in the project dataset path.

#### **Examples**

#### Example 1

### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject", "019793" ]' \
```

```
https://10.200.245.4/zebi/api/v2/deleteProject -k
```

#### Response

The API returns the HTTP status code 200 (OK) and '0' as integer indicating a successful operation.

0

## Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject" ]' \
https://10.200.245.4/zebi/api/v2/deleteProject -k
```

## **Error Response**

The API returns the EZEBI\_GENERAL error code and the following message when you send a request without valid verification code.

# deleteProject

Deletes a project

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createProject, listProjects

# Parameters projectDatasetpath

The path for the project dataset.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

#### **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified project doesn't exist.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in the project dataset path.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

## Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a/Local/testProject"]' \
https://198.51.100.10/zebi/api/v2/deleteProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a/Local/nonExistentProject"]' \
https://198.51.100.10/zebi/api/v2/deleteProject -k
```

#### Example 2

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
  "code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Cannot find the specified project 'pool63a/Local/
nonExistentProject'.",
  "extendedData": {}
}
```

## deleteShare

Deletes the specified share and optionally deletes its dependents. This REST call will verify access by Two-Factor Authentication (2FA) with the passed **verificationCode** parameter if 2FA is enabled for the user requested in the basic-authorization header.



**Note:** 2FA is supported in API version V2.8 and above. So, you need to send a delete share request along with a valid verification code. For users with 2FA enabled on their user array login account, earlier (e.g. V1) versions of this API will not support 2FA.

#### First Available Version

API v2.8, IntelliFlash 3.11.5.0

#### **Parameters**

#### datasetPath

This string identifies the share on the IntelliFlash array.

#### recursive

Whether to remove the dependents of the dataset before deleting it.

#### errorlfNotExist

Whether to raise an exception if the datasetPath to delete does not exist.

#### promote

Whether to remove the dependents of the dataset before deleting it.

#### verificationCode

Six digit 2FA verification code to validate the Two-Factor Authentication for an array user who has that feature enabled. Refer to *IntelliFlash User Guide* for more details on how to get this verification code (application code) from your mobile device authenticator.

#### Returns

The API returns an integer '0' if the request succeeds.

# Exceptions Thrown EZEBI GENERAL

The API returns this error if:

- Invalid request, while 2FA is enabled for user. The API version V2.8 supports 2FA, so you need to send a request along with the valid verification code.
- Invalid verification code provided for user.
- Deletion of share failed.

## EZEBI\_PERMISSION\_DENIED

This exception is thrown if access is denied.

### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if a dataset is not found.

#### **EZEBI RESOURCE INUSE**

This exception is thrown if the replication is currently running.

#### **EZEBI RESOURCE SUSPENDED**

This exception is thrown if the pool is suspended.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If the dataset is empty.
- If the length is greater than the maximum length.
- If it contains invalid characters.

#### **Examples**

#### Example 1

#### Request (curl):

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject/testShare", false, true, true, "568346" ]' \
https://10.200.245.4/zebi/api/v2/deleteShare -k
```

## Response

The API returns the HTTP status code 200 (OK) and '0' as integer indicating a successful operation.

```
0
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ pool-1/Local/testProject/testShare", false, true, true ]' \
https://10.200.245.4/zebi/api/v2/deleteShare -k
```

#### **Error Response**

The API returns the EZEBI\_GENERAL error code and the following message when you send a request without valid verification code.

## deleteShare

Promotes dependents as specified, and then deletes the share whose dataset path is supplied as an argument.

Dependents are deleted as well if promote is false.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

deleteDataset

#### **Parameters**

#### datasetPath

This string identifies the share on the IntelliFlash array.

#### recursive

Whether to remove the dependents of the dataset before deleting it.

#### errorlfNotExist

Whether to raise an exception if the datasetPath to delete doesn't exist.

## promote

Whether to remove the dependents of the dataset before deleting it.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if a dataset is not found.

#### **EZEBI RESOURCE INUSE**

This exception is thrown if the replication is currently running.

#### EZEBI\_RESOURCE\_SUSPENDED

This exception is thrown if the pool is suspended.

#### **EZEBI GENERAL**

This exception is thrown if deletion failed.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If the dataset is empty
- If the length is greater than the maximum length
- · If it contains invalid characters

## **Examples**

#### Example 1

#### Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-share", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

## Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-share", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteShare -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the

following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "No such share exists.",
   "extendedData": {}
}
```

## deleteShare

Deletes the specified share and optionally any dependents of the share.



**Caution:** If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the given share) are also deleted.



**Warning:** The delete operation is not reversable.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

listShares, createShare, createShare.

## **Parameters**

#### datasetPath

A string: the path which uniquely identifies the share. The dataset path has the format: PoolName/Local/ProjectName/ShareName. You can obtain the datasetPath from the listShares API. For more information, see *listShares* and *Share\_V1\_0*.

#### recursive

A boolean: a true specifies that dependents of the share should be deleted before deleting the share or not (false)

#### errorlfNotExist

A boolean value: that specifies if an exception is raised (if true) if the given dataset path does not exist or not (if false).

#### Returns

Returns no data.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["Pool1/Local/Project1/Share1", false, false]' \
  https://198.51.100.10/zebi/api/v2/deleteShare -k
```

#### Response

On success, the above request returns the HTTP status code 200 (OK) and no data.

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["test/Local/KKKK/NoSuchShare", false, false]' \
  https://198.51.100.10/zebi/api/v2/deleteShare -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

## deleteVolume

Deletes the specified volume and optionally deletes its dependents with Two-Factor Authentication (2FA) if it is enabled for the user specified in the header.



**Note:** 2FA is supported in API version V2.8 and above. So, you need to send a delete volume request along with a valid verification code. For users with 2FA enabled on their user array login account, earlier (e.g. V1) versions of this API will not support 2FA.

#### First Available Version

API v2.8, IntelliFlash 3.11.5.0

#### **Parameters**

#### datasetPath

This string identifies the volume on the IntelliFlash array.

#### recursive

Whether to remove the dependents of the dataset before deleting it.

#### errorlfNotExist

Whether to raise an exception if the datasetPath to delete does not exist.

#### promote

Whether to remove the dependents of the dataset before deleting it.

#### verificationCode

Six digit 2FA verification code to validate the Two-Factor Authentication for an array user who has that feature enabled. Refer to *IntelliFlash User Guide* for more details on how to get this verification code (application code) from your mobile device authenticator.

#### Returns

The API returns an integer '0' if the request succeeds.

# **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error if:

- Invalid request, while 2FA is enabled for user. The API version V2.8 supports 2FA, so you need to send a request along with the valid verification code.
- Invalid verification code provided for user.
- · Deletion of voulme failed.

#### **EZEBI PERMISSION DENIED**

This exception is thrown if access is denied.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the dataset is not found.

## EZEBI\_RESOURCE\_INUSE

This exception is thrown if replication is currently running.

#### **EZEBI RESOURCE SUSPENDED**

This exception is thrown if pool is suspended.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- · If the dataset is empty
- If the length is greater than the maximum length
- If it contains invalid characters

## **Examples**

#### Example 1

## Request (curl):

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject/testLun", true, true, true, "818427" ]' \
https://10.200.245.4/zebi/api/v2/deleteVolume -k
```

#### Response

The API returns the HTTP status code 200 (OK) and '0' as integer indicating a successful operation.

```
0
```

## Example 2

#### **Erroneous Request**

```
curl -X POST \
-H 'authorization: Basic Auth_TOKEN' \
-H 'content-type: application/json' \
-d '[ "pool-1/Local/testProject/testLun", true, true, true ]' \
https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

#### **Error Response**

The API returns the EZEBI\_GENERAL error code and the following message when you send a request without valid verification code.

## deleteVolume

Promotes the specified dependent and then deletes the volume whose dataset path is supplied as an argument. Dependents are deleted as well if promote is false.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

deleteDataset

#### **Parameters**

#### datasetpath

The string that uniquely identifies the volume on the IntelliFlash array.

#### recursive

Whether to remove the dependants (for example, clones) and lun of the dataset before trying to delete it. Deletion might fail if there are dependants or lun existing on the dataset.

#### errorlfNotExist

Whether to raise an exception if the datasetPath to delete doesn't exist.

#### promote

Whether to promote clone before deletion

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED(0) on success

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the dataset is not found.

#### EZEBI\_RESOURCE\_INUSE

This exception is thrown if replication is currently running.

## EZEBI\_RESOURCE\_SUSPENDED

This exception is thrown if pool is suspended.

#### **EZEBI\_GENERAL**

This exception is thrown if deletion failed.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- · If the dataset is empty
- If the length is greater than the maximum length
- If it contains invalid characters

#### **Examples**

#### Example 1

## Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-volume", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-volume", false, true, true
]' https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

#### **Error Response**

The above request returns the HTTP status code 404 and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "No such volume exists.",
  "extendedData": {}
}
```

## deleteVolume

Deletes the specified volume, and optionally, any dependents of the volume.



**Caution:** If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the given volume) are also deleted.



**Warning:** The delete operation is not reversible.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### Related APIs

listVolumes. createVolume.

#### **Parameters**

#### datasetPath

A string: the path which uniquely identifies the volume on the IntelliFlash system. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume\_V1\_0*.

#### recursive

A boolean: indicates whether the dependents (for example, clones of the dataset) of the dataset should be removed (if true) before trying to delete the dataset. This API fails if you try to delete a volume that has dependents and the recursive parameter is set to false.

#### errorlfNotExist

A boolean value: indicates whether to raise (if true) an exception if the path specified by the dataset parameter does not exist.

#### Returns

Returns no data.

#### **Examples**

## Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/api_createVolume_name_2", \
        true,true]' \
  https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

### Response

The above request returns the HTTP status code 200 (OK) and no data.

## Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/api_createVolume_", \
    true,true]' \
  https://198.51.100.10/zebi/api/v2/deleteVolume -k
```

## **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
  "message": "Unable to delete pool1/Local/TechPubs/api_createVolume_
because it does not exist",
  "extendedData": {},
  "details": "",
  "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

# **exportPool**

Exports a pool.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

deletePool, importPool, resetPoolError, checkPoolIntegrity

#### **Parameters**

#### poolName

Name of the pool to export.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

If the pool does not exist.

## EZEBI\_INVALID\_ARGUMENT

If an invalid character is detected in the poolName.

## EZEBI\_RESOURCE\_EXIST

If an active pool with the same name exists already.

## EZEBI\_OPERATION\_NOT\_ALLOWED

If pool is in a state where export cannot be done.

#### **EZEBI\_GENERAL**

## **Examples**

#### Example 1

## Request (curl):

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool6a"]' \
https://198.51.100.10/zebi/api/v2/exportPool -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

## Example 2

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["nonExistentPool6a", false]' \
https://198.51.100.10/zebi/api/v2/exportPool -k
```

## **Error Response**

The above request returns the HTTP status code 404 (not found) and thefollowing message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "Pool requested for export was not found",
"message": "Failed to export the pool [nonExistentPool6a].",
"extendedData": {
    "EX_CAUSE_MESSAGE": "Pool requested for export was not found",
    "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
}
```

# getCopyStatus

Returns the status of a copy operation task.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

copyDataset, listRunningCopyOperations, listAllCopyOperations, abortCopy

# Parameters taskGUID

The GUID of the copy operation task.

#### Returns

Returns the CopyDestination\_V2\_1 object.

# Exceptions Thrown EZEBI GENERAL

This exception is thrown if the task GUID is invalid.

#### **Examples**

## **Example 1**

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["europa:84944c8a-8bc1-4705-809e-144363797a57"]' \
https://198.51.100.10/zebi/api/v2/getCopyStatus -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the *CopyDestination\_V2\_1* object.

```
"numberOfCopies": 3,
"completedCopies": 3,
"status": "COMPLETED",
"allDatasets": [
   "napa/Local/remotecopy/prod1",
    "napa/Local/remotecopy/prod2",
    "napa/Local/remotecopy/prod3"
"completedDatasets": [
    "napa/Local/remotecopy/prod1",
    "napa/Local/remotecopy/prod2",
    "napa/Local/remotecopy/prod3"
"pendingDatasets": [],
"percentComplete": 100,
"errorCode": null,
"startTime": "2017-07-10T11:00:16-07:00",
"endTime": "2017-07-10T11:01:03-07:00"
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '["euro:84944c8a-8bc1-4705-809e-144363797a57"]' \
https://198.51.100.10/zebi/api/v2/getCopyStatus -k
```

## **Error Response**

The above request returns HTTP status code 400 with the following message:

```
"code": "EZEBI_GENERAL",
  "details": "",
  "message": "Pool euro is not mounted.",
  "extendedData": {}
}
```

# getDatasetSpaceInfo

Returns a *DatasetSpaceInfo\_V2\_1* object if the specified dataset exists.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getPoolSpaceInfo

#### **Parameters**

#### **Dataset-path**

A string specifying path to the dataset (share or volume).

#### Returns

A DatasetSpaceInfo\_V2\_1 object.

## **Exceptions Thrown**

#### **EZEBI INVALID ARGUMENT**

This error is thrown if the parameters are invalid (if dataset name contains special characters).

#### **EZEBI\_GENERAL**

This error is thrown if the operation failed with internal reasons.

## EZEBI\_RESOURCE\_NOT\_FOUND

This error is thrown if the specified dataset doesn't exist.

## **Examples**

#### Example 1

#### Request (curl)

#### Response

The above request returns the HTTP status code 200 (OK) and a *DatasetSpaceInfo\_V2\_1* object.

```
"originalUsedByDataAndSnapshot": 30208,
   "usedByDataAndSnapshot": 30208,
   "compressionSavingsPercentage": 0,
   "available": 1202104,
   "usedByData": 13824,
   "usedBySnapshot": 16384,
   "usedByReservation": 0,
   "quota": 1232312,
   "volSize": 0
```

#### Example 2

#### **Erroneous Request (curl)**

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "",
"message": "Cannot find dataset: pool-a/Local/my-project/non-exist",
```

```
"extendedData": {}
}
```

# getFloatingIPList

Lists floating IP addresses associated with a storage pool.

#### First Available Version

API v2.2, IntelliFlash 3.7.1.0

#### **Parameters**

## poolName

The name of the target pool.

For empty string "", the API lists all the floating IP addresses.

#### **Returns**

Returns a *FloatingIP\_V2\_2* object.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified pool does not exist.

#### **EZEBI GENERAL**

This exception is thrown if an internal error is detected.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the pool name is invalid.

## **Examples**

## **Example 1**

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a"]' \
https://198.51.100.10/zebi/api/v2/getFloatingIPList -k
```

# Response

```
[
{
    "resourceGroupName": "defaultResourceGroup1",
    "description": "data_10g_0@ha-controller-b,data_10g_0@ha-controller-a",
    "failoverMode": "Immediately",
    "ipAddress": "198.51.10.20",
    "netmask": "255.255.0.0",
    "poolName": "pool-a"
}
```

#### Example 2

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[""]' \
https://198.51.100.10/zebi/api/v2/getFloatingIPList -k
```

## Response

As the request was sent with an empty string, the API returns all the floating IP addresses.

```
[
  "resourceGroupName": "defaultResourceGroup1",
  "description": "data 10g 0@ha-controller-b,data 10g 0@ha-controller-a",
  "failoverMode": "Immediately",
  "ipAddress": "198.30.10.20",
  "netmask": "255.255.0.0",
  "poolName": "pool-a"
},
"resourceGroupName": "defaultResourceGroup1",
"description": "data_10g_0@ha-controller-b,data_10g_0@ha-controller-a",
"failoverMode": "Immediately",
"ipAddress": "198.168.100.50",
"netmask": "255.255.0.0",
"poolName": "pool-b"
},
]
```

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[null]' \
```

```
https://198.51.100.10/zebi/api/v2/getFloatingIPList -k
```

#### **Error Response**

# getPoolSpaceInfo

Returns a *PoolSpaceInfo\_V2\_1* object if it exists.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getDatasetSpaceInfo

#### **Parameters**

#### Pool-name

A string specifying pool name.

#### Returns

A PoolSpaceInfo\_V2\_1 object.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This error is thrown if the parameters are invalid (pool name contains special characters).

#### **EZEBI\_GENERAL**

This error is thrown if the operation failed with internal reasons.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This error is thrown if the specified pool doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a"
  }
]' https://198.51.100.10/zebi/api/v2/getPoolSpaceInfo -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a *PoolSpaceInfo\_V2\_1* object.

```
"totalPoolSize": 1024173568,
  "originalUsedByDataAndSnapshot": 899392896,
  "usedByDataAndSnapshot": 248960000,
  "compressionSavingsPercentage": 72.32,
  "dedupeSavingsPercentage": 0,
  "totalSavingsPercentage": 72.32,
  "usedByAll": 252706816,
  "available": 771466752,
  "usedByData": 248025600,
  "usedBySnapshot": 934400,
  "usedByReservation": 0,
  "totalMetaSize": 0,
  "usedMeta": 0
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-non-exist"
  }
]' https://198.51.100.10/zebi/api/v2/getPoolSpaceInfo -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (Not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Cannot find the pool: pool-non-exist",
   "extendedData": {}
}
```

# getProject

Returns a *Project\_V2\_4* object which contain details of the specified project.

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

#### **Parameters**

#### poolName

Name of the pool that contains the project.

#### projectName

Name of the project.

#### local

A Boolean value indicating whether the project is local or replica.

#### Returns

A Project\_V2\_4 object.

#### **Exceptions thrown**

#### **EZEBI\_INVALID\_ARGUMENT**

This exception is thrown if the project name or pool name contains special characters.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic YOUR_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d ' ["pool-a", "projectX", true]'
https://198.51.100.10/zebi/api/v2/getProject -k
```

#### Response

```
{
   "poolName": "pool-a",
    "projectName": "projectX",
    "localDataset": true,
    "purpose": "Generic",
    "mountPoint": "/export/projectX",
    "compression": "lz4",
    "compressedLog": "off",
    "intendedProtocolList": [
        "NFS",
        "SMB",
       "FC",
        "iSCSI"
    "quotaInByte": 42949672960,
    "quotaEnabled": true,
    "dedup": "on",
    "copies": "1",
    "primaryCache": "all",
    "secondaryCache": "all",
    "readonly": "off",
    "logbias": "latency",
    "aclInherit": "on",
    "aclMode": "passthrough",
    "krbStatus": false,
    "defaultVolumeSizeInByte": 1073741824,
    "defaultVolumeBlockSize": "32KB",
    "defaultThinProvisioning": false,
    "sync": "always",
    "zfsDataSetName": "pool-a/Local/projectX",
    "recordSize": "128KB",
    "quota": 40,
    "quotaMetric": "GB",
    "defaultVolumeSize": 1,
    "defaultVolumeSizeUnit": "GB",
    "compressionClass": "Optimal Performance",
    "reservation": 0,
    "overrideSpaceUsageThreshold": true,
    "spaceUsageWarningThreshold": 70,
    "spaceUsageCriticalThreshold": 75,
    "spaceUsageThresholdStatus": "NORMAL"
}
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic YOUR_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d ' ["pool-a", "project99", true]'
```

```
https://198.51.100.10/zebi/api/v2/getProject -k
```

#### **Error Response**

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
    "message": "Cannot find the specified project 'pool-a/Local/
project99'.",
    "extendedData": {}
}
```

## getProject

Returns a *Project\_V2\_1* object if the project exists.

#### **Related APIs**

createProject, modifyProjectProperties, getProjectProperty

#### **Parameters**

#### pool-name

A string specifying the name of the pool

#### Project-name

A string specifying the name of the project.

#### Is-local

A Boolean value indicating whether the project is local or replica.

#### project

The name of the project.

#### Returns

A *Project\_V2\_1* object.

#### **Exceptions thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (project or pool name contains special characters).

#### **EZEBI GENERAL**

This exception is thrown if operation failed with internal reasons.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if specified project doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic YOUR_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
      "pool-a", "my-project", true
]' https://YOUR_IP/zebi/api/v2/getProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a Project\_V2\_1 object.

```
{
    "poolName": "pool-a",
    "projectName": "my-project ",
    "localDataset": true,
    "purpose": "generic",
    "mountPoint": "/export/my-project ",
    "compression": "lz4",
    "compressedLog": "off",
    "intendedProtocolList": [
        "NFS",
        "SMB",
        "FC",
        "iSCSI"
    "quotaInByte": 0,
    "quotaEnabled": false,
    "dedup": "on",
    "copies": "1"
    "primaryCache": "all",
    "secondaryCache": "all",
    "readonly": "off",
"logbias": "latency",
    "aclInherit": "off",
    "aclMode": "passthrough",
    "krbStatus": false,
    "defaultVolumeSizeInByte": 1073741824,
    "defaultVolumeBlockSize": "4KB",
    "defaultThinProvisioning": true,
    "sync": "standard",
    "zfsDataSetName": "pool-a/Local/my-project ",
    "recordSize": "16KB",
    "quota": 0,
    "quotaMetric": "GB",
    "defaultVolumeSize": 1,
    "defaultVolumeSizeUnit": "GB"
}
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic YOUR_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a", "non-exist", true
]' https://YOUR_IP/zebi/api/v2/getProject -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (Not found) and the following message:

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
    "message": "Cannot find the specified project 'pool-a/Local/non-exist'.",
    "extendedData": {}
}
```

# getProjectProperty

Returns a *DatasetProperty\_V2\_1* object if the project exists.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createProject, modifyProjectProperties, getProject

#### **Parameters**

#### **Dataset-path**

A string specifying the project path.

#### **Property-name**

A string specifying the property to query.

#### Returns

A *DatasetProperty\_V2\_1* object that contains the query key and value.

# **Exceptions Thrown**

**EZEBI INVALID ARGUMENT** 

This exception is thrown if the parameters are invalid (project or property name contains invalid characters).

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified project doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Local/my-project", "dedup"
    ]'
https://198.51.100.10/zebi/api/v2/getProjectProperty -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a DatasetProperty\_V2\_1 object.

```
{
   "propertyKey": "dedup",
   "propertyValue": "on"
}
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Local/my-project", "non-exist-property"
    ]'
https://198.51.100.10/zebi/api/v2/getProjectProperty -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "",
  "message": "Can't get property:non-exist-property.
  Please supply a valid project property.
  Check API documents for more details",
  "extendedData": {}
```

getShare

Returns all the details of the specified share.

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

#### **Parameters**

#### datasetPath

The dataset path of the share. This is a string. The dataset path has the format:

PoolName/Local/ProjectName/ShareName.

#### Returns

Returns a JSON array of *Share\_V2\_4* objects that contains all the details of the share.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the name of the share is invalid.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool-a/Local/SMBProject1/SQLServerShare_1"]' \
  https://198.51.100.10/zebi/api/v1/getShare -k
```

```
"name": "SQLServerShare_1",
   "poolName": "pool-a",
   "projectName": "SMBProject1",
   "purpose": "SQL Server",
   "guid": "5e665476-6235-4905-afa6-b439b81757ce",
   "compression": "lz4",
   "overrideCompression": false,
   "localDataset": true,
   "reservationInByte": 0,
   "reservationWetric": "GB",
   "reservationEnabled": false,
```

```
"dedup": "off",
"overrideDedup": false,
"copies": "1",
"overrideCopies": false,
"primaryCache": "all",
"overridePrimaryCache": false,
"secondaryCache": "all",
"overrideSecondaryCache": false,
"readonly": "off",
"overrideReadonly": false,
"logbias": "latency",
"overrideLogbias": false,
"sync": "always",
"overrideSync": false,
"overrideProjectSnapshotSettings": false,
"zfsDataSetName": "pool-a/Local/coolSMBProject/SQLServerShare 1",
"compressedLog": "off",
"overrideCompressedLog": false,
"compressionClass": "Optimal Performance",
"overrideMountPoint": false,
"quotaInByte": 0,
"quota": 0,
"quotaMetric": null,
"quotaEnabled": false,
"mountPoint": "/export/coolSMBProject/SQLServerShare 1",
"availableSize": 9730339679232,
"totalSize": 9730339704320,
"overrideSharenfs": false,
"overrideSharesmb": false,
"krbStatus": false,
"cifsDisplayName": "coolSMBProject SQLServerShare 1",
"questStatus": false,
"aclInherit": "on",
"overrideAclInherit": true,
"recordSize": "64KB",
"overrideRecordSize": true,
"atime": "off",
"nbmand": "off",
"aclList": [
    {
        "id": 0,
        "controllerId": null,
        "aclType": "Everyone",
        "aclUser": "",
        "aclGroup": ""
        "aclValDisplay": "rwxpdDaARWcCos",
        "aclVal": 2032127,
        "aclMode": "Allow",
        "aclInheritanceFlag": "Both",
        "includeSubShares": false,
        "userId": 0,
        "groupId": 0
"sharenfs": "off",
"sharesmb": "on",
"overrideSpaceUsageThreshold": true,
"spaceUsageWarningThreshold": 85,
"spaceUsageCriticalThreshold": 90,
"spaceUsageThresholdStatus": "NORMAL",
"containerName": "Local"
```

}

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool-a/Local/SMBProject1/SQLServerShare_99"]' \
  https://198.51.100.10/zebi/api/v1/getShare -k
```

#### **Error Response**

# getShare

Returns a Share\_V2\_1 object if it exists.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

createShare, modifyShareProperties, getShareProperty

#### **Parameters**

#### Share-path

A string specifying path to share.

#### Returns

A Share\_V2\_1 object.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (project or share name contains special characters).

#### **EZEBI GENERAL**

This exception is thrown if the operation failed with internal reasons.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-share"
  }
]' https://198.51.100.10/zebi/api/v2/getShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a Share\_V2\_1 object.

```
{
   "name": "my-share",
   "poolName": "pool-a",
   "projectName": "my-project ",
   "purpose": "custom",
   "quid": "07ee6f26-f701-4e98-8db6-778736e72df8",
   "compression": "lz4",
   "overrideCompression": false,
   "localDataset": true,
   "reservationInByte": 43,
   "reservation": 0.00004100799560546875,
   "reservationMetric": "MB",
   "reservationEnabled": true,
   "dedup": "on",
   "overrideDedup": false,
   "copies": "1",
   "overrideCopies": false,
   "primaryCache": "metadata",
   "overridePrimaryCache": true,
   "secondaryCache": "all",
   "overrideSecondaryCache": false,
   "readonly": "off",
   "overrideReadonly": false,
   "logbias": "throughput",
```

```
"overrideLogbias": true,
    "sync": "standard",
    "overrideSync": false,
    "overrideProjectSnapshotSettings": false,
    "zfsDataSetName": "pool-a/Local/my-project/my-share ",
    "compressedLog": "off",
    "overrideCompressedLog": true,
    "overrideMountPoint": true,
    "quotaInByte": 1232312,
    "quota": 1.1752243041992188,
    "quotaMetric": "MB",
    "quotaEnabled": true,
    "mountPoint": "/export/my-project/my-share",
    "availableSize": 1202104,
    "totalSize": 1232312,
    "overrideSharenfs": true,
    "overrideSharesmb": true,
    "krbStatus": false,
    "cifsDisplayName": "my-share",
    "questStatus": false,
    "aclInherit": "off",
    "overrideAclInherit": false,
    "recordSize": "16KB",
    "overrideRecordSize": false,
    "atime": "on",
    "nbmand": "off",
    "aclList": [
        {
            "id": 0,
            "controllerId": null,
            "aclType": "Group",
            "aclUser": null,
            "aclGroup": "dasd",
            "aclValDisplay": "rwxpdDaARWcCos",
            "aclVal": 2032127,
            "aclMode": "Allow",
            "aclInheritanceFlag": "Default",
            "includeSubShares": false,
            "userId": 0,
            "groupId": 104
        },
            "id": 0,
            "controllerId": null,
            "aclType": "User",
            "aclUser": "user1",
            "aclGroup": null,
"aclValDisplay": "rwxpdDaARWcCos",
            "aclVal": 2032127,
            "aclMode": "Allow",
            "aclInheritanceFlag": "Default",
            "includeSubShares": false,
            "userId": 104,
            "groupId": 0
    "containerName": "Local"
}
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
   {
    "pool-a/Local/my-project/non-exist"
   }
]' https://198.51.100.10/zebi/api/v2/getShare -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "Unable to open pool-a/Local/my-project/non-exist: dataset
does not exist",
   "message": "Unable to open pool-a/Local/my-project/non-exist: dataset
does not exist",
   "extendedData": {
        "EX_CAUSE_MESSAGE": "Unable to open pool-a/Local/
            my-project/non-exist: dataset does not exist",
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_CODE_NUMBER": "2009"
   }
}
```

# getShareProperty

Returns a *DatasetProperty\_V2\_1* if it exists.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createVolume, modifyVolumeProperties, getVolumeProperty, getProjectProperty

#### **Parameters**

#### Share-path

A string specifying the path to share.

#### Returns

A *DatasetProperty\_V2\_1* contains the query key and value.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This error is thrown if the parameters are invalid (project or share name contains special characters)

#### **EZEBI GENERAL**

This error is thrown if the operation failed with internal reasons.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This error is thrown if the specified share doesn't exist.

#### **Examples**

#### **Example 1**

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-share",
        "quotaInByte"
  }
]' https://198.51.100.10/zebi/api/v2/getShareProperty -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a *DatasetProperty\_V2\_1* object.

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code": "EZEBI_INVALID_ARGUMENT",
    "details": "",
    "message": "Can't get property:non-exist-property is not a valid
field!.
    Please supply a valid property. Check API documents for more details",
    "extendedData": {}
}
```

# getVolume

Returns a *Volume\_V2\_4* object in JSON format for the specified volume.

#### **First Available Version**

API v2.4, IntelliFlash 3.10.x.x

#### **Parameters**

#### dataset path

A string specifying the path to the volume. The dataset path has the format:

PoolName/Local/ProjectName/VolumeName

#### Returns

A Volume\_V2\_4 object.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid volume name is provided.

#### **Examples**

#### **Example 1**

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/projectX/projectX_V1_VV1"
  }
]' https://198.51.100.10/zebi/api/v2/getVolume -k
```

#### Response

```
"name": "projectX V1 VV1",
"poolName": "pool-a",
"projectName": "projectX",
"purpose": "Generic",
"guid": "30662b2f-a36c-4e38-bce2-c586ce0224db",
"compression": "lz4",
"overrideCompression": false,
"localDataset": true,
"reservationInByte": 3380281344,
"reservationMetric": "GB",
"reservationEnabled": true,
"dedup": "on",
"overrideDedup": false,
"copies": "1",
"overrideCopies": false,
"primaryCache": "all",
"overridePrimaryCache": false,
"secondaryCache": "all",
"overrideSecondaryCache": false,
"readonly": "off",
"overrideReadonly": false,
"logbias": "latency",
"overrideLogbias": false,
"sync": "always",
"overrideSync": false,
"overrideProjectSnapshotSettings": false,
"zfsDataSetName": "pool-a/Local/projectX/projectX_V1_VV1",
"compressedLog": "off",
"overrideCompressedLog": false,
"compressionClass": "Optimal Performance",
"volSize": 3276800000,
"volSizeUnit": "GiB",
"luId": "61C5A0B0FAC2850000005C119B570009",
"thinProvisioning": false,
"blockSize": "32KB",
"writeBackCache": "enable",
"overrideViews": false,
"protocol": "iSCSI",
"overrideSpaceUsageThreshold": true,
"spaceUsageWarningThreshold": 50,
"spaceUsageCriticalThreshold": 55,
"spaceUsageThresholdStatus": "NORMAL",
"containerName": "Local"
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/projectX_V1"
  }
]' https://198.51.100.10/zebi/api/v2/getVolume -k
```

#### **Error Response**

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "Unable to open pool-a/Local/my-project/projectX_V1: dataset
does not exist",
   "message": "Unable to open pool-a/Local/my-project/projectX_V1: dataset
does not exist",
   "extendedData": {
        "EX_CAUSE_MESSAGE": "Unable to open pool-a/Local/my-project
        /projectX_V1: dataset does not exist",
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_CODE_NUMBER": "2009"
   }
}
```

# getVolume

Returns a *Volume\_V2\_1* object if it exists.

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

createVolume, modifyVolumeProperties, getVolumeProperty

#### **Parameters**

#### Volume-path

A string specifying the path to volume.

#### Returns

A Volume\_V2\_1 object.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (project or volume name contains special characters).

#### **EZEBI GENERAL**

This exception is thrown if the operation failed with internal reasons.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified volume doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-volume"
  }
]' https://198.51.100.10/zebi/api/v2/getVolume -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a Volume\_V2\_1 object.

```
{
   "name": "my-volume",
   "poolName": "pool-a",
   "projectName": "my-project",
   "purpose": "custom",
   "guid": "007ef1b2-cae6-41ff-9523-de0d81249819",
   "compression": "lz4",
   "overrideCompression": false,
   "localDataset": true,
   "reservationInByte": 0,
   "reservation": 0,
   "reservationMetric": null,
   "reservationEnabled": false,
   "dedup": "off",
   "overrideDedup": false,
   "copies": "1",
   "overrideCopies": false,
   "primaryCache": "all",
   "overridePrimaryCache": false,
   "secondaryCache": "all"
   "overrideSecondaryCache": false,
   "readonly": "off",
   "overrideReadonly": false,
   "logbias": "latency",
```

```
"overrideLogbias": false,
"sync": "standard",
"overrideSync": false,
"overrideProjectSnapshotSettings": false,
"zfsDataSetName": "pool-a/Local/my-project/ my-volume ",
"compressedLog": "off",
"overrideCompressedLog": false,
"volSize": 33285996544,
"luId": "600144F087EC75370000594058180013",
"usedSize": 48733696,
"thinProvisioning": true,
"blockSize": "32KB",
"writeBackCache": "enable",
"overrideViews": false,
"protocol": "iSCSI",
"containerName": "Local"
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/non-exist"
  }
]' https://198.51.100.10/zebi/api/v2/getVolume -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

# getVolumeProperty

Returns a *DatasetProperty\_V2\_1* object if it exists.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createVolume, modifyVolumeProperties, getShareProperty, getProjectProperty

#### **Parameters**

#### Volume-path

A string specifying path to volume.

#### **Property-name**

A string specifying the property to query.

#### Returns

A DatasetProperty\_V2\_1 object that contains the query key and value.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (project or volume name contains special characters).

#### **EZEBI GENERAL**

This exception is thrown if the operation failed with internal reasons.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified volume doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/my-project/my-volume",
  "dedup"
]' https://198.51.100.10/zebi/api/v2/getVolumeProperty -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a *DatasetProperty\_V2\_1* object.

```
{
    "propertyKey": "dedup",
    "propertyValue": "off"
}
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
     "pool-a/Local/my-project/my-volume",
     "non-exist-property"
     ]'
https://198.51.100.10/zebi/api/v2/getVolumeProperty -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Can't get property:non-exist-property is not a valid
field!.
   Please supply a valid property. Check API documents for more details",
   "extendedData": {}
}
```

# importPool

Imports a pool.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

deletePool, exportPool, resetPoolError, checkPoolIntegrity

# Parameters poolName

Name of the pool to import.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the pool does not exist.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in the poolName.

#### EZEBI\_RESOURCE\_EXIST

This exception is thrown if an active pool with the same name exists already.

#### EZEBI\_OPERATION\_NOT\_ALLOWED

This exception is thrown if pool is in a state that doesn't permit import.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool6a"]' \
https://198.51.100.10/zebi/api/v2/importPool -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '["nonExistentPool6a", false]' \
https://198.51.100.10/zebi/api/v2/importPool -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "Pool requested for import was not found",
"message": "Failed to import the pool [nonExistentPool6a].",
"extendedData": {
    "EX_CAUSE_MESSAGE": "Pool requested for import was not found",
    "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
}
```

# inheritPropertyFromProject

Reverts share or volume configuration value to parent configuration value.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

createProject, modifyProjectProperties, getProjectProperty, modifyShareProperties, modifyVolumeProperties

#### **Parameters**

#### **Dataset-path**

A string specifying path to the dataset (either share or volume).

#### **Property-name**

A string specifying the property to revert.

Valid property name includes Compression, Dedup, Copies, PrimaryCache,

SecondaryCache, Readonly, Logbias, Sync, CompressedLog,

ProjectSnapshotSettings, MountPoint, Sharenfs, Sharesmb, AcIInherit, and Views.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.

2 indicates that the request failed.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (project or share name contains special characters).

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed with internal reasons.

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified dataset doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {
    "pool-a/Local/my-project/my-dataset",
        "Dedup"
  }
]'
https://198.51.100.10/zebi/api/v2/inheritPropertyFromProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and an integer.

#### Example 2

#### **Erroneous Request (curl)**

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
    "details": "inheritPropertyFromProject.arg1 value 'non-supported-
property':
    Supported Inheritable Properties includes: Compression, Dedup, Copies,
    PrimaryCache,
    SecondaryCache, Readonly, Logbias, Sync, CompressedLog,
    ProjectSnapshotSettings,
    MountPoint, Sharenfs, Sharesmb, AclInherit, Views.",
    "message": "Supported Inheritable Properties includes:
    Compression, Dedup, Copies, PrimaryCache, SecondaryCache, Readonly,
    Logbias, Sync,
    CompressedLog, ProjectSnapshotSettings, MountPoint, Sharenfs, Sharesmb,
    AclInherit, Views.",
    "extendedData": {
        "EX_CAUSE_MESSAGE": null
    }
}
```

### **isProjectExposedOverNFS**

Returns whether the NFS protocol is enabled for a project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, getNFSNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

#### Returns

Returns True or False based on whether NFS protocol is enabled.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/isProjectExposedOverNFS -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and returns a true or false value indicating whether NFS is enabled over the specified project.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/isProjectExposedOverNFS -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
   "extendedData":{}
```

# **isShareExposedOverNFS**

Returns whether the NFS protocol is enabled for the share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLOnShare, removeAllNFSNetworkACLsOnShare, getNFSNetworkACLsOnShare

#### **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

This operation is not allowed for replica share datasets.

#### Returns

Returns True or False based on whether the NFS protocol is enabled.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
```

```
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Local/Project/demoShare"
    ]' \
https://198.51.100.10/zebi/api/v2/isShareExposedOverNFS -k
```

#### Response:

The above request returns the HTTP status code 200 (OK) and the following response:

```
true
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare"
    ]' \
  https://198.51.100.10/zebi/api/v2/isShareExposedOverNFS -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
   "extendedData":{}
}
```

# **listAllCopyOperations**

Lists all copy operations.

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

copyDataset, getCopyStatus, listRunningCopyOperations, abortCopy

#### **Parameters**

None

#### Returns

Lists the GUIDs of all copy operations.

#### **Exceptions Thrown**

None

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X GET \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  https://198.51.100.10/zebi/api/v2/listAllCopyOperations -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a list of GUIDs.

```
"europa:aeca7e25-a74e-4a81-860d-e1f3640f2ad5",
"europa:2282afb2-97b2-4ff8-86e5-10e3368766a3",
"europa:69bc5f81-242d-4908-9b5c-5a4029cadd7d",
"europa:a621708c-9a09-44da-b4d8-733a9e4883b5",
"europa:bb8602e3-1431-4507-b83e-63e7a4ae2bf5",
"europa:0e7b6bc7-5337-4974-83db-6f9e179034ea",
"europa:42a85c00-d067-42c9-9947-883e853d0862",
"europa:12bebd45-ae3c-451d-98ea-befdd595568a",
"europa:825ae7b1-f596-400d-89bc-a4f7466badc3",
"europa:1e1bc102-d8cc-4f8e-88b0-a0cc41f224fc",
"europa:69bc5f81-242d-4908-9b5c-5a4029cadd7d"
```

# **listLunsByld**

Lists LUN details for the specified LUN IDs.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

listPools, listProjects, listVolumes, listShares, createVolume.

#### **Parameters**

#### lunids

An array of strings where each string contains the logical unit ID of a LUN on the array. For example, "600144F0FA2A820000004FF35C280003".

#### Returns

A JSON array of *LunStatus* objects that contain details of the requested LUNs.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d
  '[["600144F0B4510D0000005631F7DB0001","600144F0B4510D0000005631F7E80002"]]'
  \
  https://198.51.100.10/zebi/api/v2/listLunsById -k
```

#### Response

```
ſ
    "viewCount" : 1,
    "operationalStatus" : 2,
    "metaFile" : null,
    "commandStatus" :0,
    "size" :"1073741824",
    "vendorId" : null,
    "writeCacheDisable" : false,
    "dataFile" : "/dev/zvol/rdsk/pool-a/Local/smb nfs/llun1",
    "guid" : "600144F0B4510D0000005631F7DB0001",
    "accessState" :0,
    "commandException" : null,
    "blockSize" : null,
    "productId" :null,
    "serialNumber" : null,
    "writeProtect" : false,
    "alias" :"/dev/zvol/rdsk/pool-a/Local/smb_nfs/llun1",
    "mgmtURL" :"",
    "datasetPath" : "pool-a/Local/smb nfs/llun1"
},
```

```
"viewCount" : 1,
    "operationalStatus" :2,
    "metaFile" : null,
    "commandStatus" : 0,
    "size" : "",
    "vendorId" : null,
    "writeCacheDisable" :false,
    "dataFile" : "/dev/zvol/rdsk/pool-a/Local/smb_nfs/lun2",
    "guid" : "600144F0B4510D0000005631F7E80002",
    "accessState" :0,
    "commandException" : null,
    "blockSize" : null,
    "productId" :null,
    "serialNumber" : null,
    "writeProtect" : false,
    "alias" : "/dev/zvol/rdsk/pool-a/Local/smb nfs/lun2",
    "mgmtURL" :"",
    "datasetPath" : "pool-a/Local/smb nfs/lun2"
1
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[["600144F012190100000052D92EC20165"]]' \
  https://198.51.100.10/zebi/api/v2/listLunsById -k
```

#### **Error Response**

```
HTTP Status Code: 200
[
    "commandStatus": 2,
    "commandException": {
        "code": "EZEBI RESOURCE NOT FOUND",
        "details": "",
        "extendedData": {},
        "message": "Lun 600144F012190100000052D92EC20165 doesn't exist"
         },
    "quid": null,
    "alias": null,
    "dataFile": null,
    "metaFile": null,
    "vendorId": null,
    "productId": null,
    "mgmtURL": null,
    "serialNumber": null,
    "viewCount": 0,
    "size": null,
    "blockSize": null,
    "writeProtect": false,
    "writeCacheDisable": false,
    "operationalStatus": 0,
    "accessState": 0,
```

```
"datasetPath": null
}
```

## **listPools**

Lists all the pools on the array. This is an HTTP GET method.

#### **First Available Version**

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

listProjects, listVolumes, listLunsByld, listShares.

#### **Parameters**

None

#### Returns

Returns a JSON array of *Pool\_V1\_0* objects that contains details of all the pools.

#### **Example**

#### Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json -d '[]'\
  https://198.51.100.10/zebi/api/v2/listPools -k
```

#### Response

```
[
{
"name":"pool-a",
"availableSize":3931776248832,
"totalSize":3931908341760
},
{
"name":"pool-b",
"availableSize":1965925029376,
"totalSize":1965954170880
}
```

# **listProjects**

Lists all the local or replicated projects in a pool.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### Related APIs

listPools, listVolumes, listLunsByld, listShares.

#### **Parameters**

#### poolName

A string: the name of the pool for which projects need to be listed.

#### local

A boolean: a true returns the local projects only; a false returns the replicated projects only.

#### **Returns**

Returns a JSON array of *Project\_V1\_0* objects that contains details of all the local or replicated projects in the specified pool.

#### **Examples**

#### **Example 1**

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["plaut", true]' \
  https://198.51.100.10/zebi/api/v2/listProjects -k
```

#### Response

```
[
{
"poolName":"plaut",
"name":"CIFS_TEST",
"local":true
},
{
"poolName":"plaut",
"name":"new_proj",
"local":true
}
]
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json -d '["pool11",true]' \
  https://198.51.100.10/zebi/api/v2/listProjects -k
```

#### **Error Response**

```
HTTP Status Code: 500
{
    "message": "Unable to open pool11/Local : dataset does not exist",
    "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool11/Local : dataset does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
        },
    "details": "Unable to open pool11/Local : dataset does not exist",
    "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

# **listRunningCopyOperations**

Lists all running copy operations.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

copyDataset, getCopyStatus, listAllCopyOperations, abortCopy

#### **Parameters**

None

#### **Returns**

Lists the GUIDs of all currently running operations. Copy operations that are completed or aborted are not listed.

#### **Exceptions Thrown**

None

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X GET \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
https://198.51.100.10/zebi/api/v2/listRunningCopyOperations -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a list of GUIDs. For example:

```
[
   "europa:137b93ca-280f-4693-a4d8-a39496827d9e",
   "europa:69bc5f81-242d-4908-9b5c-5a4029cadd7d"
]
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN' \
 -H 'cache-control: no-cache' \
 -H 'content-type: application/json' \
 -d '[{"poolName": "europa1",
"projectName": "images",
"subProjectName": "template"
},
"hostName": "10.68.132.120",
"poolName": "napa",
"projectName": "remotecopy",
"subProjectNamePrefix": "prod",
"subProjectNameNumberStart": 1,
"subProjectNameNumberEnd": 3,
"subProjectNameWildcard": ""
]'\
https://198.51.100.10/zebi/api/v2/copyDataset -k
```

#### **Error Response**

The above request returns HTTP status code 400 with the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "",
  "message": "Unable to find project images in europal",
  "extendedData": {}
```

## **listShares**

Lists all the local and replicated shares in a project.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### Related APIs

listPools, listProjects, listVolumes, listLunsByld, createShare, createShare.

#### **Parameters**

## poolName

A string: the name of the pool that contains the project specified by the projectName parameter.

## projectName

A string: the name of the project for which shares need to be listed.

#### local

A boolean: a **true** returns the local shares only; a **false** returns the replicated shares only.

#### Returns

Returns a JSON array of *Share\_V1\_0* objects that contains details of all the local or replicated shares in the specified pool and project.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["plaut","project2", true]' \
  https://198.51.100.10/zebi/api/v2/listShares -k
```

#### Response

```
[
{
    "poolName": "plaut",
```

```
"projectName": "project2",
    "name": "default_share",
    "availableSize": 9275971622400,
    "totalSize": 9275971769856,
    "datasetPath": "plaut/Local/project2/default_share",
    "mountpoint": /export/plaut/project2/default_share,
    "local": true
}
```

## Example 2

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool0","TechPubs", true]' \
  https://198.51.100.10/zebi/api/v2/listShares -k
```

## **Error Response**

```
HTTP Status Code: 500
{
   "message": "Unable to open pool0/Local/TechPubs : dataset does not exist",
   "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool0/Local/TechPubs : dataset
   does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
        },
   "details": "Unable to open pool0/Local/TechPubs : dataset does not exist",
   "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

## **listSharesByMountPoints**

Lists all shares available for given mountpoints or mountpoint patterns.

Sample valid patterns include:

- /export/project/share1, /export/project/\*, /export/project?/Share[1-3]
- /export/project/{share1,newshare}, \*Project\*

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

**listShares** 

#### **Parameters**

#### mountPointPatterns

An array of of mount points patterns.

#### Returns

A list of key value pairs, which consists of a mount point and its associated Share\_V2\_1 object.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specific resource (pool, project, or share) is not found.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the mountpoint pattern is invalid.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[["/export/*"]]' \
https://198.51.100.10/zebi/api/v2/listSharesByMountPoints -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a list of key-value pairs that consists of a mount point and its associated *Share\_V2\_1* object.

```
"/export/*": [
    "poolName": "pool63b",
        "projectName": "testProject",
        "name": "testShare",
        "availableSize": 1930781823488,
        "totalSize": 1945635603968,
        "datasetPath": "pool63b/Local/testProject/testShare",
        "mountpoint": "/export/testProject/testShare",
        "local": true
    },
    {
        "poolName": "pool63a",
         "projectName": "doNotCreateMeAgain",
        "name": "firstShare",
        "availableSize": 1073693696,
```

```
"totalSize": 1073741824,
    "datasetPath": "pool63a/Local/doNotCreateMeAgain/firstShare",
    "mountpoint": "/export/doNotCreateMeAgain",
    "local": true
    }
]
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[["export/*"]]' \
https://198.51.100.10/zebi/api/v2/listSharesByMountPoints -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
"details": "",
"message": "Mountpoint Pattern is not valid.
It can begin with '/', '[', '{' or '*'.
Example: /export/ExampleProject , *export/*.",
"extendedData": {}
}
```

## **listVolumes**

Lists all the local or replicated volumes within a project.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

listPools, listProjects, listLunsByld, listShares, createVolume.

#### **Parameters**

#### poolName

A string: the name of the pool that contains the project specified by the **projectName** parameter.

## projectName

A string: the name of the project for which volumes need to be listed.

#### local

A boolean: a true returns the local volumes only; a false returns the replicated volumes only.

#### Returns

Returns a JSON array of *Volume\_V1\_0* objects that contains details of all the local or replicated volumes within the requested project.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["plaut","project1", true]' \
  https://198.51.100.10/zebi/api/v2/listVolumes -k
```

## Response

```
[
    "poolName":"plaut",
    "projectName":"project1",
    "name":"iscsilun_0",
    "luId":"600144F0DE8CCA000000561C554A0006",
    "volSize":1073741824,
    "blockSize":"4KB",
    "thinProvision":false,
    "protocol":"iSCSI",
    "datasetPath":"plaut/Local/project2/iscsilun_0",
    "local":true
}
```

## Example 2

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool0","TechPubs", true]' \
  https://198.51.100.10/zebi/api/v2/listVolumes -k
```

## **Error Response**

```
HTTP Status Code: 500 {
```

```
"message": "Unable to open pool0/Local/TechPubs : dataset does not exist",
 "extendedData": {
      "EX CAUSE CODE NAME": "EZFS NOENT",
      "EX CAUSE MESSAGE": "Unable to open pool0/Local/TechPubs : dataset
does not exist",
      "EX CAUSE CODE NUMBER": "2009"
 "details": "Unable to open pool0/Local/TechPubs : dataset does not exist",
 "code": "EZEBI RESOURCE NOT FOUND"
```

## modifyProjectProperties

Modifies project properties with given values.

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

## **Parameters**

## zfsdatapath

A string specifying the path of the project.

## **Project**

A *Project V2 4* object used as a key-value.



The *Project V2 4* object includes space usage threshold parameters. A user can set the space usage threshold parameters only if the following conditions are met:

- Both warning and critical thresholds are provided and the overrideSpaceUsageThreshold flag is omitted. In this case, the system will automatically set the overrideSpaceUsageThreshold flag to true.
- 2. overrideSpaceUsageThreshold is set to false without providing both the warning and critical threshold values. This instructs the system to inherit the space usage threshold parameters.
- 3. overrideSpaceUsageThreshold is set to true and both the warning and critical threshold values are provided. This is similar to case 1 above but the user specifically sets the overrideSpaceUsageThreshold value to true.

#### Returns

Returns 0 if the request succeeds.

## **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This error is thrown if the property name or value is invalid.

#### **Examples**

#### **Example 1**

## Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/projectX",
  {
    "spaceUsageWarningThreshold":70,
    "spaceUsageCriticalThreshold":75,
  }
}

j'
https://198.51.100.10/zebi/api/v2/modifyProjectProperties -k
```

## Response

0

#### **Example 2**

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/projectX",
  {
    "spaceUsageWarningThreshold":200,
    "spaceUsageCriticalThreshold":75,
  }
]'
https://198.51.100.10/zebi/api/v2/modifyProjectProperties -k
```

#### **Error Response**

## modifyProjectProperties

Modifies project properties with given values.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createProject, getProject, getProjectProperty

#### **Parameters**

#### Project-path

A string specifying the path of the project.

## **Project**

A *Project\_V2\_1* object as key-value collection of properties to change.

You can modify other properties in *Project\_V2\_1* that are not marked as "read only".

## Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- · 2 indicates that the request failed.

## **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

If the parameters are invalid (when an invalid key-value pair is not supported by *Project\_V2\_1*).

## EZEBI\_RESOURCE\_NOT\_FOUND

If the specified project doesn't exist.

#### **Examples**

## Example 1

#### Request (curl):

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/my-project",
  {
    "quotaInByte":42949672960,
    "compression":"gzip-9",
    "recordSize":"128Kb",
    "dedup":"on"
  }
]' https://198.51.100.10/zebi/api/v2/modifyProjectProperties -k
```

## Response

The above request returns the HTTP status code 200 (OK) and an integer.

## Example 2

## **Erroneous Request (curl)**

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "modifyProjectProperties.arg1 value
   'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$Project_V2_1@7049d5c7':
   Please set quotaInByte, reservationInByte to configure quota/reservation
feature.
   quotaInByte/reservationInByte value should be at least 1MB(1048576)
   or set to 0 for no limit.",
   "message": "Please set quotaInByte, reservationInByte to
   configure quota/reservation feature. quotaInByte/reservationInByte
value should be
   at least 1MB(1048576), or set to 0 for no limit.",
   "extendedData": {
      "EX_CAUSE_MESSAGE": null
```

```
}
```

## modifyShareProperties

Modifies share properties with given values.

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

## **Parameters**

## datasetPath

The data path of the share.

## datasetProperties

Pass the Share\_V2\_4 object that is unique to this API.



## Note:

The *Share\_V2\_4* object includes space usage threshold parameters. A user can set the space usage threshold parameters if the following conditions are met:

- Both warning and critical thresholds are provided and the overrideSpaceUsageThreshold flag is omitted. In this case, the system will automatically set the overrideSpaceUsageThreshold flag to true.
- overrideSpaceUsageThreshold is set to false without providing both the warning and critical threshold values. This instructs the system to inherit the space usage threshold parameters.
- overrideSpaceUsageThreshold is set to true and both the warning and critical
  threshold values are provided. This is similar to case 1 above but the user specifically
  sets the overrideSpaceUsageThreshold value to true.

### Returns

Returns 0 if the request succeeds.

## Exceptions Thrown EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the property name or value is invalid.

#### **Examples**

#### Request (curl)

#### Response

0

#### Example 2

#### **Erroneous Request (curl)**

#### **Error Response**

## modifyShareProperties

Returns a Share\_V2\_1 object if it exists.

You can configure other general properties in Share\_V2\_1 that is not marked as "read only".

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

## **Related APIs**

createShare, getShare

#### **Parameters**

## Share-path

A string specifying the path to share.

## **Share**

A Share\_V2\_1 object as key-value collection of properties to change.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

#### **Exceptions Thrown**

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (project or share name contains special characters).

## EZEBI\_GENERAL

This exception is thrown if the operation failed with internal reasons.

## **EZEBI RESOURCE NOT FOUND**

This exception is thrown if the specified share doesn't exist.

#### **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-share",
        {
            "sync":"always",
            "quotaInByte":123456789
        }
     ]'
https://198.51.100.10/zebi/api/v2/modifyShareProperties -k
```

## Response

0

## Example 2

## Request (curl)

#### Response

0

## Example 3

#### Request (curl)

```
https://198.51.100.10/zebi/api/v2/modifyShareProperties -k
```

## Response

0

#### **Example 4**

## **Erroneous Request (curl)**

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "modifyShareProperties.arg1 value 'com.tegile.skywalk.api.v2.
  IPublicAPI_V2_1$Share_V2_1@1c8df8ce': Supported Data Sync Preference
  includes: Standard, Always.",
  "message": "Supported Data Sync Preference includes: Standard, Always.",
  "extendedData":
  {
    "EX_CAUSE_MESSAGE": null
  }
}
```

## modifyVolumeProperties

Modifies volume properties with given values.

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

## **Parameters**

datasetpath

A string specifying the path of the volume.

#### datasetProperties

A Volume V2 4 object that includes the new space usage threshold parameters.



The Volume\_V2\_4 object includes space usage threshold parameters. A user can set the space usage threshold parameters if the following conditions are met:

- Both warning and critical thresholds are provided and the overrideSpaceUsageThreshold flag is omitted. In this case, the system will automatically set the overrideSpaceUsageThreshold flag to true.
- 2. overrideSpaceUsageThreshold is set to false without providing both the warning and critical threshold values. This instructs the system to inherit the space usage threshold parameters.
- 3. overrideSpaceUsageThreshold is set to true and both the warning and critical threshold values are provided. This is similar to case 1 above but the user specifically sets the overrideSpaceUsageThreshold value to true.

#### Returns

Returns 0 if the request succeeds.

#### **Exceptions Thrown**

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the parameters are invalid (project or volume name contains special characters).

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN' \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 -d '[pool-a/Local/projectX/projXLUN_1,
         "spaceUsageWarningThreshold" : 50,
         "spaceUsageCriticalThreshold": 55
https://198.51.100.10/zebi/api/v2/modifyVolumeProperties -k
```

## Response

0

## Example 2

## Request (curl)

## Response

0

## Example 3

## **Erroneous Request (curl)**

#### **Error Response**

## modifyVolumeProperties

Modifies volume properties with given values.

You can configure other general properties in *Volume\_V2\_1* that is not marked as "read only".

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

createVolume, getVolume

#### **Parameters**

## Volume-path

A string specifying the path of the volume.

#### Volume

A *Volume\_V2\_1* object as key-value collection of properties to change.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

## **Exceptions Thrown**

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (project or volume name contains special characters).

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed with internal reasons.

## **EZEBI RESOURCE NOT FOUND**

This exception is thrown if the specified volume doesn't exist.

## **Examples**

#### Example 1

## Request (curl)

#### Response

0

#### Example 2

## **Erroneous Request (curl)**

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "createProject.arg0 value
   'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$Project_V2_1@1778db80':
    Invalid Compression Algorithm, disable compression by passing in
   'Off' or enable compression by using one of the following:
    Lzjb, Gzip-2, Gzip, Gzip-9, Lz4.",
   "message": "Invalid Compression Algorithm, disable compression by
passing in 'Off' or enable
   compression by using one of the following: Lzjb, Gzip-2, Gzip, Gzip-9,
Lz4.",
   "extendedData": {"EX_CAUSE_MESSAGE": null}
}
```

## Example 4

## **Erroneous Request (curl)**

## **Error Response**

## resetPoolError

Clears errors associated with a pool.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

## **Related APIs**

deletePool, exportPool, importPool, checkPoolIntegrity

# **Parameters**

#### poolName

Name of the pool where you want to clear the errors.

#### **Returns**

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

## **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the pool does not exist.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in the poolName.

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63a"]' \
https://198.51.100.10/zebi/api/v2/resetPoolError -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
   -H 'authorization: Basic AUTH_TOKEN' \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '["nonExistentPool6a"]' \
https://198.51.100.10/zebi/api/v2/resetPoolError -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "Pool not found.",
"message": "The pool [nonExistentPool6a] was not found.",
"extendedData": {
    "EX_CAUSE_MESSAGE": "Pool not found.",
    "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
}
```

## setNFSSharingOnProject

Enables or disables NFS protocol for project. If you disable NFS protocol for a project, any existing network ACLs on the project are removed as well.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

#### turnOn

Enables or disables NFS protocol on the project.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

## **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified project is not found.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", true
   ]' \
  https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This enables NFS sharing on the specified project.

## Example 2

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", false
    ]' \
  https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This disables NFS sharing on the specified project.

#### Example 3

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", true
   ]' \
  https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

#### **Error Response**

The above reguest returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

#### Example 4

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject", true
   ]' \
  https://198.51.100.10/zebi/api/v2/setNFSSharingOnProject -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
    "details":"setNFSSharingOnProject.arg0 value 'pool-a/Replica/
replicaProject':
    Local dataset path expected. For example, valid formats are
    'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
    "message":"Local dataset path expected.
    For example, valid formats are 'pool-name/Local/project-name' or
    'pool-name/Local/project-name/share-or-lun-name'.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

## setNFSSharingOnShare

Enables or disables NFS protocol for a share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

#### **Parameters**

#### datasetPath

```
Path of the project. The format is <poolName>/Local//cal/<shareName>.
```

This operation is not allowed for replica project datasets.

#### turnOn

Enables or disables NFS protocol on the share.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

## **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share is not found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to a replica dataset.

### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/demoShare", true]'
    https://198.51.100.10/zebi/api/v2/setNFSSharingOnShare -k
```

## Response

The above request returns the HTTP status code 200 (OK).

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/UNKNOWNShare", true]'
    https://198.51.100.10/zebi/api/v2/setNFSSharingOnShare -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following response:

## Example 3

#### **Erroneous Request**

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Replica/replicaProj/replicaShare", true]'
    https://198.51.100.10/zebi/api/v2/setNFSSharingOnShare -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"EX_CAUSE_MESSAGE":null
}
```

## modifyACLInheritanceOfShare

Modifies the inheritance property of ACL in a share.

## First Available Version

API v2.7, IntelliFlash 3.11.4.2

#### **Parameters**

## projectName

The name of the valid local project. You can modify ACL of a local project only.

## poolName

The valid pool name on which project is created.

#### shareName

The specific share on a local project whose ACL inheritance flag needs to be modified.

#### User

The ACL type "User" with permission can modify the ACL inheritance flag of a share.

## Group

The ACL type "Group" with permission can modify the ACL inheritance flag of a share.

## **Everyone**

The ACL type "Everyone" with permission can modify the ACL inheritance flag of a share.

#### Inheritance

The Inheritance attributes have ACL for 4 values as below:

- Files
- Directories
- Both
- None

#### Access

A share can have only two access types; "Allow" or "Deny".

#### Returns

The API returns 'code= 200' if the request succeeds.

# Exceptions Thrown EZEBI\_GENERAL

The API returns this error when you:

- Provide invalid new inheritance flag value
- · Provide invalid old inheritance flag value
- Do not provide valid ACL type
- Provide wrong userName value
- Provide wrong groupName value
- Do not provide userName value
- Do not provide groupName value

## EZEBI\_RESOURCE\_NOT\_FOUND

The API returns this error when wrong poolName parameter is provided.

## EZEBI\_INVALID\_ARGUMENT

The API returns this error when share name is not provided.

## **Examples**

#### Example 1

## Request (curl)

## Response

The API returns the following code:

```
200
```

'200' means that the request is successful and 'User' modified the ACL inheritance flag.

#### Example 2

## Request (curl)

#### Response

The API returns the following code:

```
200
```

'200' means that the request is successful and 'Group' modified the ACL inheritance flag.

## Example 3

## Request (curl)

#### Response

The API returns the following code:

```
200
```

'200' means that the request is successful and 'Everyone' modified the ACL inheritance flag.

### **Example 4**

#### **Erroneous Request**

#### **Error Response**

The API returns the following error response when **wrong poolName** is provided.

#### Example 5

## **Erroneous Request**

## **Error Response**

The API returns the following error response when invalid new inheritance flag value is provided.

### Example 6

#### **Erroneous Request**

## **Error Response**

The API returns the following error response when invalid old inheritance flag value is provided.

## Example 7

## **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["project1", "pool-1", "", "Everyone", "Allow", "", "", "Both", "None"]' \
https://10.200.245.4/zebi/api/v2/modifyACLInheritanceOfShare -k
```

## **Error Response**

The API returns the following error response when share name is not provided.

## Example 8

### **Erroneous Request**

#### **Error Response**

The API returns the following error response when valid ACL type is not provided.

```
{
    "code": "EZEBI_GENERAL",
```

## Example 9

## **Erroneous Request**

## **Error Response**

The API returns the following error response when wrong userName value is provided.

## Example 10

#### **Erroneous Request**

#### **Error Response**

The API returns the following error response when wrong groupName value is provided.

}

#### Example 11

## **Erroneous Request**

## **Error Response**

The API returns the following error response when userName value is not provided.

```
"code": "EZEBI_GENERAL",
  "details": "",
  "message": "Username value is empty. Please provide a valid username.",
  "extendedData": {}
}
```

## Example 12

## **Erroneous Request**

#### **Error Response**

The API returns the following error response when groupName value is not provided.

## getKerberosInfo

Fetches the Kerberos server information of an array.

#### First Available Version

API v2.7, IntelliFlash 3.11.4.2

#### **Parameters**

None

#### Returns

The API returns a JSON boolean status where:

- True indicates that the Kerberos server is enabled on array.
- False indicates that the Kerberos server is disabled on array.

## **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when Kerberos server is not configured on array.

## **Request Timeout**

The API returns this error when wrong Kerberos server IP is provided.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[]' \
https://10.200.245.4/zebi/api/v2/getKerberosInfo -k
```

#### Response

The API returns the following response.

```
[
    "id": 0,
    "controllerId": null,
    "ipAddress": "10.204.217.116",
    "hostName": "n6200-mgt1-pool-a.eco1.local",
    "krbStatus": true
},
    {
    "id": 0,
    "controllerId": null,
    "ipAddress": "10.204.217.106",
    "hostName": "n6200-mgt2-pool-a.eco1.local",
```

```
"krbStatus": true
},
{
    "id": 0,
    "controllerId": null,
    "ipAddress": "10.204.217.115",
    "hostName": "n6200-115-mgt.ecol.local",
    "krbStatus": false
}
```

'True' indicates that the Kerberos server is enabled on array.

While 'False' indicates that the Kerberos server is disabled on array.

## Example 2

## **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[]' \
https://10.200.245.4/zebi/api/v2/getKerberosInfo -k
```

## **Error Response**

The API returns the following error response when Kerberos server is not configured.

## Example 3

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[]' \
https://10.10.10.10/zebi/api/v2/getKerberosInfo -k
```

#### **Error Response**

The API returns the following error response when wrong Kerberos server IP is provided.

```
Request Timeout
```

## enableKerberos

Enables the Kerberos on an array.

#### **First Available Version**

API v2.7, IntelliFlash 3.11.4.2

## **Parameters**

#### **IPaddress**

The IP address of the Kerberos server to be enabled.

#### Username

The user name of the Kerberos server.

#### **Password**

The password of the Kerberos server.

#### Returns

If the request succeeds, the response is empty.

## **Exceptions Thrown**

## **EZEBI GENERAL**

The API returns this error when DNS cannot be resolved as there are no dns entries on the DNS server for the IPs provided.

## **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["10.200.245.4", "username", "password"]' \
https://10.200.245.4/zebi/api/v2/enableKerberos -k
```

## Response

The API returns HTTPS status code 200 with an empty JSON response.

Empty response means that the Kerberos server is enabled.

#### Example 2

## **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["10.200.245.4", "username", "wrongPassword"]' \
https://10.200.245.4/zebi/api/v2/enableKerberos -k
```

## **Error Response**

The API returns the following error response when incorrect Kerberos server credentials are provided.

## disableKerberos

Disables the Kerberos on an array.

## First Available Version

API v2.7, IntelliFlash 3.11.4.2

#### **Parameters**

#### **IPaddress**

The IP address of the Kerberos server to be disabled.

#### Username

The user name of the Kerberos server.

#### **Password**

The password of the Kerberos server.

#### **Returns**

If the request succeeds, the response is empty.

# **Examples**

# Example 1

# Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["10.200.245.4", "username", "password"]' \
https://10.200.245.4/zebi/api/v2/disableKerberos -k
```

# Response

The API returns HTTPS status code 200 with an empty JSON response.

Empty response means that the Kerberos server is disabled.

# Chapter 5

# **SAN Methods**

#### Topics:

- addInitiatorToInitiatorGroup
- createFCInitiator
- createInitiatorGroup
- createlscsilnitiator
- createISCSITarget
- createISCSITargetForGroup
- createMappingForVolume
- createMappingForVolume
- createTargetGroup
- deleteInitiatorGroup
- deletelSCSIInitiator
- deletelSCSITarget
- deleteMappingFromVolume
- deleteTargetGroup
- getInitiatorGroup
- getProjectDefaultFcITView
- getProjectDefaultIscsiITView
- getVolumeITView
- initiatorGroupExists
- listFCInitiators
- listFCInitiatorGroups
- listFCTargets
- listFCTargetGroups
- listInitiatorGroups
- listISCSIInitiatorGroups
- listISCSIInitiators
- listInitiatorsInInitiatorGroup
- listISCSITargetGroups
- listISCSITargets
- listProjectDefaultIscsiMappings
- listProjectDefaultFCMappings
- listTargetGroups
- listTargetsInTargetGroup
- listVolumeMappings
- modifyISCSITargetAlias
- moveTargetToTargetGroup
- moveInitiatorToInitiatorGroup

The following sections describe SAN methods, parameters, return types, and examples.

# addInitiatorToInitiatorGroup

Associates an initiator with an initiator group. If the initiator group is not present, then this method attempts to create it. If the initiator does not exist, then the method fails.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

initiatorGroupExists, addInitiatorToInitiatorGroup

#### **Parameters**

#### initiatorName

The name of an initiator.

#### **initiatorGroupName**

A string: the name of an initiator group.

#### Returns

Returns an integer, where:

- 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- · 2 indicates that the request failed

#### **Examples**

# Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '["iqn.2012-11.com.tegile.iscsi:Initiator1", "iscsi-TestGroup"]' \
https://198.51.100.10/zebi/api/v2/addInitiatorToInitiatorGroup -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and an integer 0 indicating success.

#### Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth TOKEN" \
```

```
-H Content-Type:application/json \
-d '["iqn.2012-11.com.tegile.iscsi:Initiator2", "iscsi-TestGroup2"]'\
https://198.51.100.10/zebi/api/v2/addInitiatorToInitiatorGroup -k
```

### **Error Response**

In the above request, the initiator already exists in the group. So the request returns the HTTP status code 400 (bad request) and the following message:

# createFCInitiator

Creates the Fibre Channel (FC) Initiator on the IntelliFlash Array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

listFCInitiators, deleteISCSIInitiator, listInitiatorGroups, createIscsiInitiator

#### **Parameters**

#### initiatorName

The name of the fibre channel initiator you want to create. This must be in the format wwn.<16 hex digits>. For example, wwn.5001438001FF7742.

#### initiator Group Name

The name of the fibre channel initiator group to add the initiator as a member.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified initiator group is not found.

#### EZEBI\_RESOURCE\_EXIST

This exception is thrown if the specified initiator already exists.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the initiator group is over 512 characters long
- If the initiator group has invalid characters such as \*,#,/,\\,!,@,~,(,),[,],{,},=, and %.
- If the initiator name is not in the format of wwn.<16 alpha-numeric-hex characters>

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["wwn.5001438001ffbbbb", "fc-igroup"]' \
https://198.51.100.10/zebi/api/v2/createFCInitiator -k
```

# Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the initiator was created in the specified initiator group.

#### Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["wwn.5001438001ffbbbb", "fc-igroup"]' \
https://198.51.100.10/zebi/api/v2/createFCInitiator -k
```

# **Error Response**

In this example, the fibre channel initiator already exists. So the request returns the HTTP status code 400 (bad request) and the following response:

```
{"code":"EZEBI_RESOURCE_EXIST","details":"",
"message":"The Fibre Channel initiator [wwn.5001438001ffbbbb]
already exists, but must not exist for this operation
[create initiator].","extendedData":{}}
```

# createInitiatorGroup

Creates an initiator group on an IntelliFlash Array.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

createlscsilnitiator, listInitiatorsInInitiatorGroup, addInitiatorToInitiatorGroup

#### **Parameters**

#### initiatorGroupName

A string: name of the new initiator group. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%,  $^*$ ,(, ),  $^*$ ,+, =, },|, {, [, ], ;, \', \", \_, & are not allowed in initiatorgroupname. The empty and space characters and the null values are not allowed in initiatorgroupname.

#### Returns

Returns an integer, where:

- 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- · 2 indicates that the request failed

# **Examples**

### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
-d '[ "APIInitiatorGroup" ]' \
https://198.51.100.10/zebi/api/v2/createInitiatorGroup -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the integer 0 indicating success.

### Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[ "API_InitiatorGroup" ]' \
  https://198.51.100.10/zebi/api/v2/createInitiatorGroup -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

# createlscsilnitiator

Creates an iSCSI initiator object on the IntelliFlash Array. If the initiator name already exists, then the method fails.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

initiatorGroupExists, addInitiatorToInitiatorGroup

#### **Parameters**

#### iscsilnitiator

A JSON object of type *Iscsilnitiator\_V1\_0* that contains the name of the initiator and optional CHAP information.

#### Returns

Returns an integer, where

- 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- 2 indicates that the request failed

# **Examples**

### Example 1

# Request (curl)

### Response

The above request returns the HTTP status code 200 (OK) and an integer 0 indicating success.

# Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[{"initiatorName":"","chapUserName":"","chapSecret":""}]' \
  https://198.51.100.10/zebi/api/v2/createIscsiInitiator -k
```

#### **Error Response**

In the above request, the initiator name is empty. So the request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "",
  "message": "Initiator name is not valid.",
  "extendedData": {}
}
```

# createISCSITarget

Creates an iSCSI target with the specified target group, chap authentication, alias, and network bindings.

This API allows the user to specify all the attributes of the target in the JSON ISCSITargetCreate\_V2\_1 parameter object passed.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createTargetGroup, moveTargetToTargetGroup, createISCSITargetForGroup, deleteISCSITarget, modifyISCSITargetAlias, listISCSITargets

#### **Parameters**

### iscsiTarget

A JSON object of type *ISCSITargetCreate\_V2\_1* that contains the attributes of the iSCSI target to create.

The JSON fields of the iSCSI target object parameter are

- targetSuffixName
- targetAlias
- targetGroupName
- targetAuthenticationMode
- targetChapName
- targetChapSecret
- targetNetworkBinding

The target suffix name is the user specified portion after the iqn target name colon character. For example, iqn.2012-02.com.tegile:myTargetSuffix.

Specify only a target suffix and not the full target name because the iSCSI target prefix is pre-defined for all targets on the array. The alias is the user friendly alternate name of the target.

The authentication mode is a value of 'none', 'chap', or 'mutual'. The chapName and chapSecret must be set depending on whether the authentication mode is set. Only if 'mutual' authentication is set, the chapName and chapSecret must be specified. The network binding (IP:PORT) can be any of the bindings associated with the target group name's pool. The default target group cannot be modified or used here.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

### **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified iSCSI target group does not exist.

#### EZEBI\_RESOURCE\_EXIST

This exception is thrown if the specified target already exists.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the default group is being modified

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[{
    "targetSuffixName": "test",
    "targetAlias": "testAlias",
    "targetGroupName": "iscsi-tgroup",
    "targetAuthenticationMode": "none",
    "targetChapName": "",
    "targetChapSecret": "",
    "targetNetworkBinding": [
        "10.68.97.211:3260"
    ] } ]' \
https://198.51.100.10/zebi/api/v2/createISCSITarget -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "iqn.2012-02.com.tegile:test" was created in the specified target group "iscsitgroup".

#### Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
```

```
-d '[{
    "targetSuffixName": "test3",
    "targetAlias": "testAlias",
    "targetGroupName": "iscsi-tgroup",
    "targetAuthenticationMode": "invalidauth",
    "targetChapName": "",
    "targetChapSecret": "",
    "targetNetworkBinding": [
        "10.68.97.211:3260"
    ] } ] ' \
https://198.51.100.10/zebi/api/v2/createISCSITarget -k
```

# **Error Response**

In this example, the chap authentication is an invalid type value. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "createISCSITarget.arg0.targetAuthenticationMode value
'invalidauth':
   Chap authentication should be one of the values:none, chap, or mutual
   createISCSITarget.arg0 value

'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$ISCSITargetCreate_V2_1@45b06d12':
   Invalid CHAP authentication passed[invalidauth],
   supported values are: none, chap, or mutual.",
   "message":
   "Chap authentication should be one of the values:none, chap, or mutual
   Invalid CHAP authentication passed[invalidauth],
   supported values are: none, chap, or mutual.",
   "extendedData": {
        "EX_CAUSE_MESSAGE": null
   }
}
```

# createISCSITargetForGroup

Creates an ISCSI target for the specified target group.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createTargetGroup, moveTargetToTargetGroup, createISCSITarget

### **Parameters**

targetNameSuffix

The iSCSI target name suffix.

This is the portion of the iSCSI iqn name that comes after the colon. This is the user specified part of the target name.

# targetAlias

The iSCSI alias user friendly name used to refer to the target.

This is typically the same as the target suffix.

# targetGroupName

Existing iSCSI target group that the new target will be a member of.

New targets created here cannot be added to the default target group. So the name here cannot be the default target group.

#### **Returns**

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified target group does not exist.

#### EZEBI\_RESOURCE\_EXIST

This exception is thrown if the specified target already exists.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the target group has invalid characters such as \*,#,/,\\,!,@,~,(,),[,],{,},=, and %.
- If the target group is the default target group
- If the target group is over 512 characters long

# **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["myTargetSuffix", "myTargetAlias", "myTargetGroup" ]' \
https://198.51.100.10/zebi/api/v2/createISCSITargetForGroup -k
```

### Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "iqn.2012-02.com.tegile:myTargetSuffix" was created in the specified target group "myTargetGroup".

### Example 2

### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["myTargetSuffix", "myTargetAlias", "group-does-not-exist-yet" ]' \
https://198.51.100.10/zebi/api/v2/createISCSITargetForGroup -k
```

#### **Error Response**

In this example, the target group does not exist. So the request returns the HTTP status code 400 (bad request) and the following response:

# createMappingForVolume

Maps a volume to an initiator group and a target group.

#### First Available Version

#### API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

deleteMappingFromVolume, initiatorGroupExists, listISCSIInitiatorGroups, listISCSITargetGroups, createVolume.

#### **Parameters**

#### datasetPath

The dataset path of the volume. This is a string. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume\_V1\_0*.

# initiatorGroupName

The name of the initiator group to which the volume must be mapped. This is a string.

# targetGroupName

The name of the target group to which the volume must be mapped. This is a string.

#### **lunNumber**

The LUN number for the newly defined LUN. To assign a LUN number automatically (default), use the value -1. This is an integer.

### **Returns**

Returns an integer, where

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

#### **Examples**

# Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[ "pool1/Local/TechPubs/TechPubsLUN", \
   "api_InitiatorGroup", \
   "iqn.2014-11.com.tegile.iscsi:testtargetgroup-group", -1]' \
https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

### Response

0

### Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[ "pool1/Local/TechPubs/TechPubsLUN2", \
  "api_InitiatorGroup", \
  "iqn.2014-11.com.tegile.iscsi:testtargetgroup-group", -1]' \
  https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

# **Error Response**

If the initiator group is not found, the above request returns the HTTP status code 200 (OK) and no data.

# createMappingForVolume

Creates a mapping for a volume, with the option for it to be read only.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

createMappingForProject, deleteMappingFromProject

# **Parameters**

#### datasetPath

```
Path of the LUN. The format is <poolName>/Local//
<lunName>.
```

This operation is not allowed for Replica datasets.

# initiatorGroupName

Name of the initiator group in the existing mapping.

# targetGroupName

Name of the target group in the existing mapping.

#### **LUNNumber**

LUN number to use. Pass a value of -1 if you want the system to assign an available LUN number.

# readOnly

Whether mapping is read-only. The values are True and False.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project, initiator group, or target group cannot be found.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown for any of the following reasons:

- The path specified belongs to a replica dataset.
- The volume protocol does not match the protocol of the SAN groups.
- The mapping does not exist.
- The mapping for this target group already exists (when trying to make All mapping).
- The mapping with 'All' initiator groups already exists on this target group for this LUN.

#### **Examples**

# Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject/demoLUN", "All", "demoiSCSITargetGroup", 1, true
    ]' \
  https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

# Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '[
   "pool-a/Local/demoProject/demoLUN", "All", "default-pool-a-iscsi-target-group", 1, true
    ]' \
   https://198.51.100.10/zebi/api/v2/createMappingForVolume -k
```

### **Error Response**

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"",
  "message":"View already exists with different read only value: true",
  "extendedData":{}
}
```

#### Example 3

#### **Erroneous Request**

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"",
    "message":"Cannot create mapping: volume protocol does not match
protocol
    of specified initiator group.",
    "extendedData":{}
}
```

# createTargetGroup

Creates a target group with the specified target group name in the resource group containing the named pool.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

moveTargetToTargetGroup, listFCTargetGroups, listISCSITargetGroups

#### **Parameters**

#### targetGroupName

Name of the new target group.

### poolName

Specifies the pool resource group to place the target group.

The poolName applies to iSCSI target groups only. For FC target groups, specify an empty string or null.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request failed.

#### **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified pool cannot be found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in either the targetGroupName or poolName.

# **Examples**

#### Example 1

#### Request (curl)

curl -X POST \

```
-H 'authorization: Basic AUTH TOKEN' \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '["aCoolTargetGroup", "pool63a"]' \
https://198.51.100.10/zebi/api/v2/createTargetGroup -k
```

### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating a successful request to create an iSCSI target group.

# Example 2

### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["aBad#TargetGroup", "pool63a"]' \
https://198.51.100.10/zebi/api/v2/createTargetGroup -k
```

# **Error Response**

The above request contains invalid characters. So the request returns HTTP status code 400 (bad request) and the following JSON exception:

```
"code": "EZEBI_INVALID_ARGUMENT",
"details": "createTargetGroup.arg0 value
'aBad#TargetGroup': Target group name cannot have
special characters like *,#,/,\\,!,@,~,(,),[,],{,},=,%...",
"message":
"Target group name cannot have special characters like
   *,#,/,\\,!,@,~,(,),[,],{,},=,%...",
"extendedData": {
   "EX_CAUSE_MESSAGE": null
}
```

# deleteInitiatorGroup

Deletes the initiator group specified from the IntelliFlash array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

listInitiatorGroups, deleteISCSIInitiator, createInitiatorGroup

#### **Parameters**

# initiatorGroupName

The name of the initiator group you want to delete.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

### **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified initiator group is not found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the initiator group is over 512 characters long

#### EZEBI\_GENERAL

This exception is thrown if the operation failed.

### **Examples**

# Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["myInitiatorGroupToDelete"]' \
  https://198.51.100.10/zebi/api/v2/deleteInitiatorGroup -k
```

# Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the initiator group 'myInitiatorGroupToDelete' was deleted.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["myGroupToDeleteDoesNotExist"]' \
https://198.51.100.10/zebi/api/v2/deleteInitiatorGroup -k
```

#### **Error Response**

In this example, the initiator group does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

# deleteISCSIInitiator

Deletes an ISCSI initiator with the specified initiator name.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

deletelscsilnitiator, listISCSIInitiatorGroups, listISCSITargets, createlscsilnitiator

#### **Parameters**

#### initiatorName

The name of the initiator you want to delete. For example, iqn.1991-05.com.microsoft:test.tegile.com. The 'initiatorName' is returned by listISCSIInitiators API.

#### Values returned

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.

• 2 indicates that the request failed.

### **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified iSCSI target does not exist.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- · If the default group is being modified

#### EZEBI\_GENERAL

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["iqn.1991-05.com.microsoft:test.tegile.com"]' \
https://198.51.100.10/zebi/api/v2/deleteISCSIInitiator -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "iqn.2012-02.com.tegile:test" was deleted.

# Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["iqn.1991-05.com.microsoft:doesnotexist.tegile.com"]' \
https://10.68.97.100/zebi/api/v2/deleteISCSIInitiator -k
```

#### **Error Response**

In this example, the initiator does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
"details":"ISCSI Initiator was not found.",
```

```
"message":"Failed to find iSCSI Initiator to delete
[iqn.1991-05.com.microsoft:doesnotexist.tegile.com].",
"extendedData":{"EX_CAUSE_MESSAGE":"ISCSI Initiator was not found.",
"EX_CAUSE_CODE_NAME":"EZEBI_RESOURCE_NOT_FOUND"}}
```

# deletelSCSITarget

Deletes an iSCSI target with the specified target name.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

createTargetGroup, moveTargetToTargetGroup, createISCSITargetForGroup, createISCSITarget, modifyISCSITargetAlias, listISCSITargets

#### **Parameters**

### targetName

The name of the target you want to delete. For example, iqn.2012-02.com.tegile:myTargetSuffix.

The targetName is returned by listISCSITargets API. Targets in default target group cannot be deleted.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified iSCSI target does not exist.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- · If the default group is being modified

# **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["iqn.2012-02.com.tegile:test"]' \
https://198.51.100.10/zebi/api/v2/deleteISCSITarget -k
```

### Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target "ign.2012-02.com.tegile:test" was deleted.

#### Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["iqn.2012-02.com.tegile:doesnotexist"]' \
https://10.68.97.100/zebi/api/v2/deleteISCSITarget -k
```

#### **Error Response**

In this example, the target does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":"",
"message":"Failed to find iSCSI
Target[iqn.2012-02.com.tegile:doesnotexist].
The target must exist for this operation to succeed.",
"extendedData":{}}
```

# deleteMappingFromVolume

Deletes the view (mapping) between the given volume, initiator group, and target group.



**Note:** The delete operation deletes the mapping. But you can add the original mapping again.

#### First Available Version

# API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

createMappingForVolume, initiatorGroupExists, listISCSIInitiatorGroups, listISCSITargetGroups, listVolumes.

#### **Parameters**

#### datasetPath

A string: the dataset path for the volume. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume\_V1\_0*.

# initiatorGroupName

A string. The name of an initiator group.

# targetGroupName

A string. The name of a target group.

#### Returns

Returns an integer, where

- 0 indicates that the request succeeded
- 1 indicates that the request was not attempted
- · 2 indicates that the request failed

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/TechPubsLUN", \
   "iscsi-initiatorGroup", \
   "iscsi-TargetGroup"]' \
https://198.51.100.10/zebi/api/v2/deleteMappingFromVolume -k
```

#### Response

The above request returns an integer 0, which indicates success.

# Example 2

# **Erroneous Request**

#### **Error Response**

```
HTTP Status Code: 500
{
   "message": "Unable to open pool1/Local/TechPubs2 : dataset does not exist",
   "extendedData": {
    "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
    "EX_CAUSE_MESSAGE": "Unable to open pool1/Local/TechPubs2 : dataset does not exist",
    "EX_CAUSE_CODE_NUMBER": "2009"
    },
    "details": "Unable to open pool1/Local/TechPubs2 : dataset does not exist",
   "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

# deleteTargetGroup

Deletes the target group specified from the IntelliFlash array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createTargetGroup, moveTargetToTargetGroup, createISCSITarget

# **Parameters**

#### targetGroupName

The name of the target group you want to delete.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified target group is not found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the target group is over 512 characters long
- If the target group is the default target group

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["myTargetGroupToDelete"]' \
  https://198.51.100.10/zebi/api/v2/deleteTargetGroup -k
```

#### Response:

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the target group 'myTargetGroupToDelete' was deleted.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["myTargetGroupToDeleteDoesNotExist"]' \
  https://198.51.100.10/zebi/api/v2/deleteTargetGroup -k
```

#### **Error Response**

In this example, the target group does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":"",
"message":"Failed to find target group
  [myTargetGroupToDeleteDoesNotExist].",
"extendedData":{}}
```

# getInitiatorGroup

Obtains the name of the initiator group to which the initiator belongs.

#### **First Available Version**

API v1.0, IntelliFlash 2.1.0.0

#### **Related APIs**

listInitiatorsInInitiatorGroup, createIscsiInitiator, addInitiatorToInitiatorGroup

#### **Parameters**

#### initiatorName

The name of the initiator. This is a string.

#### Returns

Returns a JSON string. The string has the name of the initiator group associated with the given initiator.

#### **Examples**

# Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iqn.2012-11.com.tegile.iscsi:api-initiator-1"]' \
  https://198.51.100.10/zebi/api/v2/getInitiatorGroup -k
```

# Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
"iqn.2012-11.com.tegile.iscsi:testinigroup-group"
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
```

```
-H Content-Type:application/json \
-d '["iqn.2012-11.com.tegile.iscsi:api-initiator-2"]' \
https://198.51.100.10/zebi/api/v2/getInitiatorGroup -k
```

#### **Error Response**

If the initiator name is not found, the request returns the HTTP status code 200 (OK) and no data.

# getProjectDefaultFcITView

Lists all of the existing default Fibre Channel views given a project's dataset path.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getVolumeITView, getProjectDefaultIscsiITView

#### **Parameters**

#### datasetPath

A string representing the project dataset path.

A project dataset must start with a letter followed by a series of alpha-numeric. It can contain only the following characters: 'A-Z', 'a-z', '0-9', '\_', '.', '-', ':', and '/'. The dataset, however, should not end with '/'.

#### **Returns**

A list of *ITView\_V2\_1* objects.

#### **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

If the specified project cannot be found.

# EZEBI\_INVALID\_ARGUMENT

If an invalid character is detected in the project dataset path.

#### **Examples**

#### Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/fctest"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultFcITView -k
```

# Response

The above request returns the HTTP status code 200 (OK) and a list of the ITView\_V2\_1 objects:

# Example 2

### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Local/nonExistentTestProject"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultFcITView -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
   "code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Cannot find the specified project 'pool63b/Local/
nonExistentTestProject'.",
   "extendedData": {}
}
```

#### Example 3

# **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Lo+cal/testProject"]' \
```

```
https://198.51.100.10/zebi/api/v2/getProjectDefaultFcITView -k
```

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "getProjectDefaultFcITView.arg0
  value 'pool63b/Lo+cal/testProject':
  Dataset path is not in the expected format that starts with a letter
  followed by alpha-numeric and may contain only the following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "message": "Dataset path is not in the expected format that starts
  with a letter followed by alpha-numeric and may contain only the
  following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "extendedData": {
    "EX_CAUSE_MESSAGE": null
  }
}
```

# getProjectDefaultIscsilTView

Returns all the existing default iSCSI views for the specified project dataset path.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getVolumeITView, getProjectDefaultFcITView

# **Parameters**

#### datasetPath

A string representing the project dataset path.

A project dataset must start with a letter followed by a series of alphanumeric. It can contain only the following characters: 'A-Z', 'a-z', '0-9', '\_', '.', '-', ':', and '/'. The dataset, however, should not end with '/'.

#### Returns

A list of ITView\_V2\_1 objects.

# Exceptions Thrown EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in the project dataset path.

#### **Examples**

# Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-test/Local/proj_snap"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultIscsiITView -k
```

### Response

The above request returns the HTTP status code 200 (OK) and a list of *ITView\_V2\_1* objects if found.

```
"hostGroupName": "All",
   "targetGroupName": "default-pool-test-iscsi-target-group",
   "lunNbr": -1,
   "readOnly": false
}
```

# Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Local/nonExistentTestProject"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultIscsiITView -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
  "code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Cannot find the specified project
  'pool63b/Local/nonExistentTestProject'.",
```

```
"extendedData": {}
}
```

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Lo+cal/testProject"]' \
https://198.51.100.10/zebi/api/v2/getProjectDefaultIscsiITView -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "getProjectDefaultIscsiITView.arg0
value 'pool63b/Lo+cal/testProject':
Dataset path is not in the expected format that starts with a letter
followed by alpha-numeric and may contain only the following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "message": "Dataset path is not in the expected format that starts
  with a letter followed by alpha-numeric and may contain only the
following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "extendedData": {
    "EX_CAUSE_MESSAGE": null
}
```

# getVolumeITView

Lists all the existing default iSCSI views for the specified volume dataset path.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getProjectDefaultIscsiITView, getProjectDefaultFcITView

# **Parameters**

datasetPath

A string representing the volume dataset path.

A volume dataset must start with a letter followed by a series of alpha-numeric characters. It can contain only the following characters: 'A-Z', 'a-z', '0-9', '\_', '.', '-', ':', and '/'. The dataset, however, should not end with '/'.

#### Returns

A list of ITView\_V2\_1 objects.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if an invalid character is detected in the volume dataset path.

### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified volume doesn't exist.

### **Examples**

### Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Local/testProject/LUN1"]' \
https://198.51.100.10/zebi/api/v2/getVolumeITView -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a list of ITView\_V2\_1 objects.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '["pool63b/Local/testProject/nonExistentLlun"]' \
https://198.51.100.10/zebi/api/v2/getVolumeITView -k
```

# **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
"details": "",
"message": "Cannot find the specified volume
'pool63b/Local/testProject/nonExistentLun'.",
"extendedData": {}
}
```

# Example 3

### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool63b/Lo+cal/testProject/nonExistentLun"]' \
https://198.51.100.10/zebi/api/v2/getVolumeITView -k
```

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_INVALID_ARGUMENT",
"details": "getVolumeITView.arg0 value
'pool63b/Lo+cal/testProject/nonExistentLun':
  Dataset path is not in the expected format that starts with a
  letter followed by alpha-numeric and may contain only the following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
"message": "Dataset path is not in the expected format that starts with
  a letter followed by alpha-numeric and may contain only the following:
  'A-Z', 'a-z', '0-9', '_', '.', '-', ':', and '/' but not end with '/'.",
  "extendedData": {
    "EX_CAUSE_MESSAGE": null
}
```

# initiatorGroupExists

Checks if an initiator group exists on the IntelliFlash Array.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### Related APIs

### listInitiatorsInInitiatorGroup, addInitiatorToInitiatorGroup

#### **Parameters**

### initiatorGroupName

A string: the name of the initiator group.

#### Returns

Returns a boolean value: true if the group exists, and false if it does not.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iqn.2012-11.com.tegile.iscsi:testinigroup-group"]' \
  https://198.51.100.10/zebi/api/v2/initiatorGroupExists -k
```

# Response

If the initiator group exists, the above request returns the HTTP status code 200 (OK) and the following data:

```
true
```

# Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json -d '[2012]' \
  https://198.51.100.10/zebi/api/v2/initiatorGroupExists -k
```

#### Response

If the initiator group does not exist, the above request returns the HTTP status code 200 (OK) and the following data:

```
false
```

# **listFCInitiators**

Lists the FC initiators on the IntelliFlash array.

### First Available Version

API v2.1, IntelliFlash 3.7.0.x

### Related APIs

createFCInitiator, listFCInitiatorGroups, listInitiatorsInInitiatorGroup, listTargetsInTargetGroup

### **Parameters**

### initiatorNamePattern

The name of the FC initiator you want to retrieve, or a regular expression pattern to retrieve more than one FC initiator name.

For example:

- "wwn.21000024FF279210" lists a specific initiator.
- ".\*" lists all Fibre Channel initiators.
- "wwn.123.\*" lists FC initiators starting with wwn.123.
- ".\*89112" lists initiators ending with 89112.

#### Returns

A JSON array of the *FCInitiator\_V2\_1* objects that contain the details of the ISCSI initiators that currently exist.

## **Exceptions Thrown**

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

# **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

# **Examples**

## Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth TOKEN" \
```

```
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://198.51.100.10/zebi/api/v2/listFCInitiators -k
```

## Response:

The above request returns the HTTP status code 200 (OK) and an array of JSON *FCInitiator\_V2\_1* objects for all the FC initiators found on the array. For example:

## Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["wwn.5001438001FCCCCC"]' \
https://198.51.100.10/zebi/api/v2/listFCInitiators -k
```

## **Error Response**

In this example, the initiator pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of JSON *FCInitiator\_V2\_1* objects.

## Example 3

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[""]' \
https://198.51.100.10/zebi/api/v2/listIFCInitiators -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following response:

```
{
```

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "listFCInitiators.arg0 value '':
   Pattern name is not valid, an invalid null, empty or blank pattern name
was detected.",
   "message": "Pattern name is not valid,
   an invalid null, empty or blank pattern name was detected.",
   "extendedData": {
        "EX_CAUSE_MESSAGE": null
   }
}
```

# **listFCInitiatorGroups**

Lists the names of all Fibre Channel initiator groups created on an IntelliFlash Array. This is an HTTP GET method.

### First Available Version

API v1.0, IntelliFlash 2.1.0.0

### **Related APIs**

listFCTargetGroups, listInitiatorsInInitiatorGroup, createMappingForVolume.

#### **Parameters**

None

### Returns

Returns an array of JSON strings. Each string in this list is a group name within the complete list of Fibre Channel Initiator group names found on the IntelliFlash Array.

### Example

## Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[]' https://198.51.100.10/zebi/api/v2/listFCInitiatorGroups -k
```

## Response

```
[
"fcinigroup",
"fcinigroup1"
]
```

# **listFCTargets**

Lists the Fibre Channel (FC) targets on the IntelliFlash array.

### First Available Version

API v2.1, IntelliFlash 3.7.0.x

### Related APIs

listTargetsInTargetGroup, createTargetGroup, moveTargetToTargetGroup

### **Parameters**

## targetNamePattern

The name of the FC target you want to retrieve, or a regular expression pattern to retrieve more than one FC target name.

For example:

- "wwn.1234567890123456" lists a specific FC target.
- ".\*" retrieves all the FC targets.
- "wwn.210.\*" retrieves targets starting with wwn.210.
- ".\*89112" retrieves targets ending with 89112.

#### Returns

A JSON array of the *FCTarget\_V2\_1* objects that contains the details of the available FC targets.

## **Exceptions Thrown**

## **EZEBI INVALID ARGUMENT**

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

## **EZEBI GENERAL**

This exception is thrown if the operation failed.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
```

```
-d '[".*"]' \
https://198.51.100.10/zebi/api/v2/listFCTargets -k
```

## Response

The above request returns the HTTP status code 200 (OK) and an array of JSON FCTarget\_V2\_1 objects for all the FC targets found on the array. For example:

```
"targetName": "wwn.21000042BB326F3C",
    "targetStatus": "online",
    "targetNode": "controller-a",
    "targetGroupName": "default-fc-target-group",
    "targetSpeed": "4Gb"
    "targetPortType": "HBA"
},

{
    "targetName": "wwn.31C5A0BE4F7D7463",
    "targetStatus": "offline",
    "targetNode": "controller-b",
    "targetGroupName": "",
    "targetSpeed": "not established"
    "targetPortType": "NPIV"
},
```

# Example 2

### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["wwn.5001438001FCCCCC"]' \
https://198.51.100.10/zebi/api/v2/listFCTargets -k
```

## **Error Response**

In this example, the target pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of the JSON *FCTarget\_V2\_1* objects.

### Example 3

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[""]' \
https://198.51.100.10/zebi/api/v2/listIFCTargets -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "listFCTargets.arg0 value '':
  Pattern name is not valid, an invalid null,
  empty or blank pattern name was detected.",
  "message": "Pattern name is not valid, an invalid null,
  empty or blank pattern name was detected.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
}
```

# **listFCTargetGroups**

Lists all Fibre Channel Target groups available on an IntelliFlash Array. This is an HTTP GET method.

#### First Available Version

API v1.0, IntelliFlash 2.1.1.1

### **Related APIs**

listFCInitiatorGroups, createMappingForVolume.

### **Parameters**

None

## Returns

Returns an array of JSON strings. Each string returned is the name of one Fibre Channel (FC) target group within the list of all FC target groups on the array. If the array does not have any FC card, an empty array is returned.

## **Example**

# Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  https://198.51.100.10/zebi/api/v2/listFCTargetGroups -k
```

### Response

```
[
"default-fc-target-group"
```

**listInitiatorGroups** 

]

Lists all initiator groups available on the IntelliFlash array.

### First Available Version

API v2.1, IntelliFlash 3.7.0.x

### **Related APIs**

deleteInitiatorGroup

## **Parameters**

None

### **Returns**

A list of *InitiatorGroup\_V2\_1* objects.

# **Example**

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[]' \
https://198.51.100.10/zebi/api/v2/listInitiatorGroups -k
```

## Response

The above request returns the HTTP status code 200 (OK) and a list of *InitiatorGroup\_V2\_1* objects if found.

# **listISCSIInitiatorGroups**

Lists all the iSCSI initiator groups available on an IntelliFlash Array. This is an HTTP GET method.

### First Available Version

API v1.0, IntelliFlash 2.1.0.0

## **Related APIs**

*listISCSITargetGroups*, *initiatorGroupExists*, *addInitiatorToInitiatorGroup*, *createMappingForVolume*.

### **Parameters**

None

#### Returns

Returns an array of JSON strings. Each string has the names of all iSCSI Initiator groups on the IntelliFlash Array.

## **Example**

# Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
https://198.51.100.10/zebi/api/v2/listISCSIInitiatorGroups \
-k
```

# Response

```
[
"inigrp1",
"testinigroup"
]
```

# **listISCSIInitiators**

Lists the iSCSI initiator details on the IntelliFlash array.

## First Available Version

API v2.1, IntelliFlash 3.7.0.x

## **Related APIs**

deletelscsilnitiator, listISCSIInitiatorGroups, listInitiatorsInIntiatorGroup, listISCSITargets, createlscsilnitiator

#### **Parameters**

### initiatorNamePattern

The name of the iSCSI initiator you want to retrieve, or a regular expression pattern to retrieve more than one iSCSI initiators.

For example, "iqn.1991-05.com.microsoft:myHost" lists a specific initiator, ".\*" retrieves all the initiators, "iqn.1991-05.com.microsoft:.\*" retrieves initiators with that prefix, ".\*myHost.\*" retrieves initiators that contain 'myHost' in the name.

### Returns

A JSON array of the *ISCSIInitiator\_V2\_1* objects that contain the details of the ISCSI initiators that currently exist.

## **Exceptions Thrown**

## **EZEBI INVALID ARGUMENT**

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://10.68.89.10/zebi/api/v2/listISCSIInitiators -k
```

## Response:

The above request returns the HTTP status code 200 (OK) and an array of JSON *ISCSIInitiator V2 1* objects for all the ISCSI initiators found on the array. For example:

```
[ {
```

# Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["iqn.2012-02.com.tegile:does-not-exist"]' \
  https://10.68.89.10/zebi/api/v2/listISCSIInitiators -k
```

## **Error Response**

In this example, the initiator pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of JSON *ISCSIInitiator\_V2\_1* objects.

### Example 3

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN"
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["*()(&^%$"]' \
https://10.68.89.10/zebi/api/v2/listISCSIInitiators -k
```

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "listISCSIInitiators.arg0 value '*()(&^%$':
  Invalid regular expression argument was detected.
  Please check the regular expression syntax.",
  "message": "Invalid regular expression argument was detected.
  Please check the regular expression syntax.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
}
```

}

# **listInitiatorsInInitiatorGroup**

Lists all initiators belonging to the specified initiator group.

## First Available Version

API v1.0, IntelliFlash 2.1.0.0

### Related APIs

initiatorGroupExists, getInitiatorGroup, listTargetsInTargetGroup.

#### **Parameters**

## initiator Group Name

A string: name of an iSCSI or a Fibre Channel initiator group.

### Returns

Returns an array of JSON strings. Each string returned has a name of an initiator in the specified initiator group.

# **Examples**

# **Example 1**

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["APIInitiatorGroup"]' \
https://198.51.100.10/zebi/api/v2/listInitiatorsInInitiatorGroup -k
```

# Response

```
[
"iqn.1998-01.com.vmware:esx99",
"iqn.1998-01.com.vmware:esx98"
]
```

## Example 2

### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iqn.2012-11.com.tegile.iscsi:testinigroup-grp"]' \
```

```
https://198.51.100.10/zebi/api/v2/listInitiatorsInInitiatorGroup -k
```

## **Error Response**

If the initiator group is not found, the above request returns the HTTP status code 200 (OK) and no data.

# **listISCSITargetGroups**

Lists all the iSCSI target groups available on an array. This is an HTTP GET method.

### First Available Version

API v1.0, IntelliFlash 2.1.0.0

### **Related APIs**

listISCSIInitiatorGroups, createMappingForVolume.

### **Parameters**

None

## Returns

Returns an array of JSON strings. Each string returned is a name of an iSCSI target group found within the list of all iSCSI target groups found on the array.

# Example

# Request (curl)

```
curl -X GET -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  https://198.51.100.10/zebi/api/v2/listISCSITargetGroups -k
```

## Response

```
[
"default-plaut-iscsi-target-group",
"tgtgrp1","testtargetgroup"
]
```

# **listISCSITargets**

Lists the iSCSI target details on the IntelliFlash array.

## First Available Version

API v2.1, IntelliFlash 3.7.0.x

## **Related APIs**

createTargetGroup, moveTargetToTargetGroup, createISCSITarget, createISCSITargetForGroup, deleteISCSITarget

#### **Parameters**

## targetNamePattern

The name of the target you want to retrieve, or a target name regular expression pattern to retrieve a list of targets.

For example, "iqn.2012-12.com.acme:atarget" lists a specific target, ".\*" retrieves all the iSCSI targets, "iqn.2012-12.com.tegile:.\*" retrieves targets with the prefix iqn.2012-12.com.tegile, ".\*pool-a.\*" retrieves targets with 'pool-a' in the name.

### Returns

A JSON array of ISCSITarget\_V2\_1 objects that contain the details of the ISCSI targets.

# **Exceptions Thrown**

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (bad format, blank, or an invalid regular expression).

# **EZEBI GENERAL**

This exception is thrown if the operation failed.

## **Examples**

### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://10.68.89.10/zebi/api/v2/listISCSITargets -k
```

## Response:

The above request returns the HTTP status code 200 (OK) and a JSON array of ISCSITarget\_V2\_1 objects for all the ISCSI targets found on the array. For example:

```
]
       "targetSuffixName": "test",
       "targetAlias": "iscsi-alias",
       "targetGroupName": "iscsi-tgroup",
       "targetAuthenticationMode": "none",
       "targetChapName": "",
        "targetChapSecret": null,
        "targetNetworkBinding": [
            "10.68.97.211:3260"
        "targetName": "iqn.2012-02.com.tegile:test"
   },
       "targetSuffixName": "pool-demo",
       "targetAlias": "pool-demo",
       "targetGroupName": "default-pool-demo-iscsi-target-group",
       "targetAuthenticationMode": "none",
        "targetChapName": "",
        "targetChapSecret": null,
        "targetNetworkBinding": [
            "10.68.97.212:3260"
        "targetName": "iqn.2012-02.com.tegile:pool-demo"
   } ]
```

## Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["iqn.2012-02.com.tegile:no-exist"]' \
  https://10.68.89.10/zebi/api/v2/listISCSITargets -k
```

# **Error Response**

In this example, the target pattern requested does not exist. So the request returns HTTP status code 200 (OK) and an empty array of JSON ISCSITarget\_V2\_1 objects for ISCSI targets found on the array.

# **listProjectDefaultIscsiMappings**

Lists all the existing default iSCSI mappings for the specified project path.

## First Available Version

API v2.4, IntelliFlash 3.10.x.x

## **Parameters**

### datasetPath

The project path. The format is <poolName>/Local/<projectName>. This operation is not allowed for Replica datasets.

### Returns

Returns the *Mapping\_V2\_4* object, which contains the project default iSCSI mappings.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the project is not found.

## **EZEBI\_GENERAL**

This exception is thrown when an invalid record is detected.

## **Examples**

# Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '"pool-a/Local/virtualServerProject"' \
  https://198.51.100.10/zebi/api/v2/listProjectDefaultIscsiMappings
```

## Response

# Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
```

```
-d '["pool-a/Local/virtualServerProjectX"]' \
https://198.51.100.10/zebi/api/v2/listProjectDefaultIscsiMappings
```

# **Error Response**

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
    "message": "Cannot find the specified project 'pool-a/Local/
virtualServerProjectX'.",
    "extendedData": {}
}
```

# **listProjectDefaultFCMappings**

Lists all the existing default FC mappings for the specified project path.

### First Available Version

API v2.4, IntelliFlash 3.10.x.x

### **Parameters**

### datasetPath

The project path. The format is <poolName>/Local/<projectName>.

This operation is not allowed for Replica datasets.

### Returns

Returns the *Mapping\_V2\_4* object, which contains the project default FC mappings.

## **Exceptions Thrown**

## EZEBI RESOURCE NOT FOUND

This exception is thrown if the project is not found.

## **EZEBI\_GENERAL**

This exception is thrown when an invalid record is detected.

## **Examples**

## Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '"pool-a/Local/virtualServerProject"' \
```

https://198.51.100.10/zebi/api/v2/listProjectDefaultFCMappings

## Response

# Example 2

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool-a/Local/projectX"]' \
  https://198.51.100.10/zebi/api/v2/listProjectDefaultFCMappings
```

## **Error Response**

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Cannot find the specified project 'pool-a/Local/projectX'.",
   "extendedData": {}
}
```

# **listTargetGroups**

Lists all target groups available on the IntelliFlash array.

If no targets are mapped to a target group, the intendedProtocol is shown as "Unknown."

## First Available Version

API v2.2, IntelliFlash 3.7.1.0

# **Related APIs**

createTargetGroup, listISCSITargetGroups, listFCTargetGroups

### **Parameters**

None

### **Returns**

A list of *TargetGroup\_V2\_2* objects.

# Example

# Request (curl)

```
curl -X POST \
-H 'authorization: Basic Auth_TOKEN' \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[]' \
https://198.51.100.10/zebi/api/v2/listTargetGroups -k
```

## Response

The above request returns the HTTP status code 200 (OK) and a list of *TargetGroup\_V2\_2* objects:

```
[
{
"targetGroupName": "default-fc-target-group",
"intendedProtocol": "FC"
},
{
"targetGroupName": "default-pool-a-iscsi-target-group",
"intendedProtocol": "iSCSI"
},
{
"targetGroupName": "default-pool-a-virtual-fc-target-group",
"intendedProtocol": "FC"
},
{
"targetGroupName": "iqn.2012-02.com.tegile:trayambah.a-pool-a-proj1-group",
"intendedProtocol": "Unknown"
}
]
```

# **listTargetsInTargetGroup**

Lists all targets associated with the target group.

# **First Available Version**

API v1.0, IntelliFlash 2.1.0.0

## **Related APIs**

listInitiatorsInInitiatorGroup, createMappingForVolume.

#### **Parameters**

## targetGroupName

A string: name of an iSCSI or a Fibre Channel target group.

### Returns

Returns an array of JSON strings. Each string returned is a name of a target in the specified target group.

# **Examples**

## Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["iscsitarget61"]' \
  https://198.51.100.10/zebi/api/v2/listTargetsInTargetGroup \
  -k
```

## Response

```
[
"iqn.2012-02.com.tegile:iscsitarget61",
"iqn.2012-02.com.tegile:test",
"iqn.2012-02.com.tegile:test1"
]
```

# Example 2

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["default-test1-iscsi-target-group"]' \
  https://198.51.100.10/zebi/api/v2/listTargetsInTargetGroup \
  -k
```

## **Error Response**

If the target group is not found, the above request returns the HTTP status code 200 (OK) and no data.

# **listVolumeMappings**

Lists all the mappings for a specified volume path.

## First Available Version

API v2.4, IntelliFlash 3.10.x.x

# **Parameters**

### datasetPath

The volume path. The format is <poolName>/Local//columeName>. This operation is not allowed for Replica datasets.

### Returns

Returns the *Mapping\_V2\_4* object, which contains the volume mapping information.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the volume is not found.

## **EZEBI\_GENERAL**

This exception is thrown when an invalid record is detected.

## **Examples**

# Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool-a/Local/virtualServerProject/volume1"]' \
  https://198.51.100.10/zebi/api/v2/listVolumeMappings
```

## Sample Response

```
[
    "initiatorGroupName": "All",
    "targetGroupName": "default-pool-a-iscsi-target-group",
    "lunNbr": 718,
    "readOnly": false
}
]
```

## Example 2

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth TOKEN" \
```

```
-H Content-Type:application/json \
-d '["pool-a/Local/virtualServerProject/volume1_not_found]"' \
https://198.51.100.10/zebi/api/v2/listVolumeMappings
```

## **Error Response**

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
    "message": "Cannot find the specified volume
    'pool-a/Local/virtualServerProject/volume1_not_found'.",
    "extendedData": {}
```

# modifyISCSITargetAlias

Modifies the iSCSI target alias (or user friendly name) of the target to newly specified name.

### First Available Version

API v2.1, IntelliFlash 3.7.0.x

### **Related APIs**

#### **Parameters**

## targetName

The name of the target you want to modify. For example, "iqn.2012-02.com.tegile:myTargetSuffix". The targetName is returned by listISCSITargets API. The targets in default target group cannot be modified.

# targetAlias

The new target alias name.

### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

## **Exceptions Thrown**

## EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified iSCSI target does not exist.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If the parameters are invalid (bad format or blank)
- If the default target is being modified

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["iqn.2012-02.com.tegile:test","rename-this-alias"]' \
https://10.68.89.10/zebi/api/v2/modifyISCSITargetAlias -k
```

# Response

The above request returns the HTTP status code 200 (OK) and an integer status of 0 to indicate that the user friendly alias of the target "iqn.2012-02.com.tegile:test" has been renamed to "rename-this-alias".

## Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["iqn.2012-02.com.tegile:does-not-exist","new-alias"]' \
  https://10.68.89.10/zebi/api/v2/modifyISCSITargetAlias -k
```

### **Error Response**

In this example, the target does not exist. So the request returns the HTTP status code 404 (not found) and the following response:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"Failed to find iSCSI Target[iqn.2012-02.com.tegile:does-not-exist].
The target must exist for this operation to succeed.",
  "message":"Failed to find iSCSI Target to modify
[iqn.2012-02.com.tegile:does-not-exist].",
  "extendedData":{"EX_CAUSE_MESSAGE":
  "Failed to find iSCSI Target[iqn.2012-02.com.tegile:does-not-exist]. T
  he target must exist for this operation to succeed.",
  "EX_CAUSE_CODE_NAME":"EZEBI_RESOURCE_NOT_FOUND"}}
```

# moveTargetToTargetGroup

Moves an iSCSI or Fibre Channel target to an existing target group.

### First Available Version

API v2.1, IntelliFlash 3.7.0.x

Updated in API v2.2.

### Related APIs

createTargetGroup, listFCTargetGroups, listISCSITargetGroups, listTargetGroups, createISCSITarget, listTargetsInTargetGroup

## **Parameters**

## targetName

Name of the target you want to move. This can be an iSCSI or Fibre Channel target name.

For iSCSI target name, it must be in the format, ign.yyyy-mm.

[reverse-domain-name]:unique-user-suffix. For example,

iqn.2012-02.com.tegile:myTargetPool1Suffix.

For Fibre Channel target, it must be in the format, wwn. [16-hexadecimalnumbers]. For example, wwn.21000024FF199A22.

## destinationTargetGroupName

Name of the destination target group. This must be an existing target group.

The protocol (iSCSI or FC) of the target being moved must match the protocol of the destination target group, or the target group must be empty. The iSCSI targets must match the resource group of the destination target resource group. The target cannot be moved to or from the default target group. If the target is already in a target group, the API removes the target from that target group.

### force

Boolean value indicating to bypass in-use target check.



Note: This parameter is included in API v2.2.

If the value is true, the API moves the target even if it is in an active project or LUN mapping. If the value is false, API throws an exception when the target is being used in a project or LUN mapping.

### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- · 2 indicates that the request failed.

## **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the target or target group does not exist.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If an invalid character is detected in either the targetName or the destinationTargetGroupName.
- If the target group has a different protocol or belongs to a different resource group than the target.
- If an attempt is made to move a target to or from the default target groups.

## **EZEBI GENERAL**

This exception is thrown if an internal error is detected.

# EZEBI\_RESOURCE\_BUSY

This exception is thrown if the target is already in a group that is in an active LUN or project mapping.

# **Examples**

## Exampe 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2012-02.com.tegile:testtarget1", "aCoolTargetGroup", false]' \
https://198.51.100.10/zebi/api/v2/moveTargetToTargetGroup -k
```

### Response

The above request returns the HTTP status code 200 (OK) and an integer 0 indicating a successful operation.

## Example 2

### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2012-02.com.tegile:testtarget1", "aNonExistentTargetGroup",
  false]' \
https://198.51.100.10/zebi/api/v2/moveTargetToTargetGroup -k
```

## **Erroneous Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
  "code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Cannot find target group: aNonExistentTargetGroup",
  "extendedData": {}
}
```

# Example 3

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic AUTH_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2012-02.com.tegile:testtarget1", "emptyTargetGroup", false]' \
https://198.51.100.10/zebi/api/v2/moveTargetToTargetGroup -k
```

### **Erroneous Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code": "EZEBI RESOURCE BUSY",
    "details": "Unable to remove the target safely
    from its current active Target Group. Please remove 'is-tgroup-active'
    from its existing project and LUN mapping(s) and try again.
   Can't remove the Target because the group [is-tgroup-active]
   which contains the target is being used by 1 lun(s)",
    "message": "Failed to move target [iqn.2012-02.com.tegile:target1]
    to the target group [emptyTargetGroup]",
    "extendedData":
       {"EX CAUSE MESSAGE": "Unable to remove the Target safely from its
       current active Target Group. Please remove 'is-tgroup-active'
       from its existing project and LUN mapping(s) and try again.
       Can't remove the Target because the group [is-tgroup-active]
       which contains the target is being used by 1 lun(s)",
       "EX CAUSE CODE NAME": "EZEBI RESOURCE BUSY"
}
```

# movelnitiatorToInitiatorGroup

Moves an iSCSI or Fibre Channel initiator to an existing initiator group.

### **First Available Version**

API v2.2, IntelliFlash 3.7.1.0

#### Related APIs

listISCSIIntiators, listInitiatorsInIntiatorGroup, listISCSIInitiatorGroups, listInitiatorGroups, createIscsiInitiator, addInitiatorToInitiatorGroup, createFCInitiator, createInitiatorGroup

### **Parameters**

#### initiatorName

Name of the initiator you want to move.

This can be an iSCSI or Fibre Channel initiator in any of the following formats:

- iqn.yyyy-mm.[reverse-domain-name]:unique-user-suffix
- eui.[16-hexadecimal-digits]
- wwn.[16-hexadecimal-numbers]

For example, iqn.2017-12.com.tegile.dev:test, eui.1543553633737279 or wwn.5001438002211672.

### destinationInitiatorGroupName

Name of the destination initiator group. This must be an existing initiator group.

The protocol (iSCSI or FC) of the initiator being moved must match the protocol of the destination initiator group, or the initiator group must be empty. If the initiator is already in an initiator group, the API removes the initiator from that initiator group.

### force

Boolean value indicating to bypass in-use initiator check.

If the value is true, the API moves the initiator even if it is in an active project or LUN mapping. If the value is false, API throws an exception when the initiator is being used in a project or LUN mapping.

### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.

• 2 indicates that the request failed.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the initiator or initiator group does not exist.

## **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If an invalid character is detected in either the initiatorName or the destinationInitiatorGroupName parameters.
- If the initiator group has a different protocol than the initiator.

## **EZEBI\_GENERAL**

This exception is thrown if an internal error is detected.

## **EZEBI RESOURCE BUSY**

This exception is thrown if the initiator is already in a group that is in an active LUN or project mapping.

## **Examples**

# Exampe 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2012-02.com.tegile:testInitiator1", "emptyInitiatorGroup",
  false]' \
https://198.51.100.10/zebi/api/v2/moveInitiatorToInitiatorGroup -k
```

## Response

The above request returns the HTTP status code 200 (OK) and an integer 0 indicating a successful operation.

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2012-02.com.tegile:testInitiator1", "NonExistentInitiatorGroup",
  false]' \
```

```
https://198.51.100.10/zebi/api/v2/moveInitiatorToInitiatorGroup -k
```

## **Erroneous Response**

The above request returns the HTTP status code 404 (not found) and the following message:

## Example 3

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic YOUR_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["iqn.2017-10.com.tegile.dev:initiator1", "empty-is-igroup", false]' \
https://YOUR_IP/zebi/api/v2/moveInitiatorToInitiatorGroup -k
```

# **Erroneous Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
   "code": "EZEBI RESOURCE BUSY",
   "details": "Unable to remove initiator safely
    from its current active initiator group. Please remove inuse-is-igroup
    from its existing project and LUN mapping(s) and try again.
    Can't remove the Initiator because the group [inuse-is-igroup]
    which contains the initiator is being used by 1 Lun(s)",
   "message": "Failed to move initiator
[iqn.2017-10.com.tegile.dev:initiator1]
   to the initiator group [empty-is-igroup]",
   "extendedData":
       "EX CAUSE MESSAGE":
       "Unable to remove initiator safely from
       its current active initiator group. Please remove
       inuse-is-igroup from its existing project and LUN mapping(s) and try
again.
       Can't remove the Initiator because the group [inuse-is-igroup]
       which contains the initiator is being used by 1 Lun(s)",
       "EX CAUSE CODE NAME": "EZEBI RESOURCE BUSY"
```

# **Chapter 6**

# **Snapshot Methods**

## Topics:

- cloneProjectSnapshot
- cloneReplicaProjectSnapshot
- cloneReplicaSubProjectSnapshot
- cloneShareSnapshot
- cloneVolumeSnapshot
- cloneVolumeSnapshot
- createProjectSnapshot
- createShareSnapshot
- createSnapshotSchedule
- createVolumeSnapshot
- deleteProjectSnapshot
- deleteSubshareSnapshot
- deleteShareSnapshot
- deleteSnapshotSchedule
- deleteSnapshotSchedule
- deleteSnapshotSchedules
- deleteSnapshotSchedules
- deleteVolumeSnapshot
- getProjectCloneStatus
- getProjectSnapshotCreationStatus
- getShareSnapshotCreationStatus
- getSnapshotSchedule
- getVolumeSnapshotCreationStatus
- inheritSnapshotSettingsFromProject
- isSnapshotSchedulesInheritedFromProject
- listDependenciesAndSnapshotCountOnDelete
- listDependenciesAndSnapshotCountOnRollback
- listSnapshots
- rollBackToProjectSnapshot
- rollBackToShareSnapshot
- rollBackToVolumeSnapshot

The following sections describe Snapshot methods, parameters, return types, and examples.

# cloneProjectSnapshot

Clones the specified project-level snapshot. This creates new datasets at the share and volume levels for all shares and volumes that have a snapshot with the specified name.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

### **Related APIs**

getProjectCloneStatus, createProjectSnapshot, deleteProjectSnapshot.

### **Parameters**

### snapshotPath

Path of the project-level snapshot that has to be cloned. The snapshot path has the format: PoolName/Local/ProjectName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

### cloneName

A string that is used to create names of the new datasets. The clone name is appended to the resultant share and volume names. The characters ,, /,\\,!,?, @, <, >, #, \$, ',%, ^,\*,(, ), ~,+, =, },|, :, {, [, ], ;, \', \", & are not allowed in clonename. The empty and space characters and the null values are not allowed in clonename.

# inheritProjectSettings

A boolean value that indicates whether the new dataset will inherit project settings.

## **Returns**

No Data.

## **Examples**

## Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@Manual-P-NewTPSS", \
  "mkclone", false]' \
  https://198.51.100.10/zebi/api/v2/cloneProjectSnapshot -k
```

### Response

The above request returns the HTTP status code 200 (OK) and no data.

### Example 2

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@NewTPSS", \
   "mkclone2", false]' \
  https://198.51.100.10/zebi/api/v2/cloneProjectSnapshot -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/sProj@NewTPSS: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

## Example 3

### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@Manual-P-NewTPSS", \
  "", false]' \
  https://198.51.100.10/zebi/api/v2/cloneProjectSnapshot -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
message: "Clone name is not valid."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

# cloneReplicaProjectSnapshot

Clones a replica project by its specified snapshot.

## First Available Version

API v2.1, IntelliFlash 3.7.0.x

## **Related APIs**

cloneReplicaSubProjectSnapshot

### **Parameters**

## snapshotPath

Snapshot path of the project to clone from. The path can be pool/container/project@snapshot or pool/project@snapshot.

### cloneName

The name of the clone project.

## readOnly

Read only clone.

# inheritSettings

Inherit project settings.

# keepLuGuid

Keep LUN GUID

### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED(0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specific project is not found.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the snapshot path is invalid.

# EZEBI\_RESOURCE\_INUSE

This exception is thrown if the target project name or target project mount point already exists.

# EZEBI\_REQUEST\_INTERRUPTED

This exception is thrown if the clone failed.

# **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

### Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKENY' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Replica/my-project@my-snapshot", "my-clone", false, true, true
]' https://198.51.100.10/zebi/api/v2/cloneReplicaProjectSnapshot -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 as an integer indicating a successful operation.

## Example 2

# **Erroneous Request (curl)**

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_GENERAL",
   "details": "Failed to clone from pool-a/Replica/my-project@non-exist-
snapshot to
        pool-a/Local/myclone.
        Result message: Failure: cannot open 'pool-a/Replica/my-project@non-
exist-snapshot':
        dataset does not exist",
        "message": "Failed to clone Project 'my-project' when cloning
        'pool-a/Replica/my-project@non-exist-snapshot'.",
        "extendedData": {"EX_CAUSE_MESSAGE": "Failed to clone from
        pool-a/Replica/my-project@non-exist-snapshot to pool-a/Local/myclone.
        Result message: Failure: cannot open 'pool-a/Replica/my-project@non-
exist-snapshot':
        dataset does not exist", "EX_CAUSE_CODE_NAME":"EZEBI_GENERAL"}
}
```

# cloneReplicaSubProjectSnapshot

Clones a replica sub-project by the specified snapshot.

### First Available Version

API v2.1, IntelliFlash 3.7.0.x

### Related APIs

cloneReplicaProjectSnapshot

### **Parameters**

# snapshotPath

Snapshot path of the project to clone from. The path could be pool/container/project@snapshot or pool/project@snapshot.

### cloneName

The name of the clone project.

### readOnly

Read-only clone.

# inheritSettings

Inherit project settings.

# keepLuGuid

Keep LUN GUID

### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED(0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specific project is not found.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the snapshot path is invalid.

# EZEBI\_RESOURCE\_INUSE

This exception is thrown if the target project name or target project mount point already exists.

# EZEBI\_REQUEST\_INTERRUPTED

This exception is thrown if the clone failed.

# **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

### **Examples**

### Example 1

### Request (curl)

# Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

# Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    "pool-a/Replica/my-project/my-dataset@non-exist-snapshot",
    "my-clone", false, true, true
    ]'
https://198.51.100.10/zebi/api/v2/cloneReplicaSubProjectSnapshot -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code": "EZEBI_REQUEST_INTERRUPTED",
   "details": "Failed to clone from pool-a/Replica/my-project/my-
dataset@non-exist-snapshot
   to pool-a/Local/myclone/my-dataset. Result message: Failure: cannot
   open
        'pool-a/Replica/my-project/my-dataset@non-exist-snapshot': dataset does
not exist",
        "message": "Failed to clone share 'pool-a/Replica/my-project/my-
dataset@non-exist-snapshot'.",
        "extendedData": {"EX CAUSE MESSAGE": "Failed to clone from
```

```
pool-a/Replica/my-project/my-dataset@non-exist-snapshot to pool-a/
Local/myclone/my-dataset.
   Result message: Failure: cannot open 'pool-a/Replica/my-project/my-
dataset@non-exist-snapshot':
   dataset does not exist", "EX_CAUSE_CODE_NAME":"EZEBI_GENERAL"}
}
```

# cloneShareSnapshot

Clones the specified share-level snapshot.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

### **Related APIs**

createShareSnapshot, deleteShareSnapshot.

#### **Parameters**

# snapshotPath

Path of the share-level snapshot that has to be cloned. The snapshot path has the format: PoolName/Local/ProjectName/ShareName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### cloneName

#### inheritShareSettings

A boolean value that indicates whether the new dataset will inherit the share settings.

#### Returns

No Data.

### **Examples**

### Example 1

### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
```

```
-H "Content-Type:application/json" \
-d '["pool1/Local/sProj/TP_Check@Manual-P-NewTPSS", \
"mk32", false]' \
https://198.51.100.10/zebi/api/v2/cloneShareSnapshot -k
```

### Response

The above request returns the HTTP status code 200 (OK) and no data.

# Example 2

### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj/TP_Check/Manual-P-NewTPSS", \
  "mk11", false]'
https://198.51.100.10/zebi/api/v2/cloneShareSnapshot -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

# cloneVolumeSnapshot

Clones the specified snapshot of a volume.

### **First Available Version**

API v2.0, IntelliFlash 3.5.0.0

### **Related APIs**

clone Volume Snapshot, create Volume Snapshot, delete Volume Snapshot.

#### **Parameters**

### snapshotPath

The snapshot path of the volume dataset to be cloned. The snapshot path has the format: PoolName/Local/ProjectName/VolumeName@SnapshotName. You can

get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### cloneName

A string that is used to create the name of the new dataset. The clone name is appended to the resultant volume name. The characters  $,,/,\setminus, !,?,@,<,>,\#,\$, ',%,^*,(,),~,+,=, \},|,:, \{, [, ], ;, \', \", & are not allowed in clonename. The empty and space characters and the null values are not allowed in clonename.$ 

#### inheritViewsFromVolume

A boolean value that indicates whether the new dataset will inherit views from the volume.

# inheritViewsFromProject

A boolean value that indicates whether the new dataset will inherit views from the project.

# protocol

A boolean value that indicates protocol to be set for the clone. Valid values are **true** for iSCSI and **false** for FC.

#### Returns

Returns the HTTP status code 200 (OK) and no data.

### **Examples**

### Example 1

### Request (curl)

#### Response

The above request returns the HTTP status code 200 (OK) and no data.

# Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth TOKEN" \
```

### **Error Response**

The above request returns the HTTP status code 400 (Bad Request) and the following response:

# cloneVolumeSnapshot

Clones the specified snapshot of a volume.

### **First Available Version**

API v1.2, IntelliFlash 2.1.2.1

### **Related APIs**

clone Volume Snapshot, create Volume Snapshot, delete Volume Snapshot.

#### **Parameters**

### snapshotPath

The snapshot path of the volume dataset to be cloned. The snapshot path has the format: PoolName/Local/ProjectName/VolumeName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

### cloneName

A string that is used to create the name of the new dataset. The clone name is appended to the resultant volume name. The characters  $,,/,\setminus, !,?,@,<,>,\#,\$, ',%,^*,(,),~,+,=, \},|,:, \{,[,],;,\',\'', & are not allowed in clonename. The empty and space characters and the null values are not allowed in clonename.$ 

### inheritViewsFromVolume

A boolean value that indicates whether the new dataset will inherit views from the volume.

# inheritViewsFromProject

A boolean value that indicates whether the new dataset will inherit views from the project.

#### Returns

No Data.

### **Examples**

### Example 1

### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/vProj/vol2\
@Manual-V-vProj_S3", "mkclone2", false, false]' \
  https://198.51.100.10/zebi/api/v2/cloneVolumeSnapshot -k
```

# Response

The above request returns the HTTP status code 200 (OK) and no data.

# Example 2

### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/vProj/vol2\
@vProj_S3","mkclone2", false]' \
https:7/198.51.100.10/zebi/api/v2/cloneVolumeSnapshot -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

# Example 3

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/vProj/vol2@vProj","mkclone2", false]' \
https://198.51.100.10/zebi/api/v2/cloneVolumeSnapshot -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unknown error cloning volume."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# createProjectSnapshot

Recursively creates snapshots of the specified project and the datasets within the project. The string "Manual-P-" is prefixed to the names of the snapshots created.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

getProjectSnapshotCreationStatus, listSnapshots, createVolumeSnapshot, createShareSnapshot, deleteProjectSnapshot.

#### **Parameters**

# project

A *Project\_V1\_2* object that specifies the project for which the snapshots are created.

### snapshotName

Name for the new snapshots that are created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%,  $^*$ ,(, ),  $^*$ ,+, =, },|, :, {, [, ], ;, \', \", & are not allowed in snapshotName. The empty and space characters and the null values are not allowed in snapshotName.

#### quiesce

A boolean that specifies whether the snapshot is quiesced or not.

#### Returns

No Data.

# **Examples**

# Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[{"name": "sProj", "local": true, \
   "poolName": "pool1"}, "NewTPSS9", false]' \
  https://198.51.100.10/zebi/api/v2/createProjectSnapshot -k
```

# Response

The above request returns the HTTP status code 200 (OK) and no data.

### Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[{"name": "sProj", "local": true, \
    "poolName": "NotExistantPool"}, "NewTPSS9", false]' \
    https://198.51.100.10/zebi/api/v2/createProjectSnapshot -k
```

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NotExistantPool/Local/sProj: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# createShareSnapshot

Recursively creates snapshot of the specified share. The string "Manual-S-" is prefixed to names of the snapshots created.

### **First Available Version**

API v1.2, IntelliFlash 2.1.2.1

### **Related APIs**

getShareSnapshotCreationStatus, listSnapshots, deleteShareSnapshot, cloneShareSnapshot.

#### **Parameters**

#### share

The Share\_V1\_0 object that specifies the share for which the snapshots are created.

# snapshotName

Name for the new snapshots that are created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%,  $^*$ ,',\, \, -,+, =, },|, :, {, [, ], ;, \', \", & are not allowed in snapshotName. The empty and space characters and the null values are not allowed in snapshotName.

# quiesce

A boolean value that specifies whether the snapshots are quiesced or not.

#### Returns

No Data.

# **Examples**

#### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
   -H "Content-Type:application/json" \
   -d '[{"poolName": "pool1", "projectName": "sProj", \
   "name": "TP_Check-newclone", "availableSize": 0, \
   "totalSize": 7794361020176, \
   "datasetPath": "pool1/Local/sProj/TP_Check-newclone", \
   "mountpoint": null, "local": true }, \
   "NewShareSnapShot", false]' \
   https://198.51.100.10/zebi/api/v2/createShareSnapshot -k
```

# Response

The above request returns the HTTP status code 200 (OK) and no data.

# Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[{"poolName": "pool1", "projectName": "sProj", \
"name": "TP_Check-newclone", "availableSize": 0, \
```

```
"totalSize": 7794361020176, \
"datasetPath": "pool1/Local/sProj/TP_Check-newclone", \
"mountpoint": null, "local": true }, \
"NewShareSnapShot", false]' \
https://198.51.100.10/zebi/api/v2/createShareSnapShot -k
```

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{ message: "Unable to open NotAPool/Local/sProj/TP_s1:
   dataset does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"}
```

# createSnapshotSchedule

Creates a snapshot schedule for the specified dataset.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

### **Related APIs**

getSnapshotSchedule, deleteSnapshotSchedules, deleteSnapshotSchedule

### **Parameters**

### schedule

Snapshot schedule definition.

This operation is not allowed for replica project datasets.

#### Returns

Returns a schedule ID.

### **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified dataset does not exist.

### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the schedule is invalid.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 {
     "scheduleId":0,
     "retentionPeriod": 6,
     "scheduleIntervalType": "Week",
     "repeatInterval": 1,
     "startDate": "2017-08-09",
     "startTime": "10:00",
     "endTime": "",
     "daysOfWeek": "2,3,4,5,6",
     "dayOfMonth": 0,
     "weekdayOfMonth": "",
     "datasetPath": "pool-a/Local/demoProject",
      "quiesce": "Off"
   ]'\
 https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

# Response:

The above request returns the HTTP status code 200 (OK) and a new schedule ID. For example, 44.

### Example 2

# **Erroneous Request (curl)**

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN \
 -H 'cache-control: no-cache' \
 -H 'content-type: application/json' \
 -d '[
 {
     "scheduleId":0,
     "retentionPeriod": 6,
     "scheduleIntervalType": "Hour",
     "repeatInterval": 1,
     "startDate": "2017-08-10",
     "startTime": "10:00",
     "endTime": "",
     "daysOfWeek": "",
     "dayOfMonth": 0,
     "weekdayOfMonth": "",
     "datasetPath": "pool-a/Local/demoProject",
      "quiesce": "Off"
```

```
}
]' \
https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

### Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"createSnapshotSchedule.arg0
   value
'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$SnapshotSchedule_V2_1@10ed209':
   Invalid end time. End time should be in 24HR HH:MM format.",
   "message":"Invalid end time. End time should be in 24HR HH:MM format.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}}
```

### Example 3

# **Erroneous Request**

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN \
 -H 'cache-control: no-cache' \
 -H 'content-type: application/json' \
 -d '[
 {
     "scheduleId":0,
     "retentionPeriod": 6,
     "scheduleIntervalType": "Monthly",
     "repeatInterval": 1,
     "startDate": "2017-08-10",
     "startTime": "10:00",
     "endTime": "20:00",
     "daysOfWeek": "",
     "dayOfMonth": 0,
     "weekdayOfMonth": "",
     "datasetPath": "pool-a/Local/demoProject",
     "quiesce": "Off"
   }
   ]'\
 https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"createSnapshotSchedule.arg0 value
```

```
'com.tegile.skywalk.api.v2.IPublicAPI_V2_1$SnapshotSchedule_V2_1@5b6c021e':
    Invalid schedule interval type.
    Possible values are: Minute, Hour, Day, Week, Month.",
    "message":"Invalid schedule interval type.
    Possible values are: Minute, Hour, Day, Week, Month.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# Example 4

# **Erroneous Request**

```
curl -X POST \
 -H 'authorization: Basic Auth TOKEN \
 -H 'cache-control: no-cache' √
 -H 'content-type: application/json' \
 -d '[
 {
     "scheduleId":0,
     "retentionPeriod": 6,
     "scheduleIntervalType": "Hour",
     "repeatInterval": 1,
     "startDate": "2017-08-10",
     "startTime": "10:00",
     "endTime": "20:00",
      "daysOfWeek": "",
      "dayOfMonth": 0,
      "weekdayOfMonth": "",
      "datasetPath": "pool-a/Local/UNKNOWNProject",
      "quiesce": "Off"
    ]'\
 https://198.51.100.10/zebi/api/v2/createSnapshotSchedule -k
```

# **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "message":"Dataset does not exist.",
   "extendedData":{}
}
```

# createVolumeSnapshot

Recursively creates snapshot of the specified volume. The string "Manual-V-" is prefixed to the names of the snapshots created.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

getProjectSnapshotCreationStatus, listSnapshots, createProjectSnapshot, createShareSnapshot, deleteProjectSnapshot.

#### **Parameters**

#### volume

A *Volume\_V1\_0* object for which snapshot needs to be created.

# snapshotName

Name for the new snapshots that are created. The characters ,, /,\\, !, ?, @, <, >, #, \$, ',%,  $^*$ ,(, ),  $^*$ ,+, =, },|, :, {, [, ], ;, \', \", & are not allowed in snapshotName. The empty and space characters and the null values are not allowed in snapshotName.

# quiesce

A boolean value that specifies whether the snapshots are quiesced or not.

#### Returns

No Data.

# **Examples**

# Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN"
  -H "Content-Type:application/json" \
  -d '[{"poolName": "pool1", \
    "projectName": "vProj", "name": "vol2", \
    "luId": "600144F0A6308900000053BD51250002", \
    "volSize": 161061273600, "blockSize": "32KB", \
    "thinProvision": false, "protocol": "FC", \
    "datasetPath": "pool1/Local/vProj/vol2", \
    "local": true}, "vProj_S3", false]' \
    https://198.51.100.10/zebi/api/v2/createVolumeSnapshot -k
```

# Response

The above request returns the HTTP status code 200 (OK) and no data.

#### Example 2

# **Erroneous Request**

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

# deleteProjectSnapshot

Deletes the specified project snapshot.



**Caution:** If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified project snapshot) are also deleted.



**Warning:** The delete operation is not reversable.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

# **Related APIs**

createProjectSnapshot.

#### **Parameters**

# projectSnapshotPath

Dataset path of the project snapshot. The dataset path of a project snapshot has the following format: PoolName/Local/ProjectName@SnapshotName. You can

get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### recursive

A boolean value that specifies whether dependents of the snapshot are deleted before the snapshot is deleted.

#### Returns

A JSON object of type *SnapShotDeletionStatus* that contains information about the snapshot deletion status.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@Manual-P-NewTPSS2", \
   true]' \
  https://198.51.100.10/zebi/api/v2/deleteProjectSnapshot -k
```

# Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
snapshotDeletionStatus: 0
  deletedList: [
     "pool1/Local/sProj@Manual-P-NewTPSS9"
     "pool1/Local/sProj/TP_Check@Manual-P-NewTPSS9"
     "pool1/Local/sProj/TP_Check-newclone@Manual-P-NewTPSS9"
     "pool1/Local/sProj/TP_NFS_Share@Manual-P-NewTPSS9"
     "pool1/Local/sProj/TP_NFS_Share-newclone@Manual-P-NewTPSS9"
     "pool1/Local/sProj/manus-pc-backup@Manual-P-NewTPSS9"
     "pool1/Local/sProj/newShareClone@Manual-P-NewTPSS9"
     "pool1/Local/sProj/newShareClone@Manual-P-NewTPSS9"
     ]
     failedToDeleteList: [ ]
}
```

### **Example 2**

### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj@NewTPSS2", true]' \
  https://198.51.100.10/zebi/api/v2/deleteProjectSnapshot -k
```

# **Error Response**

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
snapshotDeletionStatus: 2
deletedList: [ ]
failedToDeleteList: ["pool1/Local/sProj@NewTPSS2"]
}
```

# Example 3

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj/Manual-P-NewTPSS2", \
    true]' \
  https://198.51.100.10/zebi/api/v2/deleteProjectSnapshot -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NotAPool/Local/sProj: dataset does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# deleteSubshareSnapshot

Deletes the sub-share snapshots if any exist with Two-Factor Authentication (2FA) if it is enabled for the user specified in the header.



**Note:** 2FA is supported in API version V2.8 and above. So, you need to send a delete subshare snapshot request along with a valid verification code. For users with 2FA enabled on their user array login account, earlier (e.g. V1) versions of this API will not support 2FA.

#### First Available Version

API v2.8, IntelliFlash 3.11.5.0

### **Parameters**

#### datasetPath

This string identifies the share on the IntelliFlash array.

# snapshotName

Name of the snapshot.

### notify

Whether to send notification of snapshot before deleting it.

#### recursive

Whether to remove the dependents of the dataset before deleting it.

# jobID

Job ID of the snapshot.

#### verificationCode

Six digit 2FA verification code to validate the Two-Factor Authentication for an array user who has that feature enabled. Refer to *IntelliFlash User Guide* for more details on how to get this verification code (application code) from your mobile device authenticator.

#### Returns

If the request succeeds, the response is empty.

# **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error if:

- Invalid request, while 2FA is enabled for user. The API version V2.8 supports 2FA, so you need to send a request along with the valid verification code.
- Invalid verification code provided for user.

### EZEBI\_PERMISSION\_DENIED

This exception is thrown if access is denied.

### **Examples**

# Example 1

# Request (curl)

```
https://10.200.245.4/zebi/api/v2/deleteSubshareSnapshot -k
```

# Response

The API returns HTTPS status code 200 with an empty JSON response.

Empty response means that the Subshare snapshot is deleted.

# Example 2

# **Erroneous Request**

# **Error Response**

The API returns the EZEBI\_GENERAL error code and the following message when you send a request without valid verification code.

# deleteShareSnapshot

Deletes the specified share snapshot.



**Caution:** If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified share snapshot) are also deleted.



**Warning:** The delete operation is not reversable.

#### **First Available Version**

API v1.2, IntelliFlash 2.1.2.1

# **Related APIs**

createShareSnapshot.

#### **Parameters**

# shareSnapshotPath

Dataset path of the share snapshot. The dataset path of a share snapshot has the following format: PoolName/Local/ProjectName/ShareName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### recursive

A boolean value that specifies whether dependents of the snapshot are deleted before deleting the snapshot.

#### Returns

A JSON object of type SnapShotDeletionStatus.

### **Examples**

### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/proj1/share1@Manual-P-snap1", false]' \
  https://198.51.100.10/zebi/api/v2/deleteShareSnapshot -k
```

### Response

```
{
snapshotDeletionStatus: 0
deletedList: ["pool1/Local/proj1/share1@Manual-P-snap1"]
failedToDeleteList: [ ]
}
```

# Example 2

### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/proj1/NoSuchShare@Manual-P-snap1", false]' \
https://198.51.100.10/zebi/api/v2/deleteShareSnapshot -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
 snapshotDeletionStatus:
 deletedList: [ ]
 failedToDeleteList: [
   "pool1/Local/proj1/NoSuchShare@Manual-P-snap1"
```

# deleteSnapshotSchedule

Deletes the snapshot schedule for the dataset path specified by the snapshot ID with Two-Factor Authentication (2FA) if it is enabled for the user specified in the header.



Note: 2FA is supported in API version V2.8 and above. So, you need to send a delete snapshot schedule request along with a valid verification code. For users with 2FA enabled on their user array login account, earlier (e.g. V1) versions of this API will not support 2FA.

#### First Available Version

API v2.8, IntelliFlash 3.11.5.0

#### **Parameters**

### datasetPath

Full path of the dataset or project.

This operation is not allowed for replica project datasets.

# scheduleld

ID of the snapshot schedule.

### verificationCode

Six digit 2FA verification code to validate the Two-Factor Authentication for an array user who has that feature enabled. Refer to IntelliFlash User Guide for more details on how to get this verification code (application code) from your mobile device authenticator.

#### Returns

The API returns an integer '0' if the request succeeds.

# **Exceptions Thrown EZEBI GENERAL**

The API returns this error if:

- Invalid request, while 2FA is enabled for user. The API version V2.8 supports 2FA, so you need to send a request along with the valid verification code.
- Invalid verification code provided for user.

# EZEBI\_PERMISSION\_DENIED

This exception is thrown if access is denied.

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified dataset does not exist.

### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset or if the dataset path is invalid.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject", 67, "535195" ]' \
https://10.200.245.4/zebi/api/v2/deleteSnapshotSchedule -k
```

### Response

The API returns the HTTP status code 200 (OK) and '0' as integer indicating a successful operation.

```
0
```

### Example 2

# **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject", 67 ]' \
https://10.200.245.4/zebi/api/v2/deleteSnapshotSchedule -k
```

# **Error Response**

The API returns the EZEBI\_GENERAL error code and the following message when you send a request without valid verification code.

# deleteSnapshotSchedule

Deletes the snapshot schedule for the dataset path, specified by the snapshot ID.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

createSnapshotSchedule, getSnapshotSchedule, deleteSnapshotSchedules

#### **Parameters**

#### datasetPath

Full path of the dataset or project.

This operation is not allowed for replica project datasets.

#### scheduleld

ID of the snapshot schedule.

### Returns

COMMAND STATUS.COMMAND SUCCEED (0) on success.

# **Exceptions Thrown**

### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified dataset does not exist.

# **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to a replica dataset or if the dataset path is invalid.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", 41
   ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedule -k
```

# Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

### Example 2

# **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", 100
    ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedule -k
```

### **Error Response**

In this example, the request returns the HTTP status code 400 (bad request) and the following message:

```
{
   "code":"EZEBI_INVALID_ARGUMENT",
   "details":"",
   "message":"Specified schedule id does not exist.",
   "extendedData":{}
}
```

# Example 3

### **Erroneous Request**

```
curl -X POST \
```

```
-H 'authorization: Basic Auth_TOKEN \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Replica/replicaProject", 10
   ]' \
https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedule -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"deleteSnapshotSchedule.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
   "message":"Local dataset path expected. For example,
   valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# deleteSnapshotSchedules

Deletes all the snapshot schedules for the specified dataset with Two-Factor Authentication (2FA) if it is enabled for the user specified in the header.



**Note:** 2FA is supported in API version V2.8 and above. So, you need to send a delete snapshot schedules request along with a valid verification code. For users with 2FA enabled on their user array login account, earlier (e.g. V1) versions of this API will not support 2FA.

### First Available Version

API v2.8, IntelliFlash 3.11.5.0

### **Parameters**

#### datasetPath

Full path of the dataset or project.

This operation is not allowed for replica project datasets.

#### verificationCode

Six digit 2FA verification code to validate the Two-Factor Authentication for an array user who has that feature enabled. Refer to *IntelliFlash User Guide* for more

details on how to get this verification code (application code) from your mobile device authenticator.

#### Returns

The API returns an integer '0' if the request succeeds.

# **Exceptions Thrown**

# **EZEBI\_GENERAL**

The API returns this error if:

- Invalid request, while 2FA is enabled for user. The API version V2.8 supports 2FA, so you need to send a request along with the valid verification code.
- Invalid verification code provided for user.

# EZEBI\_PERMISSION\_DENIED

This exception is thrown if access is denied.

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified dataset does not exist.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset or if the dataset path is invalid.

# **Examples**

# Example 1

### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject", "528543" ]' \
https://10.200.245.4/zebi/api/v2/deleteSnapshotSchedules -k
```

### Response

The API returns the HTTP status code 200 (OK) and '0' as integer indicating a successful operation.

0

### Example 2

### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ "pool-1/Local/testProject" ]' \
https://10.200.245.4/zebi/api/v2/deleteSnapshotSchedules -k
```

### Response

The API returns the EZEBI\_GENERAL error code and the following message when you send a request without valid verification code.

# deleteSnapshotSchedules

Deletes all snapshot schedules for the specified dataset.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createSnapshotSchedule, getSnapshotSchedule, deleteSnapshotSchedule

# **Parameters**

# datasetPath

Full path of the dataset or project.

This operation is not allowed for replica project datasets.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified dataset does not exist.

### **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to a replica dataset or if the dataset path is invalid.

# **Examples**

# **Example 1**

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedules -k
```

# Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

# Example 2

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedules -k
```

### Response

In this example, the request returns the HTTP status code 404 (Not Found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "message":"Dataset does not exist.",
   "extendedData":{}
}
```

# Example 3

# Request

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/deleteSnapshotSchedules -k
```

### Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"deleteSnapshotSchedule.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
   "message":"Local dataset path expected. For example,
   valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# deleteVolumeSnapshot

Deletes the specified volume snapshot.



**Caution:** If the **recursive** parameter is set to **true**, all dependent objects (snapshots and clones of the specified volume snapshot) are also deleted.



**Warning:** The delete operation is not reversable.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

createVolumeSnapshot

#### **Parameters**

volumeSnapshotPath

Dataset path of the volume snapshot. The dataset path of a volume snapshot has the following format: PoolName/
Local/ProjectName/VolumeName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### recursive

A boolean value that specifies whether dependents of the snapshot are deleted before deleting the snapshot.

#### Returns

A JSON object of type SnapShotDeletionStatus.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[{"pool1/Local/proj1/vol1@Manual-V-snap1", false}]' \
  https://198.51.100.10/zebi/api/v2/deleteVolumeSnapshot -k
```

# Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
  snapshotDeletionStatus: 0
  deletedList: ["pool1/Local/proj1/vol1@Manual-V-snap1"]
  failedToDeleteList: [ ]
}
```

# Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[{"pool1/Local/NoProj/vol1@Manual-V-snap1", false}]' \
https://198.51.100.10/zebi/api/v2/deleteVolumeSnapshot -k
```

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/NoProj/vol1@Manual-V-snap1: dataset
does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# getProjectCloneStatus

Gets the status of a clone request on the specified project snapshot.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

cloneProjectSnapshot.

#### **Parameters**

# snapshotPath

Path to a project snapshot. The snapshot path has the format: PoolName/Local/ProjectName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### cloneName

Name of the new dataset.

### Returns

A JSON object of type *ProjectCloneProgressStatus\_v1\_2*.

### **Examples**

# Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/sProj@Manual-P-NewTPSS", \
"mkclone"]' \
https://198.51.100.10/zebi/api/v2/getProjectCloneStatus -k
```

### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
failedSubProjects: 1
  totalSubProjects: 6
  projectCloneState: 3
}
```

### Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1/Local/sProj@NewTPSS","mkclone"]' \
https://198.51.100.10/zebi/api/v2/getProjectCloneStatus -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/sProj@NewTPSS: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# ${\tt getProjectSnapshotCreationStatus}$

Gets the status of a project snapshot creation request.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

### **Related APIs**

createProjectSnapshot.

# **Parameters**

#### dataSetPath

Dataset path of the project. The dataset path has the format: PoolName/
Local/ProjectName. You can get the datasetPath from the listProjects API.
For more information, see *listProjects*.

### snapshotName

Name of the project snapshot for which status is required. You must use the name that you specified while invoking the *createProjectSnapshot* API, because this API prefixes the string "Manual-P-" to the name before getting the status.

#### Returns

A JSON object of type SnapshotProgressStatus.

# **Examples**

# Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj", "NewTPSS111"]' \
  https://198.51.100.10/zebi/api/v2/\
  getProjectSnapshotCreationStatus -k
```

# Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
     {
        snapshotProgressStatus: 0
     }
]
```

# Example 2

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NotAPool/Local/sProj", ""]' \
  https://198.51.100.10/zebi/api/v2/\
getProjectSnapshotCreationStatus -k
```

# **Error Response**

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
   snapshotProgressStatus: 2
}
```

### Example 3

### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NotAPool/Local/sProj", "NewTPSS111"]' \
  https://198.51.100.10/zebi/api/v2/\
getProjectSnapshotCreationStatus -k
```

### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open pool1/Local/sProj2: dataset does not exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# getShareSnapshotCreationStatus

Gets the status of a share snapshot creation request.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

### **Related APIs**

createShareSnapshot.

#### **Parameters**

#### dataSetPath

Dataset path of the share. The dataset path has the format: PoolName/Local/ProjectName/ShareName. You can get the datasetPath from the listShares API. For more information, see *listShares* and *Share\_V1\_0*.

# snapshotName

Name of the share snapshot for which status is required. You must use the name that you specified while invoking the *createShareSnapshot* API, because this API prefixes the string "Manual-S-" to the name before getting the status.

#### **Returns**

A JSON object of type SnapshotProgressStatus.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj/TP_Check-newclone", \
  "NewShareSnapShot"]' \
  https://198.51.100.10/zebi/api/v2/\
getShareSnapshotCreationStatus -k
```

# Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
     {
        snapshotProgressStatus: 0
    }
]
```

# **Example 2**

# **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/sProj/TP_Check", \
  "NotASnapShot"]' \
  https://198.51.100.10/zebi/api/v2/\
getShareSnapshotCreationStatus -k
```

### **Error Response**

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
    {
       snapshotProgressStatus: 2
    }
]
```

### Example 3

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NotAPool/Local/sProj/TP_Check", \
"NotASnapShot"]' \
```

```
https://198.51.100.10/zebi/api/v2/\
getShareSnapshotCreationStatus -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NotAPool/Local/sProj/TP_Check: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

# getSnapshotSchedule

Returns snapshot schedules for a dataset.

### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

createSnapshotSchedule, deleteSnapshotSchedules, deleteSnapshotSchedule

# **Parameters**

# datasetPath

Full path of the dataset.

This operation is not allowed for replica project datasets.

### **Returns**

Returns a list of snapshot schedules for the specified dataset path.

### **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified dataset does not exist.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

# **Examples**

### Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/getSnapshotSchedule -k
```

# Response:

The above request returns the HTTP status code 200 (OK) and a schedule object as shown below.

```
"scheduleId": 42,
    "retentionPeriod": 6,
    "scheduleIntervalType": "Week",
    "repeatInterval": 1,
    "startDate": "2017-08-09",
    "startTime": "00:00",
    "endTime": "00:00",
    "daysOfWeek": "2,3,4,5,6",
    "dayOfMonth": 0,
    "weekdayOfMonth": null,
    "datasetPath": "pool-a/Local/demoProject",
    "quiesce": "Off"
}
```

# Example 2

# **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/getSnapshotSchedule -k
```

#### Response

The above request returns the HTTP status code 404 (Not Found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"",
  "message":"Dataset does not exist.",
  "extendedData":{}
}
```

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Replica/replicaProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/getSnapshotSchedule -k
```

#### Response

In this example, the request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"getSnapshotSchedule.arg0 value
  'pool-a/Replica/replicaProject': Local dataset path expected.
  For example, valid formats are 'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "message":"Local dataset path expected.
  For example, valid formats are 'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

## getVolumeSnapshotCreationStatus

Gets the status of a volume snapshot creation request.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

createVolumeSnapshot.

#### **Parameters**

#### dataSetPath

Dataset path of the volume. The dataset path has the format: PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume V1 0*.

#### snapshotName

Name of the volume snapshot for which status is required. You must use the name that you specified while invoking the *createVolumeSnapshot* API, because this API prefixes the string "Manual-V-" to the name before getting the status.

#### Returns

A JSON object of type SnapshotProgressStatus.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool1/Local/vProj/vol2", \
  "vProj_S3"]' \
  https://198.51.100.10/zebi/api/v2/\
  getVolumeSnapshotCreationStatus -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data.

```
[
    {
      snapshotProgressStatus: 0
    }
]
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
```

```
-d '["pool1/Local/vProj/vol2", \
"vProj_S"]' \
https://198.51.100.10/zebi/api/v2/\
getVolumeSnapshotCreationStatus -k
```

#### **Error Response**

The above request returns the HTTP status code 200 (OK) and the following data:

```
{snapshotProgressStatus: 2}
```

#### Example 3

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["NoPool/Local/vProj/vol2", \
"vProj_S3"]' \
https://198.51.100.10/zebi/api/v2/\
getVolumeSnapshotCreationStatus -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
  message: "Unable to open NoPool/Local/vProj/vol2: dataset does not
  exist."
  extendedData: { }
  details: ""
  code: "EZEBI_GENERAL"
}
```

## inheritSnapshotSettingsFromProject

Inherits project snapshot settings for local dataset.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

isSnapshotSchedulesInheritedFromProject

# Parameters datasetPath

This string uniquely identifies the dataset on the IntelliFlash array.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED(0) on success.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This error is thrown if the specified dataset doesn't exist.

#### EZEBI\_INVALID\_ARGUMENT

This error is thrown if the path specified belongs to a replica dataset.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-dataset"
        ]'
https://198.51.100.10/zebi/api/v2/inheritSnapshotSettingsFromProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 as integer indicating a successful operation.

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-dataset"
]'
https://198.51.100.10/zebi/api/v2/inheritSnapshotSettingsFromProject -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
```

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Invalid dataset path. ",
  "extendedData": {}
}
```

## isSnapshotSchedulesInheritedFromProject

Checks whether the dataset is currently inheriting project snapshot settings.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

inheritSnapshotSettingsFromProject

#### **Parameters**

#### datasetPath

This string uniquely identifies the dataset on the IntelliFlash array.

#### **Returns**

TRUE, if the snapshot schedule is inherited from project

FALSE, if the snapshot schedule is overridden by the project rule

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This error is thrown if the specified dataset doesn't exist.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/my-dataset"
        ]'
https://198.51.100.10/zebi/api/v2/isSnapshotSchedulesInheritedFromProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a boolean (true or false).

#### Example 2

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-a/Local/my-project/non-exist-dataset"
        ]'
https://198.51.100.10/zebi/api/v2/isSnapshotSchedulesInheritedFromProject -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Invalid dataset path. ",
   "extendedData": {}
}
```

## listDependenciesAndSnapshotCountOnDelete

Lists all the dependents affected by the delete operation.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

listDependenciesAndSnapshotCountOnRollback

#### **Parameters**

#### path

The project path, share or volume path, or snapshot path to delete.

#### Returns

A Dependencies object.

#### **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This error is thrown if the specified project path, share or volume path, or snapshot path is not found.

#### **EZEBI INVALID ARGUMENT**

This error is thrown if the specified path is invalid.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-01/Local/genericProject"
        ]'
https://198.51.100.10/zebi/api/v2/listDependenciesAndSnapshotCountOnDelete -k
```

#### Response

```
"deleteableSnapCount": {
       "pool-01/Local/genericProject/clone2": 2,
       "pool-01/Local/genericProject/genericLun-genericProject-clone": 38,
       "pool-01/Local/genericProject/clone3": 1,
       "pool-01/Local/genericProject/genericLun": 4351,
       "pool-01/Local/genericProject/genericLun-genericProjectClone": 2,
       "pool-01/Local/genericProject": 3,
       "pool-01/Local/genericProject/
       genericLun-genericProject-clone-genericProjectClone": 1
   "deleteableClonesWithSnapCount": {
       "pool-01/Local/genericProject/clone2": 2,
       "pool-01/Local/genericProject/clone3": 1,
       "pool-01/Local/genericProject/genericLun-genericProjectClone": 2,
       "pool-01/Local/genericProject/genericLun": 4351,
       "pool-01/Local/genericProject/clone2-rollbackclone": 0,
       "pool-01/Local/genericProject/
       genericLun-genericProjectClone-rollbackclone": 0,
       "pool-01/Local/genericProject/
       genericLun-genericProject-clone-genericProjectClone": 1,
       "pool-01/Local/genericProject/clone3-rollbackclone": 0,
       "pool-01/Local/genericProject/genericLun-rollbackclone": 0,
       "pool-01/Local/genericProject/
        genericLun-genericProject-clone-genericProjectClone-rollbackclone":
0,
       "pool-01/Local/genericProject/
        genericLun-genericProject-clone-rollbackclone": 0
```

}

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
        "pool-01/Local/non-exist-project"
]'
https://198.51.100.10/zebi/api/v2/listDependenciesAndSnapshotCountOnDelete -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Dataset does not exist. ",
   "extendedData": {}
}
```

### **listDependenciesAndSnapshotCountOnRollback**

Lists all the dependents affected by the rollback operation.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

listDependenciesAndSnapshotCountOnDelete

#### **Parameters**

#### snapshotPath

The project path, share or volume path, or snapshot path to roll back to.

#### Returns

A Dependencies object.

# Exceptions Thrown EZEBI\_RESOURCE\_NOT\_FOUND

This error is thrown if the specified snapshot is not found.

#### **EZEBI\_INVALID\_ARGUMENT**

This error is thrown if the specified snapshot path is invalid.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ""pool-01/Local/genericProject@Manual-P-ss""
    ]'
https://198.51.100.10/zebi/api/v2/listDependenciesAndSnapshotCountOnRollback
  -k
```

#### Response

```
"deleteableSnapCount": {
    "pool-01/Local/genericProject/genericLun-genericProject-clone": 1,
    "pool-01/Local/genericProject/genericLun": 1,
    "pool-01/Local/genericProject": 1
},
    "deleteableClonesWithSnapCount": {
        "pool-01/Local/genericProject/genericLun-rollbackclone": 0,
        "pool-01/Local/genericProject/genericLun-genericProject-clone-rollbackclone": 0
}
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ""pool-01/Local/genericProject@non-exist-snapshot""
    ]'
https://198.51.100.10198.51.100.10/zebi/api/v2/
listDependenciesAndSnapshotCountOnRollback -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Dataset does not exist. ",
   "extendedData": {}
}
```

## **listSnapshots**

Lists names of snapshots (from the specified dataset) that match with the given regex pattern.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Parameters**

#### datasetPath

A string that contains the dataset path. The dataset path has the format:

PoolName/Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see *listVolumes* and *Volume\_V1\_0*.

#### snapshotPattern

A string that contains a regex pattern for matching snapshot names. Use an empty string to list all snapshots.

#### Returns

A JSON array of strings that contains names of snapshots (from the specified dataset) that match with the given regex pattern.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/TechPubsLUN",".*"]' \
  https://198.51.100.10/zebi/api/v2/listSnapshots -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
"Auto-LF-Day-011714-21:15",
   "Auto-LF-Day-011814-21:15",
   "Auto-LF-Day-011914-21:15",
   "Auto-LF-Week-011914-21:30",
   "Auto-LF-Day-012014-21:15",
   "Auto-LF-Day-012114-21:15"]
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '["pool1/Local/TechPubs/TechPubs",""]' \
  https://198.51.100.10/zebi/api/v2/listSnapshots -k
```

#### **Error Response**

```
HTTP Status Code: 500
{
   "message": "Unable to open pool1/Local/TechPubs/TechPubs : dataset does not exist",
   "extendedData": {
        "EX_CAUSE_CODE_NAME": "EZFS_NOENT",
        "EX_CAUSE_MESSAGE": "Unable to open pool1/Local/TechPubs/TechPubs : dataset does not exist",
        "EX_CAUSE_CODE_NUMBER": "2009"
        },
   "details": "Unable to open pool1/Local/TechPubs/TechPubs : dataset does not exist",
   "code": "EZEBI_RESOURCE_NOT_FOUND"
}
```

## rollBackToProjectSnapshot

Reverts the project state to the point-in-time state when the snapshot was taken.



**Caution:** If the **deleteDependents** parameter is set to **true**, all dependent objects (snapshots and clones of the specified project snapshot) are also deleted.

#### First Available Version

API v2.0, IntelliFlash 3.5.0.1

#### **Related APIs**

createProjectSnapshot, listSnapshots, deleteProjectSnapshot

#### **Parameters**

#### snapshotPath

Path of the project-level snapshot that has to be rolled back. The snapshot path has the format: PoolName/Local/ProjectName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### deleteDependents

A boolean value: indicates whether to delete the snapshot dependents.

If the deleteDependents is set to false and rollback is invoked, the method throws an error if there are existing dependents for the snapshot.

#### Returns

Returns an integer: the number 0 if the request succeeds.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test@Manual-P-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToProjectSnapshot -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data.

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test1@Manual-P-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToProjectSnapshot -k
```

#### **Error Response**

```
{"message":"Snapshot
    pool-2-mirror/Local/proj-test1@Manual-P-test does not
    exist.","extendedData":{},"details":"","code":"EZEBI_GENERAL"}
```

## rollBackToShareSnapshot

Reverts the share state to the point-in-time state when the snapshot was taken.



**Caution:** If the deleteDependents parameter is set to true, all dependent objects (snapshots and clones of the specified share snapshot) are also deleted.

#### First Available Version

API v2.0, IntelliFlash 3.5.0.1

#### Related APIs

createShareSnapshot, listSnapshots, deleteShareSnapshot

#### **Parameters**

#### snapshotPath

Path of the share-level snapshot that has to be rolled back. The snapshot path has the format: PoolName/Local/ProjectName/ShareName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### deleteDependents

A boolean value: indicates whether to delete the snapshot dependents.

If the deleteDependents is set to false and rollback is invoked, the method throws an error if there are existing dependents for the snapshot.

#### Returns

Returns an integer: the number 0 if the request succeeds.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test/share1@Manual-S-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToShareSnapshot -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data.

0

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
```

```
-H "Content-Type:application/json" \
-d '["pool-2-mirror/Local/proj-test/share_test@Manual-S-test",true]' \
https://198.51.100.10/zebi/api/v2/rollBackToShareSnapshot -k
```

#### **Error Response**

```
{"message":"Snapshot
pool-2-mirror/Local/proj-test/share_test@Manual-S-test does not
exist.","extendedData":{},"details":"","code":"EZEBI_GENERAL"}
```

## rollBackToVolumeSnapshot

Reverts the volume state to the point-in-time state when the snapshot was taken.



**Caution:** If the deleteDependents parameter is set to true, all dependent objects (snapshots and clones of the specified volume snapshot) are also deleted.

#### First Available Version

API v2.0, IntelliFlash 3.5.0.1

#### Related APIs

createVolumeSnapshot, listSnapshots, deleteVolumeSnapshot

#### **Parameters**

#### snapshotPath

Path of the volume-level snapshot that has to be rolled back. The snapshot path has the format: PoolName/Local/ProjectName/VolumeName@SnapshotName. You can get the snapshotPath from the listSnapshots API. For more information, see *listSnapshots*.

#### deleteDependents

A boolean value: indicates whether to delete the snapshot dependents.

If the deleteDependents is set to false and rollback is invoked, the method throws an error if there are existing dependents for the snapshot.

#### Returns

Returns an integer: the number 0 if the request succeeds.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test/lun_test@Manual-V-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToVolumeSnapshot -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data.

0

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-2-mirror/Local/proj-test/lun_test_dummy@Manual-V-test",true]' \
  https://198.51.100.10/zebi/api/v2/rollBackToVolumeSnapshot -k
```

#### **Error Response**

```
{"message":"Snapshot
    pool-2-mirror/Local/proj-test/lun_test_dummy@Manual-V-test does not
    exist.","extendedData":{},"details":"","code":"EZEBI_GENERAL"}
```

## Chapter 7

## **Synchronous Replication Methods**

#### **Topics:**

- configureSyncReplicationSetUp
- getSyncReplicationSetUp
- getSyncReplicationStatus
- getSyncReplicationPoolPairObjects
- setSyncReplicationPoolPairObjects
- startSyncReplication
- stopSyncReplication
- unconfigureSyncReplicationSetUp

The following sections describe synchronous replication methods, parameters, return types, and examples.

### configureSyncReplicationSetUp

Configures synchronous replication between two IntelliFlash arrays.

#### **First Available Version**

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

#### peerConfig

A *SyncReplicationPeerConfig\_V2\_5* object that contains the partner array details, such as the host name and the user credentials.

#### quorumConfig

A *SyncReplicationQuorumConfig\_V2\_5* object that contains the quorum witness server details, such as the host name and the passphrase.

The quorum witness server is deployed on a host that is network accessible by both the source array and the partner array. The quorum witness server helps decide which IntelliFlash array takes over during a disaster.

#### **Returns**

The API returns an integer '1' if the request succeeds.

## **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when the parameters are invalid.

#### **Examples**

#### Example 1

#### Request (curl)

https://10.200.245.4/zebi/api/v2/configureSyncReplicationSetUp -k



Note: The quorum witness hostname can be an IP address or FQDN (as in the above case, which is an EC2 instance).

#### Response

The API returns the HTTP status code 200 (OK) and the following code:

```
1
```

'1' implies that the request is successful and that the synchronous replication is set up between the two IntelliFlash arrays.

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization: Basic Auth TOKEN" \
-H "Content-Type:application/json" \
-d '[
       "peerHostName": "198.200.205.95",
       "peerUserName": "admin",
       "peerPassword": "wertyf"
       "quorumHostName": "ec9-24-88-03-839.uk-east-9.compute.amazonaws.com",
       "passPhrase": "gS9kle9KPDQS:pspyPBNRunlzo9tqwbk"
https://10.200.245.4/zebi/api/v2/configureSyncReplicationSetUp -k
```

#### **Error Response**

The API returns the following error response as the synchronous replication has already been configured.

```
"code": "EZEBI GENERAL",
"details": "The host '198.200.205.95' is already configured
           as synchronous replication peer.
           Please unconfigure to add new peer.",
"message": "The host '198.200.205.95' is already configured
           as synchronous replication peer.
           Please unconfigure to add new peer.",
"extendedData": {
    "EX CAUSE MESSAGE": "The host '10.204.215.75' is already configured
                        as synchronous replication peer.
                        Please unconfigure to add new peer."
```

#### Example 3

#### **Erroneous Request**

#### **Error Response**

The API returns the following error response as the peer hostname is empty.



**Note:** The API returns error messages whenever the fields are empty, contain invalid characters, or wrong passwords.

#### Example 4

#### **Erroneous Request**

#### **Error Response**

The API returns the following error response as it is the IP address of the Controller-B. Use the array management IP address.

## getSyncReplicationSetUp

Returns the synchronous replication setup details.

#### First Available Version

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

None

#### Returns

Returns an object, *SyncReplicationSetUp\_V2\_5* 

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[]' \
https://10.202.209.4/zebi/api/v2/getSyncReplicationSetUp -k
```

#### Response

```
[ {
```

```
"localHostName": "10.202.209.4",
    "peerHostName": "10.204.244.5",
    "quorumHostName": "10.204.212.24"
}
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[]' \
  https://10.202.209.4/zebi/api/v2/getSyncReplicationStatus -k
```

#### **Error Response**

The API returns the following error response since synchronous replication is not configured.

## getSyncReplicationStatus

Returns the synchronous replication status for the specified project.

#### First Available Version

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

#### dataset path

The dataset path of the project for which you want the synchronous replication status.

#### Returns

If the project path is valid, and synchronous replication is configured on the project, the API returns an object of type *SyncReplicationStatus\_V2\_5*.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-a/Local/syncrepproj"]' \
  https://10.202.209.4//zebi/api/v2/getSyncReplicationStatus -k
```

#### Response

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["pool-a/Local/notSyncRepproj"]' \
  https://10.202.209.4/zebi/api/v2/getSyncReplicationStatus -k
```

#### **Error Response**

The API returns the following error response as the project does not have synchronous replication configured.

## getSyncReplicationPoolPairObjects

Returns synchronous replication pool mapping details.

#### **First Available Version**

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

None

#### **Returns**

Returns an object of *SyncReplicationPoolPairConfig\_V2\_5*.

#### **Examples**

#### **Example 1**

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[]'
https://10.200.245.4/zebi/api/v2/getSyncReplicationPoolPairObjects -k
```

#### Response

```
"localPoolName": "pool-1",
    "peerPoolName": "pool-1",
    "localNetworkAddresses": ["192.100.54.3"],
    "peerNetworkAddresses": ["192.100.54.21"]
}
```

#### Example 2

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[]'
https://10.200.245.4/zebi/api/v2/getSyncReplicationPoolPairObjects -k
```

#### Response

The API returns the following error since synchronous replication is not configured.

## setSyncReplicationPoolPairObjects

Configures synchronous replication pool mapping details.

#### **First Available Version**

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

#### poolPairConfig

A *SyncReplicationPoolPairConfig\_V2\_5* object that consists of the pool details and the floating addresses of both the source and partner arrays.

#### Returns

Returns an integer '1' if the request succeeds.

#### **Examples**

#### **Example 1**

#### Request (curl)

#### Response

The API returns the HTTP status code 200 (OK) and the following code:

```
1
```

'1' implies that the request is successful and the synchronous replication is set up between the two IntelliFlash arrays.

#### Example 2

#### Request (curl)

#### Response

The API returns the following error as the pool is already configured.

#### Example 3

#### Request (curl)

#### Response

The API returns the following error when the pool name is wrong.

#### Example 4

#### Request (curl)

#### Response

The API returns the following error because of invalid network address.



Note: The API returns error responses when the fields are empty or invalid.

## startSyncReplication

Starts the synchronous replication on the specified project.

#### First Available Version

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

#### project path

The dataset path of the project for which you want to start synchronous replication.

#### Returns

Returns an integer '1' if the request succeeds.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization: Basic Auth TOKEN" \
-H "Content-Type:application/json" \
-d '["pool-a/Local/syncrepproj"]' \
https://10.202.209.4/zebi/api/v2/startSyncReplication -k
```

#### Response

The API returns the HTTP status code 200 (OK) and the following data:

```
1
```

'1' implies that the API was successful in starting synchronous replication on the project.

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth TOKEN" \
-H "Content-Type:application/json" \
-d '["pool-a/Local/non exist proj"]' \
https://10.202.209.4/zebi/api/v2/startSyncReplication -k
```

#### **Error Response**

The API returns the following error response as the project does not exist.

#### Example 3

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool-a/Local/syncRep_proj"]' \
https://10.202.209.4/zebi/api/v2/startSyncReplication -k
```

#### **Error Response**

The API returns the following error response as the project already has synchronous replication configured.

## stopSyncReplication

Stops the synchronous replication on the specified project.

#### First Available Version

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

#### project path

The dataset path of the project for which you want to stop synchronous replication.

#### Returns

Returns an integer '1' if the request succeeds.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool-a/Local/syncrepproj"]' \
https://10.202.209.4/zebi/api/v2/stopSyncReplication -k
```

#### Response

The API returns the HTTP status code 200 (OK) and the following data:

```
1
```

'1' implies that the API was successful in stopping synchronous replication on the project.

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool-a/Local/non_exist_proj"]' \
https://10.202.209.4//zebi/api/v2/stopSyncReplication -k
```

#### **Error Response**

The API returns the following error response as the project does not have synchronous replication configured.

```
as the project does not exist."
}
```

## unconfigureSyncReplicationSetUp

Removes the synchronous replication configuration set up between the two IntelliFlash arrays.

#### First Available Version

API v2.5, IntelliFlash 3.11.0.0

#### **Parameters**

None

#### Returns

Returns an integer '1' if the request succeeds.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[]' \
  https://10.200.245.4/zebi/api/v2/unconfigureSyncReplicationSetUp -k
```

#### Response

The API returns the HTTP status code 200 (OK) and the following code:

```
1
```

'1' implies that the request is successful and the synchronous replication configuration between the two IntelliFlash arrays is removed.

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[]' \
https://10.200.245.4/zebi/api/v2/unconfigureSyncReplicationSetUp -k
```

#### **Error Response**

The API returns the following error response since you must first delete all active synchronous replications before calling the API.

## Chapter 8

## **Asynchronous Replication Methods**

#### **Topics:**

- getReplicationConfigList
- getReplicationStatus
- startReplication

The following sections describe Asynchronous Replication methods, parameters, return types, and examples.

## getReplicationConfigList

Lists all the replication configurations for the specified project.

#### **First Available Version**

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

getReplicationStatus.

#### **Parameters**

#### poolName

Name of a pool.

#### projectName

Name of a project within the specified pool.

#### Returns

A JSON object of type ReplicationConfig\_V1\_2.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '["pool1","p1"]' \
https://198.51.100.10/zebi/api/v2/getReplicationConfigList -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
[
{
   id: 1
   projectName: "p1"
   projectGuid: "f5553354-2a91-4533-8e98-1cd52b1da3d6"
   poolName: "pool1"
   baseDataSetName: "pool1/Local/p1"
   scopeOption: 0
   remoteHost: "198.51.100.11"
   lastSnapshotName: ""
   remotePoolName: "san-pool"
   remoteProjectName: "p1"
```

```
remoteBaseDataSetName: "san-pool/Replica/p1"
}
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '["NotAPool","Failover_LUN"]' \
  https://198.51.100.10/zebi/api/v2/getReplicationConfigList -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

## getReplicationStatus

Lists the replication status for the specified replication configuration.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### **Related APIs**

getReplicationConfigList, startReplication.

#### **Parameters**

#### replicationConfig

An object of type *ReplicationConfig\_V1\_2* that contains the replication configuration. You can get the list of replication configurations from the <code>getReplicationConfigList</code> API. For more information, see <code>getReplicationConfigList</code>.

#### Returns

A JSON object of type ReplicationStatus\_v1\_2.

#### **Examples**

#### Example 1

#### Request (curl)

#### Response

The above request returns the HTTP status code 200 (OK) and the following data:

```
{
currentStatus: 1
startTimestamp: 1410165951163
completeTimestamp: 1410165951163
updateTimestamp: 1410165951120
dataSent: 0
sendSpeed: 0
taskSize: 0
completedTask: 0
}
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-d '[ \
{ \
"id": 1, \
"projectName": "p2", \
"projectGuid": "f5553354-2a91-4533-8e98-1cd52b1da3d6", \
"poolName": "pool-22", \
"baseDataSetName": "pool1/Local/p1", \
"scopeOption": 0, \
"remoteHost": "10.7.1.16", \
"lastSnapshotName": "", \
```

```
"remotePoolName": "san-pool", \
"remoteProjectName": "p1", \
"remoteBaseDataSetName": "san-pool/Replica/p1" \
} \
]' https://198.51.100.10/zebi/api/v2/getReplicationStatus -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
message: "Pool pool-22 is not mounted."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

## startReplication

Starts a replication for the specified replication configuration.

#### First Available Version

API v1.2, IntelliFlash 2.1.2.1

#### Related APIs

getReplicationConfigList, getReplicationStatus.

#### **Parameters**

#### replicationConfig

An object of type *ReplicationConfig\_V1\_2* that contains the replication configuration.

#### Returns

No Data.

#### **Examples**

#### Example 1

#### Request (curl)

```
"remoteBaseDataSetName": "testpool/Replica/replica_project",
    "poolName": "pool1",
    "lastSnapshotName": "",
    "scopeOption": 1,
    "remoteHost": "198.51.100.20",
    "baseDataSetName": "plaut-1/Local/rep_project",
    "id": 1,
    "projectGuid": "9d6b46ce-05dd-4df1-9ca9-4924bfeb9473",
    "remotePoolName": "testpool"
    }
    \
]'
https://198.51.100.10/zebi/api/v2/startReplication -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and no data.

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization: Basic Auth TOKEN" \
-H "Content-Type:application/json" \
-d '[
 {
 "projectName": "rep_project",
 "remoteProjectName": "replica project",
 "remoteBaseDataSetName": "testpool/Replica/replica project",
 "poolName": "pool-22",
 "lastSnapshotName": "",
 "scopeOption": 1,
 "remoteHost": "198.51.100.20",
 "baseDataSetName": "plaut-1/Local/rep project",
 "projectGuid": "9d6b46ce-05dd-4df1-9ca9-4924bfeb9473",
 "remotePoolName": "testpool"
 }
] '
https://198.51.100.10/zebi/api/v2/startReplication -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
message: "Pool pool-22 is not mounted."
extendedData: { }
details: ""
code: "EZEBI_GENERAL"
}
```

# **Chapter 9**

# **NAS Audit Methods**

# **Topics:**

- enableAudit
- disableAudit
- isAuditEnabled
- getAuditConfig
- setAuditConfig
- addAuditDatasetAccessProtocol
- removeAuditDatasetAccessProtocols
- addNetworkACLForAuditDataset
- setNetworkACLForAuditDataset
- removeNetworkACLForAuditDataset
- modifyAuditShareProperties
- bringUserAuditLogsUpToDate
- getNotificationById

The following sections describe NAS audit methods, parameters, return types, and examples.

#### enableAudit

Enables the NAS audit service and initializes the audit shares if required.

#### **First Available Version**

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

disableAudit, isAuditEnabled

#### **Parameters**

None

#### **Returns**

If the request succeeds, the response is empty.

### **Exceptions Thrown**

# **EZEBI\_GENERAL**

The API returns this error when the SMB Virtualization File Services mode is enabled instead of General File Services. The NAS audit feature is only supported when General Purpose SMB is enabled.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/enableAudit -k
```

#### Response

Empty response means that the NAS Audit feature is enabled on the IntelliFlash array.

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/enableAudit -k
```

#### **Error Response**

The API returns the following error response as the SMB Virtualization File Services mode is enabled instead of the General File Services.

## disableAudit

Disables the NAS audit service.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

enableAudit, isAuditEnabled

#### **Parameters**

None

#### Returns

If the request succeeds, the response is empty.

# **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when the IntelliFlash system is unable to flush logs.

#### **Example**

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/disableAudit -k
```

#### Response

Empty response means that the NAS Audit feature is disabled on the IntelliFlash array.

#### **isAuditEnabled**

Checks whether the NAS audit service is enabled.

#### **First Available Version**

API v2.6, IntelliFlash 3.11.4.0

#### Related APIs

disableAudit, enableAudit

#### **Parameters**

None

#### **Returns**

The API returns a JSON boolean status where:

- True indicates that the NAS audit service is enabled.
- False indicates that the NAS audit service is not enabled.

#### **Exceptions Thrown**

#### **EZEBI\_GENERAL**

The API returns this error when the system is not able to test whether the audit service is enabled.

#### **Example**

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/isAuditEnabled -k
```

#### Response

The API returns the following JSON boolean status:

```
True
```

'True' indicates that the NAS audit service is enabled on the IntelliFlash array.

# getAuditConfig

Retrieves the NAS audit configuration. This includes the following attributes:

- Whether NAS audit is enabled
- NAS audit share names
- NAS audit share quota size
- Retention period of NAS audit logs
- Protocols used to access logging shares
- User ACL list
- Network ACL list
- Errors or warnings detected while retrieving the audit configuration

#### **First Available Version**

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

setAuditConfig, enableAudit

#### **Parameters**

None

#### Returns

The API returns an *AuditConfig\_V2\_6* object which also includes *AuditDataset\_V2\_6* and *SharePermissions\_V2\_6* objects.

# **Exceptions Thrown**

#### **EZEBI\_GENERAL**

The API returns this error when the system is not able to read the configuration. This can be when the NAS Auditing is disabled, or the array SMB server mode is not set to General Purpose SMB.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/getAuditConfig -k
```

#### Response

The API returns a *AuditConfig\_V2\_6* object:

```
"auditDatasets": [
    "poolName": "pool-a",
    "name": "Audit",
    "auditQuota": 23,
    "quotaMetric": "GiB",
    "usedSpace": 59904,
"totalSpace": 35878411960320,
    "datasetPath": "pool-a/Audit", "mountPoint": "/pool-a/Audit",
    "cifsDisplayName": "pool-a_Audit_18211317$",
    "logRetentionDays": 10,
    "spaceCriticalThreshold": 60,
    "spaceWarningThreshold": 10,
    "spaceThresholdConfigured": true,
    "protocol": [
       "SMB"
    ]
],
"accessProtocols": [
 "SMB"
"userPermissions": [
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[]' \
https://10.200.245.4/zebi/api/v2/getAuditConfig -k
```

#### **Error Response**

The API returns the following error response when the NAS audit is disabled or when the SMB Virtualization File Services mode is enabled instead of the General File Services in the IntelliFlash system.

```
"code": "EZEBI_GENERAL",
"details": "",
"message": "Audit is not enabled. Please enable audit.",
"extendedData": {}
}
```

# setAuditConfig

Sets the NAS audit configuration settings for all the pools.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

getAuditConfig, isAuditEnabled

### **Parameters**

#### quotalnGiB

The maximum size that the audit log share can grow to. Measured in gibibyte (GiB). 1GiB is 2^30 bytes. The current minimum quota is 50GiB and the maximum is 5120GiB (5TiB).

#### **logRetentionDays**

The number of days to retain the audit logs. The current minimum is 30 days and the maximum is 3650 days (or 10 years).

#### **Returns**

If the request succeeds, the response is empty.

#### **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when the system is not able to set the configuration.

#### EZEBI\_RESOURCE\_NOT\_FOUND

The API returns this error when the pools being audited are not found.

#### EZEBI\_INVALID\_ARGUMENT

The API returns this error when there is an invalid log retention value or quota value.

#### **Examples**

### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[53, 31]' \
https://10.200.245.4/zebi/api/v2/setAuditConfig -k
```

# Response

Empty response means that the NAS audit log shares have the new quota and log retention settings.

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[5, 31]' \
https://10.200.245.4/zebi/api/v2/setAuditConfig -k
```

#### **Error Response**

The API returns the following error response when the quota value is less than the minimum range.

#### addAuditDatasetAccessProtocol

Adds an access protocol such as SMB or NFS to the NAS audit log shares.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

getAuditConfig, removeAuditDatatsetAccessProtocols

#### **Parameters**

#### newProtocol

This contains the protocol to use to access the logging shares (SMB/NFS).

#### Returns

If the request succeeds, the response is empty.

#### **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when the system is not able to access the logging share.

#### EZEBI\_RESOURCE\_NOT\_FOUND

The API returns this error when the audit pool is not found.

#### EZEBI\_INVALID\_ARGUMENT

The API returns this error when an invalid access protocol is detected.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[\"NFS\"]' \
https://10.200.245.4/zebi/api/v2/addAuditDatasetAccessProtocol -k
```

#### Response

Empty response means that the NFS access protocol is added to the NAS audit log shares on the IntelliFlash array.

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[\"NFS\"]' \
https://10.200.245.4/zebi/api/v2/addAuditDatasetAccessProtocol -k
```

#### **Error Response**

The API returns the ZebiException object with EZEBI\_RESOURCE\_NOT\_FOUND code and the following message when you try to add the SMB protocol when no pools exist or when the NAS audit feature is disabled.

```
{
```

#### Example 3

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[\"SMB\"]' \
https://10.200.245.4/zebi/api/v2/addAuditDatasetAccessProtocol -k
```

#### **Error Response**

The API returns the EZEBI\_RESOURCE\_EXISTS error code and the following message when you try to add an access protocol that already exists.

```
{
  "code": "EZEBI_RESOURCE_EXISTS",
  "details": "",
  "message": "Log share already has access protocol enabled : SMB",
  "extendedData": {}
}
```

#### removeAuditDatasetAccessProtocols

Clears all the access protocols such as SMB or NFS from the target audit log shares.

#### **First Available Version**

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

getAuditConfig, addAuditDatatsetAccessProtocol

#### **Parameters**

None

#### Returns

If the request succeeds, the response is empty.

## **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when not able to access the logging share.

#### EZEBI\_RESOURCE\_NOT\_FOUND

The API returns this error when the pools are not found to configure.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[]' \
https://10.200.245.4/zebi/api/v2/removeAuditDatasetAccessProtocols -k
```

#### Response

Empty response means that the access protocol is removed from the target NAS audit log share on the IntelliFlash array.

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/removeAuditDatasetAccessProtocol -k
```

#### **Error Response**

The API returns the EZEBI\_RESOURCE\_NOT\_FOUND error code and the following message when you try to remove access protocols when the NAS audit is disabled.

#### addNetworkACLForAuditDataset

Adds the Network ACLs on audit log shares with the specified access protocol enabled. Add Network ACLs will add to the existing Network ACLs.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

getAuditConfig, setNetworkACLForAuditDataset, removeNetworkACLForAuditDataset

#### **Parameters**

#### Protocol

The protocol used to access the log shares (SMB or NFS) and to configure.

#### networkACL

A NetworkACL\_V2\_1 object with the address and access to add. The accessMode field must be 'ro' to provide read-only access and added security of the audit logs. The rootAccessForNFS field must be set to 'false' for NFS for added security of the audit logs.

#### Returns

If the request succeeds, the response is empty.

#### **Exceptions Thrown**

#### **EZEBI\_GENERAL**

The API returns this error when the system is not able to access the logging share.

#### EZEBI RESOURCE NOT FOUND

The API returns this error when the network path for ACL is not found.

#### EZEBI\_INVALID\_ARGUMENT

The API returns this error when invalid access protocol or network ACL is detected.

#### **Examples**

### Example 1

#### Request (curl)

#### Response

```
Empty response means that the API has added the network ACLs to the audit log share (i.e.
```

FQDN eng.ac.com read-only) for the protocol specified (i.e. NFS) on the IntelliFlash array.

# Example 2

#### **Erroneous Request**

#### **Error Response**

The API returns the EZEBI\_INVALID\_ARGUMENT error code indicating that the host type is invalid (DNS-NAME instead of IP or FQDN).

#### Example 3

#### **Erroneous Request**

#### **Error Response**

The API returns the EZEBI\_RESOURCE\_EXISTS code indicating that the ACL already exists.

```
{
"code": "EZEBI_RESOURCE_EXIST",
"details": "",
"message": "ACL: 'engineering.acme.com' already exists",
"extendedData": {}
}
```

#### Example 4

#### **Erroneous Request**

#### **Error Response**

The API returns the EZEBI\_GENERAL error code indicating that the root NFS access is not supported.

#### setNetworkACLForAuditDataset

Sets the network ACLs on the NAS audit log shares with specified access protocol. Set Network ACLs will replace the network ACLs for the specified access protocol with the list of NetworkACL\_V2\_1 values passed.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### Related APIs

getAuditConfig, removeNetworkACLForAuditDataset, addNetworkACLForAuditDataset

#### **Parameters**

#### Protocol

The protocol used to access the logging shares (SMB/NFS) and configure.

#### networkACLs

A *NetworkACL\_V2\_1* object with the address and access to set. The accessMode field must be 'ro' to provide read-only access and added security of the audit logs. The rootAccessForNFS field must be set to 'false' for NFS for added security of the audit logs.

#### **Returns**

If the request succeeds, the response is empty.

#### **Exceptions Thrown**

#### **EZEBI\_GENERAL**

The API returns this error when the system is not able to access the audit log share.

#### EZEBI\_RESOURCE\_NOT\_FOUND

The API returns this error when the network path for ACL is not found.

#### EZEBI\_INVALID\_ARGUMENT

The API returns this error when an invalid access protocol or network ACL is detected.

#### **Examples**

### Example 1

#### Request (curl)

#### Response

Empty response means that the NAS audit network ACLs is set on the audit log share (i.e. with IP address 10.1.2.3, and read-only access) for the protocol specified (i.e. SMB) on the IntelliFlash array.

# Example 2

#### **Erroneous Request**

#### **Error Response**

The API returns the EZEBI\_INVALID\_ARGUMENT error code indicating the invalid access type. It must be specified 'ro' in network ACL.

#### Example 3

#### **Erroneous Request**

#### **Error Response**

The API returns the EZEBI\_RESOURCE\_NOT\_FOUND exception code indicating that you need to enable audit, create a pool, or bring a pool online.

# removeNetworkACLForAuditDataset

Removes the network ACL on the NAS audit log shares with specified access protocol.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

getAuditConfig, setNetworkACLForAuditDataset, addNetworkACLForAuditDataset

#### **Parameters**

#### **Protocol**

The protocol used to access the audit log share (SMB or NFS) and to configure.

#### networkACLs

A NetworkACL\_V2\_1 object with the address and access to remove.

#### Returns

If the request succeeds, the response is empty.

## **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when the system is not able to access the logging share.

#### EZEBI\_RESOURCE\_NOT\_FOUND

The API returns this error when the network path for ACL is not found.

#### EZEBI\_INVALID\_ARGUMENT

The API returns this error when invalid access protocol or network ACL is detected.

#### **Examples**

#### Example 1

#### Request (curl)

#### Response

Empty response means that the API removed the network ACLs on the audit log share (with IP address 10.250.97.34 and read-only access) for the protocol specified (i.e. SMB) on the IntelliFlash array.

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ \"SMB\", {\"hostType\": \"FQDN\", \"host\":\"doesnotexist.acme.com\", \"accessMode\":\"ro\", \"rootAccessForNFS\":false} ]' \
https://10.200.245.4/zebi/api/v2/removeNetworkACLForAuditDataset -k
```

#### **Error Response**

The API returns the EZEBI\_RESOURCE\_NOT\_FOUND error code indicating that the ACL requested does not exist.

# modifyAuditShareProperties

Modifies the critical and warning space usage thresholds of an audit log share for a given pool.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

getAuditConfig

# **Parameters**

#### poolName

The pool where you want to modify the dataset properties of the audit share.

#### datasetProperties

A *Share\_V2\_4* object. You can currently modify critical and warning space usage thresholds.

#### Returns

The API returns an integer '0' if the request succeeds.

#### **Exceptions Thrown**

#### **EZEBI GENERAL**

The API returns this error when not able to set the configuration.

#### **EZEBI RESOURCE NOT FOUND**

The API returns this error when the pools being audited are not found.

#### EZEBI\_INVALID\_ARGUMENT

The API returns this error when invalid properties are detected.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ \"pool-a\", {\"spaceUsageCriticalThreshold\": 80,
        \"spaceUsageWarningThreshold\": 10} ]' \
https://10.200.245.4/zebi/api/v2/modifyAuditShareProperties -k
```

#### Response

The API returns the following code:

```
0
```

'0' means that the request is successful with the space threshold adjusted.

#### Example 2

#### **Erroneous Request**

#### **Error Response**

The API returns the EZEBI\_RESOURCE\_NOT\_FOUND error code indicating that the pool requested does not exist.

# bringUserAuditLogsUpToDate

A manual request to start the binary to XML log conversion of the latest auditing entries tracked.

When all the audit log entries are first recorded they are in binary form on the audit logging share.

By default, the XML files are generated from the existing binary logs once in every 24 hours.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### Related APIs

getAuditConfig, isAuditEnabled, getNotificationById

#### **Parameters**

None

#### Returns

The API returns a String that contains the event of the asynchronous job id started. This identifier can be passed to the REST API *getNotificationById* to watch the progress of the background update.

#### **Exceptions Thrown**

#### **EZEBI\_GENERAL**

The API returns this error when the system is not able to read the configuration.

#### **EZEBI RESOURCE NOT FOUND**

The API returns this error when the pools being audited are not available.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/bringUserAuditLogsUpToDate -k
```

#### Response

The API returns the following notification id of the job that is used to update the logs.

```
"c274ce50-86c9-4a7f-a915-7d69fdfd056d"
```

#### Example 2

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ ]' \
https://10.200.245.4/zebi/api/v2/bringUserAuditLogsUpToDate -k
```

#### Response

The API returns the EZEBI\_GENERAL exception code which indicates that the wrong SMB mode is active.

# getNotificationByld

Gets a specific notification by the event id. This can be used to query a specific event job status. The notification event id is returned by APIs like *bringUserAuditLogsUpToDate*, or *listNotifications*.

#### First Available Version

API v2.6, IntelliFlash 3.11.4.0

#### **Related APIs**

bringUserAuditLogsUpToDate, isAuditEnabled

#### **Parameters**

#### String - notificationId

This contains the notification identifier to query a specific event job status.

#### **Returns**

The API returns a *Notification\_V2\_6* object.

# Exceptions Thrown

**EZEBI\_GENERAL** 

The API returns this error when there is a timeout waiting for the audit logs event.

#### EZEBI\_RESOURCE\_NOT\_FOUND

The API returns this error when the event identifier requested is not found.

#### **EZEBI INVALID ARGUMENT**

The API returns this error when the parameter is invalid (e.g. id is empty or null).

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ \"c274ce50-86c9-4a7f-a915-7d69fdfd056d\" ]' \
https://10.200.245.4/zebi/api/v2/getNotificationById -k
```

#### Response

The API returns a Notification V2 6 object and NasAuditState object.

```
{
 "timestamp": 1656290545087,
 "eventCode": "NAL8501I85012",
 "priority": "Low",
 "description": "NAS Audit log update done for 'ns6200-10910-mgt'.",
 "errorMessage": "Updated audit logs",
 "details": {
    "Array Name": "ns6200-10910-mqt",
   "Error Message": "Updated audit logs",
   "Pool Names": "[pool-a, pool-b]",
    "User": "SYSTEM",
    "NAS Audit State": "Update user audit logs completed.
                        [UPDATE AUDITLOGS DONE]",
   "Local Host Name": "ns6200-\overline{1}09-a",
   "Local Host status": "Update audit logs completed on ns6200-109-a",
   "Peer Host Name": "ns6200-110-b",
   "Peer Host status": "Update audit logs completed on ns6200-110-b"
 "state": "Completed",
 "subState": "UPDATE AUDITLOGS DONE"
```

#### Example 2

#### Request (curl)

```
curl -X POST \
```

```
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ \"c274ce50-86c9-4a7f-a915-7d69fdfd056d\" ]' \
https://10.200.245.4/zebi/api/v2/getNotificationById -k
```

#### Response

The API returns the *Notification\_V2\_6* object with state "Initial" and substate equal to "UPDATE\_AUDITLOGS\_NOTSTARTED". Refer to *NasAuditState* object for all the possible states.

```
"timestamp": 1656346482121,
"eventCode": "NAL8501185010",
"priority": "Low",
"description": "NAS Audit logs are being prepared for
                update on 'ns6200-10910-mgt'.",
"errorMessage": "Log update not started.",
"details": {
  "Peer Host Name": "ns6200-110-b",
  "Array Name": "ns6200-10910-mgt",
  "Error Message": "Log update not started.",
  "Pool Names": "[pool-a, pool-b]",
  "User": "admin",
  "NAS Audit State": "Update audit logs has not started yet.
                      [UPDATE AUDITLOGS NOTSTARTED] ",
  "Local Host Name": "ns6200-109-a"
},
"state": "Initial",
"subState": "UPDATE AUDITLOGS NOTSTARTED"
```

#### Example 3

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ \"c274ce50-86c9-4a7f-a915-11112341234\" ]' \
https://10.200.245.4/zebi/api/v2/getNotificationById -k
```

#### **Error Response**

The API returns the EZEBI\_RESOURCE\_NOT\_FOUND exception code on requesting an identifier that does not exist.

```
{
  "code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "Failed to find notification identifier",
  "message": "Failed to retrieve notification by id:
```

```
c274ce50-86c9-4a7f-a915-11112341234",
"extendedData": {
    "EX_CAUSE_MESSAGE": "Failed to find notification identifier",
    "EX_CAUSE_CODE_NAME": "EZEBI_RESOURCE_NOT_FOUND"
}
```

#### **Example 4**

#### **Erroneous Request**

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "cache-control: no-cache" \
-H "Content-Type:application/json" \
-d '[ \"\" ]' \
https://10.200.245.4/zebi/api/v2/getNotificationById -k
```

#### **Error Response**

The API returns the EZEBI\_INVALID\_ARGUMENT exception code on requesting an identifier with an incorrect format which is emtpy.

# Chapter 10

# **System Methods**

#### **Topics:**

- getDiskCount
- getDisks
- getDisksByChassis
- getSMBConfig
- getUpgradeHistory
- identifyDisk
- identifyDiskByIndex
- isProjectExposedOverSMB
- isShareExposedOverSMB
- listSystemProperties
- setSMBConfig
- setSMBSharingOnProject
- setSMBSharingOnShare
- fetchContollerStatus

The following sections describe the System methods, parameters, return types, and examples.

# getDiskCount

Returns the count of disks connected to the IntelliFlash array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getDisksByChassis, getDisks, identifyDisk, identifyDiskByIndex

#### **Parameters**

None

#### **Returns**

An integer count of all the disks found on the IntelliFlash array.

# **Exceptions Thrown**

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" -d '[]' \
-H 'cache-control: no-cache' \
https://10.68.97.100/zebi/api/v2/getDiskCount -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a numeric count of the disks detected. For example, 27.

# getDisks

Returns the details of disks connected to the IntelliFlash Array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

getDisksByChassis, getDiskCount, identifyDisk, identifyDiskByIndex

#### **Parameters**

#### diskAliasPattern

The disk name (alias) to obtain detailed JSON disk objects. This is the same disk alias name shown in IntelliFlash Web UI for each disk.

This parameter can be a complete specific disk name or partial regular expression to match several disks.

For example, you can specify <code>c2t5000C50040CF0707d0</code> to obtain a specific disk, ".\*" to obtain all disks, <code>c2t5000C50040.\*</code> to obtain disks starting with <code>c2t5000C50040.\*</code> to obtain disks starting with <code>c2t5000C50040CF07.\*</code> to obtain disks that contain 5000C50040CF07 in the name.

#### **Returns**

A JSON array of the *Disk\_V2\_1* objects that contain the details of the requested disks.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameters are invalid (for example, bad format or blank), or if the requested wild card regular expression is in an invalid format.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[".*"]' \
https://198.51.100.10/zebi/api/v2/getDisks -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a list of all disks on that IntelliFlash array. For example:

```
[
   {
       "diskChassisIndex": 0,
       "diskBayIndex": 0,
       "diskChassisName": "[N5800]",
       "diskSize": "1.46 TiB",
       "poolName": "r2",
       "diskType": "NVMe",
       "diskAlias": "c4t000CCA0B01331E00d0",
       "deviceId": "w000cca0b01331e00"
       "diskChassisIndex": 0,
       "diskBayIndex": 1,
       "diskChassisName": "[N5800]",
       "diskSize": "1.46 TiB",
       "poolName": "",
       "diskType": "NVMe",
       "diskAlias": "c5t000CCA0B01335F00d0",
       "deviceId": "w000cca0b01335f00"
       "diskChassisIndex": 0,
       "diskBayIndex": 2,
       "diskChassisName": "[N5800]",
       "diskSize": "1.46 TiB",
       "poolName": "",
       "diskType": "NVMe",
       "diskAlias": "c6t000CCA0B01335A80d0",
       "deviceId": "w000cca0b01335a80"
]
```

```
{
      "diskChassisIndex": 0,
       "diskBayIndex": 1,
       "diskChassisName": "IS1201-0022[HA2100]",
       "diskSize": "1.82 TB",
       "poolName": "ZebiSystem",
       "diskType": "HDD",
      "diskAlias": "c2t5000C50040CF04E7d0",
      "deviceId": "n5000c50040cf04e7"
       "diskChassisIndex": 0,
       "diskBayIndex": 2,
       "diskChassisName": "IS1201-0022[HA2100]",
       "diskSize": "1.82 TB",
       "poolName": "vmpool",
       "diskType": "HDD",
       "diskAlias": "c2t5000C50040CF0707d0",
```

```
"deviceId": "n5000c50040cf0707"
},
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["c2t5000C50040CF0F97d0" ]' \
https://198.51.100.10/zebi/api/v2/getDisks -k
```

#### **Error Response**

In this example, the disk "c2t5000C50040CF0F97d0" does not exist. So the request returns the HTTP status code 200 (OK) and the following response of an empty array of disks:

## Example 3

#### Request (curl)

```
curl -X POST -H "Authorization:Basic AUTH_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '[""]' \
  https://198.51.100.10/zebi/api/v2/getDisks -k
```

#### Response

In this example, the disk name was empty. So the request returns the HTTP status code 400 (Bad Request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "getDisks.arg0 value '': Pattern name is not valid,
  an invalid null, empty or blank pattern name was detected.",
  "message": "Pattern name is not valid, an invalid null,
  empty or blank pattern name was detected.",
  "extendedData":
  {
    "EX_CAUSE_MESSAGE": null
  }
}
```

# getDisksByChassis

Lists the disks connected to the specified disk chassis. The chassis are the IntelliFlash array itself (head) and the JBOD chassis connected to the array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

getDisks, getDiskCount, identifyDisk, identifyDiskByIndex

#### **Parameters**

#### chassisIndex

The chassis index on the array that contains the disk bays to enumerate. Often the array has only one disk chassis, which would be chassis index 0. But an array with 3 chassis might typically have chassis index 0, 1, and 2, depending how they are connected. The chassis index can be retrieved by calling getDisks API first in the returned JSON array of *Disk\_V2\_1* objects.

#### Returns

A JSON array of the *Disk\_V2\_1* objects that contain the details of the disks found on the requested chassis.

#### **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the requested disk chassis index does not exist, or is out of range.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[0]' \
```

```
https://198.51.100.10/zebi/api/v2/getDisksByChassis -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and a JSON array of *Disk\_V2\_1* objects on the first chassis. For example:

```
{
        "diskChassisIndex": 0,
        "diskBayIndex": 1,
        "diskChassisName": "IS1201-0022[HA2100]",
        "diskSize": "1.82 TB",
        "poolName": "ZebiSystem",
        "diskType": "HDD",
        "diskAlias": "c2t5000C50040CF04E7d0",
        "deviceId": "n5000c50040cf04e7"
},
        "diskChassisIndex": 0,
        "diskBayIndex": 2,
        "diskChassisName": "IS1201-0022[HA2100]",
        "diskSize": "1.82 TB",
        "poolName": "vmpool",
        "diskType": "HDD",
        "diskAlias": "c2t5000C50040CF0707d0",
        "deviceId": "n5000c50040cf0707"
}
```

# Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[500]' \
https://198.51.100.10/zebi/api/v2/getDisksByChassis -k
```

#### **Error Response**

As the chassis index 500 does not exist, the request returns the HTTP status code 404 (not found) and the following exception:

```
{
"code":"EZEBI_RESOURCE_NOT_FOUND",
"details":"",
"message":"Failed to find the disk chassis requested (500).",
"extendedData":{}
}
```

# getSMBConfig

Lists all the SMB configuration values.

#### First Available Version

API v2.2, IntelliFlash 3.7.1.0

#### **Related APIs**

setSMBConfig

#### **Parameters**

None

#### **Returns**

Returns an SMBConfig\_V2\_2 object that contains the SMB configuration details.

## **Exceptions Thrown**

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### **Example 1**

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
https://198.51.100.10/zebi/api/v2/getSMBConfig -k
```

#### Response

```
"pdc": null,
    "subsharesFeatureEnabled": false,
    "smbProtocolMode": "SMB3",
    "restrictAnonymous": true,
    "restrictGuest": true
}
```

# getUpgradeHistory

Returns the history of IntelliFlash software installs and upgrades for the array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

*listSystemProperties* 

#### **Parameters**

N/A

#### **Returns**

A JSON array of the *ArrayUpgrade\_V2\_1* objects that contain the upgrades done on the IntelliFlash array.

# **Exceptions Thrown**

# EZEBI\_GENERAL

This exception is thrown if the operation failed.

#### **Examples**

#### **Example 1**

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
   -d '[]' \
  https://198.51.100.10/zebi/api/v2/getUpgradeHistory -k
```

#### Response:

The above request returns the HTTP status code 200 (OK) and the *ArrayUpgrade\_V2\_1* objects that contain the upgrades done on the IntelliFlash array. For example:

```
"version": "3.7.0.0.170619",
    "timeInstalledOnNodeA": "Tue Jun 20 14:19:39 PDT 2017",
    "timeInstalledOnNodeB": "Tue Jun 20 13:43:25 PDT 2017"
```

```
},
{
    "version": "3.7.0.0.170425",
    "timeInstalledOnNodeA": "Wed Apr 26 22:07:17 PDT 2017",
    "timeInstalledOnNodeB": "Wed Apr 26 21:31:57 PDT 2017"
},
{
    "version": "3.6.0.0.170215",
    "timeInstalledOnNodeA": "Wed Feb 15 13:09:10 PST 2017",
    "timeInstalledOnNodeB": "Wed Feb 15 16:28:39 PST 2017"
}
```

## identifyDisk

Identifies a disk connected to the IntelliFlash array by flashing the bay light of the disk.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

getDisks, getDisksByChassis, getDiskCount, identifyDiskByIndex

## **Parameters**

#### diskAlias

The name of the disk, which you want to identify. For example, c2t5000C50040CF0707d0 could be the disk name.

This is the same disk alias name shown in the IntelliFlash Web UI for each disk.

#### Returns

Returns an integer status, where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified disk was not found.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **EZEBI INVALID ARGUMENT**

This exception is thrown if the disk name parameter is invalid (bad format or blank).

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["c2t5000C500409B5663d0",true]' \
https://198.51.100.10/zebi/api/v2/identifyDisk -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0. This indicates that the blinking disk light for the disk "c2t5000C500409B5663d0" was successfully turned on.

#### Example 2

## **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["XYZ",true]' \
https://198.51.100.10/zebi/api/v2/identifyDisk -k
```

#### **Error Response**

In this example, 'xyz' is not a valid disk name. The disk name must be in the c[Controller#]t[Target#]d[Disk#] format. For example, c2t5000C50040CF0F97d0. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "identifyDisk.arg0 value 'xyz': The disk alias name should
be
  in the format of c[Controller#]t[Target#]d[Disk#] (e.g.
c2t5000C50040CF0F97d0).
  Disk names can be found in the UI disk hardware page, or by enumerating
all disks.",
  "message": "The disk alias name should in
  the format of c[Controller#]t[Target#]d[Disk#] (e.g.
c2t5000C50040CF0F97d0).
  Disk names can be found in the UI disk hardware page, or by enumerating
all disks.",
```

# identifyDiskByIndex

Identifies a disk connected to the IntelliFlash Web UI array by flashing the bay light of the disk.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

getDisks, getDisksByChassis, getDiskCount, identifyDisk

#### **Parameters**

## diskBayIndex

The disk bay index number of the disk you want to identify.

This is the same number displayed in the IntelliFlash Web UI and same disk index number returned in the disk objects by the getDisks API

#### chassisIndex

The disk chassis index number of the disk you want to identify. This is the same disk chassis index number returned in the disk objects by the getDisks API and displayed in the IntelliFlash Web UI.

#### blinkLED

JSON boolean to indicate whether to turn on or turn off the disk bay light used to identify the disk.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# Exceptions Thrown EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the chassis index or disk bay index is out of range or not found.

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

## Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[2,2,true]' \
https://198.51.100.10/zebi/api/v2/identifyDiskByIndex -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0. This indicates that the blinking disk light was successfully turned on.

## Example 2

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -d '[2,10000,true]' \
  https://198.51.100.10/zebi/api/v2/identifyDiskByIndex -k
```

#### **Error Response**

In this example, 10000 is not a valid existing disk chassis index. So the request returns the HTTP status code 400 (bad request) and the following response:

```
{
   "code": "EZEBI_RESOURCE_NOT_FOUND",
   "details": "",
   "message": "Invalid chassis index of 10000 was passed,
    the maximum chassis index currently available is 2.",
   "extendedData": {}
}
```

# **isProjectExposedOverSMB**

Returns whether the SMB protocol is enabled for a project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, getSMBNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

#### Returns

Returns True or False based on whether SMB protocol is enabled.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to replica dataset.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

## Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
```

```
]' \
https://198.51.100.10/zebi/api/v2/isProjectExposedOverSMB -k
```

## Response:

The above request returns the HTTP status code 200 (OK) and returns a true or false value indicating whether SMB is enabled over the specified project.

#### Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/isProjectExposedOverSMB -k
```

## **Error Response:**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

# **isShareExposedOverSMB**

Returns whether the SMB protocol is enabled for a share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, getSMBNetworkACLsOnShare

#### **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local//Local/

#### Returns

Returns True or False based on whether the SMB protocol is enabled.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

## **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to replica dataset.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
"pool-a/Local/Project/demoShare"
   ]' \
  https://198.51.100.10/zebi/api/v2/isShareExposedOverSMB -k
```

## Response

The above request returns the HTTP status code 200 (OK) and returns the following response:

```
true
```

#### Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \[
  \]
```

```
-H 'content-type: application/json' \
-d '[
"pool-a/Local/Project/UNKNOWNShare"
]' \
https://198.51.100.10/zebi/api/v2/isShareExposedOverSMB -k
```

## **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following response:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

# **IistSystemProperties**

Lists values of the requested system properties for an IntelliFlash Array.

#### First Available Version

API v1.0, IntelliFlash 2.1.0.0

#### **Parameters**

#### properties

An array of strings where each string is a predefined string literal indicating a system property. The enumeration *ZEBI\_SYSTEM\_PROPERTY* defines the string literals that can be requested.

#### Returns

A JSON array of strings that contains values of the requested system properties. The error "EZEBI\_RESOURCE\_NOT\_FOUND" is returned if a requested system property is not available.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[["ZEBI_API_VERSION","ZEBI_APPLIANCE_VERSION"]]' \
```

```
https://198.51.100.10/zebi/api/v2/listSystemProperties -k
```

#### Response

```
[ "1.2", "A1"]
```

## Example 2

## **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H Content-Type:application/json \
-d '[["ZEBI_API_VERSIONS"]]' \
https://198.51.100.10/zebi/api/v2/listSystemProperties -k
```

#### **Error Response**

```
[
"EZEBI_RESOURCE_NOT_FOUND"
]
```

## setSMBConfig

Defines SMB configuration values.

#### **First Available Version**

API v2.2, IntelliFlash 3.7.1.0

#### Related APIs

getSMBConfig

#### **Parameters**

An SMBConfig\_V2\_2 object that contains the SMB configuration details.

#### **Returns**

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- · 2 indicates that the request failed.

## **Exceptions Thrown**

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[{"smbProtocolMode": "SMB3"}]' \
  https://198.51.100.10/zebi/api/v2/setSMBConfig -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

## Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {"smbProtocolMode": "SMB3"}
    ]' \
  https://198.51.100.10/zebi/api/v2/setSMBConfig -k
```

## **Error Response**

```
"code": "EZEBI_GENERAL",
   "details": "",
   "message": "The following shares have NFS and SMB enabled and hence
cannot move to SMB3:
   pool-a/Local/proj1/share-1, pool-a/Local/proj1/share-2."
   "extendedData": []
}
```

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  {"smbProtocolMode": "SMB1"}
    ]' \
  https://198.51.100.10/zebi/api/v2/setSMBConfig -k
```

#### **Error Response**

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "setSMBConfig.arg0.smbProtocolMode value 'SMB1':
  Incorrect input: SMB protocol can only be CIFS or SMB3.",
  "message": "Incorrect input: SMB protocol can only be CIFS or SMB3.",
  "extendedData": {
        "EX_CAUSE_MESSAGE": null
    }
}
```

## setSMBSharingOnProject

Enables or disables SMB protocol for project. If you disable SMB protocol for a project, any existing network ACLs on the project are removed as well.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

#### turnOn

Enables or disables SMB protocol on the project.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

## **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project is not found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

## Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", true
   ]' \
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This enables SMB sharing on the specified project.

#### Example 2

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", false
   ]' \
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This disables CMB sharing on the specified project.

## Example 3

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", true
   ]' \
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

#### Example 4

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
"pool-a/Replica/replicaProject", true
   ]' \
  https://198.51.100.10/zebi/api/v2/setSMBSharingOnProject -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"setSMBSharingOnProject.arg0 value 'pool-a/Replica/
replicaProject':
    Local dataset path expected. For example, valid formats are
```

```
'pool-name/Local/project-name' or 'pool-name/Local/project-name/share-
or-lun-name'.",
    "message":"Local dataset path expected.
    For example, valid formats are 'pool-name/Local/project-name' or
    'pool-name/Local/project-name/share-or-lun-name'.",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# setSMBSharingOnShare

Enables or disables SMB protocol for share. If the dataset contains any network ACLs, they are removed as well.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLonShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

#### **Parameters**

#### datasetPath

```
Path of the project. The format is <poolName>/Local//cal/<shareName>.
```

This operation is not allowed for replica project datasets.

#### turnOn

Enables SMB protocol on the project.

## displayName

Display name of the share.

#### enableGuestMode

Enables guests mode for the share.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

#### **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified share is not found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/demoShare", true, "test", true]'
    https://198.51.100.10/zebi/api/v2/setSMBSharingOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK).

## Example 2

#### Request (curl)

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/UNKNOWNShare", true, "test", true]'
    https://198.51.100.10/zebi/api/v2/setSMBSharingOnShare -k
```

#### Response

The above request returns the HTTP status code 500 (internal server error) and the following response:

#### Example 3

#### **Erroneous Request**

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Replica/replicaProj/replicaShare", true, "test", true]'
    https://198.51.100.10/zebi/api/v2/setSMBSharingOnShare -k
```

## **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{"code":"EZEBI_INVALID_ARGUMENT",

"details":"setSMBSharingOnShare.arg0 value
'pool-a/Replica/replicaProj/replicaShare': Local dataset path expected.
For example, valid formats are 'pool-name/Local/project-name' or
'pool-name/Local/project-name/share-or-lun-name'.",

"message":"Local dataset path expected.
For example, valid formats are 'pool-name/Local/project-name' or
'pool-name/Local/project-name/share-or-lun-name'.", "extendedData":
{"EX_CAUSE_MESSAGE":null}}
```

## **fetchContollerStatus**

Fetches the controller status of an array.

#### First Available Version

API v2.7, IntelliFlash 3.11.4.2

#### **Parameters**

None

#### Returns

The API returns 'code= 200' if the request succeeds.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth_TOKEN" \
```

```
-H "Content-Type:application/json" \
https://10.200.245.4/zebi/api/v2/fetchContollerStatus -k
```

## Response

The API returns the following response with status 'code= 200'.

```
{
   "upTimeA": "131 days 8:22",
   "upTimeB": "81 days 21:10"
}
```

'200' means that the request is successful and lists the two controllers up Time as below:

- upTimeA = 131 days
- upTimeB = 81 days

## Example 2

## Request (curl)

```
curl -X POST \
-H "Authorization:Basic Auth TOKEN" \
-H "Content-Type:application/json" \
https://10.200.245.4/zebi/api/v2/fetchContollerStatus -k
```

## Response

The API returns the following response when one of the controllers is down. The upTime for controller A is 131 days while for controller B is not applicable.

```
{
   "upTimeA": "131 days 8:22",
   "upTimeB": "N/A"
}
```

# **Chapter 11**

# **Network ACL Methods**

#### Topics:

- addNFSNetworkACLOnProject
- addNFSNetworkACLOnShare
- addSMBNetworkACLOnProject
- addSMBNetworkACLOnShare
- getNFSNetworkACLsOnProject
- getNFSNetworkACLsOnShare
- getSMBNetworkACLsOnProject
- getSMBNetworkACLsOnShare
- inheritNetworkACLsettingsFromProject
- removeAlINFSNetworkACLsOnProject
- removeAlINFSNetworkACLsOnShare
- removeAllSMBNetworkACLsOnProject
- removeAllSMBNetworkACLsOnShare
- removeNFSNetworkACLOnProject
- removeNFSNetworkACLOnShare
- removeSMBNetworkACLOnProject
- removeSMBNetworkACLOnShare
- setNFSNetworkACLsOnProject
- setNFSNetworkACLsOnShare
- setSMBNetworkACLsOnProject
- setSMBNetworkACLsOnShare

The following sections describe Network ACL methods, parameters, return types, and examples.

## addNFSNetworkACLOnProject

Adds network ACL to the NFS project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

## type

Type of network ACL host, whether IP or FQDN.

## host

The host to use for providing access.

#### accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

#### isRoot

Whether ACL is root access.

#### Returns

COMMAND STATUS.COMMAND SUCCEED (0) on success.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.

• If the path specified belongs to a replica dataset.

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "FQDN", "www.example.com", "rw", true
  ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

## Response:

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

## Example 2

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
```

```
"pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
    ]' \
https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

## Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation
again.",
   "message":"NFS sharing is not enabled for the specified project
   'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

#### **Example 4**

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", "IP", "198.51.100.255", "rw", true
   ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

#### Example 5

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
```

```
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Local/demoProject", "IP", "198.51.100.255", "read-write", true
    ]' \
https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnProject -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"addNFSNetworkACLOnProject.arg3
    value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
    "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

## addNFSNetworkACLOnShare

Adds network ACL to the NFS share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSSharingOnShare, setNFSNetworkACLsOnShare, removeNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

#### **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

This operation is not allowed for replica share datasets.

## type

Type of network ACL host, whether IP or FQDN.

#### host

The host to use for providing access.

#### accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

#### isRoot

Whether ACL is root access.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth_TOKEN \
   -H 'cache-control: no-cache' \
   -H 'content-type: application/json' \
   -d '[
   "pool-a/Local/Project/demoShare", "FQDN", "www.example.com", "rw", true
    ]' \
   https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

## Example 2

## Request (curl)

```
curl -X POST \
```

```
-H 'authorization: Basic Auth_TOKEN \
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
"pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true
]' \
https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

## Example 3

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true]'
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

## Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation
again.",
   "message":"NFS sharing is not enabled for the specified share
   'pool-a/Local/Project/demoShare'.",
   "extendedData":{}
}
```

#### **Example 4**

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

## Example 5

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "read-write",
  true
    ]' \
  https://198.51.100.10/zebi/api/v2/addNFSNetworkACLOnShare -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"addNFSNetworkACLOnShare.arg3
    value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
    "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# addSMBNetworkACLOnProject

Adds network ACL to the SMB project.

## First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBSharingOnProject, setSMBNetworkACLsOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

## type

Type of network ACL host, whether IP or FQDN.

#### host

The host to use for providing access.

#### accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.
- If the path specified belongs to a replica dataset.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

## **Examples**

## Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "FQDN", "www.example.com", "rw", true
  ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

#### Example 2

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

#### Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"SMB sharing is not enabled on the specified dataset.
```

```
Please enable SMB sharing on the dataset and then try the operation
again.",
   "message":"SMB sharing is not enabled for the specified project
   'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

## **Example 4**

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

## **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

## Example 5

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255", "read-write", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnProject -k
```

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
```

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"addSMBNetworkACLOnProject.arg3
   value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
   "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

## addSMBNetworkACLOnShare

Adds a network ACL to the SMB share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBSharingOnShare, setSMBNetworkACLsOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

#### **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

This operation is not allowed for replica share datasets.

#### type

Type of network ACL host, whether IP or FQDN.

#### host

The host to use for providing access.

#### accessMode

Access mode. 'rw' for Read-Write access, 'ro' for Read-Only access.

#### Returns

COMMAND STATUS.COMMAND SUCCEED (0) on success.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "FQDN", "www.example.com", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK).

#### Example 2

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

## Response

The above request returns the HTTP status code 200 (OK).

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "rw", true
   ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

## Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"SMB sharing is not enabled on the specified dataset.
   Please enable SMB sharing on the dataset and then try the operation
again.",
   "message":"SMB sharing is not enabled for the specified project
   'pool-a/Local/Project/demoShare'.",
   "extendedData":{}
}
```

#### **Example 4**

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare", "IP", "198.51.100.255", "rw", true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

## **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/Project/
UNKNOWNShare'.",
```

```
"extendedData":{}
}
```

#### Example 5

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255", "read-write",
  true
    ]' \
  https://198.51.100.10/zebi/api/v2/addSMBNetworkACLOnShare -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
    "code":"EZEBI_INVALID_ARGUMENT",
    "details":"addSMBNetworkACLOnShare.arg3
    value 'read-write': Network ACL can only be \"rw\" (Read-Write) or \"ro
\" (Read-Only).",
    "message":"Network ACL can only be \"rw\" (Read-Write) or \"ro\" (Read-Only).",
    "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# getNFSNetworkACLsOnProject

Returns all the network ACLs of the NFS project.

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

## **Related APIs**

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS

# Parameters datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

#### **Returns**

List of network ACLs objects of type NetworkACL\_V2\_1.

## **Exceptions Thrown**

## EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

## **Examples**

#### **Example 1**

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and returns the list of NFS network ACL objects.

```
[
    "hostType":"IP",
        "host":"198.51.100.255",
        "accessMode":"ro",
        "rootAccessForNFS":true
},
{
    "hostType":"FQDN",
        "host":"www.example.com",
        "accessMode":"rw",
        "rootAccessForNFS":true
}
```

## Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnProject -k
```

## **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

## getNFSNetworkACLsOnShare

Returns all the network ACLs of the NFS share.

## First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLOnShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS

## **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

#### Returns

List of network ACLs objects of type NetworkACL\_V2\_1.

## **Exceptions Thrown**

#### **EZEBI RESOURCE NOT FOUND**

This exception is thrown if the specified share cannot be found.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### **Example 1**

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare"
   ]' \
  https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnShare -k
```

## Response

The above request returns the HTTP status code 200 (OK) and returns the list of NFS network ACL objects.

```
[
    "hostType":"IP",
    "host":"198.51.100.255",
    "accessMode":"ro",
    "rootAccessForNFS":true
},
{
    "hostType":"FQDN",
    "host":"www.example.com",
    "accessMode":"rw",
    "rootAccessForNFS":true
}
]
```

#### Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
```

```
-d '[
"pool-a/Local/Project/UNKNOWNShare"
    ]' \
https://198.51.100.10/zebi/api/v2/getNFSNetworkACLsOnShare -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following response:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified share 'pool-a/Local/Project/
UNKNOWNShare'.",
    "extendedData":{}
}
```

# getSMBNetworkACLsOnProject

Returns all the network ACLs of the SMB project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB

# **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

#### Returns

List of network ACL objects of type NetworkACL\_V2\_1.

## **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

# Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnProject -k
```

## Response:

The above request returns the HTTP status code 200 (OK) and returns the list of SMB network ACL objects.

```
[
    "hostType":"IP",
    "host":"198.51.100.255",
    "accessMode":"ro",
    "rootAccessForNFS":true
},
{
    "hostType":"FQDN",
    "host":"www.example.com",
    "accessMode":"rw",
    "rootAccessForNFS":true
}
```

# Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnProject -k
```

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

# getSMBNetworkACLsOnShare

Returns all the network ACLs of the SMB share.

# First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB

#### **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

#### Returns

List of network ACL objects of the NetworkACL\_V2\_1 type.

# **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified share cannot be found.

## **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare"
   ]' \
  https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnShare -k
```

## Response

The above request returns the HTTP status code 200 (OK) and the following response:

# Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/UNKNOWNShare"
    ]' \
  https://198.51.100.10/zebi/api/v2/getSMBNetworkACLsOnShare -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
```

# inheritNetworkACLsettingsFromProject

Enables or disables NFS protocol for a share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLsOnShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLOnShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local//shareName>.

This operation is not allowed for replica share datasets.

#### Values returned

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to a replica dataset.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

## **Examples**

#### Example 1

## Request (curl)

# Response

The above request returns the HTTP status code 200 (OK).

#### **Example 2**

# **Erroneous Request (curl)**

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Local/project/UNKNOWNShare"]'
    https://198.51.100.10/zebi/api/v2/inheritNetworkACLsettingsFromProject
  -k
```

#### Response

The above request returns the HTTP status code 500 (internal server error) and the following response:

# Example 3

#### **Erroneous Request**

```
curl -X POST \
  -H 'Authorization:Basic Auth_TOKEN' \
  -H 'cache-control: no-cache' \
  -H 'Content-Type:application/json' \
  -d '["pool-a/Replica/replicaProj/replicaShare"]'
        https://198.51.100.10/zebi/api/v2/inheritNetworkACLsettingsFromProject
  -k
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

# removeAlINFSNetworkACLsOnProject

Removes all network ACLs from an NFS project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

# Parameters datasetPath

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the specified project does not support the protocol.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

# Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnProject -k
```

# Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

# Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnProject -k
```

# Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

# removeAlINFSNetworkACLsOnShare

Removes all network ACLs from an NFS share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLonShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

# **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local/<projectName>/ <shareName>.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

## EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified share cannot be found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the specified share does not support the protocol.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

# **Examples**

# Example 1

## Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/demoShare"]'
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK).

#### Example 2

# **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/UNKNOWNShare"]'
  https://198.51.100.10/zebi/api/v2/removeAllNFSNetworkACLsOnShare -k
```

#### Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation again.",
   "message":"NFS sharing is not enabled for the specified share
   'pool-a/Local/project/UNKNOWNShare'.","extendedData":{}}
```

# removeAllSMBNetworkACLsOnProject

Removes all network ACLs from an SMB project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

#### **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the specified project does not support the protocol.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

# **Examples**

## Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnProject -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

#### Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject"
   ]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnProject -k
```

#### Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

# removeAIISMBNetworkACLsOnShare

Removes all network ACLs from an SMB share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

# **Related APIs**

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLonShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

# **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local//colname>/
<shareName>.

This operation is not allowed for replica share datasets.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the specified share does not support the protocol.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

## **Examples**

# Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/demoShare"]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK).

# Example 2

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '["pool-a/Local/Project/UNKNOWNShare"]' \
  https://198.51.100.10/zebi/api/v2/removeAllSMBNetworkACLsOnShare -k
```

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"SMB sharing is not enabled on the specified dataset.
Please enable SMB sharing on the dataset and then try the operation
again.",
  "message":"SMB sharing is not enabled for the specified share
  'pool-a/Local/project/UNKNOWNShare'.","extendedData":{}}
```

# removeNFSNetworkACLOnProject

Removes network ACL from an NFS project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setNFSSharingOnProject, setNFSNetworkACLsOnProject, addNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

# type

Type of network ACL host, whether IP or FQDN.

#### host

The host to use for providing access.

#### Returns

COMMAND STATUS.COMMAND SUCCEED (0) on success.

#### **Exceptions Thrown**

#### EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found, or if the specified ACL does not exist.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the path specified belongs to a replica dataset.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

## **Examples**

# Example 1

## Request (curl)

# Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

# Example 2

# **Erroneous Request (curl)**

#### **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
    "extendedData":{}
}
```

#### Example 3

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "FQDN", "www.example.com"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeNFSNetworkACLOnProject -k
```

## **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
   "code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "message":"The specified ACL 'www.example.com' does not belong to the
   dataset.",
    "extendedData":{}
}
```

# removeNFSNetworkACLOnShare

Removes network ACL from an NFS share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSSharingOnShare, setNFSNetworkACLsOnShare, addNFSNetworkACLonShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

#### **Parameters**

#### datasetPath

```
Path of the share. The format is <poolName>/Local//colname>/
<shareName>.
```

This operation is not allowed for replica share datasets.

#### type

Type of network ACL host, whether IP or FQDN.

#### host

The host to use for providing access.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found, or if the specified ACL does not exist.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

# **EZEBI GENERAL**

This exception is thrown if the operation failed.

# **Examples**

# **Example 1**

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeNFSNetworkACLOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK).

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
"pool-a/Local/Project/demoShare", "IP", "198.51.100.255"
  ]' \
```

```
https://198.51.100.10/zebi/api/v2/removeNFSNetworkACLOnShare -k
```

#### Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation again.",
   "message":"NFS sharing is not enabled for the specified share
   'pool-a/Local/project/demoShare'.","extendedData":{}}
```

# removeSMBNetworkACLOnProject

Removes network ACL from an SMB project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBSharingOnProject, setSMBNetworkACLsOnProject, addSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

# type

Type of network ACL host, whether IP or FQDN.

#### host

The host to use for providing access.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

## **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found, or if the specified ACL does not exist.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

# **Examples**

# Example 1

# Request (curl)

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

#### Example 2

# **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/UNKNOWNProject", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeSMBNetworkACLOnProject -k
```

#### Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
```

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"",
   "message":"Cannot find the specified project 'pool-a/Local/
UNKNOWNProject'.",
   "extendedData":{}
}
```

#### Example 3

# **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/demoProject", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeSMBNetworkACLOnProject -k
```

# **Error Response**

The above request returns the HTTP status code 404 (not found) and the following message:

```
{
    "code":"EZEBI_RESOURCE_NOT_FOUND",
    "details":"",
    "message":"The specified ACL '@198.51.100.255' does not belong to the dataset.",
    "extendedData":{}
}
```

# removeSMBNetworkACLOnShare

Removes network ACL from an SMB share.

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setSMBSharingOnShare, setSMBNetworkACLsOnShare, addSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

#### **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local//colname>/
<shareName>.

This operation is not allowed for replica share datasets.

# type

Type of network ACL host, whether IP or FQDN.

#### host

The host to use for providing access.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found, or if the specified ACL does not exist.

#### **EZEBI\_INVALID\_ARGUMENT**

This exception is thrown if the share specified belongs to a replica dataset.

# **EZEBI GENERAL**

This exception is thrown if the operation failed.

## **Examples**

#### **Example 1**

#### Request (curl)

## Response

The above request returns the HTTP status code 200 (OK).

#### Example 2

## **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
  "pool-a/Local/Project/demoShare", "IP", "198.51.100.255"
    ]' \
  https://198.51.100.10/zebi/api/v2/removeSMBNetworkACLOnShare -k
```

## **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND",
  "details":"SMB sharing is not enabled on the specified dataset.
  Please enable SMB sharing on the dataset and then try the operation again.",
  "message":"SMB sharing is not enabled for the specified share
  'pool-a/Local/project/demoShare'.","extendedData":{}}
```

# setNFSNetworkACLsOnProject

Set the network ACLs on the NFS project. If the dataset contains any existing network ACLs, they are replaced with the new ones.

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

setNFSSharingOnProject, addNFSNetworkACLOnProject, removeNFSNetworkACLOnProject, removeAllNFSNetworkACLsOnProject, isProjectExposedOverNFS, getNFSNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

#### networkACLs

Array of Network ACLs. Each object in the array is of the NetworkACL V2 1 type.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified project cannot be found.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.
- If the path specified belongs to a replica dataset.

# **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

#### Request (curl)

#### Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

# Example 2

#### Request (curl)

```
curl -X POST \
```

# Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

#### Example 3

## **Erroneous Request (curl)**

## Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"NFS sharing is not enabled on the specified dataset.
   Please enable NFS sharing on the dataset and then try the operation again.",
   "message":"NFS sharing is not enabled for the specified project
   'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

#### **Example 4**

#### **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
```

# **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setNFSNetworkACLsOnProject.arg1[0] value
  'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each
  address whole number is no greater than 255.",
  "message":"Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address
  whole number is no greater than 255.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

#### Example 5

#### **Erroneous Request**

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
{
```

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"setNFSNetworkACLsOnProject.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "message":"Local dataset path expected.
   For example, valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# setNFSNetworkACLsOnShare

Set the network ACLs on the NFS share. If the dataset contains any existing network ACLs, they are replaced with the new ones.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setNFSSharingOnShare, addNFSNetworkACLOnShare, removeNFSNetworkACLOnShare, removeAllNFSNetworkACLsOnShare, isShareExposedOverNFS, getNFSNetworkACLsOnShare

# **Parameters**

#### datasetPath

```
Path of the share. The format is <poolName>/Local//colname>/
<shareName>.
```

This operation is not allowed for replica project datasets.

#### networkACLs

Array of Network ACLs. Each object in the array is of the NetworkACL\_V2\_1 type.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

# Request (curl)

## Response

The above request returns the HTTP status code 200 (OK).

## Example 2

#### **Erroneous Request (curl)**

#### **Error Response**

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
{"code":"EZEBI_RESOURCE_NOT_FOUND","details":
"NFS sharing is not enabled on the specified dataset.
Please enable NFS sharing on the dataset and then try the operation again.
```

```
","message":"NFS sharing is not enabled for the specified share 'pool-a/Local/project/demoShare'.","extendedData":{}}
```

#### Example 3

#### **Erroneous Request**

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setNFSNetworkACLsOnShare.arg1[0] value
  'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "message":"Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

#### **Example 4**

#### **Erroneous Request**

#### Error Response

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"setNFSNetworkACLsOnShare.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "message":"Local dataset path expected.
   For example, valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

#### Example 5

#### **Erroneous Request**

#### **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

# setSMBNetworkACLsOnProject

Sets the network ACLs on the SMB project.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setSMBSharingOnProject, addSMBNetworkACLOnProject, removeSMBNetworkACLOnProject, removeAllSMBNetworkACLsOnProject, isProjectExposedOverSMB, getSMBNetworkACLsOnProject

#### **Parameters**

#### datasetPath

Path of the project. The format is <poolName>/Local/<projectName>.

This operation is not allowed for replica project datasets.

#### networkACLs

Array of Network ACLs. Each object in the array is of type NetworkACL\_V2\_1.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

#### **Exceptions Thrown**

#### EZEBI RESOURCE NOT FOUND

This exception is thrown if the specified project cannot be found.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified project does not support the protocol.
- If the path specified belongs to a replica dataset.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

# **Examples**

#### Example 1

## Request (curl)

# Response

The above request returns the HTTP status code 200 (OK) and 0 indicating success.

#### Example 2

## **Erroneous Request (curl)**

#### Response

The above request returns the HTTP status code 404 (not found) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"SMB sharing is not enabled on the specified dataset.
   Please enable SMB sharing on the dataset and then try the operation again.",
   "message":"SMB sharing is not enabled for the specified project
   'pool-a/Local/demoProject'.",
   "extendedData":{}
}
```

#### Example 3

#### **Erroneous Request**

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setSMBNetworkACLsOnProject.arg1[0] value
  'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN.NNN format, where each
  address whole number is no greater than 255.",
  "message":"Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN.NNN format, where each address
  whole number is no greater than 255.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

# Example 4

#### **Erroneous Request**

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
   "details":"setSMBNetworkACLsOnProject.arg0 value 'pool-a/Replica/
replicaProject':
   Local dataset path expected. For example, valid formats are
   'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "message":"Local dataset path expected.
   For example, valid formats are 'pool-name/Local/project-name' or
   'pool-name/Local/project-name/share-or-lun-name'.",
   "extendedData":{"EX_CAUSE_MESSAGE":null}
}
```

# setSMBNetworkACLsOnShare

Sets the network ACLs on the SMB share.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

setSMBSharingOnShare, addSMBNetworkACLOnShare, removeSMBNetworkACLOnShare, removeAllSMBNetworkACLsOnShare, isShareExposedOverSMB, getSMBNetworkACLsOnShare

#### **Parameters**

#### datasetPath

Path of the share. The format is <poolName>/Local/<projectName/ <shareName>.

This operation is not allowed for replica share datasets.

#### networkACLs

Array of Network ACLs. Each object in the array is of type NetworkACL\_V2\_1.

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# Exceptions Thrown EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the specified share cannot be found.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown for the following conditions:

- If an incorrect IP address or access mode is specified.
- If the specified share does not support the protocol.
- If the path specified belongs to a replica dataset.

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

#### Request (curl)

```
curl -X POST \
   -H 'authorization: Basic Auth TOKEN \
   -H 'cache-control: no-cache' \[
   -H 'content-type: application/json' \
   -d '[
   "pool-a/Local/Project/DemoShare", [{"hostType": "IP",
   "host":"198.51.100.255",
        "accessMode":"ro", "rootAccessForNFS":true},
        {"hostType": "FQDN", "host":"www.example.com", "accessMode":"rw",
        "rootAccessForNFS":true}]
        ]' \
   https://198.51.100.10/zebi/api/v2/setSMBNetworkACLsOnShare -k
```

#### Response

The above request returns the HTTP status code 200 (OK).

## **Example 2**

#### **Erroneous Request (curl)**

## Response

The above request returns the HTTP status code 500 (internal server error) and the following message:

```
"code":"EZEBI_RESOURCE_NOT_FOUND",
   "details":"SMB sharing is not enabled on the specified dataset.
   Please enable SMB sharing on the dataset and then try the operation again.",
   "message":"SMB sharing is not enabled for the specified share
   'pool-a/Local/Project/demoShare'.",
   "extendedData":{}
}
```

#### Example 3

## **Erroneous Request**

#### **Error Response**

The above request returns the HTTP status code 400 (Bad Request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setSMBNetworkACLsOnShare.arg1[0] value
  'com.example.skywalk.api.v2.IPublicAPI_V2_1$NetworkACL_V2_1@6cb39d3b':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "message":"Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format, where each address whole number is no greater than 255.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

#### Example 4

# **Erroneous Request**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
"pool-a/Replica/replicaProject/replicaShare",
        [{"hostType": "IP", "host":"198.51.100.255",
        "accessMode":"ro", "rootAccessForNFS":true},
        {"hostType": "FQDN", "host":"www.example.com",
        "accessMode":"rw", "rootAccessForNFS":true}]
    ]' \
    https://198.51.100.10/zebi/api/v2/setSMBNetworkACLsOnShare -k
```

## **Error Response**

The above request returns the HTTP status code 400 (bad request) and the following message:

```
"code":"EZEBI_INVALID_ARGUMENT",
  "details":"setSMBNetworkACLsOnShare.arg0 value
  'pool-a/Replica/replicaProject/replicaShare':
  Local dataset path expected. For example, valid formats are
  'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "message":"Local dataset path expected.
  For example, valid formats are 'pool-name/Local/project-name' or
  'pool-name/Local/project-name/share-or-lun-name'.",
  "extendedData":{"EX_CAUSE_MESSAGE":null}
```

# Chapter 12

# **SNMP Methods**

# **Topics:**

- addSNMPTrapListener
- disableSNMPService
- enableSNMPService
- getSNMPSettings
- isSNMPServiceEnabled
- modifySNMPCommunityString
- recreateSNMPTables
- removeSNMPTrapListener
- resyncSNMPTables

The following sections describe SNMP methods, parameters and return types. They also include examples with sample responses.

# addSNMPTrapListener

Adds an SNMP trap listener address that receives the SNMP event notifications.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

#### **Parameters**

#### trapListenerlp

IP address of the Trap listener.

Only up to 10 listeners are allowed. Must be a valid IPv4 address. The IP address cannot be any of the reserved addresses. For example, addresses such as 127.0.0.1, 0.0.0.0 and 255.255.255.255 are not allowed.

# trapListenerPort

Port number of the Trap listener. The trap port must be in the 1-65535 range.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- · 2 indicates that the request failed.

#### **Exceptions Thrown**

#### **EZEBI RESOURCE EXIST**

This exception is thrown if the trap listener you added already exists.

#### **EZEBI INVALID ARGUMENT**

This exception is thrown if the IPv4 address of the listener is invalid (incorrectly blank, invalid IPv4 format, the trap port not in the 1-65535 range, or the SNMP service not enabled).

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.50.10",162]' \
https://198.51.100.10/zebi/api/v2/addSNMPTrapListener -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that it successfully added the SNMP trap listener.

#### Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '["10.68.50.10",162]' \
  https://198.51.100.10/zebi/api/v2/addSNMPTrapListener -k
```

### Response

In this example, the requested SNMP trap listener already exists. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_RESOURCE_EXIST",
   "details": "",
   "message":
   "Trap listener 10.68.50.10:162 already exists in SNMP settings and cannot be added",
   "extendedData": {}
}
```

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.500.500",162]' \
https://198.51.100.10/zebi/api/v2/addSNMPTrapListener -k
```

#### Response

In this example, the SNMP trap was requested for an invalid IP address. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "addSNMPTrapListener.arg0 value '10.68.500.500':
  Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format,
  where each address whole number is no greater than 255.",
  "message": "Internet Protocol Network Address is in the wrong format.
  Expecting a address in the NNN.NNN.NNN format,
  where each address whole number is no greater than 255.",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
}
```

# disableSNMPService

Disables the SNMP service on the IntelliFlash array.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

enableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

#### **Parameters**

None

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# **Exceptions Thrown**

#### **EZEBI GENERAL**

This exception is thrown if the operation failed.

# **Examples**

#### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
  -d '[]' \
https://198.51.100.10/zebi/api/v2/disableSNMPService -k
```

# Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that the API successfully disabled the service.

# enableSNMPService

Enables the SNMP service on the IntelliFlash array and sets the SNMP community string.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

#### **Parameters**

## communityString

Community string to be used on the enabled SNMP service. The SNMP community string cannot be longer than 64 characters. It cannot have special characters such as  $*,\#,/,\backslash,!,@,\sim,(,),[,],\{,\},=,$  and %.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# Exceptions Thrown EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the parameter is invalid. The SNMP community string is invalid when it is incorrectly blank or beyond 64 characters long, or has non-alphanumeric characters other than, dash, underscore or period.

# EZEBI\_GENERAL

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

# Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["public"]' \
https://198.51.100.10/zebi/api/v2/enableSNMPService -k
```

# Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that the API successfully enabled the service.

#### Example 2

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN"
-H "Content-Type:application/json" \
  -d '["public#!@~"]' \
https://198.51.100.10/zebi/api/v2/enableSNMPService -k
```

#### Response

In this example, the requested SNMP community string format was invalid. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "enableSNMPService.arg0 value 'public#!@~'':
  SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "message": "SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
  }
```

}

# getSNMPSettings

Returns the SNMP settings of the current SNMP service.

This includes the trap listeners and the SNMP community string in the JSON object SNMP\_Setting\_V2\_1.

#### **First Available Version**

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, modifySNMPCommunityString

#### **Parameters**

None

#### **Returns**

Returns the JSON object *SNMP\_Setting\_V2\_1*, which contains an array of the SNMP trap listener ip:port values, and the SNMP community string.

# Exceptions Thrown

# **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### **Example 1**

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '[]' \
https://198.51.100.10/zebi/api/v2/getSNMPSettings -k
```

## Response

The above request returns the HTTP status code 200 (OK) and a JSON object SNMP\_Setting\_V2\_1. For example:

```
{
   "communityString": "public3",
   "trapListeners": [
       "10.68.97.43:162",
       "10.68.97.44:162",
       "10.68.97.45:162",
       "10.68.97.46:162",
       "10.68.50.10:10000"
]
}
```

#### Example 2

### **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H 'cache-control: no-cache' \
-H "Content-Type:application/json" \
-d '[]' \
https://198.51.100.10/zebi/api/v2/getSNMPSettings -k
```

#### Response

In this example, the requested SNMP service is not running. So the request returns the HTTP status code 400 (bad request) and the following response:

```
{
    "code": "EZEBI_RESOURCE_NOT_FOUND",
    "details": "",
    "message": "SNMP Service must be enabled for this operation. Please
enable SNMP and try again.",
    "extendedData": {}
}
```

# **isSNMPServiceEnabled**

Checks whether the SNMP Service is enabled.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

enableSNMPService, disableSNMPService, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

#### **Parameters**

None

#### Returns

Returns a JSON boolean status where:

- False indicates that the service is not enabled.
- True indicates that the service is enabled.

# **Exceptions Thrown**

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

### **Example 1**

## Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H "Content-Type:application/json" \
  -H 'cache-control: no-cache' \
  -d '[]' \
  https://198.51.100.10/zebi/api/v2/isSNMPServiceEnabled -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and JSON boolean result (true = SNMP enabled), indicating that the service is enabled.

# modifySNMPCommunityString

Modifies the SNMP community string to be a new value.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### **Related APIs**

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, removeSNMPTrapListener, getSNMPSettings

#### **Parameters**

### communityString

Community string to be used on the enabled SNMP service. The SNMP community string cannot be longer than 64 characters. It cannot have special characters such as  $*,\#,/,\backslash,!,@,\sim,(,),[,],\{,\},=,$  and %.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the community string parameter is invalid. The SNMP community string is invalid when it is incorrectly blank or beyond 64 characters long, or has non-alphanumeric characters other than dash, underscore or period.

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["public2"]' \
https://198.51.100.10/zebi/api/v2/modifySNMPCommunityString -k
```

## Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that it successfully modified the SNMP community string to "public2".

## Example 2

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["public#!@~"]' \
https://198.51.100.10/zebi/api/v2/modifySNMPCommunityString -k
```

#### Response

In this example, the requested SNMP community string format was invalid. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "enableSNMPService.arg0 value 'public#!@~'':
  SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "message": "SNMP Community String cannot be longer than 64 characters
  and it cannot have special characters
  like *,#,/,\\,!,@,~,(,),[,],{,},=,%... (default='public')",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
    }
}
```

# recreateSNMPTables

Recreates the SNMP entries. After deletion or creation of objects, the SNMP table entries might have gaps in the indices. Use this API to re-index the table entries.

#### First Available Version

API v2.1, IntelliFlash 3.5.4.0/3.7.0.x

#### Related APIs

resyncSNMPTables

#### **Parameters**

None

#### Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

# Exceptions Thrown EZEBI GENERAL

This exception is thrown if the operation failed or SNMP is not enabled.

#### **Examples**

## Example 1

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ]' \
  https://198.51.100.10/zebi/api/v2/recreateSNMPTables -k
```

## Response:

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This initiates the SNMP table recreation in the background in asynchronous mode.

# removeSNMPTrapListener

Removes an SNMP trap listener address that would have received SNMP event notifications.

#### First Available Version

API v2.1, IntelliFlash 3.7.0.x

#### Related APIs

enableSNMPService, disableSNMPService, isSNMPServiceEnabled, addSNMPTrapListener, getSNMPSettings, modifySNMPCommunityString

#### **Parameters**

#### trapListenerlp

IP address of the Trap listener.

Only up to 10 listeners are allowed. Must be a valid IPv4 address. The IP address cannot be any of the reserved addresses. For example, addresses such as 127.0.0.1, 0.0.0.0 and 255.255.255.255 are not allowed.

#### trapListenerPort

Port number of the Trap listener. The trap port must be in the 1-65535 range.

#### Returns

Returns an integer status where:

- 0 indicates that the request succeeded.
- 1 indicates that the request was not attempted.
- 2 indicates that the request failed.

# **Exceptions Thrown**

# EZEBI\_RESOURCE\_NOT\_FOUND

This exception is thrown if the trap listener does not exist.

# EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the IPv4 address of the listener is invalid (incorrectly blank, invalid IPv4 format, the trap port not in the 1-65535 range, or the SNMP service not enabled).

#### **EZEBI\_GENERAL**

This exception is thrown if the operation failed.

#### **Examples**

# Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.50.10",162]' \
https://198.51.100.10/zebi/api/v2/removeSNMPTrapListener -k
```

#### Response

The above request returns the HTTP status code 200 (OK) and 0, indicating that it successfully removed the SNMP trap listener.

#### Example 2

# **Erroneous Request (curl)**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
-H "Content-Type:application/json" \
-H 'cache-control: no-cache' \
-d '["10.68.50.28",162]' \
```

```
https://198.51.100.10/zebi/api/v2/removeSNMPTrapListener -k
```

#### Response

In this example, the requested SNMP trap listener does not exist. So the request returns the HTTP status code 400 (bad request) and the following response:

```
"code": "EZEBI_RESOURCE_NOT_FOUND",
  "details": "",
  "message": "Failed to find SNMP trap listener to remove",
  "extendedData": {}
}
```

# resyncSNMPTables

Resyncs the SNMP entries between the two controllers of the array. SNMP queries can be sent to the management IP address or the individual controller IP address. If querying the individual controllers for the same OID (SNMP Object Index) fetches different response, use this API to resync the table entries between the controllers.

#### First Available Version

API v2.1, IntelliFlash 3.5.4.0/3.7.0.x

#### Related APIs

recreateSNMPTables

#### **Parameters**

None

## Returns

COMMAND\_STATUS.COMMAND\_SUCCEED (0) on success.

### **Exceptions Thrown**

**EZEBI\_GENERAL** 

This exception is thrown if the operation failed, or SNMP is not enabled.

#### **Examples**

#### Example 1

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ]' \
  https://198.51.100.10/zebi/api/v2/resyncSNMPTables -k
```

# Response:

The above request returns the HTTP status code 200 (OK) and 0 indicating success. This initiates the SNMP table resync between controllers in the background in asynchronous mode.

# Chapter 13

# **Analytics Methods**

# **Topics:**

The following sections describe analytics methods, parameters, getOneMinuteSystemAnalyticsHistory

getOneMinuteSystemAnalyticsHistory

- getOneMinuteDataAnalyticsHistory

# getOneMinuteSystemAnalyticsHistory

Returns the previous minute of analytics history for the specified system analytics.

The available system analytics are as follows:

• CPU: Provides the CPU usage data for each controller.

The following values are returned:

- Controller-[AB]/User: Percent CPU time spent in user space.
- Controller-[AB]/System: Percent CPU time spent in kernel.
- Controller-[AB]/Total\_Used: Total percent CPU time used.
- Controller-[AB]/Interrupts: Average interrupts fired per second.
- Controller-[AB]/System\_Calls: Average system calls per second.
- Cache Hits: Provides information on filesystem cache usage for each controller.

The following values are returned:

- Controller-[AB]/SSD\_Reads: Percentage of reads that hit SSD cache.
- Controller-[AB]/RAM\_Reads: Percentage of reads that hit RAM cache.
- Controller-[AB]/Cache\_Reads: Percentage of reads that hit either RAM or SSD cache.
- Pool Performance: Provides average disk IO statistics for each disk type in each pool.

The values are returned in the following format:

```
[pool-name]/[disk-type]/[statistic]
```

Disk-types have the following values:

- Data: Disks used for data-only. HDDs in hybrid pools.
- Cache: SSDs designated as read/write cache.
- Meta: SSDs designated for metadata only.
- Iflash: SSD disk type housing metadata and cache.

The following statistics are returned for each disk:

- Read\_MBps
- Write Mbps
- Read\_Ops
- Write\_Ops
- Read\_Latency
- Write\_Latency

MBps and Ops values are per-second averages. Latency values are per-operation averages in milliseconds.

• Network: Provides network IO statistics for each interface, interface group, and controller.

For interfaces, the values are returned in the following format:

```
Controller-[AB]/I/[name]/[statistic]
```

For interface groups, the values are returned in the following format:

```
Controller-[AB]/IG/[name]/[statistic]
```

For controllers, the values are returned in the following format:

```
Controller-[AB]/Total/[statistic]
```

The following statistics are returned for each interface, interface group, or controller:

- Read\_Mbps
- Transmit\_Mbps

The network statistics are provided in Mbps, while all the other data statistics are provided in MBps.

#### First Available Version

API v2.3, IntelliFlash 3.9.0.0

#### Related APIs

getOneMinuteDataAnalyticsHistory

#### **Parameters**

## analyticsTypes

An array of requested analytics types to include. The allowed values are NETWORK, POOL\_PERFORMANCE, CPU, and CACHE\_HITS.

#### Returns

Returns arrays of SystemAnalyticsResult\_V2\_3 objects.

# **Exceptions Thrown**

### **EZEBI\_GENERAL**

This exception is thrown when an internal error is detected.

## EZEBI\_INVALID\_ARGUMENT

This exception is thrown when a non-existent system analytic is requested.

# **Examples**

# **Example 1**

# Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    ["NETWORK", "POOL_PERFORMANCE", "CPU", "CACHE_HITS"]
    ]' \
  https://198.51.100.10/zebi/api/v2/getOneMinuteSystemAnalyticsHistory -k
```

# Response:

```
[
        "systemAnalyticsType": "POOL_PERFORMANCE",
        "timestamps": [
            1527187950000,
            1527187955000,
            1527187960000,
            1527187965000,
            1527187970000,
            1527187975000,
            1527187980000,
            1527187985000,
            1527187990000,
            1527187995000,
            1527188000000,
            1527188005000
        ],
"datapoints": {
   "appl-a/Ifla";

             "pool-a/Iflash/Read_Latency": [
                 Ο,
                 0,
                 0,
                 0,
                 0,
                 0,
                 0,
                 Ο,
                 0,
                 0,
                 0,
             "pool-a/Data/Write_MBps": [
                 6.11,
                 13.75,
                 13.41,
                 9.21,
                 15.65,
```

```
4.11,
    10.86,
    16.16,
    4.8,
    15.11,
    13.55,
    11.09
],
"pool-a/Iflash/Write_Latency": [
    1.74,
    0.61,
    0.4,
    0.38,
    1.51,
    0.6,
    0.51,
    0.65,
    0.32,
    0.52,
    0.44,
    0.52
"pool-a/Iflash/Read_MBps": [
    Ο,
    0,
    0,
    0,
    0,
    0,
    0,
    Ο,
    0,
    Ο,
    0,
"pool-a/Data/Write_Latency": [
    8.07,
102.73,
    111.88,
    86.99,
    45.92,
    33.55,
    74.72,
    98.97,
    55.25,
    92.84,
    115.95,
    86.53
"pool-a/Data/Read_Ops": [
    Ο,
    0,
    0,
    0,
    0,
    0,
    0,
    0,
    0,
    0,
```

```
0,
    0
"pool-a/Data/Read_MBps": [
    0,
    0,
    0,
    0,
    0,
    0,
    0,
    0,
    0,
    0,
    Ο,
    0
],
"pool-a/Iflash/Write_Ops": [
    653.25,
    563,
    588.5,
    600.5,
    669.5,
    614.75,
    594,
    606.5,
    605.5,
    589.5,
    580.25,
    604.5
],
"pool-a/Data/Read_Latency": [
    0,
    0,
    0,
    Ο,
    0,
    Ο,
    0,
    0,
    0,
    Ο,
    Ο,
],
"pool-a/Data/Write_Ops": [
    11,
13.5,
    14,
    10,
22.5,
    5.5,
    12,
17.5,
    5.5,
    16.5,
    13,
12.5
"pool-a/Iflash/Read_Ops": [
    Ο,
```

```
0,
            0,
            0,
            0,
            0,
            0,
            0,
            0,
            Ο,
            0,
            0
        "pool-a/Iflash/Write_MBps": [
            18.64,
            19.22,
            20.19,
            20.54,
            19.29,
            20.38,
            19.98,
            20.16,
            20.7,
            19.73,
            19.78,
            20.48
    "averages": {
        "pool-a/Iflash/Read Latency": 0,
        "pool-a/Data/Write MBps": 11.15,
        "pool-a/Iflash/Write_Latency": 0.68,
        "pool-a/Iflash/Read_MBps": 0,
        "pool-a/Data/Write_Latency": 76.12,
        "pool-a/Data/Read_Ops": 0,
        "pool-a/Data/Read_MBps": 0,
        "pool-a/Iflash/Write_Ops": 605.81,
        "pool-a/Data/Read_Latency": 0,
        "pool-a/Data/Write_Ops": 12.79,
        "pool-a/Iflash/Read_Ops": 0,
        "pool-a/Iflash/Write_MBps": 19.92
    }
},
    "systemAnalyticsType": "NETWORK",
    "timestamps": [
        1527187950000,
        1527187955000,
        1527187960000,
        1527187965000,
        1527187970000,
        1527187975000,
        1527187980000,
        1527187985000,
        1527187990000,
        1527187995000,
        1527188000000,
        1527188005000
    "datapoints": {
        "Controller-B/I/igb0/Receive Mbps": [
            8,
```

```
8,
    8,
    7,
    8,
    8,
    8,
    8,
    8,
    8,
    8,
    8
"Controller-B/IG/mgmt0/Transmit_Mbps": [
    299,
    303,
    279,
    302,
    296,
    302,
    302,
    302,
    294,
    303,
    294
],
"Controller-A/Total/Transmit_Mbps": [
    7,
    8,
    8,
    8,
    7,
    8,
    8,
    8,
    8,
    8,
    8,
],
"Controller-A/I/igb0/Transmit_Mbps": [
    7,
    8,
    8,
    8,
    7,
    8,
    8,
    8,
    8,
    8,
    8,
],
"Controller-A/IG/mgmt0/Transmit_Mbps": [
    7,
    8,
    8,
    8,
    7,
    8,
```

```
8,
    8,
    8,
    8,
    8,
    8
],
"Controller-B/Total/Transmit_Mbps": [
    299,
    303,
    279,
    302,
    296,
    302,
    302,
    302,
    294,
    303,
    294
],
"Controller-A/I/igb0/Receive_Mbps": [
    289,
    302,
    307,
    277,
    303,
    297,
    299,
    309,
    294,
    296,
    305
],
"Controller-B/I/igb0/Transmit_Mbps": [
    299,
    303,
    279,
    302,
    296,
    302,
    302,
    302,
    294,
    303,
    294
],
"Controller-A/IG/mgmt0/Receive_Mbps": [
    269,
    289,
    302,
    307,
    277,
    303,
    297,
    299,
    309,
    294,
    296,
```

```
305
        "Controller-B/IG/mgmt0/Receive_Mbps": [
            8,
            8,
            8,
            7,
            8,
            8,
            8,
            8,
            8,
            8,
            8,
            8
        ],
"Controller-A/Total/Receive_Mbps": [
            289,
            302,
            307,
            277,
            303,
            297,
            299,
            309,
            294,
            296,
            305
        "Controller-B/Total/Receive_Mbps": [
            8,
            8,
            8,
            7,
            8,
            8,
            8,
            8,
            8,
            8,
            8,
        ]
    "averages": {
        "Controller-B/I/igb0/Receive Mbps": 7.92,
        "Controller-B/IG/mgmt0/Transmit Mbps": 297.33,
        "Controller-A/Total/Transmit Mbps": 7.83,
        "Controller-A/I/igb0/Transmit Mbps": 7.83,
        "Controller-A/IG/mgmt0/Transmit Mbps": 7.83,
        "Controller-B/Total/Transmit Mbps": 297.33,
        "Controller-A/I/igb0/Receive_Mbps": 295.58,
        "Controller-B/I/igb0/Transmit_Mbps": 297.33,
        "Controller-A/IG/mgmt0/Receive_Mbps": 295.58,
        "Controller-B/IG/mgmt0/Receive_Mbps": 7.92,
        "Controller-A/Total/Receive Mbps": 295.58,
        "Controller-B/Total/Receive Mbps": 7.92
},
```

```
"systemAnalyticsType": "CACHE_HITS",
"timestamps": [
    1527187950000,
    1527187955000,
    1527187960000,
    1527187965000,
    1527187970000,
    1527187975000,
    1527187980000,
    1527187985000,
    1527187990000,
    1527187995000,
    1527188000000,
    1527188005000
],
"datapoints": {
    "Controller.";
    "Controller-A/SSD_Reads": [
         Ο,
         0,
         0,
         0,
         0,
         0,
         Ο,
         Ο,
         Ο,
         0,
         0,
         0
    ],
"Controller-B/SSD_Reads": [
        0,
         0,
         0,
         0,
         0,
         0,
         0,
         0,
         0,
         0,
         0,
    "Controller-A/Cache_Reads": [
        100,
        100,
        100,
        100,
        100,
        100,
        100,
         100,
         100,
         100,
         100,
         100
    "Controller-B/RAM_Reads": [
         100,
         100,
```

```
100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100
        "Controller-A/RAM_Reads": [
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100
        ],
"Controller-B/Cache_Reads": [
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100,
            100
        ]
    "averages": {
        "Controller-A/SSD Reads": 0,
        "Controller-B/SSD_Reads": 0,
        "Controller-A/Cache_Reads": 100,
        "Controller-B/RAM_Reads": 100,
        "Controller-A/RAM_Reads": 100,
        "Controller-B/Cache Reads": 100
    }
},
    "systemAnalyticsType": "CPU",
    "timestamps": [
        1527187950000,
        1527187955000,
        1527187960000,
        1527187965000,
        1527187970000,
        1527187975000,
        1527187980000,
        1527187985000,
        1527187990000,
```

```
1527187995000,
    1527188000000,
    1527188005000
],
"datapoints": {
    "Controller-
    "Controller-A/Total_Used": [
         7,
         6,
         5,
         5,
         6,
         5,
         6,
         6,
         5,
         8,
         5,
    ],
"Controller-A/System": [
        5,
        6,
         5,
         5,
         6,
         5,
         6,
         6,
         5,
         7,
         5,
5
    ],
"Controller-B/Interrupts": [
         2883,
         2698,
         17917,
         5275,
         2707,
         18019,
         2719,
         2788,
         18173,
         5145,
         2818
    ], "Controller-A/User": [
         2,
         0,
         0,
         0,
         0,
         0,
         0,
         0,
         Ο,
         1,
         Ο,
         0
```

```
"Controller-B/System Calls": [
    28848,
    30049,
    27126,
    28281,
    31055,
    33048,
    29474,
    30022,
    30586,
    30349,
    28219,
    28531
],
"Controller-A/Interrupts": [
    21457,
    2734,
    2772,
    18501,
    3448,
    3827,
    22768,
    2719,
    3590,
    9798,
    8864
],
"Controller-A/System_Calls": [
    44313,
    44414,
    45189,
    44876,
    42671,
    44464,
    45133,
    45545,
    48780,
    42323,
    44076
],
"Controller-B/User": [
    Ο,
    0,
    0,
    Ο,
    0,
    0,
    Ο,
    Ο,
    Ο,
    0,
    Ο,
],
"Controller-B/System": [
    7,
    8,
    7,
    7,
```

```
9,
                9,
                7,
                8,
                7,
                7,
                7,
            ],
"Controller-B/Total_Used": [
                7,
                8,
                7,
                7,
                9,
                9,
                7,
                8,
                7,
                7,
                7,
                7
            ]
        "averages": {
            "Controller-A/Total Used": 5.75,
            "Controller-A/System": 5.5,
            "Controller-B/Interrupts": 8267.92,
            "Controller-A/User": 0.25,
            "Controller-B/System Calls": 29632.33,
            "Controller-A/Interrupts": 8682.5,
            "Controller-A/System_Calls": 44466.58,
            "Controller-B/User": 0,
            "Controller-B/System": 7.5,
            "Controller-B/Total Used": 7.5
        }
   }
]
```

# Example 2

## **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
["NONE"]
   ]' \
  https://198.51.100.10/zebi/api/v2/getOneMinuteSystemAnalyticsHistory -k
```

## **Error Response:**

```
{
```

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "",
  "message": "Unknown system analytics type: 'NONE'",
  "extendedData": {}
}
```

# getOneMinuteDataAnalyticsHistory

Returns the previous minute of analytics history for the specified data entities.

The API returns the following values for each given data entity:

- Read\_MBps
- Write\_MBps
- Total\_MBps
- Read\_Ops
- Write\_Ops
- Total\_Ops
- Read\_Latency
- Write\_Latency
- Average\_Latency

MBps and Ops values are per-second averages. Latency values are per-operation averages in milliseconds.

#### First Available Version

API v2.3, IntelliFlash 3.9.0.0

#### Related APIs

getOneMinuteSystemAnalyticsHistory

#### **Parameters**

#### datasets

A dataset can be a pool, project, share, or LUN. The path for each dataset should be in the following format:

```
[pool[/project[/dataset]]]
```

#### **VMs**

Provide the VM name in any of the following formats:

```
[vm-name]
```

```
[pool-name]/[vm-name]

[esx-host]/[vm-name]

[pool-name]/[esx-host]/[vm-name]
```

If multiple VMs match a given name, then all the macthing VMs are included.

# protocols

A protocol name such as NFS, SMB, ISCSI, or FC.

#### Returns

Returns arrays of *DataAnalyticsResult\_V2\_3* objects.

# **Exceptions Thrown**

# **EZEBI\_GENERAL**

This exception is thrown when an internal error is detected.

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown when a non-existent protocol is requested.

### **Examples**

#### **Example 1**

### Request (curl)

#### Response:

```
1527188385000,
    1527188390000,
    1527188395000,
    1527188400000,
    1527188405000,
    1527188410000,
    1527188415000,
    1527188420000,
    1527188425000,
    1527188430000
"datapoints": {
    "Read_Ops": [
        0,
         0,
         Ο,
         Ο,
         Ο,
         0,
         0,
         0,
         0,
         0,
         0,
         0
    ],
"Write_Ops": [
        11\overline{4}3,
        1153,
        1124,
        1122,
        1033,
        1057,
        1136,
        1151,
        1163,
        1156,
        1141,
        1145
    ],
"Read_MBps": [
         0,
         0,
         0,
         0,
         0,
         0,
         0,
         0,
        0,
         0,
         0,
         0
   "Write_Latency": [
    0.52,
         0.57,
         0.51,
         0.54,
         1.88,
         1.34,
```

```
0.52,
     0.59,
     0.5,
     0.51,
     0.52,
    0.53
Total MBps": [
    36.03,
    35.15,
    35.09,
    32.3,
    33.04,
    35.51,
    35.99,
    36.35,
    36.14,
    35.66,
    35.8
],
"Read_Latency": [
    0,
    0,
    0,
     0,
     0,
    0,
    0,
    0,
    0,
    0,
    0,
     0
],
"Total_Ops": [
    11\overline{4}3,
    1153,
    1124,
    1122,
    1033,
    1057,
    1136,
    1151,
    1163,
    1156,
    1141,
    1145
],
"Write_MBps": [
    35.74,
    36.03,
    35.15,
    35.09,
    32.3,
    33.04,
    35.51,
    35.99,
     36.35,
     36.14,
     35.66,
```

```
35.8
        "Average_Latency": [
            0.52,
            0.57,
            0.51,
            0.54,
            1.88,
            1.34,
             0.52,
            0.59,
             0.5,
             0.51,
             0.52,
             0.53
    "averages": {
        "Read Ops": 0,
        "Write Ops": 1127,
        "Read \overline{M}Bps": 0,
        "Write Latency": 0.71,
        "Total MBps": 35.23,
        "Read_Latency": 0,
        "Total Ops": 1127,
        "Write MBps": 35.23,
        "Average Latency": 0.71
    }
},
    "entityType": "DATASET",
    "entityName": "pool-a/nfs2/sh1",
    "timestamps": [
       1527188375000,
        1527188380000,
        1527188385000,
        1527188390000,
        1527188395000,
        1527188400000,
        1527188405000,
        1527188410000,
        1527188415000,
        1527188420000,
        1527188425000,
        1527188430000
    "datapoints": {
        "Read_Ops": [
            0,
            0,
             0,
             0,
             0,
             0,
             Ο,
             0,
             0,
             0,
             0,
             0
```

```
"Write Ops": [
    11\overline{4}3,
    1153,
    1124,
    1122,
    1033,
    1057,
    1136,
    1151,
    1163,
    1156,
    1141,
    1145
],
"Read_MBps": [
    0,
    0,
    0,
    0,
    0,
    0,
    Ο,
    0,
    0,
    0,
    Ο,
    0
],
"Write_Latency": [
    0.57,
    0.51,
    0.54,
    1.88,
    1.34,
    0.52,
    0.59,
    0.5,
    0.51,
    0.52,
    0.53
Total_MBps": [
    35.74,
    36.03,
    35.15,
    35.09,
    32.3,
    33.04,
    35.51,
    35.99,
    36.35,
    36.14,
    35.66,
    35.8
"Read Latency": [
    0,
    0,
    0,
    0,
```

```
0,
         0,
         0,
         Ο,
         Ο,
         Ο,
         Ο,
         0
    ],
"Total_Ops": [
        11\overline{4}3,
        1153,
        1124,
        1122,
        1033,
        1057,
        1136,
        1151,
        1163,
        1156,
        1141,
        1145
    "Write_MBps": [
         35.74,
        36.03,
        35.15,
        35.09,
         32.3,
         33.04,
         35.51,
         35.99,
        36.35,
        36.14,
        35.66,
         35.8
    ],
    "Average_Latency": [
         0.52,
        0.57,
        0.51,
         0.54,
        1.88,
        1.34,
         0.52,
         0.59,
         0.5,
         0.51,
         0.52,
         0.53
    ]
"averages": {
    "Read_Ops": 0,
    "Write_Ops": 1127,
    "Read_MBps": 0,
    "Write_Latency": 0.71, "Total_MBps": 35.23,
    "Read Latency": 0,
    "Total Ops": 1127,
    "Write MBps": 35.23,
```

```
"Average Latency": 0.71
    }
} ,
    "entityType": "PROTOCOL",
    "entityName": "ISCSI",
    "timestamps": [
       1527188375000,
        1527188380000,
        1527188385000,
        1527188390000,
        1527188395000,
        1527188400000,
        1527188405000,
        1527188410000,
        1527188415000,
        1527188420000,
        1527188425000,
        1527188430000
    ],
"datapoints": {
    "Doad Ops":
         "Read_Ops": [
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
        ],
"Write_Ops": [
            0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
         "Read_MBps": [
            0,
             Ο,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
```

```
0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0
Total_MBps": [
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
],
"Total_Ops": [
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
   0,
0,
```

```
0,
             0,
             0,
             Ο,
             0,
             0,
             Ο,
             0,
             0,
             0
         "Average_Latency": [
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0
        ]
    },
    "averages": {
        "Read Ops": 0,
        "Write_Ops": 0,
        "Read \overline{M}Bps": 0,
        "Write_Latency": 0,
        "Total_MBps": 0,
        "Read_Latency": 0,
        "Total_Ops": 0,
         "Write MBps": 0,
         "Average Latency": 0
    }
},
    "entityType": "POOL",
    "entityName": "pool-a",
    "timestamps": [
        1527188375000,
        1527188380000,
        1527188385000,
        1527188390000,
        1527188395000,
        1527188400000,
        1527188405000,
        1527188410000,
        1527188415000,
        1527188420000,
        1527188425000,
        1527188430000
    ],
"datapoints": {
    "Dood Ops":
         "Read Ops": [
             0,
             0,
             0,
             0,
```

```
0,
      0,
      0,
      0,
     0,
     0,
     Ο,
      0
],
"Write_Ops": [
     1153,
     1124,
     1122,
     1033,
     1057,
     1136,
     1151,
     1163,
     1156,
     1141,
     1145
],
"Read_MBps": [
     0,
     0,
     0,
     0,
      0,
     0,
     0,
     0,
     0,
     Ο,
     Ο,
],
"Write_Latency": [
    0.52,
    0.57,
    0.51,
     0.54,
     1.88,
     1.34,
     0.52,
     0.59,
     0.5,
     0.51,
     0.52,
     0.53
],
"Total_MBps": [
     35.74,
     36.03,
     35.15,
     35.09,
     32.3,
     33.04,
      35.51,
     35.99,
      36.35,
```

```
36.14,
     35.66,
     35.8
], "Read_Latency": [
    0,
     0,
     0,
     0,
     0,
     0,
     0,
     0,
     0,
     0,
     Ο,
     0
"Total_Ops": [
    11\overline{4}3,
    1153,
    1124,
    1122,
    1033,
    1057,
    1136,
    1151,
    1163,
     1156,
     1141,
     1145
],
"Write_MBps": [
     35.74,
     36.03,
     35.15,
     35.09,
     32.3,
     33.04,
     35.51,
     35.99,
     36.35,
     36.14,
     35.66,
     35.8
],
"Average_Latency": [
    0.52,
     0.57,
     0.51,
     0.54,
     1.88,
     1.34,
     0.52,
     0.59,
     0.5,
     0.51,
     0.52,
     0.53
]
```

```
"averages": {
        "Read Ops": 0,
        "Write Ops": 1127,
        "Read MBps": 0,
        "Write Latency": 0.71,
        "Total MBps": 35.23,
        "Read Latency": 0,
        "Total Ops": 1127,
        "Write MBps": 35.23,
        "Average Latency": 0.71
    }
},
    "entityType": "PROTOCOL",
    "entityName": "NFS",
    "timestamps": [
        1527188375000,
        1527188380000,
        1527188385000,
        1527188390000,
        1527188395000,
        1527188400000,
        1527188405000,
        1527188410000,
        1527188415000,
        1527188420000,
        1527188425000,
        1527188430000
    ],
"datapoints": {
    "Dand Ops":
        "Read_Ops": [
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             0,
             Ο,
             0,
        "Write_Ops": [
            1143,
            1153,
            1124,
            1122,
            1033,
            1057,
            1136,
            1151,
            1163,
            1156,
            1141,
             1145
        "Read MBps": [
             0,
             0,
```

```
0,
     0,
     0,
     0,
     0,
     0,
     0,
     0,
     0,
     0
],
"Write_Latency": [
     0.57,
     0.51,
     0.54,
    1.88,
    1.34,
     0.52,
     0.59,
     0.5,
     0.51,
     0.52,
     0.53
Total_MBps": [
    35.74,
    36.03,
    35.15,
    35.09,
    32.3,
     33.04,
     35.51,
     35.99,
    36.35,
    36.14,
    35.66,
     35.8
],
"Read_Latency": [
    0,
    0,
     0,
     0,
     0,
     0,
     0,
    0,
     0,
     0,
     Ο,
     0
],
"Total_Ops": [
    11\overline{4}3,
    1153,
    1124,
    1122,
     1033,
    1057,
     1136,
```

```
1151,
                 1163,
                 1156,
                 1141,
                 1145
             "Write_MBps": [
                35.74,
                36.03,
                35.15,
                 35.09,
                 32.3,
                 33.04,
                 35.51,
                 35.99,
                 36.35,
                 36.14,
                 35.66,
                 35.8
             "Average Latency": [
                0.52,
                 0.57,
                 0.51,
                 0.54,
                 1.88,
                 1.34,
                 0.52,
                 0.59,
                 0.5,
                 0.51,
                 0.52,
                 0.53
            ]
        "averages": {
            "Read Ops": 0,
            "Write_Ops": 1127,
            "Read_MBps": 0,
            "Write_Latency": 0.71,
            "Total_MBps": 35.23,
            "Read Latency": 0,
            "Total Ops": 1127,
            "Write_MBps": 35.23,
             "Average Latency": 0.71
        }
   }
]
```

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
null,
```

```
null,
    ["VFS"]
    ]' \
https://198.51.100.10/zebi/api/v2/getOneMinuteDataAnalyticsHistory -k
```

#### **Error Response:**

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "",
  "message": "Unknown protocol requested: 'VFS'",
  "extendedData": {}
}
```

#### Example 3

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
[pool-non-existent],
        [],
        []
        ]' \
  https://198.51.100.10/zebi/api/v2/getOneMinuteDataAnalyticsHistory -k
```

#### **Error Response:**

```
"code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Invalid dataset requested: 'pool-non-existent'",
   "extendedData": {}
}
```

# Chapter 14

### **Notification Methods**

#### **Topics:**

- acknowledgeNotifications
- getRecentNotifications
- getRecentCriticalNotifications
- listNotifications

The following sections describe notification methods, parameters, return types, and examples.

#### acknowledgeNotifications

This API acknowledges all records that match the following conditions:

- The specified period
- Priority (API acknowledges notifications that exceed the specified priority)
- Event code filter (API acknowledges all notifications that match the filter)

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

#### **Parameters**

#### startTime

String which represents the start time from which the system should query the notifications. If specified, the start time date format should be as follows:

YYYY-MM-DDTHH: MM (RFC3339 date format)

A null or empty string start time is an acceptable value.

#### endTime

String which represents the end time from which the system should query the notifications. If specified, the start time date format should be as follows:

YYYY-MM-DDTHH: MM (RFC3339 date format)

A null or empty string start time is an acceptable value.



- If the startTime and endTime are both specified, the system acknowledges all the records that match the query of eventTime greater than or equal to startTime and eventTime lesser than or equal to endTime.
- If the startTime is not specified and endTime is specified, the system acknowledges all the records that match the query of eventTime lesser than or equal to endTime.
- If the startTime is not null or empty and endTime is null or empty, the system acknowledges all the records where eventTime is greater than or equal to startTime.
- If both the startTime and endTime are null or empty, the system acknowledges all the records.

#### **IowestPriority**

A string which represents the minimum priority. Accepted values: 'LOW', 'MEDIUM', 'HIGH', 'CRITICAL.'

#### eventCodeFilter

A string representing the event code. For example, "SNP", "POL". A null filter value will return all results.

#### Returns

An integer that represents the actual number of notifications acknowledged.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This error is thrown if the priority is not a known value, or if the start and end dates are not valid.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[null, "", "LOW", null]' \
  https://198.51.100.10/zebi/api/v2/acknowledgeNotifications
```

#### Response

200

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[null, "", "VERY LOW", null]' \
  https://198.51.100.10/zebi/api/v2/acknowledgeNotifications
```

#### **Error Response**

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "acknowledgeNotifications.arg2 value 'VERY LOW':
  Invalid priority requested:'VERY LOW'",
  "message": "Invalid priority requested: 'VERY LOW'",
  "extendedData": {
      "EX_CAUSE_MESSAGE": null
}
```

getRecentNotifications

Returns the most recent events within the specified duration that exceed the specified priority and match the event code filter.

#### First Available Version

API v2.3, IntelliFlash 3.9.0.0

#### **Related APIs**

getRecentCriticalNotifications

#### **Parameters**

#### durationInMinutes

The duration in minutes.

#### **IowestPriority**

Minimum priority. Accepted values are LOW, MEDIUM, HIGH, and CRITICAL. The values are case sensitive.

#### eventCodeFilter

Free-text filter for event code. For example, SNP and POL. A null filter value returns all results.

#### Returns

Returns an array of *Notification\_V2\_3* objects.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the priority is not a known value, or if the duration is zero or negative.

#### **Examples**

#### **Example 1**

#### Request (curl)

```
curl -X POST \
  -H 'authorization: Basic Auth TOKEN \
```

```
-H 'cache-control: no-cache' \
-H 'content-type: application/json' \
-d '[
    8400,
    "CRITICAL",
    ""
    ]' \
https://198.51.100.10/zebi/api/v2/getRecentNotifications -k
```

#### Response:

```
[
       "timestamp": 1536728451968,
        "eventCode": "DSK2208W22011",
        "priority": "Critical",
        "description": "JBOD Information mismatch across ha controllers for
jbod with chasis serial: 1123581321345589.",
        "errorMessage": null,
        "details": {
            "User": "SYSTEM",
            "Message": "Controller-A: [Chasis Id = TS1406-0090, Model = ]",
            "Controller-B": "[Chasis Id = ST1403-0036, Model = ]"
    },
        "timestamp": 1536728417815,
        "eventCode": "DSK2208W22011",
        "priority": "Critical",
        "description": "JBOD Information mismatch across ha controllers for
jbod with chasis serial: 1123581321345589.",
        "errorMessage": null,
        "details": {
            "User": "SYSTEM",
            "Message": "Controller-A: [Chasis Id = TS1406-0090, Model = ]",
            "Controller-B": "[Chasis Id = ST1403-0036, Model = ]"
       }
    },
       "timestamp": 1536693680334,
       "eventCode": "CTR3600E36001",
        "priority": "Critical",
        "description": "Controller '2400-b' is down.",
        "errorMessage": null,
        "details": {
            "User": "SYSTEM",
            "Host 2": "2400-b",
            "Host 1": "2400-a"
       }
    },
       "timestamp": 1536693568659,
        "eventCode": "CTR3600E36001",
        "priority": "Critical",
        "description": "Controller '2400-a' is down.",
        "errorMessage": null,
        "details": {
            "User": "SYSTEM",
```

```
"Host 2": "2400-a",
"Host 1": "2400-b"
}
```

#### Example 2

#### **Erroneous Request (curl)**

#### **Error Response:**

### getRecentCriticalNotifications

Returns the most recent critical events within the specified duration.

#### First Available Version

API v2.3, IntelliFlash 3.9.0.0

#### **Related APIs**

getRecentNotifications

# Parameters durationInMinutes

The duration in minutes.

#### Returns

Returns an array of *Notification\_V2\_3* objects.

# Exceptions Thrown EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the duration is zero or negative.

#### **Examples**

#### **Example 1**

#### Request (curl)

#### Response:

```
[
        "timestamp": 1532602657656,
        "eventCode": "DSK2204E23001",
        "priority": "Critical",
        "description": "Disk error occurred. A disk read error occurred.",
        "errorMessage": null,
        "details": {
            "VdevDevId": "id1,kdev@w000cca0b01a37e80/a",
            "Product Id": "N5200-D1",
            "User": "SYSTEM",
            "Message": "Disk error occurred. A disk read error occurred.",
            "Make": "HGST-HUSMR7619BDP3Y1",
            "Fault Disk Information": "Unavailable",
            "Chassis Id": "TG1806-1002",
            "VdevType": "disk",
            "Server Id": "NVMe-B",
            "PoolName": "pool-2",
            "VdevPath": "/dev/dsk/c8t000CCA0B01A37E80d0s0",
"ParentType": "--",
            "RecordBy": "SystemMonitor"
       }
   },
        "timestamp": 1532595977954,
        "eventCode": "DSK2204E23001",
        "priority": "Critical",
        "description": "Disk error occurred. A disk read error occurred.",
```

```
"errorMessage": null,
    "details": {
        "VdevDevId": "id1,kdev@w000cca0b01a37e80/a",
        "Product Id": "N5200-D1",
        "User": "SYSTEM",
        "Message": "Disk error occurred. A disk read error occurred.",
        "Make": "HGST-HUSMR7619BDP3Y1",
        "Fault Disk Information": "Unavailable",
        "Chassis Id": "TG1806-1002",
        "VdevType": "disk",
        "Server Id": "NVMe-B",
        "PoolName": "pool-2",
        "VdevPath": "/dev/dsk/c8t000CCA0B01A37E80d0s0",
        "ParentType": "--",
        "RecordBy": "SystemMonitor"
   }
},
   "timestamp": 1532595438903,
   "eventCode": "DSK2204E23001",
   "priority": "Critical",
   "description": "Disk error occurred. A disk read error occurred.",
   "errorMessage": null,
    "details": {
        "VdevDevId": "id1, kdev@w000cca0b01a37e80/a",
        "Product Id": "N5200-D1",
        "User": "SYSTEM",
        "Message": "Disk error occurred. A disk read error occurred.",
        "Make": "HGST-HUSMR7619BDP3Y1",
        "Fault Disk Information": "Unavailable",
        "Chassis Id": "TG1806-1002",
        "VdevType": "disk",
        "Server Id": "NVMe-B",
        "PoolName": "pool-2",
        "VdevPath": "/dev/dsk/c8t000CCA0B01A37E80d0s0",
        "ParentType": "--",
        "RecordBy": "SystemMonitor"
   }
},
   "timestamp": 1532502366523,
   "eventCode": "DSK2204E23001",
   "priority": "Critical",
   "description": "Disk error occurred. A disk read error occurred.",
   "errorMessage": null,
    "details": {
        "VdevDevId": "id1, kdev@w000cca0b01a37e80/a",
        "Product Id": "N5200-D1",
        "User": "SYSTEM",
        "Message": "Disk error occurred. A disk read error occurred.",
        "Make": "HGST-HUSMR7619BDP3Y1",
        "Fault Disk Information": "Unavailable",
        "Chassis Id": "TG1806-1002",
        "VdevType": "disk",
        "Server Id": "NVMe-B",
        "PoolName": "pool-2",
        "VdevPath": "/dev/dsk/c8t000CCA0B01A37E80d0s0",
        "ParentType": "--",
        "RecordBy": "SystemMonitor"
   }
```

]

#### Example 2

#### **Erroneous Request (curl)**

```
curl -X POST \
  -H 'authorization: Basic Auth_TOKEN \
  -H 'cache-control: no-cache' \
  -H 'content-type: application/json' \
  -d '[
    0
    ]' \
https://198.51.100.10/zebi/api/v2/getRecentCriticalNotifications -k
```

#### **Error Response:**

```
{
   "code": "EZEBI_INVALID_ARGUMENT",
   "details": "",
   "message": "Invalid duration: '0' minutes",
   "extendedData": {}
}
```

#### **listNotifications**

Returns notifications based on the following conditions:

- The specified period
- Priority (API returns notifications that exceed the specified priority)
- Event code filter (API returns notifications that match the filter)
- · Notifications acknowledged or not

The listNotifications API returns a maximum of 200 records per call.

#### First Available Version

API v2.4, IntelliFlash 3.10.x.x

### **Parameters**

#### startTime

String which represents the start time from which the system should query the notifications. If specified, the start time date format should be as follows:

YYYY-MM-DDTHH: MM (RFC3339 date format)

A null or empty string start time is an acceptable value.

#### endTime

String which represents the end time from which the system should query the notifications. If specified, the start time date format should be as follows:

YYYY-MM-DDTHH: MM (RFC3339 date format)

A null or empty string start time is an acceptable value.

- If the startTime and endTime are both specified (i.e not null and not empty), the system returns all the records where eventTime is greater than or equal to startTime and eventTime is lesser than or equal to endTime.
- If the startTime is null or empty and endTime is not null or empty, the system returns all the records where eventTime is lesser than or equal to endTime.
- If the startTime is not null or empty and endTime is null or empty, the system returns all the records where eventTime is greater than or equal to startTime.
- If both the startTime and endTime are null or empty, the system returns all the records.

#### **IowestPriority**

A string which represents the minimum priority. Accepted values: 'LOW', 'MEDIUM', 'HIGH', 'CRITICAL.'

#### eventCodeFilter

A string representing the event code. For example, "SNP", "POL". A null filter value returns all results.

#### requiresAckOnly

A Boolean that determines whether or not the notification has been acknowledged. If not specified (i.e. null) or set to **false**, the system returns records that have NOT been acknowledged. If set to **true**, the system returns all the records that have been acknowledged.

#### Returns

Returns array of *Notification\_V2\_3* object.

#### **Exceptions Thrown**

#### EZEBI\_INVALID\_ARGUMENT

This exception is thrown if the priority is not a known value, or if the start and end dates are not valid.

#### **Examples**

#### Example 1

#### Request (curl)

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[null, null, "LOW", null, null]' \
  https://198.51.100.10/zebi/api/v2/listNotifications
```

#### Sample Response

#### Example 2

#### **Erroneous Request**

```
curl -X POST -H "Authorization:Basic Auth_TOKEN" \
  -H Content-Type:application/json \
  -d '[null, null, "VERY LOW", null, null]' \
  https://198.51.100.10/zebi/api/v2/listNotifications
```

#### **Error Response**

```
"code": "EZEBI_INVALID_ARGUMENT",
  "details": "listNotifications.arg2 value 'VERY LOW':
  Invalid priority requested: 'VERY LOW'",
  "message": "Invalid priority requested: 'VERY LOW'",
  "extendedData": {
        "EX_CAUSE_MESSAGE": null
   }
}
```

## Chapter 15

### **Objects**

#### Topics:

- ArrayUpgrade\_V2\_1
- AuditConfig V2 6
- AuditDataset\_V2\_6
- CopyDestination\_V2\_1
- CopySource\_V2\_1
- CopyStatus\_V2\_1
- DataAnalyticsResult\_V2\_3
- DatasetProperty\_V2\_1
- DatasetSpaceInfo\_V2\_1
- DatasetStatus
- Disk\_V2\_1
- FCInitiator\_V2\_1
- FCTarget\_V2\_1
- FloatingIP\_V2\_2
- InitiatorGroup\_V2\_1
- *Iscsilnitiator\_V1\_0*
- ISCSIInitiator\_V2\_1
- ISCSITarget\_V2\_1
- ISCSITargetCreate\_V2\_1
- ITView\_V2\_1
- LocalGroup\_V1\_2
- LocalUser\_V1\_2
- LunStatus
- Mapping\_V2\_4
- NasAuditState
- NetworkACL\_V2\_1
- Notification\_V2\_3
- Notification\_V2\_6
- Pool\_V1\_0
- PoolSpaceInfo\_V2\_1
- Project\_V1\_0
- Project\_V1\_2
- Project\_V2\_1
- Project\_V2\_4
- ProjectCloneProgressStatus\_v1\_2
- ReplicationConfig\_V1\_2
- ReplicationStatus\_v1\_2

The following sections describe the objects used by the IntelliFlash API.

- Schedule\_V2\_1
- Share\_V1\_0
- Share\_V2\_1
- Share\_V2\_4
- ShareOptions
- SharePermissions
- SharePermissions\_V2\_6
- SMBConfig\_V2\_2
- SnapShotDeletionStatus
- SnapshotProgressStatus
- SnapshotSchedule\_V2\_1
- SNMP\_Setting\_V2\_1
- SyncReplicationPeerConfig\_V2\_5
- SyncReplicationPoolPairConfig\_V2\_5
- SyncReplicationQuorumConfig\_V2\_5
- SyncReplicationSetUp\_V2\_5
- SyncReplicationStatus\_V2\_5
- SystemAnalyticsResult\_V2\_3
- TargetGroup\_V2\_2
- Volume\_V1\_0
- Volume\_V2\_1
- Volume\_V2\_4
- UserACL (Read Only) v2.1

### ArrayUpgrade\_V2\_1

This class represents the upgrade and install history of the array. Each object instance is one IntelliFlash OS install or upgrade.

Field	Туре	Description
Version	String	Version of the install or upgrade.
timeInstalledOnNodeA	String	Date and time the upgrade or install was done for node A.
timeInstalledOnNodeB	String	Date and time the upgrade or install was done for node B.

### AuditConfig\_V2\_6

Field	Туре	Description
auditDatasets	List <auditdataset_v2_6></auditdataset_v2_6>	Audit datasets (i.e. shares) that have audit logging files that can be consumed by a customer to process (e.g. SACL audit operations, such as, user X opened file AB1, etc.). Each audit dataset object contains the attributes of the share like quota, log retention, space used, name, mountpoint etc.
accessProtocols	List <string></string>	Access protocols on audit logging shares (SMB or NFS).
userPermissions	List <sharepermissions_v2_6></sharepermissions_v2_6>	User-Group permission ACLs on audit logging shares.
nfsNetworkAcls	List <networkacl_v2_1></networkacl_v2_1>	NFS network ACLs on audit logging shares.
smbNetworkAcIs	List <networkacl_v2_1></networkacl_v2_1>	SMB network ACLs on audit logging shares.
warning	String	Errors and warnings detected reading the audit configuration.

### AuditDataset\_V2\_6

Field	Туре	Description
poolName	String	Pool that has the audit logging dataset (e.g. share).

Field	Туре	Description
name	String	Dataset name (e.g. share name) that has audit logs generated on it.
auditQuota	Double	Quota (or maximum allowed size) of the audit logging share.
quotaMetric	String	Quota metric of the audit logging share.
usedSpace	Double	Space used in the audit logging share.
totalSpace	Double	Current total space of the audit logging share.
datasetPath	String	Path to the audit logging dataset (e.g. share).
mountPoint	String	Mount point of the audit logging dataset (e.g. share).
cifsDisplayName	String	SMB display name for the audit logging dataset (e.g. share).
logRetentionDays	Long	Log retention (in days) on the audit logging dataset (e.g. share).
spaceCriticalThreshold	Integer	Critical space threshold utilization percent on the audit logging dataset (e.g. share), before a warning is generated.
spaceWarningThreshold	Integer	Warning space threshold utilization percent on the audit logging dataset (e.g. share), before a warning is generated.
spaceThresholdConfigured	Boolean	Indicates dataset (e.g. share) space threshold overrides pool-default threshold.
accessProtocols	List <string></string>	Protocols (SMB or NFS) used to access the audit logging dataset (e.g. share).

### CopyDestination\_V2\_1

Object defining destination datasets.

Field	Description	
hostName	Destination partner system name.	
	Leave this field empty for same array.	
poolName	Destination pool.	
projectName	Destination project.	

Field	Description
subProjectNamePrefix	Destination sub project name prefix.  Leave this field empty for project copy.
subProjectNameNumberStart	Destination sub project name suffix start. The value should be a number.
subProjectNameNumberEnd	Destination sub project name suffix end. The value should be a number.
subProjectNameWildcard	Destination sub project name wildcard (bash style).

### CopySource\_V2\_1

Object defining the source dataset.

Field	Description
poolName	Source dataset pool.
projectName	Source dataset project.
subProjectName	Source sub project name.
	Leave this field empty for project copy.

### CopyStatus\_V2\_1

Object representing the current status of the copy operation.

Field	Description
completedCopies	Completed copies for the task.

Field	Description
status	Current status of the task.
	It has the following values:
	Unknown
	Start
	Connected
	Sending
	Local Replication
	Completed
	Error
	Paused
allDatasets	All datasets created by the task.
completedDatasets	Datasets completed by the task.
pendingDatasets	Datasets yet to be created by the task.
percentComplete	Percentage of task completion.
errorCode	Error code of the task, if there is any error.
startTime	Start time of the task.
endTime	End time of the task.

### DataAnalyticsResult\_V2\_3

Field	Туре	Description
entityType	String	Data entity type.
		Possible values are VM, Dataset, Project, Pool, and Protocol.
entityName	String	Data entity name.
		For a dataset, pool, or a project, this is a path with the [pool[/project[/dataset]]] format.
		For a VM, this is a VM path with the [pool]/[esx-host]/[vm-name] format.
		For a protocol, this is a protocol name, such as NFS, SMB, ISCSI, or FC.

Field	Туре	Description
timestamps	Array of longs	Milliseconds since Unix epoch (midnight Jan 1 1970).
Datapoints	Map (String >Array of numbers)	Datapoint list mapping. Each datapoint list has one element per timestamp. Possible values are Read_MBps, Write_MBps, Read_IOPs, Write_IOPs, Read_Latency, and Write_Latency.
Averages	Map (String >Array of numbers)	Averages of the datapoint listings.

### DatasetProperty\_V2\_1

Field	Description
propertyKey	Key of the property
propertyValue	Value of the property

### DatasetSpaceInfo\_V2\_1

Field	Description
originalUsedByDataAndSnapshot	Original used by dataset data and snapshot before compression (bytes).
usedByDataAndSnapshot	Amount used by the dataset data and snapshot after compression (bytes).
compressionSavingsPercentage	Amount saved from compression as a percentage.
available	For datasets with a quota, this represents the amount of space remaining in the quota.
	For shares and luns without a quota, this represents the amount of space remaining in the project's quota (if it exists).
	If a quota does not exist on a project, this value represents the amount of space (in bytes) remaining on the pool.
usedByData	Amount used by this dataset's data after compression (bytes).
usedBySnapshot	Amount used by this dataset's snapshots after compression (bytes).

Field	Description
usedByReservation	Share and project field. Amount used by reservation (bytes).
quota	Share and project field. The user assigned quota for the dataset (bytes). The quota is 0 if it doesn't exist.
volSize	Volume only field. The size of the volume (bytes).

### **DatasetStatus**

Field	Туре	Description
cleanupException	String	Contains details of the exception, if an exception occurs.
cleanupStatus	Integer	An integer return value as defined in CLEANUP_STATUS.
commandException	String	Contains details of the exception, if an exception occurs.
commandStatus	Integer	An integer return value as defined in COMMAND_STATUS.
datasetPath	String	A string that contains the dataset path. A dataset path should have the format PoolName/Local/ProjectName/VolumeName for volumes and PoolName/ Local/ProjectName/ShareName for shares.
overwriteException	String	Contains details of the exception, if an exception occurs.
overwriteStatus	Integer	An integer value as defined in OVERWRITE_STATUS.

### Disk\_V2\_1

Field	Туре	Description
diskChassisIndex	Integer	Index of the chassis to enumerate, as listed by getDisks API.
diskBayIndex	Integer	Disk bay index relative to each disk chassis (as listed by the Web UI, and is zero relative).

Field	Туре	Description
diskChassisName	String	Name of the disk chassis as given by
		Web UI
		serial number [chassis name]
diskSize	String	Disk size with units (for example, 2TB).
poolName	String	Pool that is using the disk currently.
diskType	String	Disk type (for example, HDD, RW_META_SSD, or NVMe).
diskAlias	String	Disk name used to identify the disk.
		For example, "c2t5000CCA013067A90d0".
deviceId	String	Disk device id that is unique across array controllers.

### FCInitiator\_V2\_1

This class represents the initiator for the FC protocol.

Field	Туре	Description
initiatorName	String	Initiator name (for example, "wwn.5001438001FFAAAA" ).
initiatorGroupName	String	Initiator group name.

### FCTarget\_V2\_1

This class represents the target for the FC protocol.

Field	Туре	Description	
targetName	String	Target name (for example, "wwn.21000024FF236C15")	
targetStatus	String	Target status (for example, "online" or "offline").	
targetNode	String	Node (or IntelliFlash controller) where the target is active.	
targetGroupName	String	Target group name.	
targetSpeed	String	Target speed (for example, 4GB, 8GB, or "not established").	
targetPortType	String	Whether the target port type is HBA or NPIV.	

### FloatingIP\_V2\_2

Field	Туре	Description
resourceGroupName	String	The name of the resource group.
failoverMode	String	Lists the condition for a failover.
		The failover condition can be Immediately, Never, or Wait till all IP addresses fail.
ipAddress	String	The floating IP addresses.
netmask	String	The netmask of the floating IP address.
poolName	String	Pools associated with this IP address.

### InitiatorGroup\_V2\_1

Field	Туре	Description
initiatorGroupName	String	Initiator group name as listed in the Web UI.
intendedProtocol	String	The protocol the initiator group is configured to use (e.g. iSCSI, FC, or Unknown)

### Iscsilnitiator\_V1\_0

Field	Туре	Description
chapSecret	String	Optional CHAP secret if the initiator uses CHAP for authentication.
chapUserName	String	Optional CHAP username if the initiator uses CHAP for authentication.
initiatorName	String	Standard initiator names can have either of these two formats:  • iqn.yyyy-mm.[reverse-domain-name]  • eui.02004567A425678D (EUI-64 identifier - 16 ASCII-encoded hexadecimal digits)
		The characters ,, /,\ !, ?, @, <, >, #, \$, ',%, ^,*, (, ), ~,+, =, }, , {, [, ], ;, \', \", _, & are not allowed in initiatorgroupname. The empty and space characters and the null values are not allowed in initiatorgroupname.

### ISCSIInitiator\_V2\_1

This class represents the ISCSI initiator attributes.

Field	Туре	Description	
initiatorName	String	Initiator Name (iqn or eui iscsi name)	
		This must be in the iqn.yyyy.mmm.[reverse-domain-name]:unique-name or eui.16-hexadecimal-digits and no more than 255 characters.	
initiatorGroupName	String	Initiator or host group name.	
		This cannot have special characters such as '', *, #, /, \ !, @, $\sim$ , (, ), [, ], {, }, =, and %. The string must be between 1 to 512 characters long.	
chapUserName	String	Optional chap user name if the initiator uses chap for authentication.	
		If specified this chap user name can't be blank or cannot have special characters such as ' ', \ /, !, #, \$, %, ^, &, *, (, ), :, ;, and @.	
chapSecret String		Optional chap secret if the initiator uses CHAP authentication. This is only used on write-modify-create methods. The string is always null or empty for read methods.	
		The chap secret must between 12 and 16 characters if specified, and cannot have special characters such as such as ', \ /, !, #, \$, %, ^, &, *, (, ), :, ;, and @.	

### ISCSITarget\_V2\_1

This class represents the target for the iSCSI protocol and is returned when enumerating iSCSI targets.

Field	Туре	Description
targetName	String	This is the full ISCSI target name enumerated in the format:
		<pre>iqn.yyyy-mm.[reverse-domain-name]:user- specified-suffix.</pre>

Field	Туре	Description
targetSuffixName	String	Target suffix or user-specified portion of the iSCSI target name after the iqn colon.
		For example, iqn.2012-12.com.tegile:targetSuffixName.
targetAlias	String	Target Alias, as alternate user friendly name of target.
		This is often the same as the target name suffix.
targetGroupName	String	Target group name.
targetAuthenticationMode	String	Target authentication type.
		The values must be 'none', 'chap', or 'mutual' string names.
		'none' indicates no user or password required, 'chap' indicates one way authentication (no user or password required), 'mutual' is two way authentication (provide chap user and secret).
targetChapName	String	User name for the chap authentication. Only required if 'mutual' chap authentication is chosen.
targetChapSecret	String	Password for the chap authentication. Only required if 'mutual' chap authentication is chosen.
targetNetworkBinding	String[]	Network binding string (ip:port) indicating the network ports to bind the target with.

### ISCSITargetCreate\_V2\_1

This class represents the target for iSCSI protocol and can be used to create an iSCSI target.

Field	Туре	Description
targetSuffixName	String	Target suffix. This is just the user specified portion of the iSCSI target name after the iqn colon.
		For example, iqn.2012-12.com.tegile:targetSuffixName.
		This cannot have special characters such as '',*,#,/,\!,@,~, (,),[,],{,},=, and %. The string must be between 1 to 255 characters long.
targetAlias	String	Target Alias, as alternate user friendly name of target (often same as target name suffix).
targetGroupName	String	Target group name
		This cannot have special characters such as *, #, /, \ !, @, $\sim$ , (, ), [, ], {, }, =, and %. The string must be 1 to 512 characters long.
targetAuthenticationMode	String	Target authentication type, which must be 'none', 'chap', or 'mutual' string names.
		'none' indicates no user or password required, 'chap' indicates one way authentication (no user or password required), and 'mutual' is two way authentication (provide chap user and secret).
targetChapName	String	Optional user name for the chap authentication.
		Only required if 'mutual' chap authentication was chosen. If specified this chap user name can't be blank or cannot have special characters such as ' ', \ /, !, #, \$, %, ^, &, *, (, ), :, ;, and @.
targetChapSecret	String	Optional password for the chap authentication.
		Only required if 'mutual' chap authentication is chosen. This is only set on write or modify operations. For read operations, this string is null. The chap secret must between 12 and 16 characters if specified, and cannot have special characters such as '', \ /, !, #, \$, %, ^, &, *, (, ), :, ;, and @.

Field	Туре	Description
targetNetworkBinding	String[]	Network Binding (in ip:port format) string indicating the network ports to bind target with.

## ITView\_V2\_1

Field	Туре	Description
hostGroupName	String	Name of the host group
targetGroupName	String	Name of the target group
lunNbr	Integer	LUN number associated with the mapping. Populated with the default lun number -1 for project default mappings
readOnly	Boolean	Flag that indicates whether the view is read only. True for read only, false for read-write.

# LocalGroup\_V1\_2

Field	Туре	Description
groupId	Integer	Group ID of the group
groupName	String	Name of the group
userList	List	List of users associated to the group

## LocalUser\_V1\_2

Field	Туре	Description
groupId	Integer	Group ID of the group
groupName	String	Name of the group
userld	Integer	User ID of the user
userName	String	Name of the user

#### **LunStatus**

Field	Туре	Description
accessState	Integer	An integer indicating whether the LUN is:
		• active (0)
		<ul><li>active to standby (1)</li><li>standby (2)</li></ul>
		• standby to active (3)
alias	String	The LUN alias, if specified.
blockSize	String	The block size of the LUN.
commandException	String	Contains details of the exception, if an exception occurs.
commandStatus	Integer	An integer return value as defined in COMMAND_STATUS.
dataFile	String	The data file path for the LUN.
datasetPath	String	A string that contains the path to the dataset. The dataset path should have the format PoolName/Local/ProjectName/VolumeName for LUNs.
guid	String	The lunld of the LUN.
metaFile	String	The meta file path of the LUN.
mgmtURL	String	The management URL of the LUN.
operationalStatus	Integer	Operational status of the LU.
		Stmf (SCSI target mode framework) logical unit offline (0)
		Stmf logical unit offlining (1)
		Stmf logical unit online (2)     Stmf logical unit online (2)
		<ul><li>Stmf logical unit onlining (3)</li><li>Stmf logical unit unregistered (4)</li></ul>
productId	String	Field not used.
serialNumber	String	Field not used.
size	String	The size of the LUN.
vendorld	String	Field not used.
viewCount	Integer	The number of mappings defined for the LUN.
writeCacheDisable	Boolean	A boolean that indicates if the data write cache is disabled.

Field	Туре	Description
writeProtect	Boolean	A boolean that indicates if write protect is enabled or disabled.
		The values are as follows:
		<ul><li>Read-Only (True)</li><li>Write (False)</li></ul>

### Mapping\_V2\_4

This class represents the existing mappings for the specified volume path. Each object instance is one IntelliFlash OS install or upgrade.

Table 2: Mapping \_V2\_4

Field	Туре	Descripition
initiatorGroupName	String	Name of the initiator group
targetGroupName	String	Name of the target group
lunNbr	Integer	The LUN number associated with the mapping. The default LUN number for project default mappings is -1.
readOnly	Boolean	Flag that indicates whether the mapping is read only. True if read only, False if read-write.

#### **NasAuditState**

Field	Туре	Description
UPDATE_AUDITLOGS_NOTSTARTED	enum - 0	Update audit logs has not started yet.
UPDATE_AUDITLOGS_STARTED	enum - 1	Update audit logs started.
UPDATE_AUDITLOGS_DONE	enum - 2	Update user audit logs completed.
UPDATE_AUDITLOGS_FAILED	enum - 3	Update user audit logs failed.
UPDATE_AUDITLOGS_TIMEDOUT	enum - 4	Update user audit logs timedout.

### NetworkACL\_V2\_1

Field	Туре	Description
hostType	String	Type of network ACL host, IP address or FQDN.
host	String	Host to which access is provided.
accessMode	String	Access mode: 'ro' for read-only access or 'rw' for read-write access.
rootAccessForNFS	String Flag that indicates whether the NFS ACL has root	
		Note: This is applicable only for NFS ACLs.

## Notification\_V2\_3

Field	Туре	Description
timestamp	Long	Milliseconds since Unix epoch (midnight Jan 1 1970).
eventCode	String	Event-unique code.
priority	String	Priority. Possible values are LOW, MEDIUM, HIGH, or CRITICAL.
description	String	Event description or subject.
errorMessage	String	Error message (if applicable).
details	Map of key- value pairs	Key value mapping of event-specific details.

#### Notification\_V2\_6

Field	Туре	Description
timestamp	Long	Timestamp in milliseconds since epoch
eventCode	String	Event-unique code
priority	String	Priority: 'Low', 'Medium', 'High', or 'Critical'
description	String	Event description or subject
errorMessage	String	Error message (if applicable)
details	Map <string, String&gt;</string, 	Key-Value mapping of event-specific details
state	String	State of the event

Field	Туре	Description
subState	String	Sub-state of the event

## Pool\_V1\_0

Field	Туре	Description
availableSize	Long	The available size of the pool in bytes.
name	String	Name of the storage pool.
totalSize	Long	The total size of the pool in bytes.

## PoolSpaceInfo\_V2\_1

Field	Description
totalPoolSize	Total size of the pool (bytes).
originalUsedByDataAndSnapshot	Original used by data and snapshot before compression and deduplication (bytes).
usedByDataAndSnapshot	Amount used by data and snapshot after compression and deduplication (bytes).
compressionSavingsPercentage	Amount saved from compression as a percentage.
dedupeSavingsPercentage	Amount saved from deduplication as a percentage.
totalSavingsPercentage	Amount saved from compression and deduplication as a percentage.
usedByAll	Amount used for data and reservation (bytes).
available	Amount of available space left on the pool (bytes).
usedByData	Amount used by data after compression and deduplication (bytes).
usedByReservation	Amount used by reservation (bytes).
usedBySnapshot	Amount used by snapshot after compression and deduplication (bytes).
totalMetaSize	Total metadata size (bytes).
usedMeta	Used metadata (bytes).

### Project\_V1\_0

Field	Туре	Description
local	Boolean	Indicates whether the project belongs to the current array.
name	String	Name of the project.
poolName	String	The pool in which the project exists.

## Project\_V1\_2

Field	Туре	Description
local	boolean	Indicates whether the project belongs to the current array.
name	String	Name of the project.
poolName	String	The pool in which the project exists.

## Project\_V2\_1

Field	Description
poolName	Name of the pool.
	This field is mandatory while creating a project. The field becomes read only after creation.
projectName	Name of the project.
	This field is mandatory while creating a project. The field becomes read only after creation.
localDataset	Indicates whether it is a local project or a replica from a remote system.
	True indicates local, while False indicates replica.
	This field is read only.
purpose	Purpose of the project.
	Project created by createProject API has a "generic" purpose.
	This field is read only.
mountPoint	Mount point of the project on file system.

Field	Description
compression	Compression algorithm applied on the project.
	Supported values:
	• off
	<ul><li>Izjb</li><li>gzip-2</li></ul>
	• gzip-2
	• gzip-9
	Iz4 (default)
compressedLog	Log compression algorithm for the project.
	Supported values:
	• Iz4
	off (default)
intendedProtocolList	Adds protocol features to the project. This field is a list of string values, and is read only.
	The default value is "NFS, SMB, FC, iSCSI". The value can also be a combination of any of the following protocols:
	• FC
	iSCSI     NFS
	• SMB
	Note: After you create a project, you cannot dynamically modify this property.
quotalnByte	Enables quota on the project if intended for NFS use.
	The value should be greater than or equal to 1 MB (1048576 bytes). When setting this value to 0, no quota is assigned to the project.
quotaEnabled	Checks whether quota is enabled on the project.
	This field is read only.
quota	Quota number.
	This field is read only.
quotaMetric	Quota metric unit.
	This field is read only.

Field	Description
dedup	Turns on or off deduplication on the project.
	Supported values:
	on (default)
	• off
copies	Specifies number of the project copies.
	Supported values:
	1 (default)
	• 2 • 3
nrimarı (Caaba	
primaryCache	Specifies primary cache type.  Supported values:
	All (default)
	None
	Metadata
secondaryCache	Specifies secondary cache type.
	Supported values:
	All (default)
	None     Metadata
readonly	Specifies whether project is read only.
	Supported values:
	On Off
La phia a	
logbias	Specifies log bias type.
	Supported values:
	<ul><li>Latency (default)</li><li>Throughput</li></ul>
aclInherit	Turns on or off ACL inheritance on the project.
Commont	Supported values:
	On (default)
	Off  Off
	1

Field	Description
aclMode	Checks the ACL mode on the project.
	This field is read only.
krbStatus	Checks the krb status if SMB is enabled.
	This field is read only.
defaultVolumeSizeInByte	Default volume size.
	The value should be greater than or equal to 1 MB (1048576 bytes). The default value is 1 GB.
defaultVolumeSize	Volume size number.
	This field is read only.
defaultVolumeSizeUnit	Volume size unit.
	This field is read only.
defaultVolumeBlockSize	Sets default volume block size.
	Supported values:
	• 4 KB
	• 8 KB
	<ul><li>16 KB</li><li>32 KB (default)</li></ul>
	• 64 KB
	• 128 KB
defaultThinProvisioning	Sets default thin provisioning for volume. The value is either True or False.
sync	Checks synchronization mode.
zfsDataSetName	Returns ZFS dataset path name.
	This field is read only.
recordSize	Default share block size.
	Supported values:
	• 4 KB
	8 KB     16 KB
	16 KB     32 KB (default)
	• 64 KB
	• 128 KB

### Project\_V2\_4

Field	Description
poolName	Name of the pool.
	This field is mandatory while creating a project. The field becomes read only after creation.
projectName	Name of the project.
	This field is mandatory while creating a project. The field becomes read only after creation.
localDataset	Indicates whether it is a local project or a replica from a remote system.
	True indicates local, while False indicates replica.
	This field is read only.
purpose	Purpose of the project.
	Project created by createProject API has a "generic" purpose.
mountPoint	Mount point of the project on file system.
compression	Compression algorithm applied on the project.
	Supported values:
	• off
	• Izjb
	• gzip-2
	<ul><li>gzip</li><li>gzip-9</li></ul>
	• Iz4 (default)
compressedLog	Log compression algorithm for the project.
	Supported values:
	• Iz4
	off (default)

Field	Description
intendedProtocolList	Adds protocol features to the project. This field is a list of string values, and is read only.
	The default value is "NFS, SMB, FC, iSCSI". The value can also be a combination of any of the following protocols:
	FC ISCSI
	NFS     SMB
	Note: After you create a project, you cannot dynamically modify this property.
quotalnByte	Enables quota on the project if intended for NFS use.
	The value should be greater than or equal to 1 MB (1048576 bytes). When setting this value to 0, no quota is assigned to the project.
quotaEnabled	Checks whether quota is enabled on the project.
	This field is read only.
quota	Quota number.
	This field is read only.
quotaMetric	Quota metric unit.
	This field is read only.
dedup	Turns on or off deduplication on the project.
	Supported values:
	<ul><li>on (default)</li><li>off</li></ul>
copies	Specifies number of the project copies.
	Supported values:
	• 1 (default)
	• 2 • 3

Field	Description
primaryCache	Specifies primary cache type.
	Supported values:
	All (default)
	<ul><li>None</li><li>Metadata</li></ul>
secondaryCache	Specifies secondary cache type.
	Supported values:
	All (default)     None
	Metadata
readonly	Specifies whether project is read only.
loadoniy	Supported values:
	• On
	• Off
logbias	Specifies log bias type.
	Supported values:
	Latency (default)
	Throughput
aclInherit	Turns on or off ACL inheritance on the project.
	Supported values:
	On (default)
	• Off
aclMode	Checks the ACL mode on the project.
	This field is read only.
krbStatus	Checks the krb status if SMB is enabled.
	This field is read only.
defaultVolumeSizeInByte	Default volume size.
	The value should be greater than or equal to 1 MB (1048576 bytes). The default value is 1 GB.
defaultVolumeSize	Volume size number.
	This field is read only.

Field	Description
defaultVolumeSizeUnit	Volume size unit.
	This field is read only.
defaultVolumeBlockSize	Sets default volume block size.
	Supported values:
	• 4 KB
	8 KB     16 KB
	32 KB (default)
	• 64 KB
	• 128 KB
defaultThinProvisioning	Sets default thin provisioning for volume. The value is either True or False.
sync	Checks synchronization mode.
zfsDataSetName	Returns ZFS dataset path name.
	This field is read only.
recordSize	Default share block size.
	Supported values:
	• 4 KB
	8 KB     16 KB
	32 KB (default)
	• 64 KB
	• 128 KB
reservation	A number that represents the reserved space for the project.
overrideSpaceUsageThreshold	A Boolean value that determines whether the space usage threshold parameters are inherited or custom.
	If the field is set to true, it indicates that the space usage threshold parameters are custom. False indicates that the space usage threshold parameters are inherited.
spaceUsageWarningThreshold	An integer representing the warning space usage threshold setting value as a percentage.
spaceUsageCriticalThreshold	An integer representing the critical space usage threshold setting value as a percentage.

Field	Description
spaceUsageThresholdStatus	A string representing the space usage threshold status. Possible values are: NORMAL, WARNING, CRITICAL or QUOTA FINISHED. This field is read-only.

## ProjectCloneProgressStatus\_v1\_2

Field	Туре	Description
failedSubProjects	Integer	Number of sub projects (shares and volumes) for which clone snapshot has failed.
projectCloneState	Integer	The integer return value is defined in CLONE_PROGRESS_STATUS.
totalSubProjects	Integer	Total number of sub projects for the given project.

## ReplicationConfig\_V1\_2

Field	Туре	Description
baseDataSetName	String	Base Dataset name
id	Long	Replication config ID
lastSnapshotName	String	Last snapshot name
poolName	String	Pool name
projectGuid	String	Project Guid
projectName	String	Project name
remoteBaseDataSetName	String	Remote dataset name
remoteHost	String	Target(Remote) host
remotePoolName	String	Remote pool name
remoteProjectName	String	Remote project name
scopeOption	Integer	The integer return value is defined in Replication_Scope_Option.

## ReplicationStatus\_v1\_2

Field	Туре	Description
completedTask	Integer	Number of tasks completed.
completeTimestamp	Date	Time stamp indicating when replication was completed.
currentStatus	Integer	Current status of replication. The integer return value is defined in <i>State</i>
dataSent	Long	Total data sent.
sendSpeed	Long	Replication data send speed.
startTimestamp	Date	Time stamp indicating when replication started.
taskSize	Integer	Total task size.
updateTimestamp	Date	Time stamp indicating when replication was last updated.

### Schedule\_V2\_1

Field	Туре	Description	
scheduleId	Integer	Schedule ID. Read-Only field.	
retentionPeriod	Integer	Maximum period to retain snapshots.	
		Schedule Interval Type	Retention Period Unit
		Minutes	Days
		Hourly	Days
		Daily	Weeks
		Weekly	Months
		Monthly	Years
scheduleIntervalType	String	Type of schedule interval. The possible values are minutes, hours, days, weeks, or months.	

Field	Туре	Description	
repeatInterval	Integer	How often the schedule should recur.	
		Schedule Interval Type	Retention Interval
		Minutes	Minutes
		Hourly	Hours
		Daily	Days
		Weekly	Weeks
		Monthly	Months
startDate	String	Start date for scheduling a snapsho Should be specified in YYYY-MM-D Start date can be either current date	D format.
startTime	String	Start time for the schedule. This should be in 24HR HH:MM format.  The date cannot be a past date.	
endTime	String	End time for the schedule. This sho This is applicable only for Minutes a	
daysOfWeek	String	Days of the Week.	
		This is for the Weekly Schedule inte	erval types.
		Should be specified in comma-sepa specifying day of the week.	rated numbers and each number
		For example:	
		Sunday:1, Monday:2, Tuesday:3 an	d so on.
		For Weekdays Only: 2,3,4,5,6	
		For Weekend Only: 1,7	
		For Mon-Wednesday only: 2,4	

Field	Туре	Description
dayOfMonth	String	Day of the month.
		This is for the monthly schedule interval types and the value indicates the date of each month when the schedule should be run.
		If the specified date does not exist in the s month, the job is not run and is scheduled to next month, depending on the repeat interval specified.
		For example, not each month has 31 days, so the job is skipped for those months.
		Either this field or weekdayOfMonth can be specified, but not both.
weekdayOfMonth	String	Weekday of the month. This should be in W:D format.
		This is for the monthly schedule interval types.
		Examples:
		Sunday:1, Monday:2, Tuesday:3 and so on.
		2nd Monday of the Month : 2:2
		4th Thursday of the Month: 4:5
		This field could also contain the value "LAST" to indicate that the job has to run on the last day of the month.
		Either this field or the dayOfWeek can be specified, but not both.

### Share\_V1\_0

Field	Type	Description
availableSize	Long	The available size of the share in bytes.
datasetPath	String	This field is a string that uniquely identifies the share on an IntelliFlash Array. A dataset path should have the format: PoolName/Local/ProjectName/ShareName.
local	Boolean	This boolean identifies whether the share belongs to a local project or a replicated project.
mountpoint	String	This string exposes the mountpoint of the share on an IntelliFlash Array.
name	String	Name of the share.
poolName	String	The pool that contains this share.
projectName	String	The project that contains this share.
totalSize	Long	The total size of the share in bytes.

### Share\_V2\_1

Field	Description	
name	Name of the dataset. This field is read only.	
poolName	Name of the parent storage pool. This field is read only.	
projectName	Name of the project. This field is read only.	
purpose	Purpose of the dataset. This field is read only.	
guid	Global unique identifier of the dataset. This field is read only.	
compression	Compression algorithm that applies on the dataset.	
	Supported values:	
	<ul> <li>off</li> <li>lzjb</li> <li>gzip-2</li> <li>gzip</li> <li>gzip-9</li> <li>lz4</li> </ul>	
overrideCompression	Checks whether compression algorithm overrides parent project. This field is read only.	
localDataset	Indicates whether the dataset is local or replica. This field is read only.	
reservationInByte	Enables reservation on the dataset. This value should be greater than or equal to 1 MB (1048576 bytes). When setting this value to 0, no quota is assigned to the share.	
reservationEnabled	Checks whether reservation is enabled on the dataset. This field is read only.	
reservation	Reservation number. This field is read only.	
reservationMetric	Reservation metric unit. This field is read only.	
dedup	Turns on or off deduplication on the dataset. Supported values are on and off.	
overrideDedup	Check whether deduplication overrides parent project. This field is read only.	
primaryCache	Specifies primary cache type. Supported values are All, None, and Metadata.	
overridePrimaryCache	Checks whether primary cache overrides parent project. This field is read only.	

Field	Description
secondaryCache	Specifies secondary cache type. Supported values are All, None, and Metadata.
overrideSecondaryCache	Checks whether secondary cache overrides parent project.
readonly	Specifies whether the dataset is read only. Supported values are On and Off
overrideReadonly	Checks whether read only overrides parent project. This field is read only.
logbias	Specifies log bias type. Supported values are Latency and Throughput
overrideLogbias	Checks whether log bias overrides parent project. This field is read only.
sync	Checks the synchronization mode.
overrideSync	Checks whether sync mode overrides parent project. This field is read only.
overrideProjectSnapshot Settings	Checks whether snapshot settings override parent project. This field is read only.
zfsDataSetName	Returns ZFS dataset path name. This field is read only.
compressedLog	Log compression algorithm for the dataset. Supported values are lz4 and off.
overrideCompressedLog	Checks whether log compression algorithm overrides parent project. This field is read only.
containerName	Checks current dataset container name. This field is read only.
mountPoint	Checks current mount point.
overrideMountPoint	Check whether mount point overrides default. This field is read only.
quotalnByte	Enables quota on the share if intended for NFS use. This value should be greater than or equal to 1 MB (1048576 bytes). When setting this value to 0, no quota is assigned to the share.
quotaEnabled	Checks whether quota is enabled on the share. This field is read only.
quota	Quota number. This field is read only.
quotaMetric	Quota metric unit. This field is read only.

Field	Description
availableSize	Checks current available share size. This field is read only.
totalSize	Checks current total share size. This field is read only.
overrideSharenfs	Checks whether NFS sharing overrides project setting. This field is read only.
overrideSharesmb	Checks whether SMB sharing overrides project setting. This field is read only.
krbStatus	Checks current Kerberos status of the share if SMB is enabled. This field is read only.
cifsDisplayName	Checks CIFS display name. This field is read only.
guestStatus	Checks guest status of the share. This field is read only.
aclInherit	Turns on or off ACL inheritance on the project. Supported values are On and Off.
overrideAclInherit	Check whether aclinherit overrides parent project setting. This field is read only.
recordSize	Default share block size.
	Supported values:
	• 4 KB
	• 8 KB
	16 KB     32 KB
	• 32 KB • 64 KB
	• 128 KB
	This field can be modified.
overrideRecordSize	Check whether share block size overrides parent project. This field is read only.
atime	Checks access time. This field can be modified.
nbmand	Checks non-blocking mandatory locks. This field can be modified.
aclList	A list of UserACL objects. This field checks current ACLs applied to the share. This field is read only.

#### Share\_V2\_4

Field	Description
name	Name of the dataset. This field is read only.

Field	Description	
poolName	Name of the parent storage pool. This field is read only.	
projectName	Name of the project. This field is read only.	
purpose	Purpose of the dataset. This field is read only.	
guid	Global unique identifier of the dataset. This field is read only.	
compression	Compression algorithm that applies on the dataset.	
	Supported values:	
	• off	
	• Izjb	
	<ul><li>gzip-2</li><li>gzip</li></ul>	
	• gzip-9	
	• Iz4	
overrideCompression	Checks whether compression algorithm overrides parent project. This field is read only.	
localDataset	Indicates whether the dataset is local or replica. This field is read only.	
reservationInByte	Enables reservation on the dataset. This value should be greater than or equal to 1 MB (1048576 bytes). When setting this value to 0, no quota is assigned to the share.	
reservationEnabled	Checks whether reservation is enabled on the dataset. This field is read only.	
reservation	Reservation number. This field is read only.	
reservationMetric	Reservation metric unit. This field is read only.	
dedup	Turns on or off deduplication on the dataset. Supported values are on and off.	
overrideDedup	Check whether deduplication overrides parent project. This field is read only.	
primaryCache	Specifies primary cache type. Supported values are All, None, and Metadata.	
overridePrimaryCache	Checks whether primary cache overrides parent project. This field is read only.	
secondaryCache	Specifies secondary cache type. Supported values are All, None, and Metadata.	
overrideSecondaryCache	Checks whether secondary cache overrides parent project.	
readonly	Specifies whether the dataset is read only. Supported values are On and Off	

Field	Description	
overrideReadonly	Checks whether read only overrides parent project. This field is read only.	
logbias	Specifies log bias type. Supported values are Latency and Throughput	
overrideLogbias	Checks whether log bias overrides parent project. This field is read only.	
sync	Checks the synchronization mode.	
overrideSync	Checks whether sync mode overrides parent project. This field is read only.	
overrideProjectSnapshot	Checks whether snapshot settings override parent project. This field is read only.	
zfsDataSetName	Returns ZFS dataset path name. This field is read only.	
compressedLog	Log compression algorithm for the dataset. Supported values are lz4 and off.	
overrideCompressedLog	Checks whether log compression algorithm overrides parent project. This field is read only.	
containerName	Checks current dataset container name. This field is read only.	
mountPoint	Checks current mount point.	
overrideMountPoint	Check whether mount point overrides default. This field is read only.	
quotalnByte	Enables quota on the share if intended for NFS use. This value should be greater than or equal to 1 MB (1048576 bytes). When setting this value to 0, no quota is assigned to the share.	
quotaEnabled	Checks whether quota is enabled on the share. This field is read only.	
quota	Quota number. This field is read only.	
quotaMetric	Quota metric unit. This field is read only.	
availableSize	Checks current available share size. This field is read only.	
totalSize	Checks current total share size. This field is read only.	
sharenfs	A string indicating whether NFS access is turned on or off for this share.	
overrideSharenfs	Checks whether NFS sharing overrides project setting. This field is read only.	

Field	Description	
sharesmb	A string indicating whether SMB access is turned on or off for this share.	
overrideSharesmb	Checks whether SMB sharing overrides project setting. This field is read only.	
overrideSpaceUsageThreshold	A Boolean value that determines whether the space usage threshold parameters are inherited or custom.	
	If the field is set to true, it indicates that the space usage threshold parameters are custom. False indicates that the space usage threshold parameters are inherited.	
spaceUsageWarningThreshold	An integer representing the warning space usage threshold setting value as a percentage.	
spaceUsageCriticalThreshold	An integer representing the critical space usage threshold setting value as a percentage.	
spaceUsageThresholdStatus	A string representing the space usage threshold status. Possible values are: NORMAL, WARNING, CRITICAL or QUOTA FINISHED. This field is read-only.	
krbStatus	Checks current Kerberos status of the share if SMB is enabled. This field is read only.	
cifsDisplayName	Checks CIFS display name. This field is read only.	
guestStatus	Checks guest status of the share. This field is read only.	
aclInherit	Turns on or off ACL inheritance on the project. Supported values are On and Off.	
overrideAclInherit	Check whether aclInherit overrides parent project setting. This field is read only.	
recordSize	Default share block size.	
	Supported values:	
	• 4 KiB	
	8 KiB     16 KiB	
	• 32 KiB	
	• 64 KiB	
	• 128 KiB	
	This field can be modified.	
overrideRecordSize	Check whether share block size overrides parent project. This field is read only.	
atime	Checks access time. This field can be modified.	

Field	Description
nbmand	Checks non-blocking mandatory locks. This field can be modified.
aclList	A list of UserACL objects. This field checks current ACLs applied to the share. This field is read only.

## **ShareOptions**

Field	Туре	Description
blockSize	String	Block size of the share. Valid values are 4 KiB, 8 KiB, 16 KiB, 32 KiB, 64 KiB, or 128 KiB.
mountPoint	String	Mount point of the share
quota	Long	Maximum amount of storage space (in bytes) the share can use. If set to "-1", no quota limit is set on the share.
reservation	Long	Amount of storage space (in bytes) reserved for the share. If set to "-1", no storage space is reserved for the share.

### **SharePermissions**

Field	Туре	Description
groupList	Array	A JSON array of LocalGroup_V1_2 object. You can use the response of the listGroups method for this paramater. This will be used if the sharePermissionEnum parameter (Permission_type_enum) is set to GROUP.
sharePermissionEnum	Integer	User ACL permission type. Valid values are defined by the Permission_type_enum enumeration.
sharePermissionMode	Integer	User ACL mode. Valid values are defined by the <i>Mode_enum</i> enumeration.

Field	Туре	Description
userList	Array	A JSON array of LocalUser_V1_2 object. You can use the response of the listUsers method for this parameter. This will be used if the sharePermissionEnum parameter (Permission_type_enum) is set to USER.

## SharePermissions\_V2\_6

Field	Туре	Description
inheritance	String	Indicates how the ACLS will be inherited, with values of "discard", "pass-through", "None", "Both"
permissionMask	Integer	ACL mask lists all the ACL permissions active as a bit mask
sharePermissionEnum	Permission_type_enum	User ACL permission type (EVERYONE=0, USER=1, or GROUP=2)
sharePermissionMode	Mode_enum	User ACL mode (ALLOW=0 or DENY=1)
userList	List <localuser_v1_2></localuser_v1_2>	Local user list. This will be used if permission type is selected as USER.
groupList	List <localgroup_v1_2></localgroup_v1_2>	Local group list. This will be used if permission type is selected as GROUP.

## SMBConfig\_V2\_2

Field	Туре	Description
pdc	String	Primary domain controller.
subsharesFeatureEnabled	Boolean	Determines whether subshare can be created. Set the field to true or false.
smbProtocolMode	String	The protocol mode, whether CIFS or SMB 3.0.
restrictAnonymous	Boolean	Determines whether to restrict anonymous SMB user. Set the field to true or false.
restrictGuest	Boolean	Determines whether to restrict SMB guest user. Set the field to true or false.

## **SnapShotDeletionStatus**

Field	Туре	Description
deletedList	List	Deleted snapshots list
failedToDeleteList	List	Not deleted snapshots list
snapshotDeletionStatus	Integer	The integer return value is defined in SNAPSHOT_DELETION_STA

## **SnapshotProgressStatus**

Field	Туре	Description
snapshotProgressStatus	Integer	An integer from the enumeration SNAPSHOT_PROGRESS_STATUS that indicates the snapshot progress status.

#### SnapshotSchedule\_V2\_1

Field	Туре	Description
datasetPath	String	Dataset path. It can be a project, LUN or a share. This should not be a replica dataset.
quiesce	String	Quiesce on or off.

#### SNMP\_Setting\_V2\_1

This class represents the SNMP service settings (community string and trap listeners).

Field	Туре	Description
communityString	String	SNMP Community String. This must be 1 to 64 alpha-numeric characters, or should be * _, -, . (default='public'))
trapListeners	String	List of Trap listeners strings in IP: Port_Number format.

### $SyncReplication Peer Config\_V2\_5$

Field	Туре	Description
peerHostName	String	The host name of the partner array
peerUserName	String	The user name of the partner array
peerPassword	String	The password of the partner array

## SyncReplicationPoolPairConfig\_V2\_5

Field	Туре	Description
localPoolName	String	Pool name of source array
peerPoolName	String	Pool name of partner array
localNetworkAddresses	List	List of floating IP addresses of source array
peerNetworkAddresses	List	List of floating IP addresses of partner array

## SyncReplicationQuorumConfig\_V2\_5

Field	Туре	Description
quorumHostName	String	Quorum witness server host name
passPhrase	String	Passphrase of the Quorum witness server

### $SyncReplicationSetUp\_V2\_5$

Field	Туре	Description
localHostName	String	Source array host name.
peerHostName	String	Partner array host name
quorumHostName	String	Quorum witness server host name

## SyncReplicationStatus\_V2\_5

Field	Туре	Description
activeHost	String	The array where the LUNs are active.
standbyHost	String	The array where the LUNs are on standby.

Field	Туре	Description
currentState	String	The current status of synchronous replication

## SystemAnalyticsResult\_V2\_3

Field	Туре	Description
systemAnalyticsType	String	System analytics type.
		Possible values are CPU, CACHE_HITS, POOL_PERFORMANCE, and NETWORK.
timestamps	Array of longs	Milliseconds since Unix epoch (midnight Jan 1 1970).
Datapoints	Map (String >Array of numbers)	Datapoint list mapping. Each datapoint list has one element per timestamp.
Averages	Map (String >Array of numbers)	Averages of the datapoint listings.

## TargetGroup\_V2\_2

Field	Туре	Description
targetGroupName	String	Target group name as listed in the Web UI.
intendedProtocol	String	The protocol ( iSCSI, FC, or Unknown) that the target group is configured to use.
		Unknown is listed when there are no targets mapped to the target group.

## Volume\_V1\_0

Field	Туре	Description
blockSize	String	The block size of the volume.
datasetPath	String	This field is a string that uniquely identifies the volume on an IntelliFlash Array. A dataset path should have the format: PoolName/ Local/ProjectName/VolumeName. You can get the datasetPath from the listVolumes API. For more information, see listVolumes. The datasetPath is not required for createVolume API.

Field	Туре	Description
local	Boolean	This boolean identifies whether the volume belongs to a local project or a replicated project. The local boolean is not required for <i>createVolume</i> API.
luld	String	The unique identifier for the lun. The luld is not required for <i>createVolume</i> API.
name	String	Name of the volume.
poolName	String	The pool that contains this volume.
projectName	String	The project that contains this volume.
protocol	String	This is the protocol on which the volume will be exposed. The valid values are iSCSI, FC, and Unknown.
thinProvision	Boolean	Indicates whether this volume is thin provisioned or thick provisioned.
volSize	Long	The size of the volume in bytes.

## Volume\_V2\_1

Field	Description
name	Name of the dataset. This field is read only.
poolName	Name of the parent storage pool. This field is read only.
projectName	Name of the project. This field is read only.
purpose	Purpose of the project. This field is read only.
guid	Global unique identifier of the dataset. This field is read only.
compression	Compression algorithm applied on the dataset. Supported values are off, lzjb, gzip-2, gzip, gzip-9, and lz4.
overrideCompression	Checks whether compression algorithm overrides parent project. This field is read only.
localDataset	Indicates whether the dataset is local or replica. This field is read only.
reservationInByte	Enables reservation on the dataset. The value should be greater than 1 MB (1048576 bytes) or set to 0 (no limit).
reservationEnabled	Checks whether reservation is enabled on the dataset. This field is read only.
reservation	Reservation number. This field is read only.
reservationMetric	Reservation metric unit. This field is read only.

Field	Description	
dedup	Turns on or off deduplication on the dataset. Supported values are on and off.	
overrideDedup	Checks whether deduplication overrides parent project. This field is read only.	
primaryCache	Specifies primary cache type. Supported values are All, None, and Metadata.	
overridePrimaryCache	Checks whether primary cache overrides parent project. This field is read only.	
secondaryCache	Specifies secondary cache type. Supported values are All, None, and Metadata.	
overrideSecondaryCache	Checks whether secondary cache overrides parent project. This field is read only.	
readonly	Specifies whether it is read only. Supported values are on and off.	
overrideReadonly	Checks whether read only overrides parent project. This field is read only.	
logbias	Specify log bias type. Supported values are Latency and Throughput.	
overrideLogbias	Checks whether log bias overrides parent project. This field is read only.	
sync	Checks synchronization mode.	
overrideSync	Checks whether sync mode overrides parent project. This field is read only.	
overrideProjectSnapshotSettings	Checks whether snapshot settings override parent project. This field is read only.	
zfsDataSetName	Returns ZFS dataset path name. This field is read only.	
compressedLog	Log compression algorithm for the dataset. Supported values are lz4 and off.	
overrideCompressedLog	Checks whether log compression algorithm overrides parent project. This field is read only.	
containerName	Checks current dataset container name. This field is read only.	
volSize	Volume size in bytes.	
luld	Unique identifier for the lun. This field is read only.	
usedSize	Used Volume size in bytes. This field is read only.	

Field	Description	
thinProvisioning	Indicates whether this volume is thin provisioned. This field is read only.	
blockSize	Sets volume block size.	
	Supported values:	
	<ul> <li>4 KB</li> <li>8 KB</li> <li>16 KB</li> <li>32 KB</li> <li>64 KB</li> <li>128 KB</li> </ul>	
writeBackCache	Enables or disables disk write back cache. Supported values are Enable and Disable.	
overrideViews	Checks whether initiator-target view overrides parent project. This field is read only.	
Protocol	Checks current protocol for the volume. This field is read only.	

Field	Description		
Purpose	The purpose for creating the volume.		
	Note:		
	If the project purpose is "Generic" then the expected volume purpose must be one of Generic, Backup, Database, Storage, Virtual Server, VMware VDI, Hyper-V VDI, SQL Data, SQL Log, SQL Backup, SQL TempDB Data, SQL TempDB Log, SQL Large Object, Exchange Server 2010/2013 Database, Exchange Server 2010/2013 Log Exchange Server 2007 Database, Exchange Server 2007 Log.		
	If the project purpose is "Virtual Server" then the expected volume purpose must be one of Generic, Virtual Server if the project purpose is "Hyper-V VDI" then the expected volume purpose must be one of Generic, Hyper-V VDI if the project purpose is "Hyper-V VDI" then the expected volume purpose must be one of Generic, Hyper-V VDI		
	If the project purpose is "SQL Server" then the expected volume purpose must be one of Generic, SQL Data, SQL Log, SQL Backup, SQL TempDB Data, SQL TempDB Log, SQL Large Object		
	If the project purpose is "VMware VDI" then the expected volume purpose must be one of Generic, VMware VDI		
	If the project purpose is "Exchange Server 2007" then the expected volume purpose must be one of Generic, Exchange Server 2007 Database, Exchange Server 2007 Log		
	If the project purpose is "Exchange Server 2010/2013" then the expected volume purpose must be one of Generic, Exchange Server 2010/2013 Database, Exchange Server 2010/2013 Log		

#### Volume\_V2\_4

Field	Description	
name	Name of the dataset. This field is read only.	
poolName	Name of the parent storage pool. This field is read only.	
projectName	Name of the project. This field is read only.	

Field	Description	
purpose	Purpose of the project. This field is read only.	
guid	Global unique identifier of the dataset. This field is read only	
compression	Compression algorithm applied on the dataset. Supported values are off, Izjb, gzip-2, gzip, gzip-9, and Iz4.	
overrideCompression	Checks whether compression algorithm overrides parent project. This field is read only.	
localDataset	Indicates whether the dataset is local or replica. This field is read only.	
reservationInByte	Enables reservation on the dataset. The value should be greater than 1 MB (1048576 bytes) or set to 0 (no limit).	
reservationEnabled	Checks whether reservation is enabled on the dataset. This field is read only.	
reservationMetric	Reservation metric unit. This field is read only.	
dedup	Turns on or off deduplication on the dataset. Supported values are on and off.	
overrideDedup	Checks whether deduplication overrides parent project. This field is read only.	
primaryCache	Specifies primary cache type. Supported values are All, None, and Metadata.	
overridePrimaryCache	Checks whether primary cache overrides parent project. This field is read only.	
secondaryCache	Specifies secondary cache type. Supported values are All, None, and Metadata.	
overrideSecondaryCache	Checks whether secondary cache overrides parent project. This field is read only.	
readonly	Specifies whether it is read only. Supported values are on and off.	
overrideReadonly	Checks whether read only overrides parent project. This field is read only.	
logbias	Specify log bias type. Supported values are Latency and Throughput.	
overrideLogbias	Checks whether log bias overrides parent project. This field is read only.	
sync	Checks synchronization mode.	
overrideSync	Checks whether sync mode overrides parent project. This field is read only.	

Field	Description	
overrideProjectSnapshotSettings	Checks whether snapshot settings override parent project. This field is read only.	
zfsDataSetName	Returns ZFS dataset path name. This field is read only.	
compressedLog	Log compression algorithm for the dataset. Supported values are lz4 and off.	
overrideCompressedLog	Checks whether log compression algorithm overrides parent project. This field is read only.	
containerName	Checks current dataset container name. This field is read only.	
volSize	Volume size in bytes.	
luld	Unique identifier for the lun. This field is read only.	
thinProvisioning	Indicates whether this volume is thin provisioned. This field is read only.	
blockSize	Sets volume block size.	
	Supported values:	
	• 4 KB	
	• 8 KB	
	• 16 KB	
	32 KB     64 KB	
	• 128 KB	
······································		
writeBackCache	Enables or disables disk write back cache. Supported values are Enable and Disable.	
overrideViews	Checks whether initiator-target view overrides parent project. This field is read only.	
protocol	Checks current protocol for the volume. This field is read only.	
overrideSpaceUsageThreshold	A Boolean value that determines whether the space usage threshold parameters are inherited or custom.	
	If the field is set to true, it indicates that the space usage threshold parameters are custom. False indicates that the space usage threshold parameters are inherited.	
spaceUsageWarningThreshold	An integer representing the warning space usage threshold setting value as a percentage.	
spaceUsageCriticalThreshold	An integer representing the critical space usage threshold setting value as a percentage.	

Field	Description	
spaceUsageThresholdStatus	A string representing the space usage threshold status. Possible values are: NORMAL, WARNING, CRITICAL or QUOTA FINISHED. This field is read-only.	

## UserACL (Read Only) v2.1

Field	Description	
id	Trivia	
controllerId	Trivia	
aclType	Group/User/Everyone	
aclUser	If type is User, show user name	
aclGroup	If type is Group, show group name	
aclValDisplay	String of ACL value. For example, rwxpdDaARWcCos.	
aclVal	Integer value of aclValDisplay.	
aclMode	Allow or deny	
aclInheritanceFlag	Inheritance type. Default/Files/Directories/Both	
includeSubShares	True/False	

# Chapter 16

### **Enumerations**

#### Topics:

- CLEANUP\_STATUS
- CLONE\_PROGRESS\_STATUS
- COMMAND\_STATUS
- Mode\_enum
- OVERWRITE\_STATUS
- Permission\_type\_enum
- Replication\_Scope\_Option
- SNAPSHOT\_DELETION\_STATUS
- SNAPSHOT\_PROGRESS\_STATUS
- State
- ZEBI\_SYSTEM\_PROPERTY

The following sections describe the enumerations used by the IntelliFlash API.

#### **CLEANUP\_STATUS**

Status	Returned Value	Description
CLEANUP_NONE	0	Indicates cleanup is not needed.
CLEANUP_NEEDED	1	Indicates that cleanup is needed.
CLEANUP_DONE	2	Indicates that cleanup is completed.
CLEANUP_FAILED	3	Indicates that cleanup has failed.

#### **CLONE\_PROGRESS\_STATUS**

Indicates the status of a clone project snapshot request.

Status	Returned Value	Description	
INPROGRESS	0	Indicates that the <i>cloneProjectSnapshot</i> request is in progress.	
SUCCESS	1	Indicates that all of the project snapshots are cloned successfully.	
PARTIAL	2	Indicates that some of the project snapshots are cloned successfully	
FAILURE	3	Indicates that none of the project snapshots are cloned.	

#### Related APIs, Objects, and Enumerations

A value from this enumeration is returned by the *getProjectCloneStatus* API to indicate the status of a project clone request.

getProjectCloneStatus, cloneProjectSnapshot, ProjectCloneProgressStatus\_v1\_2.

#### **COMMAND\_STATUS**

Status	Returned Value	Description
COMMAND_SUCCEED	0	Indicates that command (request) succeeded.
COMMAND_NOT_ATTEMPTED	1	Indicates that command (request) not attempted.

Status	Returned Value	Description
COMMAND_FAILED	2	Indicates that command (request) failed.

#### Mode\_enum

Indicates the mode for ACLs supplied using the SharePermissions object to the createShare methods.

Value	Returned Value	Description
ALLOW	0	Indicates that permission should be granted to the specified set of users.
DENY	1	Indicates that permission should be denied to the specified set of users.

#### Related APIs, Objects, and Enumerations

createShare, createShare, SharePermissions.

#### **OVERWRITE\_STATUS**

Status Returned Value		Description	
OVERWRITE_NONE	0	Indicates overwrite is not required.	
OVERWRITE_DONE	1	Indicates overwrite completed.	
OVERWRITE_FAILED	2	Indicates overwrite failed.	

### Permission\_type\_enum

Indicates the scope of ACLs supplied using the SharePermissions object to the createShare methods.

Value	Returned Value	Description	
EVERYONE	0	Indicates that the supplied ACL is for everyone.	
USER	1	Indicates that the supplied ACL is for the specified user.	
GROUP	2	Indicates that the supplied ACL is for the specified group.	

#### Related APIs, Objects, and Enumerations

createShare, createShare, SharePermissions.

#### Replication\_Scope\_Option

Specifies the condition that determines which datasets in a project will be replicated when you start replication on the project.

Value	Returned Value	Description
FULL	0	All datasets in the project will be replicated
INCLUDE	1	All selected datasets will be replicated
EXCLUDE	2	All selected datasets will not be replicated

#### Related APIs, Objects, and Enumerations

getReplicationConfigList, getReplicationStatus, startReplication, ReplicationConfig\_V1\_2.

#### SNAPSHOT\_DELETION\_STATUS

Indicates the status of a snapshot deletion request.

Status	Returned Value	Description
SUCCESS	0	Indicates that the snapshot deletion succeeded.
PARTIAL	1	This value is applicable only to the deleteProjectSnapshot API. It indicates that only some of the snapshots could be deleted (other snapshots that were selected for deletion could not be deleted.)
FAILURE	2	Indicates that the snapshot deletion has failed.

#### Related APIs, Objects, and Enumerations

deleteProjectSnapshot, deleteVolumeSnapshot, deleteShareSnapshot.

#### SNAPSHOT\_PROGRESS\_STATUS

Status	Returned Value	Description
SUCCESS	0	The snapshot request completed successfully.

Status	Returned Value	Description
INPROGRESS	1	The snapshot request is in progress.
ERROR	2	The snapshot request failed due to an error.

#### **State**

The **State** enumeration indicates the state of a replication request.

Status	Returned Value	Description	
UNKNOWN	0	Indicates that the replication task exited due to an unknown error.	
START	1	Indicates that the replication task has started.	
RESTART	2	Indicates that an interrupted replication task has restarted.	
SENDING	3	Indicates that the system is sending replication data.	
COMPLETING	4	Indicates that data transfer for replication is complete, and the replication task is finishing.	
COMPLETED	5	Indicates that the replication task is complete.	
ERROR	6	Indicates that the replication task exited with an error due to system, network, or other issues.	
ABORTING	7	Indicates that the initial state (before <b>ABORTED</b> ) of an aborted replication. You cannot restart the replication task if it is aborting.	
ABORTED	8	Indicates that you have aborted the replication. If you abort a replication, the system rolls back to the previous replication snapshot completely.	
ABANDONING	9	Indicates that the system is <b>ABANDONING</b> a running replication task. The system abandons a replication if you manually switchover the pool or if the pool goes offline for any reason.	

#### States of a replication task

An uninterrupted and successful replication task goes through the start, sending, completing, and completed states. If the task fails due to an error or if you abort a running task, you can restart it at a later time.

#### Related APIs, Objects, and Enumerations

getReplicationConfigList, getReplicationStatus, startReplication, ReplicationConfig\_V1\_2, ReplicationStatus\_v1\_2.

## ZEBI\_SYSTEM\_PROPERTY

Value	Description	
ZEBI_APPLIANCE_MODEL	Indicates the array model.	
ZEBI_APPLIANCE_VERSION	Indicates the array version.	
ZEBI_GUI_VERSION	The IntelliFlash Web UI version.	
ZEBI_SUPPORTED_TDPS_API_VERSIONS	The IntelliFlash Data Protection Services (IDPS) versions supported by this version of the IntelliFlash API.	
ZEBI_API_MINOR_VERSION	Indicates the minor version of the IntelliFlash API.	
ZEBI_API_VERSION	Indicates the full version of the IntelliFlash API.	
INTELLIFLASH_ARRAY_GUID	Indicates the GUID of the IntelliFlash array.	
INTELLIFLASH_ARRAY_FQDN	Indicates the FQDN of the IntelliFlash array.	

# **Appendix**

A

# **Appendix A**

#### Topics:

• JSON Quick Reference

#### **JSON Quick Reference**

This quick reference includes some JSON examples for users who are not familiar with the JSON syntax.

All JSON data sent in HTTP requests must be enclosed within square brackets ([]). For example, to send a single string, use the following:

```
["pool1"]
```



Note: As JSON ignores whitespace, such as newlines, tabs, and spaces, you can also send the following:

```
"pool1"
```

#### **Boolean**

true

false

#### **Integers**

213

#### String

```
"pool1"
```

#### **Array of strings**

```
"string1","string2","string3"
]
```

#### **Objects**

```
"lunNumber":-1,
"name":"testVol",
"local":true,
```

#### Array of objects

[

```
{"lunNumber":-1, "name":"testVol", "local":true},
{"lunNumber":-1, "name":"testVol", "local":true}
]
```

#### Mixed

```
"DatasetPath",
[{"lunNumber":-1,"name":"testVol","local":true}],
true
```