Slackforce: Documentation on the Theoretical Background

Tilman Sinning

June 22, 2017

Contents

1	Intr	oduction	3
2	Mea	Measure Force	
	2.1	Physical Background	4
	2.2	The Influence of the Stretch Characteristic	5
3	Calculate Force		6
	3.1	Basics	6
	3.2	Calculating the Pretension	7
	3.3	Rodeo Lines	
	3.4	Calculating Slackline Forces from the Pretension	10
		Slackliner who is not in the middle of the Line (not implemented)	
4	Dynamic Force Simulation		12
	4.1	Slackline as a Spring	12
	4.2	The Standard Linear Solid Model	
	4.3	Equation of Motion	
	4.4	Solving the Equation of Motion with the Runge-Kutta-Method	

1 Introduction

For slackliners it is often important to know the physical forces involved in slacklining, for example to estimate the suitability of potential slackline anchors. For static conditions, some well known calculations exist, to get the force on a slackline anchor from the sag of the slackline and the weight of the slackliner. However, it is often not easy to estimate the sag of a slackline precisely. Therefore it would be nice to have other measurement methods as well. Even more complicated is the estimation of the peak force in a slackline during dynamic movements like jumping.

The idea of the app "Slackforce" is to provide an easy to use solution for measuring and calculating forces in a slackline. This document describes the physical background and derivation of formulas and calculations used within this app. The app contains the following three main functionalities:

Measure Force: Measure the pretension of a slackline from the sound you hear when slapping the line with your finger.

Static Calculations: Calculate the forces on a slackline at static conditions resulting from the geometric setup of the line.

Dynamic Simulation: Simulate the movement and forces of a slackline during dynamic conditions like bouncing or jumping.

This document is divided into three chapters corresponding to the app functionalities. Note that the presented calculations are experimental and might contain errors. Use the formulas careful and do not fully trust the calculated values. The creator of this document is not responsible for any harm resulting from the use of the presented calculations and formulas.

2 Measure Force

When slapping a tensioned slackline with your finger, you will hear a corresponding acoustical sound. The sound travels along the slackline as a mechanical wave and gets reflected at the end of the slackline. The propagation speed directly depends on the tension and the weight of the slackline. The idea is to calculate the pretension of the slackline from the time that sound needs to travel along the slackline back and forth.

2.1 Physical Background

The propagation speed of a wave on a tensioned rope or slackline can be described with the following formula

$$v = \sqrt{\frac{F}{\mu_0}} \tag{2.1}$$

where v is the propagation speed, F the force and μ_0 the weight per unit length of the line. In between two sounds, the mechanical wave travels from one slackline anchor to the other and back, so it covers a distance two times the length l of the line. If you measure the time of oscillation t_{osc} the propagation speed can be calculated as:

$$v = \frac{2 \cdot l}{t_{osc}} \tag{2.2}$$

If you combine equation 2.1 and 2.2 and solve for the force you will get the following equation:

$$F_0 = \frac{4 \cdot l^2 \cdot \mu_0}{t_{osc}^2} \tag{2.3}$$

 F_0 is the pretension of the line. As you can see, the weight and the length of the line have to be known. In the app the time of oscillation can be measured automatically with the microphone and some simple audio processing or manually by typing sound pattern on a button.

2.2 The Influence of the Stretch Characteristic

During the tensioning of the line, the line also stretches. As the total weight of the line does not change, this leads to a decrease of weight per unit length. Therefore equation 2.3 contains a systematic error on stretchy webbings. To take this into account a linear stretch behavior corresponding to the following formula is assumed.

$$\frac{\Delta l}{l} = \alpha \cdot F \tag{2.4}$$

where α is the stretch coefficient and F is the force on the line. The corrected weight per unit length is calculated to

$$\mu = \mu_0 \cdot \frac{1}{1 + \alpha \cdot F} \tag{2.5}$$

If you replace μ_0 in formula 2.3 with the corrected value μ and solve the equation for F you get the following formula:

$$F = \sqrt{\frac{1}{4\alpha^2} + \frac{\mu_0 \cdot 4l^2}{\alpha \cdot t_{osc}^2} - \frac{1}{2\alpha}}$$
 (2.6)

In the App this more exact formula is used whenever a stretch coefficient greater than zero is entered. It can be shown that formula 2.6 equals formula 2.3 for $\alpha \to 0$.

3 Calculate Force

The forces in a slackline can be obtained by using the geometric setup of the line at a given load. If the tension of the line at a given sag is known the tension at a different sag can easily be calculated with the aid of the stretch behavior.

3.1 Basics




Figure 3.1: Schematical slackline with horizontal and vertical components of an applied force

Figure 3.1 shows a scheme of a slackline with a given length and sag. The load that is applied in the middle of the line results in a specific sag. The force on the anchor F_a is determined by the vertical Force F_v and horizontal force F_h as shown in Figure 3.1. The forces on the left part of the line correspond to the shown forces on the right side. The total force is the sum of the forces on the left and the right side. The horizontal components eliminate each other while the vertical ones add up. If a slackliner is standing on the line, the total vertical force corresponds to the slackliner's weight. From the geometric properties shown in figure 3.1 the following equation can easily be derived:

$$\frac{F_a}{0.5 \cdot F_v} = \frac{l_1}{s} = \frac{\sqrt{\frac{l^2}{4} + s^2}}{s} \tag{3.1}$$

Together with the gravity acceleration $g = 9.81 \frac{m}{s^2}$ and the weight of the slackliner m this leads to the following four equations:

$$F = \frac{\sqrt{s^2 + \frac{l^2}{4}}}{2 \cdot s} \cdot m \cdot g \tag{3.2}$$

$$m = \frac{2 \cdot s \cdot F}{g \cdot \sqrt{s^2 + \frac{l^2}{4}}} \tag{3.3}$$

$$s = \sqrt{\frac{m^2 \cdot l^2 \cdot g^2}{4 \cdot (4F^2 - m^2 g^2)}} \tag{3.4}$$

$$l = \sqrt{\frac{4 \cdot s \cdot (4F^2 - m^2 g^2)}{m^2 g^2}}$$
 (3.5)

With Equation 3.2 - 3.5 it is possible to calculate any of the parameters force, weight of slackliner, sag and length, if the other parameters are known.

3.2 Calculating the Pretension

If you know the (walking) tension of a slackline with a person standing in the middle and the stretch behavior, it is possible to calculate the pretension. Figure 3.2 shows the stretch behavior of a Type 18 MKII line as an example. It can be seen that the stretch is not linear. To get the pretension of the line you need to know the increase of length Δl due to the sag of the line. This can be calculated with the following formula:

$$\Delta l = 2 \cdot l_1 - l = 2 \cdot \sqrt{s^2 + \frac{l^2}{4}} - l \tag{3.6}$$

To get the pretension you have to do the following steps:

- 1. Calculate the anchor force with a slackliner on the line
- 2. Read the corresponding stretch from the force-stretch-diagram




Figure 3.2: Force-Stretch-Diagramm of a 100 m Type 18 Line with 4,5 kN Pretension

- 3. Calculate the new stretch with formula 3.6
- 4. Read the pretension from the force-stretch-diagram

If a linear stretch behavior $\frac{\Delta l}{l} = \alpha \cdot F$ is assumed, it is possible to put that relation into an analytic formula:

$$F = F_0 + \frac{2 \cdot \sqrt{s^2 + \frac{l^2}{4}} - l}{\alpha \cdot l} \tag{3.7}$$

However, the app always uses the force-stretch-diagram if available, as the results are better with that method. Unfortunately some slackline manufacturers provide very little information on the stretch behavior of their lines and only a few data points are available. The app interpolates those data points linear for the calculations.

3.3 Rodeo Lines

Rodeo Lines are slacklines with a lot of sag and no pretension. So the pretension F_0 is always zero and the line has an initial sag s_0 without any slackliner standing on the line. When a slackliner steps on the line, it might stretch further and lead to a sag greater than the initial sag. Figure 3.3 shows the forces on an rodeo line.




Figure 3.3: Schematical rodeo line with horizontal and vertical components of force

As it can be seen there is no change to the static forces with a slackliner on the line from figure 3.1. So all the calculations of the section "Basics" are still valid. If you want to do calculations based on the force-stretch-diagram you have to be aware that equation 3.6 now changes to

$$\Delta l = 2 \cdot (l_2 - l_1) = 2 \cdot \left(\sqrt{s^2 + \frac{l^2}{4}} - \sqrt{s_0^2 + \frac{l^2}{4}} \right)$$
 (3.8)

In addition there is no pretension to calculate, but you can calculate the initial sag of the line using the force-stretch-diagram. Therefore you have to read the stretch Δl from the diagram and use the following formula:

$$s_0 = \sqrt{l_1^2 - \frac{l^2}{4}} = \sqrt{(l_2 - \Delta l)^2 - \frac{l^2}{4}}$$
(3.9)

$$= \sqrt{\left(\sqrt{s^2 + \frac{l^2}{4}} - \Delta l\right)^2 - \frac{l^2}{4}} \tag{3.10}$$

3.4 Calculating Slackline Forces from the Pretension

Unfortunately it is very difficult for linear stretch behavior and impossible for a custom stretch behavior to get an analytic expression of the walking tension, that is a function of the pretension. Therefore some kind of approximation algorithm has to be used. The App is currently using the Illinois algorithm.

3.5 Slackliner who is not in the middle of the Line (not implemented)

In the following it is assumed, that the slackliner is standing at a position $p \in [0, 1]$ on the line. The forces are always calculated for the left anchor point. The forces at the right anchor point equal the forces at the left anchor point at position 1 - p. Figure 3.4 shows the forces in this new setup. If the slackliner is not moving, the horizontal forces have to be the same on both sides. That leads to different vertical forces and anchor forces on both sides.




Figure 3.4: Force Components on Unsymmetric Conditions

According to fig. 3.4 the equation below can be derived.

$$\frac{p \cdot l}{s} = \frac{F_{h,l}}{F_{v,l}} = \frac{\sqrt{F_{a,l}^2 - F_{v,l}^2}}{F_{v,l}}$$
(3.11)

The total vertical force is still the sum of both sides:

$$F_v = F_{v,l} + F_{v,r} (3.12)$$

The absolute values of both horizontal forces are the same which leads to:

$$\frac{p \cdot l}{s} \cdot F_{v,l} = \frac{(1-p) \cdot l}{s} \cdot F_{v,r} \tag{3.13}$$

Combining equation 3.13 and 3.12 results in:

$$F_{v,l} = (1 - p) \cdot F_v \tag{3.14}$$

Inserting equation 3.14 in 3.11 leads to the final equation

$$F_{a,l} = \frac{(1-p) \cdot F_v}{s} \cdot \sqrt{(p \cdot l)^2 + s^2}$$
 (3.15)

For p=0.5 this equation is identical to equation 3.2 from the previous section. Note that equation 3.6 now changes to

$$\Delta l = \sqrt{(p \cdot l)^2 + s^2} + \sqrt{(1-p)^2 l^2 + s^2} - l \tag{3.16}$$

4 Dynamic Force Simulation

In the previous section the calculations at static conditions were described. However, normally you do not just stand statically in the middle of a slackline. Often you want to do some bouncing or jumping, which leads to a significant increase of force on the line. The goal of this section is to calculate those forces and get an idea of the influence of different setup parameters like length, pretension and stretch.

4.1 Slackline as a Spring

The simplest approach is to consider a slackline as a spring that can be described with the same formulas as in the previous section. Together with the following formulas and the formulas described in section 3.1 it is easy to calculate the movement of the slackliner and the corresponding force:

$$v(t) = at + v_0 \tag{4.1}$$

$$s(t) = \frac{a}{2}t^2 + v_0t + s_0 \tag{4.2}$$

$$F = a \cdot m \tag{4.3}$$

where a is the acceleration, m the mass, v the speed and s the current sag. In a first version of the app the following iterative algorithm was used to simulate the movement of a slackliner:

- 1. Set the sag of the slackline to the current position of the slackliner
- 2. Calculate the force affecting the slackliner $F = m \cdot g F_{v,slackline}$
- 3. Calculate the acceleration of the slackliner a = F/m
- 4. Calculate change in speed $\Delta v = a \cdot \Delta t$

- 5. Calculate change in position $\Delta s = \frac{1}{2} \cdot a \cdot \Delta t^2 + v \cdot \Delta t$
- 6. Calculate the current position and speed of the slackliner $s_{t+1} = s_t + \Delta s$, $v_{t+1} = v_t + \Delta v$
- 7. Repeat steps 2 6

However, this approach as some disadvantages. First from a numerical perspective it would be better to describe the movement of the slackliner with a differential equation and use a numerical approximation method for solving. But more important, dynamic measurements have shown that slacklines behave more like a viscoelastic material and not like a simple spring, that leads to a different behavior than shown above. To take this into account a more advanced model has to be used for the simulation.

4.2 The Standard Linear Solid Model




Figure 4.1: Standard linear solid model

In this app, a calculation based on the standard linear solid model, as shown in Figure 4.1, is proposed as basis for dynamic slackline simulations. This model is commonly used to describe the behavior of viscoelastic materials. The springs and damper in the model can be described with the following equations:

$$F_{k_1} = k_1 \cdot x_1 \tag{4.4}$$

$$F_{k_2} = k_1 \cdot x_2 \tag{4.5}$$

$$F_d = d \cdot \dot{x}_2 \tag{4.6}$$

From the connection of the elements in Figure 4.1 follows:

$$F_{k_1} = F_{k_2} + F_d \tag{4.7}$$

Together with $x_1 + x_2 = x$ and $F = k_1 \cdot x_1$ the following equation can be derived:

$$F + \frac{d}{k_1 + k_2}\dot{F} = \frac{k_1 \cdot k_2}{k_1 + k_2}x + \frac{d \cdot k_1}{k_1 + k_2}\dot{x}$$
(4.8)

With this equation the behavior of the slackline will be described in the following. For static conditions we have $\dot{x}_1 = 0$. Therefore the total spring constant $k_{ges} = \frac{k_1 \cdot k_2}{k_1 + k_2}$ can be described by the static stretch behavior of the slackline the following formula:

$$k_{ges} = \frac{1}{\alpha \cdot l} \tag{4.9}$$

 k_1 and k_2 are determined by the stretch coefficient which is known for many webbings and the ratio $\frac{k_1}{k_2}$ that might be similar on different webbings.

4.3 Equation of Motion

By looking at the equations from Section 3.1 again and considering that the acceleration of the slackliner has an additional input on the force in the dynamic case, the force at the slackline anchor can be described as

$$F = \frac{\sqrt{s^2 + \frac{l^2}{4}}}{2 \cdot s} \cdot F_{vertical} = \frac{\sqrt{s^2 + \frac{l^2}{4}}}{2 \cdot s} \cdot m \cdot (g - \ddot{s})$$
 (4.10)

From the geometrics of the slackline the absolute stretch of one slackline half can be

described as

$$x = \frac{\Delta l_0}{2} + \sqrt{s^2 + \frac{l^2}{4}} - \sqrt{s_0^2 + \frac{l^2}{4}}$$
 (4.11)

where $\Delta l_0 = \alpha \cdot F_0 \cdot l$ is the initial stretch of the slackline due to pretensioning and s_0 is the initial sag of a rodeo line (either Δl_0 or s_0 is always zero). Derivating this equations with respect to the time results in the following two equations:

$$\dot{F} = -\frac{l^2}{8} \cdot m \cdot (g - \ddot{s}) \frac{\dot{s}}{s^2 \cdot \sqrt{s^2 + \frac{l^2}{4}}} - m \ddot{s} \frac{\sqrt{s^2 + \frac{l^2}{4}}}{2 \cdot s}$$
(4.12)

$$\dot{x} = \frac{s \cdot \dot{s}}{\sqrt{s^2 + \frac{l^2}{4}}}\tag{4.13}$$

Inserting this equation into equation 4.8 from the linear solid model and solving for \ddot{s} leads to the following equation of motion:

$$\ddot{s} = \frac{k_1 + k_2}{d} \cdot (g - \ddot{s}) - \frac{\dot{s} \cdot l^2}{4 \cdot s \cdot l_2^2} \cdot (g - \ddot{s}) - \frac{2sk_1k_2}{dml_2} \left(\frac{\Delta l_0}{2} + l_2 - l_1\right) - \frac{2s^2 \dot{s}k_1}{ml_2^2} \quad (4.14)$$

with

$$l_1 = \sqrt{s_0^2 + \frac{l^2}{4}} \tag{4.15}$$

$$l_2 = \sqrt{s^2 + \frac{l^2}{4}} \tag{4.16}$$

As can be seen, we have a third order, non linear differential equation, that can only be solved with numerical algorithms.

4.4 Solving the Equation of Motion with the Runge-Kutta-Method

To solve the equation of motion it has to be transformed into three first order differential equations:

$$\dot{s} = G(s, v, a) = v \tag{4.17}$$

$$\dot{v} = H(s, v, a) = a \tag{4.18}$$

$$\dot{a} = I(s, v, a) = \frac{k_1 + k_2}{d} \cdot (g - a) - \frac{v \cdot l^2}{4 \cdot s \cdot l_2^2} \cdot (g - a) - \frac{2sk_1k_2}{dml_2} \left(\frac{\Delta l_0}{2} + l_2 - l_1\right) - \frac{2s^2vk_1}{ml_2^2}$$

$$(4.19)$$

Now the equation can be solved iteratively with the Runge-Kutta-Method (4th order) with the following formula:

$$s_{t+1} = s_t + \frac{1}{6} \cdot \Delta t \cdot (M_{1,i} + 2M_{2,i} + 2M_{3,i} + M_{4,i})$$
(4.20)

$$v_{t+1} = v_t + \frac{1}{6} \cdot \Delta t \cdot (N_{1,i} + 2N_{2,i} + 2N_{3,i} + N_{4,i})$$
(4.21)

$$a_{t+1} = a_t + \frac{1}{6} \cdot \Delta t \cdot (O_{1,i} + 2O_{2,i} + 2O_{3,i} + O_{4,i})$$
(4.22)

with

$$M_{1,i} = G(s_i, v_i, a_i) (4.23)$$

$$M_{2,i} = G\left(t_i + \frac{1}{2} \cdot \Delta t \cdot M_{1,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot N_{1,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot O_{1,i}\right)$$
(4.24)

$$M_{3,i} = G\left(t_i + \frac{1}{2} \cdot \Delta t \cdot M_{2,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot N_{2,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot O_{2,i}\right)$$
(4.25)

$$M_{4,i} = G(t_i + \Delta t \cdot M_{1,i}, t_i + \Delta t \cdot N_{1,i}, t_i + \Delta t \cdot O_{1,i})$$
(4.26)

$$N_{1,i} = H(s_i, v_i, a_i) (4.27)$$

$$N_{2,i} = H\left(t_i + \frac{1}{2} \cdot \Delta t \cdot M_{1,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot N_{1,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot O_{1,i}\right)$$
(4.28)

$$N_{3,i} = H\left(t_i + \frac{1}{2} \cdot \Delta t \cdot M_{2,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot N_{2,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot O_{2,i}\right)$$
(4.29)

$$N_{4,i} = H(t_i + \Delta t \cdot M_{1,i}, t_i + \Delta t \cdot N_{1,i}, t_i + \Delta t \cdot O_{1,i})$$
(4.30)

$$O_{1,i} = I(s_i, v_i, a_i) (4.31)$$

$$O_{2,i} = I\left(t_i + \frac{1}{2} \cdot \Delta t \cdot M_{1,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot N_{1,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot O_{1,i}\right)$$
(4.32)

$$O_{3,i} = I\left(t_i + \frac{1}{2} \cdot \Delta t \cdot M_{2,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot N_{2,i}, t_i + \frac{1}{2} \cdot \Delta t \cdot O_{2,i}\right)$$
(4.33)

$$O_{4,i} = I(t_i + \Delta t \cdot M_{1,i}, t_i + \Delta t \cdot N_{1,i}, t_i + \Delta t \cdot O_{1,i})$$
(4.34)

Unfortunately there are no measurements available characterizing the dynamic behavior of different webbings, so the parameters $\frac{k_1}{k_2}$ and d can only be guessed. However, as a starting point there exists a document from Ulrich Leuthäusser with some measurements on climbing ropes. For the ropes tested there, the ratio $\frac{k_1}{k_2}$ was always about 3. The geometry independent damping factor $\delta = d \cdot l$ was varying between $\delta = 4.8 \dots 9 \, kN \cdot s$.