
1 Features

- General purpose 16-bit PWM/Counter module.
- Two independent output compare units and One input capture unit
- Variable PWM.
- Four independent interrupt sources (TOV1, OCF0A, OCF1B and ICF1).
- Clear timer on compare match (auto reload)

2 Block Diagram



3 Terminologies and Registers


		Register - 16 bit	Name
Parameter	Description	TCN10	Timer/Counter1count value
BOTTOM	counter reaches 0x0000	TCCR1A	Timer/Coutner1 Control Register A
MAX	ounter reaches 0xFFFF	TCCR1B	Timer/Coutner1 Control Register B
TOP	counter reaches highest value	OCBR1A	Output compare register A
	(depends on mode of oper-	OCBR1B	Output compare register B
	ation can be 0xFF, 0x1FF,	TIFR1	Timer Interrupt Flag Register
	0x3FF, OCR1A, ICR1)	TIMSK1	Timer interrupt Mask Register
		ICR1	Input Capture Register

Note:

- The CNT1, OCR1A/B, ICR1 are 16-bit registers that can be accessed by the CPU via the 8-bit data bus.
- For 16-bit write, the high byte must be written before the low byte.
- For 16-bit read, the low byte must be read before the high byte.


4 Timer/Counter1 Units

4.1 Clock Source/Select Unit




- The source for the Timer/Counter0 can be external or internal.
- External clock source is from T1 pin.
- While Internal Clock source can be clocked via a prescalar.
- The output of this unit is the timer clock (clk_{T_1}) .
- It uses *CS1*[2:0] bits in **TCCR1B** register to select the source.

4.2 Counter Unit




- The main part of the 16-bit Timer/Counter is the programmable bi-directional counter.
- Counter high (TCNT1H) containing the upper eight bits of the counter, and counter low (TCNT1L) containing the lower eight bits.
- Depending the mode of operation the counter is cleared, incremented, or decremented at each timer clock (clk_{T1}) .
- Counting sequence is determined by *WGM1[3:0]* bits of **TCCR1A** -Timer/Counter1 Control register A and **TCCR1B** Timer/Counter1 Control register B.
- The Timer/Counter1 Overflow flag (TOV1) is set and can generate interrupt according to the mode.

4.3 Input Capture Unit




- Can capture external events and give them time-stamp indicating time of occurance.
- External signal can be from *ICP1* pin or analog-comparator unit.
- Usage : calculate frequency, duty-cycle, log of the signal
- When a change of the logic level (an event) occurs on the input capture pin (*ICP1*), or on the analog comparator output (*ACO*), and this change confirms to the setting of the edge detector, a capture will be triggered.
- When a capture is triggered, the 16-bit value of the counter (TCNT1) is written to the input capture register (ICR1).
- The input capture flag (ICF1) is set at the same system clock as the TCNT1 value is copied into ICR1 register.
- If enabled (ICIE1 = 1), the input capture flag generates an input capture interrupt.
- *ICF1* flag is automatically cleared when the interrupt is executed and by writing on to i.
- An input capture can be triggered by software by controlling the port of the *ICP1* pin.

4.4 Output Compare Unit



- 16-bit comparator continuously compares TCNT1 with both OCR1A and OCR1B.
- When TCNT1 equals OCR1A or OCR1B, the comparator signals a match which will set the output compare flag at the next timer clock cycle.
- If interrupts are enabled, then output compare interrupt is generated.
- The waveform generator uses the match signal to generate an output according to operating mode set by the WGM1/3:0 bits and compare output mode COM0x/1:0 bits.

4.5 Compare Match Output Unit




- This unit is used for changing the state of OC1A and OC1B pins by configuring the COM1x[1:0] bits.
- But, general I/O port function is overriiden by DDR reigster.

5 Modes of Operation

- The mode of operation can be defined by combination of waveform generation mode (WGM1[3:0]) and compare output mode(COM1[1:0]) bits.
- The waveform generation mode (WGM1/3:0) bits affect the counting sequence.
- For non-PWM mode, COM1[1:0] bits control if the output should be set, cleared or toggled at a compare match.
- For PWM mode, COM1[1:0] bits control if the PWM generated should be inverted or non-inverted.

5.1 Normal Mode - Non-PWM Mode

- WGM1/3:0/-->000.
- Counter counts up and no counter clear.
- Overruns TOP(0XFFFF) and restarts from BOTTOM(0X0000).
- TOV1 Flag is only set when overrun.
- We have to clear TOV1 flag inorder to have next running.
- But, if we use interrupt we don't need to clear it as interrupt automatically clear the TOV1 flag.
- The input capture unit can be used to capture events at *ICP1* pin or *ACO* pin.
- The timing can be seen below.




5.2 Clear Timer on Compare Match(CTC) Mode - Non-PWM Mode

- WGM1/3:0/-->0100 or 1100.
 - Counter value clears when **TCNT1** reaches **OCR1A** if **WGM1**[3:0] is 0100.
 - Counter value clears when **TCNT1** reaches **ICR1** if **WGM1**[3:0] is 1100.
- Interrupt can be generated each time TCNT1 reaches OCR1A register value by OCF1A flag.
- Interrupt can be generated each time TCNT1 reaches ICR1 register value by ICF1 flag.
- When COM1A[1:0] == 01, the OC1A pin output can be set to toggle its match between TCNT1 and OCR1A or ICR1 register to generate waveform.
- The frequency of the waveform its


$$f_{OC1A} = \frac{f_{clkT1}}{2*N*(1+OCR1A)}$$

• Here N is prescalar factor and can be (1, 8, 64, 256, or 1024).

$5.2.1 \quad WGM1[3:0] == 0100$



$5.2.2 \quad \text{WGM1[3:0]} == 1100$




5.3 Fast PWM Mode


- WGM1/3:0/-->0101 or 0110 or 0111 or 1110 or 1111.
- Power Regulation, Rectification, DAC applications.
- Single slope operations causing high frequency PWM waveform.
- Counter starts from BOTTOM to TOP and then restarts from BOTTOM.
- TOP is defined by
 - $\text{ TOP} == 0 \times 00 \text{FF if } WGM1/3:0/--> 0101$
 - $\text{ TOP} == 0 \times 01 \text{FF if } WGM1/3:0/ --> 0110$
 - $\text{ TOP} == 0 \times 03 \text{FF if } WGM1/3:0/ --> 0111$
 - TOP == ICR1 if WGM1[3:0] --> 1110
 - $\text{ TOP} == \frac{\text{OCR1A}}{\text{OCR1A}} \text{ if } \frac{WGM1/3:0}{\text{OCR1A}} = 0.5 \text{ or } 0.5 \text{ or$
- When COM1A[1:0] == 01, the OC1A pin output can be set to toggle its match between **TCNT1** and TOP to generate waveform.
 - The above is possible only when WGM12 bit is set.
 - And only on OC1A pin and not on OC1B pin.
- In Inverting Compare Mode COM1A[1:0] == 10, the OC1A or OC1B pins is made 1 on compare match between TCNT1 and TOP and made 0 on reaching BOTTOM.
- In Non-Inverting Compare Mode COM1A[1:0] == 11, the OC1A or OC1B pins is made 0 on compare match between **TCNT1** and TOP and 1 made on reaching BOTTOM.
- The Timer/Counter overflow flag (TOV1) is set each time the counter reaches TOP.
- The PWM frequency is given by

$$f_{OC1xPWM} = \frac{f_{clkT1}}{N*(1+TOP)}$$

$5.3.1 \quad WGM1[3:0] == 0101$




$5.3.2 \quad \text{WGM1[3:0]} == 0110$




$5.3.3 \quad WGM1[3:0] == 0111$



$5.3.4 \quad WGM1[3:0] == 1110$



$5.3.5 \quad WGM1[3:0] == 1111$



5.4 Phase Correct PWM Mode


- WGM1[3:0] --> 0001 or 0010 or 0011 or 1010 or 1011.
- High resolution phase correct PWM.
- Motor control due to symmetric features
- Dual slope operations causing ower frequency PWM waveform.
- Counter starts from BOTTOM to TOP and then from TOP to BOTTOM.
- TOP is defined by

```
- TOP == 0x00FF if WGM1[3:0] -- > 0001
```

$$- \text{ TOP} == 0x01\text{FF if } WGM1/3:0/-->0010$$

- $\text{ TOP} == 0 \times 03 \text{FF if } WGM1/3:0/ --> 0011$
- TOP == ICR1 if WGM1/3:0/ --> 1010
- TOP == OCR1A if WGM1/3:0/--> 1011
- When COM1A[1:0] == 01, the OC1A pin output can be set to toggle its match between **TCNT1** and TOP to generate waveform.
 - The above is possible only when WGM12 bit is set.
 - And only on *OC1A* pin and not on *OC1B* pin.
- In Inverting Compare Mode COM1A[1:0] == 10, the OC1A or OC1B pins is made 1 on compare match between **TCNT1** and TOP and made 0 on reaching BOTTOM.
- In Non-Inverting Compare Mode COM1A[1:0] == 11, the OC1A or OC1B pins is made 0 on compare match between **TCNT1** and TOP and 1 made on reaching BOTTOM.
- The Timer/Counter overflow flag (TOV1) is set each time the counter reaches BOTTOM...
- The PWM frequency is given by

$$f_{OC1xPWM} = \frac{f_{clkT1}}{2*N*TOP}$$



5.5 Phase and Frequency Corrected PWM Mode

- WGM1/3:0/-->1000 or 1001.
- High resolution and Phase correctd PWM.
- Dual-Slope.
- Counter counts from BOTTOM to TOP and then from TOP to BOTTOM.

```
- TOP == OCR1A if WGM1[3:0] -- > 1001
- TOP == ICR1 if WGM1[3:0] -- > 1000
```

- In Inverting Compare Mode COM1x[1:0] == 10 the COM1x[1:0] is made 1 on compare match between **TCNT1** and TOP when upcounting and made 0 on compare match between **TCNT1** and TOP when downcounting.
- In Non-Inverting Compare Mode COM1x[1:0] == 11, the OC0x pins is made 0 on compare match between **TCNT1** and TOP when upcounting AND made 1 on compare match between **TCNT1** and TOP when down-counting.
- The Timer/Counter overflow flag (TOV1) is set each time the counter reaches BOTTOM.
- The interrupt flag can be used to generate an interrupt each time the counter reaches the BOTTOM value.
- The PWM frequency is given by

$$f_{OC1xPWM} = \frac{f_{clkT1}}{2*N*TOP}$$

6 Register Description

TCCR1A – Timer/Counter 1 Control Register A

7	6	5	4	3	2	1	0	
COM1A1	COM1A0	COM1B1	COM1B0	-	-	WGM11	WGM10	

COM1x[1:0]	Non-PWM modes	Fast PWM	Phase Corrected PWM & Phase and Frequency Corrected PWM
00	No output @ <i>PB1 - OC1A</i>	No output @ $PB1 - OC1A$ or	No output @ <i>PB1 - OC1A</i> or
	or $PB2$ - $OC1B$ pin	PB2 - OC1B pin	PB2 - OC1B pin
01	Toggle $PB1$ - $OC1A$ or	When $WGM[3:0] == 1110$	When $WGM[3:0] == 1110$
	PB2 - OC1B pin on com-	or 1111, Toggle $OC1A$ pin on	or 1111, Toggle <i>OC1A</i> pin on
	pare Match.	compare match	comapre match.
10	Clear $PB1$ - $OC1A$ or $PB2$	Clear $PB1 - OC1A$ or $PB2 -$	Clear $PD5 - OC0B$ on compare
	- OC1B pin on compare	OC1B on compare match and	match when up-counting and set
	Match.	set $PB1 - OC1A$ or $PB2 -$	<i>PB1 - OC1A</i> or <i>PB2 - OC1B</i>
		OC1B at BOTTOM	on compare match when down-
			counting.
11	Set <i>PB1</i> - <i>OC1A</i> or <i>PB2</i>	Set $PB1 - OC1A$ or $PB2 -$	Set $PD5$ - $OC0B$ on compare
	- OC1B pin on compare	OC1B on compare match and	match when up-counting and
	Match.	clear $PB1$ - $OC1A$ or $PB2$ -	clear $PB1$ - $OC1A$ or $PB2$ -
		OC1B at BOTTOM	OC1B on compare match when
			down-counting.

WGM1[3:0]	Mode of operation	TOP	TOV1 Flag set on
0000	Normal	0xFFFF	MAX
0001	PWM Phase corrected – 8bit	0x00FF	BOTTOM
0010	PWM Phase corrected – 9bit	0x01FF	BOTTOM
0011	PWM Phase corrected – 10bit	0x03FF	BOTTOM
0100	CTC	OCR1A	MAX
0101	$Fast\ PWM-8bit$	0x00FF	TOP
0110	Fast PWM - 9bit	0x01FF	TOP
0111	$Fast\ PWM-10bit$	0x03FF	TOP
1000	PWM, phase and frequency corrected	ICR1	BOTTOM
1001	PWM, phase and frequency corrected	OCR1A	BOTTOM
1010	PWM, phase corrected	ICR1	BOTTOM
1011	PWM, phase corrected	OCR1A	BOTTOM
1100	CTC	ICR1	MAX
1110	Fast PWM	ICR1	TOP
1111	Fast PWM	OCR1A	TOP

TCCR1B - Timer/Counter1 Control Register B

7	6	5	4	3	2	1	0
ICNC1	ICES1	-	WGM13	WGM12	CS12	CS11	CS10

- \bullet ICNC1 Input Capture Noise Canceler activates the input capture noise canceler.
- *ICES1 Input Capture Edge Select -* selects which edge on the input capture pin (*ICP1*) that is used to trigger a capture event. [1 Rising edge; 0 falling edge;]

	C C	011 100 101 110 Extern	$clk_{I/d}$	O – no prescalin $\frac{\frac{clk_{I/O}}{8}}{\frac{clk_{I/O}}{6}}$	ng					
	C 	011 100 101 110 Extern		$\overline{clk_{I/O}^8}$						
	- - - -	100 101 110 Extern			$\frac{10}{200}$					
	- - -	101 110 Exteri		$\frac{100}{clk_{I/O}}$						
	-	110 Extern		$\frac{clk_{I/O}}{256}$ $clk_{I/O}$						
			anl clock source	1024	ock on falling edge	2				
					ock on rising edge					
		•		•	0 0					
CNT1H - Time	r/Counte	er1 Counter l	Higher Byte							
7	6	5	4	3	2	1	0			
			TCNT	1[15:8]						
CCNT1L – Timer	·/Counto	vil Counton I	ower Bute							
7	6	5	4	3	2	1	0			
•		<u>.</u>			<u> </u>		<u> </u>			
			TCNT	1[1:0]						
OCR1AH – Outp	ut Comp	are Register	1 A Higher E	Byte						
7	6	5	4	3	2	1	0			
		-	OCR1A							
			001111	1[10.0]						
OCR1AL – Outpu	ut Comp	are Register	1 A Lower By	vte						
OCR1AL – Outpo	ut Comp	are Register	1 A Lower By	aute	2	1	0			
				3	2	1	0			
			4	3	2	1	0			
7	6	5	4 OCR1.	3 A[7:0]	2	1	0			
7	6	5	4 OCR1.	3 A[7:0]	2	1	0			
7 CR1BH – Outp	6 ut Comp	5 eare Register	4 OCR1 1 B Higher B	3 A[7:0] Syte 3						
7 OCR1BH – Outp	6 ut Comp	5 eare Register	4 OCR1	3 A[7:0] Syte 3						
7 OCR1BH – Outp 7	6 ut Comp	5 eare Register 5	4 OCR1 1 B Higher B 4 OCR1	3 A[7:0] Syte 3 B[15:8]						
7 OCR1BH – Outp	6 ut Comp	5 eare Register 5	4 OCR1 1 B Higher B 4 OCR1	3 A[7:0] Syte 3 B[15:8]						
7 OCR1BH – Outp 7	6 ut Comp	5 eare Register 5	4 OCR1 1 B Higher B 4 OCR1	3 A[7:0] Syte 3 B[15:8]						
7 OCR1BH – Outp 7 OCR1BL – Outpu	6 ut Comp	5 oare Register 5 are Register	4 OCR1 1 B Higher B 4 OCR1 1 B Lower By	3 A[7:0] Syte 3 B[15:8]	2	1	0			
7 OCR1BH – Outp 7 OCR1BL – Outpu	6 ut Comp	5 oare Register 5 are Register	4 OCR1 1 B Higher B 4 OCR1 1 B Lower By	3 A[7:0] Syte 3 B[15:8]	2	1	0			
7 OCR1BH – Outp 7 OCR1BL – Outpu	6 ut Comp	5 oare Register 5 are Register	4 OCR1 1 B Higher B 4 OCR1 1 B Lower By	3 A[7:0] Syte 3 B[15:8]	2	1	0			
7 OCR1BH – Outp	ut Comp	5 eare Register 5 eare Register 5	4 OCR1 1 B Higher B 4 OCR1 1 B Lower By 4 OCR1	3 A[7:0] Syte 3 B[15:8]	2	1	0			
7 OCR1BH – Outp 7 OCR1BL – Outpu	ut Comp	5 eare Register 5 eare Register 5	4 OCR1 1 B Higher B 4 OCR1 1 B Lower By 4 OCR1	3 A[7:0] Syte 3 B[15:8]	2	1	0			

 $\frac{\textbf{Description(Prescalar)}}{\text{No clock source(Timer/Counter Stopped)}}$

CS1[2:0] 000

ICR1L - Input Capture Register 1 Lower Byte

7	6	5	4	3	2	1	0	
ICR1[7:0]								

TIMSK1 – Timer/Counter 1 Interrupt Mask Register

7	6	5	4	3	2	1	0
-	-	ICIE1	-	-	OCIE1B	OCIE1A	TOIE1

Enable interrupts for compare match between **TCNT1** and **OCR1A** or **TCNT1** and **OCR1B** or overflow in **TCNT1** or Input capture interrupt enable.

TIFR1 - Timer/Counter 1 Interrupt Flag Register

7	6	5	4	3	2	1	0
-	-	ICF1	-	-	OCIE1B	OCIE1A	TOIE1

Flag registers for interrupts on compare match between $\mathbf{TCNT0}$ and $\mathbf{OCR0A}$ or $\mathbf{TCNT0}$ and $\mathbf{OCR0B}$ or overflow in $\mathbf{TCNT1}$ or capture event occurs on the $\mathbf{\mathit{ICP1}}$ pin .


7 Configuring the Timer/Counter

7.1 Normal Mode

7.1.1 As Timer

$$ON_TIME = \frac{max_count}{\frac{F_CPU}{PRESCALAR}}$$

- Depending on PRESCALR value, we get different ON_TIME.
- First, WGM1[3:0] bits are configured as 0000 for Normal Mode in TCCR1A and TCCR1B registers.
- Next, COM1A[1:0] and/or COM1A[1:0] bits are configured to make outputs OC1A and/or OC1B pins to do nothing, set, clear or toggle in TCCR1A register.
- Next, Interrupt is Enabled by *TOIE1* (overflow enable) in *TIMSK1* reigster.
- Finally, Timer is started by setting prescalar in CS1[2:0] bits as needed prescalar of TCR1B reigster.
- Global Interrupt is enabled.
- A interrupt Service Routine for Timer1 overflow is Written.
- No need to clear the overflow flag as it is done by hardware.
- The timing when both pins OC1A and OC1B are made to toggle.



• The code can be seen below,

```
// MOde of operation to Normal Mode -- WGM1[3:0] === 0000
// WGM1[3](bit4) from TCCR1B, WGM1[2](bit3) from TCCR1B, WGM1[1](bit1) from TCC1RA, WGM1[0](bit0)

→ from TCCR1A
TCCR1A = TCCR1A & ~(1<<WGM10);
TCCR1A = TCCR1A & ~(1<<WGM11);
TCCR1B = TCCR1B & ~(1<<WGM12);</pre>
```

```
TCCR1B = TCCR1B \& ~(1 << WGM13);
/* What to do when timer reaches the MAX(OxFFFF) value */
// toggle OC1A on each time when reaches the MAX(OxFFFF)
// which is reflected in PB1
// Output OC1A to toglle when reaches MAX -- COM1A[1:0] === 01
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A \& ~(1 << COM1A1);
TCCR1A = TCCR1A | (1<<COM1A0);</pre>
// toggle OC1B on each time when reaches the MAX(OxFFFF)
// which is reflected in PB2
// Output OC1B to toglle when reaches MAX -- COM1B[:0] === 01
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A \& ~(1 << COM1B1);
TCCR1A = TCCR1A | (1<<COM1B0);
//Enable Interrupt of OVERFLOW flag so that interrupt can be generated
TIMSK1 = TIMSK1 | (1 << TOV1);
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B \mid (1 << CS10);
TCCR1B = TCCR1B \& ~(1 << CS11);
TCCR1B = TCCR1B \& ~(1 << CS12);
// enabling global interrupt
sei();
// SO ON TIME = max_count / (F_CPU / PRESCALAR)
// ON TIME = 0xFFFFF / (16000000/1) = 4.096ms
// since symmetric as toggling OFF TIME = 4.096ms
// hence, we get a square wave of fequency 1 / 8.192ms = 122.07Hz
```

7.1.2 As Counter

- Every rising/falling edge the count increases.
- So to reach 0xFFFF count, it would take a time of $\frac{0xFFFF}{frequency@T1pin}$.
- First, WGM1[3:0] bits are configured as 0000 for Normal Mode in TCCR1A and TCCR1B registers.
- Finally, Counter is started by configuring CS1[2:0] bits to 110 or 111 for external falling or rising edge on T1 -PD5.
- The code when T1 pin is used as counter @ falling edge.

```
// MOde of operation to Normal Mode -- WGM1[3:0] === 0000
// WGM1[3](bit4) from TCCR1B, WGM1[2](bit3) from TCCR1B, WGM1[1](bit1) from TCC1RA, WGM1[0](bit0)

-- from TCCR1A
TCCR1A = TCCR1A & ~(1<<WGM10);
TCCR1B = TCCR1B & ~(1<<WGM11);
TCCR1B = TCCR1B & ~(1<<WGM12);
TCCR1B = TCCR1B & ~(1<<WGM13);

/* to count external event -we must connect source to T1 (PD5) */
// THE CLK IS CLOCKED FROM external source
// Falling edge of T1(PD5) -- CS1[2:0] === 110
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B & ~(1<<CS10);</pre>
```

```
TCCR1B = TCCR1B | (1<<CS11);
TCCR1B = TCCR1B | (1<<CS12);
```

7.1.3 As Input Capture

- Capture the value of **TCNT1** into **ICR1** register when there is rising or falling edge.
- First, WGM1[3:0] bits are configured as 0000 for Normal Mode in TCCR1A and TCCR1B registers.
- Next, the falling or rising edge for the *ICP1* pin is selected by *ICES1* bit in **TCCR1B**.
- The interrupts for input capture is enabled by setting the *ICIE1* bit in **TIMSK1**.
- A interrupt service routing is written.
- Finally, Timer is started by setting prescalar in CS1/2:0 bits as needed prescalar of TCR1B reigster.
- The code when *ICP1 PB0* pin is used as capture @ rising edge.

```
// MOde of operation to Normal Mode -- WGM1[3:0] === 0000
// WGM1[3](bit4) from TCCR1B, WGM1[2](bit3) from TCCR1B, WGM1[1](bit1) from TCC1RA, WGM1[0](bit0)
→ from TCCR1A
TCCR1A = TCCR1A \& ~(1 << WGM10);
TCCR1A = TCCR1A \& ~(1 << WGM11);
TCCR1B = TCCR1B \& ~(1 << WGM12);
TCCR1B = TCCR1B \& ~(1 << WGM13);
// Select the edge for Input Capture
// ICES1(bit6) from TCCR1B
// Capture on Rising edge, ICES1 === 1
TCCR1B |= (1<<ICES1);
//Enable Interrupt of Input Capture Interrupt Enable so that interrupt can be generated
TIMSK1 = TIMSK1 | (1<<ICIE1);
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B | (1<<CS10);
TCCR1B = TCCR1B & ^{\sim} (1<<CS11);
TCCR1B = TCCR1B \& ~(1 << CS12);
// enabling global interrupt
sei();
ISR(TIMER1_CAPT_vect)
        if((TIFR1 & (1<<ICF1)) != 0)
        {
                capVal = ICR1L;
                capVal = (ICR1H<<8) | (capVal & OxFF);</pre>
                // see datamemory
        }
}
```

7.1.4 Application I - Delay

```
/* TCNT1 starts from OXO000 goes upto OXFFFF and restarts */
/* No possible use case as it just goes upto OxFFFF and restarts */
// MOde of operation to Normal Mode -- WGM1[3:0] === 0000
```


```
// WGM1[3](bit4) from TCCR1B, WGM1[2](bit3) from TCCR1B, WGM1[1](bit1) from TCC1RA, WGM1[0](bit0)
\hookrightarrow from TCCR1A
TCCR1A = TCCR1A & ~(1 << WGM10);
TCCR1A = TCCR1A & ~(1<<WGM11);
TCCR1B = TCCR1B \& ~(1 << WGM12);
TCCR1B = TCCR1B \& ~(1 << WGM13);
/* What to do when timer reaches the MAX(OxFFFF) value */
// nothing should be done on OC1A for delay
// nothing -- COM1A[1:0] === 00
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A & ~(1<<COM1A1);
TCCR1A = TCCR1A \& ~(1 << COM1AO);
/* The delay possible = Oxffff / (F_CPU/prescalar) */
// lowest delay = 0xffff / (16000000 / 1) = 4.096ms
// when prescalar == 8 --> delay = 0xffff / (16000000 / 8) = 32.768ms
// when prescalar == 64 --> delay = 0xffff / (16000000 / 64) = 262.144ms
// when prescalar == 256 --> delay = 0xffff / (16000000 / 256) = 1.048576s
//\ highest\ delay\ possible = 0xffff\ /\ (16000000\ /\ 1024) = 4.194304s
// start timer by setting the clock prescalar
// divede by 64 from I/O clock
// divede by 64-- CS1[2:0] === 101
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B \mid (1 << CS10);
TCCR1B = TCCR1B \mid (1 << CS11);
TCCR1B = TCCR1B \& ~(1 << CS12);
// actual delaying - wait until delay happens
while((TIFR1 & 0x01) == 0x00); // checking overflow flag when overflow happns
// clearing the overflag so that we can further utilize
TIFR1 = TIFR1 \mid OxO1;
```

7.2 CTC Mode

7.2.1 As Timer

$$ON_TIME = \frac{1 + OCR1A}{\frac{F_CPU}{PRESCALAR}}$$

- Depending on OCR1A register and/or ICR1 register and PRESCALR value, we get different ON_TIME.
- First, WGM1[3:0] bits are configured as 0100 or 1100 for CTC Mode in TCCR2A and TCCR1B registers.
- Next, COM1A[1:0] and/or COM1B[1:0] bits are configured to make outputs OC1A and/or OC1B pins to do nothing, set, clear or toggle in TCCR0A register.
- Next, Interrupt is Enabled by OCIE1A (output compare on match on OCR1A register enable) in TIMSK1 reigster.
- Finally, Timer is started by setting prescalar in CS1[2:0] bits as needed prescalar of TCR1B reigster.
- Global Interrupt is enabled.
- A interrupt Service Routine for Timer1 compare is Written.
- No need to clear the overflow flag as it is done by hardware.
- The timing when both pins *OC1n* are made to toggle.



• The code can be seen below,

```
// WGM1[3](bit4) from TCCR1B, WGM1[2](bit3) from TCCR1B, WGM1[1](bit1) from TCC1RA, WGM1[0](bit0)
→ from TCCR1A
// we take TOP to be OCR1A for custom frequency
TCCR1A = TCCR1A \& ~(1 << WGM10);
TCCR1A = TCCR1A \& ~(1 << WGM11);
TCCR1B = TCCR1B \mid (1 << WGM12);
TCCR1B = TCCR1B \& ~(1 << WGM13);
/* What to do when timer reaches the OCR1A value */
// toggle OC1A on each time when reaches the OCR1A
// which is reflected in PB1
// Output OC1A to toglle when reaches OCR1A -- COM1A[1:0] === 01
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1AO);
TCCR1A = TCCR1A \& ~(1 << COM1A1);
// toggle OC1B on each time when reaches the OCR1A
// which is reflected in PB2
// Output OC1B to toglle when reaches OCR1A -- COM1B[1:0] === 01
// COM1B[1](bi57) from TCCR1A, COM1B[0](bit64) from TCCR1A
TCCR1A = TCCR1A \mid (1 << COM1B0);
TCCR1A = TCCR1A \& ~(1 << COM1B1);
// Enable Interrupt when counter matches OCR1A Rgister
// OCIE1A bit is enabled
TIMSK1 = TIMSK1 | (1<<OCIE1A);</pre>
// setting the value till the counter should reach in OCR1A
// for toggling of OC1A pin
OCR1A = 0x4861;
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B \mid (1 << CS10);
TCCR1B = TCCR1B \& ~(1 << CS11);
TCCR1B = TCCR1B & ^{\sim}(1<<CS12);
// enabling global interrupt
sei();
// SO ON TIME = (1 + OCR1A) / (F_CPU / PRESCALAR)
// ON TIME = 0x4861 / (16000000/1) = 1.15ms
// since symmetric as toggling OFF TIME = 1.15ms
// hence, we get a square wave of fequency 1 / 2.31ms = 431Hz
ISR(TIMER1_COMPA_vect)
{
    // do the thing when overflows.
```

// MOde of operation to Normal Mode -- WGM1[3:0] === 0100(TOP = OCR1A) or 1100(TOP = ICR1)

7.2.2 As Counter

- Every rising/falling edge the count increases.
- So to reach required count, it would take a time of $\frac{OCR1A}{frequency@T1pin}$.
- First, WGM1[3:0] bits are configured as 0100 or 1100 for CTC Mode in TCCR2A and TCCR1B registers.

- Finally, Counter is started by configuring CS1[2:0] bits to 110 or 111 for external falling or rising edge on T1 PD5 pin.
- The code when *T1* pin is used as counter @ falling edge.

```
// MOde of operation to Normal Mode -- WGM1[3:0] === 0100(TOP = OCR1A) or 1100(TOP = ICR1)
// WGM1[3](bit4) from TCCR1B, WGM1[2](bit3) from TCCR1B, WGM1[1](bit1) from TCC1RA, WGM1[0](bit0)
→ from TCCR1A
TCCR1A = TCCR1A \& ~(1 << WGM10);
TCCR1A = TCCR1A \& ~(1 << WGM11);
TCCR1B = TCCR1B | (1<<WGM12);</pre>
TCCR1B = TCCR1B \& ~(1 << WGM13);
/* What to do when timer reaches the OCR1A value */
// toggle OC1A on each time when reaches the OCR1A
// which is reflected in PB1
// Output OC1A to toglle when reaches OCR1A -- COM1A[1:0] === 01
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1AO);
TCCR1A = TCCR1A \& ~(1 << COM1A1);
//we count till OCR1A register value and toggle
// lets' count 10 pulses
OCR1A = Ox000a;
/* to count external event -we must connect source to T1 (PD5) */
// THE CLK IS CLOCKED FROM external source
// Falling edge of T1(PD5) -- CS1[2:0] === 110
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B & ^{\sim} (1<<CS10);
TCCR1B = TCCR1B | (1<<CS11);
TCCR1B = TCCR1B \mid (1 << CS12);
// since for every rising edge the count increase
// so to reach 10 count, it would take Oxa / (frequency of input at T1 pin or PD5)
// we wave used 5kHz so it would take ==> 2ms to toggle as we have made OC1A toggle when overflows
→ (by setting COMA[1:0])
// also we canuse TCNT1 as edge counter
```

7.3 Application I - Delay

```
// minimum delay being 4us -- choose like that - because, of the the delay for execution, - we get
\rightarrow us if we use toggling of pins OC1A or OC1B
// use PRESCALAR OF 1 -- 4us - 4.096ms -- usage 4us - 4ms -- factor=0 -- CS1[2:0]=1
// use PRESCALAR OF 8 -- 4us - 32.768ms -- usage 5ms - 32ms -- factor=3 -- CS1[2:0]=2
// use PRESCALAR OF 64 -- 4us - 262.144ms -- usage 33ms - 260ms -- factor=6 -- CS0[2:0]=3
// use PRESCALAR OF 256 -- 16us - 1.048s -- usage 261ms - 1.048s -- factor=8 -- CS0[2:0]=4
/* TCNT1 starts from OX0000 goes upto OCR1A or ICR1 and restarts */
// MOde of operation to Normal Mode -- WGM1[3:0] === 0100(TOP = OCR1A) or 1100(TOP = ICR1)
// WGM1[3](bit4) from TCCR1B, WGM1[2](bit3) from TCCR1B, WGM1[1](bit1) from TCC1RA, WGM1[0](bit0)
→ from TCCR1A
// we take TOP to be OCR1A for custom frequency
TCCR1A = TCCR1A \& ~(1 << WGM10);
TCCR1A = TCCR1A \& ~(1 << WGM11);
TCCR1B = TCCR1B | (1<<WGM12);</pre>
TCCR1B = TCCR1B \& ~(1 << WGM13);
/* What to do when timer reaches the MAX(OxFFFF) value */
```

```
// nothing should be done on OC1A for delay
// nothing -- COM1A[1:0] === 00
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A \& ~(1 << COM1A1);
TCCR1A = TCCR1A \& ~(1 << COM1AO);
if(delay_in_us <=3)</pre>
    // if delay_in_us <= 3us -- so we stop clock
    OCR1A = 0;
    // stop clcok
    // stop clcok-- CS1[2:0] === 000
    // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
    TCCR1B = TCCR1B \& ~(1 << CS10);
    TCCR1B = TCCR1B & ~(1<<CS11);
    TCCR1B = TCCR1B \& ~(1 << CS12);
}
else if((3 < delay_in_us) && (delay_in_us <= 4000))
    OCR1A = ((delay_in_us * 16) >> 0) - 1;
    // start timer by setting the clock prescalar
    // SAME AS from I/O clock
    // same-- CS1[2:0] === 001
    // CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B
    TCCR1B = TCCR1B | (1<<CS10);
    TCCR1B = TCCR1B \& ~(1 << CS11);
    TCCR1B = TCCR1B \& ~(1 << CS12);
}
else if((4000 < delay_in_us) && (delay_in_us <= 32000))
{
    OCR1A = ((delay_in_us * 16) >> 3) - 1;
    // start timer by setting the clock prescalar
    // divide by 8 from I/O clock
    // divide by 8 CS1[2:0] === 010
    // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
    TCCR1B = TCCR1B \& ~(1 << CS10);
    TCCR1B = TCCR1B \mid (1 << CS11);
    TCCR1B = TCCR1B \& ~(1 << CS12);
}
else if((32000 < delay_in_us) && (delay_in_us <= 260000))
{
    OCR1A = ((delay_in_us * 16) >> 6) - 1;
    // start timer by setting the clock prescalar
    // divide by 64 from I/O clock
    // divide by 64 CS1[2:0] === 011
    // CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B
    TCCR1B = TCCR1B \mid (1 << CS10);
    TCCR1B = TCCR1B | (1<<CS11);
    TCCR1B = TCCR1B \& ~(1 << CS12);
}
else if((260000 < delay_in_us) && (delay_in_us <= 1000000))
{
    OCR1A = ((delay_in_us * 16) >> 8) - 1;
    // start timer by setting the clock prescalar
    // divide by 256 from I/O clock
    // divide by 256 CS1[2:0] === 100
    // CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B
    TCCR1B = TCCR1B \& ~(1 << CS10);
    TCCR1B = TCCR1B \& ~(1 << CS11);
    TCCR1B = TCCR1B | (1<<CS12);
```

```
else if(delay_in_us > 1000000)
{
    Timer1_asDelayIn_us(delay_in_us - 1000000);
    OCR1A = ((1000000 * 16) >> 8) - 1;
    // start timer by setting the clock prescalar
    // divide by 256 from I/O clock
    //divide by 256 CS1[2:0] === 100
    // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
    TCCR1B = TCCR1B \& ~(1 << CS10);
    TCCR1B = TCCR1B & ^{\sim} (1<<CS11);
    TCCR1B = TCCR1B | (1<<CS12);</pre>
}
// actual delaying - wait until delay happens
while((TIFR1 & 0x02) == 0x00); // checking OCF1A (compare match flag A) flag when match happns
// clearing the compare match flag so that we can further utilize
TIFR1 = TIFR1 \mid 0x02;
```


7.4 Fast PWM Mode

```
ISR(TIMER1_OVF_vect)
{
}
ISR(TIMER1_COMPA_vect)
{
}
ISR(TIMER1_COMPB_vect)
{
}
```

7.4.1 Non-Inverting PWM with TOP at MAX(0x00FF or 0x01FF or 0x03FF)

Frequency is chosen by PRESCALAR and Duty cycle by OCR1A and/or OCR1B register.

- First, WGM1[3:0] bits are configured as 0101 or 0110 or 0111 for Fast PWM Mode with TOP at MAX in TCCR1A and TCCR1B registers.
- Next, COM1A[1:0] and/or COM1B[1:0] bits of TCCR1A register are configured to make outputs OC1A and/or OC01 pins to generate PWM by comparing between OCR1A and/or OCR1B respectively. That is for Non-Inverting, COM1x[1:0] is written 10.
- Next, the duty cycle value is loaded into OCR1A and/or OCR1B register for OC1A and/or OC1B pins.
- Also, the *OCIE1A* and/or *OCIE1B* bits of **TIMSK1** register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match and/or overflow.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for PWM on 10% duty cycle OC1A and 75% duty cycle OC1B pins are shown assuming.
 - WGM1[3:0] === 0111 TOP equals 0x03FF
 - 0x66 for OCR1A.
 - 0x2FF for OCR1B.



```
/* TCNT1 starts from OXOOOO goes upto TOP and restarts from OXOO*/
/* Mode of operation:
    WGM1[3:0] --> 0101 --
                                 TOP--> OXOOFF
    WGM1[3:0] --> 0110 --
                                  TOP--> 0x01FF
                                 TOP--> 0x03FF
    WGM1[3:0] --> 0111 --
    WGM1[3:0] --> 1110 --
                                 TOP--> ICR1
    WGM1[3:0] --> 1111 --
                                 TOP--> OCR1A
// we take 0x03FF for fixed frequency and OCR1B for PWM on time(duty cycle)
// choose WGM1[3:0] --> 0111 for OCR1A as TOP for custom frequency
TCCR1A = TCCR1A | (1 << WGM10);
TCCR1A = TCCR1A | (1<<WGM11);</pre>
TCCR1B = TCCR1B | (1<<WGM12);
TCCR1B = TCCR1B \& ~(1 << WGM13);
// here we set COMOA[1:0] as 10 for non-inverting
// here we set COMOB[1:0] as 10 for non-inverting
// which is reflected in PD6
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1A1);</pre>
TCCR1A = TCCR1A & ~(1 << COM1AO);
// which is reflected in PD65
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1B1);</pre>
TCCR1A = TCCR1A \& ~(1 << COM1B0);
// Enable Interrupt when TOV1 overflows TOP - here 0x03FF
// TOIE1 bit is enabled
TIMSK1 = TIMSK1 | (1<<TOIE1);</pre>
/* we use OCF1A flag - which is set at every time TCNO reaches OCR1A */
TIMSK1 = TIMSK1 | (1<<OCIE1A);</pre>
/* we use OCF1B flag - which is set at every time TCNO reaches OCR1B */
TIMSK1 = TIMSK1 | (1<<0CIE1B);</pre>
// Next we set values for OCR1A and OCR2B
// Since, TCNT1 goes till\ max(Ox3FF), we can choose OCR1A and OCR1B to any value below max(Ox03FF)
OCR1A = 102; // for 10% duty clcle
OCR1B = 767; // for 75% duty clcle
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B \mid (1 << CS10);
TCCR1B = TCCR1B \& ~(1 << CS11);
TCCR1B = TCCR1B \& ~(1 << CS12);
//enabled global interrupt
sei();
```


7.4.2 Inverting PWM with TOP at MAX(0x00FF or 0x01FF or 0x03FF)

Frequency is chosen by PRESCALAR and Duty cycle by OCR1A and/or OCR1B register.

- First, WGM1[3:0] bits are configured as 0101 or 0110 or 0111 for Fast PWM Mode with TOP at MAX in TCCR1A and TCCR1B registers.
- Next, COM1A[1:0] and/or COM1B[1:0] bits of TCCR1A register are configured to make outputs OC1A and/or OC01 pins to generate PWM by comparing between OCR1A and/or OCR1B respectively. That is for

Inverting, COM1x/1:0 is written 11.

- Next, the duty cycle value is loaded into OCR1A and/or OCR1B register for OC1A and/or OC1B pins.
- Also, the *OCIE0A* and/or *OCIE0B* bits of **TIMSK0** register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match and/or overflow.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for PWM on 10% duty cycle OC1A and 75% duty cycle OC1B pins are shown assuming.
 - WGM1[3:0] === 0111 TOP equals 0x03FF
 - -0x66 for OCR1A.
 - 0x2FF for OCR1B.




```
/* TCNT1 starts from OX0000 goes upto TOP and restarts from OX00*/
/* Mode of operation:
    WGM1[3:0] --> 0101 --
                                  TOP--> OXOOFF
    WGM1[3:0] --> 0110 --
                                  TOP--> Ox01FF
    WGM1[3:0] --> 0111 --
                                  TOP--> 0x03FF
    WGM1[3:0] --> 1110 --
                                  TOP--> ICR1
    WGM1[3:0] --> 1111 --
                                  TOP--> OCR1A
// we take 0x03FF for fixed frequency and OCR1B for PWM on time(duty cycle)
// choose WGM1[3:0] --> 0111 for OCR1A as TOP for custom frequency
TCCR1A = TCCR1A | (1<<WGM10);</pre>
TCCR1A = TCCR1A | (1<<WGM11);</pre>
TCCR1B = TCCR1B | (1<<WGM12);</pre>
TCCR1B = TCCR1B \& ~(1 << WGM13);
// here we set COMOA[1:0] as 11 for inverting
// here we set COMOB[1:0] as 11 for inverting
// which is reflected in PD6
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1A1);</pre>
TCCR1A = TCCR1A | (1<<COM1A0);
// which is reflected in PD65
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1B1);
TCCR1A = TCCR1A | (1<<COM1BO);
// Enable Interrupt when TOV1 overflows TOP - here 0x03FF
// TOIE1 bit is enabled
TIMSK1 = TIMSK1 | (1<<TOIE1);</pre>
/* we use OCF1A flag - which is set at every time TCNO reaches OCR1A */
TIMSK1 = TIMSK1 | (1<<0CIE1A);</pre>
/* we use OCF1B flag - which is set at every time TCNO reaches OCR1B */
TIMSK1 = TIMSK1 | (1<<0CIE1B);</pre>
// Next we set values for OCR1A and OCR2B
// Since, TCNT1 goes till max(0x3FF), we can choose OCR1A and OCR1B to any value below max(0x03FF)
OCR1A = 102; // for 10% duty clcle
OCR1B = 767; // for 75% duty clcle
```

```
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B | (1<<CS10);
TCCR1B = TCCR1B & ~(1<<CS11);
TCCR1B = TCCR1B & ~(1<<CS12);
//enabled global interrupt
sei();</pre>
```

7.4.3 Non-Inverting PWM with TOP at OCR1A

Frequency is chosen by **OCR1A** and Duty cycle by **OCR1B** register.

- First, WGM1[3:0] bits are configured as 1110 or 1111 for Fast PWM Mode with ICR1 or OCR1A at MAX in TCCR1A and TCCR1B registers.
- Next, COM1B[1:0] bits of TCCR1A register are configured to make output OC1B pins to generate PWM by comparing between TCNT1 and OCR1B. That is for Non-Inverting, COM1B[1:0] is written 10.
- The frequency of duty cycle is loaded into OCR01A register.
- Next, the duty cycle value is loaded into OCR1B register for OC1B bits.
- Also, the *OCIE01B* bits of **TIMSK1** register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for PWM on 37% duty cycle OC1B pins are shown assuming .
 - -0x7869 for OCR0A.
 - 0x1A20 for OCR0B.



```
/* TCNT1 starts from OXOOOO goes upto TOP and restarts from OXOO*/
/* Mode of operation:
    WGM1[3:0] --> 0101 --
                                 TOP--> OXOOFF
    WGM1[3:0] --> 0110 --
                                 TOP--> 0x01FF
    WGM1[3:0] --> 0111 --
                                  TOP--> 0x03FF
    WGM1[3:0] --> 1110 --
                                  TOP--> ICR1
    WGM1[3:0] --> 1111 --
                                  TOP--> OCR1A
// we take DCR1A for custom frequency and DCR1B for PWM on time(duty cycle)
// choose WGM1[3:0] --> 1111 for OCR1A as TOP for custom frequency
TCCR1A = TCCR1A | (1<<WGM10);
TCCR1A = TCCR1A | (1<<WGM11);
TCCR1B = TCCR1B | (1<<WGM12);</pre>
TCCR1B = TCCR1B | (1<<WGM13);
// for non-inverting on OC1B we use 10 for and COM1B[1:0]
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A \& ~(1 << COM1B0);
TCCR1A = TCCR1A | (1<<COM1B1);</pre>
// Next we set values for OCR1A and OCR1B
// Since, TCNT1 goes till OCR1A, we can choose OCR1B to any value below OCR1A
OCR1A = 0x7869; // for frequency
```

```
OCR1B = Ox1A2O; // for pwm duty cylc

// Enable interrupt when count reaches the overflow value
TIMSK1 |= (1<<TOV1);

// Enable interrupt when count reaches the OCR1B
TIMSK1 |= (1<<OCF1B);

// start timer by setting the clock prescalar

// SAME AS from I/O clock

// same-- CS1[2:0] === 001


// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B | (1<<CS10);
TCCR1B = TCCR1B & ~(1<<CS11);
TCCR1B = TCCR1B & ~(1<<CS12);

//e enabel globalinterrupt
sei();</pre>
```

7.4.4 Inverting PWM with TOP at OCR1A

Frequency is chosen by **OCR1A** and Duty cycle by **OCR1B** register.

- First, WGM1[3:0] bits are configured as 1110 or 1111 for Fast PWM Mode with ICR1 or OCR1A at MAX in TCCR1A and TCCR1B registers.
- Next, *COM1B[1:0]* bits of **TCCR1A** register are configured to make output *OC1B* pins to generate PWM by comparing between **TCNT1** and **OCR1B**. That is for Inverting, *COM1B[1:0]* is written 11.
- The frequency of duty cycle is loaded into OCR01A register.
- Next, the duty cycle value is loaded into **OCR1B** register for *OC1B* bits.
- Also, the OCIE01B bits of TIMSK1 register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match.
- Finally, Timer is started by setting CS1/2:0 bit as needed prescalar in TCR1B register.
- The timing for PWM on 37% duty cycle(0x60) OC1B pins are shown assuming.
 - 0x7869 for OCR0A.
 - 0x1A20 for OCR0B.



```
/* TCNT1 starts from OX0000 goes upto TOP and restarts from OX00*/
/* Mode of operation:
    WGM1[3:0] --> 0101 --
                                  TOP--> OXOOFF
    WGM1[3:0] --> 0110 --
                                  TOP--> Ox01FF
    WGM1[3:0] --> 0111 --
                                  TOP--> 0x03FF
    WGM1[3:0] --> 1110 --
                                  TOP--> ICR1
    WGM1[3:0] --> 1111 --
                                  TOP--> OCR1A
// we take OCR1A for custom frequency and OCR1B for PWM on time(duty cycle)
// choose WGM1[3:0] --> 1111 for OCR1A as TOP for custom frequency
TCCR1A = TCCR1A \mid (1 << WGM10);
TCCR1A = TCCR1A | (1<<WGM11);
TCCR1B = TCCR1B | (1<<WGM12);
TCCR1B = TCCR1B | (1<<WGM13);</pre>
// for ninverting on OC1B we use 11 for and COM1B[1:0]
```

```
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1B0);
TCCR1A = TCCR1A | (1<<COM1B1);</pre>
// Next we set values for OCR1A and OCR1B
// Since, TCNT1 goes till OCR1A, we can choose OCR1B to any value below OCR1A
OCR1A = 0x7869; // for frequency
OCR1B = 0x1A20; // for pwm duty cylc
// Enable interrupt when count reaches the overflow value
TIMSK1 |= (1<<TOV1);
// Enable interrupt when count reaches the OCR1B
TIMSK1 \mid = (1<<0CF1B);
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B \mid (1 << CS10);
TCCR1B = TCCR1B \& ~(1 << CS11);
TCCR1B = TCCR1B \& ~(1 << CS12);
//e enabel globalinterrupt
sei();
```

7.4.5 Toggling mode square Wave

Frequency is chosen by **OCR1A** register.

- First, WGM1[3:0] bits are configured as 1111 for Fast PWM Mode with OCR1A at MAX in TCCR1A and TCCR1B registers.
- Next, COM1A[1:0] bits of TCCR1A register are configured to make output OC1A pins to generate PWM by comparing between OCR1A and TCNT1. That is for Toggling square wave COM1A[1:0] is written 01.
- The frequency of duty cycle is loaded into **OCR1A** register.
- Also, the OCIE1A bits of TIMSK1 register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for squared wave on *OC1A* pins are shown assuming.
 - -0x1234 for OCR1A.

```
C1k.T1

TCNT1

OC1A

(0x1034)(0x0000)(0x0001); (0x1234)(0x0000)(0x0001); (0x1234)(0x0000)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x1234)(0x12
```

```
/* TCNT1 starts from OX0000 goes upto TOP and restarts from OX00*/
/* Mode of operation:
WGM1[3:0] --> 0101 --
                              TOP--> OXOOFF
WGM1[3:0] --> 0110 --
                              TOP--> Ox01FF
WGM1[3:0] --> 0111 --
                              TOP--> 0x03FF
WGM1[3:0] --> 1110 --
                              TOP--> ICR1
                              TOP--> OCR1A
WGM1[3:0] --> 1111 --
// we take OCR1A for custom frequency
// choose WGM1[3:0] --> 1111 for OCR1A as TOP for custom frequency
TCCR1A = TCCR1A \mid (1 << WGM10);
TCCR1A = TCCR1A | (1<<WGM11);</pre>
TCCR1B = TCCR1B | (1<<WGM12);
```

```
TCCR1B = TCCR1B | (1<<WGM13);</pre>
// here we set COM1B[1:0] as 01 for toggling of OC1A
// which is reflected in PB1
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A \& ~(1 << 5);
TCCR1A = TCCR1A \mid (1 << 4);
OCR1A = 0x1234; // for frequency
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B | (1<<CS10);
TCCR1B = TCCR1B & ^{\sim} (1<<CS11);
TCCR1B = TCCR1B & ^{\sim} (1<<CS12);
//enabled global interrupt
sei();
}
```

7.4.6 Application I - PWM generation

```
void Timer1_FastPWMGeneration(uint32_t on_time_us, uint32_t off_time_us)
{
        uint32_t total_time = on_time_us + off_time_us;
        /* TCNT1 starts from OX0000 goes upto TOP and restarts from OX00*/
        /* Mode of operation:
                WGM1[3:0] --> 0101 --
                                              TOP--> OXOOFF
                WGM1[3:0] --> 0110 --
                                              TOP--> 0x01FF
                WGM1[3:0] --> 0111 --
                                             TOP--> 0x03FF
                WGM1[3:0] --> 1110 --
                                             TOP--> ICR1
                WGM1[3:0] --> 1111 --
                                              TOP--> OCR1A
        */
        // we take OCR1A for custom frequency and OCR1B for PWM on time(duty cycle)
        // choose WGM1[3:0] --> 1111 for OCR1A as TOP for custom frequency
        TCCR1A = TCCR1A \mid (1 << WGM10);
        TCCR1A = TCCR1A \mid (1 << WGM11);
        TCCR1B = TCCR1B | (1<<WGM12);
        TCCR1B = TCCR1B | (1<<WGM13);</pre>
        // COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
        TCCR1A = TCCR1A | (1<<COM1B0);</pre>
        TCCR1A = TCCR1A | (1<<COM1B1);</pre>
        if(total_time <4)</pre>
        {
                // if total_time <= 3us -- so we stop clock
                OCR1A = 0;
                OCR1B = 0;
                // start timer by setting the clock prescalar
                // use the same clock from I/O clock
                // CS1[2:0] === 001
                 // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
                TCCR1B = TCCR1B \& ~(1<<0);
```

```
TCCR1B = TCCR1B \& ~(1 << 1);
                TCCR1B = TCCR1B & ^{\sim}(1 << 2);
        }
        else if((3 < total_time) && (total_time <= 4000))
                OCR1A = ((total_time * 16) >> 0) - 1;
                OCR1B = ((on_time_us * 16) >> 0) - 1;
                // start timer by setting the clock prescalar
                // use the same clock from I/O clock
                // CS1[2:0] === 001
                // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
                TCCR1B = TCCR1B \mid (1 << 0);
                TCCR1B = TCCR1B \& ~(1 << 1);
                TCCR1B = TCCR1B & ~(1<<2);
        }
        else if((4000 < total_time) && (total_time <= 32000))
                OCR1A = ((total_time * 16) >> 3) - 1;
                OCR1B = ((on_time_us * 16) >> 3) - 1;
                // start timer by setting the clock prescalar
                // dived by 8 from I/O clock
                // CS1[2:0] === 010
                // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
                TCCR1B = TCCR1B & ~(1<<0);
                TCCR1B = TCCR1B \mid (1 << 1);
                TCCR1B = TCCR1B & ^{\sim}(1 << 2);
        else if((32000 < total_time) && (total_time <= 260000))
        {
                OCR1A = ((total_time * 16) >> 6) - 1;
                OCR1B = ((on_time_us * 16) >> 6) - 1;
                // start timer by setting the clock prescalar
                // dived by 64 from I/O clock
                // CS1[2:0] === 011
                // CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B
                TCCR1B = TCCR1B \mid (1 << 0);
                TCCR1B = TCCR1B \mid (1 << 1);
                TCCR1B = TCCR1B \& ~(1 << 2);
        else if((260000 < total_time) && (total_time <= 1000000))
        {
                OCR1A = ((total_time * 16) >> 8) - 1;
                OCR1B = ((on_time_us * 16) >> 8) - 1;
                // start timer by setting the clock prescalar
                // divide by256 from I/O clock
                // CS1[2:0] === 100
                // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
                TCCR1B = TCCR1B & ^{\sim}(1<<0);
                TCCR1B = TCCR1B \& ~(1 << 1);
                TCCR1B = TCCR1B \mid (1 << 2);
        else if(total_time > 1000000)
        {
                // dont' cross more than 1s
        }
void PWMGeneration(double duty_cycle_percent,uint32_t frequency)
        double total_time_us = (1000000.0/frequency);
        double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
        if (on_time_us<1.0)</pre>
```

```
{
            on_time_us = 1;
}

// max time = 1S -- min frequency = 1 Hz
            // min time = 4us -- max frequency = 250000 = 250khz
            Timer1_FastPWMGeneration(on_time_us, total_time_us - on_time_us);
}
```


7.5 Phase Corrected PWM Mode

```
ISR(TIMER1_OVF_vect)
{
}
ISR(TIMER1_COMPA_vect)
{
}
ISR(TIMER1_COMPB_vect)
{
}
```

7.5.1 Non-Inverting PWM with TOP at MAX(0x00FF or 0x01FF or 0x03FF)

Frequency is chosen by PRESCALAR and Duty cycle by OCR1A and/or OCR1B register.

- First, WGM1[3:0] bits are configured as 0001 or 0010 or 0011 for Phase Corrected PWM Mode with TOP at MAX in TCCR1A and TCCR1B registers.
- Next, COM1A[1:0] and/or COM1B[1:0] bits of TCCR1A register are configured to make outputs OC1A and/or OC01 pins to generate PWM by comparing between OCR1A and/or OCR1B respectively. That is for Non-Inverting, COM1x[1:0] is written 10.
- Next, the duty cycle value is loaded into OCR1A and/or OCR1B register for OC1A and/or OC1B pins.
- Also, the OCIE1A and/or OCIE1B bits of TIMSK1 register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for PWM on 10% duty cycle OC1A and 75% duty cycle OC1B pins are shown assuming.
 - WGM1[3:0] === 0011 TOP equals 0x03FF
 - 0x66 for OCR1A.
 - -0x2FF for OCR1B.



```
/* TCNT1 starts from OX0000 goes upto TOP and from TOP to BOTTOM*/

/* Mode of operation:

WGM1[3:0] --> 0001 --

WGM1[3:0] --> 0010 --

WGM1[3:0] --> 0011 --

WGM1[3:0] --> 1010 --

WGM1[3:0] --> 1010 --

WGM1[3:0] --> 1011 --

TOP--> OCR1A

*/

// we take Ox03FF for fixed frequency and OCR1B for PWM on time(duty cycle)

// choose WGM1[3:0] --> 0011 for Ox03FF as TOP for custom frequency

TCCR1A = TCCR1A | (1<<WGM10);
```

```
TCCR1A = TCCR1A | (1<<WGM11);</pre>
TCCR1B = TCCR1B \& ~(1 << WGM12);
TCCR1B = TCCR1B \& ~(1 << WGM13);
/* in timerO_phase_pwm_top_max, only two possiblites are there for COMOB[1:0] and COMOA[1:0] i.e)
→ 10(Inverting) and 11(Non-inverting) */
// here we set COMOA[1:0] as 10 for non-inverting
// here we set COMOB[1:0] as 10 for non-inverting
// which is reflected in PD6
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1A1);</pre>
TCCR1A = TCCR1A & ~(1<<COM1AO);
// which is reflected in PD65
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1B1);</pre>
TCCR1A = TCCR1A \& ~(1 << COM1B0);
// Enable Interrupt when TOV1 overflows TOP - here 0x03FF
// TOIE1 bit is enabled
TIMSK1 = TIMSK1 | (1<<TOIE1);</pre>
/* we use OCF1A flag - which is set at every time TCNO reaches OCR1A */
TIMSK1 = TIMSK1 | (1<<0CIE1A);</pre>
/* we use OCF1B flag - which is set at every time TCNO reaches OCR1B */
TIMSK1 = TIMSK1 | (1<<0CIE1B);</pre>
// Next we set values for OCR1A and OCR2B
// Since, TCNT1 goes till max(0x3FF), we can choose OCR1A and OCR1B to any value below max(0x03FF)
OCR1A = 102; // for 10% duty clcle
OCR1B = 767; // for 75% duty clcle
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B \mid (1 << CS10);
TCCR1B = TCCR1B & ~(1<<CS11);
TCCR1B = TCCR1B \& ~(1 << CS12);
//enabled global interrupt
sei();
```

7.5.2 Inverting PWM with TOP at MAX(0x00FF or 0x01FF or 0x03FF)

Frequency is chosen by PRESCALAR and Duty cycle by OCR1A and/or OCR1B register.

- First, WGM1[3:0] bits are configured as 0001 or 0010 or 0011 for Phase Corrected PWM Mode with TOP at MAX in TCCR1A and TCCR1B registers.
- Next, COM1A[1:0] and/or COM1B[1:0] bits of TCCR1A register are configured to make outputs OC1A and/or OC01 pins to generate PWM by comparing between OCR1A and/or OCR1B respectively. That is for Inverting, COM1x[1:0] is written 11.
- Next, the duty cycle value is loaded into OCR1A and/or OCR1B register for OC1A and/or OC1B pins.
- Also, the OCIE1A and/or OCIE1B bits of TIMSK1 register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for PWM on 10% duty cycle OC1A and 75% duty cycle OC1B pins are shown assuming .

- WGM1[3:0] === 0011 TOP equals 0x03FF
- -0x66 for OCR1A.
- 0x2FF for OCR1B.

```
C1k_T1

TCNT1

Occide


Occide
```

```
/* TCNT1 starts from OXOOOO goes upto TOP and from TOP to BOTTOM*/
/* Mode of operation:
                                  TOP--> OXOOFF
    WGM1[3:0] --> 0001 --
    WGM1[3:0] --> 0010 --
                                  TOP--> 0x01FF
                                  TOP--> 0x03FF
    WGM1[3:0] --> 0011 --
    WGM1[3:0] --> 1010 --
                                  TOP--> ICR1
    WGM1[3:0] --> 1011 --
                                  TOP--> OCR1A
// we take 0x03FF for fixed frequency and <code>OCR1B</code> for PWM on <code>time(duty cycle)</code>
// choose WGM1[3:0] --> 0011 for 0x03FF as TOP for custom frequency
TCCR1A = TCCR1A | (1<<WGM10);</pre>
TCCR1A = TCCR1A | (1<<WGM11);</pre>
TCCR1B = TCCR1B \& ~(1 << WGM12);
TCCR1B = TCCR1B \& ~(1 << WGM13);
/* in timerO_phase_pwm_top_max, only two possiblites are there for COMOB[1:0] and COMOA[1:0] i.e)
   10(Inverting) and 11(Non-inverting) */
// here we set COMOA[1:0] as 11 for inverting
// here we set COMOB[1:0] as 11 for inverting
// which is reflected in PD6
// COM1A[1](bit7) from TCCR1A, COM1A[0](bit6) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1A1);</pre>
TCCR1A = TCCR1A | (1<<COM1AO);
// which is reflected in PD65
// COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
TCCR1A = TCCR1A | (1<<COM1B1);</pre>
TCCR1A = TCCR1A | (1<<COM1B0);
// Enable Interrupt when TOV1 overflows TOP - here 0x03FF
// TOIE1 bit is enabled
TIMSK1 = TIMSK1 | (1<<TOIE1);</pre>
/* we use OCF1A flag - which is set at every time TCNO reaches OCR1A */
TIMSK1 = TIMSK1 | (1<<0CIE1A);
/* we use OCF1B flag - which is set at every time TCNO reaches OCR1B */
TIMSK1 = TIMSK1 | (1<<0CIE1B);</pre>
// Next we set values for OCR1A and OCR2B
// Since, TCNT1 goes till\ max(Ox3FF), we can choose OCR1A and OCR1B to any value below max(Ox03FF)
OCR1A = 102; // for 10% duty clcle
OCR1B = 767; // for 75% duty clcle
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
// CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B | (1<<CS10);</pre>
TCCR1B = TCCR1B \& ~(1 << CS11);
TCCR1B = TCCR1B \& ~(1 << CS12);
//enabled global interrupt
```

7.5.3 Non-Inverting PWM with TOP at OCR1A

Frequency is chosen by **OCR1A** and Duty cycle by **OCR1B** register.

- First, WGM1[3:0] bits are configured as 1011 for Phase Corrected PWM Mode with OCR1A at MAX in TCCR1A and TCCR1B registers.
- Next, COM1B[1:0] bits of TCCR1A register are configured to make output OC1B pins to generate PWM by comparing between OCR1B respectively. That is for Non-Inverting, COM1B[1:0] is written 10.
- The frequency of duty cycle is loaded into OCR1A register.
- Next, the duty cycle value is loaded into **OCR1B** register for *OC1B* bits.
- Also, the *OCIE1B* bits of TIMSK1 register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for PWM on 37% duty cycle OC1B pins are shown assuming .
 - -0x7869 for OCR1A.
 - -0x1A20 for OCR1B.




```
/* TCNT1 starts from OXOOOO goes upto TOP and from TOP to BOTTOM*/
/* Mode of operation:
    WGM1[3:0] --> 0001 --
    TOP--> OXOOFF
    WGM1[3:0] --> 0010 --
    TOP--> OxO1FF
    WGM1[3:0] --> 0011 --
    TOP--> 0x03FF
    WGM1[3:0] --> 1010 --
    TOP--> ICR1
    WGM1[3:0] --> 1011 --
    TOP--> OCR1A
// we take 0x03FF for fixed frequency and OCR1B for PWM on time(duty cycle)
// choose WGM1[3:0] --> 1011 for OCR1A as TOP for custom frequency
TCCR1A = TCCR1A | (1<<WGM10);
TCCR1A = TCCR1A \mid (1 << WGM11);
TCCR1B = TCCR1B \& ~(1 << WGM12);
TCCR1B = TCCR1B | (1<<WGM13);</pre>
// here we set COM1A[1:0] as 10 for non-inverting
// which is reflected in PD5
// COM1B[1](bit5) from TCCR1A, COMOB[0](bit4) from TCCR1A
TCCR1A = TCCR1A \mid (1 << 5);
TCCR1A = TCCR1A \& ~(1 << 4);
// Next we set values for OCR1A and OCR1B
// Since,\ 	extit{TCNT1} goes till\ 	extit{OCR1A},\ 	extit{we}\ 	extit{can}\ 	extit{choose}\ 	extit{OCR1B}\ to\ 	extit{any}\ 	extit{value}\ 	extit{below}\ 	extit{OCR1A}
OCR1A = 0x7869; // for frequency
OCR1B = Ox1A2O; // for pwm duty cylc
// start timer by setting the clock prescalar
// SAME AS from I/O clock
// same-- CS1[2:0] === 001
```

```
// CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B
TCCR1B = TCCR1B | (1<<CS10);
TCCR1B = TCCR1B & ~(1<<CS11);
TCCR1B = TCCR1B & ~(1<<CS12);
//enabled global interrupt
sei();</pre>
```

7.5.4 Inverting PWM with TOP at OCR1A

Frequency is chosen by OCR1A and Duty cycle by OCR1B register.

- First, WGM1[3:0] bits are configured as 1011 for Phase Corrected PWM Mode with OCR1A at MAX in TCCR1A and TCCR1B registers.
- Next, *COM1B[1:0]* bits of **TCCR1A** register are configured to make output *OC1B* pins to generate PWM by comparing between **OCR1B** respectively. That is for Inverting, *COM1B[1:0]* is written 11.
- The frequency of duty cycle is loaded into OCR1A register.
- Next, the duty cycle value is loaded into **OCR1B** register for *OC1B* bits.
- Also, the OCIE1B bits of TIMSK1 register are enabled for Output Compare Interupts if needed.
- The interrupt Service routine is written if needed for compare match.
- Finally, Timer is started by setting CS1[2:0] bit as needed prescalar in TCR1B register.
- The timing for PWM on 37% duty cycle OC1B pins are shown assuming.
 - -0x7869 for OCR1A.
 - -0x1A20 for OCR1B.



```
/* TCNT1 starts from OXOOOO goes upto TOP and from TOP to BOTTOM*/
/* Mode of operation:
    WGM1[3:0] --> 0001 --
    TOP--> OXOOFF
    WGM1[3:0] --> 0010 --
    TOP--> 0x01FF
    WGM1[3:0] --> 0011 --
    TOP--> 0x03FF
    WGM1[3:0] --> 1010 --
    TOP--> ICR1
    WGM1[3:0] --> 1011 --
    TOP--> OCR1A
// we take 0x03FF for fixed frequency and OCR1B for PWM on time(duty cycle)
// choose WGM1[3:0] --> 1011 for OCR1A as TOP for custom frequency
TCCR1A = TCCR1A | (1<<WGM10);
TCCR1A = TCCR1A | (1<<WGM11);
TCCR1B = TCCR1B \& ~(1 << WGM12);
TCCR1B = TCCR1B | (1<<WGM13);
// here we set COM1A[1:0] as 11 for inverting
// which is reflected in PD5
// COM1B[1](bit5) from TCCR1A, COMOB[0](bit4) from TCCR1A
TCCR1A = TCCR1A \mid (1 << 5);
TCCR1A = TCCR1A \mid (1 << 4);
// Next we set values for OCR1A and OCR1B
// Since, TCNT1 goes till OCR1A, we can choose OCR1B to any value below OCR1A
OCR1A = 0x7869; // for frequency
```

```
OCR1B = Ox1A20; // for pwm duty cylc

// start timer by setting the clock prescalar

// SAME AS from I/O clock

// same-- CS1[2:0] === 001

// CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B

TCCR1B = TCCR1B | (1<<CS10);

TCCR1B = TCCR1B & ~(1<<CS11);

TCCR1B = TCCR1B & ~(1<<CS12);

//enabled global interrupt
sei();</pre>
```

7.5.5 Application I - PWM generation

```
void Timer1_PhaseCorrectedPWMGeneration(uint32_t On_time_us, uint32_t Off_time_us)
    // Since, it is dual slope, the time would be doubled for one cylce, so we divide by 2
    uint32_t total_time = (On_time_us>>1) + (Off_time_us>>1);
    uint32_t on_time_us = On_time_us >> 1;
    /* TCNT1 starts from OXOOOO goes upto TOP and from TOP to BOTTOM*/
    /* Mode of operation:
        WGM1[3:0] --> 0001 --
        TOP--> OXOOFF
        WGM1[3:0] --> 0010 --
        TOP--> 0x01FF
        WGM1[3:0] --> 0011 --
        TOP--> 0x03FF
        WGM1[3:0] --> 1010 --
        TOP--> ICR1
        WGM1[3:0] --> 1011 --
        TOP--> OCR1A
    */
    // we take OxO3FF for fixed frequency and OCR1B for PWM on time(duty cycle)
    // choose WGM1[3:0] --> 1011 for OCR1A as TOP for custom frequency
    TCCR1A = TCCR1A | (1<<WGM10);
    TCCR1A = TCCR1A | (1<<WGM11);
    TCCR1B = TCCR1B \& ~(1 << WGM12);
    TCCR1B = TCCR1B | (1<<WGM13);</pre>
    // COM1B[1](bit5) from TCCR1A, COM1B[0](bit4) from TCCR1A
    TCCR1A = TCCR1A | (1<<COM1B0);
    TCCR1A = TCCR1A | (1<<COM1B1);
    if(total_time <4)</pre>
        // if total_time <= 3us -- so we stop clock
        OCR1A = 0;
        OCR1B = 0;
        // start timer by setting the clock prescalar
        // use the same clock from I/O clock
        // CS1[2:0] === 001
        // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
        TCCR1B = TCCR1B \& ~(1<<0);
        TCCR1B = TCCR1B \& ~(1 << 1);
        TCCR1B = TCCR1B \& ~(1 << 2);
    else if((3 < total_time) && (total_time <= 4000))
    {
        OCR1A = ((total_time * 16) >> 0) - 1;
        OCR1B = ((on_time_us * 16) >> 0) - 1;
        // start timer by setting the clock prescalar
```

```
// use the same clock from I/O clock
        // CS1[2:0] === 001
        // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
        TCCR1B = TCCR1B \mid (1 << 0);
        TCCR1B = TCCR1B & ^{\sim}(1 << 1);
        TCCR1B = TCCR1B \& ~(1<<2);
    }
    else if((4000 < total_time) && (total_time <= 32000))
        OCR1A = ((total_time * 16) >> 3) - 1;
        OCR1B = ((on_time_us * 16) >> 3) - 1;
        // start timer by setting the clock prescalar
        // dived by 8 from I/O clock
        // CS1[2:0] === 010
        // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
        TCCR1B = TCCR1B \& ~(1<<0);
        TCCR1B = TCCR1B \mid (1 << 1);
        TCCR1B = TCCR1B & ^{\sim}(1<<2);
    else if((32000 < total_time) && (total_time <= 260000))
    {
        OCR1A = ((total_time * 16) >> 6) - 1;
        OCR1B = ((on_time_us * 16) >> 6) - 1;
        // start timer by setting the clock prescalar
        // dived by 64 from I/O clock
        // CS1[2:0] === 011
        // CS1[2](bit2) from TCCR1B, CS1[1](bit1) from TCCR1B, CS1[0](bit0) from TCCR1B
        TCCR1B = TCCR1B \mid (1 << 0);
        TCCR1B = TCCR1B \mid (1 << 1);
        TCCR1B = TCCR1B \& ~(1 << 2);
    else if((260000 < total_time) && (total_time <= 1000000))
        OCR1A = ((total_time * 16) >> 8) - 1;
        OCR1B = ((on_time_us * 16) >> 8) - 1;
        // start timer by setting the clock prescalar
        // divide by256 from I/O clock
        // CS1[2:0] === 100
        // CS1[2](bit2) from TCCR1B,CS1[1](bit1) from TCCR1B,CS1[0](bit0) from TCCR1B
        TCCR1B = TCCR1B & \sim (1<<0);
        TCCR1B = TCCR1B & ~(1<<1);
        TCCR1B = TCCR1B \mid (1 << 2);
    else if(total_time > 1000000)
    {
        // dont' cross more than 1s
}
void PWMGeneration(double duty_cycle_percent,uint32_t frequuncy)
{
    double total_time_us = (1000000.0/frequency);
    double on_time_us = (duty_cycle_percent/100.0) * total_time_us;
    if (on_time_us<1.0)</pre>
    {
        on_time_us = 1;
    }
    // max time = 8ms -- min frequency = 125 Hz
    // min time = 8us -- max frequency = 250000 = 125khz
    Timer1_PhaseCorrectedPWMGeneration(on_time_us, total_time_us - on_time_us);
}
```