

## Teensy 3.2

I2C: D18/A4(SDA0),D19/A5(SCL0)

PWM: 3,4,5,6,9,10,25(BS),32(BS),D20/A6,D21/A7,D22/A8,D23/A9

Interrupts: all digital pins - D0-D23 & D24-D33(BS)