SIMPLE FLOW RATE

Q = K P 0.5, where

Q = flow rate (GPM)

K = discharge coefficient of pipe

P = pressure (PSI)

GENERAL VOLUMETRIC FLOW RATE

Q = flow rate (GPM)

D = outlet diameter (Inches)

Cd = discharge coefficient based on outlet geometry

P = pressure (PSI)

Q = 29.8 D 2 Cd P 0.5, where

Pressure Tank Sizing (Tank above sprinklers)

P = (30/A) - 15, where

P = air pressure in tank (PSI)

A = proportion of air in the tank

PRESSURE TANK SIZING (TANK BELOW SPRINKLERS)

P = [(30/A) - 15] + (0.43 H/A), where

P = air pressure carried in tank (PSI)

A = proportion of air in the tank

H = height of highest sprinkler above tank bottom (Ft)

Pressure Tank Sizing (Hydraulically calculated)

$$Pi = [(Pf = 15)/A] - 15$$
, where

Pi = tank air pressure to use (PSI)

A = proportion of air in the tank

Pf = system pressure req'd per hydraulic calc. (PSI)

DARCY-WEISBACH FORMULA FOR FRICTION LOSS:

HL = f v 2 / 2 g D, where

HL = friction loss (Ft)

Re = Reynolds number

f = friction factor (f=64/Re)

v = water velocity (Ft/Sec)

g = gravitational constant (Ft/Sec^2)

D = pipe diameter (Ft)

HAZEN-WILLIAMS FORMULA FOR PRESSURE LOSS

 $P = 4.52 \ Q \ 1.85 \ /C \ 1.85 \ D \ 4.87 \ , where:$

P = pressure loss (PSI) per lineal ft.

Q = flow rate (GPM)

C = friction factor of pipe (constant)

D = internal diameter of pipe (Inches)

Typical "C" values:

Unlined cast or ductile iron	100
Black steel (dry sys.incl.preaction)	100
Black steel (wet sys.incl.deluge)	120
Galvanized (all)	120
Plastic (listed) – all	150
Cement lined cast or ductile iron	140
Copper tube or stainless steel	150

HAZEN-WILLIAMS FORMULA FOR PRESSURE LOSS (IN SI UNITS):

P = 10.5 (6.05) Q 1.85 / C 1.85 D 4.87, where

P = pressure loss (Bars) per lineal ft

Q = flow rate (Litre/Min)

C = friction factor of pipe (constant)

D = internal diameter of pipe (mm)

Pressure Velocity:

Pv = 0.001123 Q 2 / D 4, where

Pv = pressure velocity (PSI)

Q = upstream flow rate (GPM)

D = internal dia. of pipe (Inches)

ESTIMATE - DRY PIPE TRIP TIME:

t = 0.0352 (Vt/An TO 0.5) In(pao/pa), where

t = time (seconds)

Vt = dry volume of sprinkler system(Cu. Ft)

An = flow area of open sprinklers (Sq. Ft)

TO = air temperature (Degrees Rankine)

pao = initial air pressure (absolute)

pa = trip pressure (absolute)